

Prepared by	Initials	Date
Checked by		

Check Plans

J-84	J-83	J-82 CONSOLE PRINTER	J-81 DATA COMM	J-80	J-79 SELF SCAN	J-78 Keyboard	J-87
J-75 MINT'S	J-74	J-73	J-72 CONSOLE PRINTER	J-71	J-70	J-69 FDISK	J-60
J-66 Power	J-65	J-64	J-63 Power	J-62	J-61 Power		

Self scan pluss in below - Near Power supply
 Console Keyboard - 2 pluss on Key board
 Console Printer - Above Mother board

AIR FILTER

Part No - 2857-1057

\$ 14350

*9/24/85
Clyde Jones*

to be 27978

REV.A

Number 216-12791

Customer

AD

Part Number 12-12-839

Qty.

1

R.O.

Cust. P.O.

HEAD ASSEMBLY

Mfg Check

Q.C. Check



JUL 02 1981



**INFORMATION
MAGNETICS
CARIBE, INC.**

A subsidiary of CCT

Part # 2857-1057

16h21918

REV.A

Part Number 16-12791 AD

Mfg Check

Serial Number

Div

4

Cust. P.O.

RC

Q C Check



JUL 02 1981



INFORMATION
MAGNETICS
CARIBE, INC.

A subsidiary of CCT

Top platter is DFB (R2S4S)

Bottom platter is DFA (WORK)

Head Positioner Assembly Replacement

- a. Lift the disk shroud.

CAUTION

Do not allow the positioner to hit the disk(s).

- b. Slide the positioner into place.
- c. Install the three 1/4-20 screws from the underside of the baseplate.
- d. Push the positioner base flush with the alignment bar and tighten the three screws.
- e. Connect the head cable connectors to the backplane. Figure 5-2 shows the proper location of the connectors for the S card cage.
- f. Connect the transducer connector (P27) to backplane S03.
- g. Connect the positioner motor connector (P31) to the power amplifier module.
- h. Replace the disk shroud.

READ/WRITE HEAD

Heads are constructed such that the angle of the head arm is precisely measured to provide the correct head gram loading force required for operation of a drive unit.

Head insertion and removal tools are provided to protect the arm angle. Failure to use the insertion/removal tool subjects the heads to unusual and unnecessary risk. Once the precise angle is disturbed, the flying characteristics of the head itself are disturbed.

Damaged, distorted, or disturbed head arm angle results in errors or head crashes. The head insertion/removal tool must be used whenever heads are to be changed (see figure 5-3).

Read/Write Head Removal

- a. Remove the head positioner assembly as described in this section.
- b. Loosen the spring clamp located on the head positioner assembly as shown in figure 5-1.
- c. Remove the head mounting clamp.
- d. Using the head insertion/removal tool, remove the head.
- e. Refer to Read/Write Head Replacement in this section for the replacement of the head.


Read/Write Head Replacement

- a. Install heads (lower head first) with the head insertion/removal tool.

NOTE

Locate the head(s) in the carriage so that the arm is relatively centered. See figure 5-4.



- b. Torque the head mounting clamp screws to 5.5 \pm 0.1 inch/pounds.
- c. Route the heads leads through the spring clamp located on the head positioner assembly as shown in figure 5-1 and tighten the screw.
- d. Replace the head positioner assembly as described in this section.
- e. Connect the read/write head connectors in accordance with figure 5-2.
- f. Remove the positioner motor connector (P31) from the power amplifier module.
- g. Apply ac power.
- h. After the disk(s) have come up-to-speed, carefully load the heads onto the disk(s) manually. Slowly push the carriage in and out from cylinder 000 to cylinder 405. Verify that the heads fly without any unusual noise.
- i. Unload the heads manually.



W10866


Figure 5-2. Connector Locations for S Card Cage

COMPONENT SIDE





DCIII

- R10 P.7-5
- R11 P.7-5
- R26 P.7-6
- R27 P.7-5
- R31 P.2-6
- R38 P.7-6
- R42 P.7-5






R/W MACH.



- R2 P.2-11
- R8 P.2-6, P.8-4
- R10 P.2-12
- R19 P.8-3
- R20 P.8-3
- R29 P.8-3
- R38 P.8-3
- C12 P.8-3

COMPONENT SIDE



- R10 P.7-5
- R11 P.7-5
- R26 P.7-6
- R27 P.7-5
- R31 P.2-6
- R38 P.7-6
- R42 P.7-5

S09 S08	
S07	
S06	TEMP COMP
S05	RD/WRT INTERFACE
S04	SERVO AMP
S03	TRANSUCER AMP
S02	WRT DRIVER
S01	RD/WRT AMP

FIG. 2-17

R17 R10 R26 R31 R38 R42

FIG. 2-12

FIG. 3-15

FIG. 3-6

C20 C19	PADDLE CARD II
C18	PADDLE CARD I
C17	RD/WRT MACHINE
C16	ECC GENERATOR
C15	LPC CORRUPT
C14	DATA DISCRIMINATOR
C13	TIMING RECOVERY UNIT
C12	WRITE ENCODER
C11	
C10	
C09	PRESENT ADDRESS REGISTER
C08	ADDRESS COMPARE
C07	SERVO PREAMP
C06	DRIVE CONTROL III
C05	DRIVE CONTROL II
C04	DRIVE CONTROL I
C03	SECTOR GENERATOR
C02	DC VOLT MONITOR
C01	

FIG. 3-1F

FIG. 3-5

FIG. 4-2

FIG. 4-1

FIG. 4-4

FIG. 3-8

FIG. 3-11

FIG. 2-10

FIG. 2-11

FIG. 2-9

FIG. 2-E

FIG. 2-7

FIG. 2-19

FIG. 5-3

R2 P.2-11

R8 P.2-6, P.8-4

R10 P.2-12

R19 P.8-3

R20 P.8-3

R29 P.8-3

R38 P.8-3

C12 P.8-3