

**READ ORDERING
INSTRUCTIONS**

LOG LITERATURE LITERATURE
CATALOG LITERATURE CATALOG LI
CATALOG LITERATURE LITERATURE
LITERATURE LITERATURE ERAT
LITERATURE CATALOG LI
CATALOG LITERATURE CATALOG LI
LITERATURE CATALOG LI
LITERATURE CATALOG LI

**CONTROL DATA
CORPORATION**

CORPORATE HEADQUARTERS

8100 34TH AVENUE SOUTH, MINNEAPOLIS, MINNESOTA

MAILING ADDRESS • BOX 0, MINNEAPOLIS, MINNESOTA 55440

CONTROL DATA

July 15, 1975

Dear Customer:

Attached is the July 1975 Literature Catalog. Please read all instructions in the front section of this catalog before placing orders. This catalog obsoletes all previous editions.

Tranex Users Guide, Publication No. 60436500 will not be available under Kronos V2.1. This document will be available under NOS V1.0, but not until 11-15-75.

Batch Users Guide, Publication No. 60436300 will not be available until 10-22-75.

T-S Users Guide, Publication No. 60436400 will not be available until 9-15-75.



G. F. Moore, Manager
Literature & Distribution Services

GFM/sku

**CONTROL DATA CORPORATION
LITERATURE AND DISTRIBUTION SERVICES
8100 34TH AVENUE SOUTH, P.O. BOX O
MINNEAPOLIS, MINNESOTA 55440
TELEPHONE: 612-853-4157
TWX NUMBER 910-576-2978
TELEX NUMBER 290-435**



JULY 1975 EDITION

THIS CATALOG OBSOLETE
ALL PREVIOUS EDITIONS

EXTERNAL CUSTOMER CATALOG
PUBLICATION 90310500

INTRODUCTION

The Literature and Distribution Services Department of Control Data Corporation is responsible for the publishing of this catalog and the distribution of the items contained therein. The purpose of LDS is to provide a central ordering and distribution service for the external sale of literature and coding forms to Control Data customers.

The Customer Catalog will be published twice during 1975, with literature supplements published during the interim months. The monthly supplements reflect the changes which have taken place in the previous month including obsoleted publications, new publications and revision changes.

LDS solicits your comments and requests that verbal or written communication be directed to the Manager of Literature and Distribution Services.

TABLE OF CONTENTS

	<u>PAGE</u>
Manual Definition	I-1 - I-2
Procedures For Ordering Manuals	I-3 - I-5
Procedures For Ordering Coding Forms	I-5
Listing Of Coding Forms	I-6 - I-7
Accumulated Literature Change Listings	I-8 - I-27
Obsoleted Publications	I-28 - I-29
Numerical Listing Of Publications	
With Page Locations	I-30 I-38
Section I - Hardware Manuals	1-53
Listed Under Equip. Designator	
Section II - Software Manuals	54-127
Listed Under Product Number	
Section III - Software Manuals	128-155
Listed Under Operating Systems	
Table Of Software Abbreviations	129
Section IV - Miscellaneous Manuals -	156
Binders, Templates, Etc.	
Miscellaneous Manuals	157-158
Education Manuals	159
Training Manuals	159-162
Technical Reports	162-163
Video Lecture Manuals	163
SCM Publications	163-164
Hard Cover Binders	164-165
Templates	165
Motor Generator Set Manuals	165
Refrigeration Manuals	165
Power Supply Manuals	165-166
Printed Circuit Manuals	166
Site Preparation Manuals	166-167
Vendor Manuals	167-168
Long Line Transmission For 1604 Type I/O	168
Miscellaneous Equipment Modifications	168-169
QSE	169
Standard Options	169-171
Special Options	171-172
Cybernet Publications	172-179

MANUAL DEFINITION

The following general description of manuals, operator guides and handbooks is provided to allow the catalog user to more quickly identify categorically, the type of book he requires. With this information the user can then relate more easily to the section of this catalog which contains the required manual.

Hardware Reference Manual - This manual provides functional and operational descriptions and general programming capability information on Control Data hardware products and systems. This manual is written to the level of a knowledgeable prospective customer, professional programmer, and equipment operator.

Customer Engineering Manual - This manual provides the technical information necessary to maintain Control Data hardware products. Categories of information presented, in one or more volumes, are: General Description, Operation and Programming, Installation and Checkout, Theory of Operation, Diagrams, Maintenance, Maintenance Aids, Parts Data, Wire Lists, and Equation Summary {or equivalent}.

Hardware Reference/Customer Engineering Manual - This combined manual, usually for less complex devices that require minimal programming information, contains the same information as that in separate Reference and Customer Engineering manuals.

Site Preparation Manual - This manual presents technical information with which to plan and prepare sites for computer installation. Three sections make up this manual:

Section I: General Information - Two Section I manuals are available: One for small systems; the other covers large and medium-scale systems.

Section II: System Information - Section II manuals cover site planning information for specific systems; e.g., 3300, 6400, etc.

Section III: Peripheral Equipment - Section III provides site planning data on all Control Data peripheral equipment.

Hardware Diagnostic Reference Manual - This manual provides a functional description and detailed operating instructions for diagnostic programs.

System Operator's Manual - This manual provides operating instructions to the system operator. Instructions in this manual normally include system start-up, message formats, error recovery procedures, and general system information. This manual is written to the level of computer operators who do not have a detailed knowledge of programming.

System Reference Manual - This manual describes the system in terms of function, applications, and capabilities. Provides a configuration of the hardware that makes up the system with a brief description of the system function of each product. May also include a description of the software available with the system. Written to the level of the prospective customer who does not have a detailed knowledge of either the hardware or software.

Software General Information Manual - This manual provides introductory descriptions of functional and operational characteristics of Control Data software products.

Software Reference Manual - This manual provides complete descriptions of external functional and operational characteristics of Control Data software products.

Software Operator's Guide - This manual provides detailed instructions for operating Control Data software systems.

Software Diagnostic Handbook - This manual provides the messages issued by all programs in a software product set, together with the recommended action.

Software Installation Handbook - This manual provides installation and modification instructions for Control Data software products.

Software User's Guide - This manual provides the layman with the instructions on how to use a software product.

Software Instant Manual - This pocket-size manual provides summary information {deck structures, etc.} for system programmers and operators of software systems.

LITERATURE ORDERING POLICY AND PROCEDURES

Please read these policies and procedures prior to ordering to avoid confusion and mistakes and also to expedite the handling of orders.

PURCHASE ORDERS - Orders directed to LDS should include, if possible, a numbered purchase order, a money order or personal check.

ORDER LEAD TIME - All customer orders received will be handled on a priority basis and normally processed within a four working day period. Please keep in mind the transit time required by your order to both get to LDS and for the order to travel to your place of business. Under normal conditions, complete turn around on orders should not exceed fourteen calendar days.

DOMESTIC ORDERS - All purchase orders from domestic customers should be forwarded directly to:

Literature & Distribution Services
Control Data Corporation HQC00C
8100 34th Avenue South, P.O. Box 0
Minneapolis, Minnesota 55440

INTERNATIONAL ORDERS - International customer orders should be directed to the nearest Control Data Sales Office. The Control Data Sales Office will then process your order through LDS.

PRICING - The prices contained in this catalog are subject to change without notice.

FOB - All prices are F.O.B. Minneapolis, Minnesota

TERMS: NET 30 DAYS

SHIPPING REQUIREMENTS - Shipping instructions as given by the customer will be followed whenever possible. However, when the instructions cannot be adhered to, LDS reserves the right to determine the mode of transportation.

PRICE QUOTES - Price quotes are available upon request and are valid for 30 days only.

TELEPHONE ORDERS - LDS will accept telephone orders but each order must reference a purchase order number. A purchase order must follow confirming the phone order, and should be marked 'confirmation, do not duplicate'.

IDENTIFICATION OF MANUALS NEEDED - When ordering, you must specify whether you require a specific revision packet to a manual or if you desire the complete manual with all applicable revision packets updating the publication to its current revision level.

LITERATURE ORDERING POLICY AND PROCEDURES (CONT.)

NOTE: In some cases, the revision packet required is not available. However, the manual itself may have been reprinted through the revision which you require. If the packet is not available and you wish LDS to send you the updated manual, please specify same on your order. If you do not give LDS specific instructions for such a possibility, LDS will return your order and will not arbitrarily send the updated manual in place of the unavailable revision packet.

BACK ORDERS - All out of stock items will be automatically backordered and routed to you upon resupply of the item to stock. Please contact LDS should you not want specific items backordered.

DISCOUNTS - Discounts are given for literature as follows:

- {1} A 10% discount is given when ordering 25 to 99 copies of a single document.
- {2} A 20% discount is given when ordering 100 or more copies of a single document.

RETURNS FOR CREDIT - LDS does not sell literature on a consignment basis but will accept returns to stock if LDS has misfilled or delayed delivery of order so that the manuals are no longer required. Manuals which customers have ordered in excess of their needs may be returned if the publications are still current. IT IS IMPORTANT THAT YOU CONTACT AND RECEIVE FROM LDS WRITTEN APPROVAL BEFORE ANY MANUALS ARE RETURNED TO LDS. The manuals must be unused, in new condition and sent freight prepaid. Complete paperwork must accompany all returns for credit. Complete paperwork would include your original order number and if possible a copy of the order, the date of order and a copy of the LDS generated order invoice. All uncleared return to stock orders which LDS receives will be returned to the originator at the originator's expense.

AUTOMATIC SOFTWARE REVISION PACKET DISTRIBUTION SERVICE - On July 1, 1972, an additional service was made available to CDC customers. This service provides for the free postpaid automatic distribution to eligible customers of software revision packets as the packets become available. The policy holds that all external customer manual orders received directly from the customer by LDS on July 1, 1972 and thereafter will be eligible for automatic revision packet distribution. The customer is requested to return a copy of the shipping document which will be provided by Literature and Distribution and indicate on the document which Software publications they wish to have placed on the A/D service. A cover memo will be sent with each shipment indicating the guidelines you must follow. The packets will then be supplied to the customer in the same quantity as the manuals purchased under the original manual purchase order. The packets will continue to be distributed as long as packets are published or until the customer notifies LDS that the distribution should stop. You must establish eligibility

LITERATURE ORDERING POLICY AND PROCEDURES {CONT.}

by the purchase of a manual as a customer will not be placed on the listing if he purchases only a revision packet. Revision packets for manuals purchased prior to July 1, 1972, must be purchased by the customer and not through a CDC Sales Office. Not all customers will want this service as some manuals are purchased for a short duration use, such as orders by educational institutions for class use. Please indicate on your order if you do not wish this automatic packet distribution service.

GENERAL REVISION PACKET PRICING - All revision packets which support manuals sold to external CDC customers by LDS after July 1, 1972, will be provided free of charge. The packets will be given in the same quantity as the original manual purchase. Software packets will be automatically distributed {see Automatic Software Revision Packet Distribution above} whereas, requests for Hardware and Miscellaneous packets to support previously purchased manuals must be made directly to LDS by the customer. Please state on your order that the packets are in support of previously ordered manuals to avoid a billing for the packets. Quantities of packets which are in excess of the total number of manuals initially purchased by the customer will be charged to the customer.

PROCEDURES FOR ORDERING CODING FORMS

All purchase orders for coding forms from International customers should be directed to the nearest Control Data Sales Office. All purchase orders from Domestic customers should be directed to:

Literature & Distribution Services
Control Data Corporation
8100 34th Avenue South, P.O. Box 0
Minneapolis, Minnesota 55440

The unit price, form number, description and sheets per pad are as shown on the following pages.

Control Data does not offer quantity discounts on Forms sales.

CODING FORMS

<u>FORM NO.</u>	<u>DESCRIPTION</u>	<u>UNIT PRICE</u>
AA0138	OSAS/OSAS-A Coding Form	\$.75/PD
*AA0193	1604 Assembly Coding Form	
*AA0235	1604 Octal Card For General Load	
*AA0236	1604 Decimal Card For General Load	
AA0252	FORTTRAN Coding Form	.84/PD
AA0323	80 Column Punched Card Layout	.90/PD
AA0366	3600 COMPASS System Coding Form	1.00/PD
AA0382	COBOL Coding Form	.86/PD
AA0382-1	COBOL Coding Form	1.00/PD
AA0383	AUTOCOMM Coding Form	.66/PD
AA0540	160/160-A Data Processor	.81/PD
*AA0543	160 G Octal/Decimal Loader Form	
AA0649	Tape Record Layout	1.02/PD
AA1030	Computer Operating Instructions	1.33/PD
AA1031	Intercom Program	.87/PD
AA1040	Report and Tape Layout	2.82/PD
AA1053	Cybernet Tape/Pkt. Lab	.06/EA
AA1084	Obsolete - Use AA5491	
AA1085	Obsolete - Use AA5492	
AA1086	Obsolete - Use AA5490	
AA1133	Obsolete - Use AA5494	
AA1283	Loadflow Program - Control Information	.73/PD
AA1284	Loadflow Program - Line & Transformer Data	1.18/PD
AA1385	Software Document	1.40/PD
AA1385-1	Software Document	2.75/PD
AA1401	Index To Data Files For System	.99/PD
AA1405	Documentation Charting Form - Large	4.17/PD
AA1457	1700 Absolute Programming Sheet	1.24/PD
AA1502	Element Values LP-DCD Linear Programming Code	.87/PD
AA1503	Row Or Column Name LP-DCD Linear Programming Code	.70/PD
AA1529	Tape Record Format	.97/PD
AA1530	Card Format {S}	.97/PD
AA1708	SIMSCRIPT Report Generator Layout Form	1.46/PD
AA1709	SIMSCRIPT Initial	1.48/PD
AA1710	SIMSCRIPT Definition Form	1.62/PD
AA1775	6600 ASCENT System Coding Form	.64/PD
AA1779	80 Column Punched Card Layout	1.20/PD
AA2142	PERT/TIME Coding Form - Type A Data	1.36/PD
AA2184	Obsolete - No Replacement	
AA2212	OSAS/OSAS-A TAS 915 Coding Form	48.60/RM
AA2364	Transfer Request	.64/PD
AA2394	Report Generator Coding Form	.90/PD
AA2422	Multiple Layout Card Form	.78/PD
AA2442	CIVCO Input Data Form	1.63/PD
AA2453	Pagination Sequence	.98/PD
AA2501	Forecasting Worksheet	1.44/PD
AA2583	Form Layout Sheet - 8 1/2 x 11 Vertical	1.57/PD
AA2583-1	Form Layout Sheet - 8 1/2 x 11 Horizontal	2.00/PD
AA2836	Sample Format and Card	.94/PD
AA2986	Eunas Data Form	1.02/PD

*PRICES AVAILABLE UPON REQUEST

CODING FORMS {CONT}

<u>FORM NO.</u>	<u>DESCRIPTION</u>	<u>UNIT PRICE</u>
AA2987	6000/7000 Compass Coding Form	\$.76/PD
AA3034	Department Data and Recaps	.84/PD
AA3034-1	Departmental Recap Names	.85/PD
AA3168	SAMIS, Pseudo Instruction Input Data-Form 1	1.02/PD
AA3169	SAMIS, Materials Tables Input Data-Form 2	1.02/PD
AA3170	SAMIS, Facet and Beam Element Input Data-Form 3	1.02/PD
AA3171	SAMIS, Matrix Input Data - Form 4	1.02/PD
AA3385	Program Trouble Sheet	.17/EA
AA3389	CDC/MACRAN Coding Form	1.02/PD
AA3422	STAR DYNE Data Form, Prep Data Form 2	.87/PD
AA3423	STAR DYNE Data Form, 10 Digit Decimal Data	.71/PD
AA3424	STAR DYNE Data Form, Stardyne Static Loads	.93/PD
AA4173	3000L Compass System Coding Form	1.44/PD
AA4193	TELCOM User Master Corrections	.87/PD
AA4206	6000/7000 Table Form	.91/PD
AA4405	Revision Record	1.29/PD
AA4437	OPHELIE-LP MPS Data Form	.67/PD
AA5490	DCO/Tranplan Transit NE	1.12/PD
AA5491	DCO/Tranplan Transit NE	1.40/PD
AA5492	DCO/Tranplan Transp System	.88/PD
AA5493	DCO/Tranplan Transp PLA	1.29/PD
AA5494	DBO/Tranplan Transp PLA	1.53/PD
AA6036	Bridge Analysis Input Data-Card Type 1	1.62/PD
AA6037	Bridge Analysis Input Data-Card Types 2, 5, 6	1.44/PD
AA6038	Bridge Analysis Input Data-Card Type 3	1.62/PD
AA6039	Bridge Analysis Input Data-Card Type 7	1.46/PD
AA6040	Bridge Analysis Input Data-Card Type 8	1.45/PD
AA6041	Bridge Analysis Input Data-Card Type 9	1.46/PD
AA6042	Bridge Analysis Input Data-Card Type 10	1.42/PD
AA6043	Bridge Analysis Input Data-Card Type 11	1.46/PD
AA6044	Bridge Analysis Input Data-Card Type 12	1.35/PD
AA6045	Bridge Analysis Input Data-Card Type 13	1.46/PD
AA6046	Bridge Analysis Input Data-Card Type 14	1.46/PD
AA6047	Bridge Analysis Input Data-Card Type 15	1.46/PD
AA6048	Bridge Analysis Input Data-Card Type 60	1.46/PD
AA6049	Bridge Analysis Input Data-Card Type 61	1.38/PD
AA6050	Bridge Analysis Input Data-Card Type 62	1.62/PD
AA6051	Bridge Analysis Input Data-Card Type 63	1.35/PD
AA6052	Bridge Analysis Input Data-Card Type 64	1.35/PD
AA6053	Bridge Analysis Input Data-Card Type 65	1.46/PD
AA6054	Bridge Analysis Input Data-Control Cards	1.62/PD
MSC015R1	LGP 30 Coding Form Forms comprise set, must	1.16/PD
MSC016R1	LGP 30 Coding Form be sold together	1.16/PD
MSC05710	LGP 30 Work Format	.99/PD

All pads contain 50 sheets each
 All reams contain 500 sheets each

ACCUMULATED LITERATURE CHANGE LISTING

This section is an accumulation of all literature revisions, additions and deletions which have taken place since the issuance of the January 1975 Literature Catalog. The manuals are listed numerically by product number.

The legend for columns one through six is as follows:

- 1-New or revised literature published since last edition.
 - A. N-New Publication
 - B. R-Revision in packet form only
 - C. RM-Revision in manual form only
 - D. RMP-Revised manual/packet available
 - E. RO-Revised publication obsoletes all previous editions.
 - 2-Publication number of literature
 - 3-The latest revision level
 - 4-Indicates size of hard cover binder that may be used for manuals
 - 5-Publication division responsible for contents of literature
- *FOR CONTROL DATA USE ONLY

1	TITLE	2	3	4	5
*N	33158 MEMORY SYSTEMS SALES REFERENCE MAN	10121100	-	--	HQW
R	FJ601-A {3316-1, 3516-1} MULTIPLEXER CONTROLLER THEORY OF OPERATION, INSTALLATION/CHECKOUT, DIAGS., MAINT., MAINT. AIDS, PARTS DATA AND WIRE LISTS CE MAN	13796700	K	22	ARH
N	469 COMPUTER SYSTEM 462-01A AND 462-02A TELETYPE CONTROLLER HARDWARE REF/CE MANUAL	14060200	-	22	MSP
N	469 COMPUTER SYSTEM 461-01B/02A PUNCHED TAPE MEMORY LOADER/TAPE PUNCH HARDWARE REFERENCE/CE MANUAL	14060300	A	22	GSD
N	MP-60 COMPUTER SYSTEM COMPASS REFERENCE MAN	14061300	B	22	GSD
N	MP-60 COMPUTER SYSTEM COSY REFERENCE MANUAL	14062100	A	22	GSD
N	MP-60 COMPUTER SYSTEM PRELIB REFERENCE MAN	14062200	A	22	GSD
N	469 COMPUTER SYSTEM PROGRAMMING REF MANUAL	14065300	B	22	GSD
N	469 COMPUTER SYSTEM ASSEMBLER V 1.2 REF MAN	14077300	C	22	GSD
N	469 COMPUTER SYSTEM SIMULATOR V 1.0B REF MAN	14082100	D	22	GSD
N	469 COMPUTER SYSTEM BASIC ARITHMETIC SUB-ROUTINES REFERENCE MANUAL	14082200	B	22	GSD
RO	5600 COMPUTER SERIES MPP REFERENCE MANUAL	14232000	A	22	GSD
N	MP-60 COMPUTER SYSTEM REFERENCE MANUAL	14306500	A	22	GSD
N	33159 MONOLITHIC MAIN MEMORY SYSTEMS SALES REFERENCE GUIDE	15001100	-	--	HQW
R	6000 COMPUTER SYSTEMS CONTINUOUS SYSTEM SIMULATION LANGUAGE III USERS GUIDE VERSION I	17304400	F	22	SVL
N	6000/CYBER 70 MODELS 72/73/74 COMP SYSTEM DIGITAL DISPLAY SYSTEM {DDS} VER 3 REFERENCE MANUAL	17318900	A	22	SVL
RO	6000/CYBER 70 MODELS 72, 73, 74 COMP SYSTEM 777 INTERACTIVE GRAPHICS SYSTEM VER 2 OPERATORS GUIDE	17322600	B	22	SVL
RO	6000/CYBER 70 MODELS 72, 73, 74 LCGT/IGS VERSION 1 G.I.M.	17322700	B	3	SVL
RO	CYBER 70 COMPUTER SYSTEMS MODELS 72, 73, 74 LOW COST GRAPHICS TERMINAL {LCGT} INTERACTIVE GRAPHICS SYSTEM {IGS} VERSION 1.1 REFERENCE MANUAL	17322800	B	22	SVL
N	777 THREE DIMENSIONAL INTERACTIVE GRAPHICS SYSTEM {3-D IGS} VER 1 REF MAN CONTROL DATA 6000 CYBER 70 MODELS 72, 73, 74 COMPUTER SYSTEMS	17326500	A	22	SVL
R	6000/CYBER 70 MODELS 72, 73, 74 COMPUTER SYS 3000L TO CYBER 70 CONVERSION AIDS SYSTEM VER 1.0 FORTRAN CONVERSION FOR SCOPE 3.4	19980600	C	22	TTO

CONT.

1	TITLE	2	3	4	5
R	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS 300DL TO CYBER 70 CONVERSION AIDS SYSTEM VER 1.0 COBOL CONVERSION FOR SCOPE 3.4	19980700	B	22	TTO
R	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS 300DL TO CYBER 70 CONVERSION AIDS SYSTEM VER 1.0 LANGUAGE CONVERSION USERS GUIDE FOR SCOPE 3.4	19980900	B	22	TTO
RO	CYBER 170-MODELS 172/173/174 SYSTEMS DATA SITE PREPARATION MANUAL	19981400	A	22	ARH
N	CYBER 170 MODELS 172,173,174 CENTRAL PRO- CESSOR UNIT THEORY OF OPERATION, DIAGS, HARDWARE MAINT. MANUAL VOLUME 1 OF 2 {PRELIMINARY ED.}	19981800	01	22	TTO
N	CYBER 70/CYBER 170/6000 SERIES COMPUTER SYS COBOL VERSION 5.0 GIM	19984100	A	22	TTO
N	FF525 PRINTER SUBSYSTEM CENTRAL CONTROL UNIT LOGIC DIAGRAMS	22272500	A	34	PLY
N	28211-21 PRINTER SUBSYSTEM LOGIC DIAGRAMS	22273100	A-G	34	PLY
RO	1538 {FL301A} HIGH-SPEED, HIGH LEVEL ANALOG INPUT CONTROLLER	39074500	D	22	LJL
N	1700 A/Q {DC220/221-A} DSA ADAPTERS GEN DESC., OPER AND PROGRAMMING, INSTALLA- TION AND CHECKOUT, THEORY OF OPER., DIAGS, MAINT, MAINT. AIDS, PARTS DATA, WIRE LISTS, HDWE/REF/CE MANUAL	39392700	C	22	LJL
RO	1700 COMPUTER SYSTEMS MS0S 4 FILE MANAGER VERSION 1 SOFTWARE REFERENCE MANUAL	39520600	B	22	LJL
N	1700 COMPUTER SYSTEMS 1700 MS0S 4.1 FORTRAN 3.2 A/B, AND TIMESHARE 2.0 RELEASE BULLETIN	39520800	A	22	LJL
N	1700 COMPUTER SYSTEMS MS0S VERSION 4 ORDER- ING BULLETIN	39521900	B	22	LJL
RO	1700 COMPUTER SYSTEMS MS0S 4 G.I.M.	39522400	B	22	LJL
R	GH107-B/ED301-E MULTIPLEXER {MX-7A} GENERAL DESC., DIAGRAMS, WIRE LISTS, PARTS DATA CE MANUAL	39660400	B	22	LJL
N	BG504A-H DRUM MEMORY SUBSYSTEM HARDWARE REFERENCE/CE MANUAL	39731700	C	22	LJL
RO	DK605-A {1595-10/11} SERIAL I/O UNIT REF CE MANUAL	39909507	B	22	LJL
N	1590-3 {DN124-A, FJ124-A} REMOTE COMPUTER INTERFACE SUBSYSTEM HARDWARE REF/CE MANUAL	39909513	A	22	LJL
RO	BE102 {608} MAGNETIC TAPE TRANSPORT PARTS LIST CE MANUAL	40864100	G	22	VFD
R	FJ103-A/B/C/D/E {1748-2} MULTIPLEXER CON- TROLLER THEORY OF OPERATION, INSTALLA- TION CHECKOUT, DIAGS., MAINT., MAINT. AIDS, PARTS DATA CE MANUAL	41601700	J	22	ARH
RMP	DJ110-A{311-2} DATA SET ADAPTER THEORY OF OPERATION, INSTALLATION/CHECKOUT, DIAGS., MAINT., MAINT. AIDS, PARTS DATA CE MANUAL	41603200	C	22	ARH
R	FJ103-A/B/C/D/E {1748-2} MULTIPLEXER CONTROLLER CARD PLACEMENT, LOGIC WIRING, WIRE LISTS EQUATION SUMMARY CE MANUAL	41603300	E	22	ARH

CONT.

1	TITLE	2	3	4	5
R	361-5 {DJ144-A} COMMUNICATIONS ADAPTER REFERENCE MANUAL	41611800	C	22	ARH
RO	1700/SC1700 COMPUTER SYSTEMS DRAFT VERSION 5.1 OCR REFERENCE MANUAL	48143900	F	22	ROK
RO	CJ122 DIAGRAMS VOLUME 2, PART 3, CE MANUAL	48430045	B	22	ROK
RO	CJ122 PAGE AND DOCUMENT READER MODELS C-K VOLUME 1 HARDWARE MAINTENANCE MANUAL	48430080	C	22	ROK
RO	BE406 {659-1} MAGNETIC TAPE TRANSPORT GEN. DESC., THEO OF OPER., MAINT. CE MAN	49750600	G	22	VFD
N	34201 MAGNETIC TAPE TRANSPORT OPERATORS MANUAL	49752300	A	3	VFD
RO	415 CARD PUNCH DIAGRAMS, THEORY OF OPERATION GEN. DESC., CE/REFERENCE MANUAL	49755300	C	22	VFD
RO	BE482 {9525} MAGNETIC TAPE TRANSPORT DIAGS. CE MANUAL	49755800	C	22	VFD
N	CH102-A/B CARD PUNCH PART IDENTIFICATION MANUAL	49762400	A	22	VFD
RO	BE103 {657-1} MAGNETIC TAPE TRANSPORT PARTS LIST CE MANUAL	49815000	G	22	VFD
N	3000 COMPUTER SYSTEM BROKERAGE CONTROL SYS VER 4.0 REF MAN	59159000	A	22	ARH
N	3000 COMPUTER SYSTEMS BROKERAGE CONTROL SYS VER 4.0 OPERATORS GUIDE	59159100	A	22	ARH
N	EXTENDED CORE STORAGE DATA PATH AND STACK SELECT MAINTENANCE AID CHART	59304600	-	--	ARH
N	14031 TRAIN PRINTER GEN DESC., INSTALLATION & CHECKOUT, OPER AND PROGRAMMING, PRINCIPLES OF OPERATION, MAINT, MAINT AIDS CE MANUAL VOLUME I	59708200	A-01	22	RHT
N	14031 TRAIN PRINTER DIAGRAMS & WIRE LIST CE MANUAL VOLUME 2	59708300	A-01	22	RHT
N	14031 TRAIN PRINTER VOLUME 3 PARTS DATA CE MANUAL	59708400	A-01	22	RHT
RO	SINGER BUSINESS MACHINES LINE PRINTER EQUIPMENT MODELS 53,54,55 AND 56 PARTS MAN	59708700	D	3	RHT
RO	9322 SINGER FIELD SERVICE MANUAL VOLUME 2	59709000	B-01	34	RHT
R	PRINTED CIRCUIT MANUALS CORDWOOD MANUAL VOLUMES 1,2,3	60042700	AY	22	ARH
R	3200 COMPUTER SYSTEM CE DIAGRAMS	60049400	AY	22	ARH
R	3100/3150/3170/3200/3300/3500 COMPUTER SYS MASTER/MSOS/RTS MASS STORAGE FORTRAN VERSION 3 AND 4 REFERENCE MANUAL	60057600	G	22	ARH
R	3228-A/B MAGNETIC TAPE CONTROLLER CE MANUAL	60093700	V	22	ARH
R	6000 COMPUTER SYSTEMS REFERENCE MANUAL	60100000	AE	22	ARH
R	3104/3114-A/B COMPUTER DIAGRAMS CE MANUAL	60111100	BE	22	ARH
R	3000L SYSTEM MAINTENANCE MONITOR REF MANUAL VOLUME 1 AND 2	60118600	M	22	ARH
R	DC211-A {6684-A} DATA CHANNEL CONVERTER CE MANUAL	60125000	AZ	22	ARH
R	6411-A/6416-A AUGMENTED I/O BUFFER CONTROL DIAGRAMS AND CIRCUIT DESCRIPTION	60146200	U	22	AR
R	3104-A/B, 3114-A/B COMPUTER CARD PLACEMENT, EQUATION SUMMARY CE MANUAL	60152500	AD	22	ARH
R	3104-A/B, 3114-A/B COMPUTER WIRE LIST {TERM} CE MANUAL	60152600	AA	22	ARH
R	3458-A LINE PRINTER CONTROLLER DIAGS CIRC. DESC., MAINT AND PARTS LIST	60158200	Z	22	ARH
RO	1700 COMPUTER SYSTEM CODES	60163500	H	6	LJL

CONT.

1	TITLE	2	3	4	5
R	1706-A BUFFERED DATA CHANNEL DIAGS., CIRCUIT DESC., MAINTENANCE, PARTS LISTS CE MANUAL	60165700	L	22	LJL
R	1700 COMPUTER SYSTEM INPUT/OUTPUT SPECIFICATIONS MANUAL	60165800	H	22	LJL
R	6400/6500-A/B/C CENTRAL COMPUTER CABLE TABS {FOR 6404-A, 6414/6514-A/B/C {ONLY}}	60166000	M	22	ARH
R	6400/6500-A/B/C CENTRAL COMPUTERS CHASSIS 3 CHASSIS TABS	60166300	AR	22	ARH
R	1738-A/B/C DISK DRIVE CONTROLLER CE MANUAL	60167700	U	22	LJL
R	3234-A/B MASS STORAGE CONTROLLER DIAGRAMS CE MANUAL	60167900	AD	22	ARH
R	6400/6500-A/B/C CENTRAL COMPUTERS CABLE TABS {FOR 6405-A, 6415-A/B/C ONLY}	60169700	M	22	ARH
R	6400/6500-A/B/C CENTRAL COMPUTERS MAINT. AND COMMAND TIMING	60182100	J	22	ARH
R	1716-A COUPLING DATA CHANNEL CE MANUAL	60182800	N	22	LJL
RO	1708-A {BB310-A/BB311-A/BB312-A} STORAGE INCREMENT CE MANUAL	60182900	G	22	LJL
R	SMM17 REFERENCE MANUAL VOLUME 1 AND 2	60182000	M	22	ARH
R	FF511-A/B {1742} LINE PRINTER CONTROLLER CE MANUAL {INCLUDES PMI/PMP}	60183000	H	22	LJL
R	3300 COMPUTER SYSTEMS INSTRUCTION CODES	60186900	D	--	ARH
R	6400/6500-A/B/C CENTRAL COMPUTERS CHASSIS 8 CHASSIS TABS	60187700	V	22	ARH
R	6400/6500-A/B/C CENTRAL COMPUTER CABLE TABS {FOR 6413/6513-A/B/C ONLY}	60188900	G	22	ARH
R	3458-A LINE PRINTER CONTROLLER CARD PLACEMENT, EQUATION SUMMARY, WIRE LIST CE MANUAL	60197000	S	22	ARH
R	3104-C/3114-C COMPUTER CARD PLACEMENT, EQUATION SUMMARY CE MANUAL	60197900	S	22	ARH
R	3104-C/3114-C COMPUTER WIRE LIST {TERM} CE MANUAL	60198000	M	22	ARH
R	6673/6674 DATA SET CONTROLLER CARD PLACEMENT EQUATION SUMMARY CE MANUAL	60201500	N	22	ARH
R	6673/6674 DATA SET CONTROLLER WIRE LISTS CE MANUAL	60205400	L	22	ARH
RM	1732-A/B MAGNETIC TAPE CONTROLLER CE MANUAL	60208200	L	22	LJL
R	BB319-A {6634-C} EXTENDED CORE STORAGE ASSEMBLY DIAGRAMS, CIRC. DESC., WIRE LIST CE MANUAL	60209600	W	22	ARH
R	BB313-A {3502} STORAGE MODULE CE MANUAL	60210200	AC	22	ARH
R	BB323-A {6635-C} EXTENDED CORE STORAGE ASSEMBLY DIAGRAMS, CIRC. DESC., PARTS LIST, CARD PLACEMENT CE MANUAL	60212200	W	22	ARH
R	FJ411-A/B {6671} DATA SET CONTROLLER DIAGS. CIRCUIT DESC., PARTS LIST, CARD PLACEMENT, EQUATION SUMMARY, WIRE LISTS CE MANUAL	60217400	W	22	ARH
RO	SMM17 PROGRAM LISTINGS - MEM	60220100	F	22	ARH
RO	SMM17 PROGRAM LISTINGS - COM	60220200	E	22	ARH
RO	SMM17 PROGRAM LISTINGS - PTP	60220300	E	22	ARH
RO	SMM17 PROGRAM LISTINGS - PTR	60220400	E	22	ARH
RO	SMM17 PROGRAM LISTINGS - TTY	60220500	F	22	ARH
RO	SMM17 PROGRAM LISTINGS - CR1	60220600	D	22	ARH
RO	SMM17 PROGRAM LISTINGS - MT1	60220700	E	22	ARH
RO	SMM17 PROGRAM LISTINGS - DP1	60220800	F	22	NRM

CONT.

1	TITLE	2	3	4	5
RO	SMM17 PROGRAM LISTINGS - RPT	60220900	F	22	ARH
RO	SMM17 PROGRAM LISTINGS - SC1	60221100	F	22	ARH
RO	SMM17 PROGRAM LISTINGS - LP1	60221200	F	22	ARH
RO	SMM17 PROGRAM LISTINGS - MT2	60221300	E	22	ARH
RO	SMM17 - PROGRAM LISTINGS - MT3	60221700	G	22	ARH
RO	FF516-A {1740} LINE PRINTER CONTROLLER CE MANUAL	60223800	J	22	LJL
R	BB323-A {6635-C} EXTENDED CORE STORAGE ASSEMBLY CHASSIS/CABLE TABS CE MANUAL	60230300	S	22	ARH
R	6000 COMPUTER SYSTEMS SIMULA REFERENCE MAN	60234800	F	22	SVL
R	6613-D COMPUTER SYSTEM CENTRAL MEMORY CLOCK, ECS COUPLER, POWER DIAGRAMS CE MANUAL	60246600	U	22	ARH
R	6400/6500-D CENTRAL COMPUTERS CPU, CENTRAL MEMORY, CLOCK, ECS COUPLER AND POWER DIAGRAMS	60246800	AG	22	ARH
R	6400/6500-D CENTRAL COMPUTERS CHASSIS 1 CHASSIS CABLE TABS	60246900	S	22	ARH
R	6613-D COMPUTER SYSTEM CHASSIS 4 CHASSIS/ CABLE TABS CE MANUAL	60247000	R	22	ARH
R	6613-D COMPUTER SYSTEM CHASSIS 8 CHASSIS/ CABLE TABS CE MANUAL	60247400	J	22	ARH
R	6614-D COMPUTER SYSTEM CHASSIS 9 CHASSIS/ CABLE TABS CE MANUAL	60247600	P	22	ARH
R	6400/6500-D CENTRAL COMPUTER CHASSIS 3 CHASSIS/CABLE TABS	60248500	U	22	ARH
R	6400/6500-D CENTRAL COMPUTER CHASSIS 6 CHASSIS/CABLE {FOR 6415-D ONLY}	60249000	K	22	ARH
R	6400/6500-D CENTRAL COMPUTER CHASSIS 8 CHASSIS/CABLE TABS	60249100	S	22	ARH
RMP	ACTIVE EXPERIMENT NETWORKS	60250500	C	3	CDI
N	6000 COMPUTER SYSTEMS SCOPE USERS GUIDE VERSION 3.3	60252700	C	22	CYB
R	FA704-A/B {3553-2} MASS STORAGE CONTROLLER CE MANUAL	60266000	AE	22	ARH
R	SMM17 INSTANT ERROR CODES	60266200	G		ARH
R	REFRIGERATION THEORY MAINTENANCE MANUAL	60268100	H	22	ARH
R	3234-A/B MASS STORAGE CONTROLLER WIRE LIST, EQUATION SUMMARY CE MANUAL	60268900	P	22	ARH
R	AT131-A {10169, 10173-3/4/5, 10174-1/2} CENTRAL MEMORY ACCESS PRIORITY REFER- ENCE CE MANUAL	60270900	H	22	ARH
RO	SMM17 PROGRAM LISTINGS {CRP} 1728/430 CARD READER/PUNCH CE MANUAL	60271300	F	22	ARH
RO	SMM17 PROGRAM LISTINGS {CR3} 1729-2/411 CARD READER	60271400	F	22	ARH
RO	SMM17 PROGRAM LISTINGS {CR2} 1726/405 CARD READER	60271500	E	22	ARH
RO	SMM17 PROGRAM LISTINGS - 1735/915 OCR OPTICAL CHARACTER READER CE MANUAL	60271700	F	22	ARH
R	AT129-A {10169, 10173-6/7/8/9/10} CENTRAL MEMORY ACCESS PRIORITY OPTION FOR 64/6500 A/B/C REFERENCE/CE MANUAL	60272700	G	22	ARH
RO	SMM17 DDC 1745/1746/210 DATA DISPLAY CE MAN	60273200	E	22	ARH
R	SECTION 3 PERIPHERAL EQUIPMENT DATA SITE PREPARATION MANUAL	60275300	06	22	ARH
RO	7700 SYSTEMS DATA SITE PREPARATION MANUAL	60277800	B	22	ARH
R	1706-A BUFFERED DATA CHANNEL CROSS TABS CE MANUAL	60284000	B	22	LJL

CONT.

1	TITLE	2	3	4	5
R	AA103-A CENTRAL COMPUTER {6414-E} PERIPHERAL PROCESSOR UNIT DIAGRAMS CE MANUAL	60284100	U	22	ARH
R	1770/SC-1700 SYSTEM CONTROLLER I/O SPECIFICATIONS	60285200	04	22	LJL
R	AA103-A CENTRAL COMPUTER {6614-E} CHASSIS 1 CHASSIS/CABLE TABS CE MANUAL	60285300	AD	22	ARH
R	AA105-A CENTRAL COMPUTER {6414-E} CHASSIS 3 CHASSIS/CABLE TABS CE MANUAL	60285500	Z	22	ARH
R	AA103-A CENTRAL COMPUTER {6614-E} CPW/FUNCTIONAL UNIT DIAGRAMS CE MANUAL	60287300	T	22	ARH
R	BB319-A {6634-C} EXTENDED CORE STORAGE ASSEMBLY, MAINTENANCE, MAINTENANCE AIDS, CE MANUAL	60289200	K	22	ARH
R	FA705-A {3553-1} MASS STORAGE CONTROLLER CE MANUAL	60290000	R	22	ARH
R	FJ427-A {6671-1} DATA SET CONTROLLER INSTALLATION/CHECKOUT, DIAGS, PARTS DATA, WIRE LISTS, EQ SUMMARY CE MANUAL	60294500	K	22	ARH
R	AA103-A CENTRAL COMPUTER {6614-E} CHASSIS 8 CHASSIS/CABLE TABS CE MANUAL	60294900	F	22	ARH
R	DT122-A {7683-1} REMOTE CHANNEL COUPLER REFERENCE/CE MANUAL	60296200	H	22	ARH
R	AA102-A {7601-1} CENTRAL COMPUTER THEORY OF OPERATION, DIAGRAMS, MAINT. AIDS	60297600	AC	22	ARH
RO	SMM3L PROGRAM LISTINGS {MM2} 3300 MEMORY	60300400	G	22	ARH
RO	SMM3L PROGRAM LISTINGS {COM}	60300600	E	22	ARH
RO	SMM3L PROGRAM LISTINGS {FPT} FLOATING POINT TEST	60300700	E	22	ARH
RO	SMM17 PROGRAM LISTINGS - CH2	60301500	G	22	ARH
RO	SMM3L PROGRAM LISTINGS {MS1}	60301900	G	22	ARH
RO	SMM3L PROGRAM LISTINGS {DVN} EXECUTIVE MODE MONITOR	60303000	F	22	ARH
RO	SMM3L PROGRAM LISTINGS 3L00 QUICK LOOK MEMORY TEST	60303700	B	22	ARH
RO	SMM3L PROGRAM LISTINGS 3L00 QUICK LOOK COMMAND TEST	60303800	C	22	ARH
RO	SMM3L PROGRAM LISTINGS 3200 EXTERNAL EQUIPMENT	60303900	E	22	ARH
RO	SMM3L PROGRAM LISTINGS - RFT	60304000	B	22	ARH
RO	SMM3L PROGRAM LISTINGS MMX INTERRUPT PROC	60304100	E	22	ARH
RO	SMM3L PROGRAM LISTINGS - SIMULATED RANDOM INSTR TEST	60304500	B	22	ARH
RO	SMM3L PROGRAM LISTINGS - 3316 CONTROLLER {CEN}	60304600	C	22	ARH
R	6000/7000/CYBER 70/CYBER 170 COMPUTER SYS FORTRAN EXTENDED REF/MANUAL VERSION 4	60305600	G	22	SVL
R	6000/7000/CYBER 70/CYBER 170 COMPUTER SYS CYBER RECORD MANAGER VERSION 1, 7000 RECORD MANAGER REFERENCE MANUAL	60307300	G	22	SVL
R	6000/CYBER 70 MODELS 72/73/74 COMPUTER SYS SCOPE INSTALLATION HANDBOOK VERSION 3.4.3	60307400	V	22	SVL
RO	SMM17 PROGRAM LISTINGS - 0C3 - FF406 TEST CE MANUAL	60309200	E	22	ARH
R	AA105-A CENTRAL COMPUTER {6414-E} DIAGRAMS CE MANUAL	60316200	Z	22	ARH
RO	SMM17 PROGRAM LISTINGS - MTS	60325800	E	22	ARH
RO	SMM17 PROGRAM LISTINGS - 0C4	60326400	D	22	ARH

CONT.

1	TITLE	2	3	4	5
R	6000/CYBER 70 MODELS 72, 73, 74 COMPUTER SYS SYMPL REFERENCE MANUAL VERSION 1	60328800	C	22	SVL
R	FV218-A/B {733-10} HSB SUBSYSTEM TERMINAL CONTROLLER CE MANUAL	60329700	V	22	ARH
R	1742-A/B {CL309-A/B, FF511-A/B} LINE PRINTER WITH CONTROLLER REFERENCE MANUAL	60331300	B	22	LJL
R	3248-A/B CARD READER CONTROLLER REF MANUAL	60332300	D	22	ARH
R	3458-A LINE PRINTER CONTROLLER REF MANUAL	60332800	B	22	ARH
RO	6681-B/C/D DATA CHANNEL CONVERTOR REF MANUAL	60334400	G	22	ARH
R	6673/6674 DATA SET CONTROLLER REFERENCE MAN	60334500	B	22	ARH
R	AA105-A CENTRAL COMPUTER {6414-E} CHASSIS & CHASSIS/CABLE TABS CE MANUAL	60336400	L	22	ARH
R	SMM3L PROGRAM LISTINGS - BDP TESTS 3312-A	60336500	D	22	ARH
R	SMM3L PROGRAM LISTINGS - BDP TESTS 3514	60336800	D	22	NRM
R	SMM3L PROGRAM LISTINGS - 33/3500 PAGE FILE TEST - PFT	60336900	D	22	ARH
RO	SMM3L PROGRAM LISTINGS - 3553-2/821 MS4	60337100	D	22	ARH
RO	6000/7600/CYBER 70/CYBER 170 COMPUTER SYS LOADER REF MANUAL	60344200	G	22	ARH
RO	7600/CYBER 70 MODEL 76 SCOPE 2.1 INSTANT MODEL 72 SYSTEM DESCRIPTION/PROGRAMMING INFO VOLUME 1	60344300	B	6	ARH
R	MODEL 72 SYSTEM DESCRIPTION/PROGRAMMING INFO VOLUME 1	60347000	H	22	ARH
R	MODEL 73 SYSTEM DESC/PROGRAMMING INFO VOLUME 1	60347200	E	22	ARH
R	MODEL 72/73/74 INSTRUCTION DESC VOLUME 2	60347300	J	22	ARH
R	MODEL 74 SYSTEMS DESC/PROGRAMMING INFO VOLUME 1	60347400	K	22	ARH
RO	AF104-A {ST OP 10256} 3200 BUSINESS DATA PROCESSOR INTERFACE CE MANUAL	60347600	C	22	PLY
RO	10256 {AF101-C, AF104-A} 3200 BDP OPTION REFERENCE MANUAL	60347700	B	22	PLY
R	AC113-A CENTRAL COMPUTER THEORY OF OPERATION DIAGRAMS, MAINTENANCE CE MANUAL	60348000	AB	22	ARH
R	AC113-A CENTRAL COMPUTER LCM STACK WIRE LIST CE MANUAL	60349600	D	22	ARH
R	AA115-A {72-XX, 73-XX} BASIC UNIFIED PROCESSOR CHASSIS 1,3,11 WIRE LIST CE MAN	60350200	R	22	ARH
R	AA115-A {72-XX, 73-XX} BASIC UNIFIED PROCESSOR CHASSIS 2,6 WIRE LIST CE MANUAL	60350300	V	22	ARH
RMP	AA115-A {72-XX, 73XX} BASIC UNIFIED PROCESSOR CHASSIS 3 WIRE LIST CE MANUAL	60350400	L	22	ARH
R	AA115-A {72-XX, 73-XX} BASIC UNIFIED PROCESSOR CHASSIS 4 WIRE LIST CE MANUAL	60350500	AC	22	ARH
R	AA115-A {72-XX, 73-XX} BASIC UNIFIED PROCESSOR CHASSIS 7 WIRE LIST CE MANUAL	60350800	K	22	ARH
R	AA115-A {72-XX, 73-XX} BASIC UNIFIED PROCESSOR CHASSIS 8 WIRE LIST CE MANUAL	60350900	R	22	ARH
R	AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 12 WIRE LIST CE MANUAL	60351300	L	22	ARH
RO	PASSIVE ELECTRONICS STUDENT MANUAL	60354500	G	3	CDI
R	DK518-A {7681-1} DATA CHANNEL CONVERTER CE MANUAL	60355900	F	22	ARH
RO	6000/CYBER 70 MODELS 72, 73, 74 COMPUTER SYS SCOPE VERSION 3.3 TO SCOPE VERSION 3.4 CONVERSION AIDS PROGRAMMING SYSTEMS BULLETIN	60358200	D	22	SVL
R	6000/CYBER 70 MODELS 72, 73, 74 COMPUTER SYS DATA DESCRIPTION	60359000	B	22	SVL

CONT.

1	TITLE	2	3	4	5
RO	6000/CYBER 70 COMPUTER SYSTEMS DDL FOR THE QUERY UPDATE SUBSCHEMA {QUIDDL} REFERENCE MANUAL	60359200	C	22	SVL
R	6000/CYBER 70/CYBER 170 COMPUTER SYSTEMS & BIT SUBROUTINES REF MANUAL VER 1.0	60359400	C	22	SVL
RO	1700 COMPUTER SYSTEMS MSOS VERSION 4 REFERENCE MANUAL	60361500	D	22	LJL
R	1700 COMPUTER SYSTEMS MSOS DIAGNOSTIC HANDBOOK VERSION 4	60361800	D	--	LJL
R	1700 COMPUTER SYSTEMS 1700 MSOS 4 MS FORTRAN 3A/B REFERENCE MANUAL	60362000	D	22	LJL
R	7054-1 {DT209-C, FA710-A-F, FA719-A-D, MA710-A/B} OPERATION AND PROGRAMMING MANUAL	60363900	J	22	ARH
R	DT209-C {7054-1/2} 6000 COUPLER REF/CE MAN	60364100	R	22	ARH
RO	7054-1 {DT209-C, FA710-A/B/C/D/E/F, FA719- A/B/C/D/MA710-A/B} GEN INFO MANUAL	60364400	D	22	ARH
R	FA710-A/B/C/D {7054-1} DISK CONTROLLER HARDWARE REFERENCE MANUAL	60364500	G	22	ARH
RMP	7600/CYBER 70 MODEL 76 COMPUTER SYSTEMS HARDWARE REFERENCE MANUAL	60367200	C	22	ARH
R	GH 214-B 10-TON CONDENSING UNIT REFRIGERA- TION CE MANUAL	60367300	G	22	ARH
R	DC135-A {6642-1, 7030-XX} DISTRIBUTIVE DATA PATH CE MANUAL	60369400	D	22	ARH
R	AA115-A {72-XX, 73-XX} BASIC UNIFIED PRO- CESSOR CHASSIS 1,3,11 DIAGRAMS CE MAN	60369700	R	22	ARH
R	AA115-A {72-XX, 73-XX} BASIC UNIFIED PRO- CESSOR CHASSIS 4 DIAGRAMS CE MANUAL	60370100	Z	22	ARH
R	AA115-A {72-XX, 73-XX} BASIC UNIFIED PRO- CESSOR CHASSIS 3 DIAGRAMS CE MANUAL	60370200	M	22	ARH
R	AT145-A/B/C {10173} ADDITIONAL PPU CHASSIS FOR 6000 COMPUTERS {INCR TO 20 PPU'S} CE MANUAL	60370600	K	22	ARH
R	AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 4,5,6,7,8 DIAGRAMS MANUAL	60370800	R	22	ARH
R	AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 9 DIAGRAMS MANUAL	60370900	P	22	ARH
R	AE116-D {74-2X} SECOND CENTRAL PROCESSOR CHASSIS 2 WIRE LIST CE MANUAL	60371000	J	22	ARH
R	AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 4 WIRE LIST CE MANUAL	60371100	K	22	ARH
R	AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS WIRE LIST CE MANUAL	60371200	S	22	ARH
R	3100/3150/3170/3200/3300/3500 COMPUTER SYS MASTER/MSOS ALGOL VERSION 1 REF MANUAL	60371800	C	22	ARH
RO	6000/7600/CYBER/CYBER 170 COMPUTER SYSTEMS LOADER INSTANT	60372200	B		ARH
R	SMM V 3 OPERATORS GUIDE	60373800	C	22	ARH
RO	CYBER 76 SMM V3 REFERENCE MANUAL	60373900	C	22	ARH
R	AE116-B {10174-X} SECOND CENTRAL PROCESSOR CONVERTS A 6600-A/B/C WITH SPIGOTS TO A 6700-A/B/C DIAGRAMS, WIRE LIST CE MANUAL {CH. 12}	60374800	D	22	ARH
R	AA115-A {72-XX, 73-XX} BASIC UNIFIED PRO- CESSOR CHASSIS 5 DIAGRAMS CE MANUAL	60377200	G	22	ARH
RMP	AA115-A {72-XX, 73-XX} BASIC UNIFIED PRO- CESSOR CHASSIS 8 DIAGRAMS CE MANUAL	60377300	L	22	ARH

CONT.

1	TITLE	2	3	4	5
R	3L00 SOFTWARE STUDENT MANUAL	60380400	A	3	CDI
R	AT154-A {10173-X} ADDITIONAL MEMORY ACCESS FOR 6613-A/B/C CHASSIS 5 WIRE LIST CE MANUAL	60380800	G	22	ARH
R	AA115-A {72-XX,73-XX} BASIC UNIFIED PROCESSOR REFRIGERATION SYSTEM CE MANUAL	60382300	C	22	ARH
R	AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 10 DIAGRAMS MANUAL	60382600	D	22	ARH
R	AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 11 DIAGRAMS MANUAL	60382700	C	22	ARH
R	AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 12 DIAGRAMS MANUAL	60382800	H	22	ARH
R	6000/7600/CYBER 70 MODELS 72,73,74,76 COMPUTER SYSTEMS ALGOL REF MAN VER 4	60384700	C	22	SVL
R	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS QUERY UPDATE VERSION 2 REFERENCE MANUAL VOLUME 1 & 2	60384900	D	22	SVL
R	6000/CYBER 70 MODELS 72/73/74 COMPUTER SYS QUERY UPDATE MINI USER GUIDE VER 2	60385500	C	22	SVL
RO	6000/7600/CYBER 70 MODELS 72/73/74 COMPUTER SYSTEMS FORTRAN COMMON LIBRARY MATHEMATICAL ROUTINES	60387900	B	22	SVL
R	6682-A SATELLITE COUPLER CE MANUAL	60390100	E	22	ARH
R	AT153-A {10173-4/5,10174-2} ADDITIONAL CENTRAL MEMORY ACCESS FOR 6614-A/B/C COMPUTER SYSTEM CHASSIS 5 WIRE LISTS CE MANUAL	60391900	D	22	ARH
R	AT251-A {CYBER 72,73,74} EXTERNAL DATA CHANNEL	60392700	F	22	ARH
R	FA705-B {3553-1} MASS STORAGE CONTROLLER CE MANUAL	60394600	D	22	ARH
R	FA705-C {3053-2} MASS STORAGE CONTROLLER CE MANUAL	60394700	H	22	ARH
R	3234-D/E MASS STORAGE CONTROLLER CE MANUAL	60394800	D	22	ARH
R	AA121-A {7700} CENTRAL COMPUTER CHANNEL TABS WIRE LISTS CE MANUAL	60398200	B	22	ARH
R	AD102-A {7700} ADJUNCT PROCESSOR CHANNEL TABS, WIRE LISTS CE MANUAL	60399200	B	22	ARH
R	6671-3{FJ440-A} DATA SET CONTROLLER HARDWARE REFERENCE MANUAL	60399900	B	22	ARH
R	FA102-A {1733-1} DISK STORAGE CONTROLLER CE MANUAL	60400100	F	22	LJL
R	AT194-A {6500-D OR 6500-E WITH ECS. CAPABILITY FOR 6400-D WITH AT198-A CHASSIS 2,6,3,8 DIAGRAMS WIRE LIST CE MANUAL	60401200	G	22	ARH
R	FA401-A/B {7021-1} 1X8 MAG TAPE CONTROLLER CE MANUAL	60404100	G	22	ARH
R	7600/CYBER 70 MODEL 76 COMPUTER SYSTEMS SCOPE 2.1 ON-LINE MAINT PROGRAMS REFERENCE MANUAL	60406200	D	22	ARH
R	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS KRONOS 2.1 REFERENCE MANUAL	60407000	C	22	ARH
R	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS KRONOS 2.1 INSTALLATION HANDBOOK	60407500	K	22	ARH
R	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS KRONOS 2.1 TIMESHARING USERS REF MAN	60407600	C	22	ARH

CONT.

1	TITLE	2	3	4	5
R	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS KRONOS 2.1 OPERATORS GUIDE	60407700	D	22	ARH
R	3100/3150/3170/3200/3300/3500 COMPUTER SYS MSOS VERSION 5 OPERATING SYSTEM REFERENCE MANUAL	60410600	C	22	ARH
RO	3100/3150/3170/3200/3300/3500 COMPUTER SYS MSOS VERSION 5 OPERATORS GUIDE	60410700	B	22	ARH
R	3100/3150/3170/3200/3300/3500 COMPUTER SYS MSOS VERSION 5 INSTALLATION HANDBOOK	60410800	D	22	ARH
R	3100/3150/3170/3200/3300/3500 COMPUTER SYS MSOS VERSION 5 DIAGNOSTIC HANDBOOK	60410900	C	22	ARH
N	3100/3150/3170/3200/3300/3500 COMPUTER SYS MSOS VERSION 5 INSTANT	60411000	A		ARH
RO	SMM17 PROGRAM LISTINGS - DMP	60411500	C	22	ARH
RO	SMM17 PROGRAM LISTINGS - AQM	60412100	C	22	ARH
RO	SMM17 PROGRAM LISTINGS - LST	60412200	C	22	ARH
RO	SMM17 PROGRAM LISTINGS - MCC	60412400	C	22	ARH
RO	SMM17 PROGRAM LISTINGS - CDD	60412700	C	22	ARH
RO	SMM17 PROGRAM LISTINGS - DRM	60412800	D	22	ARH
RO	SMM17 PROGRAM LISTINGS - IOM	60413100	C	22	ARH
RO	SMM17 PROGRAM LISTINGS - DPE	60413900	D	22	ARH
RO	SMM17 PROGRAM LISTINGS - EDT	60414700	C	22	ARH
R	3170/3300/3500 COMPUTER SYSTEMS MASTER VERSION 4.0 INSTALLATION HANDBOOK	60415300	D	22	ARH
R	3170/3300/3500 COMPUTER SYSTEMS MASTER VERSION 4.0 REFERENCE MANUAL	60415100	C	22	ARH
R	3170/3300/3500 COMPUTER SYSTEMS MASTER VERSION 4.0 LIBRARY GENERATION AND MAINTENANCE MANUAL	60415400	C	22	ARH
R	3170/3300/3500 COMPUTER SYSTEMS MASTER VERSION 4.0 DIAGNOSTIC HANDBOOK	60415500	C	22	ARH
R	AT149-A {ST.OP.10173} ADDITIONAL MEMORY ACCESS OPTION FOR 6414-A/B/C, 6514- A/B/C CABLE TABS {AT149-A ONLY} CE MANUAL	60415800	C	22	ARH
R	AE116-D {74-2X} SECOND CENTRAL PROCESSOR CHASSIS 2 DIAGRAMS CE MANUAL	60416000	E	22	ARH
R	6500-D WITH ECS CAPABILITY AT198-A/6500-D CONVERSION AND DT143-A ECS KIT DT 205- A ECS INTERFACE LOGIC, AT194-A 6500 ECS CONVERSION THEORY OF INSTALLATION, DIAGRAMS, MAINT AIDS, WIRE LISTS CE MANUAL	60416700	G	22	ARH
N	STANDARD OPTIONS 10309-1 AND 10309-2 GO MODE SDL FOR THE AC104-A AND AC106-A/B CE MANUAL	60417600	A	34	ARH
RO	CYBER 170-MODEL 175 SYSTEMS DATA SITE PREPARATION MANUAL	60420100	A	22	ARH
N	CYBER 170 MODEL 175 CENTRAL COMPUTER AND ALL OPTIONS MAINTENANCE, PARTS DATA HARDWARE MAINTENANCE MANUAL	60420600	DJ	22	ARH
N	CYBER 170 MODEL 175 POWER DISTRIBUTION AND WARNING SYSTEM GEN DESC., OPERATION, THEORY OF OPER., DIAGS, APPENDIX AND WIRE LIST HARDWARE MAINTENANCE MANUAL	60420700	A	22	ARH
R	AC113-B CENTRAL COMPUTER CHASSIS 6 WIRE LIST CE MANUAL	60421400	C	22	ARH
R	AC113-B CENTRAL COMPUTER CHASSIS 7 WIRE LIST CE MANUAL	60421500	C	22	ARH

CONT.

1	TITLE	2	3	4	5
R	AC113-B CENTRAL COMPUTER CHASSIS 8 WIRE LIST CE MANUAL	60421600	D	22	ARH
R	AC113-B CENTRAL COMPUTER CHASSIS 9 WIRE LIST CE MANUAL	60421700	B	22	ARH
R	AC113-B CENTRAL COMPUTER CHASSIS 10 WIRE LIST CE MANUAL	60421800	C	22	ARH
R	AC113-B CENTRAL COMPUTER CHASSIS 12 WIRE LIST CE MANUAL	60422000	C	22	ARH
R	AC113-B CENTRAL COMPUTER CHASSIS 13 WIRE LIST CE MANUAL	60422100	B	22	ARH
RO	SMM17 PROGRAM LISTINGS - MY2	60422300	C	22	ARH
RO	SMM17 PROGRAM LISTINGS - MY1	60422400	C	22	ARH
RO	SMM17 PROGRAM LISTINGS - DP5	60422900	C	22	ARH
R	FE202-A/B {415-30} CARD PUNCH CONTROLLER REFERENCE/CE MANUAL	60425600	C	22	ARH
N	DC145-A/B DISTRIBUTIVE DATA PATH/DT221-A REGISTER GEN DESC, OPERATION, INSTALLATION, AND CHECKOUT, THEORY OF OPERATION DIAGRAMS, MAINT., PARTS DATA, WIRE LISTS CABLE TABS HARDWARE MAINT MAN	60425800	A	22	ARH
N	CYBER 70 MODEL 76 {AA106-A} CYBER 170 MODEL 175 REFRIGERATION SYSTEM, GEN DESC., OPERATION, INSTALLATION AND CHECKOUT, THEORY OF OPERATION, DIAGRAMS, MAINT., PARTS DATA, APPENDIX, WIRE LISTS, HARDWARE MAINTENANCE MANUAL	60427800	A	22	ARH
R	FA722-A/B {7054-21/22/41/42} DISK STORAGE CONTROLLER HARDWARE MAINTENANCE MANUAL	60428500	J	22	ARH
N	AA106-A CENTRAL COMPUTER/AB101-A, AB102-A/B, AT174-A PERIPHERAL PROCESSOR UNIT MAINTENANCE CE MANUAL	60429900	A	22	ARH
N	GH506-A/B POWER DISTRIBUTION UNIT USED WITH POWER DISTRIBUTION AND WARNING SYSTEM AA106-A CENTRAL COMPUTER A/B102-A/B I/O STATION CABINET/GK171-A I/O STATION CABINET MODIFICATION KIT CE MAN	60433400	A	22	ARH
N	AA106-A {BS101/2-A, BB360-B, AT311/312-A} CENTRAL COMPUTER INSTALLATION AND CHECKOUT, THEORY OF OPERATION, DIAGS., MAINT. AIDS, PARTS DATA VOLUMES 1-3 CE MANUAL	60433600	A	22	ARH
N	AA106-A {BS101/2-A, BB360-B, AT311/312-A} CENTRAL COMPUTER				
N	CHASSIS 7 WIRE LISTS CE MANUAL	60433700	A	22	ARH
N	CHASSIS 8 WIRE LISTS CE MANUAL	60433800	A	22	ARH
N	CHASSIS 9 WIRE LISTS CE MANUAL	60433900	A	22	ARH
N	CHASSIS 2 WIRE LISTS CE MANUAL	60434700	A	22	ARH
N	CHASSIS 3 WIRE LISTS CE MANUAL	60434800	A	22	ARH
N	CHASSIS 4 WIRE LISTS CE MANUAL	60434900	A	22	ARH
N	CHASSIS 5 WIRE LISTS CE MANUAL	60435000	A	22	ARH
N	CHASSIS 6 WIRE LISTS CE MANUAL	60435100	A	22	ARH
N	6000/CYBER 70/CYBER 170/COMPUTER SYSTEMS ON LINE MAINTENANCE SOFTWARE REFERENCE MANUAL, KRONOS 2.1-X/NOS V1.0.0	60436600	A	22	ARH
N	SYSTEM 17 SERIES MINI COMPUTER SYSTEMS SITE PREPARATION MAN SECTION 1, GEN SITE REQUIREMENT	60437000	A	22	ARH

CONT.

1	TITLE	2	3	4	5
N	SYSTEM 17 SERIES MINI COMPUTER SYSTEMS SITE PREPARATION MAN SECTION 2 - SYSTEM DATA	60437100	A	22	ARH
N	SYSTEM 17 SERIES MINI COMPUTER SYSTEMS SITE PREPARATION SECTION 3 - PERIPHERAL EQUIPMENT DATA	60437200	A	22	ARH
RO	SMM17 PROGRAM LISTINGS {GT0}	60437400	B	22	ARH
RO	SMM17 PROGRAM LISTINGS {GT1}	60437500	B	22	ARH
RO	SMM17 PROGRAM LISTINGS - GT2	60437600	B	22	ARH
RO	SMM17 PROGRAM LISTINGS - GT3	60437700	B	22	ARH
RO	SMM17 PROGRAM LISTINGS - GT5	60437900	B	22	ARH
RO	SMM17 PROGRAM LISTINGS - GT6	60438000	B	22	ARH
RO	SMM17 PROGRAM LISTINGS - LP5	60438100	B	22	ARH
RO	SMM17 PROGRAM LISTINGS - KEY	60438400	B	22	ARH
N	FA444-A/B, FF445-A/B MAGNETIC TAPE CONTROLLER MB434-A CONTROLWARE INSTALLATION AND CHECKOUT, MAINTENANCE, DIAGS, GEN DESC., OPERATION, THEORY OF OPER., PARTS DATA, WIRE LISTS, LEVEL 2 HARDWARE MAINTENANCE MANUAL VOLUMES 1-3	60438500	A	22	ARH
RO	SMM17 PROGRAM LISTINGS - MDC	60438600	B	22	ARH
R	6640-D EXTENDED CORE STORAGE CONTROLLER GEN. DESC., OPER., THEORY OF OPER., INSTALLATION AND CHECKOUT, MAINT., DIAGS, PARTS DATA, APPENDIX AND WIRE LISTS CE MANUAL	60440500	B	22	ARH
N	6681-F DATA CHANNEL CONVERTER GEN DESC., OPERATION, INSTALLATION AND CHECKOUT, THEORY OF OPER., DIAGS., MAINT., PARTS DATA, WIRE LIST, CE MANUAL	60440800	A	22	ARH
N	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS AUTOMATED INTEGRATED DESIGN SYSTEM, SEMIAUTOMATIC ARTWORK GENERATION {SAAG} USERS GUIDE	60441000	A	22	ARH
N	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS AUTOMATED INTEGRATED DESIGN SYSTEM GENERAL PURPOSE WIRE WRAP {GPWW} USERS GUIDE	60443100	A	22	ARH
N	SMM17 PROGRAM LISTINGS - DPC	60446100	A	22	ARH
N	SMM17 PROGRAM LISTINGS - MTX	60446200	A	22	ARH
N	SMM17 PROGRAM LISTINGS - PET	60446300	A	22	ARH
N	SMM17 PROGRAM LISTINGS - PAD	60446400	A	22	ARH
N	SMM17 PROGRAM LISTINGS - BDL	60446500	A	22	ARH
N	SMM17 PROGRAM LISTINGS - REP	60446600	A	22	ARH
N	SMM17 PROGRAM LISTINGS - INS	60446700	A	22	ARH
N	SMM17 PROGRAM LISTINGS - CMD	60446800	A	22	ARH
N	SMM17 PROGRAM LISTINGS - CPY	60447700	A	22	ARH
RO	6000/CYBER 170/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS CYBER RECORD MANAGER VERSION 1.1 MULTIPLE INDEX PROCESSOR PROGRAMMING SYSTEMS BULLETIN	60492900	B	22	SVL
N	6000/7600/CYBER 70/CYBER 170 COMPUTER SYS CYBER COMMON UTILITIES REF MANUAL	60493300	A	3	SVL
N	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS SCOPE INTEGRATED SCHEDULER TUNING GUIDE PROGRAMMING SYSTEMS BULLETIN	60493500	A	22	SVL
N	HOSPITAL COMMUNICATIONS SYSTEM DIGISCRIBE OPTION OPERATORS GUIDE {QSE 10892}	62995800	A-0		LJL

CONT.

1	TITLE	2	3	4	5
N	CV403-A {10892} HOSPITAL COMMUNICATIONS SYSTEM DIGISCRIBE OPTION ON-ISTE MAINTENANCE MANUAL	62995900	A-0	22	LJL
N	CV403-A DIGISCRIBE OPTION REPAIR CENTER CE MANUAL	62996000	A-0	22	LJL
N	AN/UJK-25{V} DATA PROCESSING SET INCLUDING CP1201{V}/UJK-25 {V} DIGITAL DATA COMPUTER {5601 SERIES} MU/618/UJK-25 {V} CORE MEMORY UNIT {5604 SERIES} REFERENCE MANUAL	69651800		22	MSP
RO	CJ112 PAGE READER G-H {CS/N151-200} DIAGRAMS CE MANUAL	70601700	E	22	R0K
RO	33301/33302 SUBSYSTEMS ON-LINE DIAGNOSTICS MANUAL {COLDS}	70602900	D	22	NRM
N	BR2B1 DISK STORAGE UNIT DIAGRAMS AND WIRE LISTS CE MANUAL	70607900	D	22	NRM
RO	33301 MULTIPLE DISK SYSTEM INSTALLATION CE MANUAL	70608100	G	22	NRM
R	33301 MULTIPLE DISK SYSTEM TROUBLESHOOTING MANUAL	70608200	C	22	NRM
R	BR1A9-B VOICE COIL DRIVE PARTS DATA B01 AND ABOVE CE MANUAL	70609300	J	22	NRM
R	BR2B1 DISK STORAGE UNIT MAINTENANCE MANUAL	70612500	C	3	NRM
R	TB301-A/B FIELD TEST EXERCISER MAINTENANCE MANUAL	70612800	G	3	NRM
R	FA7A4-A/B PLUG COMPATIBLE CONTROLLER MAINT CE MANUAL	70613800	G	22	NRM
R	BR2A1-D DISK STORAGE UNIT MAINTENANCE MANUAL	70616300	C	22	NRM
R	BR2A1-L DISK STORAGE UNIT DIAGRAMS CE MANUAL	70616400	F	22	NRM
R	BR1A9 DISK STORAGE UNIT DIAGRAMS, WIRE LISTS, MAINT. AIDS {MODS B03 AND ABOVE}	70617100	H	22	NRM
R	BR5A1 DISK STORAGE UNIT MAINTENANCE MANUAL	70617800	E	22	NRM
R	BR5A1 DISK STORAGE UNIT PARTS DATA CE MANUAL	70618000	P	22	NRM
R	BR1B3 DISK STORAGE UNIT PARTS DATA CE MANUAL	70620600	G	22	NRM
R	FR113-A {731-10/12-732-10/12} BUFFER CONTROLLER MAINTENANCE CE MANUAL	70621400	F	22	NRM
R	BR2A7 DISK STORAGE UNIT DIAGRAMS AND WIRE LIST	70622200	L	22	NRM
RM	BR2A8 DISK STORAGE UNIT DIAGRAMS AND WIRE LISTS CE MANUAL	70622300	M	22	NRM
R	BR2A8 DISK STORAGE UNIT MAINTENANCE CE MAN	70622400	G	22	NRM
R	BR2A7 DISK STORAGE UNIT PARTS DATA CE MANUAL	70622500	M	22	NRM
R	BR2A6-B DISK STORAGE UNIT MAINT. CE MANUAL	70622600	H	22	NRM
R	BR2A6-B DISK STORAGE UNIT PARTS DATA CE MAN	70622800	N	22	NRM
R	BR5A2 DISK STORAGE UNIT MAINTENANCE MANUAL	70624500	G	22	NRM
R	BR5A2 DISK STORAGE UNIT PARTA DATA CE MANUAL	70624700	J	22	NRM
R	BR304 DISK STORAGE UNIT MAINTENANCE CE MAN	70627900	D	22	NRM
R	BR304 DISK STORAGE UNIT GENERAL DESCRIPTION, OPERATION, THEORY OF OPERATION, KEY TO LOGIC, INTEGRATED/DISCRETE CIRCUITS CE MANUAL	70628000	C	22	NRM
R	BR304 DISK STORAGE UNIT PARTS DATA CE MANUAL	70628100	C	22	NRM
R	BR3B4 DISK STORAGE UNIT MAINTENANCE MANUAL	70628200	L	3	NRM
R	BR3B4 DISK STORAGE UNIT MAINTENANCE MANUAL	70628400	G	3	NRM
N	BR5A3 DISK STORAGE UNIT GEN DESC., OPER., INSTALLATION/CHECKOUT, THEORY OF OPER., MAINTENANCE CE MANUAL	70628500	B	22	NRM
N	BR5A3 DISK STORAGE UNIT DIAGRAMS AND WIRE LISTS CE MANUAL	70628600	D	22	NRM

CONT.

1	TITLE	2	3	4	5
R	BR501 DISK STORAGE UNIT GENERAL DESCRIPTION, OPERATION, THEORY OF OPERATION CE MANUAL	70629200	F	22	NRM
RMP	BR501 DISK STORAGE UNIT PREVENTIVE AND CORRECTIVE MAINTENANCE DIAGRAMS AND WIRE LISTS CE MANUAL	70629300	M	22	NRM
R	BR501 DISK STORAGE UNIT PARTS DATA CE MANUAL	70629400	K	22	NRM
R	BR303 DISK STORAGE UNIT GENERAL DESCRIPTION, OPERATION, THEORY OF OPERATION CE MAN	70629500	C	22	NRM
R	BR303 DISK STORAGE UNIT INSTALLATION/CHECK-OUT, PREVENTIVE/CORRECTIVE MAINT, DIAGRAMS WIRE LIST, CE MANUAL	70629600	H	22	NRM
R	BR303 DISK STORAGE UNIT PARTS DATA CE MANUAL	70629700	J	22	NRM
N	BR3B5 DISK STORAGE UNIT PARTS DATA MANUAL	70630500	F	3	NRM
R	BJ5XX STORAGE MODULE DRIVE MAINTENANCE MAN	70630900	K	3	NRM
R	BJ5XX STORAGE MODULE DRIVE PARTS DATA CE MAN	70631100	L	3	NRM
N	BR2B2/3 DISK STORAGE UNIT GEN. DESC., MAINTENANCE CE MANUAL	70631300	D	22	NRM
R	BR2B2/3 DISK STORAGE UNIT DIAGRAMS AND WIRE LISTS CE MANUAL	70631400	F	22	NRM
R	BR2B2/3 DISK STORAGE UNIT PARTS DATA CE MAN	70631500	G	22	NRM
N	CYBER 1000 {FA101-A, DY128-A} DISK PACK CONTROLLER HARDWARE MAINTENANCE MANUAL	73361200	B	22	STA
N	CYBER 1000 MAGNETIC TAPE CONTROLLER DY120-A, FA419-A HARDWARE MAINTENANCE MANUAL	74607500		22	STA
N	CYBER 1000/3000 SERIES CONTROLLER-ADAPTER {DY122-A} HARDWARE MAINTENANCE MANUAL	74660300	A	22	STA
N	CYBER 1000 {DY127-A} HIGH-SPEED LINE CONTROLLER HARDWARE MAINTENANCE MANUAL	74664300	A	22	STA
N	CYBER 1000/1700 SERIES {DY123-A} CONTROLLER ADAPTER HARDWARE MAINTENANCE MANUAL	74675500	A	22	STA
N	DY121-A {CYBER 1000} FAST DISK CONTROLLER HARDWARE MAINTENANCE MANUAL	74691800	A	22	STA
N	DW110-A {CYBER 1000} TWO BAY EXCHANGE UNIT HARDWARE MAINTENANCE MANUAL	74717600	A	22	STA
N	DW105-A/DW111-A {CYBER 1000} THREE BAY EXCHANGE UNIT HARDWARE MAINTENANCE MAN	74720400	A	22	STA
N	DY124-A/DY129-A {CYBER 1000} CONTROLLER EXTENSION CABINETS HARDWARE MAINT MAN	74720500	A	22	STA
N	DY107-110-A {CYBER 1000} LINE MODULE EXTENSION CABINET HARDWARE MAINT MANUAL	74724500	A	22	STA
N	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS MARS VI REF MANUAL FOR PARTIAL INVERSION KRONOS 2.1 USAGE	76070100		3	CYB
N	6000 CYBER 70 MODELS 72,73,74 COMPUTER SYS TOTAL-CDC REFERENCE MANUAL VERSION 1	76070300		3	CYB
N	1FMS-INTERACTIVE FINANCIAL MODELING SYSTEM USER INFORMATION MANUAL	76070400		3	CYB
N	SYSCAP-II - SYSTEM OF CIRCUIT ANALYSIS PROGRAMS U.I.M.	76070600		3	CYB
R	CC-TEGAS3-TEST GENERATION AND SIMULATION SYSTEM USER INFORMATION MANUAL	76070700	A	3	CYB
N	SYSTEMS PROFESSIONAL PROGRAMS COST GUIDE USER COST GUIDE	76070800		3	CYB
N	ANSYS - ENGINEERING ANALYSIS SYSTEM EXAMPLES MANUAL	76070900		3	CYB
N	XEDIT-EXTENDED KRONOS TEXT EDITOR U.I.M.	76071000		3	CYB
N	FASTIME/LOADFLOW-POWER SYSTEM ANALYSIS USER INFORMATION MANUAL	76071200		3	CYB

CONT.

1	TITLE	2	3	4	5
N	ATHENA/ON-LINE INTERACTIVE RETRIEVAL UPDATE LANGUATE USER INFORMATION MANUAL	76071400	A	3	CYB
N	CYBERNET CYBER 70/MODEL 76 {PRELIMINARY} TERMINAL USERS GUIDE	76072700		3	CYB
N	SYSTEM 2000 LEVEL 2-A MULTI-PURPOSE DATA MANAGEMENT SYSTEM USER INFORMATION MANUAL	76074000		3	CYB
N	SYSTEM 2000 LEVEL 2-A MULTI-PURPOSE DATA MANAGEMENT SYSTEM DIAGNOSTIC MESSAGE SUPPLEMENT	76074300		3	CYB
N	SYSTEM 2000 LEVEL 2-A MULTI-PURPOSE DATA MANAGEMENT SYSTEM IMMEDIATE ACCESS FEATURE SUPPLEMENT	76074400		3	CYB
N	SYSTEM 2000 LEVEL 2-A MULTI-PURPOSE DATA MANAGEMENT SYSTEM FORTRAN PROCEDURAL LANGUAGE SUPPLEMENT	76074600		3	CYB
N	SYSTEM 2000 LEVEL 2-A MULTI-PURPOSE DATA MANAGEMENT SYSTEM REPORT WRITER FEATURE SUPPLEMENT	76074700		3	CYB
R	PUNCH CARD EQUIPMENT STUDENT MANUAL	76360001	C	3	CDI
R	BR3B8 DISK STORAGE UNIT MAINTENANCE CE MAN	83301000	K	3	NRM
R	BR3B8-DISK STORAGE UNIT REFERENCE MANUAL	83301100	C	3	NRM
R	BR3B8 DISK STORAGE UNIT PARTS DATA CE MANUAL	83301200	K	3	NRM
R	3330/DISK MEMORY SUBSYSTEM SITE PLANNING KIT	83301400	C	22	NRM
R	33302 DISK MEMORY SUBSYSTEM REFERENCE MANUAL	83301500	B	22	NRM
R	33302 DISK MEMORY SUBSYSTEM INSTALLATION CE MANUAL	83301600	D	22	NRM
R	FA721 STORAGE CONTROL HARDWARE REFERENCE CE MANUAL	83301800	B	22	NRM
R	FA721 STORAGE CONTROL PREVENTIVE/CORRECTIVE MAINT. W/L CE MANUAL	83301900	E	22	NRM
R	FA721 STORAGE CONTROL DIAGRAMS VOLUME 2 CE MANUAL	83302000	R	22	NRM
R	FA721 STORAGE CONTROL EIGHT VOLUME CAU FUNCTIONAL MICROPROGRAM CE MANUAL	83302100	E	22	NRM
RO	BR5A5 DISK STORAGE UNIT GEN DESC., OPERATION, INSTALLATION AND CHECKOUT, THEORY OF OPERATION AND MAINTENANCE CE MANUAL	83302300	D	22	NRM
R	BR5A5 DISK STORAGE UNIT DIAGRAMS, MAINT. AIDS, WIRE LISTS CE MANUAL	83302400	C	22	NRM
RO	BR5A5 DISK STORAGE UNIT PARTS DATA CE MANUAL	83302500	E	22	NRM
R	BR502/4 DISK STORAGE UNIT PREVENTIVE CORRECTIVE MAINTENANCE, DIAGS., WIRE LIST, CE MANUAL	83302600	G	22	NRM
R	BR502/4 DISK STORAGE UNIT PARTS DATA CE MAN	83302800	F	22	NRM
R	BR305 DISK STORAGE UNIT - PREVENTIVE CORRECTIVE MAINTENANCE, DIAGS., WIRE LISTS CE MANUAL	83303100	B	22	NRM
R	BR305 DISK STORAGE UNIT PARTS DATA CE MANUAL	83303300	C	22	NRM
R	BR3D1-DISK STORAGE UNIT MAINTENANCE MANUAL	83305700	E	3	NRM
R	BR3D1-B DISK STORAGE UNIT REFERENCE MANUAL	83305800	C	3	NRM
R	BR3D1-B DISK STORAGE UNIT PARTS DATA MANUAL	83305900	E	3	NRM
N	FA721 STORAGE CONTROL PARTS DATA CE MANUAL	83306000	F	22	NRM
RO	FV605 CONTROLLER ADAPTER UNIT GEN. DESC., THEORY OF OPERATION,	83306100	B	22	NRM
RO	FV605 CONTROLLER ADAPTER UNIT PARTS DATA CE MANUAL	83306300	C	22	NRM
N	TB207-A FIELD TEST UNIT MAINTENANCE MANUAL	83307900	B	3	NRM

CONT.

1	TITLE	2	3	4	5
N	BJ7XX STORAGE MODULE DRIVE MAINTENANCE MAN	83308400	A	3	NRM
N	BJ7XX STORAGE MODULE DRIVE REFERENCE MANUAL	83308500	A	3	NRM
N	BJ7XX STORAGE MODULE DRIVE PARTS DATA MANUAL	83308600	A	3	NRM
R	BR306/7 DISK STORAGE UNIT PREVENTIVE CORRECTIVE MAINT., DIAGRAMS AND WIRE LISTS	83308700	C	22	NRM
R	BR306/7 DISK STORAGE UNIT REFERENCE MANUAL	83308800	B	22	NRM
R	BR306/7 DISK STORAGE UNIT PARTS DATA CE MAN	83308900	C	22	NRM
R	BR306 DISK STORAGE UNIT MAINTENANCE CE MANUAL	83309300	C	3	NRM
R	BR306 DISK STORAGE UNIT REFERENCE MANUAL	83309400	B	22	NRM
R	BR306 DISK STORAGE UNIT PARTS DATA CE MANUAL	83309500	C	3	NRM
R	BJ6XX STORAGE MODULE DRIVE MAINTENANCE MAN	83310800	C	3	NRM
R	BJ6XX STORAGE MODULE DRIVE REFERENCE MANUAL	83310900	B	3	NRM
N	BR2A1D {S/C 19 AND ABOVE} DISK STORAGE UNIT PARTS DATA CE MANUAL	83311400	A	22	NRM
N	BR3D3-A/B DISK STORAGE UNIT MAINTENANCE MAN	83311600	A	22	NRM
N	BR3D3-A/B DISK STORAGE UNIT REFERENCE MANUAL	83311700	A	3	NRM
R	FA721 STORAGE CONTROL 16 VOL CAU FUNCTIONAL MICROPROGRAM MANUAL	83311900	E	22	NRM
RO	FA721 STORAGE CONTROL IN-LINE DIAGNOSTICS MICROPROGRAM CE MANUAL	83312000	E	22	NRM
RO	FA721 STORAGE CONTROL STANDARD DIAGNOSTICS MICROPROGRAM CE MANUAL	83312100	C	22	NRM
N	TB4A1-A FIELD TEST UNIT MAINTENANCE MANUAL	83312300	A	3	NRM
N	BR3D4 DISK STORAGE UNIT MAINTENANCE MANUAL	83313100	A	3	NRM
N	BR3D4 DISK STORAGE UNIT REFERENCE MANUAL	83313200	A	3	NRM
N	BR3D4 DISK STORAGE UNIT PARTS LIST MANUAL	83313300	A	3	NRM
N	BR5A6 DISK STORAGE UNIT MAINTENANCE MANUAL	83313400	B	3	NRM
N	BR5A6 DISK STORAGE UNIT REFERENCE MANUAL	83313500	B	3	NRM
N	BR5A6 DISK STORAGE UNIT PARTS DATA MANUAL	83313600	A	3	NRM
N	BR306/BR307-D,E DISK STORAGE UNIT PREVEN- TIVE/CORRECTIVE MAINTENANCE, DIAGRAMS, AND WIRE LISTS CE MANUAL	83314000	A	22	NRM
N	FV605-D-G CONTROLLER ADAPTER UNIT PREVEN- TIVE/CORRECTIVE MAINT. DIAGRAMS, WIRE LISTS CE MANUAL	83315400	A	22	NRM
N	FA203 CONTROLLER MICRODIAGNOSTIC USERS CE MANUAL	83315600	A	22	NRM
N	FA203 CONTROLLER FLEXIBLE DISK DRIVE CE MANUAL	83315700	A	22	NRM
N	FA203 CONTROLLER MICRODIAGNOSTIC CE MANUAL	83315800	A	22	NRM
N	FA203 CONTROLLER THEORY OF OPERATION CE MAN	83316100	A	22	NRM
N	FA203 CONTROLLER PARTS DATA CE MANUAL	83316200	A	22	NRM
N	FA203 CONTROLLER HARDWARE MICROPROGRAM CE MANUAL	83316300	A	22	NRM
N	FA203 CONTROLLER DIAGNOSTIC MICROPROGRAM CE MANUAL	83316400	A	22	NRM
N	FA203 CONTROLLER DUAL ACCESS FEATURE MICRO- PROGRAM CE MANUAL	83316600	A	22	NRM
RMP	CYBERNET/KRONOS 2.1 TIME-SHARING FORTRAN REFERENCE MANUAL	84001700	B	3	CYB
R	EAC/EASE-2 USER INFORMATION/THEORHETICAL MANUAL	84002700	A	3	CYB
RO	CYBERNET/PROSE SYSTEM GUIDE	84002900	A	3	CYB
RO	GPSS V/GENERAL PURPOSE SIMULATION SYSTEM V/6000 GENERAL INFORMATION MANUAL	84003900	A	3	CYB
N	MODIFIED PCA FLAT PLATE, FLAT SLAB, WAFFLE SLAB, AND FRAME ANALYSIS AND DESIGN, WORKING OR ULTIMATE STRENGTH 1971 AC1 USERS GUIDE	84009400		3	CYB

CONT.

1	TITLE	2	3	4	5
N	FAAST-FLUID ANALYSIS AND SIMULATION TECHNIQUE U.I.M.	84009800		3	CYB
R	SYSTEM 2000 DATA MANAGEMENT SYSTEM USER INFORMATION MANUAL LEVEL II	86604500	J	3	CYB
RMP	CYBERNET/KRONOS LIBRARY PROGRAMS	86605900	D	3	CYB
RO	STRU-PAK PROGRAM ABSTRACTS	86608700	B	3	CYB
RO	E/CUBE ENERGY ANALYSIS CYBERNET SERVICE GUIDELINES	86608900	C	3	CYB
RO	SYSTEM 2000 LEVEL 2-A MULTI-PURPOSE DATA MANAGEMENT SYSTEM MINI MANUAL	86615600	B		CYB
RO	CYBERLOAN GENERAL INFORMATION MANUAL	86616100	A	3	CYB
R	NASTRAN APPLICATIONS MANUAL	86616700	I	3	CYB
N	CJ127 HARDWARE REFERENCE/CE MANUAL	87906700	A	22	ROK
N	CJ520 DOCUMENT READER LOGIC RACK HARDWARE MAINTENANCE MANUAL VOLUME 1	87911800	A	22	ROK
N	CJ127 OCR DOCUMENT READER DIAGRAMS VOLUME 2 HARDWARE REFERENCE/CE MANUAL	87971600		22	ROK
N	CJ127 OCR DOCUMENT READER PARTS DATA VOLUME 3 HARDWARE REFERENCE/CE MANUAL	87971700	01	22	ROK
RO	929 DRIVE (1784 COMP. SYST.) OCR SOFTWARE REFERENCE MANUAL	87971800	B	22	ROK
N	1700 COMPUTER SYSTEMS TOTES OPERATORS GUIDE	88818500	A	22	LJL
N	1700 COMPUTER SYSTEMS TOTES FILE MANAGER UTILITY PROGRAM REFERENCE MANUAL	88947900	A	22	LJL
N	1700 COMPUTER SYSTEMS REDUCED CORE OPERATING SYSTEM REFERENCE MANUAL V2	88948500	A	22	LJL
N	1700 COMPUTER SYSTEMS TIMESHARE 2.0 REF MAN	88964000	A	22	LJL
N	1576 (FV4A3,498) STALL ALARM UNIT HARDWARE REFERENCE/CE MANUAL	88981000	A	22	LJL
N	EB3A1-A/D FOUR CHANNEL DIGITAL-TO-ANALOG CONVERTER HARDWARE REFERENCE/CE MANUAL	88981100	A	22	LJL
N	KEY TO LOGIC SYMBOLS G.I.M.	88981500	B	22	LJL
N	6000/CYBER 170/CYBER 70 MODELS 72,73,74 C COMPUTER SYSTEMS CCP SUPPORT SOFTWARE 1 REFERENCE MANUAL	88988400	A	22	LJL
N	6000/CYBER 170/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS CCP SUPPORT SOFTWARE PASCAL COMPILER REFERENCE MANUAL	88988500	A	22	LJL
N	6000/CYBER 170/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS CCP SUPPORT SOFTWARE 1 GENERAL INFORMATION MANUAL	88988600	A	22	LJL
N	6000/CYBER 170/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS CCP SUPPORT SOFTWARE 1 DIAGNOSTIC HANDBOOK	88988700	A	22	LJL
N	6000/CYBER 170/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS CCP SUPPORT SOFTWARE 1 MICRO ASSEMBLER REFERENCE MANUAL	88988800	A	22	LJL
N	6000/CYBER 170/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS CCP SUPPORT SOFTWARE 1 MACRO ASSEMBLER REFERENCE MANUAL	88988900	A	22	LJL
N	SYSTEM 17 INSTALLATION MANUAL	88996000	A	22	LJL
N	1700 COMPUTER SYSTEMS 1700 RCOS 2 ASSEMBLER REFERENCE MANUAL	88997600	A	22	LJL
R	1784-1/2 COMPUTER SYSTEM CE MANUAL	89633300	04	22	LJL
N	FF524-A LINE PRINTER CONTROLLER	89637300	04	22	LJL
N	FE119-A CARD READER CONTROLLER HARDWARE REFERENCE/CE MANUAL	89637500	03	22	LJL
N	1732-2 (SYSTEM 17) MAGNETIC TAPE TRANSPORT CONTROLLER REFERENCE MANUAL	89637600	03	22	LJL

CONT.

1	TITLE	2	3	4	5
N	FA442-A NRZI MAGNETIC TAPE TRANSPORT CONTROLLER GEN. DESC., OPER AND PROGRAMMING, INSTALLATION/CHECKOUT, THEORY OF OPERATION, DIAGS., MAINT., MAINT. AIDS, P/L, W/L, GLOSSARY	89637700	02	22	LJL
N	FA716-A CARTRIDGE DISK DRIVE CONTROLLER CE MANUAL	89638100	02	22	LJL
N	DJ81-A SYNCHRONOUS COMMUNICATIONS CONTROLLER AND DISTRIBUTION PANEL CE MANUAL	89638300	02	22	LJL
N	FJ606-A SYNCHRONOUS COMMUNICATIONS CONTROLLER {SCC} AND DISTRIBUTION PANEL CE MANUAL	89638500	01	22	LJL
N	SYSTEM 17 REAL TIME CLOCK PRELIMINARY REFERENCE MANUAL	89638800	01	22	LJL
R	1784 {SYSTEM 17} COMPUTER SYSTEM INPUT/OUTPUT SPECIFICATIONS	89673100	02	22	LJL
N	SYSTEM 17 KEY TO LOGIC SYMBOLS	89723700		22	LJL
N	AT310-A TTL A/Q-DSA BUS EXPANDER HARDWARE REFERENCE/CE MANUAL	89758600	01	22	LJL
N	1732-3 {SYSTEM 17} MAGNETIC TAPE TRANSPORT CONTROLLER REFERENCE MANUAL	89769400	01	22	LJL
N	FA446-A NRZI-LCTT MAGNETIC TAPE TRANSPORT CONTROLLER CE MANUAL	89769500	01	22	LJL
N	FV497-A, FV618-A PHASE ENCODING FORMATTER CE MANUAL	89796100	01	22	LJL
N	929 DOCUMENT READER OCR MEDIA MANUAL	91604300	A	22	ROK
R	955/959 PAGE AND DOCUMENT READER OCR MEDIA MANUAL	91604500	B	22	ROK
N	1700/SC1700 COMPUTER SYSTEMS ASSEMBLER OCR SOFTWARE REFERENCE MANUAL	91634000	A	22	ROK
R	595 PRINT CARTRIDGE TYPE D MANUAL	91860100	A	22	RHT
N	915/8092 COMPUTER SYSTEMS GRASP OCR SOFTWARE INSTALLATION HANDBOOK	91661300			ROK
N	CW195 OCR-B PLUGGABLE FONT OPTION GEN. DESC. INSTALLATION/CHECKOUT, DIAGRAMS HARDWARE REFERENCE/CE MANUAL	91662900	A	22	ROK
N	959 PAGE AND DOCUMENT READER SYSTEM OPERATORS GUIDE	91669100	A	22	ROK
N	915/919-1700 SERIES & 955/959 1700 SERIES COMPUTER SYSTEMS PAGE READER SETUP-SOURCE EDIT TAPE UPDATE PROGRAM OCR SOFTWARE REFERENCE MANUAL	91674400	A	22	ROK
N	8092 COMPUTER SYSTEM 921 MONITOR OCR REFERENCE MANUAL V.1	91681100	A	22	ROK
N	580 LINE PRINTER EQUIPMENT INTRODUCTION, OPERATING INSTRUCTIONS, PRINCIPLES OF OPERATION REFERENCE MANUAL	91858600	B	22	RHT
N	580 LINE PRINTER EQUIPMENT INSTALLATION/CHECKOUT/PREVENTIVE MAINTENANCE CORRECTIVE MAINT., PARTS REPLACEMENT FIELD SERVICE MANUAL VOLUME 1	91858700	B	22	RHT
NMP	580 LINE PRINTER EQUIPMENT FIELD SERVICE MANUAL VOLUME II	91858800	B-01	22	RHT
N	CW207 HANDPRINT UNIT MODEL A01 HARDWARE MAINTENANCE MANUAL VOLUME 1	91558900	A	22	ROK
N	580 PRINT CARTRIDGE GEN DESC., OPER, AND PROGRAMMING, THEORY OF OPERATION, MAINTENANCE, PARTS DATA HARDWARE REFERENCE/CE MANUAL	91559000	C	22	RHT

CONT.

1	TITLE	2	3	4	5
RO	9322 LINE PRINTER EQUIPMENT INTERCONNECTION PRINT HEAD LOGIC/CONTROLLER LOGIC/ TIMING DIAGRAMS, FSM VOLUME II	91859200	B	34	RHT
R	595 PRINT CARTRIDGE TYPE D MANUAL	91860100	A	22	RHT
N	580 LINE PRINTER EQUIPMENT CONTROLS AND INDICATORS, OPERATING PROCEDURES, OPERATOR MAINTENANCE OPERATOR HANDBOOK	91860400	B	22	RHT
N	1700 COMPUTER SYSTEM TOTES G.I.M.	96716700	A	22	LJL
R	AF107-A {ST.OPT.10287-4} 3100 ENHANCED BLOCK CONTROL AND BDP INTERFACE CE MAN	97402300	B	22	PLY
N	10287-1 {AF105-A, 8T193-A, CD124-A} 3200 ENHANCED BLOCK CONTROL OPTION REF MAN	97402400	A	22	PLY
N	AF105-A {ST.OPT.10287-1} 3200 ENHANCED BLOCK CONTROL MODIFICATION CE MANUAL	97402500	A	22	PLY
N	AT146-A {10287-3} MEMORY INCREMENT 3200 CE MANUAL	97402700	A	22	PLY
*RO	MASTER OPERATING SYSTEM - DATA SHEET	10035700	-	--	ADV
*RO	9427H DOUBLE-DENSITY CART DISK DRIVE - DATA SHEET	20028300	B	--	ADV
*RO	CYBERNET: PDS/MAGEN - DATA SHEET	20032100	C	--	ADV
*RO	CYBERNET: QA-PAK-QUESTIONNAIRE	20057000	A	--	ADV
*RO	CYBERNET: PIPEFLEX - DATA SHEET	20057100	A	--	ADV
*RO	CYBERNET: SYSCAP II - DATA SHEET	20057200	B	--	ADV
*RO	CYBERNET: MAP FEB. 1975 - DATA SHEET	20059700	D	--	ADV
*RO	MILITARY DISK STORAGE UNIT - DATA SHEET	20063100	B	--	ADV
*RO	REPORT ON SOCIAL RESPONSIBILITY - BROCHURE	20067200	-	--	ADV
*RO	669 MAG TAPE TRANSPORTS - DATA SHEET	20067300	-	--	ADV
*RO	667 MAG TAPE TRANSPORTS - DATA SHEET	20067500	-	--	ADV
*RO	BRIDGE ANALYSIS & RATING SYSTEM - DATA SHEET	20070200	B	--	ADV
*RO	9760 & 9762 STORAGE MOD DRIVES - DATA SHEET	20070400	E	--	ADV
*RO	CONSULTING SERVICES FOR DATA COMM SYSTEM - BROCHURE	20071500	B	--	ADV
*RO	PERIPHERAL PRODUCTS CATALOG - BROCHURE	20083800	A	--	ADV
*RO	33158 MONOLITHIC MAIN MEMORY - DATA SHEET	20085700	-	--	ADV
*RO	MULTIPARTITION MSOS 5 - DATA SHEET	20087100	-	--	ADV
*RO	1987 CABINET - DATA SHEET	20089200	A	--	ADV
*RO	MODEL 77-2 CYBER GRAPHICS TERMINAL - DATA SHEET	20090300	-	--	ADV
*RO	844-21 MASS STORAGE SUBSYSTEM - DATA SHEET	20101200	-	--	ADV
*N	1743 COMMUNICATIONS CONTROL - DATA SHEET	20106000	-	--	ADV
*R	CYBER 170 PRESENTATION GUIDE	20106200	A	22	LDS
*RO	SYSTEM 2000 G-P DATA BASE MGMT - BROCHURE	20108400	A	--	ADV
*RO	2570-1 LINE PRINTER & 2571-1 CONTROLLER - DATA SHEET	20108500	A	--	ADV
*RO	2570-2 LINE PRINTER & 2571-1 CONTROLLER - DATA SHEET	20108600	A	--	ADV
*RO	2572-1/2572-2 CARD READER & 2571-1 CONTROLLER - DATA SHEET	20108700	A	--	ADV
*N	CYBERNATA KEY ENTRY SYSTEM - BROCHURE	20109600	-	--	ADV
*RO	COMPUTERS IN EDUCATION	20114000	A	--	ADV
*N	CORPORATE PHOTOGRAPHY CATALOG	20114600	-	22	HQN
*N	1732-3/616 MAG TAPE SUBSYSTEM - DATA SHEET	20116100	-	--	ADV
*N	1566-20/21/22/23 DIGITAL-TO-ANALOG CONVERTERS - DATA SHEET	20116500	-	--	ADV
*N	1590-3 REMOTE COMPUTER INTERFACE SUBSYSTEM SUBSYSTEM - DATA SHEET	20116000	-	--	ADV
*N	MPP/CONTROLLER FOR 9760 STORAGE MODULE DRIVE - DATA SHEET	20116700	-	--	ADV

CONT.

1	TITLE	2	3	4	5
*R0	9747 DISK STORAGE UNIT - DATA SHEET	20116900	-	--	ADV
*N	2550-100 EMULATION MODULE	20117300	-	--	ADV
*N	MU-602 [V] UYK EXTENDED CORE MEMORY UNIT - DATA SHEET	20117400	-	--	ADV
*N	MBO SYSTEMS & SERVICES COMPANY - BROCHURE	20117800	-	--	ADV
*N	MBO MARKETING COMPANY - BROCHURE	20117900	-	--	ADV
*N	MBO CORPORATE STAFF - BROCHURE	20118000	-	--	ADV
*N	CYBERNET - CYBER 76 SERVICE - DATA SHEET	20118200	-	--	ADV
*N	GRAPHICALLY ORIENTED DESIGN AND ANALYSIS SYSTEM - DATA SHEET	20118300	-	--	ADV
*N	777 CYBER GRAPHICS TERMINAL - DATA SHEET	20118400	-	--	ADV
*N	FAST-TIME/LOAD FLOW - BROCHURE	20118600	-	--	ADV
*N	CYBERNET: IS/ATHENA - DATA SHEET	20118700	-	--	ADV
*N	CYBERNET: SPOTLIGHT OVERVIEW - BROCHURE	20118800	-	--	ADV
*N	882 DISK PACK - DATA SHEET	20118900	-	--	ADV
*N	469 LARGE-PLANE COMPUTER SYSTEM	20119000	-	--	ADV
*N	BUSINESS PRODUCTS - LEADERS IN THEIR FIELD	20119100	-	--	ADV
*N	94200 CORE MEMORY - DATA SHEET	20119400	-	--	ADV
*N	DATA MASS STORAGE SYSTEM FOR IBM 370 - DATA SHEET	20119800	-	--	ADV
*N	MASS STORAGE TAPE CARTRIDGE-DATA SHEET	20119900	-	--	ADV
*N	1700 REDUCED-CORE OPER. SYSTEM VER 2 - DATA SHEET	20120200	-	--	ADV
*N	1974 CCC ANNUAL REPORT	20120300	-	--	ADV
*N	CYBERNET: IFMS	20120400	-	--	ADV
*N	1700 MASS STORAGE FORTRAN V3 A/B DATA SHEET	20120500	-	--	ADV
*N	CYBERNET: FAAS - DATA SHEET	20122300	-	--	ADV
*N	CYBERNET: CC-TEGAS 3 - DATA SHEET	20122400	-	--	ADV
*N	1974 ANNUAL REPORT	20122500	-	--	ADV
*N	CYBERNET: GPSS V/6000 - DATA SHEET	20122700	-	--	ADV
*N	CYBERNET: APEX III MATH PROG SYSTEM - DATA SHEET	20122800	-	--	ADV
*N	3373 MAG CORE STORAGE MEMORY SYSTEM - DATA SHEET	20123200	-	--	ADV
*N	3000 COMPUTER SYSTEMS - BROCHURE	20123300	-	--	ADV
*N	92451 STAND-ALONE DISPLAY TERMINAL - DATA SHEET	20124000	-	--	ADV
*N	ISP 00001 SUPPORT PACKAGE - DATA SHEET	20124600	-	--	ADV
*N	ISP 00005 SUPPORT PACKAGE - DATA SHEET	20124700	-	--	ADV
*N	ISP 20002 SUPPORT PACKAGE - DATA SHEET	20124800	-	--	ADV
*N	ISP 00006 SUPPORT PACKAGE - DATA SHEET	20124900	-	--	ADV
*N	ISP 00004 SUPPORT PACKAGE - DATA SHEET	20125000	-	--	ADV
*N	ISP 20001 SUPPORT PACKAGE - DATA SHEET	20125100	-	--	ADV
*N	ISP 00002 SUPPORT PACKAGE - DATA SHEET	20125200	-	--	ADV

OBSOLETE) PUBLICATIONS

This section lists publications which have become obsolete since the January 1975 Catalog. The publications which replaces the obsolete items are also shown and if no manual replaces an obsoleted item, the replacement is listed as "none".

<u>TITLE</u>	<u>PUB. NO.</u>	<u>REPLACEMENT</u>
657-1 MAG TAPE DATA SHEET	10038400	NONE
3400 DATA SHEET	10039400	NONE
3800 DATA SHEET	10039600	NONE
659-1 DATA SHEET	10042200	NONE
1700 COMP SYS BROCHURE	10042500	NONE
COMPUTER SITE ENGINEERING	10047200	NONE
1750 DCB TERMINATOR-DATA SHEET	10044200	NONE
1797 DATA SHEET	10044300	NONE
1739-1 DATA SHEET	10045800	NONE
1717-1 DATA SHEET	10050600	NONE
9280 DATA SHEET	10051900	NONE
CORPORATE PHOTOGRAPHY CATALOG	10056900	20114600
8194 DATA SHEET	10059000	NONE
DIS DATA SHEET	10063200	NONE
LOW LEVEL ANALOG - D.S.	10063300	NONE
1558 DATA SHEET	10063500	NONE
1547 EVENT COUNTER SUB SYS DATA SHEET	10063600	NONE
1549 DATA SHEET	10063700	NONE
1577 STALL ALARM DATA SHEET	10063800	NONE
1571 DATA SHEET	10064000	NONE
3520 DATA SHEET	10068000	NONE
9540 DATA SHEET	10071000	NONE
9525 DATA SHEET	10071200	NONE
9250 DATA SHEET	10071400	NONE
9433 DATA SHEET	10071700	NONE
9432 DATA SHEET	10071800	NONE
1581 DATA SHEET	10073000	NONE
1587 DATA SHEET	10073300	NONE
EXTERNAL REGISTER DATA SHEET	10073400	NONE
9720 DATA SHEET	10076500	NONE
9200 DATA SHEET	10076900	NONE
1534,1535 DATA SHEET	10084600	NONE
3400 BROCHURE	10089200	NONE
657-2 DATA SHEET	10091900	NONE
657-4 DATA SHEET	10092100	NONE
659-3 DATA SHEET	10092300	NONE
659-4 DATA SHEET	10092400	NONE
90100 DATA SHEET	10092800	NONE
90120 DATA SHEET	10092900	NONE
1604 BROCHURE	10093000	NONE
1572 PROG SAMPLE DATA SHEET	10093400	NONE
9486/9487 DATA SHEET	10093700	NONE
APPL. REPORT COMPUTERS BOOST COLUMBIA RIVER POWER	20001900	NONE
THROUGHPUT-FEEDBACK FOLDER	20006800	NONE
3400 DATA SHEET	20007600	NONE
9463 DATA SHEET	20010800	NONE
9736/9737 DATA SHEET	20012100	NONE
3200 BROCHURE	20015500	NONE
92413 CRT DISPLAY D.S.	20035500	20085600
A LEASING PROGRAM STRUCTURED TO FIT YOUR NEEDS	20035700	NONE
APPL. REPORT-AT DELTA AIRLINES COMMUNICATIONS RATES SEPARATE COMPUTER	20040100	NONE
3000 SERIES CASH	20040900	NONE

<u>OBSOLETE PUBLICATIONS CONT.</u>	<u>PUB. NO.</u>	<u>REPLACEMENT</u>
731 LOW SPEED TERMINAL D.S.	20041300	NONE
APPL. REPORT-VICTORIAN TAB SUCCESSFUL IN OTB AUTOMATION	20044200	NONE
1739-1 DATA SHEET	20045800	NONE
COMPUTER MAINT FOLDER	20049201	NONE
THE READY RESPONSE PLAN	20049300	NONE
THE TIME CRITICAL PLAN	20049400	NONE
THE DO IT YOURSELF PLAN	20049500	NONE
THE CALL US WHEN YOU NEED US PLAN	20049600	NONE
THE SPECIAL PLAN ARRANGEMENT	20049700	NONE
FLIP CHART NOTEBOOK	20049900	NONE
1971 ANNUAL REPORT	20051900	NONE
ELECTRICAL ENGINEERING BROCHURE	20057800	NONE
OPERATIONS RESEARCH BROCHURE	20058000	NONE
33145 MONOLITHIC MAIN MEMORY	20069900	NONE
TOTAL SERVICES MARKETING	20073700	NONE
CYBERNET MEMBER CERTIFICATE	20059800	NONE
1732-2/615 DATA SHEET	20081500	NONE
33145 MONOLITHIC MAIN MEMORY	20086500	NONE
APPL. REPORT-BRIEF DATA RETRIEVAL SYSTEM SPEEDS TAX SERVICE	20094300	NONE
COMMERCIAL TERM LEASING PLAN	20094400	NONE
APPL. BRIEF FOR SKYLAB PROJECT	20097900	NONE
CDC PIONEERS GIANT DATA STORAGE		
APPL. REPORT-AT AERONAUTICAL RADIO ELECTRONIC SWITCHING DIRECTS MESSAGE TRAFFIC	20098100	NONE
C-810 TRG SERIES D.S.	20099000	NONE
C-910 TRG SERIES DATA SHEET	20102000	NONE
9315 DATA SHEET	20105200	NONE
1973 REAL/TIME VOL 10 NO. 2	00015600	NONE
469 COMPUTER SYSTEMS CE MANUAL	14176000	NONE
EL101-A (1750-1) COMPUTER INTERFACE UNIT REF/CE	39909501	88980100
1576 (FV4A3/498) STALL ALARM UNIT REF/CE MANUAL	39909510	88981000
KEY TO LOGIC SYMBOLS G.I.M.	39909515	88981500
501 HIGH SPEED REF MANUAL	40805000	NONE
501 HIGH SPEED REF MANUAL	40815200	NONE
9464 DISK STORAGE DRIVE DIAGS. & WIRE LIST	41248700	NONE
PROFITS INFORMATION MANUAL	59157700	NONE
1700 MSOS 4 G.I.M.	60171400	39522400
955 PAGE AND DOCUMENT READER OCR MEDIA MANUAL	60216102	NONE
3000 TAPE SORT/MERGE G.I.M.	60227900	60282100
1700 COSY REFERENCE V1	60237100	60361500
PAPER TAPE EQUIPMENT TRAINING MAN	60238600	NONE
6000 SCOPE USERS GD 6000 V3.3	60252700	NONE
1700 SYSTEM CHECKOUT VI	60281800	60361500
1700 CONFIGURATOR VI	60282300	60361500
MSOS VERSION 3 REF MANUAL	60282600	60361500
LOGIC ANALYSIS STUDENT MANUAL	60313300	NONE
COBOL STUDENT MANUAL	60314600	NONE
SCIENTIFIC PROGRAMMING STUDENT MAN	60315000	NONE
6000/CYBER 70/RECORD MGR REF MAN	60385400	60307300
I/LOGIC CYBERNET U.I.M.	84000200	NONE
CSM O/P CYBERNET U.I.M.	84000300	NONE
1700 REAL/TIME MAINT SYSTEM	84542000	60361500
I/CAP CYBERNET U.I.M.	86602500	NONE
SYSTEM 2000 G.I.M.	86604400	76074100
SYSTEM 2000 U.I.M.	86604500	INDIVIDUAL MANUALS
COP U.I.M.	86605500	NONE
COP DATA CARD DIGEST	86612400	NONE
I/TRAC CYBERNET U.I.M.	86616400	NONE
APEX II USERS GUIDE	97401400	NONE
28211/14031 & 28211-21 PRINTER SYSTEMS OPERATING GUIDE	97403300	22265500 (AVAILABLE FROM BOB HED-PLYOPS)

PUBLICATION NUMERICAL SEQUENCE PAGE LISTING

This section contains a complete listing of all catalog publications by numerical sequence along with the page numbers on which each publication can be found. Note that some publications are found on more than one page.

PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.
AEG05571	57	13791400	87	13799800	50	17322800	145	31620099	92	36822900	112
AET01621	57	13791500	93	14060200	66		147 149	31620199	92	36823200	70
AET05611	167	13791600	93	14061300	130	17325100	149	31620200	92	36823300	70
AET05613	57	13791700	112	14062100	131	17326500	149	31620300	92	36823400	115
AET09611	57	13791800	112	14062200	131	19980300	145	32501300	95	36823500	114
APT45910	167	13791900	112	14065300	131	19980400	145	32503300	95	36823700	114
BER11621	57	13792000	59	14077300	131	19980600	141	35110900	89	36823800	113
BER56250	57	13792100	92	14082100	131		148 150	36810100	112	36824400	64
BPT36210	130	13792200	92	14082200	131	19980700	148	36810200	112	36824500	74
ESD10400	58	13792400	87	14091600	115		150	36810300	59	36824700	64
ESD10501	58	13792500	87	14091700	115	19980900	148	36810500	113	36824800	64
ESD10504	167	13792700	87	14091800	115		151	36810600	113	36825600	115
ESD10505	58	13792800	59	14091900	115	19981400	166	36810700	113	36825800	93
ESD10600	58	13792900	74	14092000	115	19981400	166	36810800	113	36825900	93
PED20030	68	13793000	74	14093500	115	19983600	56	36810900	113	36826000	93
PED20080	69	13793100	87	14094700	115	19983800	4	36811000	112	36826500	74
PED22140	69	13793200	91	14123800	157	20114600	157	36811300	114	36826600	115
PED22160	69	13793300	87	14142900	157	22003300	69	36811500	114	36826700	115
PPI18100	130	13793400	87	14143700	157	22006500	159	36811600	114	36827000	85
PSBAG010	130	13793500	97	14143800	157	22006600	159	36811700	112	36827100	85
PSBAG020	130	13793600	91	14155000	157	22006700	159	36812500	115	36827800	114
PSBAG030	130	13793900	93	14163300	102	22006900	159	36812600	112	36827900	114
PSBAG040	130	13794100	92	14166700	102	22008200	159	36812700	115	36828100	93
PSBAG050	130	13794400	85	14166800	102	22261700	51	36812800	171	36828200	114
PSBAG060	130	13794600	86	14167100	102	22261900	157	36813100	115	36828300	114
PSBAG070	130	13794700	86	14232000	101	22262100	157	36813300	114	36828600	74
PSBAG090	130	13794800	86	14237500	158	22262200	157	36813700	115	36828700	74
PSBAG110	130	13794900	59	14247900	102	22263500	124	36814000	112	36828900	116
PSBAG120	130	13795000	79	14306500	130	22263600	157	36814100	115	36829000	64
SB001700	142	13795100	114	15000300	123	22263800	125	36814200	115	36829100	85
SC000100	58	13795300	114	15002900	158	22263900	124	36814300	70	36829400	158
SC057600	58	13795400	158	17302500	152	22264000	124	36814400	115	36829500	87
SC063300	58	13795500	158	17303100	151	22264500	157	36814500	115	36829600	89
SC200000	58	13795600	158		152	22264600	157	36814700	116	36829700	89
SC200100	58	13795700	158	17303600	152	22264700	157	36814800	116	36800400	108
SC400600	58	13795900	43	17304200	153	22264800	124	36815000	116	36804400	79
00000200	158	13796000	114	17304400	149	22265400	124	36816000	116	36804500	79
00002100	162	13796100	64		151	22265500	123	36816200	93	36805100	172
00004600	165	13796200	86	17305100	150	22267100	157	36816300	112	36806000	108
00006000	163	13796300	168		152	22267200	157	36816400	112	36806100	108
00006100	163	13796400	64	17307300	149	22267300	157	36816600	113	36807800	108
00006300	158	13796500	38		151	22272400	46	36816700	111	36808400	108
00007300	141	13796800	95	17308100	152	22272500	46	36817300	115	39070800	75
00007500	157	13796900	114	17308300	152	22273000	123	36817400	70	39070900	76
00015000	158	13797000	116	17309500	174	22273100	123	36817500	112	39071100	85
00015100	173	13797300	116	17309700	153	22285300	125	36817600	86	39071300	76
01306700	160	13797400	64	17310100	149	22285400	125	36817700	74	39071400	76
04036700	162	13797500	158	17311600	174	22285500	125	36817900	74	39071500	76
04256700	162	13797700	74	17311700	174	22285600	124	36818000	74	39071900	76
04266700	160	13797800	83	17313000	150	22285700	125	13618100	74	39072200	79
07046700	161	13797900	47		152 153	24107700	60	36818200	74	39072400	79
082966A0	161	13798100	47	17313200	147	24140300	113	36818300	58	39072500	60
083066A0	159	13798400	64		149	31600200	98	36818500	58	39072600	76
13790100	87	13798500	64	17313600	147	31600800	99	36819100	114	39072900	85
13790200	87	13798600	64	149 151	154	31601100	99	36819900	112	39073100	76
13790300	87	13798700	64	17317200	152	31602300	100	36820000	86	39073300	75
13790400	91	13798800	47	17317400	149	31602900	100	36820100	87	39073400	75
13790500	86	13798900	159	17318900	149	31603800	101	36820200	87	39073500	75
13790700	87	13799000	85	17321800	149	17321800	149	36820300	87	39073600	75
13790800	87	13799100	47	17322100	152	31605600	99	36820400	86	39073700	75
13791100	115	13799200	47	17322500	149	31605700	99	36820600	74	39073800	75
13791200	116	13799300	64	17322600	149	31606100	100	36822500	111	39073900	75
13791300	87	13799700	116	17322700	145	31606600	101	36822700	115	39074100	75
					147	149					

PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.
39074200	75	40807200	67	40821700	117	40862700	67	41246000	120	41610700	98
39074300	75	40807700	69	40821800	117	40862900	72	41246100	121	41610900	66
39074400	75	40807800	69	40821900	22	40863100	120	41246200	121	41611000	38
39074500	75	40707900	69	40822000	69	40863200	33	41246800	120	41611200	38
39074700	63	40808100	118	40822100	116	40863300	71	41246900	121	41611300	92
39074900	66	40808200	23	40822200	69	40863600	117	41247100	121	41611700	38
39075000	75	40808300	63	40822300	116	40863900	72	41247200	121	41611800	65
39075200	76	40808400	117	40822400	68	40864000	32	41247300	71	41611900	38
39075300	76	40808500	117	40822500	68	40864100	21	41247400	72	41612000	65
39083500	141	40808600	24	40822600	69	40864400	120	41247500	120	41612100	38
39150100	74	40809100	69	40822800	69	40864600	117	41247600	120	41612200	65
39153300	75	40809300	66	40823000	68	40864800	32	41247700	120	41612300	38
39153400	75	40809500	70	40823100	71	40864900	66	41247800	121	41612400	65
39185900	79	40819600	111	40823200	72	40865000	117	41248400	121	41612500	66
39201800	133	40810800	68	40823400	71	40865100	117	41248800	121	41612600	38
39216600	85	40811200	69	40823600	117	40865200	71	41248900	26	41612700	66
39222600	42	40811400	68	40823700	117	40865500	121	41249000	26	41612800	38
39230300	74	40811500	68	40813800	117	40865800	122	41249200	25	41613200	37
39231200	47	40811700	116	40823900	66	40866400	120	41249300	25	41613400	37
39260700	134	40811800	68	40824000	69	40866500	120	41249400	25	41614300	51
39268100	133	40811900	68	40824200	23	40867100	121	41249500	25	41614400	140
39278700	75	40812000	68	40824300	71	40867300	53	41249600	25	41614500	140
39308000	79	40812300	157	40824600	116	40867600	121	41249700	25	41614600	140
39359900	76	40812400	67	40824800	71	40867700	53	41249800	25	41614700	140
	50	40812500	68	40824900	72	40867800	122	41600000	134	41614800	140
39368600	49	40812600	68	40825000	71	40868100	117	41600300	95	41614900	140
39392700	37	40812700	69	40825100	71	40868400	121		47	41615000	140
39412900	79	40812800	59	40825200	66	40868500	121	41600500	64	41615100	140
39415100	79	40813100	65	40825400	117	40868700	22	41600600	37	41615200	140
39473200	41	40813300	117	40825600	71	40869500	166	41600700	101	41615300	140
39519800	132	40814200	69	40826200	117	40869600	26	41600900	170	44016000	159
39519900	132	40814300	70	40826300	71	40869700	22	41601000	50	44016800	159
39520200	133	40814400	59	40826400	72	40869901	22	41601500	85	44020300	159
39520500	132	40814500	70	40826500	120	41240000	21	41601600	85	44020500	159
39520600	132	40814600	70	40826600	116	41240100	69	41601700	46	44610400	153
39520900	132	40814800	68	40826700	166	41240200	172	41601800	65	44616700	152
39521700	133	40814900	116	40826800	120	41240300	121	41601900	37	44623700	158
39521900	133	40815100	68	40826900	120	41240400	121	41602200	46	44629200	153
39522400	132	40815200	67	40827000	121	41240500	121	41602400	64	44629300	152
39524000	37	40815300	67	40827300	120	41240600	53	41602500	50	44855500	34
39534900	31	40815400	68	40827500	71	41240800	117	41602600	97	44855600	35
39644500	133	40815500	68	40827600	33	41240900	71	41602700	97	44855700	34
39660400	51	40815600	68	40827900	166	41241000	72	41602800	97	44855800	67
39677500	133	40815700	117	40828200	121	41241400	33	41602900	50	44895600	34
39690100	51	40816000	70	40828700	120	41241500	31	41603000	170	44895700	34
39731700	24	40816100	111	40828900	120	41241600	120	41603100	38	44895800	34
39744900	41	40816200	158	40829000	120	41241700	25	41603200	37	44895900	119
39771300	174	40816500	68	40829100	120	41241900	33	41603300	46	44896400	114
39909502	35	40816800	68	40829300	122	41242100	22	41603500	115	44896500	89
39909503	36	40816900	120	40829400	66	41242200	24	41605200	157	44976700	34
39909504	42	40817000	116	40829700	166	41242300	24	41605300	65	44977000	119
39909505	50	40817200	69	40829900	117	41242400	24	41605400	37		172
39909506	41	40817400	23	40860000	157	41243200	31	41605600	47	44977600	119
39909507	39	40818700	117	40860100	117	41243500	26	41605900	58	44977700	119
39909508	48	40818800	116	40860200	121	41243600	26	41606100	113	44978800	34
39909509	37	40818900	117	40860400	72	41243700	26	41606200	65	44980100	34
39909513	76	40819300	33	40860500	72	41243800	22	41606300	37	44980700	35
40801800	22	40819400	68	40860700	21	41243900	26	41606400	46	44980800	35
40802000	31	40819500	68	40860800	21	41244100	71	41606500	93	44980900	35
40802100	116	40819700	117	40860900	23	41244200	72	41606600	141	44981600	119
40803200	70	40819800	117	40861000	23	41244300	120	41607100	65	44982700	119
40803400	70	40819900	23	40861700	67	41244400	120	41607400	114	44983100	119
40803900	116	40820000	71	40861800	67	41244500	121	41607700	172	44983200	119
40804800	31	40820100	112	40861900	65	41244600	121	41608100	37	47500700	89
40805000	67	40820200	66	40862000	67	41244700	121	41608500	48	47966500	114
40805200	117	40820300	68	40862300	67	41245200	120	41608700	168	47966600	114
40805300	116	40820400	117	40862200	67	41245500	121	41609000	64	47966700	34
40806600	111	40820500	67	40862300	117	41245600	166	41609600	65	47967000	34
40806700	116	40820800	67	40862400	72	41245700	71	41609700	37		58
40806800	117	40821000	68	40862500	71	41245800	72	41610400	39	48143900	133
40807100	117	40821200	68	40862600	69	41245900	120	41610500	66	48143910	72

PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.
48143981	35	49752300	124	59150800	146	60007200	59	60026200	60	60052900	132
48299700	158	49754900	31	59151000	146	60007300	60	60026500	60	60053300	143
48299727	158	49755100	31	59151300	146	60007400	61	60026700	73	60053400	143
48402800	165	49755200	31	59151600	146	60007500	61	60026800	60		144
48430000	134	49755300	66	59152000	146	60007600	61	60026900	60	60053500	132
48430010	134	49755400	66	59152100	146	60007700	61	60027000	61	60053900	132
48430045	33	49755500	66	59152300	140	60007800	61	60027100	73	60054000	130
48430050	74	49755600	21	59153300	140	60007900	61	60027200	78	60054100	130
48430070	74	49755700	22	59155100	134	60008300	167	60027400	73	60054200	130
48430080	33	49755800	22	59155600	134	60008400	131	60027500	73	60054400	130
48430087	33	49755900	66		141	60009800	78	60027600	78	60054500	130
48430090	33	49757500	68	59156000	158	60010200	168	60028100	77	60054600	130
48430100	133	49757600	68	59156600	146	60010600	78	60028200	95	60055000	138
48430170	72	49762400	33	59156800	151	60010700	78	60029100	60	139	140
48643305	74	49800300	23	59156900	151	60013600	168	60029200	78	60055100	138
48704601	155	49803700	52	59157000	151	60013700	73	60029300	73	60055200	135
48704702	72	49803800	52	59157900	154	60013900	61	60041400	60	137 138	139
48704800	155	49815000	21	59158000	148	60014000	60	60041600	166	60055400	138
48704810	74	49815100	22		154	60014100	60	60041700	98	60055500	141
48704850	74	49815200	24	59158100	148	60014200	60	60041800	99		142
48704901	155	49859100	23		154	60014300	60	60041900	99	60055600	142
48706101	155	49859200	23	59158200	158	60014400	62	60042000	99	60055700	141
48706201	155	49859300	23	59158300	158	60016400	77	60042100	99		142
48707800	155	49859400	22	59158800	141	60016500	77		172	60055800	137
48707900	155	49932700	23	59158900	141	60016600	77	60042200	100		139
48708000	72	49973600	31	59159000	140	60016700	77	60042300	101	60055900	142
48781100	74	50577600	118	59159100	140	60016800	73	60042400	101	60056100	132
48814000	155	50577700	35	59159400	158	60017000	73	60042500	100	60056300	135
48883700	33	50577800	118	59159600	141	60017100	73	60042600	98	137 138	139
48911900	35	50577900	118	59159700	153	60017300	73	60042700	166	60056400	143
48948100	33	50578100	34	59159800	155	60017800	78	60042800	58		144
48948200	33	50578500	34	59304600	158	60017900	78	60042900	166	60056500	144
48991800	35		120	59349900	24	60018200	132	60043000	89	60056800	140
48996300	35	50578700	168	59577900	120	60018400	59	60043300	99	60056900	140
48996600		50579100	119	59578000	120	60018500	59	60043400	98	60057100	140
	155	50579600	119	59578100	120	60018600	159	60043500	100	60057200	141
48997900	33	50580500	119	59578800	120	60018700	59	60043800	92		142
49484600	23	50580900	52	59578900	120	60018800	78	60044400	98	60057400	141
49486400	21	50581000	119	59579200	118	60018900	78	60044800	73	142 143	144
49487000	23	50581200	168	59579300	118	60019100	131	60044900	78	60057500	141
49487100	23	50581300	119	59579400	119	60019400	61	60047600	99	142	143
49487200	22	50581400	119	59579500	119	60019500	61	60047700	100	60057600	134
49487300	22	50581500	168	59707800	119	60020900	59	60047900	89	135 136	137
49487400	22	50581600	67	59708000	119	60021300	98	60048300	101	138 139	140
49487500	22	50581800	34	59708200	123	60021400	78	60048400	100	60057800	142
49487600	23	50581900	120	59708300	123	60021500	78	60048600	158	60057900	141
49487700	23	50582000	52	59708400	123	60021600	62	60048800	87	60058200	155
49487800	21	50582200	67	59708500	167	60021700	62	60048900	73	60058300	142
49487900	21	50582300	35	59708600	167	60021800	62	60049100	63	60058500	143
49488000	23	50582400	35	59708700	167	60021900	62	60049400	92		144
49488100	23	50582500	119	59709000	167	60022000	61	60049800	100	60058600	143
49488200	21	50583100	34	59709100	118	60022200	61	60050100	131		144
49488300	23	50583200	34	60001500	77		62	60050300	131	60058700	142
49488400	23	50583300	34	60001800	132	60022300	62	60050500	131	60058900	141
49488600	23	50583400	34	60002000	76	60022400	62	60050600	132		142
49591900	32	50583500	52	60002300	59	60022500	61	60050700	131	60059000	142
49592900	32	50583600	118	60002600	59	60023000	60	60050800	132		143
49593000	32	50583700	118	60003000	77	60023800	62	60050900	132	60059100	139
49593100	32	50583800	118	60003200	77	60023900	62	60051000	132	140	142
49596700	117	50583900	35		132	60024000	62	60051100	132	60059200	142
49596800	117	50584100	52	60003300	77	60024300	76	60051200	131	60059300	138
49596900	118	50584300	34	60003500	77	60024400	76	60051300	131	60059400	141
49597000	32	50584400	118	60003600	77	60024500	76	60051500	131		142
49626100	31	50584500	118	60003700	77	60024900	59	60051600	132	60059500	141
49750300	22	50584600	118	60004100	77	60025000	59	60051900	131		142
49750400	22	50583700	120	60004400	77	60025100	131	60052000	132	60059800	141
49750600	24	50584800	119	60006600	77	60025600	77	60052100	132		142
49750700	24	59150500	144	60006800	59	60025700	76	60052200	132	60059900	155
49750900	66	145	146	60006900	59	60025800	60	60052500	143	60060100	130
49751400	69	59150600	146	60007000	59	60026000	60		144	60060200	130
49751600	158	59150700	146	60007100	59	60026100	60	60052600	132	60060300	130

PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.
60060400	130	60083800	144	60100700	99	60123900	61	60134100	134	60150200	87
60060500	130	60084000	132	60100800	102	60124000	61		135	60150300	95
60060600	130	60084100	131	60100900	92	60124100	60	60134200	142	60150700	99
60060700	130	60084200	130	60101100	92	60124300	61	60134300	138	60150800	105
60060800	130	60084400	142	60101400	89	60124400	113	60134600	143	60150900	59
60061000	57	60084900	141	60101900	113	60124600	57		144	60151000	78
60061200	130	60085100	165	60102000	113	60124800	101	60134700	138	60152100	62
60061300	56	60086000	164	60102300	95	60125000	36		139	60151500	61
60061400	57	60086100	164	60102500	61	60125400	101	60134900	134	60151700	63
60061500	130	60086900	164	60103900	60	60126400	95		139	60151800	61
60061600	130	60087000	164	60104200	60	60126500	101	60135900	137	60152700	167
60061700	57	60087200	164	60104300	61	60126800	77		138	60152300	94
60061800	57	60087400	164	60104400	61	60127000	106	60137000	142	60152500	90
60061900	130	60087500	164	60104500	57	60127500	78	60137100	141	60152600	90
60062000	130	60087600	164	60104600	60	60127800	112		142	60152700	81
60062100	130	60088500	164	60104700	60	60129300	61	60137200	142	60153000	102
60062200	130	60088600	164	60104900	101	60129400	58	60137300	142	60153100	79
60062300	56	60088700	165	60105100	93	60130000	137	60137500	143	60153500	130
60062400	57	60088800	164	60105400	60		138 139	60137600	138	60153600	130
60062500	57	60089100	164	60107100	78	60130100	140		139	60153800	130
60062600	57		179	60107300	165	60130200	138	60137700	153	60153900	94
60062700	130	60089200	164	60107400	101		139 140	60137900	143	60154000	94
60062900	57		179	60108100	96	60130400	137	60138000	131	60154100	94
60063000	57	60089300	164	60108400	89		138 139	60138100	131	60154500	102
60063100	57		179	60109800	61	60130500	143	60138200	143	60156000	141
60063200	57	60089400	179	60110100	76		144	60138300	138	60156900	165
60063400	57	60089800	112	60110400	87	60130600	143	60138400	144	60157000	93
60063500	58	60090200	62	60110900	92	60130900	155	60138800	144	60157100	102
60063600	130	60090300	73	60111000	92	60131000	182	60138900	144	60157200	90
60063700	57	60090400	97	60111100	89	60131100	134	60139000	132	60157300	98
60063800	57	60090500	93	60111200	89		135 139	60139100	141	60157400	105
60064000	57	60090800	77	60112400	90	60131200	137		142	60157500	140
60064300	58	60091000	113	60112700	62		138 139	60139300	141	60158200	97
60064400	58	60091100	113	60112800	60	60131400	135	60139500	157	60158600	158
60064500	58	60091200	113	60113200	165		137 138	60140400	90	60158700	160
60064600	58	60091300	112	60113300	171		139 140	60140700	113	60158800	160
60064700	58	60091500	113	60113400	87	60131500	143	60140800	101	60159000	102
60064800	57	60091600	113	60113900	93	60131600	142	60141200	63	60159200	99
60064900	57	60091700	78	60114200	97	60131700	141	60141300	62	60159300	112
60065000	57	60091800	97	60116000	76		142 143	60141400	61	60159400	112
60065100	130	60093100	73	60116100	92	60131800	143	60141500	61	60159600	100
60070000	95	60093700	92	60116200	61		144	60141600	60	60159700	100
60070100	59	60093800	99	60116300	62	60131900	141	60141800	93	60159900	102
60070200	59	60093900	98	60116400	61	60132000	138	60141900	102	60160000	102
60070300	73	60094100	73	60116600	60		139	60142000	167	60160300	91
60070400	76	60094200	101	60116900	113	60132100	137	60142100	167	60160400	81
60070500	77	60094400	101		168		138 139	60143100	167	60160600	103
60070600	77	60094600	74	60118600	87	60132200	143	60143200	167	60160700	94
60070700	77	60094800	60	60118700	76	60132300	142	60143400	160	60161200	157
60070800	163	60094900	61	60118800	76	60132400	142	60143600	167	60161300	167
60070900	163	60095000	61	60119100	60		143 144	60144200	168	60162300	102
60071000	163	60095200	63		62	60132500	134	60144500	78	60162600	90
60071100	163	60095400	62	60119200	61		135 136	60145300	112	60162900	95
60071300	163	60095500	99	60119300	105		137 138 139	60145500	95	60163500	79
60071400	163	60095700	168	60121100	62	60132800	143	60145600	95	60163900	112
60071500	158	60095800	168	60121300	99	60132900	141	60145700	95	60164200	82
60075400	92	60095900	167	60121400	99		142 143 144	60145900	95	60164500	102
60080400	132	60096700	99	60121600	57	60133000	143	60146000	95	60164600	57
60081000	131	60096800	98	60122600	63		144	60146100	103	60164700	57
60081100	132	60096900	95	60122700	102	60133100	138	60146200	103	60164800	57
60081300	132	60097000	95	60123100	113		139	60146400	131	60165000	159
60081500	132	60097100	78		168	60133300	147	60146500	131	60165100	93
60081900	144	60097200	171	60123200	113		150 152	60146600	131	60165200	93
60082000	144	60097900	100		168	60133500	144	60147200	91	60165300	92
60082400	144	60098200	78	60123300	112	60133600	145	60148100	167	60165400	92
60082600	131	60099400	71	60123400	113		146 147	60148500	77	60165700	82
60083400	131	60099500	71	60123500	113		150 152	60148900	106	60165800	79
60083500	144	60099800	100	60123600	60	60133700	141	60149600	106	60166000	103
60083600	132	60100000	102	60123700	62	60133800	138	60149800	113	60166100	103
60083700	132	60100200	60		78		139	60150000	95	60166200	103
	152	60100400	93	60123800	62	60133900	132	60150100	91	60166300	103

PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	
60166400	103	60175600	162	60190500	163	60213500	135	60235300	163	60244800	164	
60166700	160	60175700	162	60190900	151	60213600	136	60235400	149	60244900	164	
60166800	165	60176000	137	60191100	136	60213700	137	60235900	137	60245100	164	
60166900	91	60176100	137		137		138	60236000	135	60245200	164	
60167000	91	60176500	132	60191300	137	60214000	136	60236100	138	60245300	164	
60167100	112	60176700	135	60191500	153	60214800	143	60236300	142	60245400	164	
60167200	112		137	60191600	138		144	60236300	141	60245500	164	
60167500	84		139	60191900	151	60214900	142	60236400	134	60246400	106	
60167700	84	60177000	143	60192000	134	60215200	142		135	60246500	104	
60167900	93	60177200	144		135	60216101	74	60236500	134	60246600	107	
60169100	101	60177300	143	60192100	137	60216104	72		136	60246800	104	
60169500	159	60177400	137	60192400	163	60217400	46	60236600	136	60246900	104	
60169600	159		138	60192500	145	60217600	18	60236700	137	60247000	107	
60169700	103	60177700	137		151	60220100	79		138	60247100	107	
60170100	141		138	60192600	142	60220200	79	60236800	134	60247200	107	
60170200	138	60177800	144	60192700	142	60220300	79		135	60247300	107	
60170300	143	60178000	141	60192800	137	60220400	79	138	139	60247400	107	
	144	60178600	136	60192900	143	60220500	79	60236900	134	60247500	107	
60170400	143	60178800	136	60193100	148	60220600	79	136	137	60247600	107	
	144	60179000	144		151	60220700	79	60237000	138	60247700	107	
60170500	141	60179500	144	60193600	142	60220800	79	60237400	153	60247800	107	
	142	60179700	135	60194000	133	60220900	79	60237700	45	60247900	107	
60170700	133	60179800	135	60194400	102	60221000	79	60237800	84	60248000	107	
60170800	143	60180000	103	60194500	81	60221100	79	60238000	6	60248100	107	
	144	60180100	103	60197000	97	60221200	79	60238300	162	60248200	107	
60170900	141	60180200	170	60197100	103	60221300	79	60238400	159	60248300	107	
	142	60181200	101	60197200	103	60221400	79	60238500	159	60248500	104	
	143	60181300	63	60197300	100	60221500	79	60238700	161	60248600	104	
60171100	131	60181400	63	60197400	172	60221600	79	60238800	162	60248700	104	
	141	60182000	79	60197600	95	60221700	79	60239200	160	60248800	104	
60171200	139	60182100	103	60197700	102	60222100	36	60239400	162	60248900	104	
	140	60182400	46	60197900	90	60222200	133	60239500	160	60249000	104	
60171300	143	60182800	83	60198000	90	60222400	163	60239600	161	60249100	104	
60171500	141	60182900	82	60198200	90	60223100	132	60239700	160	60249400	160	
	142	60183000	46	60199300	102	60223300	103	60240200	165	60249900	160	
60171600	132	60183300	160	60199700	160	60223800	46	60240300	164	60250000	160	
	133	60183400	160	60199800	169	60224000	45	60240400	159	60250100	162	
60171800	139	60183900	160	60200300	97	60224100	87	60240600	159	60250200	162	
60171900	141	60184500	102	60201000	166	60224200	103	60240700	161	60250300	162	
	142	60184900	159	60201300	172	60224800	106	60241000	159	60250400	160	
60172000	140	60185500	59	60201500	108	60224900	100	60241200	161	60250500	160	
60172100	146	60185600	93	60202000	159	60225100	108	60241300	160	60250600	161	
	148	60186000	108	60202100	169	60227300	108	60241400	159	60250700	161	
60172200	144	60186100	102	60202600	91	60227400	165	60241600	161	60250800	160	
60172300	133	60186700	95	60203200	169	60227500	170	60241700	161	60250900	32	
60172500	138	60186900	94	60203300	101	60227600	135	60241800	161	60251200	107	
60172800	135	60187200	103	60205400	108	60227700	135	60241900	164	60251300	46	
	137	60187500	75	60206800	136	60228300	163	60242000	163	60251900	145	
60172900	137	60187600	133	60207200	137	60228500	133	60242100	164	148	150	152
60173000	137	60187700	103	60207300	136	60228700	9	60242200	164	60252300	163	
60173300	141	60187800	103		137	60229300	135	60242300	163	60252400	163	
	142	60187900	104		139	60229500	135	60242400	164	60252500	163	
60173400	137	60188600	63	60207700	167	60229700	163	60242500	163	60252600	152	
	138	60188800	69	60207800	91	60229900	137	60242600	164	60252700	151	
60173500	145	60188900	103	60207900	159	60230200	46	60242700	164	60253000	146	
	146	60208200	84	60208600	114	60230300	19	60242800	163		151	
	150	60209600	18	60209800	95	60231300	98	60242900	163	60253200	107	
60173600	143	60189100	149	60210200	18	60232000	45	60243000	163	60253300	107	
	144		151	60210300	72	60232200	44	60243100	163	60256700	162	
60173700	132	60189300	153	60210400	24	60232300	44	60243300	163	60257100	162	
	133	60189500	145	60210900	43	60233100	6	60243400	164	60257200	160	
60174100	137		149	60211400	58	60233500	114	60243500	164	60257600	162	
60174200	133	60189600	143	60211500	58	60233700	131	60243600	163	60257700	160	
60174500	146		144	60211600	167		141	60243800	164	60257800	160	
	148	60189700	137	60212200	18	60234300	132	60244000	164	60257900	159	
60174700	141	60190000	133	60212800	97	60234400	163	60244100	163	60258000	160	
60174800	143	60190100	143	60213100	94	60234500	133	60244200	163	60258100	160	
60174900	145	60190200	137	60213200	94	60234600	151	60244300	163	60259400	134	
	146		138	60213300	106	60234700	163	60244400	163	60259500	134	
60175000	142	60190300	137			60234800	145	60244500	164	60259700	134	
60175100	139	60190400	137	60213300	106		148	60244600	163	60265500	111	
60175300	143						150					
	144						152					

PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.
60266000	44	60279800	153	60291400	43	60304500	88	60316600	51	60331400	86
60266200	79		154	60292600	49	60304600	88	60317100	168	60331500	100
60266300	103	60279900	146	60292700	49	60304700	89		169	60331600	95
60266400	106	151 153	154	60293300	2	60305100	151	60317200	14	60331700	92
60266500	106	60280000	153	60293400	31	60305200	151	60317300	10	60331800	90
60267100	104	60280200	136	60293500	2	60305400	146	60317500	94	60331900	91
60267200	103	60280400	153	60293600	3		151	60317600	10	60332000	90
60267300	106	60280600	133	60293700	2	60305600	149	60317800	87	60332200	93
60267400	107	60280700	137	60293800	3	60305700	132	60318100	94	60332300	93
60268000	104	60280800	135	60293900	2	150 152		60318200	89	60332400	91
60268100	165	60281000	135	60294000	3	60305800	163	60318300	94	60332500	93
60268900	93	60281100	135	60294100	3	60305900	151	60318500	39	60332600	101
60269100	104		137	60294200	3	60306200	149	60318600	49	60332700	93
60269200	45	60281200	153	60294300	3		151	60318700	32	60332800	97
60270200	59	60281300	135	60294500	47	60307000	149	60318900	14	60332900	93
60270600	85	60281400	134	60294700	2	60307100	149	60319300	13	60333000	101
60270700	74	135 136	137	60294800	2	60307200	148	60319800	20	60333100	97
60270900	9	60281500	137	60294900	2	60307300	148	60320700	102	60333200	100
60271300	80	60281600	153	60295600	167		150	60321100	43	60333300	92
60271400	80	60281700	145	60295900	14	60307400	148	60321400	125	60333400	101
60271500	80	146 147	153	60296200	39	60307500	147	60321500	125	60333500	101
60271600	80	60281900	136	60296500	10		150	60321600	12	60333600	107
60271700	80	60282000	136	60296900	172	60307600	2	60321800	47	60333700	172
60271800	80	60282100	135	60297200	164	60307700	2	60323100	18	60333800	172
60271900	80	60282200	136	60297300	167	60307800	2	60323400	94	60334100	108
60272100	158	60282400	134	60297600	2	60307900	2	60323500	18	60334200	108
60272200	59	60282500	153	60297700	2	60308000	2	60324000	126	60334300	109
60272700	9	60282800	133	60297900	2	60308100	2	60324600	74	60334400	108
60273200	80	60282900	146	60298100	51	60308200	2	60324700	46	60334500	108
60273300	160	151 153		60298400	51	60308300	2	60325100	71	60334600	108
60273400	159	60283000	145	60298600	51	60308400	2	60325600	80	60335400	48
60273500	160	146 147	153	60299500	103	60308500	2	60325700	80	60336400	3
60273600	160	60283100	153	60299700	113	60308600	2	60325800	80	60336500	89
60273800	162	60283200	46	60299900	37	60308700	2	60325900	80	60336600	89
60273900	162	60283400	8	60300000	87	60308800	2	60326100	80	60336700	89
60274100	160	60283500	8	60300100	87	60308900	2	60326200	80	60336800	89
60274300	160	60283600	45	60300200	88	60309000	2	60326300	80	60336900	89
60274400	162	60283900	81	60300300	88	60309100	2	60326400	80	60337000	89
60274900	6	60284000	82	60300400	88	60309200	80	60327000	152	60337100	89
60275000	48	60284100	2	60300500	88	60309300	80	60327200	150	60337200	89
60275100	166	60285200	85	60300600	88	60309400	80	60327300	148	60341500	91
60275200	166	60285300	2	60300700	88	60309500	80	60327600	146	60341600	111
60275300	167	60285400	3	60300800	88	60309600	103		151	60342100	155
60275500	166	60285500	3	60300900	88	60309700	49	60327800	145	60342200	154
60275600	166	60285600	3	60301000	88	60309800	102	147 149	153	60342300	155
60275900	166	60285700	3	60301100	88	60310500	2	60327900	145	60342400	145
60276100	166	60286000	3	60301200	88	60311200	8	147 149	153	148	150
60276400	166		10	60301300	88	60311500	160	60328400	145	60342500	146
60276500	166	60286100	3	60301400	88	60312400	6	147 149	154	150 152	153
60276600	166		10	60301500	88	60312700	161	60328800	146	60342600	154
60277000	166	60286200	32	60301600	88	60313100	161	148 150	150	60342700	153
60277100	166	60286400	164	60301700	88	60313400	162	60328900	158	60342800	140
60277200	166	60286800	167	60301800	88	60313500	162	60329000	145	60343000	153
60277300	166	60287000	78	60301900	88	60313600	161		151	60343300	155
60277400	166	60287100	73	60302000	88	60314100	159	60329100	151	60343400	145
60277500	166	60287200	45	60302200	88	60314200	159	60329400	145	147 149	154
60277600	166	60287300	2	60302500	88	60314300	161	147 149		60343500	134
60277700	166	60287400	2	60302600	88	60314400	162	151 154		135	
60277800	166	60287600	98	60302700	88	60314800	161	60329500	70	60343600	155
60278100	6	60288100	113	60302800	88	60314900	160	60329700	49	60343700	155
60278300	48	60288700	163	60303000	88	60315100	161	60329900	94	60343800	155
60278400	2	60289000	2	60303100	88	60315200	161	60330300	82	60343900	146
60278500	98		107	60303200	88	60315500	13	60330400	83	148	150
60278800	46	60289100	43	60303300	88	60315600	10	60330500	83	60344000	154
60279100	63	60289200	18	60303600	88	60315700	10	60330600	84	60344100	154
60279200	142	60289500	6	60303900	88	60315900	20	60330700	84	60344200	145
60279400	137	60290000	44	60304000	88	60316000	20	60330900	83	150	154
60279500	153	60290900	116	60304100	88	603166100	20	60331000	84	60344300	154
60279600	153	60291000	100	60304200	88	60316200	3	60331100	84	60344400	145
	154	60291100	8	60304300	88	60316500	47	60331200	85	148	
60279700	153	60291200	8	60304400	88			60331300	85	60344700	38
	154										

PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.
60344800	14	60358500	150	60370800	5	60384700	145	60401700	48	60413800	81
60345100	153		152	60370900	5	147 148	154	60401800	48	60413900	81
60346500	20	60358700	148	60371000	8	60384900	148	60402100	48	60414000	81
60347000	55	60358800	149	60371100	5		150	60402200	48	60414100	81
60347100	56	60359000	149	60371200	5	60385200	147	60402700	48	60414200	81
60347200	55	60359200	148	60371300	5		149	60402900	48	60414300	81
60347300	56		150	60371400	5	60385300	150	60403900	155	60414400	81
60347600	8	60359400	146	60371800	134	60385500	148	60404000	42	60414500	81
60347700	170		148 150		135 136		150	60404100	42	60414600	81
60348000	7	60359600	150	60372200	154	60385600	150	60404500	4	60414700	81
60348200	6	60359700	150	60372300	135		152	60404800	15	60415100	134
60348300	6		152	60372500	135	60385700	150	60404900	15	60415200	134
60348400	6	60359800	150	60372600	154	60385900	150	60405100	157	60415300	134
60348500	7		152	60372700	134	60387900	145	60405200	16	60415400	134
60348600	7	60360100	155		135		147 149	60405400	16	60415500	134
60348700	7	60360200	146	60372800	134		154 155		127	60415600	103
60348800	7	148 150	153		135	60389600	21	60405500	45	60415800	11
60348900	7	60360400	155	60372900	153	60390100	109	60406000	158	60415900	11
60349000	7	60360500	155	60373100	135	60390600	16	60406100	11	60416000	8
60349100	7	60360700	154	60373400	132	60391700	11	60406300	171	60416400	45
60349200	7	60360900	145	60373500	157	60391800	11	60407000	145	60416700	14
60349300	7		147 149	60373800	154	60391900	11	60407100	144	60417000	158
60349400	7	60361000	145	60373900	56	60392000	11	60407200	145	60417300	93
60349500	7	147 149	154	60374500	12	60392100	11	60407500	145	60417600	17
60349600	7	60361100	140	60374800	8	60392200	11	60407700	145	60417800	134
60349700	7	60361200	140	60374900	5	60392400	11	60407800	145	60417900	136
60349800	7	60361500	132	60375600	16	60392600	37	60407900	146	60418000	134
60350200	4	60361600	132	60375700	16	60392700	16		148	60418200	166
60350300	4	60361700	145	60376300	108	60393700	5	60408000	146	60418500	158
60350400	4	147 149	154	60377100	4	60393800	5		148	60418900	134
60350500	4	60361800	132	60377200	4	60394600	44	60408100	158	60419500	15
60350600	4	60361900	133	60377300	4	60394700	44	60408200	145	60419600	15
60350700	5	60362000	133	60378100	161	60394800	93	60408300	158	60419700	15
60350800	4	60362100	133	60378200	161	60396300	111	60408400	145	60419900	165
60350900	4	60362300	133	60378300	161	60396400	5	60408800	146	60420000	56
60351000	5	60362400	135	60378400	161	60396500	6	60408700	50	60420100	166
60351100	5	60363300	49	60378500	162	60396600	5	60409200	47	60420600	5
60351200	5	60363900	110	60378600	160	60396700	5	60409400	18	60420700	5
60351300	5	60364000	44	60378700	162	60396800	5	60410000	45	60420800	165
60351900	2	60364100	40	60378900	161	60396900	5	60410100	127	60420900	7
60352000	31	60364200	40	60379000	161	60397000	5	60410200	127	60421000	7
60352300	40	60364400	110	60379100	162	60397100	5	60410600	136	60421100	7
60352500	56	60364500	44	60379200	161	60397200	5	60410700	136	60421200	7
60353000	162	60364600	110	60379300	162	60397300	5	60410800	136	60421300	7
60353100	161	60364700	102	60379500	162	60397400	5	60410900	136	60421400	7
60353200	162	60364800	102	60380000	161	60397500	5	60411000	136	60421500	7
60353300	162	60364900	83	60380100	161	60397600	5	60411300	80	60421600	7
60353500	161	60365100	109	60380200	162	60397700	6	60411400	80	60421700	7
60353700	161	60365200	43	60380300	162	60397800	6	60411500	80	60421800	7
60354300	162	60365700	48	60380400	159	60397900	6	60411600	80	60421900	7
60354500	162	60366600	31	60380500	159	60398000	6	60411700	80	60422000	7
60354600	159	60366700	32	60380600	12	60398100	6	60411800	80	60422100	7
60354700	161	60366800	6	60380700	12	60398200	6	60411900	80	60422200	7
60354900	161	60367200	56	60380800	12	60398300	7	60412000	80	60422300	81
60355100	162	60367300	51	60380900	12	60398400	8	60412100	80	60422400	81
60355200	162	60367400	48	60381000	12	60398500	8	60412200	80	60422500	81
60355300	162	60368000	47	60381100	12	60398600	8	60412300	80	60422600	81
60355400	162	60368500	49	60381200	12	60398700	8	60412400	80	60422700	81
60355500	161	60368600	84	60381300	12	60398800	8	60412500	80	60422800	81
60355700	161	60368700	112	60381400	12	60398900	8	60412600	80	60422900	81
60355800	161	60369400	36	60382200	4	60399000	8	60412700	80	60423000	81
60355900	39	60369700	4	60382300	4	60399100	8	60412800	80	60423100	165
60356000	111	60369800	16	60382600	5	60399200	8	60412900	80	60423500	17
60356300	39	60369900	15	60382700	5	60399400	110	60413000	80	60425000	17
60357100	5	60370000	4	60382800	5	60399500	70	60413100	80	60425100	47
60357900	147	60370100	4	60383300	87	60399900	108	60413200	80	60425300	152
	149 154	60370200	4	60384100	145	60400100	42	60413300	80	60425600	45
60358200	148	60370300	15		147 149	60400300	48	60413400	80	60425700	134
60358300	149	60370400	16	60384200	154	60401200	14	60413500	80	60425800	36
	153	60370500	16	60384300	147	60401500	48	60413600	80	60426000	134
60358400	149	60370600	10	60384600	150	60401600	48	60413700	81	60426500	152
	152										

PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.
60427200	165	60493500	149	70603600	26	70616100	70	70631000	25	82128900	63
60427300	165		152	70603700	26	70616200	70	70631100	25	82129000	63
60427400	165	62033500	127	70603900	24	70616300	27	70631300	28	82129700	63
60427500	8	62034200	127	70604000	53	70616400	28	70631400	28	82140400	31
60427600	42	62038000	127	70604100	124	70616700	44	70631500	28	82140800	35
60427800	51	62049500	127	70604200	121	70616800	158	73361200	41	82146800	95
60427900	157	62056300	53	70604300	25	70617000	27	73443000	157	82269600	165
60428500	45	62061700	127	70604400	25	70617100	27	73443100	157	83096200	123
60429200	158	62067900	118	70604500	25	70617400	31	73933300	157	83096300	123
60429900	3	62068000	127	70604700	25	70617800	30	74606800	39	83096400	123
60430000	110	62068100	118	70605000	25	70617900	30	74607500	41	83301000	29
60433400	3	62068200	127	70605300	25	70618000	30	74660300	41	83301100	28
60433600	3	62068300	118	70605400	71	70618400	29	74664300	41	83301200	28
60433700	3	62068400	127	70605500	25	70618500	29	74675500	41	83301400	124
60433800	3	62073300	127	70605800	27	70618600	29	74691800	41	83301500	124
60433900	3	62073800	118	70605900	53	70619100	158	74717600	41	83301600	124
60434000	3	62074000	127	70606100	26	70619200	27	74720400	41	83301700	124
60434100	3	62079500	116	70606500	25	70619300	27	74720500	41	83301800	45
60434200	4	62088900	127	70606600	123	70619400	27	74724500	41	83301900	45
60434300	4	62089100	127	70606700	24	70619500	26	75365100	123	83302000	45
60434600	3	62122800	127	70606800	72	70619600	26	75365200	124	83302300	30
60434700	3	62122900	127	70606900	24	70619700	26	75368900	124	83302400	30
60434800	3	62181600	165	70607100	24	70620400	27	75369000	125	83302500	30
60434900	3	62995900	35	70607200	26	70620500	27	75369100	124	83302600	30
60435000	3	62996000	35	70607300	26	70620600	27	75369200	124	83302700	30
60435100	3	63016700	106	70607500	24	70621300	123	75369600	124	83302800	30
60435400	147	63016900	105	70607700	121	70621400	48	75369800	124	83302900	53
60435500	147	63017100	105	70607900	28	70621500	44	75372900	124	83303100	29
60435600	147	63017200	105	70608100	124	70621600	44	75373000	124	83303200	29
60435700	147	63017300	105	70608200	124	70621700	44	75385700	124	83303300	29
60435800	147	63017400	105	70609200	27	70621800	44	75387400	123	83303700	53
60435900	147	63019200	105	70609300	27	70621900	44	75387500	123	83305700	29
60436100	147	63019600	105	70609400	26	70622000	123	75391300	124	83305800	29
60436200	147	63019700	105	70609500	27	70622100	24	75400200	65	83305900	29
60436300	147	63019800	105	70609600	33	70622200	28	75401000	123	83306000	45
60436600	145	63024900	106	70609700	26	70622300	28	75401400	124	83306100	50
60437000	166	63025400	106	70609800	27	70622400	28	75401500	124	83306300	50
60437100	166	63025500	105	70609900	27	70622500	28	75401700	124	83307900	53
60437200	167	63025600	105	70610100	27	70622600	28	75401800	124	83308000	53
60437300	111	63033500	106	70610300	28	70622700	28	75402000	124	83308400	25
60437400	81	63033600	106	70610500	28	70622800	28	75402100	124	83308500	25
60437500	81	63033700	106	70611000	27	70623500	28	76070000	145	83308600	25
60437600	81	63033800	106	70611100	27	70623600	28		148	83308700	29
60437700	81	65631800	86	70611200	27	70623700	28	76070300	146	83308800	29
60437800	81	65655800	87	70611300	27	70624500	30		148 176	83308900	29
60437900	81	65690800	87	70611500	70	70624600	30	76070400	174	83309300	29
60438000	81	65692300	36	70611600	70	70624700	30	76070600	175	83309400	29
60438100	81	65714900	58	70611700	71	70626300	29	76070700	173	83309500	29
60438200	81	65715000	58	70611800	71	70626500	28	76070800	178	83310800	25
60438300	81	65715100	58	70611900	71	70627400	124	76070900	172	83310900	25
60438400	81	65724900	91	70612000	71	70627900	29	76071000	176	83311400	28
60438500	43	65727400	87	70612200	121	70628000	29	76071200	174	83311600	29
60438600	81	65739900	59	70612400	124	70628100	29	76071400	173	83311700	29
60440800	109	69651800	9	70612500	28	70628200	28	76072700	173	83311900	45
60441000	157	70601100	71	70612600	27	70628400	28	76074000	176	83312000	45
60443100	157	70601300	24	70612800	53	70628500	30	76074300	175	83312100	45
60445300	147	70601400	25	70612900	27	70628600	30	76074400	175	83312300	53
60446100	81	70601500	25	70613000	27	70629100	158	76074600	175	83313100	29
60446200	81	70601700	33	70613100	27	70629200	30	76074700	175	83313200	29
60446300	81	70601900	26	70613200	28	70629300	30	76360001	162	83313300	29
60446400	81	70602100	33	70613300	28	70629400	30	76360002	161	83313400	30
60446500	81	70602200	25	70613700	123	70629500	29	76360003	162	83313500	30
60446600	81	70602300	25	70613800	44	70629600	29	76360010	159	83313600	30
60446700	81	70602400	26	70613900	44	70629700	29	76360011	161	83313600	30
60446800	81	70602500	26	70614000	44	70629800	124	76360012	161	83314000	29
60447700	81	70602900	124	70614100	44	70629900	124	76360015	160	83315400	50
60448200	145	70603000	26	70614200	44	70630000	30	76360023	161	83315600	42
60449200	147	70603200	26	70615100	28	70630100	30	76360031	161	83315700	42
60449200	145	70603300	26	70615700	166	70630200	30	76630900	120	83315800	42
	148	70603400	26	70615800	24	70630500	28	82115700	74	83316100	42
60493300	145	70603500	26	70615900	27	70630900	25	82128800	63	83316200	42
	147									83316300	42

PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.
83316400	42	84007900	177	86608900	173	86618400	173	91681100	155
83316600	42	84008000	177	86609000	176	86618500	173	91858500	118
84000000	175	84008100	177	86609100	176	86618900	174	91858600	67
84000100	175	84008200	177	86609200	176	86619600	174	91858700	67
84000400	175	84008300	178	86609300	176	86619700	174	91858800	67
84000500	172	84008400	178	86609400	176	86619900	174	91859000	67
84000600	173	84008500	178	86609500	176	86811400	25	91859100	118
84000700	175	84008600	178	86609600	176	87829800	33	91859200	118
84000800	173	84008700	178	86609700	176	87900200	72	91860100	67
84000900	172	84008800	178	86609800	176	87906700	33	91860200	49
84001000	173	84008900	178	86609900	176	87911800	33	91860300	52
84001100	176	84009000	178	86610000	176	87951000	33	91860400	67
84001200	173	84009100	178	86610100	176	87971600	33	96716700	133
84001300	173	84009200	178	86610200	176	87971700	33	97400200	154
84001400	173	84009300	178	86610300	176	87976600	155	97400300	152
84001500	173	84009400	178	86610400	176	87976700	155	97401500	157
84001700	173	84009600	175	86610500	176	87976800	155	97401600	157
84001800	173	84009800	174	86610600	176	87978800	74	97401700	158
84001900	173	84009900	175	86610700	176	88762000	133	97401800	170
84002000	173	84763300	140	86610800	176	88762100	133	97401900	9
84002100	173	84781600	76	86610900	176	88762200	133	97402000	171
84002400	175	84785000	158	86611000	176	88818500	133	97402100	9
84002500	174	84797500	133	86611100	177	88947900	133	97402200	171
84002600	173	84837900	75	86611200	177	88948500	133	97402300	9
84002700	173	84851100	76	86611300	177	88964000	133	97402400	9
84002800	174	84894200	74	86611400	177	88980100	42		171
84002900	173	84937300	75	86611500	177	88981000	76	97402500	9
84003000	173	84942200	43	86611600	177	88981100	41	97402600	170
84003100	173	84970400	79	86611700	177	88981500	150	97402700	8
84003200	173	86601600	175	86611800	177	88988400	149	97403500	123
84003700	173	86601700	175	86611900	177	88988500	149	97403600	158
84003800	175	86601800	172	86612000	177	88988600	149	97404600	123
84003900	145	86602000	174	86612100	174	88988700	149	97404700	152
84004000	178	86602300	174	86612200	173	88988800	149	97404800	152
84004100	178	86602800	172	86612500	173	88988900	149	97404900	152
84004200	178	86602900	173	86612600	174	88997600	133	97405000	152
84004300	178	86603000	173	86613500	173	89633300	86	97405100	152
84004400	178	86603100	173	86613600	174	89633400	86	97405200	152
84004500	178	86603200	173	86613700	174	89637200	85	97405500	152
84004600	178	86603300	173	86613800	174	89637300	46		
84004700	178	86603500	174	86614000	177	89637400	84		
84004800	178	86603700	173	86614100	174	89637700	43		
84004900	178	86604000	175	86614200	175	89638100	44		
84005000	178	86604100	175	86614300	174	89638200	85		
84005100	178	86604200	175	86614600	177	89638300	38		
84005200	178	86604300	175	86614900	177	89638400	85		
84005300	178	86604600	174	86615000	174	89638500	47		
84005400	178	86604700	174	86615100	175	89638800	171		
84005500	178	86604800	174	86615500	175	89673100	6		
84005600	178	86604900	174	86615600	177		86		
84005700	178	86605600	173	86615700	173	89723700	158		
84005800	178	86605700	177	86615800	174	89758600	17		
84005900	178	86605900	172	86615900	176	89769400	84		
84006000	178	86606100	174	86616100	173	89769500	44		
84006200	178	86606200	175	86616300	174	89796100	49		
84006300	178	86607000	175	86616600	174	91503500	169		
84006700	174	86607100	173	86616700	174	91556200	133		
84006800	177	86607200	173	86616800	172	91558900	35		
84006900	177	86607500	175	86616900	173	91566700	72		
84007000	177	86607700	172	86617100	175	91604200	74		
84007100	177	86607800	174	86617200	175	91604300	74		
84007200	177	86607900	174	86617300	175	91604400	74		
84007300	177	86608000	175	86617400	175	91604500	74		
84007400	177	86608100	175	86617500	175	91628700	52		
84007500	177	86608400	175	86617700	175	91649500	155		
84007600	177	86608500	175	86618000	172	91661300	155		
84007700	177	86608600	176	86618200	176	91662900	35		
84007800	177	86608700	176	86618300	175	91669100	33		

SECTION 1

This section contains Hardware Manuals for individual equipments arranged in equipment designator sequence. Product numbers are included in parenthesis after the equipment designator. Additional manuals may be found in Section 2 by looking up the Product Number.

TITLE	1	2	3	4
INDIVIDUAL EQUIPMENT MANUALS				
AA101-A/B COMPUTER (USE 1704-A/B, CAT. SEC. 2)				
AA102-A (7601-1) CENTRAL COMPUTER				
PARTS DATA CE MANUAL	60297700	B	22	12.35
CHANNEL TABS WIRE LIST CE MANUAL	60351900	C	22	06.25
THEORY OF OPERATION, DIAGRAMS, MAINT. AIDS	60297600	AC	22	46.50
CHASSIS 1 WIRE LIST CE MANUAL	60307600	D	22	05.10
CHASSIS 2 WIRE LIST CE MANUAL	60307700	D	22	04.60
CHASSIS 3 WIRE LIST CE MANUAL	60307800	E	22	06.70
CHASSIS 4 WIRE LIST CE MANUAL	60307900	E	22	04.50
CHASSIS 5 WIRE LIST CE MANUAL	60308000	C	22	04.15
CHASSIS 6 WIRE LIST CE MANUAL	60308100	J	22	05.70
CHASSIS 7 WIRE LIST CE MANUAL	60308200	N	22	05.50
CHASSIS 8 WIRE LIST CE MANUAL	60308300	J	22	09.70
CHASSIS 9 WIRE LIST CE MANUAL	60308400	C	22	05.05
CHASSIS 10 WIRE LIST CE MANUAL	60308500	E	22	05.05
CHASSIS 11 WIRE LIST CE MANUAL	60308600	C	22	05.00
CHASSIS 12 WIRE LIST CE MANUAL	60308700	C	22	04.80
CHASSIS 13 WIRE LIST CE MANUAL	60308800	G	22	07.00
CHASSIS 14 WIRE LIST CE MANUAL	60308900	G	22	06.15
LCM STACK WIRE LIST CE MANUAL	60309000	D	22	03.75
POWER AND REFERENCE WIRE LISTS CE MANUAL	60309100	E	22	04.30
MAINTENANCE MANUAL	60297900	E	22	15.00
REFRIGERATION INFO (USE GH214-A/B)				
(THE FOLLOWING MANUALS FOR THE ABOVE EQUIP. ARE AVAILABLE FROM D. VESTAL, ARHOPS (X3258) H2720C, H2720D SCANNER SYSTEMS SERVICE MANUAL PRICE AVAILABLE UPON REQUEST	60298500			
AA102-C () CENTRAL COMPUTER CE INFO (USE AC113-A)				
AA103-A CENTRAL COMPUTER (6614-E)				
CPU/FUNCTIONAL UNIT DIAGRAMS CE MANUAL	60287300	T	22	13.60
PERIPH PROC UNIT DIAGRAMS CE MANUAL	60284100	U	22	05.50
CENTRAL MEMORY, CLOCK, ECS COUPLER AND POWER DIAGRAMS CE MANUAL	60287400	L	22	09.35
MAINTENANCE AID-CLOCK TIMING	60289000	B	22	01.80
CHASSIS 1 CHASSIS/CABLE TABS CE MANUAL	60285300	AD	22	18.40
CHASSIS 4 CHASSIS/CABLE TABS CE MANUAL	60310500	J	22	19.75
CHASSIS 5 CHASSIS/CABLE TABS CE MANUAL	60293300	S	22	19.20
CHASSIS 6 CHASSIS/CABLE TABS CE MANUAL	60294700	F	22	20.60
CHASSIS 7 CHASSIS/CABLE TABS CE MANUAL	60294800	C	22	20.00
CHASSIS 8 CHASSIS/CABLE TABS CE MANUAL	60294900	F	22	21.70
CHASSIS 9 CHASSIS/CABLE TABS CE MANUAL	60278400	P	22	16.50
CHASSIS 10 CHASSIS/CABLE TABS CE MANUAL	60293500	G	22	08.75
CHASSIS 11 CHASSIS/CABLE TABS CE MANUAL	60293700	F	22	08.30
CHASSIS 12 CHASSIS/CABLE TABS CE MANUAL	60293900	H	22	09.80

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
AA104-A CENTRAL COMPUTER (6613-E)				
CPU/FUNTIONAL UNIT DIAGRAMS (USE AA103-A)				
PERIP PROC UNIT DIAGRAMS (USE AA103-A)				
CENTRAL MEMORY,CLOCK,ECS COUPLER,AND POWER DIAGRAMS (USE AA103-A)				
MAINTENANCE AID-CLOCK TIMING (USE AA103-A)				
CHASSIS 1 CHASSIS/CABLE TABS (USE AA103-A)				
CHASSIS 4 CHASSIS/CABLE TABS (USE AA103-A)				
CHASSIS 5 CHASSIS/CABLE TABS (USE AA103-A)				
CHASSIS 6 CHASSIS/CABLE TABS (USE AA103-A)				
CHASSIS 7 CHASSIS/CABLE TABS (USE AA103-A)				
CHASSIS 8 CHASSIS/CABLE TABS (USE AA103-A)				
CHASSIS 9 CHASSIS/CABLE TABS (USE AA103-A)				
CHASSIS 10 CHASSIS/CABLE TABS	60293600	F	22	09.50
CHASSIS 11 AND 15 TABS CE MANUAL	60293800	F	22	09.00
CHASSIS 12 CHASSIS/CABLE TABS CE MANUAL	60294000	E	22	08.45
CHASSIS 13 CHASSIS/CABLE TABS CE MANUAL	60294100	D	22	10.75
CHASSIS 14 CHASSIS/CABLE TABS CE MANUAL	60294200	D	22	08.50
CHASSIS 16 CHASSIS/CABLE TABS CE MANUAL	60294300	E	22	05.00
AA105-A CENTRAL COMPUTER (6414-E)				
DIAGRAMS CE MANUAL	60316200	Z	22	24.50
PERIPH PROC UNIT DIAGRAMS (USE AA103-A)				
CHASSIS 1 CHASSIS/CABLE TABS (USE AA103-A)				
CHASSIS 2 CHASSIS/CABLE TABS CE MANUAL	60285400	M	22	20.00
CHASSIS 3 CHASSIS/CABLE TABS CE MANUAL	60285500	Z	22	12.65
CHASSIS 4 CHASSIS/CABLE TABS CE MANUAL	60285600	E	22	09.85
CHASSIS 5 CHASSIS/CABLE TABS CE MANUAL	60285700	G	22	09.85
CHASSIS 8 CHASSIS/CABLE TABS CE MANUAL	60336400	L	22	13.30
AA105-A, AT141-A CHASSIS 9 AND 11 CARD PLACE- MENT. WIRE LIST, CE MANUAL	60286000	F	22	07.95
CHASSIS 10 AND 12 CARD PLACEMENT,WIRE LISTS CE MANUAL	60286100	G	22	10.65
AA106-A (76-XXX) CENTRAL COMPUTER				
INSTALLATION/CHECKOUT, THEORY OF OP, DIAGRAMS, MAINT AIDS, PARTS DATA CE MANUAL	60433600	A	22	65.00
POWER DISTRIBUTION/WARNING SYSTEM CE MANUAL	60433400	A	22	17.50
REFRIGERATION SYSTEM INFO (USE GH223-A)				
MAINTENANCE CE MANUAL	60429900	A	22	25.90
CHASSIS 1 WIRE LIST CE MANUAL	60434600	A	22	
CHASSIS 2 WIRE LIST CE MANUAL	60434700	A	22	23.05
CHASSIS 3 WIRE LIST CE MANUAL	60434800	A	22	26.05
CHASSIS 4 WIRE LIST CE MANUAL	60434900	A	22	19.70
CHASSIS 5 WIRE LIST CE MANUAL	60435000	A	22	20.00
CHASSIS 6 WIRE LIST CE MANUAL	60435100	A	22	23.10
CHASSIS 7 WIRE LIST CE MANUAL	60433700	A	22	22.20
CHASSIS 8 WIRE LIST CE MANUAL	60433800	A	22	24.55
CHASSIS 9 WIRE LIST CE MANUAL	60433900	A	22	22.50
CHASSIS 10 WIRE LIST CE MANUAL	60434000	A	22	
CHASSIS 11 WIRE LIST CE MANUAL	60434100	A	22	

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CHASSTS 13 WIRE LIST CE MANUAL	60434200	A	22	
CHASSTS 14 WIRE LIST CE MANUAL	60434300	A	22	
CABLE WIRE LIST CE MANUAL	60434400	A	22	
AA107-A (172-X,173-X,174-X) REFRIGERATION SYST GEN. DESC., OPERATION, THEORY OF OPERATION, INSTALLATION/CHECKOUT, MAINTENANCE, PARTS DATA HARDWARE MAINTENANCE MANUAL	19983800	01	22	03.45
AA108-A CENTRAL COMPUTER (6415-E) PERIPH PROC UNIT DIAGRAMS (USE AA103-A) CHASSIS 1 CHASSIS/CABLE TABS (USE AA103-A) CHASSIS 2,3,4,5 AND 8 CHASSIS/CABLE TABS CE MANUALS (USE AA105-A)				
AA108-B (PROD 6415-9) CENTRAL COMPUTER PERIPH PROC UNIT DIAGRAMS (USE AA103-A) CHASSIS 1 CHASSIS/CABLE TABS (USE AA103-A) CHASSIS 2,3,4,5 AND 8 CHASSIS/CABLE TABS CE MANUALS (USE AA105-A) CHASSIS 11 CHASSIS/CABLE TABS (USE AA103-A)				
AA108-C (PROD 6415-8) CENTRAL COMPUTER PERIPH PROC UNIT DIAGRAMS (USE AA103-A) CHASSIS 2,3,4,5 AND 8 CHASSIS/CABLE TABS CE MANUALS (USE AA105-A)				
AA108-D (PROD 6415-7) CENTRAL COMPUTER PERIPH PROC UNIT DIAGRAMS (USE AA103-A) CHASSIS 1 CHASSIS/CABLE TABS (USE AA103-A) CHASSIS 2,3,4,5 AND 8 CHASSIS/CABLE TABS CE MANUALS (USE AA105-A)				
AA115-A (72-XX, 73-XX) BASIC UNIFIED PROCESSOR COMMAND TIMING CE MANUAL	60404500	A	22	15.15
REFRIGERATION SYSTEMS CE MANUAL	60382300	C	22	03.30
POWER DISTRIBUTION/WARNING SYSTEM CE MANUAL	60382200	F	22	04.60
CHASSIS 1,3,11 DIAGRAMS CE MANUAL	60369700	R	22	16.55
CHASSIS 2,6 DIAGRAMS CE MANUAL	60370000	T	22	10.75
CHASSIS 3 DIAGRAMS CE MANUAL	60370200	M	22	01.20
CHASSIS 4 DIAGRAMS CE MANUAL	60370100	Z	22	16.00
CHASSIS 5 DIAGRAMS CE MANUAL	60377200	G	22	02.50
CHASSIS 7 DIAGRAMS CE MANUAL	60377100	F	22	05.90
CHASSIS 8 DIAGRAMS CE MANUAL	60377300	L	22	06.70
CHASSIS 1,3,11 WIRE LIST CE MANUAL	60350200	R	22	39.50
CHASSIS 2,6 WIRE LIST CE MANUAL	60350300	V	22	34.00
CHASSIS 3 WIRE LIST CE MANUAL	60350400	L	22	26.75
CHASSIS 4 WIRE LIST CE MANUAL	60350500	AC	22	27.75
CHASSIS 5 WIRE LIST CE MANUAL	60350600	D	22	37.35
CHASSIS 7 WIRE LIST CE MANUAL	60350800	K	22	17.60
CHASSIS 8 WIRE LIST CE MANUAL	60350900	R	22	30.45
AA116-A (1714) COMPUTER 65K				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
GEN DESC, OPER AND PROG, INSTAL, CHKOUT THEO OF OP, DIAGRAMS, MAINT CE MANUAL	60357100	C	22	09.10
PARTS DATA CE MANUAL	60393700	A	22	06.85
CROSS TABS CE MANUAL	60393800	B	22	05.30
REFRIGERATION SYSTEMS CE INFO (USE AA115-A)				
COMMAND TIMING CE MANUAL	60374900	B	22	05.50
AA117-A (74-XX) PARALLEL PROCESSOR				
POWER DIST - WARNING SYSTEM INFO (USE AA115)				
CHASSIS 1 CE INFO USE AA115-A				
CHASSIS 4 WIRE LIST CE MANUAL	60371100	K	22	27.80
CHASSIS 5 WIRE LIST CE MANUAL	60371200	S	22	32.90
CHASSIS 6 WIRE LIST CE MANUAL	60350700	E	22	27.30
CHASSIS 7 WIRE LIST CE MANUAL	60371300	E	22	32.05
CHASSIS 8 WIRE LIST CE MANUAL	60371400	E	22	31.20
CHASSIS 9 WIRE LIST CE MANUAL	60351000	P	22	20.20
CHASSIS 10 WIRE LIST CE MANUAL	60351100	D	22	19.10
CHASSIS 11 WIRE LIST CE MANUAL	60351200	F	22	20.60
CHASSIS 12 WIRE LIST CE MANUAL	60351300	L	22	20.40
CHASSIS 13 AND 15, 14 AND 16 USE AT237-A				
CHASSIS 4,5,6,7,8 DIAGRAMS MANUAL	60370800	R	22	36.70
CHASSIS 9 DIAGRAMS MANUAL	60370900	P	22	09.95
CHASSIS 10 DIAGRAMS MANUAL	60382600	D	22	03.90
CHASSIS 11 DIAGRAMS MANUAL	60382700	C	22	04.15
CHASSIS 12 DIAGRAMS MANUAL	60382800	H	22	02.35
AA119-A/B/C/D (1714) COMPUTER 65K CE INFO (USE AA116-A)				
AA120-A (175-XX) CENTRAL COMPUTER				
REFRIGERATION SYSTEM INFO (USE GH223-A)				
MAINTENANCE, PARTS DATA HOWE MAINT MANUAL (INCLUDES INFO FOR ALL OPTIONS)	60420600	01	22	08.70
POWER DISTRIBUTION/WARNING SYSTEM MANUAL	60420700	A	22	09.90
CENTRAL PROCESSOR THEORY, DIAGRAMS MANUAL	60420300		22	
CENTRAL PROCESSOR (CH 5-7) WIRE LIST MANUAL	60420400		22	
CABLE WIRE LIST MANUAL	60420200		22	
INSTALLATION/CHECKOUT MANUAL	60420500		22	
AA121-A (7700) CENTRAL COMPUTER				
INSTALLATION/CHECKOUT, THEORY OF OP, DIAGRAMS, MAINT AIDS, PARTS DATA CE MANUAL	60396400	A	22	34.10
CHASSIS 1 WIRE LISTS CE MANUAL	60396600	A	22	08.05
CHASSIS 2 WIRE LISTS CE MANUAL	60396700	A	22	07.40
CHASSIS 3 WIRE LISTS CE MANUAL	60396800	A	22	08.85
CHASSIS 4 WIRE LISTS CE MANUAL	60396900	A	22	07.80
CHASSIS 5 WIRE LISTS CE MANUAL	60397000	A	22	07.80
CHASSIS 6 WIRE LISTS CE MANUAL	60397100	A	22	05.60
CHASSIS 8 WIRE LISTS CE MANUAL	60397300	A	22	10.40
CHASSIS 7 WIRE LISTS CE MANUAL	60397200	A	22	09.60
CHASSIS 9 WIRE LISTS CE MANUAL	60397400	A	22	11.20
CHASSIS 10 WIRE LISTS CE MANUAL	60397500	A	22	11.30
CHASSIS 11 WIRE LISTS CE MANUAL	60397600	A	22	10.10

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CHASSIS 12 WIRE LISTS CE MANUAL	60397700	A	22	08.25
CHASSIS 13 WIRE LISTS CE MANUAL	60397800	A	22	10.50
CHASSIS 14 WIRE LISTS CE MANUAL	60397900	A	22	10.25
CHASSIS 15 WIRE LISTS CE MANUAL	60398000	A	22	04.95
LCM STACK CABLES WIRE LIST C.E.MANUAL	60398100	A	22	09.65
CHANNEL TABS WIRE LISTS CE MANUAL	60398200	B	22	14.15
POWER AND REFERENCE WIRE LISTS CE MANUAL	60396500	A	22	11.10
** SEE ALSO AB101-A, AD102-A MANUALS **				
AB101-A (7601-1, 7611-1/2) PERIPHERAL PROC. THEO OF OPERATION, INSTALLATION/CHECKOUT, DIAGRAMS, MAINTENANCE AIDS, PARTS DATA. WIRE LISTS CE MANUAL	60274900	P	22	09.40
AB102-A/B (7611-1/2) PERIPHERAL PROCESSOR CAB. INSTALLATION/CHECKOUT, THEORY OF OPERATION, DIAGRAMS, MAINTENANCE AIDS, PARTS DATA, WIRE LISTS CE MANUAL (USE AR101-A) REFRIGERATION INFO (USE GH214-A IF AB102-A OR GH214-B IF AB102-B) POWER DISTRIBUTION/WARNING SYSTEM (USE GH105-A/B/C IF AB102-A OR GH105-D IF AB102B				
AB103-A (90104) COMPUTE MODULE CE MANUAL	60278100	AW	22	07.75
PARTS LIST CE MANUAL	60366800	E	22	16.20
AB107/AB108 INPUT/OUTPUT SPECIFICATIONS	89673100	01	22	04.30
AC104-A (3504-1) CENTRAL COMPUTER GENERAL DESCRIPTION, DIAGRAMS, CABLE TABS CE MANUAL	60181000	AW	34	49.00
PROCESSOR (USE 3304-B, CATALOG SECTION 2) MAINT. AIDS; COMMAND TIMING CHARTS CE MANUAL	60238000	B	22	07.85
PARTS DATA CE MANUAL	60233100	AG	22	10.80
AC105-B (3174-1/2/3/4, 3304, 3304-2/3) CENTRAL PROCESSOR (USE 3304.B, CATALOG, SECTION 2)				
AC106-A (3514-1/2/3/4) CENTRAL PROCESSOR GENERAL DESC., DIAGRAMS, CABLE TABS CE MAN	60289500	AU	34	88.60
MAINT. AIDS, COMMAND TIMING CHARTS CE MANUAL	60312400	A	22	21.90
PARTS DATA (USE AC104-A)				
AC109-A (1774-1) SYSTEM CONTROLLER CE INFO (USE AB103-A)				
AC113-A () CENTRAL COMPUTER CHASSIS 1 WIRE LIST CE MANUAL	60348200	A	22	05.70
CHASSIS 2 WIRE LIST CE MANUAL	60348300	A	22	06.45
CHASSIS 3 WIRE LIST CE MANUAL	60348400	A	22	04.30

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CHASSIS 4 WIRE LIST CE MANUAL	60348500	C	22	06.30
CHASSIS 5 WIRE LIST CE MANUAL	60348600	B	22	06.15
CHASSIS 6 WIRE LIST CE MANUAL	60348700	H	22	06.85
CHASSIS 7 WIRE LIST CE MANUAL	60348800	H	22	07.00
CHASSIS 8 WIRE LIST CE MANUAL	60348900	C	22	06.95
CHASSIS 9 WIRE LIST CE MANUAL	60349000	B	22	06.75
CHASSIS 10 WIRE LIST CE MANUAL	60349100	B	22	07.90
CHASSIS 12 WIRE LIST CE MANUAL	60349300	B	22	06.40
CHASSIS 11 WIRE LIST CE MANUAL	60349200	B	22	06.90
CHASSIS 13 WIRE LIST CE MANUAL	60349400	E	22	06.15
CHASSIS 14 WIRE LIST CE MANUAL	60349500	C	22	05.80
THEO OF OPERATION, DIAGRAMS, MAINT. CE MAN	60348000	AB	22	29.95
LCM STACK WIRE LIST CE MANUAL	60349600	D	22	08.00
POWER AND REFERENCE WIRE LIST CE MANUAL	60349700	E	22	08.35
CHANNEL TABS WIRE LIST CE MANUAL	60349800	E	22	09.55
REFRIGERATION MANUAL (USE GH214-B)				
POWER DISTRIBUTION/WARNING SYSTEM (USE GH105-D)				
AC113-B () CENTRAL COMPUTER				
CHASSIS 1 WIRE LIST CE MANUAL	60420900	A	22	18.60
CHASSIS 2 WIRE LIST CE MANUAL	60421000	A	22	20.70
CHASSIS 3 WIRE LIST CE MANUAL	60421100	A	22	19.20
CHASSIS 4 WIRE LIST CE MANUAL	60421200	A	22	14.60
CHASSIS 5 WIRE LIST CE MANUAL	60421300	A	22	15.20
CHASSIS 6 WIRE LIST CE MANUAL	60421400	C	22	20.10
CHASSIS 7 WIRE LIST CE MANUAL	60421500	C	22	21.05
CHASSIS 8 WIRE LIST CE MANUAL	60421600	D	22	17.85
CHASSIS 9 WIRE LIST CE MANUAL	60421700	B	22	18.60
CHASSIS 10 WIRE LIST CE MANUAL	60421800	C	22	15.80
CHASSIS 11 WIRE LIST CE MANUAL	60421900	A	22	17.84
CHASSIS 12 WIRE LIST CE MANUAL	60422000	C	22	16.55
CHASSIS 13 WIRE LIST CE MANUAL	60422100	B	22	18.00
CHASSIS 14 WIRE LIST CE MANUAL	60422200	A	22	14.75
INSTALLATION/CHECKOUT, THEORY OF OP, DIAGRAMS, MAINT AIDS, PARTS DATA INFO (USE AC113-A)				
MAINTENANCE INFO (USE AA102-A)				
LCM STACK WIRE LIST INFO (USE AC113-A)				
POWER AND REFERENCE WIRE LIST INFO (USE AC113-A)				
CHANNEL TABS WIRE LIST INFO (USE AC113-A)				
REFRIGERATION INFO (USE GH214-B)				
POWER DISTRIBUTION AND WARNING SYSTEM INFO (USE GH105-D)				
AC115-A/B/C (1774-1) BASIC PROCESSOR CE INFO (USE AB103-A)				
AD102-A (7700) ADJUNCT PROCESSOR INSTALLATION/CHECKOUT, THEORY OF OPERATION, DIAGRAMS (USE AA121-A)				
CHASSIS 6 WIRE LISTS CE MANUAL	60398300	A	22	06.45

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CHASSIS 7 WIRE LISTS CE MANUAL	60398400	A	22	07.20
CHASSIS 8 WIRE LISTS CE MANUAL	60398500	A	22	09.65
CHASSIS 9 WIRE LISTS CE MANUAL	60398600	A	22	10.30
CHASSIS 10 WIRE LISTS CE MANUAL	60398700	A	22	11.50
CHASSIS 11 WIRE LISTS CE MANUAL	60398800	A	22	08.80
CHASSIS 12 WIRE LISTS CE MANUAL	60398900	A	22	09.70
CHASSIS 13 WIRE LISTS CE MANUAL	60399000	A	22	08.35
CHASSIS 14 WIRE LISTS CE MANUAL	60399100	A	22	09.60
CHANNEL TABS WIRE LISTS CE MANUAL	60399200	B	22	09.80
POWER AND REFERENCE WIRE LISTS CE MANUAL	60427500	A	22	05.95
AE116-B (10174-X) SECOND CENTRAL PROCESSOR CONVERTS A 6600-A/B/C WITH SPIGOTS TO A 6700-A/B/C. DIAGRAMS, WIRE LIST CE MANUAL (CH.12) (FOR CONSOLE DISPLAY CONTROLLER DOCUMENTS USE FR114-A)	60374800	D	22	26.90
AE116-C (10174-X) SECOND CENTRAL PROCESSOR CONVERTS A 6600-D/E WITH SPIGOTS TO A 6700-D/F. DIAGRAMS, WIRE LIST INFO (CH.2)(USE AE116-B)				
AE116-D (74-2X) SECOND CENTRAL PROCESSOR CHASSIS 2 WIRE LIST CE MANUAL	60371000	J	22	26.00
CHASSIS 2 DIAGRAMS CE MANUAL	60416000	E	22	11.10
AF101-A (3304-2) BUSINESS DATA PROCESSOR (USE 3312-A, CATALOG SFC. 2)				
AF101-B (3174-3/4, 3304-3, ST.OP.10256-1/2/ 3/4) BUSINESS DATA PROCESSOR MAINTENANCE - PMI/PMP (USE 3304-A) PARTS LIST (USE 3304-A) WIRE LIST (TERM LIST, HAND TABS) CE MANUAL	60291200	L	22	10.10
MAINTENANCE COMMAND TIMING CHARTS CE MANUAL	60283500	J	22	17.30
EQUATION SUMMARY, CARD PLACEMENT CE MANUAL	60291100	L	22	11.90
DIAGRAMS CE MANUAL	60283400	M	22	06.65
AF102-A (3514-2/4) BUSINESS DATA PROCESSOR MAINT. AIDS, COMMAND TIMING CHARTS (USE AC106-A) GENERAL DESCRIPTION, DIAGRAMS, CABLE TABS CE MANUAL	60311200	P	22	08.60
AF104-A/AT146-A OR AF105-A/AT165-A 3200 ENHANCED BLOCK CONTROL MODIFICATION (OPTION 10287) AND 3200 BUSINESS DATA PROCESSOR INTERFACE (OPTION 10256) CE MANUAL	97402700	A	22	33.90
AF104-A (ST.OP.10256-1) 3200 BUSINESS DATA PROCESSOR INTERFACE CE MANUAL	60347600	C	22	19.30

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
AF104-B (ST.OP.10256-2) 3100 BDP INTERFACE OPT CE MANUAL	97401900	A	22	09.70
AF105-A (ST.OP.10287-1) 3200 ENHANCED BLOCK CONTROL MODIFICATION CE MANUAL	97402500	A	22	24.70
REF MANUAL	97402400	A	22	03.60
AF106-A (ST.OP.10287-2) 3100 ENHANCED BLOCK CONTROL MODIFICATION CE MANUAL	97402100	A	22	14.60
AF107-A (ST.OP.10287-4) 3100 ENHANCED BLOCK CONTROL AND BDP INTERFACE CE MANUAL	97402300	B	22	20.95
AN/UYS-25 (V) DATA PROCESSING SET - REF MAN	69651800		22	08.90
AT105-A (ST. OPT. 10121) ACCESS CHANNEL CE INFO (USE BB313-A)				
AT106-A (ST. OPT.10123) MEMORY PROTECT - 3100 REF/CE MANUAL	60228700	D	22	04.15
AT115-A (ST. OPT.10123) MEMORY PROTECT - 3200 (USE AT106-A)				
AT124-A (3514-3/4) RELOCATION PAGE FILE DIAGRAMS (USE AC106-A) COMMAND TIMING CHARTS (USE AC104-A)				
AT129-A (10169, 10173-6/7/8/9/10) CENTRAL MEMORY ACCESS PRIORITY OPTION FOR 64/6500-ABC REF/CE MANUAL	60272700	G	22	08.15
AT130-A (10169, 10173-3/4/5/6/7/8/10, 10174-1 CENTRAL MEMORY ACCESS CE INFO (USE AA103-A PPU DIAGRAMS AND CH.1 WIRE LISTS CE MANUALS)				
AT131-A (10169, 10173-3/4/5, 10174-1/2) CENTRAL MEMORY ACCESS PRIORITY REF/CE MANUAL	60270900	H	22	12.30
AT137-A (10173-6/7/8/9) CENTRAL MEMORY ACCESS (AT130-A MUST BE INSTALLED) FOR ADDITIONAL PPU S - APPLICABLE TO A 6413-D CENTRAL COMPUTER (USE AA105-A) REF INFO (USE 6000 COMPUTER SYSTEMS REF MAN)				
AT139-A (10173-7/9/10, 10178-2) CENTRAL MEMORY ACCESS FOR ADDITIONAL PPU S - APPLICABLE TO A				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
6414-D CENTRAL COMPUTER (USE AA105-A) (AT130-A MUST BE INSTALLED)				
AT140-A (6413-E, ST.OP.10119) 65K MEMORY INCREMENT FOR AA105-A				
CHASSIS 9 AND 11 WIRE LIST CE MANUAL	60286000	B	22	07.95
CHASSIS 10 AND 12 WIRE LIST CE MANUAL FOR AN AA105-A/AT141-A COMPUTER SYSTEM	60286100	C	22	10.65
AT140-B (ST.OP. 10178-1) 32K MEMORY INCREMENT REFERENCE/CE MANUAL	60315600	D	22	09.50
AT140-E (ST.OP. 10119) MEMORY INCREMENT TO 131K FOR 6413-A/B/C AND 6513-A/B/C COMPUTERS (USE 6414/6514-A)				
AT140-F (PROD ST OPT 10178-1) 32K MEMORY INCR. FOR AN 6414/6514-A/B/C CENTRAL COMPUTER REFERENCE/CE MANUAL	60317300	C	22	10.35
AT140-G (10119) 65K MEMORY INCREMENT TO 131K FOR 6400/6500-D, USE 6413-D/6513-D. NOTE IF INSTALLED ON 6414-A/B/C OR 6500-A/B/C COMPUTERS ORDER ONLY THE FOLLOWING MANUALS.				
6413-D CHASSIS 9/11 CHASSIS TABS (60248800)				
6413-A/B/C CABLE TABS (60188900)				
6413-D CHASSIS 10/12 CHASSIS TABS (60248900)				
6413-D DIAGRAMS (USE ONLY CHASSIS 9 THROUGH 12 DIAGRAMS) (60246800)				
AT140-H (PROD ST OPT 10178-1) 32K MEMORY INCR FOR AN 6414/6514-D CENTRAL COMPUTER REF/CE MANUAL	60296500	B,C	22	05.05
AT141-A (6500-E) SECOND CPU FOR AA105-A USE MANUALS LISTED UNDER AA105-A UNLESS DT143-A OR AT194-A ARE INSTALLED IN WHICH CASE USE MANUALS LISTED UNDER AT194-A.				
AT142-F (PROD ST OPT 10177-1) 16K MEMORY INCR FOR A 6415-A/B/C CENTRAL COMPUTER REF/CE MANUAL	60317600	C	22	03.05
AT142-H (PROD ST OPT 10177-1) 16K MEMORY INCR FOR A 6415-D CENTRAL COMPUTER REFERENCE/CE MANUAL	60315700	B	22	02.90
AT145-A/B/C (10173) ADDITIONAL PPU CHASSIS FOR 6000 COMPUTERS (INCR TO 20 PPU S) CE MANUAL (ALSO REQUIRES AT177-A/B/C CE MANUAL)	60370600	K	22	22.50

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
AT146-A (10287-3) MEMORY INCREMENT - 3200 CE MANUAL (USE AF104-A)				
AT147-A (ST.OP. 10180) MEMORY INCREMENT 6600-A/B/C MACHINES 98K TO 131K (USE 6613-A/B/C)				
AT147-B (ST.OPT. 10180) MEMORY INCREMENT 6600-D MACHINES 98K TO 131K (USE 6613-D)				
AT147-C (ST.OPT. 10180) MEMORY INCREMENT 6600-E MACHINES 98K TO 131K (USE AA103-A)				
AT149-A (ST.OP.10173) ADDITIONAL MEMORY ACCESS OPTION FOR 6414-A/B/C, 6514-A/B/C DIAGRAMS, W/L, C/P CE MANUAL	60406100	B	22	01.80
CABLE TABS (AT149-A ONLY) CE MANUAL	60415800	C	22	18.15
ALSO REQUIRES THE FOLLOWING AA105-A MANUALS DIAGRAMS CE MANUAL 60316200 CH 2 WIRE LISTS CE MANUAL 60285400 CH 3 WIRE LISTS CE MANUAL 60285500				
AT151-A (10256-4) 3100 BDP OPTION CE INFO (USE AF107-A)				
AT152-A (ST.OP.10173) ADDITIONAL MEMORY ACCESS OPTION FOR 6413-A/B/C, 6513-A/B/C CABLE TABS CE MANUAL	60415900	C	22	30.85
DIAGRAMS, WIRE LIST INFO (USE AT149-A)				
AT153-A (10173-4/5, 10174-2) ADDITIONAL CENTRAL MEMORY ACCESS FOR 6614-A/B/C COMPUTER SYSTEMS. GEN.DESC. AND DIAGRAMS	60392300	E	22	03.40
CHASSIS 2 WIRE LISTS CE MANUAL	60391700	A	22	31.65
CHASSIS 3 WIRE LISTS (USE AA103-A, CH 9)				
CHASSIS 3 ECS COUPLER DIAGRAMS (USE AA103-A ECS COUPLER DIAGRAMS)				
CHASSIS 4 WIRE LISTS CE MANUAL	60391800	B	22	19.00
CHASSIS 5 WIRE LISTS CE MANUAL	60391900	D	22	31.30
CHASSIS 9 WIRE LISTS CE MANUAL	60392000	B	22	17.40
CHASSIS 10 WIRE LISTS CE MANUAL	60392100	A	22	21.25
CABLE TABS CE MANUAL	60392400	B	22	19.30
AT154-A (10173-X) ADDITIONAL MEMORY ACCESS FOR 6613-A/B/C DIAGRAMS (EXCEPT CH.1,3,12) CE MANUAL	60319300	P	22	04.60
CHASSIS 1 DIAGRAMS, WIRE LIST CE MANUAL (USE ONLY IF AT145-A/AT176-A IS NOT INSTALLED)	60423300		22	
DIAGRAMS, WIRE LIST CH.3 (USE AA103-A CH.9)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE				1	2	3	4
DIAGRAMS, WIRE LIST CH.12 (USE AE116-B)				60380600	B	22	26.50
CHASSIS 2 WIRE LIST CE MANUAL				60380700	B	22	16.25
CHASSIS 4 WIRE LIST CE MANUAL				60380800	G	22	25.90
CHASSIS 5 WIRE LIST CE MANUAL				60380900	B	22	19.70
CHASSIS 9 WIRE LIST CE MANUAL				60381000	C	22	12.10
CHASSIS 10 WIRE LIST CE MANUAL				60381100	C	22	11.30
CHASSIS 13 WIRE LIST CE MANUAL				60381200	D	22	11.25
CHASSIS 14 WIRE LIST CE MANUAL				60381300	C	22	10.35
CHASSIS 15 WIRE LIST CE MANUAL				60381400	C	22	11.80
CHASSIS 16 WIRE LIST CE MANUAL				60321600	G	22	20.25
CABLE TABS CE MANUAL							
AT155-A (10173-4/5, 10174-2) ADDITIONAL MEMORY ACCESS FOR 6614-D							
CHASSIS 9 (ONLY) DIAGRAMS, W/L, C/P CE MAN.				60374500	B	22	15.10
CHASSIS NO.	USE MANUALS FOR	DIAGRAMS PUB. NO.	CHASSIS TABS PUB.NO.				
**** 1	AA103-A	*60284100	**60285300				
4	6614-D	60224800	60247000				
5	AA103-A	***60287300	60293300				
6	6614-D	60224800	60247200				
7	6614-D	60224800	60247300				
8	6614-D	60224800	60247400				
10	AA103-A	60287400	60293500				
11	AA103-A	60287400	60293700				
12	AA103-A	60287400	60293900				
* FOR 20 PPU S USE THIS MANUAL PLUS DIFFERENCE PAGES FROM AT176-A/AT145 MANUAL, PUB.NO. 60370600							
** FOR 20 PPU S COMPLETE CHASSIS 1 AND 3 TABS ARE INCLUDED IN AT176-A/AT145 MANUAL, PUB.NO. 60370600							
*** USE ONLY CHASSIS 5 PORTION OF THIS MANUAL.							
**** THIS DOCUMENTATION SHOULD BE USED INSTEAD OF 6600-D CHASSIS 1 PLUS AT130-A OPTION MANUAL WHICH IS OBSOLETE							
AT156-A (10173-3/4, 10174-1) ADDITIONAL MEMORY ACCESS FOR 6613-D							
CHASSIS 9 (USE AT155-A)							
CHASSIS NO.	USE MANUALS FOR	DIAGRAMS PUB. NO.	CHASSIS TABS PUB.NO.				
**** 1	AA104-A	*60284100	**60285300				
4	6613-D	60224800	60247000				
5	AA104-A	***60287300	60293300				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE				1	2	3	4
6	6613-D	60224800	60247200				
7	6613-D	60224800	60247300				
8	6613-D	60224800	60247400				
10	AA104-A	60287400	60293600				
11/15	AA104-A	60287400	60293800				
12	AA104-A	60287400	60294000				
13	AA104-A	60287400	60294100				
14	AA104-A	60287400	60294200				
16	AA104-A	60287400	60294300				
<p>* FOR 20 PPU S USE THIS MANUAL PLUS DIFFERENCE PAGES FROM AT176-A/AT145 MANUAL, PUB.NO. 60370600.</p> <p>** FOR 20 PPU S COMPLETE CHASSIS 1 AND 3 TABS ARE INCLUDED IN AT176-A/AT145 MANUAL, PUB.NO. 60370600.</p> <p>*** USE ONLY CHASSIS 5 PORTION OF THIS MANUAL.</p> <p>**** THIS DOCUMENTATION SHOULD BE USED INSTEAD OF 6600-D CHASSIS 1 PLUS AT130-A OPTION MANUAL.</p>							
<p>AT160-A (ST.OP.10173) REQUIRED WHEN A 6500-A/B/C HAS AN ADDITIONAL MEMORY ACCESS ADDED (AT149-A OR AT152-A) CE INFO (USE AT141-A)</p>							
<p>AT162-A ADDITIONAL PPU (USE AA108-A OR 6400-D MANUALS)</p>							
<p>AT163-A ADDITIONAL PPU (USE AA108-A OR 6400-D MANUALS)</p>							
<p>AT164-A ADDITIONAL PPU (USE AA108-A OR 6400-D MANUALS)</p>							
<p>AT165-A (10256-3) 3200 BDP OPTION CE INFO (USE AT146-A)</p>							
<p>AT168-A (ST.OP. 10105) MEMORY INCREMENT TO 131K FOR 6614-E/6714 COMPUTER SYSTEMS (USE AA103-A)</p>							
<p>AT168-R (ST.OP.10180-1) 32K MEMORY INCR TO 98K FOR AA103-A COMPUTER REFERENCE/CE MANUAL ALSO ORDER MANUALS LISTED FOR CHASSIS 10, 11,12,13,14,15,16 FOR AA104-A</p>				60315500	A	22	07.15
<p>AT168-C (ST.OP. 10105) MEMORY INCREMENT TO 131K FOR 6614-A/B/C WITH AT153-A (USE AT154-A)</p>							

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
AT168-F (ST.OP. 10105-A) MEMORY INCREMENT TO 131K FOR 6614-A COMPUTER SYSTEM (USE 6613-A/B/C)				
AT168-F (ST.OP. 10105-B) MEMORY INCREMENT TO 131K FOR 6614-B/C COMPUTER SYSTEM (USE 6613-A/B/C)				
AT168-G (ST.OP. 10180-1) 32K MEMORY INCREMENT FOR 6614-A/B/C REF/CE MANUAL	60317200	A	22	08.15
AT168-J (ST.OP.10180-1) 32K MEMORY INCR TO 98K FOR 6614-D CENTRAL COMPUTER REFERENCE/CF MANUAL ALSO ORDER MANUALS LISTED FOR CHASSIS 9,	60295900	A	22	5.30
AT174-A () PERIPHERAL PROCESSOR CE INFO (USE AA106-A)				
AT176-A (10173) ADDITIONAL PPU CHASSIS FOR 6000 COMPUTERS (INCREMENT TO 20 PPU S) CE INFO (USE AT145-A/B/C)				
AT177-A/B/C (10173) EXTERNAL DATA CHANNEL CE MANUAL	60318900	F	22	16.05
AT194-A (6500-D OR 6500-E WITH ECS) ECS CAPABILITY FOR AA105-A WITH AT141-A OR ECS CAPABILITY FOR 6400-D WITH AT198-A				
FOR 6500-D CHASSIS 7 DIAGRAMS, WIRE LIST CE MANUAL CHASSIS 2 AND 6 DIAGRAMS, WIRE LIST INFO (IDENTICAL TO 6500-C WITH ECS - SEE AT195-A) CHASSIS 8 DIAGRAMS, WIRE LIST INFO (IDENTICAL TO 6500-E WITH ECS - SEE NEXT ENTRY BELOW)	60416700	G	22	04.30
FOR 6500-E CHASSIS 2/6,3,8 DIAGRAMS, WIRE LIST CE MAN	60401200	G	22	10.20
AT195-A (6500-A/B/C WITH ECS) ECS CAPABILITY FOR 6500-A/B/C CHASSIS 2,3,8 DIAGRAMS, WIRE LIST CE MANUAL	60344800	F	22	17.10
AT196-A (6500-A/B/C) SECOND CPU FOR 641X-A/B/C USE 6400-A/B/C UNLESS DT117-A OR AT195-A ARE INSTALLED IN WHICH CASE USE MANUALS LISTED UNDER AT195-A.				
AT197-A (6500-A) SECOND CPU FOR 6404-A MAKES A 6514-A (SEE AT195-A)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
AT198-A (6500-D) SECOND CPU FOR 641X-D USE 6400-D UNLESS AT194-A IS INSTALLED IN WHICH CASE USE MANUALS LISTED UNDER AT194-A.				
AT217-A (6200-E, 6014, 6015) CPU CONVERSION FOR AA108-A/B/C/D OR AA105-A DIAGRAMS, WIRE LISTS CE MANUAL (CHASSIS 8)	60404900	A	22	31.40
DIAGRAMS, WIRE LISTS CE MANUAL (CHASSIS 2)	60404800	B	22	24.65
AT217-A () CPU CONVERSION FOR 6415-D OR 6414-D DIAGRAMS CE MANUAL	60419500	D	22	15.35
CHASSIS 2 WIRE LISTS CE MANUAL	60419600	C	22	33.15
CHASSIS 8 WIRE LISTS CE MANUAL	60419700	B	22	18.20
AT219-A (CYBER 74-XX) ECS COUPLER ENABLE CE INFO (INCLUDED IN AA117-A, CHASSIS 9 MANUALS)				
AT224-A (10267-1) 64 BIT INCREMENT TO 128 BITS FOR INTERLOCK REGISTER CE INFO (USE AA115-A, CHASSIS 3)				
AT226-A (73-XX, 10270-2, 10272-1/2) SPEED INCREMENT FOR AA115-A BASIC UNIFIED PROCESSOR AND AT227-A SECOND BASIC UNIFIED PROCESSOR CHASSIS 2 AND 6 WIRE LISTS CE MANUAL	60370300	T	22	43.60
CHASSIS 2 AND 6 DIAGRAMS CE MANUAL (DIFFERENCE PAGES ONLY, ALSO ORDER AA115-A CHASSIS 2 AND 6 DIAGRAMS) COMMAND TIMING INFO (USE AA115-A)	60369900	N	22	04.20
AT227-A (72-XX, 73-XX) SECOND BASIC UNIFIED PROCESSOR (CHASSIS 6) CE INFO (USE AT226-A)				
AT231-A (72-XX, 73-XX) 16K INCREMENT TO 65K CE INFO (USE AA115-A)				
AT232-A (72-XX, 73-XX) 16K INCREMENT TO 49K CE INFO (USE AA115-A)				
AT233-A (10268-3, 10269-3) 3 PPU INCR TO 20 PPU S FOR AA115-A OR AA117-A CE INFO (USE AA115-A, CHASSIS 1)				
AT234-A () 4 PPU INCREMENT TO 14 PPU S FOR AA117-A CE INFO (USE AA115-A, CHASSIS 1)				
AT235-A (10268-2, 10269-2) 3 PPU INCR TO 17 PPU S FOR AA115-A OR AA117-A				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE INFO (USE AA115-A, CHASSIS 1)				
AT236-A (72-XX, 73-XX, 74-XX, 10265-4, 10264-4 32K INCR TO 131K FOR AA115-A OR AA117-A CE INFO (USE AT237-A)				
AT237-A (72-XX, 73-XX, 74-XX, 10264-3, 10265-3) 32K INCREMENT TO 98K FOR AA115-A OR AA117-A. CHASSIS 13 AND 15 WIRE LISTS CE MANUAL	60370400	J	22	24.20
CHASSIS 13 AND 15 DIAGRAMS CE MANUAL	60369800	E	22	06.10
CHASSIS 14 AND 16 WIRE LISTS CE MANUAL	60370500	G	22	24.75
CHASSIS 14 AND 16 DIAGRAMS CE MANUAL	60390600	F	22	05.95
AT239-A (CYBER 74-XX) 32K TO 49K INCREMENT CE INFO (INCLUDED IN AA117-A, CHASSIS 9, 10, 11 AND 12 MANUALS)				
AT247-A (7030) ECS INTERFACE LOGIC CE INFO (USE AA115-A, CHASSIS 8)				
AT248-A (10276-1) AUTO-RESTART OPTION CE INFO (USE AA116-A)				
AT249-A (7030-XX) ECS COUPLER ENABLE DIAGRAMS INFO (USE AA117-A)				
AT250-A () 4 PPU INCREMENT TO 14 PPU S FOR AA115-A CE INFO (USE AA115-A, CHASSIS 1)				
AT251-A (CYBER 72/73/74) EXTERNAL DATA CHANNEL CE MANUAL	60392700	F	22	25.40
AT259-A () REGISTER FILE PARITY - ABNORMAL INTERRUPT EXPANSION REF/CE MANUAL	60375600	G	22	07.75
AT260-A () PAGE FILE PARITY REFERENCE/CE MANUAL	60375700	D	22	03.95
AT265-A/B () ADDITIONAL PPU CHASSIS FOR 6000 COMPUTERS (INCREMENT TO 20 PPU S) CE INFO (USE AT145-A/B/C)				
AT267-A (CYBER 72/73) COMPARE/MOVE LOGIC CE INFO (USE AA115-A, CHASSIS 4)				
AT269-A (7611-11) SERVICE STATION CLOCK CE MANUAL	60405200	A	22	03.30
AT270-A (7611-11) SERVICE STATION ENABLE CE INFO (USE AT269-A)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
AT271-A (7700) LCM FLAG REGISTER INCREMENT CE INFO (USE AA121-A)				
AT281-A (SP.OP. 65102) AC105/3304 BUS PARITY CE MANUAL	60425000	A	22	19.74
AT282-A (SP.OP. 65102) BDP BUS PARITY CE INFO (USE AT281-A)				
AT283-A (SP.OP. 65102) PAGE FILE BUS PARITY CE INFO (USE AT281-A)				
AT284-A (SP.OP. 65102) 3316 MULTIPLEXER BUS PARITY CE INFO (USE AT281-A)				
AT285-A (SP.OP. 65102) BB316/BB105-A/3302 BUS PARITY CE INFO (USE AT281-A)				
AT286-A (SP.OP. 65102) BB351/BB105-B BUS PARITY CE INFO (USE AT281-A)				
AT289-A (ST.OP.10309-1/2) GO MODE FROM INTERRUPT FOR THE AC104-A AND AC106-A/B C.E. MANUAL	60417600	A	34	05.10
AT292-A (ST.OP. 10308-2) GO MODE FROM INTERRUPT CE MANUAL	60423500	A	22	03.10
AT293-A (ST.OP. 10308-2) SDL EXECUTION IN PROGRAM STATE CE INFO (USE AT292-A)				
AT294-A (ST.OP.10309-1) EXECUTE SDL IN PROGRAM STATE FOR AC104-A CE INFO (USE AT289-A)				
AT295-A (ST.OP.10309-2) EXECUTE SDL IN PROGRAM STATE FOR AC106-A/B CE INFO (USE AT289-A)				
AT303-A () ADJUNCT PPU REFRIGERATION INFO (USE GH223-A)				
AT310-A TTL AQ-DSA CE MANUAL	89758600	01	22	03.40
AT311-A (76-XXX, ST.OP.10348-1) I/O MUX CHANNEL CE INFO (USE AA106-A)				
AT312-A (ST.OP.10348-2) I/O MUX CHANNEL				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE INFO (USE AA106-A)				
AU102-A (7700) MEMORY SHARING UNIT CE INFO (USE AA121-A AND AD102-A)				
BB104-A () STORAGE MODULE CE MANUAL	60323500	C	22	02.00
BB105-A (3172) MAGNETIC CORE STORAGE CE INFO (USE 3304-B, CATALOG SECTION 2) CARD PLACEMENT, EQ SUM, WIRE LISTS CE MANUAL	60323100	A	22	12.00
BB106-A () STORAGE MODULE CE MANUAL OPERATION/PROGRAMMING INFO (USE 3100 COMPUTER SYSTEM REF MANUAL OR 3150 COMPUTER SYSTEM REF MANUAL OR 3200 COMPUTER SYSTEM REF MANUAL INSTALLATION/CHECKOUT INFO (USE 3000 SERIES SITE PREPARATION MANUAL)	60409400	A	22	22.00
BB107-A () STORAGE MODULE CE AND REF INFO (SEE BB106-A)				
BB201-A (7700) SCM INCREMENT CE INFO (USE AA121-A AND AD102-A)				
BB310-A (1708) STORAGE INCREMENT				
BB311-A (1708) STORAGE INCREMENT				
BB312-A (1708) STORAGE INCREMENT				
BB313-A (3502) STORAGE MODULE CE MANUAL	60210200	AC	22	22.80
BB314-A (3502) STORAGE MODULE CE INFO (USE BB313-A)				
BB316-A STORAGE MODULE (USE 3302-A, CATALOG SEC. 2)				
BB319-A (6634-C) EXTENDED CORE STORAGE ASSEMBLY DIAGRAMS, CIRC. DESC., WIRE LIST CE MANUAL	60209600	W	22	08.40
STACK ASSEMBLY-DIAGRAMS, CIRC DESC, MAINT CE MANUALS (DESCRIBES STACK ONLY)	60217600	D	22	16.05
MAINTENANCE, MAINTENANCE AIDS CE MANUAL	60289200	K	22	10.00
BB319-B (6634-D) EXTENDED CORE STORAGE ASSEMBLY (USE MANUALS UNDER BB319-A)				
BB323-A (6635-C) EXTENDED CORE STORAGE ASSEMBLY DIAGRAMS, CIRC. DESC., PARTS LIST, CARD	60212200	W	22	05.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
PLACEMENT OF MANUAL STACK ASSEMBLY OF MANUAL (USE MANUAL LISTED UNDER BB319-A) CHASSIS TABS, CABLE TABS OF MANUAL MAINTENANCE, MAINTENANCE AIDS (USE BB319-A)	60230300	S	22	46.15
BB323-B (6635-D) EXTEND CORE STORAGE ASSEMBLY (USE BB323-A MANUALS)				
BB324-B (6636-D) EXTENDED CORE STORAGE ASSEMBLY (USE BB323-A MANUALS)				
BB325-A (6633-C) EXTENDED CORE STORAGE ASSEMBLY (USE BB319-A MANUALS)				
BB325-B (6633-D) EXTENDED CORE STORAGE ASSEMBLY (USE BB319-A MANUALS)				
BB328-A (1772-1, 90104, 90108-2) MEM INCREMENT OF INFO (USE AB103-A)				
BB329-A (1772-2, 90104, 90108-1) MEM INCREMENT OF INFO (USE AB103-A)				
BB343-B (ST.OP. 10178) MEMORY INCREMENT 98K TO 131K FOR 6414/6514-D REFERENCE AT140-G/H 6414-D PRIOR TO OPT (USE 6413-D) NOT FOR USE WITH AT139 OR AT137 (USE BB343-C INSTEAD				
BB343-C (ST. OP. 10178) MEMORY INCREMENT 98K TO 131K FOR AT140-A/B 6414-E (INCLUDED IN AA105-A MANUALS) ALSO APPLIES TO 6414/6514-D WITH SPIGOT				
BB346-A (SP.OP. 60058-A) MEMORY INCREMENT 32K TO 65K FOR 6605/6615-A (USE 6604/14-A)				
BB349-A (ST.OP. 10177) MEMORY INCREMENT 49K TO 65K FOR 6415-C (USE 6414-A/B/C)				
BB349-B (ST.OP. 10177) MEMORY INCREMENT 49K TO 65K FOR 6415-D (USE 6414-D)				
BB349-C (ST.OP. 10177) MEMORY INCREMENT 49K TO 65K FOR 6415-E (AA108-A) (USE AA105-A)				
BB351-A () STORAGE MODULE				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE MANUAL	60316100	C	22	15.10
BB353-A () STORAGE MODULE CE INFO (USE BB104-A)				
BB354-A () STORAGE INCREMENT CE INFO (USE GH408-A/B)				
BB355-A () STORAGE INCREMENT CE INFO (USE GH408-A/B)				
BB360-A () LARGE CORE MEMORY INCREMENT CE INFO (USE AC113-A)				
BB360-B (76-XXX) LARGE CORE MEMORY INCREMENT CE INFO (USE AA105-A OR AC113-A)				
BB361-A () SMALL CORE MEMORY INCREMENT CE INFO (USE AC113-A)				
BB365-A (ST.OP. 10179-1) 16K INCREMENT TO 49K REF/CE MANUAL	60316000	B	22	06.00
BB365-B (ST. OPT. 10179-1) 16K MEMORY INCR. FOR 6615-D CENTRAL COMPUTER REFERENCE/CE MANUAL	60315900	B	22	05.65
BB366-A () 32K INCREMENT TO 65K FOR AA103-A USE AA103-A MANUALS				
BB367-A () 16K INCREMENT TO 65K FOR AA103-A USE AA103-A MANUALS				
BB370-A () MEM MODIFICATION FOR 6600 REFERENCE/CE MANUAL	60319800	B	22	06.80
BB372-A (731-XX, 732-XX, 730-100) 750 NANO- SECOND CORE STORAGE MODULE CE MANUAL	60346500	C	22	02.85
BB377-A (733-140, 10274-1) 4K INCREMENT CE INFO (USE FV156-A)				
BB381-A (1772-2, 90108-3) MEMORY INCREMENT CE INFO (USE AB103-A)				
BB382-A (1772-2, 90108-3) MEMORY MODULE CE INFO (USE AB103-A)				
BB385-A/B (1772-2) MEMORY MODULE CE INFO (USE AB103-A)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
BB386-A (1772-1) STORAGE INCREMENT CE INFO (USE AB103-A)				
BB387-A () MEMORY MODULE CE INFO (USE AB103-A)				
BB393-A (7030-4/8/16) EXTENDED CORE STORAGE CE INFO (USE BB323-A)				
BB394-A (7030-2) EXTENDED CORE STORAGE CE INFO (USE BB319-A)				
BB395-A (7030-1) EXTENDED CORE STORAGE CE INFO (USE BB319-A)				
BB397-A (CYBER 74-XX) 65K TO 32K DECREMENT CE INFO (INCLUDED IN AA117-A, CHASSIS 9, 10, 11 AND 12 MANUALS)				
BB399-A (10273-2) MEMORY INCREMENT MODULE CE INFO (USE AA116-A)				
BB400-A (10273-3) MEMORY INCREMENT MODULE CE INFO (USE AA116-A)				
BB402-A () CORE STORAGE MODULE CE MANUAL	60389600	A	22	02.85
BB405-A (7700) LCM INCREMENT CE INFO (USE AA121-A)				
BE1A2 (9545-14) MAGNETIC TAPE TRANSPORT PARTS LIST (A01-A02 AND ABOVE) CE MANUAL REF/CE MANUAL (EXCEPT PARTS LIST)	49487900 49487800	B A	22	04.00 09.40
BE1A3 (9525-14) MAGNETIC TAPE TRANSPORT PARTS LIST (A01 AND ABOVE) CE MANUAL REF/CE MANUAL (EXCEPT PARTS LIST)	49488200 49486400	C A	22	04.00 09.50
BE101 (604-2) MAGNETIC TAPE TRANSPORT GENERAL DESCRIPTION, DIAGRAMS CE MANUAL PARTS LIST (A04-07 B04 AND ABOVE, C02 AND ABOVE) CE MANUAL	49755600 41240000	A E	22	08.55 04.20
BE102 (608) MAGNETIC TAPE TRANSPORT THEORY OF OPERATION, DIAGRAMS, WIRE LIST CE MANUAL DESCRIPTION, OPERATION, INSTALLATION, CHECKOUT, MAINTENANCE CE MANUAL PARTS LIST CE MANUAL	40860800 40860700 40864100	J E G	22	01.50 04.75 02.95
BE103 (657-1) MAGNETIC TAPE TRANSPORT PARTS LIST CE MANUAL	49815000	G	22	05.70

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
GEN DESC., THEO OF OPER, MAINT. CE MANUAL	49750300	F	22	05.45
DIAGRAMS CE MANUAL	49750400	D	34	04.05
BE104 (657-2) MAGNETIC TAPE TRANSPORT CE INFO (USE BE103)				
BE2A1 (9568) MAGNETIC TAPE TRANSPORT PARTS LIST (A01 AND ABOVE) CE MANUAL	41243800	B	22	01.65
REF/CE MANUAL (EXCEPT PARTS LIST)	40869700	D	22	04.40
BE2A2 (9585-14) MAGNETIC TAPE TRANSPORT PARTS LIST (A01 AND ABOVE) CE MANUAL	49487300	B	22	04.00
REF/CE MANUAL (EXCEPT PARTS LIST)	49487200	A	22	09.60
BE2A3-A (9565-14) MAGNETIC TAPE TRANSPORT PARTS LIST (A01 AND ABOVE) CE MANUAL	49487500	C	22	04.00
REF/CE MANUAL (EXCEPT PARTS LIST)	49487400	A	22	09.60
BE222 (607-2) MAGNETIC TAPE TRANSPORT REFERENCE/CE MANUAL (INCLUDES BE423) (INCLUDES PMI/PMO) PARTS LIST CE INFO. (USE BE101)	40869901	C	22	04.60
BE223 (657-3) MAGNETIC TAPE TRANSPORT CE INFO (USE BE103) PARTS LIST CE MANUAL	49815100	F	22	02.10
BE224 (657-4) MAGNETIC TAPE TRANSPORT CE INFO (USE BE103)				
BE4A1 (9560) MAGNETIC TAPE TRANSPORT REF/CE MANUAL (EXCEPT PARTS LIST)	40868700	C	22	05.70
PARTS LIST CE MANUAL	41242100	C	22	01.70
BE4A1/BT103 (9560 WITH SPO 68024) MAGNETIC TAPE TRANSPORT CE MANUAL	49859400	A	22	10.35
BE4A2 (9565) GEN DESC. THEO OF OPER, MAINT. CE MANUAL	49755700	B	22	09.75
PARTS LIST CE INFO. (USE BE4A1)				
BE4A9 (9585) MAGNETIC TAPE TRANSPORT GEN DESC, THEO OF OPER, MAINT. CE MANUAL	49755700	B	22	09.75
PARTS LIST (A01, B01 AND ABOVE) CE MANUAL	40801800	D	22	03.90
BE4B1 (9545) MAGNETIC TAPE TRANSPORT GEN DESC, THEO OF OPER, MAINT. CE MANUAL	49755700	B	22	09.75
PARTS LIST (A02, B02 AND ABOVE) CE MANUAL	40821900	E	22	04.00
BE4B2 (9525) MAGNETIC TAPE TRANSPORT GEN DESC, THEO OF OPER, MAINT. CE MANUAL	49755700	B	22	09.75
DIAGRAMS CE MANUAL	49755800	C	22	09.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
BE4B3 (9540) MAGNETIC TAPE TRANSPORT PARTS LIST (A04, B04 AND ABOVE) CE INFO. (USE BE4B1) REF/CE MANUAL (EXCEPT PARTS LIST)	40817400	B	22	05.60
BE4B3/BT115 (9540 WITH SPO 68025) MAGNETIC TAPE TRANSPORT REF/CE MANUAL	49859100	A	22	09.80
BE4B4 (9580) MAGNETIC TAPE TRANSPORT REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST CE INFO. (USE BE4A9)	40824200	A	22	12.20
BE4B4 WITH BT116 (9580 WITH SPO.68023)	49859200	B	22	10.20
BE4B5 (9520) MAGNETIC TAPE TRANSPORT PARTS LIST (A01, B01 AND ABOVE) CE INFO. (USE BE4B2) DIAGRAMS, WIRE LIST CE MANUAL REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST	49859300 40808200 40819900	A B C	22 22 22	10.05 05.60 04.10
BE4B8 (9585-11) MAGNETIC TAPE TRANSPORT PARTS LIST (A01 AND ABOVE) CE MANUAL REF/CE MANUAL	49800300 49484600	C B	22 22	02.55 08.50
BE4B9 (9525-13) MAGNETIC TAPE TRANSPORT REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST (A01 AND ABOVE) CE MANUAL	49488300 49488400	A C	22 22	08.90 04.00
BE4C1 (9545-13) MAGNETIC TAPE TRANSPORT REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST CE MANUAL	49488000 49488100	A B	22 22	09.25 03.50
BE4C2 (9565-13) MAGNETIC TAPE TRANSPORT REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST (A01 AND ABOVE) CE MANUAL	49487600 49487700	A C	22 22	09.25 03.40
BE4C3 (9585-13) MAGNETIC TAPE TRANSPORT REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST (A01 AND ABOVE) CE MANUAL	49487000 49487100	A B	22 22	09.25 04.00
BE4C4 (9519) MAGNETIC TAPE TRANSPORT PARTS LIST CE MANUAL SPECIAL CARD MANUAL	49488600 49932700	E A	22 22	05.80 01.50
BE4D1 (609) MAGNETIC TAPE TRANSPORT THEORY OF OPERATION, DIAGRAMS, WIRE LIST CE MANUAL DESCRIPTION, OPERATION, INSTALLATION CHECKOUT, MAINTENANCE CE MANUAL PARTS LIST CE INFO. (USE BE102)	40861000 40860900	H E	22 22	02.40 05.55

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
BE406 (659-1) MAGNETIC TAPE TRANSPORT GEN DESC., THEO OF OPER, MAINT CE MANUAL DIAGRAMS CE MANUAL PARTS LIST CE MANUAL	49750600 49750700 49815200	G G H	22 34 22	09.10 04.90 02.20
BE407 (659-2) MAGNETIC TAPE TRANSPORT CE INFO (USE BE406)				
BE408 (659-3) MAGNETIC TAPE TRANSPORT CE INFO (USE BE406) PARTS LIST CE MANUAL	70603900	J	22	02.30
BE409 (659-4) MAGNETIC TAPE TRANSPORT CE INFO (USE BE406) PARTS LIST (A01, B01 AND ABOVE) CE INFO. (USE BE408)				
BE423 () NINE TRACK OPTION (SEE BE222)				
BG105-A/B DRUM STORAGE UNITS,DIAGS, CIRC DESC, MAINT,P/L,C/P, EQ SUM, W/L	60210400	C	22	13.55
BG108-C/D/863-C DRUM STORAGE UNIT CE MAN.	70606700	A	22	09.50
BG111-A/C MICRO DRUM CE MANUAL	40808600	B	22	01.30
BG111D-G MICRO DRUM GEN DESC., OPER., PARTS DATA, MAINT., THEO. OF OPER., CE MANUAL	70622100	B	22	03.25
BG113 DRUM STORAGE UNIT GEN DESC,MAINT AIDS, EQ SUM, W/L DIAGS CE MANUAL	70607500	B	22	16.25
BG504 A-H DRUM MEMORY SUBSYSTEM HARDWARE REF/CE MANUAL	39731700	C	22	03.00
BH1A9/BH2A1 DISK FILE THEORY OF DIAGRAMS, WIRE LIST CE MANUAL	70607100	A	22	07.80
BH2A1 DISK FILE SYSTEM PARTS DATA	70606900	B	22	02.30
BH405 DISK FILE CLOCK WRITER/EXERCISER CE MANUAL TROUBLESHOOTING GUIDE	70615800 59349900	B A	22 22	05.90 15.90
BH405-C DISK FILE GEN DESC.,OPER.,INSTAL., CHECKOUT, MAINTENANCE PRLIM.ED. CE MANUAL THEO OF OPER., DIAGS., WIRE LIST CE MANUAL PARTS DATA CE MANUAL	41242300 41242200 41242400	B F C	22 22 22	08.45 06.35 05.10
BH408/410 DISK FILE GENERAL DESCRIPTION	70601300	B	22	06.20

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
OPER., INSTALL. AND CHECKOUT, MAINT. CE MAN. PARTS LIST MOD A07, A08 AND ABOVE CE MANUAL	70601500	D	22	02.20
THEORY, DIAGRAMS AND WIRE LIST MANUAL	70601400	G	22	06.20
TROUBLE SHOOTING GUIDE CE MANUAL	86811400	A	22	08.80
BJ1A7 DISK STORAGE DRIVE--ALSO LISTED AS 9451 DIAGRAMS AND WIRE LIST CE MANUAL	41241700	B	22	06.40
BJ1A9 PARTS LIST MOD A13, B13 ABOVE CE MANUAL	70605300	C	22	02.15
BJ103 DISK STORAGE DRIVE PARTS LIST	70605000	C	22	02.85
BJ104-A/B DISK STORAGE DRIVE DIAGS AND WIRE LIST CE MANUAL	70604400	E	22	02.90
PARTS LIST MODS A13, B13 AND ABOVE MAINTENANCE CE MANUAL	70604500	C	22	02.85
	70604300	C	22	06.70
BJ2A2 DISK STORAGE DRIVE DIAGS. AND W/L MAINTENANCE MANUAL	41249700	D	22	04.55
	41249600	B	22	05.75
PARTS DATA CE MANUAL	41249800	B	22	01.80
BJ3A1 DISK STORAGE DRIVE A12 ABOVE, B12 ABOVE PARTS LIST	41249500	C	22	03.70
DIAGS, CIRC DESC., C/P, W/L, CE MANUAL	41249400	D	22	02.15
BJ3A1-A/B DISK STORAGE DRIVE MAINT. CE MANUAL	41249300	C	22	12.70
BJ3A3 DISK STORAGE DRIVE-DUAL DISK DRIVE PARTS	70606500	B	22	02.00
BJ5XX STORAGE MODULE DRIVE PARTS DATA CE MANUAL	70631100	L	3	02.80
REFERENCE MANUAL	70631000	D	3	09.35
MAINTENANCE MANUAL	70630900	K	3	09.60
BJ6XX STORAGE MODULE DRIVE MAINTENANCE MANUAL	83310800	C	3	05.70
REFERENCE MANUAL	83310900	B	3	05.40
BJ7XX STORAGE MODULE DRIVE MAINTENANCE MANUAL	83308400	A	3	10.50
REFERENCE MANUAL	83308500	A	3	12.40
PARTS DATA MANUAL	83308600	A	3	04.10
BK3A1 DUAL DISK DRIVE PARTS LIST CE MANUAL	70604700	D	22	03.45
9M1A1/9M1A3 MULTIPLE DISK DRIVE DIAGS, W/L CE	41249200	A	22	07.20
9M1A1,2,3,4 PARTS DATA CE MANUAL	70605500	D	22	06.10
9M1A2-A/B/9M1A4-A/B MULTIPLE DISK DRIVE DIAGS, WIRE LIST CE MANUAL	70602300	A	22	07.10
MAINTENANCE CE MANUAL	70602200	A	22	03.65

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
BM1A5/BM1A6 MULT. DISK DR MOD B01/ABOVE PARTS	70601900	K	22	05.95
BM1A5/BM1A7 MULTIPLE DISK DRIVE THEORY OF OPER DIAGRAMS, MAINTENANCE AIDS, WIRE LISTS	70602500	H	22	08.20
GENERAL DESCRIPTION, OPERATION, INSTALLATION AND CHECKOUT, MAINTENANCE CE MANUAL	70602400	G	22	08.00
BM1A6/BM1A8 MULTIPLE DISK DR. GEN. DESC., OPER. INST.CHKOUT,MAINT, CE MAN	41243900	E	22	03.80
BM1B1/3-A/B GENERAL DESCRIPTION MANUAL OP., DIAGRAMS, MAINT.	70603300	G	22	05.10
THEORY OF OPER. DIAGS, MAINT AIDS, WIRE LIST CE MANUAL	70603400	H	22	11.40
BM1B1,2,3,4 AND A02,B02 AND ABOVE, MULT DK DR	70603500	H	22	03.90
BM1B2-A/B, BM1B4-A/B MULT. DISK DR GEN DESC. OPER., INST., AND CHKOUT MAINT. MAN.	70603600	D	22	03.70
THEO OF OP,DIAG,MAINT AIDS,WIRE LIST CE MAN	70603700	D	22	20.15
BM1B5-B/BM1B6-B GEN DESC.,OPER.,INST. AND CHECKOUT, MAINT. CE MANUAL PARTS LIST	40869600	J	22	02.00
BM1B7 MULTIPLE DISK DRIVE PARTS LIST CE MANUAL	70603200	A	22	02.10
BM1B7-A MULTIPLE DISK DRIVE MAINTENANCE CE	70603000	A	22	03.60
BM1B8-B/BM1B9-B MULT. DISK DRIVE MAINT., GEN. DESC., CE MANUAL	70607300	E	22	01.00
DIAG, WIRE LIST, MAINT, CE MANUAL	70607200	G	22	05.90
BM1C1-B/BM1C2-B MULTIPLE DISK DRIVE GEN DESC. THEORY OF OPER, CE MANUAL	70619500	C	22	04.95
DIAGRAMS CE MANUAL	70619600	B	22	11.80
PARTS DATA CE MANUAL	70619700	C	22	04.30
BM101/103 MULTIPLE DISK DRIVE GEN DESC., OPER., INSTAL. CKOUT., MAINT. CE MAN	41248900	J	22	02.95
THEO OF OPER., DIAGRAMS, MAINT. AIDS CE LISTS CE MANUAL	41249000	J	22	07.70
PARTS DATA CE MANUAL	41243700	L	22	16.90
BM102/104-A/3 MULTIPLE DISK DRIVE GEN. DESC., OPER.,INSTL.CHKOUT,MAINT. CE MANUAL	41243500	H	22	04.35
THEO OF OPER., DIAGRAMS, MAINT AIDS, WIRE LISTS CE MAN.	41243600	J	22	22.10
PARTS DATA INFO (USE BM101/103)				
BM2A2/4 MULTIPLE DISK DRIVE MAINT, CE MANUAL	70606100	B	22	04.35
BM2A7/8 MULTIPLE DISK DRIVE MAINT. CE MANUAL	70609400	B	22	04.80
PARTS DATA CE MANUAL	70609700	F	22	04.30

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
THEORY OF OPER, DIAGRAMS, W/L, MAINT.AIDS CE	70609500	B	22	09.80
BM2B1 MULTIPLE DISK DRIVE GEN DESC, CHKOUT, MAINT. CE MANUAL	70611000	A	22	04.00
THEO OF OPER, MAINT AIDS, DIAGRAMS, W/L CE	70611100	B	22	14.90
BM2B2 MULTIPLE DISK DRIVE GEN DESC, CHECKOUT, MAINTENANCE CE MANUAL	70611300	D	22	09.25
PARTS DATA CE MANUAL	70611200	H	22	03.05
BM2B2-C/D MULTIPLE DISK DRIVE DIAGRAMS CE MANUAL	70615900	D	22	07.70
BM3A2 MULTIPLE DISK DRIVE PARTS DATA CE MAN	70609200	D	22	02.10
BP2A3 DISK STORAGE UNIT A01 ABOVE PARTS DATA CE MANUAL	70605800	B	22	02.20
BR1A1 DISK STORAGE UNIT GEN DESC, OPER, INSTAL/CHECKOUT, THEORY OF DIAGRAMS, MAINT AIDS, WIRE LISTS CE MANUAL	70609800	D	22	14.00
PARTS DATA CE MANUAL	70609900	C	22	02.50
DIAGRAMS, MAINT. AIDS, WIRE LIST CE MANUAL	70610100	J	22	01.50
(MODS A03, B03 AND C03 AND ABOVE)	70617000	L	22	12.35
BR1A1-E DISK STORAGE UNIT MAINTENANCE MANUAL	70619200	F	22	12.25
DIAGRAMS AND WIRE LIST	70619300	H	22	10.50
PARTS DATA CE MANUAL	70619400	H	22	02.10
BR1A3 DISK STORAGE UNIT PARTS DATA CE MANUAL	70613100	B	22	03.10
GEN DESC, OPER, INS0ALLATION/CHECKOUT, THEO OF OP, MAINT CE MANUAL	70612900	A	22	04.90
DIAGRAMS CE MANUAL	70613000	B	22	05.35
BR1A9 DISK STORAGE UNIT DIAGS, W/L, MAINT AIDS (MODS B03 AND ABOVE) CE MANUAL	70617100	H	22	04.50
BR1A9-B VOICE COIL DRIVE PARTS DATA(B01 AND ABOVE) CE MANUAL	70609300	J	22	03.80
BR1B3 DISK STORAGE UNIT DIAGRAMS AND WIRE LIST CE MANUAL	70620500	F	22	02.85
GEN DESC., THEORY OF OPER., INSTL/CHECKOUT, MAINTENANCE CE MANUAL	70620400	C	22	06.15
PARTS DATA CE MANUAL	70620600	G	22	02.25
BR2A1-D DISK STORAGE UNIT MAINTENANCE MANUAL	70616300	C	22	04.30
PARTS DATA CE MANUAL	70612600	C	22	01.65

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
BR2A1-D (SC19 AND ABOVE) DISK STORAGE UNIT PARTS DATA CE MANUAL	83311400	A	22	05.05
BR2A1-1 DISK STORAGE UNIT DIAGRAMS CE MANUAL	70616400	F	22	07.20
BR2A3 DISK STORAGE UNIT PARTS DATA CE MANUAL	70615100	A	22	04.15
BR2A6-B DISK STORAGE UNIT DIAGRAMS AND W/L PARTS DATA CE MANUAL	70622700	K	22	03.55
MAINTENANCE CE MANUAL	70622800	N	22	03.15
	70622600	H	22	05.30
BR2A7 DISK STORAGE UNIT DIAGRAMS AND WIRE LIST PARTS DATA CE MANUAL	70622200	L	22	03.45
	70622500	M	22	07.65
BR2A8 DISK STORAGE UNIT DIAGRAMS AND WIRE LISTS CE MANUAL	70622300	M	22	06.10
MAINTENANCE CE MANUAL	70622400	G	22	05.05
BR2B1 DISK STORAGE UNIT MAINTENANCE MANUAL	70612500	C	22	13.40
DIAGRAMS AND WIRE LISTS	70607900	D	22	07.60
BR2B2/3 DISK STORAGE UNIT GENERAL DESCRIPTION, MAINTENANCE CE MANUAL	70631300	D	22	08.45
DIAGRAMS, WIRE LISTS CE MANUAL	70631400	F	22	06.30
PARTS DATA CE MANUAL	70631500	G	22	04.35
BR3A1-G DISK STORAGE UNIT MAINTENANCE AIDS DIAGRAMS AND WIRE LIST CE MANUAL	70613300	F	22	06.50
MAINTENANCE CE MANUAL	70613200	F	22	10.30
PARTS DATA (SC 07 AND ABOVE)	70626500	C	22	04.50
BR3A4 DISK STORAGE UNIT GEN DESC., THEO OF OPER., MAINTENANCE CE MANUAL	70610300	D	22	12.75
DIAGRAMS CE MANUAL	70610500	F	22	06.25
BR3A5 DISK STORAGE UNIT PARTS DATA CE MANUAL DIAGRAMS AND WIRE LIST CE MANUAL	70623700	B	22	03.40
MAINTENANCE CE MANUAL	70623600	C	22	06.10
	70623500	A	22	07.60
BR3B4 DISK STORAGE UNIT MAINTENANCE MANUAL PARTS DATA MANUAL	70628200	L	3	05.80
	70628400	G	3	02.35
BR3B5 DISK STORAGE UNIT PARTS DATA MANUAL	70630500	F	3	05.90
BR3B8 DISK STORAGE UNIT PARTS DATA CE MANUAL	83301200	K	3	03.85
REFERENCE MANUAL	83301100	C	3	04.90

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
MAINTENANCE CE MANUAL	83301000	K	3	07.90
BR306 DISK STORAGE UNIT REFERENCE MANUAL	83309400	B	3	07.05
MAINTENANCE CE MANUAL	83309300	C	3	08.70
PARTS DATA	83309500	C	3	04.85
BR301R DISK STORAGE UNIT				
MAINTENANCE MANUAL	83305700	E	3	10.20
REFERENCE MANUAL	83305800	C	3	05.75
PARTS DATA MANUAL	83305900	E	3	03.00
BR303-A/B DISK STORAGE UNIT				
MAINTENANCE MANUAL	83311600	A	22	16.90
REFERENCE MANUAL	83311700	A	3	10.00
BR304 DISK STORAGE UNIT				
MAINTENANCE MANUAL	83313100	A	3	20.30
REFERENCE MANUAL	83313200	A	3	17.55
PARTS LIST	83313300	A	3	04.65
BR302 DISK STORAGE UNIT				
DIAGRAMS AND WIRE LIST CE MANUAL	70618500	J	22	05.70
MAINTENANCE CE MANUAL	70618400	F	22	24.25
PARTS DATA CE MANUAL	70618600	E	22	02.95
PARTS DATA CE MANUAL (S/C 09 AND ABOVE)	70626300	D	22	03.40
BR303 DISK STORAGE UNIT				
INSTALLATION/CHECKOUT, PREVENTIVE/CORRECTIVE	70629600	H	22	07.10
MAINTENANCE, DIAGRAMS, W/L, CE MANUAL				
PARTS DATA CE MANUAL	70629700	J	22	03.30
GEN DESC., OPER., THEORY OF OPERATION CE MAN	70629500	C	22	03.45
BR304 DISK STORAGE UNIT				
PARTS DATA CE MANUAL	70628100	C	22	01.95
MAINTENANCE CE MANUAL	70627900	D	22	11.30
GENERAL DESCRIPTION, OPERATION, THEORY OF	70628000	C	22	06.90
OPERATION, KEY TO LOGIC, INTEGRATED CIRCUIT				
DISCRETE CIRCUITS CE MANUAL				
BR305 DISK STORAGE UNIT				
PARTS DATA CE MANUAL	83303300	C	22	04.50
REFERENCE MANUAL	83303200	A	22	06.90
PREVENTIVE/CORRECTIVE MAINTENANCE, DIAGRAMS,	83303100	B	22	20.05
WIRE LISTS CE MANUAL				
BR306/7 DISK STORAGE UNIT				
PARTS DATA CE MANUAL	83308900	C	22	04.60
PREVENTIVE/CORRECTIVE MATNT., DIAGS, W/L	83308700	C	22	18.55
REFERENCE MANUAL	83308800	B	22	14.50
BR306/7-D/E DISK STORAGE UNIT				
PREVENTIVE/CORRECTIVE MAINTENANCE, DIAGRAMS,	83314000	A	22	13.05
WIRE LISTS CE MANUAL				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
BR5A1 DISK STORAGE UNIT MAINTENANCE MANUAL	70617800	E	22	04.50
PARTS DATA CE MANUAL	70618000	P	22	02.50
DIAGRAMS AND WIRE LIST CE MANUAL	70617900	J	22	03.45
BR5A2 DISK STORAGE UNIT MAINTENANCE MANUAL	70624500	G	22	05.90
DIAGRAMS CE MANUAL	70624600	J	22	04.45
PARTS DATA MANUAL	70624700	J	22	02.85
BR5A3 DISK STORAGE UNIT GEN. DESC., OPER., INSTALLATION AND CHECKOUT THEORY OF OPERATION, MAINTENANCE CE MANUAL	70628500	B	22	06.25
DIAGRAMS AND WIRE LISTS CE MANUAL	70628600	D	22	05.40
BR5A4 DISK STORAGE UNIT MAINTENANCE MANUAL	70630000	B	3	18.75
PARTS DATA CE MANUAL	70630200	C	3	07.80
DIAGRAMS CE MANUAL	70630100	C	22	10.90
BR5A5 DISK STORAGE UNIT GEN. DESC., OPERATION, INSTALLATION/CHECKOUT THEORY OF OPERATION AND MAINT CE MANUAL	83302300	D	22	11.05
DIAGRAMS, MAINT. AIDS, WIRE LIST CE MANUAL	83302400	C	22	08.40
PARTS DATA CE MANUAL	83302500	E	22	05.35
BR5A6 DISK STORAGE UNIT MAINTENANCE MANUAL	83313400	B	3	10.50
REFERENCE MANUAL	83313500	B	3	12.20
PARTS DATA MANUAL	83313600	A	3	03.75
BR501 DISK STORAGE UNIT PREVENTIVE AND CORRECTIVE MAINTENANCE, DIAGRAMS, WIRE LISTS, CE MANUAL	70629300	M	22	09.75
GENERAL DESCRIPTION, OPERATION, THEORY OF OPERATION CE MANUAL	70629200	F	22	03.70
PARTS DATA CE MANUAL	70629400	K	22	04.60
BR502/4 DISK STORAGE UNIT REFERENCE MANUAL	83302700	D	22	06.25
PARTS DATA CE MANUAL	83302800	F	22	02.65
PREVENTIVE/CORRECTIVE MAINTENANCE, DIAGRAMS, WIRE LIST CE MANUAL	83302600	G	22	07.95
RS101-A (76-XXX) CENTRAL MEMORY INCREMENTS CE INFO (USE AA106-A)				
RS102-A (76-XXX) CENTRAL MEMORY INCREMENT CE INFO (USE AA106-A)				
BT116 (SPO 63023) DUAL MODE OPTION (SEE BF4B4)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
BT118 (SPO 68106) NINE TRACK OPTION (SEE BE101)				
BT128-A () STORAGE MODULE CE INFO (USE B8351-A)				
BT150-A/B (1714) MEMORY EXPANSION MODULE CE INFO (USE AA116-A)				
BU104 MAGNETIC TAPE CERTIFIER PARTS DATA CE MANUAL	70617400	A	22	04.80
CA101-A, CA102-A HDWR REF/CE MAN	82140400	A00	22	01.25
CC514-A/B (7601-1) STATION CONSOLE				
CC521-A () SECOND CONSOLE DISPLAY FOR 6000-D/E COMPUTER SYSTEMS (USE 6602/6612)				
CC533-A DATA ACQUISITION/CONTROLLER CONSOLE GEN DESC., DIAGS, W/L, MAINT CE MANUAL	39534900	A	22	02.30
CE1A5 (9200) CARD READER REF/CE MANUAL (EXCEPT PARTS LIST)	49626100	D	22	10.70
CE120 (1729-2) CARD READER PARTS LIST (A01, B01 AND ABOVE) CE MANUAL REF/CE MANUAL (EXCEPT PARTS LIST)	40804800 40802000	A C	22	01.85 05.30
CE123-A/B PARTS LIST CE MANUAL DIAGRAMS, WIRE LIST, MAINTENANCE CE MANUAL	49755100 49755200	02 8	22	01.45 14.95
CE124 (410) PL10 CARD READER GEN DESC., DIAGS, THEORY OF OPERATION REF/CE MANUAL	49754900	B	22	06.70
CE149 (407) CARD READER REF/CE MANUAL (EXCEPT PARTS LIST)	49973600	B	22	11.00
CE152 (224) CARD READER REF/CE INFO (USE CE1A5) PARTS DATA CE MANUAL	60352000	D	22	01.05
CE156-A/B () CARD READER REFERENCE/CE MANUAL	60366600	A	22	16.65
CE304 (224-2) CARD READER REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST CE MANUAL	41243200 41241500	D H	22	03.55 02.50
CE305-A/B (1777-1/2, 90121-1, 90122-1) PAPER TAPE READER CE MANUAL	60293400	N	22	03.40

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
** REFER ALSO TO CATALOG SEC. 2 FOR 370 PAPER TAPE READER MANUALS				
CE306 (224-2A) CARD READER REF/CE MANUAL (EXCEPT PARTS LIST)	49593000	C	22	06.40
PARTS LIST (A01/B01 AND ABOVE) CE MANUAL	49593100	C	22	02.95
CE601-A (SP. OPT. 60031) 3447 CARD READER MODIF REFERENCE/CE MANUAL (45 COLUMN CARDS)	60250900	A	22	03.15
CE602-A (SP. OPT. 60031) 3649 CARD READER MODIF REF/CE INFO (USE CE601-A) (45 COLUMN CARDS) CE601-A				
CF104-A (1777-1/2, 90123-1, 90124-1) PAPER TAPE PUNCH - STEEL CE INFO (USE CE305-A/B) ** REFER ALSO TO VENDOR MANUALS, CATALOG SEC. 4 FOR NCR EM-B3 MANUALS				
CF105 (226-1) CARD PUNCH REF/CE MANUAL (EXCEPT PARTS LIST)	49591900	D	22	10.80
PARTS LIST CE MANUAL	49592900	C	22	06.65
CF106-A (90123-2, 90124-2) PAPER TAPE PUNCH - TUNGSTEN CARBIDE CE INFO (USE CE305-A/B) ** REFER ALSO TO VENDOR MANUALS, CATALOG SEC. 4 FOR NCR EM-B3 MANUALS				
CF109-A/B () CARD PUNCH CE MANUAL	60366700	01	22	11.70
CF5A5-A/B/C (90125-1) PAPER TAPE STATION - COMMON CONTROL				
CF504 (430) CARD READER/PUNCH REF/CE MANUAL (EXCEPT PARTS LIST) (INCLUDES PMI/PMP) PARTS LIST CE MANUAL	40864000	G	22	07.35
	40864800	E	22	05.95
CF507-A/B (9230) CARD READER/PUNCH REF/CE MANUAL (EXCEPT PARTS LIST) VOLS I-II PARTS LIST CE MANUAL	60286200	F	22	12.05
	49597000	E	22	10.95
CF508-A/B/C (1777-1/2) COMMON CONTROL CE INFO (USE CE305-A/B)				
CF511-A/B CARD READER/PUNCH CE MANUAL	60318700	A	22	16.85
CF8A1-A (90126-1) ENCLOSURE KIT				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CF801-A () PAPER TAPE PUNCH - TUNGSTEN CARBIDE OPTION CE INFO (USE CE305-A/B)				
CH102-A/B CARD PUNCH PART IDENTIFICATION MANUAL	49762400	A	22	12.35
CJ1A5 OCR DOCUMENT READER DIAGRAMS VOL 2 HARDWARE REF/CE MANUAL	87951000		22	04.80
CJ103-A/CW146-A OCR DOCUMENT READER WIRE LIST CE MANUAL (CJ103-A ONLY)	70609600	A	22	21.80
GEN.DESC., OPER., MAINT., MAINT. AIDS	40827600	A	22	06.55
THEORY OF OPERATION DIAGRAMS CE MANUAL	41241900	B	3	14.70
PARTS DATA CE MANUAL	40963200	B	22	04.15
CJ112 PAGE READER G-H (CS/N151-200) PARTS LIST CE MANUAL	41241400	B	3	10.35
DIAGRAMS OF MANUAL	70601700	E	22	17.85
PAGE READER REFERENCE CE MANUAL	40819300	A	22	10.35
WIRE LISTS (LOGIC W/L) VOL.4 CE MANUAL	70602100	C	22	20.90
CJ115, CJ1A4 OCR DOCUMENT READER GEN DESC., OPER., THEO OF OPER., MAINTENANCE CE MANUAL	48883700	A	3	15.90
CJ119 PAGE READER DIAGRAMS VOL 2 HARD.REF/CE	48997900	B	22	07.15
CJ122 MAINTENANCE CE MANUAL	48430080	C	3	21.30
DIAGRAMS VOLUME 2, PART 3, CE MANUAL	48430045	B	22	18.30
PARTS DATA VOLUME 3 CE MANUAL	48430090	B	3	06.60
PARTS DATA S/N 103-129 VOL 38 REF/CE MANUAL	48430087	D	3	08.55
PAGE READER VOL 2 CE MANUAL	48948100	B	3	19.95
959 PAGE AND DOCUMENT READER SYST. OP. GUIDE	91669100	A	22	02.75
CJ122 PAGE AND DOCUMENT READER (S/N 151-175) DIAGRAMS, RECOGNITION RACK, HARDWARE REF/ CE MANUAL (VOL II, PART II)	48948200	B	3	05.20
CJ127 OCR DOCUMENT READER DIAGS. HR/CE MAN V2	87971600	01	22	02.75
PARTS DATA HARDWARE/CE MANUAL VOL 3	87971700	01	22	02.65
HARDWARE REFERENCE/C.E.MANUAL	87906700	A	22	01.90
SYSTEMS OPERATORS GUIDE (SEE 929 DOC. READER				
CJ508-A ANST OCR-A AND E13-B CHARACTER SET OPT RECOGNITION LOGIC, DIAGRAMS, ASSERT-NEGATE DIAGRAMS AND PARTS DATA CE MANUAL	87829800	A	3	05.50
CJ520 OCR DOCUMENT READER LOGIC RACK HARDWARE MAINTENANCE MANUAL VOL I	87911800	A	22	13.30
CK501-A/B (1711-3, 90111-1) TELETYPEWRITER				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE INFO (USE AB103-A) ** REFER ALSO TO VENDOR MANUALS, CATALOG SEC. 4 FOR TELETYPE MANUALS (35KSR)				
CK502-A/B (1713-3, 90113-1) TELETYPEWRITER CE INFO (USE AB103-A) ** REFER ALSO TO VENDOR MANUALS, CATALOG SEC. 4 FOR TELETYPE MANUALS (35ASR)				
CL106A/B ELECTRONICS EQUIP., CL107A/B PRINT HEAD EQUIPMENT	44976700	B	22	02.00
CL308A/B LINE PRINTER EQUIP PARTS DATA CE MAN. PRINTER EQUIPMENT CE MANUAL	44895600 47967000	A F	22 22	02.45 08.25
CL309 A/B LINE PRINTER EQUIP PARTS DATA PRINTER EQUIPMENT CE MAN. (USE CL308-A/B)	44895700	A	22	02.70
CL320 MEDIUM SPEED BATCH TERMINAL LINE PRINTER EQUIPMENT OPERATION REFERENCE MANUAL DIAGRAMS AND WIRE LIST FIELD SERVICE MANUAL PARTS IDENTIFICATION MANUAL	50583100 50583200 50584300	A B B	22 22 22	01.55 04.35 03.55
CL484-A/B/C/D USE 9322 LINE PRINTER				
CL401-A/B, CL402-A/B (222) LINE PRINTER CONTROLLER REF/CE MANUAL PARTS DATA CE MANUAL PRINTER EQUIPMENT CE MAN. (USE CL308-A/B)	47966700 44895800	E A	22 22	04.95 02.00
CL403A/B AND CL4044/B LINE PRINTER CONT EQ MAN PRINTER EQUIPMENT CE MAN. (USE CL308-A/B)	44978800	A	22	03.10
CL408-A/B USE 9322 LINE PRINTER				
CL503 LINE PRINTER EQUIPMENT HSRT PARTS IDENTIFICATION MANUAL GENERAL DESCRIPTION, INSTALLATION AND CHECKOUT, MAINT./MAINT AIDS REF MANUAL DIAGRAMS AND WIRE LIST VOL II CE MANUAL	50583400 50581800 50583300	01 01 01	22 22 22	05.40 05.10 04.35
CL6A1 (9360) LINE PRINTER PARTS DATA CE INFO - SERIES A/C23-A/C28	50578500	A	22	05.00
CL601 (512) LINE PRINTER EQUIPMENT REF/CE MANUAL DIAGRAMS AND WIRE LIST - SERIES A23-A28, B23-B28, C23-C28, D23-D28	44980100 50578100	D A	22	01.70 03.45
CL601, CL6A1A LINE PRINTER EQUIP DIAGRAMS AND WIRE LIST DIAGRAMS, WIRE LIST MOD A01-A07 CE MANUAL	44855700 44855500	C D	22 22	02.50 05.80

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
PARTS DATA CE MANUAL - SERIES A08-A22	44855600	C	22	04.35
PARTS DATA CE MANUAL - SERIES A/D23-A/D28	50577700	A	22	10.10
CL835 LINE PRINTER EQUIP. PARTS DATA CE MAN. REF/CE MANUAL	44980900 44980700	C C	22 22	03.40 03.00
CL835 LINE PRINTER EQUIPMENT CE MANUAL	44980800	C	22	02.25
CL896 LOW SPEED BATCH TERMINAL LINE PRINTER EQUIPMENT REFERENCE MANUAL	50582300	B	22	01.85
DIAGRAMS, WIRE LIST FIELD SERVICE MANUAL	50582400	B	22	03.15
PARTS IDENTIFICATION MANUAL	50583900	B	22	02.70
CR105-A (3504-1) DESK CONSOLE GENERAL DESCRIPTION, DIAGRAMS (USE AC104-A) MAINT. AIDS; 50-PAK STRIP TABS/MAPS (USE AC104-A) PARTS DATA (USE AC104-A)				
CR106-A (3514-1/2/3/4) DESK CONSOLE GENERAL DESCRIPTION, DIAGRAMS (USE AC106-A) PARTS DATA (USE AC104-A)				
CV403-A DIGISCRIBE OPTION (10892) REPAIR CENTER CE MANUAL	62996000	A-0	22	04.10
ON SITE MAINTENANCE MANUAL	62995900	A-0	22	03.20
CW120-A/121-A LINE PRINTER ADAPTER KIT REF/CE	82140800	A01	34	03.00
CW123-A (1777-2, 90127-1) PUNCH VALIDATION FEATURE CE INFO (USE CE305-A/B)				
CW126-E/F HANDPRINT UNIT HARDWARE REF/CE MANUAL	48991800	A	3	34.80
DIAGRAMS VOL 2 HARDWARE REFERENCE MANUAL	48143981	B	3	30.15
DIAGRAMS VOL 2B HARDWARE REFERENCE MANUAL	48911900	A	3	13.80
CW140-A ISO-OCR-B NUMERICS FONT OPTION GEN.	48996300	A	3	02.95
CW195 OCR-B PLUGGABLE FONT OPTION GENERAL DESCRIPTION, INSTALLATION AND CKOUT DIAGRAMS HARDWARE REF/CE MANUAL	91662900	A	22	06.15
CW207 HANDPRINT UNIT MODEL A01 HARDWARE MAINTENANCE MANUAL VOLUME 1	91558900	A	22	44.40
DA101-A (1544-2) DIGITAL INPUT UNIT REF/CE MANUAL	39909502	B	22	03.35
DA101-B (1544-1) DIGITAL INPUT UNIT REF/CE INFO (USE DA101-A)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
DA401-A (1544-4) DIGITAL INPUT UNIT REF/CE INFO (USE DA101-A)				
DA401-B (1544-3) DIGITAL INPUT UNIT REF/CE INFO (USE DA101-A)				
DA502-E () DIGITAL OUTPUT UNIT REF/CE MANUAL DESC., DTAGS, W/L, PARTS DATA CE MANUAL	39909503	B	22	03.00
DC110-A (6641-A) ECS/MASS STORAGE ADAPTER CE MANUAL	60222100	K	22	06.00
DC111-A (3507-1) COMMUNICATION CHANNEL GENERAL DESCRIPTION, DIAGRAMS ** USE AC104-A IF 3504 COMPUTER SYSTEM ** USE AC106-A IF 3514 COMPUTER SYSTEM PARTS DATA (USE AC104-A) MAINT. AIDS 50-PAK STRIP TABS/MAPS (USE AC104-A)				
DC118-A (1775-1, 90105-1) A/Q INTERRUPT CHAN. CE INFO (USE AB103-A)				
DC119-A (1779-1, 90109-1) CHARACTER HANDLING CE INFO (USE AB103-A)				
DC120-A (1773-1, 90106-1) DIRECT STORAGE ACCESS CHANNEL CE INFO (USE AB103-A)				
DC135-A (6642-1, 7030-XX) DISTRIBUTIVE DATA PATH CE MANUAL	60369400	D	22	11.95
DC136-A (1773-1) DIRECT STORAGE ACCESS CHANNEL CE INFO (USE AB103-A)				
DC137-A (1775-1) A/Q INTERRUPT DATA CHANNEL CE INFO (USE AB103-A)				
DC145-A/B (6642-2) DISTRIBUTIVE DATA PATH HARDWARE MAINT. MANUAL	60425800	A	22	62.75
DC211-A (6684-A) DATA CHANNEL CONVERTER CE MANUAL	60125000	AZ	22	04.70
DC212-A (6684-2) CODE CONVERSION FOR 6684-1 CE INFO (USE DC211-A) REF INFO (USE 6681-R/C/D)				
DC215-A/B DATA TRANSFER BUFFER GEN.DESC,OPER AND PROG,INSTALL,CHKOUT,THEO,OF OPER,DIAGS,	65692300	A	22	06.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
DIAGNOSTIC, MAINT AIDS, P/L, W/L, EQ SUM, REF/CE				
DC216-A (SP. OP. 60128) DATA CHANNEL CONVERTER REF/CE MANUAL	60299902	C	22	02.20
DC220/DC221-A 1700 A/Q DSA ADAPTERS HARDWARE REFERENCE/CE MANUAL	39392700	C	22	07.30
DC401-A (SP.OP.65075) MASS STORAGE EXTENDER CE MANUAL	60392600	C	22	08.80
DE101-A MULTIPLEX DATA CHANNEL GEN DESC, THEORY OF CP, DIAGS, MAINT CE MAN.	39524000	A	22	14.35
DF3A1-A (1555-1/4) RELAY OUTPUT UNIT REF/CE MANUAL	39909509	A	22	03.25
DJ101-A, DJ115-A DATA SET ADAPTERS CE MANUAL	41600600	B	22	02.45
DJ110-A (311-2) DATA SET ADAPTER THEORY OF OPERATION, INSTALLATION/CHECKOUT DIAGRAMS, MAINT., MAINT. AIDS, PARTS DATA, CE MANUAL	41603200	C	22	11.05
WIRE LIST, EQ SUMMARY CE MANUAL	41608100	A	22	05.85
DJ111-A (311-2) DATA SET ADAPTER CE INFO (USE DJ110-A)				
DJ112-A-B TRANSCEIVER CE MANUAL	41605400	B	22	03.30
DJ113-A/B (358-2) TRANSCEIVER CE MANUAL (INCLUDES PMI/PMP)	41606300	E	22	04.40
DJ114-A/B/C/D (358-3/4) TRANSCEIVER CE MANUAL	41601900	E	22	04.90
DJ115-A (327-2) DATA SET ADAPTER CE INFO (USE DJ101-A)				
DJ122-A (361-4) COMMUNICATIONS ADAPTER CE MANUAL	41609700	F	22	11.55
DJ130-A (792-10) AUTOMATIC CALLING ADAPTER CE INFO (USE FJ424-A/B/C)				
DJ140-A/B (124-1) SYNCHRONOUS MODEM CE MANUAL	41613400	F	22	01.50
DJ141-A (101-1) SYNCHRONOUS MODEM CE MANUAL	41613200	E	22	01.40
DJ142-A (361-1/3) COMMUNICATIONS ADAPTER REF INFO (USE 361-1)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE MANUAL	41612100	H	22	03.30
DJ143-A (361-1/2) COMMUNICATIONS ADAPTER REF INFO (USE 361-1) CF INFO (USE DJ142-A)				
DJ144-A (361-5) COMMUNICATIONS ADAPTER CE MANUAL	41611700	J	22	12.75
DJ145-A (361-6) SYNCHRONOUS COMMUNICATIONS ADAPTER CE MANUAL	41611900	M	22	05.35
DJ146-A (361-7) COMMUNICATIONS ADAPTER CE MANUAL	41612300	A	22	03.20
DJ151-A DATA SET ADAPTER REFERENCE/CE MANUAL	60344700	A	22	05.85
DJ152-A DATA SET ADAPTER REF/CF INFO (USE DJ151-A)				
DJ604-A (792-2) DATA SET ADAPTER CF INFO (USE FJ424-A/B/C)				
DJ605-A (792-3) DATA SET ADAPTER CF INFO (USE FJ424-A/B/C)				
DJ607-A (792-1) DATA SET ADAPTER CF INFO (USE FJ424-A/B/C)				
DJ805-A/B (304-1) COMMUNICATIONS MULTIPLEXER CE MANUAL	13796500	G	22	04.30
DJ808-A (364-1/2) COMMUNICATIONS MULTIPLEXER CE MANUAL	41611000	J	22	02.35
DJ813-A (364-3) COMMUNICATIONS MULTIPLEXER CE MANUAL	41612600	02	22	04.80
DJ814-A (364-4/5) COMMUNICATIONS MULTIPLEXER CE MANUAL	41612800	F	22	07.10
DJ815-A ASYNCHRONOUS COMMUNICATIONS CONTROLLER AND DISTRIBUTION PANEL CE MANUAL	89638300	02	22	05.35
DK501-A (ST. OPT. 10128) DUAL MODE OPTION CE MANUAL	41603100	D	22	03.00
DK502-A (ST. OPT. 10127) EXPANDED MEMORY OPTION CE MANUAL	41611200	D	22	03.00
DK509-A (362-1/2) TELEGRAPHIC LEVEL CONVERTER				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE MANUAL	41610400	G	22	04.10
DK516-A (7700) MUX INCREMENT-1 CE INFO (USE AC113-A/B OR AA121-A AND AD102-A)				
DK518-A (7681-1) DATA CHANNEL CONVERTER CE MANUAL	60355900	F	22	06.35
DK520-A (7700) MUX INCREMENT-2 CE INFO (USE AC113-A/B OR AA121-A AND AD102-A)				
DK526-A (CYBER 1000) MEDIUM SPEED LINE CONTROLLER HARDWARE REFERENCE MANUAL	74606800	A	22	09.70
DK605-A (1595-10/11) SERIAL I/C UNIT REF/CE MANUAL	39909507	B	22	03.90
DK605-B (1595-20/21) SERIAL I/C UNIT REF/CE INFO (USE DK605-A)				
DN124-A USE 1590-3				
DT117-A (6500-A/B/C WITH ECS) ADDS ECS CAPABILITY TO 6500-A/B/C (USE AT195-A MANUAL)				
DT122-A (7683-1) REMOTE CHANNEL COUPLER REF/CE MANUAL	60296200	H	22	04.60
DT137-A (791-1/3/4) NORMAL OUTPUT CHANNEL CE INFO (USE FJ424-A/B/C)				
DT138-A (791-1/3/4) NORMAL INPUT CHANNEL CE INFO (USE FJ424-A/B/C)				
DT139-A (791-1) CHANNEL EXPANDER RECEIVERS AND TRANSMITTERS CE INFO (USE FJ424-A/B/C)				
DT141-A () 1700 A/Q COUPLER CE INFO (USE FF104-A)				
DT143-A () ADDS ECS CAPABILITY TO AA105-A OR 641X-D. (USE MANUALS UNDER AT194-A)				
DT158-A (7611-10) PL COUPLER CE MANUAL	60356300	D	22	05.00
DT160-A () TERMINAL COUPLER CE MANUAL	60318500	A	22	08.65

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
DT174-A (ST.OP.10266-1/2/3, 10280-1/2/3) DDP REGISTER INCREMENT (2,3 OR 4 PORT) CE INFO (USE DC135-A)				
DT175-A/B (7077-1) 6000 PL SAC COUPLER CE MANUAL	60352300	C	22	05.90
DT194-A (ST.OP. 10293-1) CHANNEL MODIFICATION				
DT196-A (ST.OP. 10293-1/2) CHANNEL MODIFICATON				
DT204-A (SP.OP. 60081-A) ECS INTERFACE LOGIC FOR 6400-A/B/C CENTRAL COMPUTER OR AUGMENTED I/O BUFFER AND CONTROLLER TO 6640 ECS USE 6400-A/B/C UNLESS AT197-A AND AT195-A OR AT196-A AND AT195-A ARE INSTALLED, IF SO SEE AT195-A.				
DT205-A (SP.OP. 60081-B) ECS INTERFACE LOGIC MAY BE INSTALLED IN 6400-D OR AA105. USE STANDARD MANUALS FOR THAT SYSTEM UNLESS AT194-A IS INSTALLED. IN THIS CASE SEE MANUALS LISTED UNDER AT194-A				
DT208-A (7611-10) PL COUPLER CE INFO (USE DT158-A)				
DT209-C (7054-1/2) 6000 COUPLER REF/CE MANUAL	60364100	R	22	16.10
DT209-D (7021-1/2) 6000 COUPLER				
DT210-A (7654-1) 7000 COUPLER REF/CE MANUAL	60364200	C	22	24.40
DT210-B (7622-1/2) 7000 COUPLER REF/CE INFO (USE DT210-A)				
DT220-A (7054-2, ST.OP 10285-1) DUAL ACCESS OPTION REF/CE INFO (USE DT209-C)				
DT220-B (7054-2) DUAL ACCESS OPTION REF/CE INFO (USE FA719-A/B/C/D COUPLER MAN)				
DT220-C (7054-22/42) SECOND CHANNEL FEATURE REF/CE INFO (USE FA722-A/B)				
DT221-A () REGISTER CE INFO (USE DC145-A/B)				
DT716-A (7054-41) DOUBLE DENSITY OPTION				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE INFO (USE FA722-A/B)				
DW105-A (CYBER 1000) THREE-BAY EXCHANGE UNIT HARDWARE MAINTENANCE MANUAL	74720400	A	22	09.00
DW110-A (CYBER 1000) TWO-BAY EXCHANGE UNIT HARDWARE MAINTENANCE MANUAL	74717600	A	22	09.15
DW111-A USE DW105-A				
DY107/8/9/10-A (CYBER 1000) LINE MODULE EXTENSION CABINET HARDWARE MAINTENANCE MANUAL	74724500	A	22	06.40
DY120-A (CYBER 1000) MAGNETIC TAPE CONTROLLER HARDWARE MAINTENANCE MANUAL	74607500	B	22	08.95
DY121-A (CYBER 1000) FAST DISK CONTROLLER HARDWARE MAINTENANCE MANUAL	74691800	A	22	09.00
DY122-A (CYBER 1000) 3000 SERIES CONTROLLER- ADAPTER HARDWARE MAINTENANCE MANUAL	74660300	A	22	08.75
DY123-A (CYBER 1000) 1700 SERIES CONTROLLER- ADAPTER HARDWARE MAINTENANCE MANUAL	74675500	A	22	05.35
DY124-A (CYBER 1000) CONTROLLER EXTENSION CAB. HARDWARE MAINTENANCE MANUAL	74720500	A	22	05.05
DY127-A (CYBER 1000) HIGH-SPEED LINE CONTROL HARDWARE MAINTENANCE MANUAL	74664300	A	22	10.80
DY128-A (CYBER 1000) DISK PACK CONTROLLER HARDWARE MAINTENANCE MANUAL	73361200	B	22	07.15
DY129-A USE DY124-A				
EA102-A (1525-2) ANALOG TO DIGITAL CONVERTER GEN DESC, DIAGS, W/L, MAINT CE MANUAL	39473200	A	22	04.40
EA309-A (1525-3) ANALOG TO DIGITAL CONVERTER REF/CE MANUAL	39909506	B	22	04.00
EB201-A/EB202-A (DA-1) THIRTY TWO CHANNEL ELEVEN BIT DAC GEN DESC, INSTALLATION/CHECKOUT, DIAGS, W/L, MAINTENANCE, PARTS DATA, REF/CE MANUAL	39744900	A	22	03.90
EB301-A/D FOUR CHANNEL DIGITAL-TO-ANALOG CONVERTER GEN.DESC.,OP AND PROGRAMMING,INSTALLATION	88981100	A	22	03.90

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
AND CHECKOUT, THEORY OF OPERATIONS, DIAGRAMS, MAINTENANCE, MAINT. AIDS, PARTS DATA HARDWARE REFERENCE/CE MANUAL				
ED105-A (1501-10) ANALOG INPUT MULTIPLEXER REF/CE MANUAL	39909504	B	22	06.35
ED106-A (1501-11) ANALOG INPUT MULTIPLEXER EXPANDER REF/CE INFO (USE ED105-A)				
EE601-A TAPE CONTR AND MONITOR UNIT (TCM) HARDWARE REFERENCE/CE MANUAL	39222600	A	22	04.90
EL101-A (1750-1) COMPUTER INTERFACE UNIT REF/CE MANUAL	88980100	C	22	
EL102-A (1750-2) COMPUTER INTERFACE EXPANDER REF/CE INFO (USE EL101-A)				
FA102-A (1733-1) DISK STORAGE CONTROLLER CE MANUAL	60400100	F	22	18.10
FA103-A (7639-2) MASS STORAGE CONTROLLER HARDWARE MAINTENANCE MANUAL	60427600	B	22	47.45
FA202-A (7639-1/2) MASS STORAGE CONTROLLER HDWE MAINT INFO (USE FA103-A)				
FA203 CONTROLLER				
MTCPODIAGNOSTICS USERS CE MANUAL	83315600	A	22	07.60
FLEXIBLE DISK DRIVE CE MANUAL	83315700	A	22	04.50
MICRODIAGNOSTIC DESCRIPTIONS CE MANUAL	83315800	A	22	03.85
THEORY OF OPERATION CE MANUAL	83316100	A	22	14.25
PARTS DATA CE MANUAL	83316200	A	22	08.75
HARDWARE MICROPROGRAM CE MANUAL	83316300	A	22	07.30
DIAGNOSTIC MICROPROGRAM CE MANUAL	83316400	A	22	18.70
DUAL ACCESS FEATURE MICROPROGRAM CE MANUAL	83316600	A	22	18.60
FA401-A/B (7021-1) 1X8 MAG TAPE CONTROLLER HARDWARE REFERENCE MANUAL CE MANUAL - VOL 1	60404000 60404100	C G	22 22	03.75 37.90
FA402-A/B (7021-2) 2X8 MAG TAPE CONTROLLER HARDWARE REF INFO (USE FA401-A/B)				
FA403-A/B (7622-1) 1X8 MAG TAPE CONTROLLER HARDWARE REF INFO (USE FA401-A/B)				
FA404-A/B (7622-2) 2X8 MAG TAPE CONTROLLER HARDWARE REF INFO (USE FA401-A/B)				
FA405-A/B (8194) MAGNETIC TAPE CONTROLLER				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE MANUAL	13795900	G	22	05.05
FA407-A7 OR 9 TRACK MAGNETIC TAPE CONTROLLER, OPER., MAINT. INSTR. MANUAL	84942200		22	05.10
FA414-A/B (3121-A/B) MAGNETIC TAPE CONTROLLER CE MANUAL ** REFER ALSO TO CATALOG SEC. 2 FOR 609 TAPE TRANSPORT CE MANUALS	60210900	K,L	22	06.25
FA416-B (3518-1/2/3) MAG TAPE CONTROLLER CE MANUAL	60289100	BG	22	16.80
FA417-B (3518-2/3, 3528-2/3) MAGNETIC TAPE CONTROLLER CE INFO (USE FA416-B)				
FA418-A (3528-1/2/3) MAGNETIC TAPE CONTROLLER CE INFO (USE FA416-B)				
FA419-A (CYBER 1000) SEE DY120-A				
FA420-B (3518-3, 3528-3) MAG TAPE CONTROLLER CE INFO (USE FA416-B)				
FA423-A () MAGNETIC TAPE CONTROLLER REF/CE MANUAL (INCLUDES PMI/PMP) ** REFER ALSO TO CATALOG SECTION 2 FOR 604 AND 607 MAG TAPE TRANSPORT MANUALS	60291400	F	22	10.05
FA428-A (7618-1, 7629-1) 1X8 MAGNETIC TAPE CONTROLLER CE MANUAL	60321100	U	22	37.60
FA429-A (7628-1, 7629-2) 2X8 MAGNETIC TAPE CONTROLLER CE INFO (USE FA428-A)				
FA434-A/B (7622-1, 7021-1) 1X8 MAG TAPE CONTROL CE MANUAL HARDWARE REF INFO (USE FA401-A/B)	60365200	D	22	23.40
FA438-A/B (7622-2, 7021-2) 2X8 MAG TAPE CONTROL CE INFO (USE FA434-A/B) HARDWARE REF INFO (USE FA401-A/B)				
FA442 MAGNETIC TAPE CONTROLLER CE MANUAL	89637700	02	22	10.05
FA444-A/B (7021-21) MAG TAPE CONTROLLER HOWE MAINT. MANUAL	60438500	A	22	41.50

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
FA445-A/B (7021-2?) MAG TAPE CONTROLLER MAINT INFO (USE FA444-A/B)				
FA446-A MTT (LCIT) CE MANUAL	89769500	01	22	06.40
FA601-A INTERIM DRUM CONTROLLER REF/CE MANUAL	60232300	B	22	05.60
FA7A3-A (OEM 9008-1) DISK CONTROLLER REF/CE INFO (USE 9008-1 CATALOG SEC 2)				
FA7A4-A/B PLUG COMPATABLE CONTROLLER MICROPROGRAM CE MANUAL	70614100	D	22	09.80
WIRE LIST CE MANUAL	70614000	E	22	11.55
DIAGRAMS CE MANUAL	70613900	H	22	05.40
THEORY OF OPERATION	70616700	A	22	04.50
MAINTENANCE CE MANUAL	70613800	G	22	05.10
FA7A4-C/D, FV1A1-A TWO CHANNEL PLUG COMPATABLE CONTROLLER CE MANUAL	70614200	B	22	06.25
FA7A5-A/B/C/D PLUG COMPATABLE CONTROLLER MICRO PROGRAM CE MANUAL	70621800	B	22	08.95
DIAGRAMS CE MANUAL (INCLUDES FV1A4-A)	70621600	G	22	07.25
THEORY OF OPERATIONS CE MANUAL	70621500	A	22	08.05
WIRE LISTS CE MANUAL	70621700	D	22	21.70
GENERAL DESCRIPTION, INSTALLATION AND CHECK- OUT THEO OF OPER., WIRE LIST CE MANUAL	70621900	A	22	15.50
FA701-A CONTROLLER 7600 INTERIM DISK FILE SYS	60232200	D	22	05.15
FA704-A/B (3553-2) MASS STORAGE CONTROLLER CE MANUAL	60266000	AE	22	20.35
FA704-C (3553-2) MASS STORAGE CONTROLLER CE MANUAL	60394700	H	22	36.50
FA705-A (3553-1) MASS STORAGE CONTROLLER CE MANUAL	60290000	R	22	12.05
FA705-B (3553-1) MASS STORAGE CONTROLLER CE MANUAL	60394600	D	22	35.95
FA710-A/B/C/D (7054-1) DISK CONTROLLER HARDWARE REFERENCE MANUAL	60364500	G	22	04.00
CE MANUAL - VOL 1 AND 2	60364000	N	22	36.15
FA710-E/F (7054-1) DISK CONTROLLER CE INFO (USE FA719-A CE MANUAL - 60405500)				
FA716 CARTRIDGE DISK CONTROLLER CE MANUAL	89638100	02	22	05.65

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
FA719-A/B/C/D (7054-1/2) DISK STORAGE CONTROLLER CE MANUAL (6000 COUPLER) CE MANUAL VOLS 1 AND 2	60416400 60405500	E G	22 22	11.50 32.60
FA720-A/B/C/D (7654-1) DISK STORAGE CONTROLLER CE MANUAL (ALSO USE FA719-A MANUAL - 60405500)	60410000	B	22	11.00
FA721 STORAGE CONTROL EIGHT VOLUME CAU FUNCTIONAL MICROPROGRAM CE MANUAL PREVENTIVE/CORRECTIVE MAINT, W/L, CE MAN V-2 DIAGRAMS VOLUME 2 CE MANUAL STANDARD DIAGNOSTICS MICROPROGRAM CE MANUAL INLINE DIAGNOSTICS MICROPROGRAM CE MANUAL 16 VOL. CAU FUNCTIONAL MICROPROGRAM MANUAL HARDWARE REFERENCE CE MANUAL PARTS DATA CE MANUAL	83302100 83301900 83302000 83312100 83312000 83311900 83301800 83306000	E E R C E E B F	22 22 22 22 22 22 22 22	18.70 07.95 27.85 25.75 18.25 18.45 06.90 03.85
FA722-A/B (7054-21/22/41/42) DISK STORAGE CONTROLLER HARDWARE MAINTENANCE MANUAL	60428500	J	22	28.00
FA802-A (7601-1, 7638-1) DISK/DRUM CONTROLLER REF INFO (USE 7638-1, CATALOG SECTION 2) CE MANUAL ** REFER ALSO TO BH405 MANUALS FOR DISK FILE DOCUMENTATION	60287200	N	22	08.80
FE107-A (1726-1) CARD READER CONTROLLER CE MANUAL	60232000	B	22	07.80
FE110-A (1729-2) CARD READER CONTROLLER CE MANUAL	60269200	G	22	04.50
FE119 CARD READER CE MANUAL	89637500	03	22	03.15
FE201-A (417-1) CARD PUNCH CONTROLLER REFERENCE/CE MANUAL	60283600	B	22	06.95
FE202-A/B (415-30) CARD PUNCH CONTROLLER REF/CE MANUAL	60425600	C	22	20.90
FE304-A (1728-A/B) CARD READER/PUNCH CONTROLLER CE MANUAL	60224000	M	22	03.75
FF103-A (1735) PAGE READER CONTROLLER CE MANUAL	60237700	H	22	08.95
FF104-A (955-1) PAGE AND DOCUMENT READER CONTROLLER				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
CE MANUAL	60324700	A	22	12.10
FF307-B (3555-1) LINE PRINTER CONTROLLER CE MANUAL	60278800	S	22	20.40
FF406-A/B/C (1736-1) UNIT RECORD READER CONTROLLER CE MANUAL	60230200	06	22	08.80
GEN DESC, FLOW CHARTS, PROGRAM LISTINGS CE MANUAL	60283200	A	22	09.80
FF510-A/B (3254) LINE PRINTER CONTROLLER CE MANUAL (INCLUDES PMI-PMP)	60182400	J	22	11.00
FF511-A/B (1742) LINE PRINTER CONTROLLER CE MANUAL (INCLUDES PMI/PMP)	60183000	H	22	04.80
FF516-A (1740) LINE PRINTER CONTROLLER CE MANUAL	60223800	J	22	23.80
FF524-A LINE PRINTER CONTROLLER GEN. DESC., OPERATION AND PROGRAMMING, INSTALL- ATION AND CHECKOUT, THEORY OF OPERATION, DIAGRAMS, MAINTENANCE, PARTS DATA, WIRE LISTS CE MANUAL	89637300	04	22	03.00
FF525 PRINTER SUBSYSTEM CENTRAL CONTROL UNIT LOGIC DIAGRAMS THEORY OF OPERATIONS	22272500	A	34	09.55
	22272400	A	3	12.90
FJ101-A (1717-1) 1700 AUTODIN INTERFACE THEORY OF OPERATION, INSTALLATION/CHECKOUT DIAGRAMS, MAINT., MAINT. AIDS, PARTS DATA, CE MANUAL	41602200	B	22	03.95
CARD PLACEMENT, EXPRESSION FILE, UNIVERSAL WIRE DATA LISTS, WIRE LISTS CE MANUAL	41606400	B,C	22	04.85
FJ103-A/B/C/D/E (1748-2) MULTIPLEXER CONTROLER THEORY OF OPERATION, INSTALLATION CHECKOUT, DIAGRAMS, MAINT., MAINT. AIDS, PARTS DATA, CE MANUAL	41601700	J	22	04.35
CARD PLACEMENT, LOGIC WIRING, WIRE LISTS, EQUATION SUMMARY CE MANUAL	41603300	E	22	08.05
FJ124-A USE 1590-3				
FJ411-A/B (6671) DATA SET CONTROLLER DIAGRAMS, CIRCUIT DESCRIPTION, PARTS LIST, CARD PLACEMENT, EQUATION SUMMARY, WIRE LISTS CE MANUAL	60217400	W	22	27.00
MAINTENANCE, MAINTENANCE AIDS CE MANUAL (INCLUDES PMI/PMP)	60251300	E	22	16.25

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
FJ412-A/B/C (1747) DATA SET CONTROLLER THEORY OF OPERATION, INSTALLATION CHECKOUT DIAGRAMS, MAINTENANCE, MAINT. AIDS, PARTS DATA CE MANUAL	13799100	E	22	04.05
WIRE LISTS, EQUATION SUMMARY CE MANUAL	13799200	E	22	03.40
FJ413-A (313, 314, 317, 318) RECEIVE CONTROL UNIT REF INFO (SEE APPROPRIATE PRODUCT, CATALOG SECTION 2) CE MANUAL	13798100	G	22	03.80
FJ414-A (313, 314, 317, 318) SEND CONTROL UNIT REF INFO (SEE APPROPRIATE PRODUCT, CATALOG SECTION 2) CE INFO (USE FJ413-A) INSTRUCTION CARD	60368000	B		01.00
FJ415-A (1717-1) AUTODIN INTERFACE UNIT THEORY OF OPERATION, INSTALLATION/CHECKOUT DIAGRAMS, MAINTENANCE, MAINT. AIDS, PARTS DATA CE MANUAL	13797900	B-E	22	05.45
CARD PLACEMENT, EXPRESSION FILE, UNIVERSAL WIRE DATA LIST, WIRE LISTS CE MANUAL	41605600	C	22	10.30
FJ424-A/B/C (791-1) LOCAL COMMUNICATIONS CONTROLLER CE MANUAL	60321800	T	22	23.50
FJ427-A (6671-1) DATA SET CONTROLLER MAINTENANCE, MAINT. AIDS CE INFO (USE FJ411-A/B) INSTALLATION/CHECKOUT, DIAGRAMS, PARTS DATA, WIRE LISTS, EQ. SUMMARY CE MANUAL	60294500	K	22	11.90
FJ430-A/B (7077-1) STORAGE ACCESS CONTROLLER CE MANUAL	60316500	D	22	24.75
FJ440-A (6671-3) DATA SET CONTROLLER CE MANUAL - VOLUME 1	60409200	B	22	34.15
MAINTENANCE, MAINTENANCE AIDS CE MAN. VOL 2	60425100	A	22	18.55
FJ601-A (3316-1, 3516-1) MULTIPLEXER CONTROLLER THEORY OF OPERATION, INSTALLATION/CHECKOUT DIAGRAMS, MAINTENANCE, MAINT. AIDS, PARTS DATA, WIRE LISTS CE MANUAL	13796700	K	22	06.15
CROSS TABS, LOGIC WIRING, EQ SUMMARY CE MAN.	13798800	H	22	06.20
TEST ROUTINE CE MANUAL	41600300	A	22	01.35
FJ606-A SYNCHRONOUS COMMUNICATIONS CONTROLLER AND DISTRIBUTION PANEL CE MANUAL	89638500	01	22	04.20
FL303-A TAGGED DATA BUS OUTPUT INTERFACES TOB/	39231200	A	22	02.05

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
DSA INTERFCE-TDI TDB/DAC INTERFACE DAI HOWE REFERENC/CE MANUAL				
FR101-B () BUFFER CONTROLLER REFERENCE MANUAL	60275000	C	22	01.00
CE MANUAL	60278300	H	22	06.55
FR113-A (731-10/12, 732-10/12) BUFFER CONTROLLER				
CE MANUAL	60335400	M	22	08.70
DIAGNOSTIC REFERENCE MANUAL - VOLS 1/2/3	60400300	D	22	25.00
MAINTFNANCE CE MANUAL	70621400	F	22	06.10
IBM 360 BUFFER CONTROLLER DIAGNOSTIC LISTING	60401600	A	22	02.80
23141/23142 MADCOP CE MANUAL				
IBM 360 BUFFER CONTROLLER DIAGNOSTIC LISTING	60401500	A	22	28.15
23141/23142 FODDER CE MANUAL				
BUFFER CONTROLLER DIAGNOSTIC LISTINGS -				
HSR 512 LINE PRINTER TEST (LP1) CE MANUAL	60401700	B	22	03.95
HSR 80X16 DRUM/DISPLAY TEST (DD2) CE MAN.	60401800	A	22	09.45
200 NSEC MEMORY TEST (MY1) CE MANUAL	60402100	A	22	01.20
200 NSEC MEMORY TEST (MY2) CE MANUAL	60402200	A	22	01.00
LSRT/MSRT DISPLAY/KEYBOARD/OPERATOR	60402700	C	22	05.65
CONSOLE TEST (DD6) CE MANUAL				
200 NSEC MEMORY TEST (BCM) CE MANUAL	60402900	A	22	01.30
FR114-A () CONSOLE DISPLAY CONTROLLER GEN DESC, DIAGRAMS, WIRE LISTS CE MANUAL	60365700	A	22	09.60
FT1A1-A (1547-1) EVENTS COUNTER UNIT REF/CE MANUAL	39909508	A	22	05.35
FT1A1-B (1547-2) EVENTS COUNTER UNIT REF/CE INFO (USE FT1A1-A)				
FT103-A/B TRANSFER SWITCH CONTROLLER REF/CE INFO (USE 8271 - CATALOG SEC 2)				
FT104-A TRANSFER SWITCH CONTROLLER REF/CE INFO (USE 8271 - CATALOG SEC 2)				
FT111-A () POWER FAULT DETECTOR CE MANUAL	60367400	A	22	05.05
FV129-A (3516-1) MULTIPLEXER CONTROLLER ADAPTER UNIT				
CE MANUAL	41608500	C	22	03.00
FV138-A DISPLAY STATION ADAPTER KIT (EDIT) REF/CE INFO (USE FV135-A)				
FV149-A (ST. OPT. 10194-2) ASCII HOLLERITH TO BCD CONVERSION KIT FOR THE 3447-B CARD READER CONTROLLER				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
REF INFO (USE 3248-A REF MAN, CATALOG SEC 2) CE MANUAL	60292600	D	22	07.65
FV150-A (ST. OPT. 10194-1) INTERNAL BCD TO ASCII HOLLERITH CONVERSION KIT FOR THE 3446-A/B CARD PUNCH CONTROLLER REF INFO (USE 3446-A/B REF MAN, CAT. SEC 2) CE MANUAL	60292700	C	22	02.50
FV156-A () 4K MEMORY CE MANUAL	60309700	B-G	22	07.35
FV165-A (791-2) EXPANSION UNIT CE INFO (USE FJ424-A/B/C)				
FV216A SWITCH UNIT HARDWARE/REF CE MANUAL	39368600	A	22	05.65
FV217-A () INTERIM MEDIUM SPEED BATCH SUBSYSTEM CE INFO (USE DT160-A)				
FV218-A/B (733-10) HSB SUBSYSTEM/TERMINAL CONTROLLER CE MANUAL	60329700	V	22	23.20
FV227-A/B (1739-1) CARTRIDGE DISK DRIVE CONTROLLER CE MANUAL	60368500	B	22	07.50
FV4A3 (1576) STALL ALARM UNIT				
FV409-A (7611-10) DRUM AND DISPLAY LOGIC REFERENCE/CE MANUAL	60318600	D	22	07.30
FV410-A (7611-10) DRUM AND DISPLAY LOGIC REF/CE INFO (USE FV409-A)				
FV433-A, FV434-A, FV435-A, FV436-A DRUM AND DISPLAY LOGIC REF/CE MANUAL	60363300	L	22	05.45
FV437-A (733-1XX) HSB SUBSYSTEM/TERMINAL RECEIVER/TRANSMITTER OPTION CE INFO (USE FV218-A)				
FV444-A () POWER REGULATOR MODULE CE INFO (USE BB372-A)				
FV497-A/FV613-A PHASE ENCODING FORMATTER CE MANUAL	89796100	01	22	06.60
FV498 (1576) STALL ALARM UNIT CII PRINT CARTRIDGE HARDWARE REFERENCE MAN	91860200	A	22	01.65

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
FV605 CONTROLLER ADAPTER UNIT PARTS DATA CE MANUAL	83306300	C	22	03.65
GENERAL DESCRIPTION, THEORY OF OPERATION	83306100	B	22	04.95
PREVENTIVE/CORRECTIVE MAINTENANCE, DIAGRAMS, WIRE LISTS CE MANUAL	83315400	A	22	21.10
FV618-A CE INFO USE FV497				
GA103-A/B/C (ST. OPT. 10126) INTERVAL TIMER THEORY OF OPERATION, INSTALLATION/CHECKOUT DIAGRAMS, MAINTENANCE, MAINT. AIDS, PARTS DATA CE MANUAL	41601000	C	22	04.00
WIRE LISTS, EQUATION SUMMARY CE MANUAL	41602500	C	22	04.00
GA104-A/B (ST. OPT. 10126) TIME OF DAY CLOCK CE MANUAL	41602900	B	22	04.90
GA107 LINE SYNCHRONIZED TIMING GENERATOR HARDWARE/REFERENCE MANUAL	39359900	A	22	01.95
GA128-A (1572-1) SAMPLE TIMING UNIT REF/CE MANUAL	39909505	C	22	03.15
GD104-A (90115-1) POWER SUPPLY - 400HZ CE INFO (USE AB103-A)				
GD105-A (90115-1) POWER SUPPLY - 50HZ CE INFO (USE AB103-A)				
GD106-A (90115-1) POWER SUPPLY - 60HZ CE INFO (USE AB103-A)				
GD108-A/B (60130-1) LOOP CURRENT POWER SUPPLY REF/CE INFO (USE GH407-A/B)				
GD306-A/B (364-1/4, 10193-1) POWER SUPPLY REF/CE INFO (USE GH407-A/B)				
GE210-A/B (90115-4) FREQUENCY CONVERTER				
GE226-A (7601-1) FREQUENCY CONVERTER CE INFO (USE MOTOR GENERATOR CE MANUAL - SEE MOTOR GENERATOR SETS, CATALOG SECTION 4)				
GE232-A (7601-1, 7611-1/2) FREQUENCY CONVERTER CE INFO (USE MOTOR GENERATOR CE MANUAL - SEE MOTOR GENERATOR SETS, CATALOG SECTION 4)				
GG105-A (303-1) COMMUNICATIONS EXPANSION UNIT CE MANUAL	13799800	B	22	06.40
GH104-A (350?) POWER MODULE				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE INFO (USE BB313-A)				
GH105-A/B/C (76XX) POWER DISTRIBUTION AND WARNING SYSTEM CE MANUAL	60298400	G	22	05.25
GH105-D (76XX) POWER DISTRIBUTION UNIT CE MANUAL	60298600	L	22	10.30
GH107-B/ED301-E MULTIPLEXER (MX-7A) GEN DESC, DIAGS, W/L, PARTS DATA CE MANUAL	39660400	B	22	03.30
GH107/ED301-F ANALOG MULTIPLEXER GEN DESC, W/L, PARTS DATA CE MANUAL	39690100	A	22	04.50
GH110-A/B () 2-TON CONDENSING UNIT ** REFER ALSO TO VENDOR MANUALS, CATALOG REFRIGERATION INFO (USE GH214-B)				
GH214-A (7601-1,) TEN TON REFRIGERATION UNIT (WATER COOLED) CE MANUAL	60298100	F	22	06.60
GH214-B () 10-TON CONDENSING UNIT REFRIGERATION CE MANUAL	60367300	G	22	09.35
GH216-A (7611-1/2) 2 TON REFRIGERATION UNIT (AIR COOLED) CE INFO (USE GH214-A)				
GH218-A (7611-1/2) 2 TON REFRIGERATION UNIT (WATER COOLED) CE INFO (USE GH214-A)				
GH223-A (76-XXX) CONDENSING UNIT CE MANUAL	60427800	A	22	10.30
GH401-A (90114-1) CABINETY CE INFO (USE AB103-A)				
GH407-A/B (362-1, 364-1, 364-4) GENERAL PURPOSE CABINET REFERENCE/CE MANUAL	41614300	E	22	02.85
GH408-A/B (7077-1) CENTRAL STORAGE CABINET CE MANUAL	60316600	F	22	13.45
GH417-A/B () CABINETY CE INFO (USE AB103-A)				
GH427-A/B DESK CABINET HARDWARE MAINTENANCE MANUAL	22261700	A	3	04.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
GH428-A (173-X,174-X) USE AA107-A				
GH432-A/B DESK CABINET HARDWARE REF/CE MANUAL	91628700	A	22	04.30
GH506-A (76-XXX) POWER DISTRIBUTION UNIT 60HZ CE INFO (USE AA106-A)				
GH506-B (76-XXX) POWER DISTRIBUTION UNIT 50HZ CE INFO (USE AA106-A)				
GJ1A1 (5560) POWERED FORMS STACKER GEN DESC., OPER, DIAGS, MAINT AIDS, PARTS DATA CE MAN.	50580900	C	3	02.55
GJ1A1-A/B-CIT POWERED FORMS STACKER REF/CE	91860300	A	22	02.35
GJ1A2 (5570) MANUAL FORMS STACKER GEN DESC., OPER, DIAGS, MAINT AIDS, PARTS DATA CE MAN.	50582000	C	22	01.00
GJ102-A (1778-1, 90122-1) PAPER TAPE READER HANDLER CE INFO (USE CE305-A/B) ** REFER ALSO TO VENDOR MANUALS, CATALOG SEC. 4 FOR REMEX TAPE SPOOLER CE MANUAL				
GJ103-A/B (1778-2, 90124-1/2) PAPER TAPE PUNCH HANDLER CE INFO (USE CE305-A/B) SEC. 4 FOR NCR EM-B3 TAPE TRANSPORT CE MANUAL				
GJ104 MANUAL FORMS STACKER GEN DESC, OPERATION DIAGRAMS, MAINTENANCE, PARTS DATA CE MAN	50584100	B	22	01.35
GJ105A/B POWERED FORMS STACKER GEN DESC., OPER, DIAGS, MAINT, MAINT AIDS, PARTS DATA CE MAN	50583500	C	22	02.95
GK102 (673) TAPE EXERCISER REF/CE MANUAL	49803700	A	22	03.40
GK111 (SP. OPT 65006) TAPE EXERCISER REF/CE MANUAL	49803800	A	22	03.30
GK153-A () DATA CHANNEL LONG LINE DRIVER CE INFO (USE AB103-A)				
GK154-A () DATA CHANNEL LONG LINE DRIVER CE INFO (USE AB103-A)				
GK181-A (76XX) I/O STATION CABINET MODIFICATION KIT CE INFO (USE GH105-D)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
GL102 (686) MAGNETIC TAPE CERTIFIER GENERAL DESCRIPTION, OPERATION, INSTALLATION CHECKOUT, MAINT. CE MANUAL (INCLUDES PMI/PMP)	40867500	C	22	14.40
THEORY OF OPERATION, DIAGRAMS, W/L CE MANUAL	40867700	G	22	06.45
PARTS LIST (A04, B04 AND ABOVE) CE MANUAL	41240600	C	22	02.95
OPERATORS CE MANUAL	70605900	A	22	02.10
GL112-A (90107-1) CONSOLE CE INFO (USE AB103-A)				
MB434-A CONTROLWARE (6000) (USE FA401-A/B CE MANUAL VOL 1 OR FA444-A/B)				
MB435-A CONTROLWARE (7000) (USE FA401-A/B CE MANUAL VOL 1)				
SD101 SOURCE DATA COLLECTION TERMINAL HARDWARE PROGRAMMING MANUAL	62056300	A	22	01.35
TB101 PERIPHERAL EXERCISER--LISTED AS 9910				
TB101-B/9910-B PERIPHERAL EXERCISER				
TB115-A FIELD TEST UNIT DIAGRAMS, WIRE LISTS, PARTS DATA, GEN. DESC, OPERATIONS CE MANUAL	70604000	A	22	04.90
TB204 FIELD TEST EXERCISER CE MANUAL	83302900	B	22	03.10
TB207-A FIELD TEST UNIT MAINTENANCE MANUAL	83307900	B	3	04.65
TB301-A/B FIELD TEST EXERCISER MAINT. MANUAL	70612800	G	3	05.00
TB3A1 FIELD TEST UNIT GEN DESC., INSTALLATION AND OPERATION, THEO. OF OPERATION, MAINT., DIAGRAMS AND W/L, PART DATA CE MANUAL	83303700	B	22	05.35
TB302 FIELD TEST UNIT CE MANUAL	83308000	B	22	06.75
TB4A1-A FIELD TEST UNIT MAINTENANCE MANUAL	83312300	A	3	12.15

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

SECTION 2

The manuals in this section are listed by Product or System Number. Many entries include a product to equipment cross reference; e.g. 1742 {CL309-A/B, FF511-A/B}. Since Hardware Manuals for equipment developed after November, 1967 are categorized by equipment designator, always look up the equipment designator in Section 1 as well as the Product Number.

TITLE	1	2	3	4
CYBER 72/73/74				
72-12 (6681-D, AA115-A, CC538-A/B)				
72-13 (6681-D, AA115-A, AT232-A, CC538-A/B)				
72-14 (6681-D, AA115-A, AT231-A, AT232-A, CC538-A/B)				
72-16 (6681-D, AA115-A, AT231-A, AT232-A, AT237-A, CC538-A/B)				
72-18 (6681-D, AA115-A, AT231-A, AT232-A, AT236-A, AT237-A, CC538-A/B)				
72-24 (6681-D, AA115-A, AT227-A, AT231-A, AT232-A, CC538-A/B)				
72-26 (6681-D, AA115-A, AT227-A, AT231-A, AT232-A, AT237-A, CC538-A/B)				
72-28 (6681-D, AA115-A, AT227-A, AT231-A, AT232-A, AT236-A, AT237-A, CC538-A/B)				
73-12 (6681-D, AA115-A, AT226-A, CC538-A/B)				
73-13 (6681-D, AA115-A, AT226-A, AT232-A, CC538-A/B)				
73-14 (6681-D, AA115-A, AT226-A, AT231-A, AT232-A, CC538-A/B)				
73-16 (6681-D, AA115-A, AT226-A, AT231-A, AT232-A, AT237-A, CC538-A/B)				
73-18 (6681-D, AA115-A, AT226-A, AT231-A, AT232-A, AT236-A, AT237-A, CC538-A/B)				
73-24 (6681-D, AA115-A, AT226-A, AT227-A, AT231-A, AT232-A, CC538-A/B)				
73-26 (6681-D, AA115-A, AT226-A, AT227-A, AT231-A, AT232-A, AT237-A, CC538-A/B)				
73-28 (6681-D, AA115-A, AT226-A, AT227-A, AT231-A, AT232-A, AT236-A, AT237-A, CC538-A/B)				
74-12 (6681-D, AA117-A, BR397-A, CC538-A/B)				
74-13 (6681-D, AA117-A, AT239-A, BR397-A, CC538-A/B)				
74-14 (6681-D, AA117-A, CC538-A/B)				
74-16 (6681-D, AA117-A, AT237-A, CC538-A/B)				
74-18 (6681-D, AA117-A, AT236-A, AT237-A, CC538-A/B)				
74-24 (6681-D, AA117-A, AE116-D, CC538-A/B)				
74-26 (6681-D, AA117-A, AE116-D, AT237-A, CC538-A/B)				
74-28 (6681-D, AA117-A, AE116-D, AT236-A, AT237-A, CC538-A/B)				
REFERENCE MANUALS (HARDWARE)				
ORDER VOL.2 AND APPROPRIATE VOL 1 FOR A				
COMPLETE REFERENCE MANUAL. ORDER VOL.3				
IF SYSTEM CONTAINS FCS.				
MODEL 72 SYS DESC/PROGRAMMING INFO-VOL 1	60347000	H	22	01.05
MODEL 73 SYS DESC/PROGRAMMING INFO-VOL 1	60347200	E	22	01.20

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
MODEL 74 SYS DESC/PROGRAMMING INFO-VOL I	60347400	K	22	02.05
MODEL 72/73/74 INSTRUCTION DESC. VOL 2	60347300	J	22	01.25
MODEL 72/73/74 ECS DESC/PROGRAMMING VOL 3	60347100	D	22	01.00
MODEL 72/73/74 INPUT/OUTPUT SPECIFICATIONS (INCLUDES 6000)	60352500	E	22	01.00
CYBER 76				
76-111 (AA106-A, AB101-A, GH506-A/B, GE226-A/B, GH214-C/D, CC522-A/B, CE149-A/B AT311-A)				
76-112 (AA106-A, AB101-A, GH506-A/B, GE226-A/B, GH214-C/D, CC522-A/B, CE149-A/B AT311-A, BB360-B)				
76-121 (AA106-A, AB101-A, GH506-A/B, GE226-A/B, GH214-C/D, CC522-A/B, CE149-A/B AT311-A, BS101-A)				
76-122 (AA106-A, AB101-A, GH506-A/B, GE226-A/B, GH214-C/D, CC522-A/B, CE149-A/B AT311-A, BS101-A, BB360-B)				
76-142 (AA106-A, AB101-A, GH506-A/B, GE226-A/B, GH223-A, CC522-A/B, CE149-A/B, BS101-A, BS102-A, BB360-B, AT311-A)				
REF MANUAL (HARDWARE)	60367200	C	22	06.70
SMMV3 REFERENCE MANUAL VOLS 1,2,3 (INC.7600)	60373900	C	22	45.00
I/O SPECIFICATIONS (INCLUDES 7600)	60408700	B	22	01.00
CYBER 172/173/174 COMPUTER SYSTEMS				
INPUT/OUTPUT SPECIFICATIONS MANUAL (INCLUDES MODEL 175)	19983600	02	22	00.70
CYBER 175				
175-4 (AA120-A, GE258-A/B, CC545-A/B, GH223-A)				
175-6 (AA120-A, GE258-A/B, CC545-A/B, GH223-A, BS110-A)				
175-8 (AA120-A, GE258-A/B, CC545-A/B, GH223-A, BS107-A)				
175-12 (AA120-A, GE258-A/B, CC545-A/B, GH223-A, BS107-A)				
175-16 (AA120-A, GE258-A/B, CC545-A/B, GH223-A, BS107-A)				
HARDWARE REFERENCE MANUAL INPUT/OUTPUT SPECS (SEE CYBER 172/173/174)	60420000	03	22	01.70
CYBER 1000 HARDWARE SEE DW105-A, DY121/122/123 124/127/129				
G-15 COMPUTER REFERENCE MANUALS				
DIGITAL COMPUTER SYSTEM MANUAL	60061300			02.00
INTERCOM 1000 INSTRUCTION CARD (G-15)	60062300			00.50

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
OPERATION MANUAL	60062400			02.20
PA-3 GRAPH PLOTTER REFERENCE	60181800			03.00
PROGRAMMING MANUAL	60062500			07.00
REFERENCE CARD (PAPER STOCK) (G-15)	60062600			00.50
REFERENCE CARD (PLASTIC STOCK) (G15)	60062600			00.75
CUSTOMER ENGINEERING MANUALS				
PARTS MANUAL	60061400			04.30
CE DIAGRAMS	60063000	A		03.60
CA-2 CARD ACCESSORY (AET-01631)	60063100	A		08.00
AN-1 ALPHANUMERIC ACCESSORY MANUAL	60064000			03.50
DA-1 DIFFERENTIAL ANALYZER	60064800			05.00
DIAPER (DIAGNOSTIC ROUTINES)	60064900			10.00
ANC-2 ALPHANUMERIC COUPLER	60065000			03.20
PA-3 GRAPH PLOTTER	60104500			04.20
THEORY OF OPERATION AND SIMPLIFIED DRAWINGS	60121600		22	12.75
DIGITAL MAGNETIC TAPE HANDLER (POTTER MODEL MTA) (902) INSTRUCTION MANUAL INCLUDING MTA-2 PARTS LIST	60124600			01.20
MTA-2 MAGNETIC TAPE UNIT ACCESSORY	AEG05571		22	03.45
PR-2 PHOTOELECTRIC TAPE READER	AET01621	A		06.60
MTA-2 MAGNETIC TAPE ACCESSORY	AET05613			03.50
PTP-1 PAPER TAPE PUNCH	AET09611			05.40
ANC-1 (OUTLINE, DISCUSSION, INSTALLATION AND DRAWINGS)				
(THE FOLLOWING MANUALS FOR THE ABOVE G-15 COMPUTER PRODUCT LINE ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY. PRICE AVAILABLE UPON REQUEST				
SERVICE MANUAL MTA-3 (AET-5611)	60164600			
SERVICE MANUAL MTA-4 (AET-10621)	60164700			
OPERATORS MANUAL MTA-4 (AEG-10621)	60164800			
G-20 COMPUTER REFERENCE MANUALS				
CONTROL BUFFER/MACHINE LANGUAGE (CB-11)	60061800			05.20
GENERAL REFERENCE MANUAL	60061000	A	22	08.00
OPERATING MANUAL	60061700			12.20
REFERENCE CARD (G-20)				
CUSTOMER ENGINEERING MANUALS				
88 SERVICE MANUAL	BER05625			07.00
1402 CARD READER/PUNCH REFR/INSTRUCTION	60063200			08.50
LP-12 HIGH SPEED PRINTER (INCL. DIAGRAMS)	60062900			10.00
PC-10 CARD PRINTER COUPLER SERVICE	BER11621		22	10.05
CB-11 BUFFER CONTROL CE DIAGRAMS	60063400	A	34	03.25
CB-11 CONTROL BUFFER/SERVICE MANUAL VOL 1	60063700			10.00
CB-11 CONTROL BUFFER/SERVICE MANUAL VOL 2	60063800			05.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
ENGINEERING DESIGN HANDBOOK FOR THE G-20 PT-10 SERVICE MANUAL (BER07621)	60129400 60042800		22	04.50 04.60
(THE FOLLOWING MANUALS FOR THE ABOVE G-20 COMPUTER PRODUCT LINE ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY. PRICE AVAILABLE UPON REQUEST				
MT-10 DIAGRAMS	60063500			
MM-10 DIAGRAMS	60064400			
LP-10 DIAGRAMS	60064500			
PC-10 DIAGRAMS	60064300			
PT-10 DIAGRAMS	60064600			
CC-10 DIAGRAMS	60064700			
G-20 CENTRAL PROC. SERVICE MANUAL VOL. 1 (BER-10622)	60211400			
G-20 CENTRAL PROC. SERVICE MANUAL VOL. 2	60211500			
LINE PRINTER EQUIPMENT (1742,3010,3254,8130 PRODUCT) CE MANUAL	47967000	F	22	08.25
LGP 21 COMPUTER SYSTEM				
MAINTENANCE AND TRAINING MANUAL (INCLUDES TALLY TAPE READER, TALLY TAPE PERFORATOR AND MODEL 101 VISUAL OSCILLOSCOPE DISPLAY)	ESD10600	-	22	07.00
PROGRAMMING MANUAL	SC200100			03.00
REFERENCE MANUAL	SC2000			02.55
LGP 30 COMPUTER SYSTEM				
MAINTENANCE MANUAL	ESD10400		3	06.35
OPERATIONS MANUAL	SC0633			01.00
PROGRAMMING CLASS NOTES	SC0001			02.00
PROGRAMMING MANUAL	SC0576			06.00
RPC 4000 MAINTENANCE AND TRAINING MANUAL MANUAL (INCLUDES RPC 4010 AND RPC 4500)	ESD10501			12.00
REFERENCE MANUAL	SC4006			12.00
RPC 4290 TRANSLATOR MAINT AND TRAINING MANUAL (INCLUDES RPC 4410,4435,4440,180 AND 891)	ESD10505			15.75
SCM-M-120 PRINTER AND 1095-D PRINTER ADAPTER REF/CE MANUAL	41605900	C	22	04.25
0101 BADGE READER AND ADAPTER REFERENCE MAN. CE DIAGRAMS	36818300 36818500	B C	22 22	01.75 02.00
0101-R/D BADGE READER 2010 BADGE READER ADAPTER DIAGRAMS	65715000	B	22	01.40
ILLUSTRATED PARTS MANUAL	65715100	B	22	01.60
MAINTENANCE MANUAL	65714900	A	22	01.80

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
0101-C/0107-B BADGE READER REFERENCE MANUAL CE MANUAL	13792800 13792000	A H	22	01.10 02.25
0120-C SCALE ADAPTER REFERENCE/CE MANUAL	13794900	A	22	03.50
0202 REMOTE TERMINAL HARDWARE REF/CE MANUAL	65739900	B	22	10.00
101-1 (DJ141-A) SYNCHRONOUS MODEM				
124-1 (DJ140-A/B) SYNCHRONOUS MODEM				
150-A CARD TESTER (THE FOLLOWING MANUAL FOR THE 150-A CARD TESTER IS AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST REFERENCE/INSTRUCTION AND DIAGRAMS MANUAL	60002600			
151-A CARD TESTER INSTRUCTION MANUAL	60018400	B		15.45
152 CARD TESTER MOD A CE MAINTENANCE MANUAL ILLUSTRATED PARTS LIST, MOD A (6/65)	40814400 40812800	A	22	09.75 03.50
160-B COMPUTER (FORMERLY 160 COMPUTER) REFERENCE MAN COMPUTER SYSTEM COMPUTING CENTER OPERATION DESCRIPTION AND OPERATION VOL 1 INSTALLATION MAN INSTRUCTION CARD (PLASTIC) SATELLITE PROGRAMMING MAN	60002300 60020900 60006800 60007200 60070100 60018700	C B	 22	 03.75 03.25 07.75 03.25 00.75 02.40
CUSTOMER ENGINEERING MANUALS CARD PLACEMENT AND EQUATION SUMMARY CARD PLACEMENT AND EQUATIONS (SERIALS 0-33) CE DIAGRAMS CE DIAGRAMS (SERIALS 0-30) VOL 2 MAINTENANCE PERIPHERAL EQUIPMENT CODES STAND ALONE DIAGNOSTIC SYSTEM REFERENCE MAN.	60007100 60185500 60007000 60150900 60006900 60024900 60270200	C A F A B A	22 22 34 34 22	04.75 04.90 03.00 02.20 06.00 01.35 07.30
160-A COMPUTER PROGRAMMING PRIMER OF MESSAGE SWITCHING SYSTEMS 160-A INSTRUCTION CARDS REFERENCE MANUAL (COMPUTER) SPECIFICATION (I/O) STAND ALONE DIAGNOSTIC SYSTEM (SAD) VOLS. I, II, III REFERENCE MANUAL INSTALLATION MANUAL	36810300 60070200 60014500 60002500 60272200 60018500	 A G F A	 22 22 22	 01.75 00.75 01.65 02.00 30.00 02.70

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CUSTOMER ENGINEERING MANUALS				
160-A WIRE LISTS	24107700	E	22	07.80
160-A CHANNEL ADAPTER OPERATION AND MAINT.	39072500			01.60
BUFFER CHANNEL LONG LINE DRIVE CE MANUAL	60123600	A		01.00
CARD PLACEMENT AND EQUATION SUMMARY	60014300	L	22	05.80
CE INSTRUCTION MANUAL-PART 1, THEO OF OPER	60014000	E	22	14.10
CE DIAGRAMS	60014200	R	22	02.40
DESC, OPERATION, MAINT.(PARTS LIST) CE MAN.	60014100	D	22	03.25
MASTER CONTROL SYSTEM MAINT MONITOR VOL 1	60104600	D	22	12.00
MASTER CONTROL SYSTEM MAINT MONITOR VOL 2	60104700	C	22	04.90
MASTER CONTROL SYSTEM MAINT MONITOR PROGRAM	60112800	G	22	45.00
LISTINGS VOLS 1 AND 2				
CHECKING PULSE WIDTHS ON 160-A/169 CLOCKED	60119100			01.50
INVERTER CARDS				
161-A/B ON-LINE INPUT/OUTPUT TYPEWRITER				
REFERENCE/INSTRUCTION MANUAL	60007300	S		02.60
CARD PLACEMENT AND EQUATION SUMMARY	60103900	F,G	22	02.00
CE DIAGRAMS (WITHOUT ECN 10) MANUAL	60105400	A	22	01.00
LONG LINE DRIVERS FOR 161 TYPEWRITER	60124100	B	22	01.00
WIRE LIST	60116600	C	22	01.25
161-F ON LINE I/O FLEXOWRITER				
REFERENCE/INSTRUCTION MANUAL	60029100	C	22	02.40
CARD PLACEMENT AND EQUATION SUMMARY	60041400	B	22	02.80
161-G TYPEWRITER				
REFERENCE/INSTRUCTION MANUAL	60094800	B		03.00
(THE FOLLOWING MANUAL FOR THE 161-G IS AVAIL- ABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST				
CARD PLACEMENT AND EQUATION SUMMARY	60141600	C	22	
162 MAGNETIC TAPE SYNCHRONIZERS				
REFERENCE MANUALS				
162(S) REFERENCE MANUAL	60023000			02.25
162-1/162-2 REFERENCE MANUAL	60025800	E	22	04.25
162-1B/162-2B/162-3B REF/INST MANUAL	60100200	B	22	06.25
CUSTOMER ENGINEERING MANUALS				
162(S) CE DIAGRAMS	60026000	E	34	03.00
162(S) CE MANUAL	60026500		22	03.00
162(S) CARD PLACEMENT AND EQUATION SUMMARY	60026800	E	22	03.60
162-1 DIAGRAMS	60026100	M	22	03.05
162-1-A CARD PLACEMENT AND EQUATION SUMMARY	60026900	L	22	05.25
162-1-P CE DIAGRAMS	60104200	J	34	03.00
162-2 DIAGRAMS	60026200	M	34	01.50

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
162-2 CARD PLACEMENT AND EQUATION SUMMARY	60027000	K	22	03.40
162-2-A/H WIRE LIST	60151800	G	22	05.00
162-2-B/G CE DIAGRAMS	60104300	H	34	02.10
162-1-H/162-2-H REF/CE MANUAL DESCRIPTION OPERATION, PROGRAMMING, DIAGRAMS AND P/L	60095000	K	22	08.00
162-3-B/G CE DIAGRAMS	60104400	K	34	03.85
162-1,2,3-B/G CARD PLACEMENT AND EQUATION SUMMARY	60129300	K	22	05.30
NORMAL CHANNEL LONG LINE DRIVERS	60123900	A	22	01.50
(THE FOLLOWING MANUALS FOR THE 162 PRODUCT LINE ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST				
162-2-H CARD PLACEMENT AND EQUATION SUMMARY	60141500	H	22	
CARD PLACEMENT AND EQUATION SUMMARY	60022200	B		
163-A MAGNETIC TAPE SYSTEM				
VOL I REFERENCE/INSTRUCTION MANUAL	60007400	C	22	07.25
163 CE DIAGRAMS	60007500	F	34	05.00
CARD PLACEMENT AND EQUATION SUMMARY	60007600	D	22	05.35
CROSS TABS	60116200		22	07.60
164-A MAGNETIC TAPE SYSTEM				
CE DIAGRAMS	60007800	C	34	04.75
VOL I DESCRIPTION, OPERATION AND MAINTENANCE	60007700	A		03.00
CARD PLACEMENT AND EQUATION SUMMARY	60007900	A	22	04.90
165/165-2 INCREMENTAL PLOTTER				
INSTRUCTION MANUAL	60013900	D		02.60
CARD PLACEMENT AND EQUATION SUMMARY	60119200	A	22	01.50
WIRE LIST, 165-B/G	60151500	C	22	03.00
165-G INCREMENTAL PLOTTER				
REFERENCE/INSTRUCTION MANUAL	60094900	B		03.80
CARD PLACEMENT AND EQUATION SUMMARY	60141400	A	22	01.70
WIRE LIST (SEE 165/165-2)				
166-2 LINE PRINTER				
NORMAL CHANNEL LONG LINE DRIVERS CE MANUAL	60124000	A	22	01.00
REFERENCE/INSTRUCTION MANUAL	60019500	F	22	10.25
CE DIAGRAMS	60022500	R	34	01.30
CARD PLACEMENT AND EQUATION SUMMARY	60102500	J	22	04.00
WIRE LISTS, CROSS TABS	60116400	C	22	03.90
H207 LINE PRINTER REFERENCE/INSTRUCTION MAN.	60109800	B	22	04.80
167-1 CARD READER REFERENCE/INSTRUCTION	60019400	E	22	04.00
167-2-A CARD READER REFERENCE/INSTRUCTION AND DIAGRAMS MANUAL	60022000	D	22	06.50
CARD READER LONG LINE DRIVERS	60124300	C	22	01.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
(THE FOLLOWING MANUAL FOR THE 167-2-A CARD READER IS AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST CARD PLACEMENT AND EQUATION SUMMARY	60022200	B		
168-1-A AUXILIARY ARITHMETIC UNIT VOL.1, DESCRIPTION, OPERATION AND MAINTENANCE MANUAL	60021600	A		04.00
CARD PLACEMENT AND EQUATION SUMMARY	60021700	A	22	04.20
CROSS TABS	60112700		22	05.80
168-2-A AUXILIARY ARITHMETIC UNIT REFERENCE/INSTRUCTION MANUAL	60023800	D	22	03.40
VOL 2 DIAGRAMS	60023900	B	34	04.00
AUX. ARITH. UNIT CARD PLGMT. AND EQ. SUMMARY	60024000	A	22	04.50
169-A AUXILIARY MEMORY UNIT REFERENCE/INSTRUCTION MANUAL	60014400	D	22	07.00
CE DIAGRAMS	60022300	H	22	04.70
CARD PLACEMENT AND EQUATION SUMMARY	60022400	F	22	05.80
CROSS TABS	60116300	A	22	08.30
CHECKING PULSE WIDTHS ON 160-A/169 CARDS	60119100		22	01.50
EXTERNAL BUFFER CHANNEL LONG LINE DRIVERS CE MANUAL	60123800	A	22	01.00
170-A CARD PUNCH CONTROLLER REFERENCE/INSTRUCTION MANUAL	60021800	A	22	02.65
CARD PLACEMENT AND EQUATION SUMMARY	60090200	D	22	03.70
CE DIAGRAMS MANUAL	60021900	E	34	04.80
CROSS TABS, 170-B/G	60151200	D	22	03.55
(THE FOLLOWING MANUAL FOR THE 170-A CARD PUNCH CONTR. IS AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY) PRICE AVAILABLE UPON REQUEST CARD PUNCH CONTROLLER LONG LINE DRIVERS	60123700	A		
170-G CARD PUNCH CONTROLLER REFERENCE/INSTRUCTION MANUAL	60095400	E	22	04.00
CROSS TABS (SEE 170-A)				
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) CARD PLACEMENT AND EQUATION SUMMARY	60141300	G	22	
174-G PAPER TAPE READER/PUNCH CE MANUAL	60121100	H	22	02.95
177-A/R CARD READER CONTROLLER				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.

4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
REFERENCE/INSTRUCTION MANUAL	60049100	D	22	01.50
CARD PLACEMENT AND EQUATION SUMMARY	60122600	A	22	02.50
SUMMARY				
WIRE LIST AND CABLE TABS, 177-8/G	60151700	B	22	02.00
177-G CARD READER CONTROLLER				
REFERENCE INSTRUCTION MANUAL	60095200	E		04.25
WIRE LIST AND CABLE TABS (SEE 177-A/B)				
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT				
ARE AVAILABLE ON A SPECIAL ORDER BASIS IN				
MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4				
WEEKS FOR PROCESSING AND DELIVERY.)				
CARD PLACEMENT AND EQUATION SUMMARY	60141200	A	22	
180 DATA COLLECTOR				
DIAGRAMS AND WIRE LIST OF MANUAL	40808300		22	02.00
210 ANALOG TO DIGITAL CONVERTER				
OPERATIONS AND MAINT INSTRUCTION MANUAL	39074700		3	01.45
217-2/FC11-B				
DISPLAY STATION FOR USE WITH 217-2 EQUIPMENT	82128800	A00	22	01.00
CONTROLLER PARTS DATA BOOK (INCLUDES INFO O				
CC505-A, CC505-B)				
218-1 TYPEWRITER STATION PARTS DATA BOOK	82128900	A00	22	01.00
(INCLUDES INFO ON CK105-A AND CK105-B)				
222 (CL401-A/B, CL402-A/B) LINE PRINTER				
CONTROLLER				
224 (CE152) CARD READER				
224-2 (CE304) CARD READER				
224-2A (CE306) CARD READER				
226-1 (CF105) CARD PUNCH				
250-2 DISPLAY SUBSYSTEM HARDWARE REF. MANUAL	82129000	A00	22	03.80
252-2 DISPLAY CONSOLE (REV. 0-3)	82129700	A00		04.40
271 DIGIGRAPHICS CONTROLLER REFERENCE MANUAL	60181400			05.75
273 DIGIGRAPHIC CONSOLE REFERENCE/CE MANUAL	60188600	A	22	08.00
274 DIGIGRAPHIC CONSOLE GEN DESC, THEO OF OP,	60279100	A	22	04.95
DIAGS, MAINT, P/L REFERENCE/CE MANUAL				
275 DIGIGRAPHIC SYSTEM				
DIGIGRAPHIC MAN-MACHINE SYSTEMS 275 BUFFER	60181300	A	22	03.75

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
MEMORY REFERENCE MANUAL				
302 COMMUNICATIONS EXPANSION MOD REF/CE MAN	13796100	A	22	02.70
303-1 (GG105-A) COMMUNICATIONS EXPANSION UNIT REFERENCE MANUAL	13797400	A	22	01.20
304-1 (DJ805-A/B) COMMUNICATIONS MULTIPLEXER REFERENCE MANUAL	13796400	D	22	01.00
311-B DATA SET ADAPTER EQUATION FILE AND WIRE LIST CE MANUAL	36824400	B	22	04.55
311-2 (DJ110-A/DJ111-A) DATA SET ADAPTER REFERENCE MANUAL	41602400	A	22	01.00
311-3 COMMUNICATIONS ADAPTER REF INFO (USE 361-5)				
312-2 DATA SET ADAPTER REFERENCE MANUAL	41609000	A	22	02.70
313 (8536-C/8537-C/FJ413-A/FJ414-A) DATA SET ADAPTER REFERENCE MANUAL	13798400	A	22	01.00
314 (8536-C/8537-C/FJ413-A/FJ414-A) DATA SET ADAPTER REFERENCE MANUAL	13798500	A	22	01.00
317 (8536-D/8537-D/FJ413-A/FJ414-A) DATA SET ADAPTER REFERENCE MANUAL	13798600	B	22	01.00
318 (8536-D/8537-D/FJ413-A/FJ414-A) DATA SET ADAPTER REFERENCE MANUAL	13798700	B	22	04.30
321 (8518-C/8519-D) TELETYPEWRITER TERMINAL UNIT REFERENCE MANUAL	13799300	A	22	03.50
323 (8518-C/8519-D) TELETYPEWRITER TERMINAL UNIT (USE 321 REFERENCE MANUAL)				
326-C TRUNK LINE ADAPTER THEORY OF OPERATION, MAINTENANCE, PROGRAMMING, CARD PLACEMENT, PARTS LISTS, DIAGRAMS REFERENCE/CE MANUAL	36829000	A	22	02.25
OPERATION, INSTALLATION, MAINTENANCE CE MAN	36824800	A	22	01.50
327 DATA SET ADAPTER CE MANUAL	36824700	A	22	07.05
327-2 (DJ101-A, DJ115-A) DATA SET ADAPTER REFERENCE MANUAL	41600500	A	22	01.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
330 (8536-D/8537-D) DATA SET ADAPTER REFERENCE MANUAL	13798300	B	22	01.00
331 (8536-/8537-E) DATA SET ADAPTER REFERENCE MANUAL	41607100	A	22	01.00
332-1 (8536-C/8537-C) DATA SET ADAPTER REFERENCE MANUAL	13798200	A	22	01.00
350 PAPER TAPE READER/REFERENCE MANUAL MOD C-G REFERENCE MANUAL MOD A AND B DIAGRAMS AND WIRE LIST, MOD J,K,L,M MAINTENANCE MANUAL MOD J,K,L,M,N,P,R,S,T,U PARTS LIST (MOD A THRU U)	40801200 PED 108A 40808000 40813100 40861900	A B B B	22 22 22 22	01.25 01.60 01.50 01.90 02.00
358-1 (DJ112-A/B) TRANSCEIVER REF MANUAL	41605300	B	22	01.00
358-2 (DJ113-A/B) TRANSCEIVER REF MANUAL	41606200	B	22	01.00
358-3 (DJ114-A/B) TRANSCEIVER REFERENCE MANUAL	41601800	C	22	01.00
360-65+/67+ MEMORY SYSTEM DIAGNOSTIC PACKAGE USERS GUIDE	75400200	A	3	17.25
358-4 (DJ114-C/D) TRANSCEIVER REF INFO (USE 358-3)				
361-1 (DJ142-A, DJ143-A) COMMUNICATIONS ADAPTER REFERENCE MANUAL	41612200	C	22	01.00
361-2 (DJ143-A) COMMUNICATIONS ADAPTER REF INFO (USE 361-1)				
361-3 (DJ142-A) COMMUNICATIONS ADAPTER REF INFO (USE 361-1)				
361-4 (DJ122-A) COMMUNICATIONS ADAPTER REFERENCE MANUAL	41609600	A	22	03.40
361-5 (DJ144-A) COMMUNICATIONS ADAPTER REFERENCE MANUAL	41611800	C	22	02.65
361-6 (DJ145-A) COMMUNICATIONS ADAPTER REFERENCE MANUAL	41612000	B	22	01.60
361-7 (DJ146-A) COMMUNICATIONS ADAPTER REFERENCE MANUAL	41612400	A	22	01.00
362-1 (GH407-A/B, DK509-A/B) TELEGRAPHIC LEVEL CONVERTER				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
REFERENCE MANUAL	41610500	A	22	01.00
362-2 (DK509-A/B) TELEGRAPHIC LEVEL CONVERTER REF INFO (USE 362-1)				
364-1/2 (DJ808-A, GD306-A/B, GH407-A/B) COMMUNICATIONS MULTIPLEXER REFERENCE MANUAL	41610900	A	22	01.00
364-3 (DJ813-A) COMMUNICATIONS MULTIPLEXER REFERENCE MANUAL	41612500	A	22	01.00
364-4 (DJ814-A, GD306-A/B, GH407-A/B) COMMUNICATION MULTIPLEXER REFERENCE MANUAL	41612700	B	22	01.00
364-5 (DJ814-A) COMMUNICATION MULTIPLEXER REF INFO (USE 364-4)				
370 PAPER TAPE READER DIAGRAMS, C/P, W/L, MODS A01-B01 AND ABOVE MAINTENANCE MANUAL MOD A AND B (6166) PARTS LIST MOD A AND B	40864900 40823900 40829400	B A D	22 22 22	01.00 01.25 01.50
402M ANALOG MULTIPLEXER OPER AND MAINT INSTR	39074900			01.65
405 HIGH SPEED CARD READER REFERENCE MANUAL A/B APENDIX FOR C, D, J AND K PARTS LIST MOD A THRU D SUPPLEMENTAL MANUAL (MOD D)	40809300 40825200 49750900	J L B	22 22 22	02.25 03.40 02.35
405 PL-10 CARD READER CE156 PARTS DATA CE MAN	49755400	A	22	04.50
407 (CE149) CARD READER				
415 CARD PUNCH ILLUSTRATED PARTS LIST MOD A AND B DIAGRAMS, THEO OF OPER., GEN DESC CE/REF MAN	40820200 49755300	G C	22 22	02.50 11.15
415-PL-10 CARD PUNCH (CF109) PARTS DATA CE MAN	49755500	A	22	04.75
415-30 (CH102-A/B, FE202-A/B) CARD PUNCH AND CONTROLLEP				
417-1 (CF108-A/B, FE201-A) CARD PUNCH WITH CONTROLLER				
430 (CF504) CARD READ-PUNCH				
430 PL-10 CARD READER-PUNCH (CF511) PARTS DATA	49755900	01	22	04.90
469 COMPUTER SYSTEM 462-01A/02A TELETYPE CONTROLLERS	14060200		22	08.60

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
501 AND 505 HIGH SPEED LINE PRINTER				
501 REFERENCE MANUAL MOD A AND B	40805000		22	02.50
ILLUSTRATED PARTS LIST (501 MODS C/D, 505 MODS A/B)	50581600	A	22	02.35
501 HIGH SPEED LINE PRINTER REFERENCE MANUAL (MOD C AND D)	40807200		22	01.45
505 HIGH SPEED LINE PRINTER REF. MOD A/B	40820800	A	22	02.50
CUSTOMER ENGINEERING MANUALS				
ILLUSTRATED PARTS LIST, MOD A AND B (501)	40815200	A	34	04.70
DIAGRAMS AND C/P (501 MOD C07-C14/D01-D08, 505 MOD A07-A14/B01-B07)	40861700	B	22	01.80
DIAGRAMS AND C/P (501 MOD C01-C06, 505 MOD A01-A06)	40861800	A		02.10
DIAGRAMS AND C/P (501 MOD A01-A07, B01-B06)	40862000	A	22	01.45
DIAGRAMS AND C/P (501 MOD A08-A09, B07 AND B08)	40862100	B	22	02.50
DIAGRAMS AND CARD PLACEMENT (501 MOD A10-A11 B09-B10)	40862200	A	22	01.40
512 (CL601) LINE PRINTER				
517 (CL835) LINE PRINTER				
580 LINE PRINTER EQUIPMENT				
INTRODUCTION, ASSEMBLY PARTS LIST, PRINTED CIRCUIT CARDS, USED-ON INDEX PART I.D. MAN. CONTROLS AND INDICATORS, OPERATING PROCEDURE	91858900	A	22	08.10
OPERATOR MAINTENANCE OPERATORS HANDBOOK	91860400	B	22	01.55
GEN. DESC., OPERATION AND PROGRAMMING, THEORY OF OPERATION, MAINTENANCE, PARTS DATA CE MAN	91859000	C	22	02.35
INTRODUCTION, OPERATING INSTRUCTIONS, PRINCIPLES OF OPERATIONS REFERENCE MANUAL	91858600	B	22	08.90
INSTALLATION AND CHECKOUT, PREVENTIVE/CORRECTIVE MAINTENANCE, PARTS REPLACEMENT FIELD SERVICE MANUAL VOL.1	91858700	B	22	13.35
FIELD SERVICE MANUAL VOLUME II	91858800	B01	22	
595 PRINT CARTRIDGE HARDWARE REFERENCE/CE MAN. GEN DESC., THEO OF OPER., MAINT., PARTS DATA CE MANUAL	44855800	C	22	01.00
TYPE D MANUAL	50582200	D	22	01.00
	91860100	A	22	01.75
599 DRUM PRINTER TESTER MAINTENANCE MANUAL	40820500		22	04.05
601 MAGNETIC TAPE TRANSPORT				
DIAGRAMS AND WIRE LIST MOD A-B	40812400	B	22	02.15
MAINTENANCE MANUAL, MOD A AND B	40815300	G	22	02.40
PARTS LIST, MOD A, B AND C (4167)	40862700	A	22	01.85

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.

4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
602 MAGNETIC TAPE TRANSPORT				
MAINTENANCE MANUAL, MOD A AND B (11/65)	40815500	A	22	06.25
DIAGRAMS AND WIRE LIST, MOD A AND B	40815600	A	22	02.50
603 MAGNETIC TAPE TRANSPORT				
ILLUSTRATED PARTS LIST, MOD F, G, H AND J	40812700	D	22	06.80
ILLUSTRATED PARTS LIST	PE02003	A	22	05.00
MAINTENANCE MANUAL MODS A,B,C,D AND E (ECN21	40814800	C		03.60
MAINTENANCE MANUAL MOD F,G,H AND J (5165)	40812600	C	22	02.40
DIAGRAMS AND WIRE LIST, MOD A01-A04 (4/66)	40823000	B		03.00
DIAGRAMS AND WIRE LIST, MOD B-E (12/65)	40820300	B	22	02.35
DIAGRAMS AND WIRE LIST, MOD F-J (9/66)	40819400	B	22	02.80
604,606,607 MAGNETIC TAPE TRANSPORTS				
ILLUSTRATED PARTS LIST	40810800			11.20
DIAGRAMS AND WIRE LIST, MODS A,B,C,D AND E	40811500	B	22	09.60
MAINTENANCE MANUAL MODS A,B,C,D AND E	40812500	C	22	10.25
604-2 (8E101) MAGNETIC TAPE TRANSPORT				
605 MAGNETIC TAPE TRANSPORT				
MAINTENANCE MANUAL, MOD G (8/65)	40811800	1	22	04.00
ILLUSTRATED PARTS LIST MOD G	40811900		3	03.50
DIAGRAMS AND WIPE LIST, MOD G (8/65)	40815400	B	22	05.30
606 MAGNETIC TAPE TRANSPORT				
CE MAINTENANCE MANUAL, MOD G,H,J,K,L	40811400	03		01.50
DIAGRAMS AND WIRE LIST, MOD G-L	40812000	C	22	02.60
MAINTENANCE MANUAL, MOD C AND E (11/65)	40816500	1	22	03.00
MAINTENANCE MANUAL MOD B AND N (2/66)	40816800	1	22	03.00
DIAGRAMS AND WIRE LIST, MOD C-E (12/65)	40821200	B	22	04.00
DIAGRAMS AND WIRE LIST, MOD 1 AND 2 (2/66)	40822400	B	22	03.30
DIAGRAMS AND WIRE LIST, MOD N03-N05 (2/66)	40822500	B	22	03.30
607 MAGNETIC TAPE TRANSPORT				
MAINTENANCE MANUAL MODS A,B,C,D,E AND F	40815100	D	22	02.95
DIAGRAMS AND WIRE LIST MANUAL, MOD A-F	40821000	E	22	02.85
DIAGRAMS, WIPE LIST, CIRC. DESC., C/P CE MAN	49757600	A	22	01.95
607-2 (8E222) MAGNETIC TAPE TRANSPORT				
607 R MAGNETIC TAPE TRANSPORT MAINT CE MANUAL	49757500	A	22	04.00
608 (8F102) MAGNETIC TAPE TRANSPORT				
609 (8F401) MAGNETIC TAPE TRANSPORT				
612 MAGNETIC TAPE TRANSPORT				
MAINTENANCE MANUAL	40819500	1	22	04.80

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
626 MAGNETIC TAPE TRANSPORT ILLUSTRATED PARTS LIST, MOD B REFERENCE MANUAL, MOD B DIAGRAMS AND WIRE LIST MOD B,C,D,F,G (5/66)	PED2008 PED2214 40824000		3 22 22	04.50 05.00 05.00
627 MAGNETIC TAPE TRANSPORT ILLUSTRATED PARTS LIST, MOD A REFERENCE MANUAL, MOD A DIAGRAMS AND WIRE LIST MOD A01 AND ABOVE	40807700 40807800 40811200	01 E	3 3 22	03.50 08.00 04.00
636 COMPUTER PROGRAMMING MANUAL	22003300			04.00
657-1 (BE103) MAGNETIC TAPE TRANSPORT				
657-2 (BE104) MAGNETIC TAPE TRANSPORT				
657-3 (BE223) MAGNETIC TAPE TRANSPORT				
657-4 (BF224) MAGNETIC TAPE TRANSPORT				
659-1 (BF406) MAGNETIC TAPE TRANSPORT				
659-3 (BE408) MAGNETIC TAPE TRANSPORT				
659-4 (BE409) MAGNETIC TAPE TRANSPORT				
66X PSDG FIELD SERVICE MANUAL	49751400	E	22	11.60
671 MAGNETIC TAPE TRANSPORT EXERCISER REFERENCE MANUAL DIAGRAMS, C/P, WIRE LIST MOD A01 AND ABOVE PARTS LIST MOD A	40814200 40817200 40822000	A C A	22 22 22	01.50 01.00 01.25
673 (GK102) TAPE EXERCISER				
680 MAGNETIC TAPE CERTIFIER DIAGRAMS AND WIRE LIST MODS A,B DIAGS AND WIRE LIST MODS E-F MAINTENANCE MANUAL FOR MODS A THUR H PARTS LIST MODS A-D PARTS LIST MODS E-H	40822800 40862600 40822200 60188800 41240100	E E D B B	22 22 22 22 22	04.60 05.00 02.90 02.90 10.95
680,685,690 MAGNETIC TAPE CERTIFIERS TECHNICAL INFORMATION MANUAL	40822600			02.40
686 (GL102) TAPE CERTIFIER				
688 CLOSED LOOP AIR DUCT SYSTEM REFERENCE AND ILLUSTRATED PARTS LIST MANUAL	PED2216			04.50
689 TRANSPORT CHANNEL SWITCH/REFERENCE MOD A DIAGRAMS AND WIRE LIST, MOD A (1/165)	40807900 40809100	A A	22 22	02.00 02.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
690 MAGNETIC TAPE CERTIFIER TECHNICAL INFO MAN REFERENCE MANUAL, MOD B, C, D AND E	40803400			02.50
DIAGRAM AND WIRE LIST, MOD D AND E (7/65)	40816000	A	22	10.00
PARTS LIST, MODS B01-B03, C01-C03, D01-D04, E01-E04, F01-F04, G01-G04	40814600	C	22	04.15
	40814300	C	22	05.90
699 TAPE TRANSPORT EXERCISER/REFERENCE (MOD C) DIAGRAMS AND WIRE LIST MOD A, B AND F	40803200			04.25
MAINTENANCE MANUAL MODS A, B AND F	40809500	B	22	01.50
	40814500	A	22	01.00
720 DIGITAL COMMUNICATIONS TERMINAL CONTROL UNIT REFERENCE MANUAL	36814300			01.50
DIAGRAMS CE MANUAL	36823200		34	01.75
EQUATION FILE, CARD PLACEMENT, WIRE TABS, CABLE TABS, MAINTENANCE CE MANUAL	36817400	C	22	02.50
720-G DIGITAL COMMUNICATION TERMINAL CONTROL DIAGRAMS CE MANUAL	36823300		34	01.75
730-100 (BB372-A) MEMORY EXPANSION FOR MEDIUM AND SLOW SPEED BATCH STATIONS				
733-10 (CE125-A/B, CL503-A/B, DT208-A, FV218-A/B, FV433-A, FV435-A) HIGH SPEED BATCH SUBSYSTEM/TERMINAL FUNCTIONAL CHARACTERISTICS AND PROGRAMMING OPERATORS MANUAL	60329500	B	22	05.15
FOR BUFFER CONTROLLER DIAGNOSTIC LISTINGS SEE FR113-A - CATALOG SECTION 1	60399500	B	22	07.00
733-101 (CF111-A/B, FV437-A) CARD PUNCH				
733-110 (CL503-A/B, FV437-A) TERMINAL LINE PRINTER				
733-120 (CE125-A/B, FV437-A) TERMINAL CARD READER				
733-130 (DJ152-A) TERMINAL ADAPTOR				
733-140 (BB377-A) MEMORY INCREMENT				
733-150 (CA115-A, CC102-A/B, FV434-A, FV436-A) KEYBOARD-DISPLAY				
733-152 (CA115-A, CC102-A/B, FV434-A/B) KEYBOARD-DISPLAY				
781 MAGNETIC TAPE CLEANER - GEN DESC., THEORY OF OP., DIAGRAMS, MAINT. CE MANUAL	70611600	A	22	01.65
OPERATORS MANUAL	70611500	A	22	01.00
CE MANUAL	70616100	A	22	01.20
OPERATORS GUIDE	70616200	A	22	01.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
782 MAGNETIC TAPE CLEANER - GEN DESC., THEORY OF OP., DIAGRAMS, MAINT. CE MANUAL OPERATORS MANUAL	70611800	A	22	04.30
	70611700	A	22	01.00
783 MAGNETIC TAPE CLEANER - GEN DESC., THEORY OF OP., DIAGRAMS, MAINT. CE MANUAL OPERATORS MANUAL	70612000	A	22	02.00
	70611900	A	22	01.20
791-1 (DT137-A, DT138-A, DT139-A, FJ424-A/B/C) COMMUNICATIONS SUBSYSTEM REFERENCE MANUAL	60325100	B	22	03.35
807/808 DISK FILES--ALSO LISTED AS BH411/BH412 DIAGRAMS AND W/L MODS A01-A08, B02-B08 DIAGS AND WIRE LIST MODS A09 AND ABOVE MAINTENANCE MOD A PARTS LIST MOD A	40862500	R	22	12.90
	70605400	B	22	06.40
	40823400	D	22	09.20
	40824300	B	22	03.40
813/814 DISK FILE DIAGRAMS,C/P,WIRE LIST MODS A01-A05,B01-B05 DIAGRAMS AND WIRE LIST MODS A06, B06 MAINTENANCE MANUAL MODS A AND B PARTS LIST THEO OF OPERATION MAINTENANCE AIDS	40827500	J	22	04.10
	70601100	D	22	06.75
	40824800	E	22	07.30
	40863300	B	22	03.75
	40865200	B	22	02.50
817 DISK FILE--LISTED AS BH405				
821 DISK FILE--LISTED AS BH408 AND BH410				
828 DISK FILE CE INSTRUCTION MANUAL CE DIAGRAMS	60099400		22	05.80
	60099500		34	04.50
841 MULTIPLE DISK DRIVE REFER TO 8M101, 9M102, 8M103, 8M104				
844-2 () DISK STORAGE UNIT GENERAL INFO (USE 7054-1) OPERATION AND PROGRAMMING (USE 7054-1)				
852 DISK STORAGE DRIVE MAINTENANCE MANUAL MOD A/B PARTS LIST MOD A AND B DIAGRAMS AND WIRE LISTS MOD A AND B	40820000	B	22	06.00
	40825000	B		02.00
	40825100	H	22	05.40
853 DISK STORAGE DRIVE DIAGS AND W/L MODS A01-A09,B01-B09 DTAGS,CIR DES,C/P,W/L, MODS A10-A11,B10-B11 MAINTENANCE MANUAL MOD A,R MAINTENANCE MANUAL MODS A12, B12 AND ABOVE PARTS LIST MODS A01-A11,B01-B11 DIAGRAMS,CIPC DFSC., C/P, W/L MODS A12 PARTS LIST MODS A12 ABOVE B12 ABOVE	40825600	P	22	03.15
	41240900	F	22	02.50
	40823100	E	22	05.60
	41245700	C	22	05.50
	40826300	D	22	02.30
	41247300	E	22	02.50
	41244100	D	22	02.40

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
ABOVE, B12 AND ABOVE				
854 DISK STORAGE DRIVE				
DIAGRAMS AND WIRE LISTS MANUAL MODS A,B	40824900	W	22	01.95
DIAGS, CIRC., DESC. C/P, W/L MODS A10-A11, B10-B1	41241000	F	22	02.10
DIAGS, AND WIRE LIST MODS A12, B12	41247400	F	22	02.00
J12, K12				
MAINTENANCE MANUAL MODS A, B	40823200	E	22	02.10
MAINT. MAN. MOD A12, B12, AND ABOVE	41245800	E	22	03.80
PARTS LIST MOD A AND B	40826400	D	22	07.35
PARTS LIST MODS A12 AND ABOVE AND B12 ABOVE	41244200	E	22	01.80
857 DISK STORAGE DRIVE--LISTED AS BJ104				
861/863/865 DRUM STORAGE UNIT REFERENCE MANUAL (SEE 3000 PER EQUIP REF MANUAL REV J)				
861-B/863-B, 863-C/BG108-C DRUM STORAGE UNITS	60210300	D	22	10.10
DIAGS, CIRC DESC, MAINT, C/P, EQ SUMMARY W/L				
PARTS LIST	70606800	A	22	02.30
863-C DRUM STORAGE UNIT (USE BG108-C/D)				
865 DRUM STORAGE UNIT--LISTED AS BG113				
897 DISK FILE CLOCK/TRACK VERIFICATION ADDRESS	40862400	B	22	08.40
WRITER GEN. DESC. INST. AND CHKOUT. OPERATION				
DIAG. MAINT, MAINT P/DATA W/L CE MANUAL				
898 DISK STORAGE DRIVE EXERCISER CE MANUAL	40860400	C	22	06.70
MOD A AND B				
899 DISK STORAGE DR EXERCISER MAINT MANUAL	40860500	C	22	05.90
915 PAGE READER				
GRASP II (GENERALIZED READ AND SIMULATE	48704702	04	3	02.35
PROGRAM) A GENERALIZED DATA CAPTURING SYS.				
FOR 915 OCR PAGE READING SYSTEMS OPERATOR				
INFORMATION MANUAL				
GRASP - 8090/160-A OCR SOFTWARE REF MAN.	48996600	A	3	03.65
THEORY OF OPERATION MANUAL	48430170	A	3	01.20
PARTS LIST MODS C, D, E, F	40862900	B	22	05.00
PARTS LIST A/B SUPPLEMENT	40863900	A	22	04.00
915/919 OCR MEDIA MANUAL	91566700		3	06.50
915/1700 PAGE READER SETUP SOFTWARE REF MAN	48143910	02		01.30
921 DOCUMENT READER OCR MEDIA MANUAL	60216104	C	3	02.20
THEORY OF OPERATION	48780800	02	3	01.15
921/8092 OCR DOCUMENT READER	87900200			10.55
SYSTEM OPERATING AND PROGRAMMING GUIDE				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
924-A COMPUTER REFERENCE MANUALS				
PERIPHERAL EQUIPMENT CODES	60026700			01.50
I/O SPECIFICATION AND INSTALLATION REFERENCE MANUAL	60027100			03.00
INSTRUCTION CARD	60027400			03.75
	60070300			00.75
CUSTOMER ENGINEERING MANUALS				
CE DIAGRAMS	60027500	S	34	09.60
CE INSTRUCTION MANUAL	60094100	A	22	03.30
PARTS LIST CE MANUAL	60017300		22	06.70
924-B COMPUTER REFERENCE MANUALS				
I/O SPECIFICATION AND INSTALLATION REFERENCE MANUAL	60013700			03.75
	60016800	E	22	06.00
CUSTOMER ENGINEERING MANUALS				
CE MAINT/INSTRUCTION MANUAL	60017000	B	22	08.85
CE DIAGRAMS	60017100	F	34	10.00
925-A MAGNETIC TAPE CONTROLLER REFERENCE MANUAL	60029300	B		03.00
DIAGRAMS	60048900	G,H	34	01.75
CE INSTRUCTION MANUAL	60090300	A	22	04.65
CARD PLACEMENT, EQUATION SUMMARY	60287100	B	22	08.20
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)				
CARD PLACEMENT, CHASSIS 33 100	24105200	D		
CARD PLACEMENT, CHASSIS 33 200	24105300			
EQUATION SUMMARY	24106100	G		
925-S MAGNETIC TAPE SYNCHRONIZER CE INSTRUCTION AND REFERENCE MANUAL (REFER TO 925-A)				
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)				
CARD PLACEMENT	24345000	A		
CE DIAGRAMS	60106300	C	34	
926-A MAGNETIC TAPE CONTROLLER PRELIMINARY REFERENCE MANUAL	60044800	A		02.80
CE DIAGRAMS	60093100	E	34	03.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE INSTRUCTION MANUAL	60094600		22	02.40
929 OCR DOCUMENT READER THEORY OF OPERATION	91604200			01.50
MEDIA MANUAL	91604300	A	22	03.40
SYSTEMS OPERATORS GUIDE	87978800	A	22	02.60
935 OCR DOCUMENT READER SYSTEM REF/OPERATIONS MANUAL	60270700	01	22	06.50
936 SETUP REFERENCE MANUAL	48704810	04	3	03.00
OCR MEDIA MANUAL	60216101	02	3	03.15
OCR DOCUMENT READER THEORY OF OPERATIONS	48704850	02	3	03.60
DITO (DOCUMENT IN-TAPE OUT) OCR 1700/SC1700 COMPILER SYSTEMS SOFTWARE REF MAN	48781100	02	3	02.55
955 PAGE AND DOCUMENT READER CONTROLLER REFERENCE MANUAL	60324600	C	22	06.55
THEORY OF OPERATIONS	48430070	A	3	01.00
SYSTEMS OPERATORS GUIDE VOL.2	48643305	02	3	06.00
SETUP SOFTWARE REFERENCE MANUAL	48430050	03	3	01.80
955/959 PAGE AND DOCUMENT READER THEORY OF OPERATION	91604400			01.50
OCR MEDIA MANUAL	91604500	B	22	01.20
1010 INPUT STATION REFERENCE MANUAL	36817700	A	22	02.50
CE DIAGRAMS MANUAL	36817900	B	34	01.50
SUPPLEMENT TO DIAGRAMS MANUAL 36817900	65699100		34	01.00
ILLUSTRATED PARTS LIST	36820500		22	03.75
1020 INPUT STATION REFERENCE MANUAL	36818000	C	22	03.50
MAINTENANCE MANUAL	36818100	D	22	03.00
SUPPLEMENT I TO MAINTENANCE MAN - 36818100	36828600			01.00
DIAGRAMS	36818200	K	34	12.15
PARTS LIST	36820600	D	22	02.30
MULTI-WIRE SEARCH UNIT SUPPLEMENT	36824500		22	01.00
DIAGRAMS AND WIRE LIST SUPPLEMENT TO 1020/1021	36828700	B	34	02.85
1022/1023/2022 DATA COLLECTOR CONTR. REFERENCE	36826500		22	01.00
1025-E INPUT STATION REFERENCE MANUAL	13792900	B	22	01.00
CE MAINTENANCE CE MANUAL	13793000	D	22	03.00
ILLUSTRATED PARTS MANUAL	13797700	H	22	02.90
QSE 1257-A,B PRINTER STATION REF/CE MANUAL	82115700	B00	22	01.00
1500 INPUT/OUTPUT EQUIPMENT MANUALS				
DATA AND CONTROL TERMINAL (DCT 30) HARDWARE REFERENCE/CE MANUAL	84894200	A	22	07.00
PERIPHERAL EQUIPMENT SITE PREPARATION MAN.	39230300	C	22	05.25
REMOTE I/O SUBSYSTEM HDWF REF/CE MANUAL	39150100		22	10.35

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
TELEMETRY CONTROL CHANNEL/TELEMETRY DATA FORMATTER(TCC/TDF)OPER AND MAINT INSTR MAN	84837900		22	11.50
EB306 +128V (+100V) 15- BIT MULTIPLYING DIGITAL TO ANALOG CONVERTER HARDWARE REF./CE MANUAL	84937300	A	22	04.35
ED101-A, ED102-A, ED103-A HIGH LEVEL ANALOG MULTIPLEXER HOWE REF./CE MANUAL	39278700	A	3	01.20
1500 SERIES CONFIGURATOR	60187500			01.25
1501-10 (ED105-A) ANALOG INPUT MULTIPLEXER				
1501-11 (ED106-A) ANALOG INPUT MUX EXPANDER				
1525-2 (EA102-A) ANALOG TO DIGITAL CONVERTER				
1525-3 (EA309-A) ANALOG TO DIGITAL CONVERTER				
1530 ANALOG INPUT INTERFACE HRDW/REF/CE MAN	39153300	B	22	03.50
1530/1534 ANALOG INPUT CONTROLLER OPER AND MAINTENANCE INSTRUCTION	39073900	A		02.40
1531 MERCURY-WETTED RELAY MULTIPLEXER INCLUDING 1563 SIGNAL CONDITIONER HARDWARE REFERENCE/CUSTOMER ENGINEERING MANUAL	39074100	A	22	01.85
1533/1535/1563 RELAY MULTIPLEXER AND SIGNAL CONDITIONING UNIT	39074200	A	3	08.30
1534 ANALOG INPUT INTERFACE HARDWARE/REF. CE MANUAL	39153400	B	22	10.00
1538 HIGH SPEED, HIGH LEVEL ANALOG INPUT INTERFACE OPERATION AND MAINTENANCE	39074500	D	3	13.35
1544-1 (DA101-B) DIGITAL INPUT UNIT				
1544-2 (DA101-A) DIGITAL INPUT UNIT				
1544-3 (DA401-B) DIGITAL INPUT UNIT				
1544-4 (DA401-A) DIGITAL INPUT UNIT				
1544/1545/1564 DIGITAL INPUT SUBSYSTEM OPERATION AND MAINTENANCE	39073300	D	3	09.60
1546/1547 EVENT COUNTER SUBSYSTEM OPER AND MAINT INSTRUCTION	39070800	B		03.70
1547-1 (FT1A1-A) EVENTS COUNTER UNIT				
1547-2 (FT1A1-B) EVENTS COUNTER UNIT				
1548/1549 EXTERNAL INTERRUPT SUBSYSTEM OPER AND MAINTENANCE	39073400	C	22	06.75
1553/1554 EXTERNAL REGISTER OUTPUT SUBSYSTEM OPER AND MAINTENANCE	39073500	C	3	08.80
1555 POWER DRIVE OUTPUT UNIT AND RELAY OUTPUT UNIT	39073600	B	22	02.65
1555-1 (DF3A1-A) RELAY OUTPUT UNIT				
1555-2 (DF3A1-B) RELAY OUTPUT UNIT				
1555-4 (DF3A1-A) RELAY OUTPUT UNIT				
1556 ANALOG (DAC) OUTPUT UNIT OPER AND MAINT INSTRUCTION	39074300	A	22	02.00
1558 LATCHING RELAY OUTPUT INTERFACE OPER AND MAINT. INSTRUCTION	39073700		22	06.70
1559 LATCHING RELAY CONTACT OUTPUT UNIT OPER AND MAINT INSTRUCTION	39073800	A		01.35
1560 LATCHING RELAY ANALOG (DAC) OUTPUT UNIT OPER AND MAINT INSTRUCTION	39074400		3	02.30
1561 ANALOG OUTPUT INTERFACE OPER AND MAINT INSTRUCTION	39075000	A	22	01.90

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
1567, ADSE 3005 AND ADSE 3014 SIMULTANEOUS SAMPLE AND HOLD MODS OPER AND MAINT INSTR	84851100		22	04.50
1567 SIMULTANEOUS SAMPLE AND HOLD UNIT OPER, MAINT INSTR MANUAL	39071400		22	01.45
1568/420C ANALOK ANALOG MEMORY OUTPUT UNITS OPER AND MAINT INSTRUCTION	39071500	A		02.65
1570 SERIES TERMINATION PANELS/OPERATION AND MAINTENANCE	39071900	C	22	06.00
1571 CHAINING BUFFER CHANNEL OPERATION AND MAINTENANCE INSTRUCTION MANUAL	39073100	B	22	18.70
1572 PROGRAMMABLE SAMPLE RATE UNIT OPERATION AND MAINT INSTRUCTION	39070900	C	22	01.55
GENERAL DESCRIPTION, OPERATION AND PROG., THEORY OF OPERATION, MAINTENANCE, DIAGRAMS PARTS LIST AND WIRE LISTS CE MANUAL	39359900	B	22	01.50
1572-1 (GA128-A) SAMPLE TIMING UNIT				
1576 (FV4A3/498) STALL ALARM UNIT REF/CE MAN	88981000	A	22	03.70
1577 STALL ALARM HARDWARE REF/CE MANUAL	84781600	B	3	05.30
1581 LOGGING TYPEWRITER INTERFACE OP/MAINT CE MANUAL	39075200	A	22	02.80
1583 I/O TYPEWRITER INTERFACE HARDWARE/REF. CE MANUAL	39075300	A	22	02.25
1585 INCREMENTAL PLOTTER CONTROLLER HARDWARE REFERENCE CE MANUAL	39072600	B	22	01.90
1587/1557 MONITOR AND CONTROL PANELS OPER AND MAINTENANCE INSTRUCTION MANUAL	39071300	B	22	02.50
1590-3 REMOTE COMPUTER INTERFACE SUBSYSTEM HARDWARE REFERENCE CE MANUAL	39909513	A	22	21.00
1595-10 (DK605-A) SERIAL I/O UNIT				
1595-11 (DK605-A) SERIAL I/O UNIT				
1595-20 (DK605-B) SERIAL I/O UNIT				
1595-21 (DK605-B) SERIAL I/O UNIT				
1604-A COMPUTER				
INSTALLATION MAN	60002000	E		03.00
PERIPHERAL EQUIPMENT CODES	60025700	B		01.00
PROGRAM CARD (SA185C)	60070400			.75
REFERENCE MANUAL	60024500			03.50
SPECIFICATIONS (I/O)	60024400	E		03.25
CUSTOMER ENGINEERING MANUALS				
CE DIAGRAMS	60024300	J	34	12.00
CE INSTRUCTION MANUAL PART 1, THEORY OF OPERATION	60118700	A	22	05.75
CE INSTRUCTION MANUAL PART 2, MAINTENANCE EQUATION SUMMARY	60118800	A	22	04.40
	60116000	A	34	20.00
1604-B COMPUTER				
REFERENCE MANUALS				
I/O SPECIFICATIONS	60110100	B	22	05.10

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
CUSTOMER ENGINEERING MANUALS				
CE DIAGRAMS (STANDARD OPTION 10003)	60090800	R	34	10.00
CE INSTRUCTION MANUAL, PART 2, MAINTENANCE CHASSIS MAPS (SEE 1604-C)	60126800		22	05.75
1604-C/1604-A COMPUTER (PREVIOUSLY 1604/1604-A)				
PROGRAMMING TRAINING MANUAL	60001500	A	22	10.40
REFERENCE MANUAL	60016700	F	22	04.60
SPECIFICATIONS (I/O)	60003000	C		02.00
CUSTOMER ENGINEERING MANUALS				
PRINCIPLES OF OPERATION INSTR. BOOK	60003200	B		02.00
PART 3 MAINTENANCE	60003300	B		05.80
CE DIAGRAMS	60003500	S	34	14.00
MAINTENANCE LIBRARY	60006600	A		03.70
CHASSIS MAPS, 1604-B	60025600	D	22	10.00
TROUBLE SHOOTING AIDS	60028100	B	22	02.30
EQUATION SUMMARY, PART 1	60070500	C	22	14.00
EQUATION SUMMARY, PART 2	60070600	A	22	12.50
EQUATION SUMMARY, PART 3	60070700	A	22	13.00
1605-A ADAPTER				
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES, ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)				
DESCRIPTION, OPERATION AND MAINTENANCE VOL 1	60003600	B		
1606-A PRINT CONTROL UNIT				
THEO OF OPER, DIAGS, C/P, EQ SUM, W/L, WIRE TABS, CABLE TABS, REFERENCE/CE MANUAL	60004400	A	22	08.30
1607-A MAGNETIC TAPE SYSTEM (PREVIOUSLY 1607)				
DESCRIPTION, OPERATION AND MAINTENANCE	60003700	A	22	08.70
CE DIAGRAMS	60014700	S	22	02.00
EQUATION SUMMARY, CARD PLACEMENT	60014800	E	22	08.40
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES, ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)				
CHARACTERISTICS	60004100	A		
1608 CONTROL UNIT				
VOL.1, DESCRIPTION, OPERATION AND MAINTENANCE	60016400			04.25
CE DIAGRAMS	60016500	A	22	01.60
CARD PLACEMENT AND EQUATION SUMMARY	60016600	A	22	07.95
WIRE LIST, WIRE TABS (1608-A)	60148500	A	22	03.40

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
1609-A CARD READ AND PUNCH UNIT				
VOL. 1, DESCRIPTION AND OPERATION	60017800			03.25
MAINTENANCE, VOLUME 2	60017900	A	22	05.60
VOL.3 DIAGRAMS CE MANUAL	60018900		34	01.65
1610-A CONTROL UNIT				
VOL 1 DESCRIPTION AND OPERATION	60010600	A		04.50
VOL. 2 MAINTENANCE	60010700	A	22	10.80
CE DIAGRAMS	60010800	A	34	07.00
1611-A LINE PRINTER CONTROLLER				
REFERENCE/CE MANUAL	60127500	F,G	22	07.60
1612-A HIGH SPEED LINE PRINTER				
OPERATION AND MAINTENANCE MANUAL	60009800	B	22	18.50
1612G LINE PRINTER CE MANUAL	60098200	H, J	22	10.50
1612-G LINE PRINTER AND OFF LINE BUFFER	60145100	D,E	22	05.00
EQUATION SUMMARY MANUAL				
1612-B CROSS TABS AND 1612-G WIRE LIST	60151000	D,E	22	04.00
1612 TESTS (REFER TO 1612-A)				
1614-A CARD READER CONTROLLER				
REFERENCE/INSTRUCTION MANUAL	60091700	D		03.75
CARD PLACEMENT AND EQUATION SUMMARY	60287000	A	22	02.00
1615/160 CHANNEL LONG LINE DRIVERS CE MANUAL	60123700	A		00.75
1615-A MAGNETIC TAPE CONTROLLER				
REFERENCE MANUAL	60027200	A	3	03.00
DIAGRAMS	60027600	E	22	03.70
PRELIMINARY CE MANUAL	60097100	A	22	05.90
1617-A CARD READER				
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT				
ARE AVAILABLE ON A SPECIAL ORDER BASIS IN				
MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4				
WEEKS FOR PROCESSING AND DELIVERY.)				
VOL 1 DESCRIPTION, OPERATION, PROGRAMMING	60021400	A	22	
VOL.2, MAINTENANCE PARTS LIST	60021500	B		
1619-A MAGNETIC DISK FILE CONTROLLER				
REFERENCE MANUAL	60044900			03.00
CE DIAGRAMS	60029200	C	34	03.50
CE INSTRUCTION MANUAL	60107100		22	03.90
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT				
ARE AVAILABLE ON A SPECIAL ORDER BASIS IN				
MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4				
WEEKS FOR PROCESSING AND DELIVERY.)				
WIRE TABS				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CHASSIS 1	22914000	G		
CHASSIS 2	22913900	J		
CHASSTIS 3	22913800	F		
CHASSIS 2 TO 3	22913700	H		
CABLE TABS				
CHASSIS 1	22914200	J		
CHASSIS 2	22914300	F		
CHASSIS 3	22914400	K		
1631 DATA CHANNEL CONVERTER				
REFERENCE MANUAL-DESC, OPERATION, PROGRAMMING	38704400	B	22	01.55
DIAGS, P/L, C/P, EQ SUM, W/L CE MANUAL	38704500	D	22	06.00
1700 COMPUTER SYSTEM				
COMMUNICATIONS AND EQUIPMENT REFERENCE MAN.	13795000	B	22	03.10
COMPUTER SYSTEM REFERENCE MANUAL	60153100	F	22	01.50
COMPUTER SYSTEMS CODES	60163500	H	6	01.35
INPUT/OUTPUT SPECIFICATIONS MANUAL	60165800	H	22	01.35
SMM17 ERROR CODES INSTANT	60266200	G		06.00
SMM17 REFERENCE MANUAL - VOLUMES 1 AND 2	60182000	M	22	50.80
SYSTEM 17 INSTALLATION MANUAL	88996000	A	22	12.30
CUSTOMER ENGINEERING MANUALS				
6VDC POWER SUPPLY HARDWARE/REF/CE MAN	39072400			01.00
24VDC POWER SUPPLY HDWE REFERENCE/CE MANUAL	39072200		3	01.00
AT171A, B THREE-PORT A/Q AND INTERRUPT SWITCH	39412900	A	22	04.65
HDWR/REF CE				
AT172A THREE-PORT DSA SWITCH HDWR/REF MAN.	39415100	A	22	05.70
ADSE 8013 21- TRACK MAGNETIC TAPE CONTROLLER	84970400		22	17.00
(MTC) HARDWARE REF./CE MANUAL				
DC115B BUFFERED INPUT/OUTPUT INTERFACE	39308000	A	3	05.50
HARDWARE REFERENCE CE MANUAL				
SEISMIC DECOMMUTATION CHANNEL/WORD ASSEMBLY	39185900		22	05.60
CONTROL HARDWARE REFERENCE/CE MANUAL				
SMM17 PROGRAM LISTINGS - MEM	60220100	F	22	07.35
SMM17 PROGRAM LISTINGS - COM	60220200	E	22	07.10
SMM17 PROGRAM LISTINGS - PTP	60220300	E	22	07.60
SMM17 PROGRAM LISTINGS - PTR	60220400	E	22	05.10
SMM17 PROGRAM LISTINGS - TTY	60220500	F	22	04.85
SMM17 PROGRAM LISTINGS - CR1	60220600	D	22	06.20
SMM17 PROGRAM LISTINGS - MT1	60220700	E	22	08.90
SMM17 PROGRAM LISTINGS - DP1	60220800	F	22	08.90
SMM17 PROGRAM LISTINGS - RPT	60220900	F	22	01.95
SMM17 PROGRAM LISTINGS - BD1	60221000	D	22	05.90
SMM17 PROGRAM LISTINGS - SC1	60221100	F	22	10.50
SMM17 PROGRAM LISTINGS - LP1	60221200	F	22	08.05
SMM17 PROGRAM LISTINGS - MT2	60221300	E	22	06.75
SMM17 PROGRAM LISTINGS - BD2	60221400	D	22	10.60
SMM17 PROGRAM LISTINGS - BTB	60221500	C	22	03.90
SMM17 PROGRAM LISTINGS - DSC	60221600	E	22	01.70
SMM17 PROGRAM LISTINGS - MT3	60221700	G	22	09.35

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
SMM17 PROGRAM LISTINGS - CRP 1728/430 CARD READER/PUNCH CE MANUAL	60271300	F	22	13.20
SMM17 PROGRAM LISTINGS - (CR3) 1729-2/411 CARD READER	60271400	F	22	10.65
SMM17 PROGRAM LISTINGS - (CR2)1726/405 CARD READER	60271500	E	22	08.65
SMM17 PROGRAM LISTINGS - (DS1) 1747 DATA SET CONTROLLER	60271600	D	22	04.40
SMM17 PROGRAM LISTINGS - 1735/915 OCR OPTICAL CHARACTER READER CE MANUAL	60271700	F	22	20.70
SMM17 PROGRAM LISTINGS (CLK) 10126 INTERVAL TIMER CE MANUAL	60271800	C	22	03.40
SMM17 PROGRAM LISTINGS (CTC) 1749/321-311B COMMUNICATIONS TERMINAL CONTROLLER	60271900	D	22	09.25
SMM17 DDC 1745/1746/210 DATA DISPLAY CE MAN	60273200	E	22	12.55
SMM17 PROGRAM LISTINGS - OC3 FF406 TEST CE	60309200	E	22	18.65
SMM17 PROGRAM LISTINGS (FFT) FAST FOURIER TRANSFORM	60309300	B	22	09.25
SMM17 PROGRAM LISTINGS (CR4) 405/DTB TEST	60309400	C	22	02.75
SMM17 PROGRAM LISTINGS (DAD) DUAL ACCESS DISK TEST CE MANUAL	60309500	B	22	05.45
SMM17 PROGRAM LISTINGS - CAR	60325600	C	22	01.00
SMM17 PROGRAM LISTINGS - DDT	60325700	C	22	02.80
SMM17 PROGRAM LISTINGS - MTS	60325800	E	22	04.05
SMM17 PROGRAM LISTINGS - D1G	60325900	C	22	05.20
SMM17 PROGRAM LISTINGS - OC2	60326100	C	22	05.10
SMM17 PROGRAM LISTINGS - BC1	60326200	C	22	03.70
SMM17 PROGRAM LISTING - AC4	60326300	A	22	06.20
SMM17 PROGRAM LISTINGS - OC4	60326400	D	22	13.40
SMM17 PROGRAM LISTINGS - QL	60411300	C	22	04.95
SMM17 PROGRAM LISTINGS - SMM	60411400	C	22	10.80
SMM17 PROGRAM LISTINGS - DMP	60411500	C	22	03.10
SMM17 PROGRAM LISTING - PNY	60411600	A	22	06.45
SMM17 PROGRAM LISTINGS - UD3	60411700	B	22	02.05
SMM17 PROGRAM LISTINGS - RX1	60411800	C	22	05.90
SMM17 PROGRAM LISTINGS - LDR/RX3	60411900	C	22	08.40
SMM17 PROGRAM LISTINGS - RX4	60412000	C	22	10.20
SMM17 PROGRAM LISTINGS - AQM	60412100	C	22	15.25
SMM17 PROGRAM LISTINGS - LST	60412200	C	22	03.85
SMM17 PROGRAM LISTINGS - SAS	60412300	B	22	03.85
SMM17 PROGRAM LISTINGS - MCC	60412400	C	22	21.55
SMM17 PROGRAM LISTINGS - LPX	60412500	B	22	04.65
SMM17 PROGRAM LISTING - DG4	60412600	B	22	04.45
SMM17 PROGRAM LISTINGS - CDD	60412700	C	22	17.85
SMM17 PROGRAM LISTINGS - DRM	60412800	D	22	11.40
SMM17 PROGRAM LISTINGS - GTR	60412900	C	22	10.35
SMM17 PROGRAM LISTINGS - D10	60413000	B	22	02.05
SMM17 PROGRAM LISTINGS - IOM	60413100	C	22	11.65
SMM17 PROGRAM LISTING - RMT	60413200	A	22	02.70
SMM17 PROGRAM LISTING - RD3	60413300	A	22	02.60
SMM17 PROGRAM LISTING - CP1	60413400	A	22	02.20
SMM17 PROGRAM LISTING - CP2	60413500	A	22	02.35
SMM17 PROGRAM LISTING - HCA	60413600	A	22	03.75

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
SMM17 PROGRAM LISTING - DP2	60413700	A	22	03.75
SMM17 PROGRAM LISTING - RD4	60413800	A	22	04.05
SMM17 PROGRAM LISTINGS - DP3	60413900	D	22	15.60
SMM17 PROGRAM LISTING - DP4	60414000	A	22	03.00
SMM17 PROGRAM LISTING - BD5	60414100	A	22	02.20
SMM17 PROGRAM LISTING - PLT	60414200	A	22	01.35
SMM17 PROGRAM LISTING - QOB	60414300	A	22	01.70
SMM17 PROGRAM LISTING - CTU	60414400	A	22	04.05
SMM17 PROGRAM LISTING - GTT	60414500	A	22	02.00
SMM17 PROGRAM LISTING - DDD	60414600	A	22	03.25
SMM17 PROGRAM LISTINGS - EDT	60414700	C	22	11.10
SMM17 PROGRAM LISTINGS - MYZ	60422300	C	22	08.40
SMM17 PROGRAM LISTINGS - MY1	60422400	C	22	08.70
SMM17 PROGRAM LISTINGS - UD1	60422500	B	22	02.00
SMM17 PROGRAM LISTINGS - UD2	60422600	B	22	02.05
SMM17 PROGRAM LISTINGS - RC3	60422700	B	22	11.05
SMM17 PROGRAM LISTING - RC2	60422800	B	22	19.10
SMM17 PROGRAM LISTINGS - DP5	60422900	C	22	05.65
SMM17 PROGRAM LISTING - CP4	60423000	A	22	02.75
SMM17 PROGRAM LISTINGS - GT0	60437400	B	22	09.65
SMM17 PROGRAM LISTINGS - GT1	60437500	B	22	20.65
SMM17 PROGRAM LISTINGS - GT2	60437600	B	22	19.10
SMM17 PROGRAM LISTINGS - GT3	60437700	B	22	14.10
SMM17 PROGRAM LISTING - GT4	60437800	A	22	04.05
SMM17 PROGRAM LISTINGS - GT5	60437900	B	22	10.05
SMM17 PROGRAM LISTINGS - GT6	60438000	B	22	17.75
SMM17 PROGRAM LISTINGS - LP5	60438100	B	22	16.75
SMM17 PROGRAM LISTING - HOR	60438200	A	22	10.05
SMM17 PROGRAM LISTING - VSD	60438300	A	22	02.10
SMM17 PROGRAM LISTINGS - KEY	60438400	B	22	09.55
SMM17 PROGRAM LISTINGS - MDC	60438600	B	22	23.05
SMM17 PROGRAM LISTING - DPC	60446100	A	22	04.05
SMM17 PROGRAM LISTING - MTX	60446200	A	22	13.80
SMM17 PROGRAM LISTING - PET	60446300	A	22	06.90
SMM17 PROGRAM LISTING - PAD	60446400	A	22	05.65
SMM17 PROGRAM LISTING - BDL	60446500	A	22	06.10
SMM17 PROGRAM LISTING - REP	60446600	A	22	08.20
SMM17 PROGRAM LISTING - INS	60446700	A	22	06.65
SMM17 PROGRAM LISTING - CMD	60446800	A	22	05.70
SMM17 PROGRAM LISTING - CPY	60447700	A	22	02.25
1703-A STORAGE INCREMENT				
REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.)				
MAINT., PARTS LIST (USE 1704-A/B)				
DIAGRAMS, CIRCUIT DESC., C/P (USE 1704-A/B)				
1704-A/B COMPUTER				
REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.)				
DIAGRAMS, CIRCUIT DESCRIPTION, CARD				
PLACEMENT OF MANUAL (INCLUDES PMI/PMP)				
MAINTENANCE, PARTS LIST OF MANUAL				
MAINTENANCE, COMMAND TIMING CHARTS OF MANUAL				
CROSS TABS OF MANUAL				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
1705-A INTERRUPT DATA CHANNEL REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) DIAGRAMS, CIRCUIT DESCRIPTION, CARD PLACEMENT (USE 1704-A/B) MAINTENANCE, PARTS LIST (USE 1704-A/B)				
1706-A BUFFERED DATA CHANNEL REFERENCE MANUAL	60330300	C	22	01.00
DIAGRAMS, CIRCUIT DESCRIPTION, MAINTENANCE, PARTS LIST CE MANUAL	60165700	L	22	02.00
CROSS TABS CE MANUAL	60284000	B	22	03.10
1708-A/BB310-A/BB311-A/BB312-A STORAGE INCREMENT REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) DIAGRAMS, CIRCUIT DESCRIPTION, CARD PLACEMENT (USE 1704-A/B) CE MANUAL	60182900	G	22	05.95
1709-A STORAGE INCREMENT REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) MAINTENANCE, PARTS LIST (USE 1704-A/B) DIAGRAMS, CIRCUIT DESCRIPTION, CARD PLACEMENT (USE 1704-A/B)				
1711-A/B TELETYPEWRITER REF INFO (FOR 1704-A/B USE 1700 SYSTEM REF. MANUAL) REF INFO (FOR 1714 USE 1714 SYSTEM REF. MANUAL) DIAGRAMS, CIRCUIT DESCRIPTION, MAINTENANCE PARTS LIST, C/P, WIRE LISTS CE MANUAL ** REFER TO VENDOR MANUALS SECTION FOR TELETYPE MANUALS (35KSR)	60164200	AF	22	21.75
1711-3 (CK501-A/B) TELETYPEWRITER (35KSR) REF INFO (USE 1770 REFERENCE MANUAL)				
1712-A TELETYPEWRITER REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) ** REFER TO VENDOR MANUALS SECTION FOR TELETYPE MANUALS (35KSR)				
1713-A/B TELETYPEWRITER REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) ** REFER TO VENDOR MANUALS SECTION FOR TELETYPE MANUALS (35ASR)				
1713-3 (CK502-A/B) TELETYPEWRITER (35ASR) REF INFO (USE 1770 REF MAN)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
1714 (AA116-A, AA119-A/B/C/D, BT150-A/B) BASIC PROCESSOR REFERENCE MANUAL	60364900	B	22	01.75
1716-A COUPLING DATA CHANNEL REFERENCE MANUAL CE MANUAL	60330400 60182800	B N	22 22	01.00 01.85
1717-1 (FJ101-A, FJ415-A) DATA SET CONTROLLER REFERENCE MANUAL	13797800	B	22	03.40
1718-A SATELLITE COUPLER REFERENCE MANUAL ** REFER ALSO TO 370 PAPER TAPE READER ** REFER ALSO TO VENDOR MANUALS SECTION FOR REMX TAPE SPOOLER CE MANUAL	60330500	A	22	01.00
1721-A/B PAPER TAPE READER REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) ** REFER ALSO TO 350 PAPER TAPE READER FOR ADDITIONAL DOCUMENTATION				
1721-C/D PAPER TAPE READER REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) ** REFER ALSO TO 370 PAPER TAPE READER FOR ADDITIONAL DOCUMENTATION				
1722-A/B PAPER TAPE READER REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) MAINTENANCE, PARTS LIST (USE 1704-A/B)				
1723-A/B PAPER TAPE PUNCH REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) ** REFER TO VENDOR MANUALS SECTION FOR NCR EM-B1 PAPER TAPE PUNCH CE MANUAL				
1724-A/B PAPER TAPE PUNCH REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) ** REFER ALSO TO VENDOR MANUAL SECTION FOR NCR EM-B1 PAPER TAPE PUNCH AND NCR EM-B2 TAPE HANDLER CE MANUALS				
1726-1 (FE107-A) CARD READER CONTROLLER REFERENCE MANUAL	60330900	A	22	01.00
1728-A/B (CF504, FE304-A) CARD READER/PUNCH WITH CONTROLLER				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
REFERENCE MANUAL CF INFO FOR READER/PUNCH (USE CF504) CE INFO FOR CONTROLLER (USE FE304-A, CATALOG SECTION 1)	60331000	A	22	01.25
1729-2 (CE120-A/B, FE110-A) CARD READER WITH CONTROLLER REFERENCE MANUAL	60331100	A	22	01.00
1729-3 CARD READER CONTROLLER REFERENCE MANUAL	89637400	02	22	01.15
1729-A/B CARD READER REF INFO (USE 1700 REF MAN) CE INFO (USE 1711-A/B)				
1731-A/B MAGNETIC TAPE CONTROLLER REFERENCE MANUAL CE MANUAL	60330700 60167500	A M	22	01.00 06.20
1732-A/B MAGNETIC TAPE CONTROLLER REFERENCE MANUAL CF MANUAL	60330800 60208200	A L	22	01.50 22.20
1732-2 (SYSTEM 17) MAGNETIC TAPE TRANSPORT CONTROLLER REFERENCE MANUAL	89637600	03	22	02.25
1732-3 (SYSTEM 17) MAGNETIC TAPE TRANSPORT CONTROLLER REFERENCE MANUAL	89769400	01	22	02.95
1733-1 (FA102-A) DISK STORAGE CONTROLLER REFERENCE MANUAL	60400200	A	22	01.30
1733-2 CARTRIDGE DISK DRIVE CONTROLLER REFERENCE MANUAL	89638000	03	22	01.65
1735 (FF103-A) PAGE READER CONTROLLER REFERENCE MANUAL	60237800	D	22	01.80
1736-1 (FF406-A/B/C) UNIT RECORD READER CONTROLLER REF INFO (USE 935 OCR SYSTEM REF/OPERATORS MANUAL)				
1738-A/B/C DISK DRIVE CONTROLLER REFERENCE MANUAL CF MANUAL	60330600 60167700	B U	22	05.10 05.35
1739-1 (BR401-A/B, FV227-A/B, GD121-A, GH421-A) CARTRIDGE DISK DRIVE REFERENCE MANUAL	60368600	B	22	03.25

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
1740 (FF516-A) LINE PRINTER CONTROLLER REFERENCE MANUAL	60331200	A	22	01.00
1742-A/B (CL309-A/B, FF511-A/B) LINE PRINTER WITH CONTROLLER REFERENCE MANUAL CE INFO FOR PRINTER (USE CL309-A/B, CATALOG SECTION 1) CE INFO FOR CONTROLLER (USE FF511-A/B)	60331300	B	22	01.40
1742-30/120 LINE PRINTER CONTROLLER REF MAN	89637200	02	22	01.10
1743-1 SYNCHRONOUS COMMUNICATION CONTROLLER AND DISTRIBUTION PANEL REFERENCE MANUAL	89638400	02	22	01.90
1743-2 ASYNCHRONOUS COMMUNICATION CONTROLLER AND DISTRIBUTION PANEL REFERENCE MANUAL	89638200	02	22	01.45
1747 (FJ412-A/B/C) DATA SET CONTROLLER REFERENCE MANUAL	13799000	C	22	01.65
1748 MULTIPLEXER CONTROLLER C/P, LOGIC WIRING, WIRE LTSTS, EQ SUM CE MAN	41601500	01	22	15.75
1748 MULTIPLEXER CONTROLLER REFERENCE MANUAL	13794400	A	22	03.90
1748-2 (FJ103-A/B) MULTIPLEXER CONTROLLER REFERENCE MANUAL	41601600	A	22	03.70
1749-A/B COMMUNICATION TERMINAL CONTROLLER REFERENCE MANUAL THEORY OF OPERATION, MAINT., INSTALLATION, PARTS LIST, DIAGRAMS, CARD PLACEMENT CE MAN WIRE LISTS, EQ SUMMARY, MAINT. AIDS CE MAN	36827100 36827000 36829100	D H G	22 22 22	01.25 02.00 09.25
1750 DATA AND CONTROL TERMINAL (DCT) OPERATION AND MAINTENANCE INSTRUCTION MANUAL	39072900	E	22	07.15
1750-1 (EL101-A) COMPUTER INTERFACE UNIT				
1750-2 (EL102-A) COMPUTER INTERFACE EXPANDER				
1751 DRUM INTERFACE AND STORAGE UNIT OPER AND INSTRUCTION MANUAL DRUM STORAGE UNIT HDR. REF./CE MANUAL	39071100 39216600	003	22 22	03.10 03.40
1770/SC-1700 SYSTEM CONTROLLER REFERENCE MANUAL COMPUTER SYSTEM CODES (USE 1700) I/O SPECIFICATIONS MANUAL	60270600 60285200	B 04	22 22	01.90 01.00
1772-1 (BB328-A) MEMORY INCREMENT MODULE REF INFO (USE 1770 REF MAN)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
1772-2 (BB329-A) MEMORY EXPANSION UNIT REF INFO (USE 1770 REF MAN)				
1773-1 (DC120-A) DIRECT ACCESS STORAGE MODULE REF INFO (USE 1770 REF MAN)				
1774-1 (AG109-A/B/C) COMPUTE MODULE REF INFO (USE 1770 REF MAN)				
1775-1 (DC118-A) A/Q INTERRUPT DATA CHANNEL REF INFO (USE 1770 REF MAN)				
1777-1 (CE305-A/B, CF104-A, CF508-A/B) PAPER TAPE STATION REFERENCE MANUAL	60331400	B	22	01.00
1777-2 (CE305-A/B, CF104-A, CF508-A/B, CW123-A) PAPER TAPE STATION W/VALIDATION OPT. REF INFO (USE 1777-1 REF MAN)				
1778-1 (GJ102-A) PAPER TAPE READER HANDLER REF INFO (USE 1777-1 REF MAN)				
1778-2 (GJ103-A/B) PAPER TAPE PUNCH HANDLER REF INFO (USE 1777-1 REF MAN)				
1779-1 (DC119-A) CHARACTER HANDLING REF INFO (USE 1770 REF MAN)				
1784 (SYSTEM 17) COMPUTER SYSTEM INPUT/OUTPUT SPECIFICATIONS	89673100	02	22	04.40
1784-1/2 () COMPUTER SYSTEM REFERENCE MANUAL	89633400	A	22	02.25
CE MANUAL	89633300	04	22	22.50
2013-A BADGE READER ADAPTER CE/REF MANUAL	13790500	D	22	05.50
2014-A TIME EMITTER CE MANUAL VOL 2 EQ FILE AND WIRE LIST MANUAL	13794700	C	22	02.25
REFERENCE/CE MANUAL	13794600	B	22	01.70
2014-B TIME EMITTER REFERENCE/CE MANUAL	13794800	A	22	01.00
2020 COMPILER CE MANUAL - DIAGRAMS	36820000	F	22	03.05
ILLUSTRATED PARTS MANUAL (TRANSACTION SYSTEM)	65631800	A	22	01.05
TRANSACTION SYSTEM REFERENCE MANUAL	36817600	A	22	03.25
INSTALLATION MANUAL	36820400	B	22	02.00
2022-P DATA COLLECTOR CONTROLLER CE MANUAL	13796200	B		02.40

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
2025-1/2 MAGNETIC TAPE COMPILER SYSTEM USERS MANUAL	65690800	B	22	06.05
SFTWR. DESC., SYS. DESC., SYSTEM REF.MAN.	65655800	B	22	06.15
SOFTWARE INSTALLATION MANUAL	65727400	A	22	01.25
2040 AUTOMATIC SHUNT CE DIAGRAMS MANUAL	36820100	C	34	02.00
2070-A CONCENTRATOR CE DIAGRAMS MANUAL	36820200	A	34	02.75
2070-B/2075-B CONCENTRATOR CONVERTER CE MANUAL-THEO OF OPER,DIAGS,P/L,C/P,W/L	36829800	C	22	03.60
2075-A CONVERTER CE DIAGRAMS MANUAL	36820300	A	34	01.75
2077/2078/2079 CONCENTRATOR TERMINAL REF. MAN.	13790300	B	22	01.25
CE MANUAL VOL I THEO OF OPER,MAINT,DIAG, P/L	13790100	G	22	13.90
CE MANUAL VOL II OF 4 (INCL EQ FILE, W/L)	13790200	D	22	10.00
CE MANUAL VOL III EQ FILE, LOGIC WIRING,W/L	13791300	D	22	15.35
2079 CONCENTRATOR TERM. CE MANUAL VOL 4 OF 4	13791400	D	22	02.85
2085-A/2086-A TRUNK LINE CONTROLLER REF MANUAL	13790700	A		01.00
LOGIC WIRING, W/L, EQ. FILE, C/P, VOL II CE MANUAL	13790800	D	22	07.65
CE MANUAL VOL 1 AND 2	36829500	F	22	02.50
2086-B TRUNK LINE CONTROLLER REFERENCE MANUAL	13792500	D	22	01.00
OPER,MAINT,DIAGRAMS AND PARTS LIST CE MANUAL	13792400	I	22	03.40
CE MANUAL VOL 2 (INC WIRE LIST,EQ FILE)	13792700	E	22	02.85
3000 SERIES COMPUTER SYSTEM INPUT/OUT SPECIFICATIONS	60048800	M	22	02.30
INSTRUCTION CODES (3100/3200)	60150200	B		01.35
PERIPHERAL EQUIPMENT CODES	60113400	J		01.65
SITE PREPARATION AND INSTALLATION MANUAL	60110400	M-N	22	04.00
CUSTOMER ENGINEERING MANUALS				
PERIPHERAL CONTROLLER CABINETS CE MANUAL INFORMATION (1700/3000/6000) SOLID FRONT STYLE	60224100	Z	22	02.20
3000L SYSTEM MAINT. MONITOR REF MAN VOL 1+2	60118600	M	22	20.00
PM1/PMP MAINT SERIES CONTROLLER (3000)	60317800	A	22	01.00
REAL TIME SYSTEMS EXECUTIVE TEST ROUTINES (3100/3200/3300)	13793100	A	22	02.15
3100/3200/3300 COMPUTER MEMORY PATTERN TEST	13793300		22	01.00
3100/3200/3300 COMPUTER UTILITY ROUTINE	13793400		22	01.50
IBM 360/370 SMM CE MANUAL	60383300	04	22	04.70
SMM3L PROGRAM LISTINGS MONITOR	60300000	F	22	07.20
SMM3L PROGRAM LISTINGS (SPV) SERVICE ROUTINE CE MANUAL	60300100	C	22	02.10

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
SMM3L PROGRAM LISTINGS (MEM) MEMORY TEST FOR 3200	60300200	B	22	02.25
SMM3L PROGRAM LISTINGS (MM1) 2DP MEMORY CE	60300300	D	22	03.25
SMM3L PROGRAM LISTINGS (MM2) 3300 MEMORY	60300400	G	22	08.95
SMM3L PROGRAM LISTINGS (LOG) 3L00 LOGIC	60300500	E	22	05.65
SMM3L PROGRAM LISTINGS (COM)	60300600	E	22	24.95
SMM3L PROGRAM LISTINGS (FPT) FLOATING POINT TEST	60300700	E	22	07.00
SMM3L PPROGRAM LISTINGS (MOE) MOVE TEST	60300800	B	22	01.00
SMM3L PROGRAM LISTINGS (RAN) RANDOM INSTR.	60300900	C	22	04.10
SMM3C PROGRAM LISTINGS 322X MAG TAPE (MT1)	60301000	C	22	04.25
SMM3L PROGRAM LISTINGS (MT6) 3127/601 MAG TAPE TEST	60301100	C	22	02.65
SMM3L PROGRAM LISTINGS (MT0) 3600/322X/60X TAPE	60301300	E	22	04.15
SMM3L PROGRAM LISTINGS (CH1) 3207/6 CHANNEL TEST	60301400	D	22	02.40
SMM3L PROGRAM LISTINGS (CH2) CHANNEL TEST 3234 853/854, 813/814 CE MANUAL	60301500	G	22	11.30
SMM3L PROGRAM LISTINGS (LP2) 501 LINE PRINT-	60301600	B	22	01.30
SMM3L PROGRAM LISTINGS (TP1) CONSOLE TYPEWRITER	60301700	B	22	01.60
SMM3L PROGRAM LISTINGS (OP4) DISK PACK TEST	60301800	C	22	03.25
SMM3L PROGRAM LISTINGS (MS1)	60301900	G	22	21.65
SMM3L PPROGRAM LISTINGS DM19DM29 3235 DRUM 3236/3237/861 DRUM CE MANUAL	60302000	C	22	02.30
SMM3L PROGRAM LISTINGS (OD5) 3290C DISPLAY	60302200	C	22	02.75
SMM3L PROGRAM LISTINGS MEMORY INTERRUPT TEST FOR 3300	60302500	B	22	01.80
SMM3L PROGRAM LISTINGS (FX2) EXECUTIVE MODE	60302600	F	22	03.05
SMM3L PROGRAM LISTINGS (SPS) 3300 SELECTIVE PROTECT SWITCH TEST	60302700	C	22	02.30
SMM3L PROGRAM LISTINGS (PF1) 3300 PAGE FILE ILLEGAL WRITE TEST	60302800	C	22	01.10
SMM3L PROGRAM LISTINGS (OVN) EXECUTIVE MODE MONITOR	60303000	F	22	09.15
SMM3L PROGRAM LISTINGS (CP4) 3446/3644 CARD PUNCH CONTROLLER	60303100	D	22	02.60
SMM3L PROGRAM LISTINGS (CR4) 3248/3447/3649 CARD READER CONTROLLER	60303200	D	22	03.55
SMM3L PROGRAM LISTINGS 3L00 QUICK LOOK MEMORY TEST	60303700	B	22	02.90
SMM3L PROGRAM LISTINGS 3L00 QUICK LOOK COMMAND TEST	60303800	C	22	08.85
SMM3L PROGRAM LISTINGS 3200 EXTERNAL EQUIP.	60303900	E	22	07.35
SMM3L PROGRAM LISTINGS - RFT	60304000	B	22	01.70
SMM3L PROGRAM LISTINGS MMX ITERRUPT PROC.	60304100	E	22	07.40
SMM3L PROGRAM LISTINGS MS3	60304200	B	22	06.00
SMM3L PROGRAM LISTINGS LOADING	60304300	B	22	04.50
SMM3L PROGRAM LISTINGS DCP 17	60304400	E	22	05.60
SMM3L PROGRAM LISTINGS SIMULATED RANDOM INSTR. TEST	60304500	B	22	12.70
SMM3L PROGRAM LISTINGS-3316 CONTROLLER CEN	60304600	C	22	21.40

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
SMM3L PROGRAM LISTINGS MM4	60304700	B	22	03.80
SMM3L PROGRAM LISTINGS-BDP TESTS 3312-A	60336500	D	22	17.60
SMM3L PROGRAM LISTINGS - BDP TESTS 3504	60336600	C	22	17.75
SMM3L PROGRAM LISTINGS-BDP TESTS 3312-B	60336700	C	22	14.55
SMM3L PROGRAM LISTINGS - BDP TESTS 3514	60336800	D	22	18.10
SMM3L PROGRAM LISTINGS - 3300/3500 PAGE FILE TEST - PFT	60336900	D	22	10.50
SMM3L PROGRAM LISTINGS - 3266 COMMUNICATIONS CONTROLLER (CTC)	60337000	B	22	04.30
SMM3L PROGRAM LISTINGS-3553-2/ 821 MS4	60337100	D	22	25.75
SMM3L PROGRAM LISTINGS - (PFR) PAGE READER	60337200	B	22	05.05
3010 LINE PRINTER EQUIPMENT				
CE MANUAL PARTS DATA	44896500	A	22	02.50
REFERENCE CE MANUAL	47500700	D	22	03.50
PRINTER EQUIPMENT CE MAN. (USE CL308-A/B)				
3020-A ALPHANUMERIC INPUT TERMINAL				
REFERENCE/CE MANUAL	36829600	D	22	01.95
EQUATION SUMMARY, LOGIC WIRING CE MANUAL	36829700	C	22	03.70
3100 COMPUTER SYSTEM				
REFERENCE MANUALS				
COMPUTER SYSTEM REFERENCE MANUAL	60108400	D	22	06.70
INSTRUCTION CARD (3100/3200)	60043000	B		00.75
CUSTOMER ENGINEERING MANUALS				
OPTIONAL ARITH. CIRCUIT DESC (3100/3200) CE MANUAL	60101400	B	22	12.45
PMI/PMP CE MANUAL	60318200	A	22	01.00
3101-A/B/C CONSOLE				
REF INFO (USE 3100 COMPUTER SYSTEM REF MAN)				
PARTS LIST (USE 3104-A/B)				
DIAGRAMS (USE 3104-A/B/C)				
** SEE 3192-A/B/C ALSO FOR TYPEWRITER MANUAL				
3103-A STORAGE MODULE				
DIAGRAMS (USE 3104-A/B)				
REF INFO (USE 3100 COMPUTER SYSTEM REF MAN)				
PARTS LIST (USE 3104-A/B)				
CARD PLACEMENT, EQ SUMMARY, WIRE LIST CE MAN (INCLUDES PREVIOUS PUB NO.S 35111000 AND 35111100) (ALSO INCLUDES 3113-A/B INFO)	35110900	C	22	08.20
3104-A/B, 3114-A/B COMPUTER				
REF INFO (USE 3100 COMPUTER SYSTEM REF MAN)				
CIRCUIT DESCRIPTION CE MANUAL	60111200	A	22	03.50
DIAGRAMS CE MANUAL	60111100	BE	22	08.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
MAINTENANCE COMMAND TIMING CHARTS CE MANUAL	60112400	A	22	05.00
PARTS LIST CE MANUAL	60157200	C	22	06.05
CARD PLACEMENT, EQUATION SUMMARY CE MANUAL	60152500	AD	22	30.00
WIRE LIST (TERM) CE MANUAL	60152600	AA	22	16.55
WIRE LIST (HAND TABS) CE MANUAL	60162600	J	22	06.30
3104-C/3114-C COMPUTER				
REF INFO (USE 3100 COMPUTER SYSTEM REF MAN)				
CIRCUIT DESCRIPTION (USE 3104-A/B)				
DIAGRAMS (USE 3104-A/B)				
MAINT. COMMAND TIMING CHARTS (USE 3104-A/B)				
PARTS LIST (USE 3104-A/B)				
CARD PLACEMENT, EQUATION SUMMARY CE MANUAL	60197900	S	22	26.00
WIRE LIST (TERM) CE MANUAL	60198000	M	22	15.10
WIRE LIST (HAND TABS) CE MANUAL	60198200	D	22	09.10
3106-A/B DATA CHANNEL				
REF INFO (USE 3100 COMPUTER SYSTEM REF MAN)				
CE INFO (USE 3104-A/B)				
3107-A/B DATA CHANNEL				
REF INFO (USE 3100 COMPUTER SYSTEM REF MAN)				
DIAGRAMS (USE 3104-A/B)				
PARTS LIST (USE 3104-A/B)				
CARD PLACEMENT, EQUATION SUMMARY				
** USE 3104-A/B FOR 3104-A/B, 3114-A/B SYSTEMS				
** USE 3104-C FOR 3104-C, 3114-C SYSTEMS				
WIRE LISTS (SAME AS CARD PLACEMENT ABOVE)				
3108-A MEMORY EXPANSION UNIT				
REF INFO (USE 3100 COMPUTER SYSTEM REF MAN)				
CE INFO (USE 3104-A/B)				
3109-A/B MEMORY MODULE				
REF INFO (USE 3100 COMPUTER SYSTEM REF MAN)				
DIAGRAMS (USE 3104-A/B)				
PARTS LIST (USE 3104-A/B)				
CARD PLACEMENT, EQ SUMMARY				
** USE 3104-A/B FOR 3104-A/B, 3114-A/B SYSTEMS				
** USE 3104-C FOR 3104-C, 3114-C SYSTEMS				
WIRE LISTS (SAME AS CARD PLACEMENT ABOVE)				
3113-A/B STORAGE MODULE				
CARD PLACEMENT, EQ SUMMARY, WIRE LISTS (USE 3103-A)				
3121-A/B (FA414-A/B) MAGNETIC TAPE CONTROLLER REFERENCE MANUAL				
	60332000	A	22	01.10
3127-A/B MAGNETIC TAPE CONTROLLER CE MANUAL REFERENCE MANUAL				
	60140400	R	22	17.90
	60331800	B	22	03.50

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
3127/3228/3329 MAG TAPE CONTROLLER AND 60X MAG TAPE TRANSPORT TEST ROUTINE	13790400		22	02.30
3128-A/B MAGNETIC TAPE CONTROLLER CE MANUAL	60202600	K	22	09.65
REFERENCE MANUAL	60331900	A	22	01.35
3142-A/B CARD READER AND CONTROLLER CE MANUAL	60160300	G	22	05.55
REFERENCE MANUAL	60332400	A	22	01.20
3150 DATA PROCESSING SYSTEM				
REFERENCE MANUAL	60207800	A	22	02.55
SOURCE DATA COLLECTION SYS SOFTWARE DESC.	65724900		3	01.00
3152-A/B LINE PRINTER CONTROLLER				
CIRCUIT DESCRIPTION, DIAGRAMS, MAINT, PARTS LIST, CARD PLACEMENT, EQ SUMMARY CE MANUAL	60108100	F	22	22.65
CROSS TABS OF MANUAL	60147200	B	22	04.00
TEST ROUTINE	13793200		22	01.05
3170 COMPUTER SYSTEM				
REFERENCE MANUAL	60341500	C	22	10.00
I/O SPECIFICATIONS (USE 3000 I/O)				
3172 (8B105-A) MAGNETIC CORE STORAGE				
REF INFO (USE 3170)				
3174-1 (AC105-B, 3301-A, 3311-A) BASIC PROCESSOR				
REF INFO (USE 3170)				
3174-2 (AC105-B, 3301-A, 3310-A, 3311-A) SCIENTIFIC PROCESSOR				
REF INFO (USE 3170)				
3174-3 (AC105-B, 3301-A, 3311-A, AF101-B) BUSINESS DATA PROCESSOR				
REF INFO (USE 3170)				
3174-4 (AC105-B, 3301-A, 3310-A, 3311-A, AF101-B) GENERAL PROCESSOR				
REF INFO (USE 3170)				
3177 (3306-C, 3307-A) COMMUNICATIONS CHANNEL				
REF INFO (USE 3170)				
3192-A/B/C/D ON-LINE MONITOR TYPEWRITER				
CE MANUAL	60150100	J	22	06.45
TEST ROUTINE	13793600		22	01.05
3195-A PAGE READER CONTROLLER				
REFERENCE MANUAL	60166900	D	22	02.00
CE MANUAL	60167000	D	22	08.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
3200 COMPUTER SYSTEM				
REFERENCE MANUAL COMPUTER SYSTEM	60043800	J	22	02.30
CUSTOMER ENGINEERING MANUALS (INCLUDE INFO ON 3203-A, 3204A/B, 3205A/B, 3206 3207A/B, 3209-A, 3210-A/B, 3215-A/B)				
CARD PLACEMENTS	31620199	AK	34	05.50
EQUATION SUMMARY, VOLUME 1 AND 2	31620099	Y	34	19.05
WIRE LIST, TERM LIST	31620200	AD	22	17.95
WIRE LIST, HAND TABS	31620300	P		08.25
CE DIAGRAMS	60049400	AY	22	13.40
PARTS LIST	60075400	D	22	07.45
CE MANUAL GIRC DESC., COMPUTATION SECT.	60100900	C	22	09.80
MAINTENANCE COMMAND TIMING CHARTS	60101100	B	22	15.00
3203 DISK DIAGNOSTIC TEST ROUTINE MANUAL	41611300	A	22	04.50
3216 REAL TIME COMMUNICATION MODULE				
CE MANUAL	13792100	A	22	01.20
CE DIAGRAMS MANUAL	13792200	B	34	02.00
3217 REAL TIME COMMUNICATION MODULE AND B.A.T.E. EXCHANGE TEST ROUTINES	13794100	A	22	02.85
3218-A PROGRAMMED DATA CHANNEL REF/CE MANUAL	60116100	E	22	07.00
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)				
EQUATION SUMMARY	60115900			
WIRE TABS	24146700			
3228-A/B MAGNETIC TAPE CONTROLLER				
REFERENCE MANUAL	60331700	C	22	01.40
CE MANUAL	60093700	V	22	07.05
3229-A/B MAGNETIC TAPE CONTROLLER (USE 3228-A) REF INFO (USE 3228-A/B)				
3231-A DISK PACK CONTROLLER				
REFERENCE MANUAL	60110900	C	22	01.75
CE MANUAL	60111000	B	22	06.00
3232-A/B DISK DRIVE CONTROLLER				
REFERENCE MANUAL	60165300	01	22	02.50
CE MANUAL	60165400	E	22	21.60
3234-A/B MASS STORAGE CONTROLLER				
REFERENCE MANUAL	60333300	B	22	02.20

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
DIAGRAMS CE MANUAL	60167900	AD	22	08.50
WIPE LIST, EQUATION SUMMARY CE MANUAL	60268900	P	22	10.00
TEST ROUTINE (SEE ALSO SPECIAL OPTION 60076-A)	41606500	A	22	02.00
3234-D/E MASS STORAGE CONTROLLER CE MANUAL	60394800	D	22	12.75
3235-A DRUM STORAGE SUBSYSTEM REFERENCE MANUAL	60165100	01		02.75
CE MANUAL	60165200	01	22	09.50
3245-A CARD PUNCH CONTROLLER REFERENCE MANUAL	60332200	A	22	01.25
CE MANUAL	60105100	J,K	22	08.00
3248-A/B CARD READER CONTROLLER REFERENCE MANUAL	60332300	D	22	02.85
CE MANUAL	60100400	R	22	03.05
3248/405 TEST ROUTINE	13793800		22	01.60
3254 (CL308-A, FF510-A/B) LINE PRINTER WITH CONTROLLER REFERENCE MANUAL	60332900	A	22	01.00
3256-A/B/C LINE PRINTER CONTROLLER REFERENCE MANUAL	60332500	A	22	01.25
CE MANUAL	60113900	AD	22	05.70
3256/3659 TEST ROUTINE	13793900		22	01.10
3266-B COMM TERMINAL CONTROLLER THEO OF OPER INSTAL., MAINT., AND PARTS LIST	36825800	J	22	01.50
MAINTENANCE AIDS MANUAL	36825900	J	22	03.25
DIAGRAMS MANUAL	36826000	H	34	03.00
REFERENCE MANUAL	36828100	D	22	01.00
3270-A/B TRANSFER SWITCH CONTROLLER RFF/CE MANUAL	60417300	A	22	09.05
3275-C DATA SET CONTROLLER REFERENCE MANUAL	13791500	A	22	01.20
CE MANUAL	13791600		22	01.00
3276 COMMUNICATION TERMINAL CONTROLLER MAINTENANCE MANUAL	36816200	A	22	03.50
3293-A/B INCREMENTAL PLOTTER REFERENCE MANUAL	60332700	B	22	01.00
CE MANUAL	60090500	N	22	03.85
3300 COMPUTER SYSTEM REFERENCE MANUAL	60157000	N	22	04.50
COMMAND TIMING CHARTS CE MANUAL	60185600	B	22	08.50

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
INSTRUCTION CODES (POCKET-SIZE) (INCLUDES 3500)	60186900	D		00.75
ON-LINE DIAGNOSTICS (33/3500 MASTER) GIM	60329900	A	22	01.00
ON-LINE DIAGNOSTICS (33/3500 MASTER) REF MAN	60323400	04	22	14.70
3301-A (3174-1/2/3/4, 3304-2/3) DESK CONSOLE REF INFO (USE 3170 OR 3300) CIRCUIT DESCRIPTION, DIAGRAMS, MAINTENANCE (USE 3304-A) MAINTENANCE - PMI/PMP (USE 3304-A) PARTS LIST (USE 3304-A)				
3302-A/BB316-A STORAGE MODULE REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CIRCUIT DESCRIPTION, DIAGRAMS, MAINTENANCE (USE 3304-A) WIRE LIST; HAND TABS (USE 3304-A) MAINTENANCE - PMI/PMP (USE 3304-A) EQUATION SUMMARY (USE 3304-A) CARD PLACEMENT (USE 3304-A) WIRE LIST (TERM LIST) (USE 3304-A) PARTS LIST (USE 3304-A)				
3304-A CENTRAL PROCESSOR CIRCUIT DESCRIPTION, DIAGRAMS, MAINT CE MAN REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) WIRE LIST; HAND TABS CE MANUAL MAINTENANCE - PMI/PMP CE MANUAL EQUATION SUMMARY CE MANUAL CARD PLACEMENT CE MANUAL WIRE LIST (TERM LIST) CE MANUAL PARTS LIST CE MANUAL	60152300	DT	22	10.15
	60317500	B	22	26.00
	60318300	A	22	01.00
	60153900	BA	22	20.00
	60154000	AZ	34	06.05
	60154100	BC	22	14.95
	60160700	E	22	10.00
3304-B/AC105-B (3304, 3304-2/3) CENTRAL PROC. REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CIRCUIT DESCRIPTION, DIAGRAMS, MAINTENANCE (USE 3304-A) WIRE LIST; HAND TABS (USE 3304-A) MAINTENANCE - PMI/PMP (USE 3304-A) EQUATION SUMMARY, CARD PLACEMENT CE MANUAL ** 3304-B/AC105-B, 3310-A, STD. OPT. 10099-B ONLY. ORDER 3304-A EQUATION SUMMARY IF INFORMATION REQUIRED FOR 3311-A, 3309-A, 3302-A, 3306-A/B/C, 3307-A. WIRE LIST (TERM LIST) CE MANUAL ** 3304-B/AC105-B, 3310-A, ST.OP.10099-B ONLY. ORDER 3304-A WIRE LIST IF INFORMATION REQUIRED FOR 3311-A, 3309-A, 3302-A, 3306-A/B/C, 3307-A PARTS LIST (USE 3304-A)	60213100	H	22	23.00
	60213200	F	22	15.50
3304-2 (AC105-B, AF101-A, 3301-A) BUSINESS				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
DATA PROCESSOR REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CE INFO (SEE APPROPRIATE EQUIPMENT)				
3304-3 (AC105-B, AF101-B, 3301-A) BUSINESS DATA PROCESSOR REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CE INFO (SEE APPROPRIATE EQUIPMENT)				
3306-A/B/C COMMUNICATION CHANNELS REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CE INFO (USE 3304-A)				
3307-A COMMUNICATION CHANNEL REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CE INFO (USE 3304-A)				
3309-A STORAGE MODULE REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CE INFO (USE 3304-A)				
3310-A (3174-2/4) FLOATING POINT MODULE REF INFO (USE 3170 OR 3300) CE INFO EXCEPT WIRE LIST, EQ SUM (USE 3304-A WIRE LIST/EQ SUMMARY (USE 3304-A OR 3304-B) FOR 3300 SYSTEMS) (USE ONLY 3304-B FOR 3170 SYSTEMS)				
3311-A (3174-2/4) MULTIPROGRAMMING MODULE REF INFO (USE 3170 OR 3300) CE INFO (USE 3304-A FOR 3300 SYSTEMS) (USE 3304-B FOR 3170 SYSTEMS)				
3312-A/AF101-A (3304-2) BUSINESS DATA PROCESSOR REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) MAINTENANCE - PMI/PMP (USE 3304-A) PARTS LIST (USE 3304-A) WIRE LIST (TERM LIST, HAND TABS) CE MANUAL EQUATION SUMMARY, CARD PLACEMENT CE MANUAL DIAGRAMS CE MANUAL MAINTENANCE COMMAND TIMING CHARTS	60197600 60186700 60162900 60209800	P P T H	22 22 22 22	07.05 13.50 05.15 11.80
3312-B/AF101-B (3304-3) BUSINESS DATA PROCESSOR REF INFO (USE 3300 COMPUTER SYSTEM REF MAN)				
3316-1 (FJ601-A) MULTIPLEXER CONTROLLER REFERENCE MANUAL TEST ROUTINE MANUAL	13796800 41600300	F A	22 22	05.00 01.35
3344 DIGIGRAPHIC CONTROLLER HDWR REF/CE MAN.	82146800	A00	22	05.15

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
3400 COMPUTER SYSTEM				
INSTRUCTION CARD	60070000			00.75
INSTRUCTION CODES (3400)	60150300			00.75
REFERENCE MANUAL	60028200	P	22	02.95
CUSTOMER ENGINEERING MANUALS				
CE DIAGRAMS	60096900	AF	22	15.00
CE INST/PART 1 THEORY OF OPERATION	60097000	C	22	13.20
MAINTENANCE MONITOR (SMM34) VOLS 1 AND 2	60126400	D	22	25.00
COMMAND TIMING CHARTS	60141800	CDE	22	08.35
WIRE TABS, CABLE TABS AND CROSS TABS	60146000	K	34	22.70
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)				
PARTS LIST	60149900	A	22	
3401 CONSOLE TYPEWRITER CONTROL CARD PLCMT, EQUATION SUMMARY,WIRE TABS,CABLE TABS,CROSS TABS	60145500	A	34	06.00
3404-A BASIC 16K COMPUTER CARD PLCMTS AND EQUATION SUMMARY VOL 1 AND 2	60145900	J	22	24.10
WIRE TABS, CABLE TABS AND CROSS TABS	60146000	K	22	22.70
3406-A STANDARD I/O CHANNEL CARD PLACEMENTS, EQUATION SUMMARY,WIRE TABS,CABLE TABS,CROSS	60145600	C,D	34	15.00
3409-A 32K STORAGE OPTION CARD PLACEMENTS, EQUATION SUMMARY,WIRE,CABLE AND CROSS TABS	60145700	B	22	09.30
3410-A FLOATING POINT OPTION C/P, EQ SUMMARY, WIRE LIST CE MANUAL (INCLUDES PREVIOUS PUB NO.S 32501400 AND 32501500)	32501300	B	22	06.50
3416-A STANDARD I/O CHANNEL CARD PLACEMENT, EQUATION SUMMARY, WIRE LIST CE MANUAL (INCLUDES INFO FOR PREVIOUS PUB NO.S 32503400 AND 32503500 - ALSO INCLUDES 3417-A INFO FOR PREVIOUS PUB NO.S 32503700, 32503800 AND 32503900)	32503300	E	22	28.70
3417-A DIRECT ACCESS CHANNEL CE INFO (SEE 3416-A)				
3421-A/B/3422-A/B/3423-A/B MAG TAPE CONTROLLER THFO OF OPER, MAINT, PARTS LIST, DIAGRAMS MAN	60102300	U	22	06.30
REFERENCE MANUAL	60331600	D	22	01.30
342X-A/B MAG TAPE CONTROLLER CARD PLACEMENT,	60150000	N	34	13.30

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
EQ. SUMMARY, WIRE TABS CE MANUAL				
3436-A DRUM CONTROLLER REFERENCE MANUAL	60333100	A	22	01.45
CE MANUAL	60114200	M, N	22	07.30
TEST ROUTINE	13793500		22	01.00
3446-A/B CARD PUNCH CONTROLLER REFERENCE MANUAL	60332100	B	22	01.20
CE MANUAL	60090400	Y	22	03.75
TEST ROUTINES - 3446, 3644/415/523/544	41602600	A	22	02.50
PUNCH/READER CARD PATTERNS FOR 3446-3644/ 415/523/544 CARD PUNCH TEST AND 3447-3649/ 405 CARD READER TEST	41602800		22	09.40
3447-A CARD READER CONTROLLER REF INFO (USE 3248-A REF MAN)	60091800	AB	22	02.65
CE MANUAL	41602700	A	22	01.30
TEST ROUTINES - 3447, 3649/405				
3447-B CARD READER CONTROLLER REF INFO (USE 3248-A REF MAN)				
CE MANUAL	60212800	M	22	03.60
TEST ROUTINES (USE 3447-A)				
3458-A LINE PRINTER CONTROLLER REFERENCE MANUAL	60332800	B	22	01.90
DIAGRAMS, CIRC. DESC., MAINT AND PARTS LIST	60158200	Z	22	07.75
CARD PLACEMENT, EQ SUMMARY, WIRE LIST CE MAN	60197000	S	22	24.50
3500 COMPUTER SYSTEM				
COMPUTER SYSTEM REFERENCE MANUAL	60200300	D	22	05.15
INSTRUCTION CODES (USE 3300)				
SMM REF INFO (USE 3300)				
HARDWARE MAINT FEATURES (3500 MASTER) GENERAL INFORMATION MANUAL (USE 3300)				
3502 (BB313-A, BB314-A, GH104-A) SYSTEM STORAGE REF INFO (USE 3500 REF MAN)				
3504-1 (AC104-A, CR105-A) PROCESSOR REF INFO (USE 3500 COMPUTER SYSTEM REF MAN.)				
3507-1 (DC111-A) DATA CHANNEL REF INFO (USE 3500 COMPUTER SYSTEM REF MAN.)				
3514-1 (AC106-A, CR106-A) BASIC PROCESSOR REF INFO (USE 3500 COMPUTER SYSTEM REF MAN)				
3514-2 (AC106-A, AF102-A, CR106-A) BUSINESS DATA PROCESSOR REF INFO (USE 3500 COMPUTER SYSTEM REF MAN)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
3514-3 (AC106-A, AT124-A, CR106-A) MULTI-PROGRAMMING PROCESSOR REF INFO (USE 3500 COMPUTER SYSTEM REF MAN)				
3514-4 (AC106-A, AF102-A, AT124-A, CR106-A) GENERAL PURPOSE PROCESSOR REF INFO (USE 3500 COMPUTER SYSTEM REF MAN)				
3516-1 (FJ601-A, FV129-A) MULTIPLEXER CONTROLLER REFERENCE MANUAL	41610700	A	22	01.00
3518 (FA416-B, FA417-B, FA420-B) MAGNETIC TAPE CONTROLLER REFERENCE MANUAL	60287600	P	22	03.80
3522 (AT122-A, AT123-A) REAL TIME INTERRUPT REF INFO (USE 3500 COMPUTER SYSTEM REF MAN.)				
3528 (FA417-B, FA418-A, FA420-B) MAGNETIC TAPE CONTROLLER REF INFO (USE 3518)				
3553-1 (FA705-A/B) MASS STORAGE CONTROLLER REFERENCE MANUAL	60278500	B	22	02.40
3553-2 (FA704-A/B/C) MASS STORAGE CONTROLLER REF INFO (USE 3553-1)				
3555-1 (FF307-B) LINE PRINTER CONTROLLER REFERENCE MANUAL	60231300	C	22	01.00
3600 COMPUTER SYSTEM REFERENCE MANUAL	60021300	N	22	03.30
INSTRUCTION CODES 3600/3800	60044400	C		03.00
CUSTOMER ENGINEERING MANUALS				
SYSTEM MAINT. MONITOR REF MANUAL	60093900	H	22	57.50
PARTS LIST	60157300	C	22	05.80
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)				
CARD TESTER REFERENCE/INSTRUCTION	60096800		22	
3601 CONSOLE DIAGRAMS	60042600	J	22	06.35
CARD PLACEMENT AND EQUATION SUM. CE MANUAL	31605400	A	22	02.25
CE INSTRUCTION MANUAL	60043400	B	22	08.75
WIRE TABS	31600200	C	22	01.50
3602-A/3802-1 COMMUNICATIONS MOD CE DIAGRAMS	60041700	J	34	01.60

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
COMMUNICATTON MOD INSTRUCTION/CE MANUAL C/P, EQ SUMMARY, W/L CE MANUAL (INCLUDES PREVIOUS PUB NO. 31605500)	60096700 31600500	E B	22 22	03.50 12.85
3604-A/B COMPUTATION MODULE CE DIAGRAMS VOLS 1 AND 2	60042100	AV	34	08.45
CE INSTRUCTION/CIRCUIT DESCRIPTION	60047600		22	18.00
PRELIMINARY COMMAND TIMING CHARTS	60093800		22	14.70
ARITHMETIC COMMAND TIMING CHARTS	60100700		22	06.45
CARD PLACEMENT, EQ SUMMARY CE MANUAL	31605600	S	22	42.35
WIRE LIST CE MANUAL	31600800	P	22	45.70
3604-B COMPUTATION MODULE WIRE LIST CARD PLACEMENT AND EQUATION SUM. VOLS. 1,2	17804500 60150700	K L	22 34	35.00 43.50
3606-A BI-DIRECTIONAL DATA CHAN CE DIAGRAMS CE INSTRUCTION MANUAL	60041800 60043300	F D	34 22	01.25 07.45
CHASSIS MAPS AND SUMMARY	31605700	D	34	05.70
WIRE TABS	31601100	D	22	03.50
3607-A 24 BIT DATA CHANNEL CE DIAGRAMS	60041900	D	34	03.30
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVATLABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)				
WIRE TABS	31601400			
CHASSIS MAPS AND SUMMARY	31605800			
3608-A 48 BIT DATA CHANNEL CE DIAGRAMS	60047900	C	34	03.10
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)				
WIRE LIST	31601700	C		
CHASSIS MAPS AND SUMMARY	31605900	B		
3609-A STORAGE MODULE CE DIAGRAMS CE INSTRUCTION MANUAL	60042000 60095500	R E	34 22	03.75 05.95
CARD PLACEMENTS,EQ SUMMARY AND WIRE TABS	60159200	B	34	21.85
3610-A/3810-A COMMUNICATIONS MOD CE DIAGRAMS CE INSTRUCTION MANUAL	60121400 60121300	C D	22	01.00 05.00
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILA3LE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WFEKS FOR PROCESSING AND DELIVERY.)				
CARD PLACEMENT, EQUATION SUMMARY	31605200			
WIRE LIST	31605300			

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
3613 SIDWAYS ALOGRITHM BOX	60047700	B	22	03.00
362X-A MAGNETIC TAPE CONTROLLER				
REFERENCE MANUAL	60331500	C	22	01.30
CE DIAGRAMS MANUAL	60042200	AF	34	10.00
REFERENCE/INSTRUCTION MANUAL	60043500	J	22	09.50
CARD PLACEMENTS AND EQUATION SUMMARY	31606100	L	34	37.00
WIRE LIST CE MANUAL	31602300	P	22	17.65
362X-B MAGNETIC TAPE CONTROLLER				
REF INFO (USE 362X-A)				
CARD PLACEMENT AND EQUATION	60159600	J	34	34.00
WIRE LISTS CE MANUAL	60159700	J	22	24.00
363X-A DTSK FILE CONTROLLER				
REFERENCE MANUAL	60333200	A	22	01.55
CIRCUIT DESC., MAINT., PARTS LIST, CARD	60099800	D	22	22.55
PLACEMENT, EQUATION SUMMARY CE MANUAL				
WIRE LISTS CE MANUAL	60197300	C	22	10.00
3637-A DRUM STORAGE CONTROLLER				
REF/CE INFO (USE 3436-A)				
3637-B/C DRUM STORAGE CONTROLLER				
CE MANUAL	60224900	H	22	07.50
3641-A CARD READER CONTROLLER				
CARD PLACEMENTS AND EQUATION SUMMARY	31606200		34	03.20
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT				
ARE AVAILABLE ON A SPECIAL ORDER BASIS IN				
MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4				
WEEKS FOR PROCESSING AND DELIVERY.)				
REFERENCE/INSTRUCTION MANUAL	60107200			
WIRE TABS	31602600		22	
3643 CARD READ WIRE TABS CE MANUAL	31602900			02.90
3644-A CARD PUNCH CONTROLLER				
REF INFO (USE 3446-A/B REF MAN)				
CE MANUAL	60048400	Z	22	09.50
TEST ROUTINES (USE 3446-A)				
3649-A CARD READER CONTROLLER				
REF INFO (USE 3248-A REF MAN)				
REFEPECF/INSTRUCTION MANUAL	60097900	B	22	02.50
CE MANUAL	60049800	W	22	04.30
TEST ROUTINES (USE 3447-A)				
3655-A LINE PRINTER ADAPTER EQ. SUM., CARD				
PLACEMENT, WIRE LIST CE MANUAL	60291000	A	22	03.80
CE DIAGRAMS MANUAL	60042500	E	34	03.20

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
3659-A/B/C LINE PRINTER CONTROLLER REF INFO (USE 3256-A/B/C)				
DIAGRAMS CE MANUAL	60094200	S	22	02.70
CIRCUIT DESCRIPTION, MAINT., PARTS LIST, CARD PLACEMENT, EQ SUMMARY, WIRE LIST CE MANUAL	60126500	M	22	10.95
TEST ROUTINES (USE 3256-A)				
3681-A DATA CHANNEL CONVERTER CE MANUAL	60042300	F	22	13.05
REFERENCE MANUAL	60333400	A	22	01.00
SYSTEM MAINTENANCE MONITOR REFERENCE	60169100	B	22	07.50
SYSTEMS MAINT. MONITOR PROG. LISTINGS	60181200	B	22	10.60
3682-A/B/C SATELLITE CONTROLLER CE MANUAL	60042400	H	22	03.00
REFERENCE MANUAL	60333500	A	22	01.00
TEST ROUTINE	41600700	A	22	01.00
3691-A PAPER TAPE READER/PUNCH REFERENCE MANUAL	60333000	B	22	01.00
PAPER TAPE READER PUNCH WIRE TABS	60140800	D	22	01.50
REFERENCE INSTRUCTION AND DIAGRAMS MANUAL	60048300	F	22	03.40
3691-B/C/D/E PAPER TAPE READ/PUNCH CE MANUAL REF INFO (USE 3691-A)	60124800	T	22	08.00
3692-A PROGRAM CONTROLLED I/O TYPEWRITER REFERENCE MANUAL	60332600	A	22	01.00
CE DIAGRAMS	60094400	E	34	02.50
WIRE TABS	31603800	C	22	01.75
CHASSIS MAPS AND SUMMARY	31606600	C	34	05.50
3694-A PAPER TAPE READER/PUNCH DIAGRAMS	60104900	A	22	01.30
REFERENCE MANUAL	60107400	A	22	03.80
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST				
CARD PLACEMENT	31554400			
EQUATION SUMMARY	31554300			
3694-C/D PAPER TAPE READER/PUNCH CE MANUAL	60125400	S	22	04.20
REFERENCE MANUAL	60203300	A	22	01.50
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST				
CARD PLACEMENT	31646700	E		
EQUATION SUMMARY	60149700	M		

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
3800 COMPUTER SYSTEM REFERENCE MANUAL	60162300	C	22	04.70
CUSTOMER ENGINEERING MANUALS				
MAINTENANCE COMMAND TIMING CHARTS	60160000	A	22	22.30
CE MANUAL-POWER DIAGRAMS	60194400	A	22	01.00
PARTS LIST CE MANUAL	60197700	A	22	08.60
3801-A CONSOLE DIAGRAMS,C/P,EQ SUMMARY,W/L AND TERM LIST CIRCUIT DESCRIPTION AND MAINTENANCE	60159000	B		02.40
	60199300	A	22	07.80
3802-A COMMUNICATION MODULF (USE 3602-A MANUAL				
3803-B STORAGE MOD DIAG,CIR DES,MAINT,C/P,W/L	60184500	C	22	06.50
3804-A/3811-A COMPUTATION MOD AND RELOCATION UNIT DIAGRAMS AND CIRCUIT DESCRIPTION CARD PLACEMENT, EQUATION SUMMARY WIRE AND TERM LISTS, HAND TABS	60154500	R	22	17.55
	60159900	K	34	30.30
	60186100	J	22	19.75
3806-A DATA CHANNEL CE MANUAL CE INSTRUCTION MANUAL	60122700	D	22	09.25
	60100800	B	22	04.75
3810-A COMMUNICATION MODULE (USE 3610-A MANUAL				
3816 PRIORITY DATA CHANNEL CE DIAGRAM,CIRC DESC,P/L,CP,EQ SUM,W/L REFERENCE MANUAL	60153000	B	22	16.05
	60157100	A	22	02.20
5100 CUSTOMER ENGINEERING MANUAL VOLS. 1 AND 2 MIMIC SOFTWARE REFERENCE MANUAL COMPASS ASSEMBLER SOFTWARE REF MAN COMPASS SOFTWARE REFERENCE MANUAL PROGRAM CHECKOUT MONITOR SOFTWARE REF MAN	14163300	A	22	12.00
	14166700			01.35
	14196600			03.90
	14166800	A		04.45
	14167100	A	22	01.05
5600 SERIES MPP REFERENCE MANUAL MAINTENANCE, DIAGS, WIPE LIST CE MANUAL	14232000	A	22	07.85
	14247900	A	22	07.45
6000 COMPUTER SYSTEMS (6014, 6015, 6200, 6400, 6500, 6600, 6700) INSTRUCTION CARD INSTRUCTION CODES INPUT/OUTPUT SPECIFICATIONS (USE CYBER 72) 73, 74 I/O SPECIFICATIONS) REFERENCE MANUAL SCOPE 3.3 ON-LINE DIAGNOSTICS GIM SCOPE 3.4 ON-LINE DIAGNOSTICS GIM SCOPE 3.3 ON-LINE DIAGNOSTICS REFERENCE MAN. SCOPE 3.4 ON-LINE DIAGNOSTICS REFERENCE MAN.	60164500	C		00.75
	60141900	F		01.00
	60100000	AE	22	03.50
	60309800	A	22	01.00
	60364700	A	22	01.05
	60320700	02	22	02.20
	60364800	D	22	03.15

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
6000/CYBER OPTIONS GENERAL INSTALLATION PROCEDURES MANUAL	60415600	A	22	03.15
CUSTOMER ENGINEERING MANUALS				
PERIPHERAL CONTROLLER CABINETS REF/CE MANUAL (1700/3000/6000) (REFER TO 3000 SERIES)				
REFRIGERATION MANUALS - (SEE CATALOG SEC 4)				
6014 6000 STATION (AT217-A)				
REF INFO (PPU AND CPU - USE 6000 SERIES REF MANUAL) (INTERFACE REF INFO - USE 6682 AND DT122-A REF OR REF/CE MANUALS)				
6015-7/8/9 6000 STATION (USE 6014)				
6400/6500-A/B/C CENTRAL COMPUTERS				
* THE MANUALS LISTED BELOW ARE USED *				
* WITH ALL 6400/6500-A/B/C COMPUTERS *				
* UNLESS INDICATED OTHERWISE *				
DIAGRAM MANUALS				
CPU,PPU,CENTRAL MEMORY,CLOCK,ECS COUPLER AND POWER DIAGRAMS	60146100	BL	22	15.00
MAINTENANCE MANUALS				
MAINTENANCE AND COMMAND TIMING	60182100	J	22	23.50
INSTANT SMM CODE BOOK (64/65/6600)	60299500	D		01.00
SYSTEM MAINTENANCE MONITOR REFERENCE MANUAL VOLS 1-5(AVAIL IN SETS ONLY)	60160600	18	22	31.00
MAINTENANCE PMI/PMP CE MANUAL	60309600	G	22	27.15
PARTS DATA				
PARTS LIST(6404-A,6414-A/B/C ONLY)	60187200	C	22	08.60
PARTS LIST(6404-A,6415-A/B/C ONLY)	60266300	A	22	10.85
PARTS LIST(6413-C/O ONLY)	60223300	C	22	06.00
PARTS LIST(6514-C ONLY)	60224200	B	22	04.05
PARTS LIST(6513-C/D ONLY)	60267200	A	22	09.70
WIRE LISTS				
CHASSIS 1 CHASSIS TABS (INCL 6411/16-A/B)	60166100	T	22	15.00
CHASSIS 2 CHASSIS TABS (INCL 6400/6500-D)	60166200	AA	22	25.30
CHASSIS 3 CHASSIS TABS	60166300	AR	22	16.60
CHASSIS 4 CHASSIS TABS	60180000	L	22	15.00
CHASSIS 5/7 CHASSIS TABS	60166400	M	22	10.00
CHASSIS 8 CHASSIS TABS	60187700	V	22	06.85
CHASSIS 9/11 CHASSIS TABS	60197100	C	22	10.00
CHASSIS 10/12 CHASSIS TABS	60197200	C	22	10.00
CABLE TABS(FOR 6404-A,6414/6514-A/B/C ONLY)	60166000	M	22	10.70
CABLE TABS(FOR 6405-A,6415-A/B/C ONLY)	60169700	M	22	07.50
CABLE TABS(FOR 6413/6513-A/B/C ONLY)	60188900	G	22	14.85
6411-A,6416-A AUGMENTED I/O BUFFER/CONTROL				
DIAGRAMS AND CIRCUIT DESCRIPTIONS	60146200	U	22	05.05
CHASSIS 1 CHASSIS TABS(SEE 64/6500-A/B/C)				
CHASSIS 3 CHASSIS TABS CE MANUAL	60180100	H	22	13.80
CHASSIS 4 CHASSIS TABS CE MANUAL	60187800	G	22	06.10

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
CABLE TABS CE MANUAL	60187900	K	22	07.10
6400/6500-D CENTRAL COMPUTER				
* THE MANUALS LISTED BELOW ARE USED *				
* WITH ALL 6400/6500-D COMPUTERS *				
* UNLESS INDICATED OTHERWISE *				
DIAGRAM MANUALS				
CPU, CENTRAL MEMORY, CLOCK, ECS COUPLER AND POWER DIAGRAMS	60246800	AG	22	27.75
PERIPH PROCESSING UNIT DIAGRAMS	60246500	K	22	03.05
MAINTENANCE MANUALS				
SYSTEM MAINT MONITOR REF(SEE 64/6500-A/B/C)				
MAINTENANCE-PMI/PMP (SEE 64/6500-A/B/C)				
PARTS DATA				
PARTS LIST (6414-D ONLY)	60268000	B	22	03.50
PARTS LIST(6514-D ONLY)	60267100	A	22	03.80
PARTS LIST(6415-D,6513-D,SEE 64/6500-A/B/C)				
WIRE LISTS				
CHASSIS 1 CHASSIS/CABLE TABS	60246900	S	22	38.40
CHASSIS 2 CHASSIS TABS(SEE 64/6500-A/B/C)				
CHASSIS 3 CHASSIS/CABLE TABS	60248500	U	22	12.00
CHASSIS 4 CHASSIS/CABLE TABS	60248600	H	22	14.00
CHASSIS 5 CHASSTIS/CABLE TABS CE MANUAL	60248700	C	22	13.00
CHASSIS 6 CHASSIS/CABLE (FOR 6415.D ONLY)	60249000	K	22	10.60
CHASSIS 8 CHASSIS/CABLE TABS	60249100	S	22	13.65
CHASSIS 9/11 CHASSIS/CAPLE TABS	60248800	E	22	14.30
CHASSIS10/12 CHASSIS/CABLE TABS	60248900	F	22	09.20
HAND TABS,SENSE AMP WIRING(FOR 64/65/6600-D)	60269100	A	22	02.38
6413-E (AA105-A WITH AT140-A)				
6414-E (AA105-A)				
6415-E (AA103-A) CENTRAL COMPUTER				
6415-7 (AA103-D) CENTRAL COMPUTER				
6415-8 (AA103-C) CENTRAL COMPUTER				
6415-9 (AA103-B) CENTRAL COMPUTER				
6500-C USE STANDARD 6400-C MANUALS. IF AT196-A/B AND DT117-A OR DT204-A AND AT196-A AND AT195-A ARE INSTALLED USE MANUALS LISTED UNDER AT195-A.				
6500-C WITH ECS CAPABILITY USE MANUALS LISTED UNDER AT195-A				
6500-D USE STANDARD 6400-D MANUALS. IF AT198-A AND DT143-A OR DT205-A AND AT194-A AND AT198-A ARE INSTALLED USE MANUALS LISTED UNDER AT194-A.				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
6500-D WITH ECS CAPABILITY USE MANUALS LISTED UNDER AT194-A.				
6500-E USE STANDARD 6400-E MANUALS. IF AT141-A AND DT143-A OR AT141-A AND DT205-A AND AT194-A ARE INSTALLED USE MANUALS LIST UNDER AT194-A.				
6500-E WITH ECS CAPABILITY USE MANUALS LISTED UNDER AT194-A.				
6601-A THROUGH F CENTRAL COMPUTER(SER.1-7) DIAGRAMS AND CIRCUIT DESC.(SEE 6601-H/J) CHASSIS 1,5,7,8,13,14,15 AND 16 CHASSIS TABS(SEE 6601-H/J) * THE FOLLOWING MANUALS FOR THE * * ABOVE SYSTEM ARE AVAILABLE ON A * * A SPECIAL ORDER BASIS IN MAX.QTY * * OF 2 COPIES.ALLOW AT LEAST 3-4 * * WEEKS FOR PROC.AND DELIVERY. * PRICE AVAILABLE UPON REQUEST				
CHASSIS 2 CHASSIS TABS(INCL 6604-B)	60161500		22	
CHASSIS 3 CHASSIS TABS	60161600		22	
CHASSIS 4 CHASSIS TABS	60161800		22	
CHASSIS 5 CHASSIS TABS(INCL 6604-B)	60162000		22	
CHASSIS 9 CHASSIS TABS	60162100		22	
CHASSIS 10 CHASSIS TABS	60162200		22	
CABLE TABS(SEE 6601-H/J)				
6601-H/J CENTRAL COMPUTER **DIAGRAM MANUALS**				
CPU, FUNCTIONAL UNIT, PERIPHERAL PROC. UNIT CLOCK,ECS COUPLER,AND POWER DIAGRAMS **MAINTENANCE AIDS**	60119300	DR	22	09.15
SYSTEM MAINT MON.REF(SEE 6400/6500-A/B/C) MAINTENANCE-PMI/PMP(SFE 6400/6500-A/B/C) **PARTS DATA**				
PARTS LIST(FOR 6601-H/J,6613-A/B/C ONLY) **WIRE LISTS**	60157400	D	22	17.20
CHASSIS 1 CHASSTIS TABS	63019800	AD	22	17.35
CHASSIS 2 CHASSIS TABS	63019700	AL	22	25.55
CHASSIS 3 (FOR 6601-H/J,6613-A/B/C ONLY)	63019600	BD	22	14.30
CHASSIS 4 (FOR 6601-H/J,6613-A/B/C ONLY)	63019200	W	22	10.00
CHASSIS 5 CHASSIS TABS	60150800	BP	22	16.85
CHASSIS 6 CHASSIS TABS	63017400	Z	22	20.00
CHASSIS 7 CHASSIS TABS	63017300	P	22	21.10
CHASSIS 8 CHASSIS TABS	63017200	AF	22	21.20
CHASSIS 9 (FOR 6601-H/J,6613-A/B/C ONLY)	63017100	V	22	10.00
CHASSIS 10 (FOR 6601-H/J,6613-A/B/C ONLY)	63016900	S	22	12.30
CHASSIS 12 CHASSIS TABS(SEE 6612-B/E)				
CHASSIS 13 (FOR 6601-H/J,6613-A/B/C ONLY)	63025600	R	22	09.15
CHASSIS 14 (FOR 6601-H/J,6613-A/B/C ONLY)	63025500	P	22	07.80

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CHASSIS 15 (FOR 6601-H/J,6613-A/B/C ONLY)	63025400	N	22	08.00
CHASSIS 16 (FOR 6601-H/J,6613-A/B/C ONLY)	63024900	R	22	07.25
CABLE TABS(FOR 6601-H/J,6613-A/B/C ONLY)	60148900	AJ	22	17.05
6602-A THROUGH E CONSOLE DISPLAY CONTROLLER REFERENCE MANUAL	60333900	B	22	01.00
DIAGRAMS (6602-A THRU E, 6612-A THRU E)	60389800	A	22	03.05
PARTS LIST CE MANUAL	60266400	A	22	01.00
CHASSIS/CABLE TABS CE MANUAL	63016700	N	22	32.45
6603-A/B/C DISK SYSTEM DIAGRAMS, WIRE LISTS CE MANUAL	60389900	A	22	06.30
REFERENCE MANUAL	60334000	A	22	01.00
SERVICE MANUAL-DIAGRAMS,CIRC DESCRIPTION	60127000	C	22	20.70
PARTS LIST CE MANUAL	60266500	B	22	01.20
MAINTENANCE-ELECTRONIC TEST PROCEDURES	60213300	C	22	02.40
6604-A/C CENTRAL COMPUTER DIAGRAMS(SEE 6601-H/J)				
CHASSIS 1,2,5,6,7,AND 8 CHASSIS TABS(SEE 6601-H/J)				
CHASSIS 3 (FOR 6604-A/C,6614-A/B/C ONLY)	63033800	BG	22	17.50
CHASSIS 4 (FOR 6604-A/C,6614-A/B/C ONLY)	63033700	Z	22	13.00
CHASSIS 9 (FOR 6604-A/C,6614-A/B/C ONLY)	63033600	S	22	10.00
CHASSIS 10(FOR 6604-A/C,6614-A/B/C ONLY)	63033500	T	22	13.85
CABLE TABS(FOR 6604-A/C,6614-A/B/C ONLY)	60149600	AG	22	11.50
PARTS LIST(FOR 6604-A/C,6614-A/B/C ONLY)	60267300	A	22	11.00
SYSTEM MAINT MONITOR REFERENCE VOL 1-5(SEE 6601-H/J)				
6604-B COMPUTER SYSTEM(SERTAL 1-7) DIAGRAMS AND CIRCUIT DESC(SEE 6601-H/J)				
SYST.MAINTENANCE MONITOR(SEE 6601-H/J)				
PARTS LIST (SEE 6604-A)				
CHASSIS 1,6,7,AND 8(SEE 6601-H/J)				
CHASSIS 2(SEE 6601-A THROUGH F)				
CHASSIS 5(SEE 6601-A THROUGH F)				
CHASSIS 9 AND 10(SEE 6604-A/C)				
6612-A THROUGH E CONSOLE DTSPLAY CONTROLLER REF INFO (USE 6602-A)				
DIAGRAMS AND CIRC DESC(SEE 6602-A-E)				
PARTS LIST(SEE 6602-A-E)				
CHASSIS/CABLE TABS(SEE 6602-A-E)				
6612-F/G CONSOLE DISPLAY CONTROLLER REF INFO (USE 6602-A)				
DIAGRAMS, CIRC DESC, CARD PLACMT, WIRE LIST,	60246400	K	22	16.20
6613-A/B/C COMPUTER SYSTEM(SEE 6601-H/J)				
6613-D COMPUTER SYSTEM CPU, FUNCTIONAL UNIT CE DIAGRAMS	60224800	W	22	15.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CENT. MEM, CLOCK, ECS COUPLER, POWER DIAGRAMS PERIPH PROC UNIT DIAGRAMS(SEE 6400/6500-D)	60246600	U	22	04.90
PARTS LIST CE MANUAL	60253300	C	22	08.65
MAINTENANCE-CLOCK TIMING	60289000	B	22	01.80
SYST MAINT MONITOR REF VOL 1-5(SEE 6601-H)				
CHASSIS 1 CHASSIS TABS(SEE 64/6500-D)				
CHASSIS 4 CHASSIS/CABLE TABS CE MANUAL	60247000	R	22	19.55
CHASSIS 5 CHASSIS/CABLE TABS CE MANUAL	60247100	Z	22	20.00
CHASSIS 6 CHASSIS/CABLE TABS CE MANUAL	60247200	H	22	17.40
CHASSIS 7 CHASSIS/CABLE TABS CE MANUAL	60247300	E	22	23.45
CHASSIS 8 CHASSIS/CABLE TABS CE MANUAL	60247400	J	22	26.20
CHASSIS 9 CHASSIS/CABLE TABS CE MANUAL	60247500	N	22	10.90
CHASSIS 10 CHASSIS/CABLE TABS CE MANUAL	60247700	F	22	07.60
CHASSIS 11/15 CHASSIS/CABLE TABS CE MANUAL	60247900	C	22	10.20
CHASSIS 12/16 CHASSIS/CABLE TABS CE MANUAL	60248100	D	22	12.80
CHASSIS 13/14 CHASSIS/CABLE TABS CE MANUAL	60248300	J	22	19.80
HAND TABS-MEMORY SENSE AMP W/L(SEE 6400-D)				
6613-E (AA104-A)				
6614-A/B/C COMPUTER SYSTEM(SEE 6604-A)				
6614-D COMPUTER SYSTEM DIAGRAM MANUALS(SEE 6613-D)				
PARTS LIST CE MANUAL	60267400	B	22	05.05
MAINTENANCE MANUALS(SEE 6613-D)				
CHASSIS 1 CHASSIS/CABLE(SEE 64/6500-D)				
CHASSIS 4,6,7,AND 8 TABS(SEE 6613-D)				
CHASSIS 5 CHASSIS/CABLE TABS	60251200	Y	22	17.45
CHASSIS 9 CHASSIS/CABLE TABS	60247600	P	22	14.50
CHASSIS 10 CHASSIS/CABLE TABS	60247800	D	22	07.75
CHASSIS 11 CHASSIS/CABLE TABS	60248000	E	22	08.75
CHASSIS 12 CHASSIS/CABLE TABS	60248200	D	22	12.00
HAND TABS-MEMORY SENSE AMP W/L(SEE 6400-D)				
DATA CHANNEL EQUIP CHASSTS TABS(SEE DC211-A)				
6614-E (AA103-A)				
6622-A/B MAGNETIC TAPE CONTROLLER REFERENCE MANUAL	60333600	A	22	01.10
DIAGRAMS, WIRE LIST CE MANUAL	60390000	A	22	
(THE FOLLOWING MANUALS MANUALS FOR THE ABOVE PRODUCT ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES ALLOW AT LEAST 3-4 WEEKS FOR DELIVERY)				
PARTS LIST CE MANUAL	60253200	A	22	01.70
6633-C (BB325-A) EXTENDED CORE STORAGE ASSEM.				
6633-D (BB325-B) EXTENDED CORE STORAGE ASSEM.				
6634-C (BB319-A) EXTENDED CORE STORAGE ASSEM.				
6634-D (BB319-B) EXTENDED CORE STORAGE ASSEM.				
6635-C (BB323-A) EXTENDED CORE STORAGE ASSEM.				
6635-D (BB323-B) EXTENDED CORE STORAGE ASSEM.				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
6636-C (BB324-A) EXTENDED CORE STORAGE ASSEM. 6636-D (BB324-B) EXTENDED CORE STORAGE ASSEM. EXTENDED CORE STORAGE REFERENCE MANUAL	60225100	F,G	22	01.00
6638 DISK FILE (USE 6639)				
6639 DISK FILE SYSTEM REFERENCE MANUAL	60334100	E	22	01.00
DIAGS, CIRC DESC, MAINT, P/L, C/P, W/L, CHASSIS TABS	60227300	H	22	04.45
6640-A/B EXT. CORE STORAGE CONTROLLER DIAGRAMS CIRC. DESC., MAINT., P/L, C/P, AND W/L	60186000	AM	22	07.60
6640-D ECS CONTROLLER HOWE MAINT. MANUAL	60440500	B	22	25.20
6641-A (DC110-A) ECS MASS STORAGE CONTROLLER REFERENCE MANUAL	60334200	A	22	01.00
6642-1 (DC135-A) DISTRIBUTIVE DATA PATH OPERATION AND PROGRAMMING REFERENCE MANUAL	60376300	A	22	01.00
6671-A/B (FJ411-A/B) DATA SET CONTROLLER REFERENCE MANUAL	60334600	E	22	02.70
6671-1 (FJ427-A) DATA SET CONTROLLER REF INFO (USE 6671-A/B)				
6671-3 (FJ440-A) DATA SET CONTROLLER HARDWARE REFERENCE MANUAL	60399900	B	22	01.30
6673/6674 DATA SET CONTROLLER REFERENCE MANUAL	60334500	B	22	01.00
CIRCUIT DESCRIPTION, MAINTENANCE, PARTS LIST CARD PLACEMENT, EQ SUMMARY CE MANUAL	60201500	N	22	04.25
WIRE LISTS CE MANUAL	60205400	L	22	02.35
6675 DATA SET CONTROLLER CE MANUAL	38700400	D	22	01.45
6676-A TTY MULTIPLEXER REFERENCE MANUAL	38706000	C	22	01.20
CE MANUAL	38708400	K	22	10.30
6676-B/C TTY MULTIPLEXER REFERENCE MANUAL	38707800	E	22	02.90
CE MANUAL	38706100	S	22	23.95
6681-B/C/D DATA CHANNEL CONVERTER REFERENCE MANUAL	60334400	F	22	02.55
CE INFO (USE DC211-A, CATALOG SEC. 1)				
6681-E DATA CHANNEL CONVERTER				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE MANUAL	60440800	A	22	17.25
6682-A SATELLITE COUPLER REFERENCE MANUAL CE MANUAL	60334300 60390100	B E	22 22	01.50 02.10
6683-A SATELLITE COUPLER REF INFO (USE 6682-A) CE INFO (USE 6682-A)				
6684-1 (DC211-A) DATA CHANNEL CONVERTER REF INFO (USE 6681-B/C/D)				
6700 DUAL CENTRAL PROCESSOR REF INFO (USE 6000) 6700-A/B/C (USE AT153-A OR AT154-A AND AE116-B) 6700-D (USE AT155-A OR AT156-A AND AE116-C) 6700-E (USE AE116-C)				
7021-1 (FA434-A/B, DT209-D OR FA401-A/B) MAGNETIC TAPE CONTROLLER GENERAL INFORMATION MANUAL	60365100	C	22	01.25
7021-2 (FA434-A/B, DT209-D OR FA402-A/B) MAGNETIC TAPE CONTROLLER REF INFO (USE 7021-1)				
7030-X ECS REF INFO FOR ECS SYSTEMS (USE CYBER 72/73/74 ECS DESCRIPTION/PROGRAMMING MANUAL - VOL.3 - PUBLICATION NUMBER 60347100) POWER DIST/WARNING SYSTEM INFO (USE AA115-A)				
7030-1 (6640-B, AT247-A, BB395-A, DC135-A) ECS 125K (FOR CYBER 72 OR 73)				
7030-1 (6640-B, AT249-A, BB395-A, DC135-A) ECS 125K (FOR CYBER 74)				
7030-2 (6640-B, AT247-A, BB394-A, DC135-A) ECS 250K (FOR CYBER 72 OR 73)				
7030-2 (6640-B, AT249-A, BB394-A, DC135-A) ECS 250K (FOR CYBER 74)				
7030-4 (6640-B, AT247-A, BB393-A, DC135-A) ECS 500K (FOR CYBER 72 OR 73)				
7030-4 (6640-B, AT249-A, BB393-A, DC135-A) ECS 500K (FOR CYBER 74)				
7030-8 (6640-B, AT247-A, BB393-A, DC135-A) ECS 1000K (FOR CYBER 72 OR 73)				
7030-8 (6640-B, AT249-A, BB393-A, DC135-A) ECS 1000K (FOR CYBER 74)				
7030-16 (6640-B, AT247-A, BB393-A, DC135-A) ECS 2000K (FOR CYBER 72 OR 73)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
7030-16 (6640-B, AT249-A, 98393-A, DC135-A) ECS 2000K (FOR CYBER 74)				
7030-1XX (CYBER 170) EXTENDED CORE STORAGE SUBSYSTEM HARDWARE REFERENCE MANUAL	60430000	B	22	03.25
7054-1 (DT203-C, FA710-A/B/C/D/E/F, FA719-A/B/C/D, MA710-A/B) GENERAL INFORMATION MANUAL	60364400	D	22	02.60
OPERATION AND PROGRAMMING MANUAL	60363900	J	22	01.65
7054-2 (DT203-C, DT220-A/B/D, FA710-A/B/C/D, FA719-A/B/C/D, MA710-A, MA720-B) DISK STORAGE CONTROLLER GENERAL INFO (USE 7054-1) OPERATION AND PROGRAMMING (USE 7054-1)				
7054-21 (FA722-A/B, MA710-A) DISK STORAGE CONTROLLER REF INFO (USE 7054-1)				
7054-22 (FA722-A/B, DT220-C, MA710-A) DISK STORAGE CONTROLLER REF INFO (USE 7054-1)				
7054-41 (DT716-A, FA722-A/B, MA710-A) DISK STORAGE CONTROLLER REF INFO (USE 7054-1)				
7054-42 (DT220-C, FA722-A/B, MA710-A) DISK STORAGE CONTROLLER REF INFO (USE 7054-1)				
7077-1 (DT175-A, FJ430-A, GH408-A) COMMUNICATIONS STATION REFERENCE MANUAL	60364600	A	22	01.75
7600 COMPUTER SYSTEM REF INFO (USE CYBER 76 REFERENCE MANUAL)				
7601-1 (AA102-A, AB101-A, GH214-A, CC514-A/B, GE226-A, GE232-A) CENTRAL COMPUTER REF INFO (USE 7600 COMPUTER SYSTEM REF MAN.)				
7611-1/2 (AB101-A, AB102-A/B, GH216-A, GH218-A, GH105-A/B, GE232-A) I/O STATION				
7611-11 () PERIPHERAL COMMUNICATIONS STATION REFERENCE MANUAL	60399400	C	22	02.95

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
7618-1 (FA428-A) MAGNETIC TAPE CONTROLLER REFERENCE MANUAL	60341600	H	22	02.00
7622-1 (FA434-A/B, DT210-B OR FA403-A/B) MAGNETIC TAPE CONTROLLER REF INFO (USE 7021-1)				
7622-2 (FA438-A/B, DT210-B OR FA404-A/B) MAGNETIC TAPE CONTROLLER REF INFO (USE 7021-1)				
7628-1 (FA429-A) MAGNETIC TAPE CONTROLLER REF INFO (USE 7618-1)				
7629-1/2 (FA428-A, FA429-A) MAGNETIC TAPE CONTROLLER SUBSYSTEM REF INFO (USE 7618-1)				
7638-1 (BH405-C, FA802-A, GH217-A) DISK STORAGE SUBSYSTEM REFERENCE MANUAL SEE INFO FOR CONTROLLER (USE FA802-A, CATALOG SECTION 1)	60265500	D	22	01.00
7639-1 (FA202-A) MASS STORAGE CONTROLLER HOWE REFERENCE MANUAL	60437300	A	22	01.50
7639-2 (FA103-A, FA202-A) MASS STORAGE CONTROLLER REF INFO (USE 7639-1)				
7654-1 (DT210-A, FA710-A/B/C/D/E/F, FA720-A/B/C/D, MA710-A, MA720-A) DISK STORAGE CONTROLLER GENERAL INFO (USE 7054-1) OPERATION AND PROGRAMMING (USE 7054-1)				
7681 (DK518-A) DATA CHANNEL CONVERTER REFERENCE MANUAL	60356000	C	22	01.00
7683-1 (DT122-A) REMOTE CHANNEL COUPLER				
7700 () DUAL PROCESSOR COMPUTER SYSTEM HARDWARE REFERENCE MANUAL	60396300	A	22	12.90
8010 DATA COLLECTION SYSTEM OF DIAGRAMS MAN USERS MANUAL	36816700 36822500	A		03.50 01.90
8011 DATA COLLECTOR/REFERENCE MANUAL ILLUSTRATED PARTS LIST WIRE LIST MOD A	40806600 40809600 40816100		22	03.00 01.75 07.30

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
ILLUSTRATED PARTS LIST	40820100			01.75
8011-B DATA COLLECTOR DIAGRAMS AND WIRE LIST	65725100	A	22	02.70
8012 REMOTE MULTIPLEXER/8017 LINE MODULE REFERENCE/CUSTOMER ENGINEERING MANUAL	36816400	A		01.90
8013 MASTER MULTIPLEXER REFERENCE MANUAL	36816300		22	01.00
8019-1 (FF106-A) DOCUMENT READER CONTROLLER REFERENCE MANUAL	60368700	01	22	01.15
8022-A/B PAGE READER CONTROLLER REFERENCE MANUAL CE MANUAL	60167100 60167200	F J	22 22	06.60 03.65
8030 RECORD TRANSMISSION TERMINAL USERS MANUAL	36822900			01.75
8041-A/8042-A/8081-A/8082-A CARD PLACEMENT AND EQUATION SUMMARY	60127800	P	22	03.00
8046-A DISK PACK CONTROLLER CE MANUAL	60163900	A	22	07.70
8047-A/B DISK DRIVE CONTROLLER CE MANUAL REFERENCE MANUAL	60159400 60159300	A C	22 22	10.40 03.05
8050 INFORMATION CONTROL SYSTEM 160-A/8050 COMPUTER MAINTENANCE -CRUCIBLE) DIAGRAMS (CRUCIBLE) DIAGRAMS (DUPONT)	36811000 36811700 36812600			12.15 03.10 04.50
8061 DATA SET CONTROLLER REFERENCE MANUAL (REVISED)	36810100	02	22	02.40
8063 DATA SET CONTROLLER REFERENCE/CE MANUAL USERS MANUAL	36810200 36817500	D		01.75 01.50
8066-B COMMUNICATIONS TERMINAL CONTROLLER REFERENCE MANUAL CE MANUAL VOL. 1 CE MANUAL VOL. 2	13791700 13791800 13791900			01.00 01.70 05.20
8067 DATA SET CONTROLLER REFERENCE MANUAL USERS MANUAL	36814000 36819900	A		01.50 01.00
8070-A/B MAG TAPE SYNCHRONIZER REF/CE MANUAL	60145300	H		07.85
8071-A/8072-A MAG TAPE SYNCH CE DIAGRAMS CARD PLACEMENT AND EQUATION SUMMARY NORMAL CHANNEL LONG LINE DRIVERS CE MANUAL	60091300 60089800 60123300	M K A	34 22 22	02.00 04.00 01.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
8073-A/B PAPER TAPE PUNCH REF INFO (USE 8090 REF MANUAL)				
8075 TALLY PAPER TAPE READER REFERENCE/INSTR	60116900			04.60
8076 COMMUNICATION TERMINAL CONTROLLER CE DIAGRAMS	36823800	1	34	01.80
CE MAINTENANCE MANUAL	36816600		22	01.80
8083-A ARITHMETIC UNIT CE DIAGRAMS	60091100		34	02.50
CARD PLACEMENTS AND EQUATION SUMMARY	60149800		22	03.00
LONG LINE DRIVERS CE MANUAL	60124400	A	22	01.00
8084A/8085A AUXILIARY MEMORY CE DIAGRAMS	60091200	F	34	02.60
CARD PLACEMENTS AND EQUATION SUMMARY	60140700	C	22	03.20
8090 COMPUTER SYSTEM REFERENCE MANUALS				
INPUT/OUTPUT SPECIFICATIONS REFERENCE MANUAL	60102000	B	22	01.00
	60091500	E	22	08.55
CUSTOMER ENGINEERING MANUALS				
CROSS TABS AND CABLE TABS MANUAL	24140300	V	22	03.75
CE DIAGRAMS	60091000	AC	34	14.05
CE INSTRUCTION MANUAL, PART 1	60091600	E	22	06.00
CE INSTRUCTION, PART 2 MAINTENANCE MANUAL	60101900	D	22	26.00
8090 MCSMM REFERENCE MANUAL VOL 1-2 (SEE 160A SECTION)				
8090 MCSMM PROGRAM LISTINGS, VOL 1-2 (SEE 160-A SECTION)				
8090 NORMAL CHANNEL LONG LINE DRIVERS CE MAN.	60123200	A	22	01.00
BUFFER CHANNEL LONG LINE DRIVERS CE MANUAL	60123100	A	22	01.00
COMPUTER 1/COMPUTER 2 I/O LONG LINE DRIVER CE MANUAL	60123500	A	22	01.00
8090/8084 EXTERNAL BUFFER CHANNEL LONG LINE DRIVERS CE MANUAL	60123400	A	22	01.00
8092 TELEPROGRAMMER CE MANUAL VOL II OF II, CABLE AND WIRE TABS, WIRE LIST	41606100	B	22	02.10
EQUIPMENT DIAGRAMS	36810900	J	34	03.00
INPUT/OUTPUT SPECIFICATIONS	36810500	A	22	01.70
PROGRAMMING REFERENCE MANUAL	36810700	A		02.25
MAINTENANCE, INSTALL, TIMING CHARTS, C/P, EO FILES, PARTS LIST	36810800	F	22	02.85
REFERENCE MANUAL	36810600	E	22	03.25
SYSTEM MAINT. MONITOR CE MANUAL VOLS 1-3	60288100	F	22	65.00
SMM92 INSTANT ERROR CODES	60299700	A		01.80

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
REFERENCE MANUAL (CARD READER CONTROLLER (C813-R813)	36827800	A	22	01.60
CE MANUAL (CARD READER CONTROLLER-C813)	36827900	D	22	01.40
8092-B TELEPROGRAMMER - A BASIC LIBRARY SYSTEM	36823500			01.00
8093 TAPE SYNCHRONIZER REFERENCE MANUAL	36811600			01.80
8094 PERIPHERAL EQUIPMENT ADAPTER REFERENCE MANUAL	36811300	A	22	01.40
8095 CONTROL PANEL CE MANUAL	36811500	B	22	01.55
8097 DIGITAL COMMUNICATIONS TERMINAL REFERENCE MANUAL	36813300			01.25
8097/8297 DATA SET CONTROLLER USERS MANUAL	36819100			01.30
8130 CARD READER/LINE PRINTER TERMINAL PROGRAM LISTINGS COMMAND TEST	60233500	01	22	07.85
8130 REMOTE TERMINAL REFERENCE MANUAL	36828000	B		01.80
USERS MANUAL	36829900	B		01.55
TEST ROUTINE MANUAL	13796900	A		01.00
8136 COMMUNICATIONS TERM CONTROLLER CE MANUAL	13795100	B	22	01.75
REFERENCE MANUAL	13795300	A	22	01.00
8137 COMMUNICATIONS EXPANSION UNIT REF/CE MAN.	41607400	A	22	01.00
8156 LINE PRINTER PRINTER EQUIPMENT CE MANUAL (USE CL308-A/B)				
PRINTER PARTS DATA CE MANUAL	44896400	A	22	02.00
CONTROLLER EQUIP. REF/CE MAN SERIES A06 HDWE	47966500	E	22	05.25
CONTROLLER EQUIP. REF/CE MAN SERIES A10 HDWE	47966600	A	22	03.25
8170-A/B MAG TAPE CONTROLLER REF/CE MANUAL	60208600	D	22	13.80
8193 MAG TAPE CONTROLLER REFERENCE/CE MANUAL	36823700	D	22	03.00
8194 MAG TAPE SYNCHRONIZER REFERENCE MANUAL	13796000	C	22	01.45
8197 DATA SET CONTROLLER CE MANUAL	36828200	G	22	14.25
REFERENCE MANUAL	36828300			02.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
8271-A/B/D TRANSFER SWITCHES AND FT103/FT104 TRANSFER SWITCH CONTROLLERS REF./CE MANUAL	36822700	G	22	14.45
8271-E CHANNEL TRANSFER SWITCH/INDICATOR REF/CE INFO (USE 3270-A/R)				
8404 CONSOLE				
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST REFERENCE MANUAL	36816900			
8490 COMPUTER SYSTEM REFERENCE MANUAL	14091600	B	22	04.10
DIAGRAMS AND THEORY OF OPERATION	14091700	C	22	14.30
SITE PREPARATION AND INSTALLATION MANUAL	14091800	A	22	01.90
ADSAS AND FORTRAN OPERATION REFERENCE MANUAL	14091900	A	22	02.25
MAINTENANCE AND COMMAND TIMING MANUAL	14092000	B	22	08.75
INSTRUCTION CARDS	14093500			00.75
SYSTEM MAINTENANCE MONITOR (SMM) REFERENCE/ PROGRAM LISTINGS MANUAL	14094700	A	22	11.75
8508B/8515B INPUT UNIT, 8509B/8519B OUTPUT UNIT REFERENCE/CE MANUAL	36826700	A	22	02.85
8518-C,8519-D CE MANUAL, INSTALL AND CHECKOUT, THEO OF OPEP, DIAG, MAINT AIDS, PARTS DATA W/	36826600	B	22	01.50
8527 DCU/8065 DGT/8096 INPUT/OUTPUT UNIT REFERENCE MANUAL (8527-A)	36812700	A	22	02.95
REFERENCE MANUAL (8527-B)	36823400	B	22	03.00
8528 DIGITAL COMMUNICATIONS TERMINAL CE MANUAL	36825600	A	22	04.10
DIAGRAMS MANUAL	36814200	4	34	02.25
MAINTENANCE AIDS MANUAL	36817300	7	22	08.00
REFERENCE MANUAL	36814100	A	22	01.75
8528-G DIGITAL COMMUNICATIONS TERMINAL CE DIAGRAMS	36814500	7	34	02.25
MAINTENANCE MANUAL (USE 8528)				
REFERENCE MANUAL	36814400	A	22	02.85
8529-B/C DATA SET CONTROLLER, W/L, EQ. SUMMARY	41603500	B	22	01.70
REFERENCE MANUAL	36813100			01.25
8529 DIGITAL COMMUNICATIONS TERMINAL DIAGRAM VOLUME	36813700		34	01.50
CUSTOMER ENGINEERING MANUAL	36812500		22	02.00
8529-B/C DATA SET CONTROLLER REFERENCE MAN	13791100	A	22	01.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE MANUAL VOL. I OF II	13791200	C	22	02.40
CE MANUAL				
8536-C/D,8537-C/D INPUT/OUTPUT UNITS CE MANUAL	13797000	E	22	07.35
8601 POWER SUPPLY REFERENCE MANUAL	36814800			01.25
8606 POWER SUPPLY REFERENCE MANUAL	36815000			01.30
8615 DUAL POWER SUPPLY REFERENCE MANUAL	36814700			01.00
8909-C TEST BOARD UNIT REFERENCE MANUAL	36816000	A	22	02.00
8909-G TEST BOARD DRAWER REF/CE MANUAL	36828900	A	22	01.50
8909-H TEST BOARD UNIT REFERENCE MANUAL	13797300	B	22	02.30
CE MAN VOL I OF II THEO OF OPER,DIAG,MAINT, MAINT AIDS,PARTS DATA	13799700	C	22	01.20
CE MANUAL VOL. II OF II WIRE LISTS	41600100	D	22	07.55
8987 R/O NIP STATION OPERATORS GUIDE	62079500	02	22	01.00
9088-1 DUAL ACCESS DISK DRIVE CONTROLLER REFERENCE/CE MANUAL	60290900	B	22	09.45
9081 PLUG COMPATIBLE CONTROLLER--LISTED AS FA7A4, FV1A1				
9082 (23142)				
9100 MAGNETIC TAPE TRANSPORT MAINT. MANUAL	40814900		22	04.00
ILLUSTRATED PARTS LIST	40803900		22	09.00
9103 MAGNETIC TAPE TRANSPORT DIAGRAMS AND WIRE LIST, MOD A	40811700			02.85
REFERENCE MANUAL, MOD A	40802100	C	22	04.60
CE MANUAL - PARTS LIST MOD A	40805300	A	22	03.60
9110 MAG TAPE TRANSPORT DIAGRAM/WIRE LIST MOD B AND C	40824600	2	22	06.80
REFERENCE MANUAL, MOD B AND C	40806700		22	06.00
9112 MAGNETIC TAPE TRANSPORT MAINT. MANUAL	40822300	B	22	10.00
9113 MAGNETIC TAPE TRANSPORT DIAGRAMS AND WIRE LIST	40818800	2	22	03.00
9114 MAGNETIC TAPE TRANSPORT MAINTENANCE CE MANUAL PARTS LIST	40817000		22	04.00
	40826600		22	01.80
9115 MAGNETIC TAPE TRANSPORT DIAGS,W/L MOD A	40822100	A	22	09.30

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
MAINTENANCE MANUAL	40819700		22	03.50
PARTS LIST	40829900			05.70
9119 MAGNETIC TAPE TRANSPORT MAINTENANCE	40823800	2	22	04.00
DIAGRAMS AND WIRE LIST	40823600	8	22	05.00
PARTS LIST, MOD A	40823700	B		03.95
9120 MAGNETIC TAPE TRANSPORT MAINTENANCE	40820400		22	04.00
DIAGRAMS AND WIRE LIST	40815700	2	22	03.20
PARTS LIST	40868200	A	22	06.60
9125 MAGNETIC TAPE TRANSPORT	40818900		22	04.00
DIAGRAMS AND WIRE LIST MOD A	40821800	3	22	07.05
9125/9135 MAGNETIC TAPE TRANSPORT PARTS LIST	40860100	A	22	10.35
9130 MAGNETIC TAPE TRANSPORT DIAGRAMS AND	40825400	2	22	05.80
WIRE LIST MOD A05 AND UP, B01 AND UP	40806800		3	08.00
REFERENCE MANUAL, MOD A AND B				
9131 MAGNETIC TAPE TRANSPORT DIAGRAMS MOD A/B	40808500		3	03.50
REFERENCE MANUAL, MOD A AND B	40805200	A	3	06.00
ILLUSTRATED PARTS LIST, MOD A AND B	40807100		3	03.50
WIRE LIST MOD A AND B	40808400		3	03.50
9135 MAGNETIC TAPE TRANSPORT MAINTENANCE	40819800	B	22	13.10
DIAGRAMS AND WIRE LIST	40821700	4	22	04.00
9155 MAGNETIC TAPE TRANSPORT CE MAINT MANUAL	40862300	A	22	04.30
9160A/B MAGNETIC TAPE TRANSPORT MAINTENANCE	40813300	2	22	04.00
9165 MAGNETIC TAPE TRANSPORT	40865000	02	22	01.60
MAINTENANCE MANUAL MOD A				
9165/9175 TAPE TRANSPORT PARTS LIST	40863600	A	22	05.60
9170 MAGNETIC TAPE TRANSPORT MAINTENANCE	40818700	A	22	04.60
9175 MAG TAPE TRANSPORT MOD A AND B MAINT MAN.	40865100	2	22	02.10
9180 MAGNETIC TAPE TRANSPORT PARTS LIST MOD A	40868100	B	22	05.55
CE MAINTENANCE MANUAL MODS A AND B	40864600	B	22	13.00
DIAGRAMS, CIRC. DESC., WIRE LIST	41240800	A		04.60
9190-B MAG TAPE TRANSPORT DIAGRAM/WIRE LIST	40826200	A	22	05.40
9200 (CE1A5) CARD READER				
9202 CARD READER				
GENERAL DESC., OPERATION, INSTALLATION,	49596700	B	22	03.00
CHECKOUT, MAINTENANCE CE MANUAL				
THEORY OF OPERATION, DIAGRAMS, WIRE LIST	49596800	B	22	05.80

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE MANUAL PARTS LIST CE MANUAL	49596900	B	22	09.35
9236/9244/9286 AIRLINES TERMINAL DISPLAY/ KEYBOARD				
HARDWARE PROGRAMMING MANUAL	62068100		22	02.05
RECEIVE ONLY- NON IMPACT OPERATORS GUIDE	62073800		22	01.00
OPERATORS GUIDE	62067900		22	01.00
ON SITE MAINT MANUAL	62068300		22	02.30
9251 CARD PUNCH SERVICE MANUAL	40808100	7		05.00
9280-A/B (CF507-A/B) CARD READER/PUNCH SUBSYSTEM				
9300 TICKET PRINTER GEN DESC, MAINT, PARTS DATA, WIRE LISTS HARDWARE REF/CE MANUAL	50577600	A	22	11.10
9301 LINE PRINTER CONTROLLER PARTS DATA, DIAGS, W/L, GEN DESC, INSTAL/ CHECKOUT.REF/CE MANUAL	50577900	A	22	15.75
9301 LINE PRINTER EQUIPMENT DIAGRAMS MANUAL	50577800	A		29.00
9320 LINE PRINTER PRINCIPLES OF OPERATION REFERENCE MANUAL	50584400	A	22	01.25
PARTS IDENTIFICATION MANUAL	50584600	A	22	02.15
MAINTENANCE, DIAGRAMS, WIRE LIST CE MANUAL	50584500	A	22	04.30
9322 LINE PRINTER MAINTENANCE, DIAGRAMS AND WIRE LIST FIELD SERVICE MANUAL	50583700	C	22	03.70
PARTS LIST PARTS IDENTIFICATION MANUAL	50583800	C	22	01.70
PRINCIPLES OF OPERATIONS REFERENCE MANUAL	50583600	D	22	01.80
LOGIC SCHEMATICS, CIRCUIT BOARDS, TIMING/ WIRING DIAGRAMS FIELD SERVICE MAN. VOL II	91859200	B	34	09.15
50982602/03 EQUIPMENT TYPE CL484C/CL484D INTRODUCTION, OPERATING INSTRUCTIONS PRINCIPLES OF OPERATION CE MANUAL				
INTRODUCTION, ASSEMBLY PARTS LISTS, PARTS IDENTIFICATION CE MANUAL	59579300	A	22	02.35
50982602/03 EQUIPMENT TYPE CL484C/D INSTALL- ATION AND CHECKOUT, MAINT, W/L, DIAGRAMS FSM	59579200	01	22	15.30
59690800/01 EQUIPMENT TYPE CL408-A/B INSTALL. AND CHECKOUT, MAINTENANCE, GLOSSARY FIELD SERVICE MANUAL	91858400	A	22	02.35
INTRODUCTION, OPERATING INSTRUCTIONS, PRINCIPLES OF OPERATION MANUAL	59709100	A	22	04.20
INTRODUCTION, PARTS LIST, USED-ON INDEX CE	91859100	A	22	03.20
INTERCONNECTION DIAGS, PRINT HEAD LOGIC DIAG CONTROLLER LOGIC DIAGS, TIMING DIAGS, FSM II	91858500	A01	34	10.40

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
9340 LINE PRINTER EQUIPMENT PARTS DATA CE MAN. SPECIAL OPTION 68091 INTRO. OPER. PROG. INST. CHECKOUT., PRINCIPLES OF OPER, MAINT. DIAGS, W/L, EQ SUM. PARTS DATA CE MANUAL PRINTER EQUIPMENT CE MAN. (USE CL308-A/B)	44895900 44977000	A C	22 22	02.00 02.90
9341 LINE PRINTER W/SPECIAL OPTION 68090 PART 1 CONTROLLER., PART 2 LINE PRINTER EQUIP., PART 3 LINE PRINTER PARTS DATA CE MANUAL	44975600	B	22	15.70
9342 LINE PRINTER EQUIPMENT (CL8P2-A THRU CL8P2-S) INSTALLATION, CHECKOUT, DIAGS, W/L, PARTS DATA, MAINTENANCE CE MANUAL	50579600	A01	22	06.95
9346E LINE PRINTER PRINT HEAD HDWR REF/CE MAN	44982700	B	22	03.70
9346-F LINE PRINTER HEAD MECHANISM (CL8R5-A/D) OPERATIONS, DIAGRAMS, WIRE LIST, MAINTENANCE, PARTS DATA CE MANUAL	50582500	B01	22	03.85
OPERATIONS, DIAGRAMS, WIRE LIST, MAINTENANCE PARTS DATA CE MANUAL	50579100	C	22	05.00
9350 SERIES LINE PRINTER EQ CE MANUAL PARTS DATA	44977600 44981600	A A	22 22	13.40 02.00
9350 LINE PRINTER EQUIP. MODIFIED FOR MSBT GEN DESC, DIAGS, W/L, MAINT. CE MANUAL PARTS DATA CE MANUAL	44983100 44983200	01 01		06.90 02.85
9352 LINE PRINTER CONTROLLER EQUIPMENT W/SPEC. OPTIONS CE MANUAL	44977700	A	22	05.15
INSTALLATION/CHECKOUT DIAGRAMS, WIRE LIST, PARTS DATA CE MANUAL	50581300	C	22	08.75
INSTALLATION/CHECKOUT, MAINT., PARTS DATA W/L, CE MANUAL	50581000	B02	22	08.40
INSTALLATION AND CHECKOUT, DIAGRAMS AND WIRE LISTS, PARTS DATA CE MANUAL	50581400	D	22	05.80
DIAGRAMS, WIRE LIST, PARTS DATA CE MANUAL EQUIPMENT MANUAL	50584800 59579400	C	22 22	06.00 03.70
LOGIC SCHEMATICS, CIRCUIT BOARDS, WIRING PRINT HEAD MECHANISM - 96 CHARACTER	59707800 59579500	A A	34 22	03.50 03.40
DIAGRAMS, TIMING DIAGRAMS, FIELD SERVICE MANUAL VOLUME II				
FOR TOP LEVEL ASSEMBLY 50709515/16 EQUIPMENT TYPE CL4A9-E/CL4A9-F INSTALLATION AND CKOUT OPER., PIN. OF OPER., POWER SUPPLY, DIAGS, MAINT, W/L, PARTS DATA HARDWARE REF/CE MAN	59708000	A	22	09.15
9355 LINE PRINTER PRINT MECHANISM HARDWARE REF/CE MANUAL	50580500			04.50

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
OPERATIONS, MAINT, DIAGRAMS, PARTS DATA CE	50581900	001	22	06.25
OPERATIONS, MAINTENANCE, DIAGRAMS, PARTS	50584700	A	22	07.90
DATA CE MANUAL				
9360 LINE PRINTER EQUIPMENT PARTS DATA	50578500	A	22	05.00
9361 LINE PRINTER EQUIPMENT PARTS IDENTIFICA-	59577900	A	22	04.80
TION MANUAL				
GEN DESC., MAINT/MAINT AIDS REFERENCE MANUAL	59578000	A	22	04.80
DIAGRAMS AND WIRE LIST FIELD SERVICE MANUAL	59578100	A	22	03.90
9362 PARTS IDENTIFICATION MANUAL	59578900	AD4	22	07.15
FIELD SERVICE MANUAL	59578800	A	22	24.30
CII- JT14A TEST BOX OPERATION MANUAL	76630900		22	02.50
9410-A, 9420-B DUAL DISK STOR DRU. MODS A01-A05	40866500	G	22	03.00
B04-B05 PARTS LIST				
GEN DESC, OPER, INSTAL AND CHECKOUT, MAINT MAN	40864400	D	22	05.65
THEORY OF OPER, DIAGS, MAINT. AIDS, AND W/L	40866400	E	22	05.65
9421 DUAL DISK DRIVE--LISTED AS BK3A1				
9431 DISK STORAGE DRIVE DIAG. AND W/L MAN A12B12	41247500	E	22	02.85
MAINTENANCE MANUAL MODS A12, B12 AND ABOVE	41245900	C	22	07.30
PARTS LIST MODS A12, B12 AND ABOVE	41244300	E	22	01.65
9432 DISK STORAGE DRIVE				
DIAGS AND WIRE LIST MANUAL MODS C, D, G, J, K	40827300	J	22	01.50
DIAGS, CIRC DESC, C/P AND WIRE LIST	41247600	E	22	02.55
MAINTENANCE MANUAL MODS A, B, C, D, G, H	40816900	E	22	06.10
MAINTENANCE MANUAL MODS C12-K12 AND ABOVE	41246000	C	22	06.85
PARTS LIST MODS C12 AND ABOVE, D12 AND ABOVE	41244400	D	22	02.40
F12 AND ABOVE, G12 AND ABOVE, J12 AND ABOVE				
K12 AND ABOVE				
PARTS MANUAL MODS C, D, F, G, J, K	40826500	C	22	02.10
9433-A/B/J/K DIAGRAMS AND WIRE LIST MANUAL	40863100	H	22	05.80
DIAGRAMS AND WIRE LIST MANUALS MOD A12, B12	41247700	E	22	02.00
J12, K12				
PARTS LIST MANUAL MOD A, B, J, K	40826800	D	22	03.20
CE MAINTENANCE MANUAL MODS A THRU G	40826900	F	22	04.10
MAINTENANCE MODS RH1A7-A AND B	41241600	B	22	08.85
9460 DISK STORAGE DRIVE				
PARTS LIST	40828700	B	22	01.30
9461 DISK STORAGE DRIVE				
DIAGRAMS AND WIRE LIST MOD A05/B05 ABOVE	40828900	N	22	05.40
PARTS LIST MODS A05-A11/R05-B11	40829000	C	22	06.55
MAINTENANCE MANUAL MODS A-B	40829100	F	22	05.55
MAINTENANCE MANUAL MODS A12, B12 AND ABOVE	41246800	C	22	04.05
PARTS LIST MODS A12, B12 AND ABOVE	41245200	F	22	02.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
DIAGS AND W/L MODS A12,B12 ABOVE, B35 ABOVE	41248400	L	22	01.55
CE MAINTENANCE MANUAL MODS A,B,J,K	41246100	C	22	06.00
MAINTENANCE MAN MODS F12,G12,L12,M12,S12, T12 AND ABOVE	41246200	B	22	02.00
PARTS LIST MODS A12 ABOVE, B12 ABOVE, J12 ABOVE, K12 ABOVE	41244500	D	22	02.00
9433 DISK STORAGE DRIVE--ALSO LISTED AS BJ1A9				
DIAG AND W/L MODS F/G/S/T 12 AND ABOVE	41247800	E	22	02.75
DIAG AND W/L MODS L/M 12 AND ABOVE	70604200	D	22	02.20
PARTS LIST MODS F/G/S/T 11 AND BELOW	40865500	D	22	01.70
PARTS LIST MODS F/G/L/M/S/T 12 AND ABOVE	41244600	D	22	01.80
9434-A/B DISK STORAGE DRIVE PARTS LIST MOD A,B	40827000	B	22	06.50
PARTS LIST MODS A12-B12 AND ABOVE	41244700	D	22	02.00
9441 DISK STORAGE DRIVE				
DIAGS,CIRC DESC,C/P AND W/L MODS B0 AND ABOVE	40828200	G	22	02.55
DIAGRAMS AND WIRE LIST OF MANUAL	70607700	B	22	02.00
9451 DISK STORAGE DRIVE--ALSO LISTED AS BJ1A7				
PART DATA MANUAL	70612700	A	22	01.65
9462-A/B DISK STORAGE DRIVE				
MAINTENANCE MANUAL MODS A12,B12 AND ABOVE	41246900	C	22	04.65
9463 DISK STORAGE DRIVE				
DIAGS,CIRC DESC, C/P AND W/L MODS A10 AND ABOVE, B10 ABOVE	40867100	C	22	05.00
9464 DISK STORAGE DRIVE				
DIAGRAMS, CIRC DESC, C/P,W/L MODS K09/ABOVE	40867600	B	22	06.00
MAINTENANCE MANUAL MODS K09-K11	40868400	D	22	09.70
MAINTENANCE MANUAL MOD A12 AND ABOVE	41247100	C	22	07.45
PARTS LIST MOD K	40868500	C	22	07.30
PARTS LIST MODS K12 AND ABOVE	41245500	D	22	02.00
9465 DISK STORAGE DRIVE--ALSO LISTED AS BJ3A3				
PARTS LIST MOD P-12 AND ABOVE	40860200	D	22	02.05
MAINTENANCE MANUAL MOD P	41240300	B	22	09.00
MAINTENANCE MANUAL MOD P12 AND ABOVE	41247200	C	22	08.10
DIAGRAMS AND WIRE LIST MODS D09 AND ABOVE	41240400	C	22	06.05
PARTS LIST MODS P09-P11	41240500	C	22	04.00
DIAGS,CARD PLACEMENT,W/L MODS P12 AND ABOVE	41248800	E	22	02.20
9468 DISK STORAGE DRIVE--LISTED AS BJ3A1				
9469 DISK STORAGE DRIVE--LISTED AS BJ2A2				
9480-1 MULTIPLE DISK DRIVE--LISTED AS BM1A3, BM1A7, BM1B3				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
9480-2 MULTIPLE DISK DRIVE--LISTED AS BM1A1, BM1A5, BM1B1				
9481-1 MULTIPLE DISK DRIVE--LISTED AS BM1A4, BM1A6, BM1B4				
9481-2 MULTIPLE DISK DRIVE--LISTED AS BM1A2, BM1B2				
9482 MULTIPLE DISK DRIVE--LISTED AS BM2A1, BM2A2, BM3A2				
9482-1 MULTIPLE DISK DRIVE--LISTED AS BM2A7				
9482-2 MULTIPLE DISK DRIVE--LISTED AS BM2A8, BM2B1, BM2B2				
9486 DISK STORAGE UNIT--LISTED AS BP2A3, BP3A8				
9492/9493 DISK FILE SYSTEM MAINTENANCE MANUAL PARTS LIST MODS A	40829300	E	22	06.70
	40867800	A	22	10.40
9496/9497 DISK FILE GENERAL DESCRIPTION, OPER, INSTALL, CHECKOUT, MAINT, CE MANUAL	40865800	C	22	03.45
9519 (BE4C4) MAGNETIC TAPE TRANSPORT				
9520 (BE4B5) MAGNETIC TAPE TRANSPORT				
9525 (BE4B2) MAGNETIC TAPE TRANSPORT				
9525-13 (BE4B9) MAGNETIC TAPE TRANSPORT				
9525-14 (BE1A3) MAGNETIC TAPE TRANSPORT				
9540 (BE4B3) MAGNETIC TAPE TRANSPORT				
9545 (BE4B1) MAGNETIC TAPE TRANSPORT				
9545-13 (BE4C1) MAGNETIC TAPE TRANSPORT				
9545-14 (BE1A2) MAGNETIC TAPE TRANSPORT				
9560 (BE4A1) MAGNETIC TAPE TRANSPORT				
9565 (BE4A2) MAGNETIC TAPE TRANSPORT				
9565-13 (BE4C2) MAGNETIC TAPE TRANSPORT				
9565-14 (BE2A3) MAGNETIC TAPE TRANSPORT				
9566 (BE4B7) MAGNETIC TAPE TRANSPORT				
9568 (BE2A1) MAGNETIC TAPE TRANSPORT				
9580 (BE4B4) MAGNETIC TAPE TRANSPORT				
9585 (BE4A9) MAGNETIC TAPE TRANSPORT				
9585-11 (BE4B8) MAGNETIC TAPE TRANSPORT				
9585-13 (BE4C7) MAGNETIC TAPE TRANSPORT				
9585-14 (BE2A2) MAGNETIC TAPE TRANSPORT				
9720 DISK FILE--LISTED AS BH1A9 AND BH2A1				
9736 DISK STORAGE UNIT--LISTED AS BR1A1/7/9				
9737 DISK STORAGE UNIT--LISTED AS BR1A8				
9738 DISK STORAGE UNIT--LISTED AS BR1A3				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
9739 DISK STORAGE UNIT--LISTED AS BR1A4				
9740 DISK STORAGE UNIT--LISTED AS BR1A5, BR2A1				
9741 DISK STORAGE UNIT--LISTED AS BR2A2				
9910 PERIPHERAL EXERCISER GEN DESC, DIAG, MAINT. CE MANUAL	70606600	B	22	03.70
23022/23030/23040/23050 MEMORY SYSTEM SITE PLANNING KIT	83096400	B		01.00
23044 MEMORY SYSTEM SITE PLANNING KIT	83096300			
23065/67 MODEL 1 MEMORY SYSTEM SITE PLANNING KIT	83096200			01.20
14031 TRAIN PRINTER GEN. DESC., INSTALLATION AND CHECKOUT, OPERA- TION AND PROGRAMMING, PRINCIPLES OF OPERA- TION, MAINT/MAINT AIDS CE MANUAL VOL 1	59708200	A01	22	09.10
DIAGRAMS AND WIRE LISTS CE MANUAL VOL 2	59708300	A01	22	07.05
PARTS DATA CE MANUAL VOL 3	59708400	A01	22	10.50
23141 (9081) MULTIPLE DISK SYSTEM REFERENCE MANUAL	70613700	A	22	01.95
23142 (9082) MULTIPLE DISK SYSTEM REF MANUAL SYSTEM ANALYSTS GUIDE	70621300	A	22	03.85
	70622000	A	22	01.30
28211 PRINTER SYSTEMS FORM DESIGN, RIBBON AND ACCESSORIES USERS MAN	97403500	A	22	01.00
PRODUCT INFORMATION MANUAL	97404600	A	22	02.15
28211/14301 AND 28211-21 PRINTER SYSTEMS OPERATORS GUIDE	22265500	A	3	03.90
28211-21 PRINTER SUBSYSTEM LOGIC DIAGRAMS	22273100	G	34	02.60
THEORY OF OPERATIONS	22273000	G	3	13.75
33100 MEMORY SYSTEMS FOR THE IBM SYSTEM 370 SALES REFERENCE GUIDE	15000300		3	06.05
33135 MEMORY SYSTEM SITE PLANNING KIT	75365100	B		02.40
LOGIC DIAGRAMS	75387400	B	34	23.85
THEORY OF OPERATION	75387500			
PRODUCT INFORMATION MANUAL	75401000			
33145 MEMORY SYSTEM				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
SITE PLANNING KIT	75365200	B		01.00
LOGIC DIAGRAMS	75372900	B	34	27.00
THEORY OF OPERATION	75373000	B	3	09.85
SERVICE MANUAL	75369200		3	12.90
33155-5XX MEMORY SYSTEM				
SITE PLANNING KIT	22264000	B		01.15
THEORY OF OPERATION	75401400	A	3	15.75
LOGIC DIAGRAMS	75401500	A	34	19.00
33155-6XX MEMORY SYSTEM				
SITE PLANNING KIT	75369100	B		03.35
PRODUCT INFORMATION MANUAL	22265400	A		01.00
MAINTENANCE MANUAL	75369600	A	3	12.75
33158 -2XX/3XX/4XX MEMORY SYSTEM				
SITE PLANNING KIT	75385700	A		02.00
THEORY OF OPERATION	75401700	A	3	15.75
LOGIC DIAGRAMS	75401800	A	34	19.00
33159 MEMORY SYSTEM				
SITE PLANNING KIT	22263900	C		02.15
PRODUCT INFORMATION MANUAL	22264800	A		01.00
SERVICE MANUAL	75369800		3	15.75
LOGIC DIAGRAMS	75391300	B	34	25.75
33165-5XX MEMORY SYSTEM				
THEORY OF OPERATION	75402000	A	3	17.25
LOGIC DIAGRAMS	75402100	A	34	19.00
SITE PLANNING KIT	75368900			
33301 MULTIPLE DISK SYSTEM PRODUCT INFOR MAN	70629800		3	00.85
REFERENCE MANUAL	70629900	D	22	06.30
GROUP III MICRODIAGNOSTICS DESCRIPTIONS	70604100	D	22	06.50
GROUP III MICRODIAGNOSTICS USERS MANUAL	70612400	C	22	02.05
TROUBLESHOOTING MANUAL	70608200	C	22	03.50
INSTALLATION CE MANUAL	70608100	G	22	08.35
33301 DISK MEMORY SUBSYSTEM SITE PLANNING KIT	83301400	C		01.00
33301/33302 SUBSYSTEM				
ON-LINE DIAGNOSTICS (COLDS MANUAL)	70602900	D	22	16.35
33302 DISK MEMORY SUBSYSTEM				
SITE PLANNING KIT	70627400		22	01.00
REFERENCE MANUAL	83301500	B	22	08.00
INSTALLATION CE MANUAL	83301600	D	22	03.75
TROUBLESHOOTING MANUAL	83301700	01	22	08.85
34201 MAGNETIC TAPE TRANSPORT				
OPERATORS MANUAL	49752300	A	3	01.10
OPERATORS GUIDE	22263500		3	01.80
MAINTENANCE	22285600		3	22.20

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
LOGIC DIAGRAMS SITE PLANNING KIT USE 38031 MAG TAPE SBSYSTEM PRODUCT MANUAL USE 38031 MAG TAPE SUBSYSTEM	22285700		34	06.80
38031 MAGNETIC TAPE CONTROLLER MAINTENANCE	22285300		3	01.35
LOGIC DIAGRAMS	22285400		34	18.65
TRANSLATOR LISTING	22285500			10.70
38031 MAGNETIC TAPE SUBSYSTEM PRODUCT MANUAL	22263800		3	03.85
SITE PLANNING KIT	75369000			01.50
90100 SYSTEM CONTROLLER COMPUTER SYSTEM REFERENCE MANUAL	60321400	A	22	01.40
INPUT/OUTPUT SPECIFICATIONS MANUAL	60321500	A	22	01.00
90104 (AB103-A, BB328-A, BB329-A) COMPUTATION MODULE REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1)				
90105-1 (DC118-A) DATA CHANNEL REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1)				
90106-1 (DC120-A) STORAGE CHANNEL REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1)				
90107-1 (GL112-A) CONSOLE REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1)				
90108-1 (BB329-A) MEMORY MODULE REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1)				
90108-2 (BB328-A) STORAGE INCREMENT REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1)				
90109-1 (DC119-A) CHARACTER HANDLER REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1) REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1) ** REFER ALSO TO VENDOR MANUALS SECTION FOR TELETYPE MANUALS (35KSP)				
90113-1 (CK502-A/B) TELETYPEWRITER ** REFER ALSO TO VENDOR MANUALS SECTION FOR TELETYPE MANUALS (35ASR)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
90114-1 (GH401-A) CABINET REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1)				
90115-1 (GD104-A, GD105-A, GD106-A) POWER SUPPLY REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1)				
90115-4 (GE210-A/B) AUXILIARY MOTOR GENERATOR CE INFO (USE 90100 SITE PREPARTION MANUAL - CATALOG SEC. 4)				
90120 PAPER TAPE STATION REFERENCE MANUAL	60324000	A	22	01.15
90121-1 (CE305-A/B) PAPER TAPE READER REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1) ** REFER ALSO TO 370 PAPER TAPE READER MANUALS				
90122-1 (CE305-A/B, GJ102-A) PAPER TAPE READER WITH HANDLER REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1) ** REFER ALSO TO 370 PAPER TAPE READER MANUALS ** REFER ALSO TO VENDOR MANUALS SECTION FOR REMEX PAPER TAPE SPOOLER CE MANUAL				
90123-1 (CF104-A) PAPER TAPE PUNCH REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1)				
90123-2 (CF106-A) PAPER TAPE PUNCH - TUNGSTEN CARBIDE REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1)				
90124-1 (CF104-A, GJ103-A/B) PAPER TAPE PUNCH WITH HANDLER REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1) ** REFER ALSO TO VENDOR MANUALS SECTION FOR REMEX TAPE SPOOLER CE MANUAL				
90124-2 (CF106-A, GJ103-A/B) PAPER TAPE PUNCH -TUNGSTEN CARBIDE- WITH HANDLER REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1) ** REFER ALSO TO VENDOR MANUALS SECTION FOR				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
REMUX TAPE SPOOLER CE MANUAL				
90125-1 (CF5A5-A/B/C) PAPER TAPE STATION - COMMON CONTROL REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1)				
90126-1 (CF8A1-A) ENCLOSURE KIT FOR 90125-1 REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1)				
90127-1 (CW123-A) PAPER TAPE PUNCH VALIDATION FEATURE REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1)				
92411 CRT DISPLAY TERMINAL OPERATORS GUIDE	62034200	01		01.00
HARDWARE PROGRAMMING MANUAL	62061700	02	22	01.00
92412 PRINTER TERMINAL OPERATORS GUIDE	62049500	00		01.00
HARDWARE PROGRAMMING MANUAL (PRELIMINARY)	62074000		22	01.20
92413 CONVERSATIONAL DISPLAY TERMINAL OPERATORS GUIDE	62038000	00		01.00
HARDWARE PROGRAMMING MANUAL	62033500	02	22	01.00
92417/92427 NON-IMPACT PRINTER STATION OPERATORS GUIDE	62073300			01.00
READ ONLY PRINTER PROGRAMMING MANUAL (92417)	62088900	01	22	01.05
READ ONLY PRINTER STATION HARDWARE PROGRAMMING MANUAL (92427)	62122800	01	22	01.00
ON-SITE MAINTENANCE MANUAL (92417)	62089100	01	22	01.20
ON-SITE MAINTENANCE MANUAL (92427)	62122900	01	22	01.05
92424/92425 AIRLINES TERMINAL DISPLAY/KEYBOARD OPERATORS GUIDE	62068000			01.00
ON SITE MAINTENANCE MANUAL	62068400			02.30
HARDWARE PROGRAMMING MANUAL	62068200			02.05
94100 () CORE MEMORY PRODUCT DESCRIPTION MANUAL	60410100	A	22	01.00
THEORY OF OPERATION MANUAL	60410200		22	02.50
CE MANUAL	60405400	A	22	08.95

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

SECTION 3

PLEASE NOTE:

A number of Software Manuals are listed in more than one location because of the fact that specific software products will run on various operating systems.

Manuals in this section

The format in this section uses a machine line heading with a listing of manuals for each operating system version and the appropriate product set members printed beneath the heading.

TABLE OF ABBREVIATIONS

All Titles for software manuals have been reviewed and standardized. The following table lists all abbreviations and their full wording.

ADB	Applications Development Bulletin
BIN	Binary
BSIPP	Simultaneous Peripheral Processor
COMPAT	Compatible
COMPARATIVE	Used with FORTRAN, notes the similarities and differences among the FORTRAN for 3000 and 6000 machine lines and USASI
EXT	Extended
FTN	FORTRAN
FUNCT	Functions
GENERIC	Algol, applicable to all 3/6 machine line
HS	High Speed
IMB	Installation Handbook
LIB	Library
META	Procedure Oriented Source Language Assembler
MP	Memory Protect
MS	Mass Storage
MSIO	Logical Input/Output On Mass Storage
REF	Reference
OP	Operating System
REGINA 1	Linear Programming Package
RESPOND	Multiaccess Subsystem For Remote And/Or Local Ter
SAINT	1401 Simulator And Interpreter
SASY	31/32 Satellite For Standard File Processing-3600
SDPS	Seismic Data Processing System
SFP	Standard File Processor
SIPP	Simultaneous Peripheral Processor, Batch Execution
SMT	Summit
TSORT	Tape Sort
XLAT	Translator

TITLE	1	2	3	4	5
G-15 COMPUTER					
ALGOL/OPERATING MANUAL	60063600			01.00	36
ALGOL/PROGRAMMING MANUAL	60060500			02.05	32
ALGOL/TECHNICAL MANUAL	60060600			04.50	224
ALTRAN/REFERENCE MANUAL	60060300			03.00	160
AUTOCARD PROGRAMMING MANUAL	60153500			03.65	68
AUTOPOINT 24 PROGRAMMING MANUAL	PPT18100			03.05	24
BIT OF MEANING (APG-12591-0761)	60062100		22	01.00	20
CODING MANUAL	60060400			01.00	26
FIXED POINT SCALE (G-15)	60062700			01.00	28
INTERCARD PROGRAMMING MANUAL	60153600	A		03.30	86
INTERCOM 500/PROGRAM MANUAL	60060700			01.50	72
INTERCOM 1000/PROGRAMMING MANUAL	60062200			01.00	32
INTERMAP/PROGRAMMING MANUAL	60060100			03.00	156
G-20 COMPUTER					
GENERAL INFORMATION MANUALS					
BINARY PATCH LOADER (CB-11)	PSB-AG06			01.00	10
BOOTSTRAP CARD PRODUCER VIA CB-11	PSB-AG05			01.00	4
FILE OPERATIONS SYSTEMS (G-20)	PSB-AG01			01.00	20
INTRODUCTION TO PERT	60062000			01.00	12
MAGNETIC TAPE MACROS (G-20)	PSB-AG02			01.00	30
PERT 2 FOR SNAP 11 VOL 1 (G-20)	PSB-AG08			01.00	15
PERT 2 FOR SNAP 11 VOL 2 (G-20)	PSB-AG09			01.00	20
PERT HANDBOOK	60153800			01.50	76
PIECES OF EIGHT, AN INTRO TO OCTAL SYSTEM	60061600			02.00	44
REVISIONS TO SPACE PROGRAMMING SYSTEM	PSB-AG04			01.00	16
SATELLITE PACKAGE (CB-11)	PSB-AG07			01.00	48
SPACE SYSTEM ARITHMETIC SUBROUTINES	PSB-AG03			01.00	7
TAPE-TO-MT-10 TAPE TRANSLATOR (603)	PSB-AG12			01.00	56
USE OF TAPES WITH THE SPACE SYSTEM	PSB-AG11			01.00	20
FORTTRAN/REFERENCE MANUAL	60061200			02.00	108
FORTTRAN 11/REFERENCE MANUAL	60054400			03.00	152
FORTPAN-4 (SPD-03) (G-20)	60084200			01.50	74
LINNEAR PROGRAMMING REF MAN	60054600			04.50	214
PERIPHERAL EQUIP. MAC LANG	60065100			05.35	106
SBAP REFERENCE MANUAL	60061900	A		02.10	32
SCIENTIFIC COMPUTING SYSTEM (G-20/G-20-A)	60054200			01.00	44
SIMULATOR REF MAN (G-20/650)	60060800			01.50	78
SIMULATOR TECHNICAL MAN (G-20/650)	BPT03621			02.75	50
SNAP 11/REF MANUAL	60061500			03.00	144
SORT MERGE/GENERATOR/INFORMATION MANUAL	60054000			01.50	72
SPAR/REFERENCE MANUAL	60054100			05.00	256
PERT/REFERENCE MANUAL (G-20)	60054500			01.50	80
MP-60 COMPUTER SYSTEMS					
	REFERENCE MANUAL				
	14306500	A	22	04.45	152
COMPASS	REF MANUAL				
	14061300	B	22	04.30	72

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
	COSY REF MANUAL	14062100	A	22	01.00	34
	PRELIR REF MANUAL	14062200	A	22	01.00	44
160-B	FORMERLY 160					
	FORTRAN GIM	60050500	B		01.00	28
	REFERENCE MANUAL	60050300			02.00	104
	OP PROCEDURE FTN-A	60082500			01.00	8
	OSAS/ASSEMBLY REFERENCE MANUAL	60050100			01.50	72
160-A						
	AUTOCOMM REF MANUAL	60051900	A		01.50	70
	FORTRAN REF MANUAL	60051300	B		02.50	120
	INTERFOR REF MANUAL	60051200			02.50	114
	OSAS-A ASSEMBLY REF MANUAL (SYSTEM)	60050700	C		01.00	52
	PERIPHERAL PROC REF MANUAL	60051700			01.00	36
	RT DECODER INST REF MANUAL	60025100	A		01.00	42
	SASY OPERATORS GUIDE	60171100			01.00	48
	SICOM REF MANUAL	60051500	A		02.50	132
MISCELLANEOUS						
	SYSTEMS PROGRAMS FOR THE 160 COMPUTER	60008400		22	08.80	304
	CHARACTERISTICS OF 160-A	60019100	C		01.00	20
270	DIGIGRAPHICS SYSTEM					
	DIGIGRAPHIC SYSTEM 270 FUNCTION CONTROL	60146400			01.00	56
	PROGRAM SPECIFICATIONS					
	DIGIGRAPHIC SYSTEM 270 FUNCTION CONTROL	60146500			01.50	84
	PROGRAM SPECIFICATIONS (SUPPLEMENT)					
	DIGIGRAPHIC SUBSYSTEM FOR 3300 GEN.DESC	60146600	B	22	01.50	74
	SYSTEM OPERATION					
	DIGIGRAPHIC SUBSYSTEM FOR 3300 (STUDY GUIDE)	60233700	A	22	01.50	78
469	COMPUTER SYSTEM					
	ASSEMBLER REF MAN V1.2	14077300		22	01.50	66
	BASIC ARITHMETIC REF MANUAL	14082200	B	22	02.00	90
	PROGRAMMING REF MANUAL	14065300	B	22	03.00	150
	SIMULATOR REF MAN V1.0B	14082100	D	22	02.00	88
	SUBROUTINES					
924-A	COMPUTER					
	924 ASSEMBLY PROGRAM FOR PAPER TAPE-CM01	60082600			01.00	16
1604-A						
	FORTRAN -60 OPERATING GUIDE	60138100			01.00	48
	SOURCE LANGUAGE (PSB)	60138000			02.00	88
1604-C/1604-A	FORMERLY 1604/1604A					
	ALGOL (AE15) GIM	60083400			01.00	84
	ALGOL (SP002) GIM	60084100			02.05	44
	CODAP-I (PSBAE10) GIM	60081000			01.00	8

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
	REF MANUAL	60051000			01.00	48
COMPATABILITY		60083600			01.00	10
COSY ASSEMBLY	PSR	60081100	A		01.00	8
COBOL	REF MANUAL	60052100	B		06.00	222
	INTRODUCTION TO	60052000			01.00	60
COM2	REF MANUAL	60051100			01.50	66
COM3	REF MANUAL	60052600			01.50	68
CO-OP MONITOR	REF MANUAL	60051600	B	3	02.00	94
	INSTANT	60056100			01.35	36
	OPERATORS GUIDE	60050900			02.00	92
	PROGRAMMING GUIDE	60050800	A		03.00	150
FTN-60 SP001	GIM	60084000			04.00	190
FORTAN II/63	CONV GUIDE (PSBAE13)	60081300			01.00	12
FORTAN IV/67	CONV GUIDE (AE-15)	60081500			01.00	10
FORTAN 60/62	CONV GUIDE (PS A505)	60080500			01.00	28
FORTAN-62		60050600	A		02.50	116
FORTAN-63		60052900	A	3	04.00	196
LIBEDIT		60080400			01.00	18
PERT		60053900			02.00	96
PERT/TIME/FTN		60139000			01.00	28
SORT		60053500		3	01.50	86
SORT TIMING		60083700			01.00	19
MISCELLANEOUS						
	CHARACTERISTICS	60001800	C		02.00	104
	COMPUTER CENTER OPERATIONS (MASTER TAPE)	60018200	B		01.00	36
	PROGRAMMING SYSTEMS	60052200			01.00	8
	PART 2 OPERATION	60003200			05.50	266
1700	ASSEMBLY SYSTEM (4K)	60133900	A		01.00	28
	REFERENCE	60171600			01.50	70
	INSTANT	60173700			01.35	28
	ADB	60176500			01.00	34
1700	MSOS					
	REF MAN V2	60223100	C		05.00	260
	REF MAN V4	60361500	D	22	08.75	460
	DIAGNOSTIC HB V4	60361800	D		03.65	144
	IHR V2.1	60234300	F	22	05.20	118
	THR V4.0	60361600	C	22	06.40	328
	OPERATORS GUIDE V4.0	60373400	A	22	01.50	74
	SYSTEM CHKOUT REF V2	60362200	A		01.00	42
	IMPORT (1700) HS REF	60305700	A	22	02.00	90
MSOS 4	FILE MANAGER V1 REF	39520600	B	22	02.50	110
	ASSEMBLER, MACPO GIM	39519800	B	22	01.00	38
	INSTANT	39520500	A		02.75	82
	GIM	39522400	B	22	01.00	38
	MS/FORTAN VER3-A/R	39519900	A	22	01.00	56
	INSTALLATION HANDBOOK	39520900	A	22	03.00	138
	GENERAL INFO MANUAL					

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
INSTANT SMALL COMPUTER MAINT. MONITOR V1	39521700	A		01.35	44
ORDERING BULLETIN V4	39521900	B	22	01.50	76
RCOS 2 ASSEMBLER REF MANUAL	88997600	A	22	01.50	72
RFF MAN V2	88948500	A	22	03.50	178
RELEASE BULLETIN	39520800	A	22	01.25	72
TIME-SHARE REF MAN 2.0	88964000	A	22	04.00	198
TOTES FILE MGR UTILITY PROG	88947900	A	22	13.65	74
OPERATORS GUIDE	88818500	A	22	15.85	94
GIM	96716700	A	22	02.90	46
ASSEMBLER, MACRO REF MAN V3	60361900	B	22	02.00	88
CONFIGURATION REF MAN V2	60362300	C	22	02.00	98
COSY/MSOS REF MANUAL	60362100	B		01.00	28
MS FORTRAN REF MAN V3	60362000	D	22	04.50	230
OLYMPUS 1700 DIAGNOSTIC PACKAGE SOFTWARE	39268100	D	22	03.90	130
SMALL COMPUTER MAINTENANCE MONITOR REF. MAN.	39520200	A	22	01.50	76
UTOPIA 1700 CONSOLE DEBUGGING PKG. SOFTWARE	84797500	C	3	01.50	80
1700					
REDUCED CORE MONITOR					
REDUCED CORE IHR V1	60282800	A	22	02.50	116
REF MAN V1	60280600	A	22	01.50	84
1700					
UTILITY SYSTEM					
GIM	60170700		3	01.00	20
REF MANUAL	60172300			02.00	90
INSTANT	60173700			01.35	28
ASSEMBLER					
GIM	60133900	A		01.00	28
REF MANUAL	60171600			01.50	70
INSTANT	60173700			01.35	28
TAPE FORTRAN					
REF MANUAL	60174200		3	02.50	122
INSTANT	60173700			01.35	28
I/O DRIVERS					
17481430	60190000			01.00	50
	60234500			01.00	16
SYSTEM BULLETINS					
SR 8	60194000			02.00	88
SR 9	60222200			01.00	22
SR 13	60228500			01.00	20
MISCELLANEOUS					
SEQ. NO. ONLY					
ANALOG/DIGITAL SYSTEMS GENERAL INFORMATION	60187600			02.00	92
AUTPAN USERS GUIDE V2.0	88762200	C	22	03.00	142
AUTRAN REFERENCE MANUAL V2.0	88762000	B	22	05.50	286
AUTRAN IHR V2.0	88762100	B	22	03.00	158
AUTRAN DACS SOFTWARE REFERENCE MAN V1	39644500	C		07.55	280
AUTPAN IT SYSTEMS MAINTENANCE SPECIFICATIONS VOLS 1 AND 2	39201800	A	22	09.00	512
CARDIO TEST II SOFTWARE OPERATORS GUIDE	39677500	A		01.00	26
DRAFT (VER. 5.1) OCR REFERENCE MANUAL	48143900	F	3	04.50	118
915/919 GRASP (VER. 2.2) OCR SOFTWARE REF MAN	48430100	B	3	03.10	80
955 GRASP (VER. 2.3) OCR SOFTWARE INSTALLATION HANDBOOK	91556200			02.45	22

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5	
MEDISCOPE GENERAL INFORMATION MANUAL	60259500		3	01.00	34	
MESSAGE ENTRY SYSTEM (MENS) SITE PREPARATION MANUAL	41600000	C	22	01.50	68	
PARIMUTUEL WAGERING SYSTEM GIM	59155600	01	22	01.00	42	
REMOTE I/O SUBSYSTEM (PRODUCTION CONFIGURA- TION) HDR. REF./OE MANUAL	39260700	A	22	08.65	482	
SETPAN SOFTWARE REFERENCE MANUAL	60259400	B		01.50	60	
SHORT OPERATING SYSTEM PROGRAM RULES REF.	60259700	A		03.50	182	
SUP-SOFTWARE REFERENCE MANUAL	91637300	01	22	03.30	54	
SUP (VER.1.0) SOFTWARE INSTALLATION HANDBOOK	91602400	B		02.50	34	
TICKET ISSUING SYSTEM USERS GUIDE	59155100	A		01.00	32	
TAPE SCOPE OCR SOFTWARE REF MANUAL	48430010	04	3	03.00	148	
1700/SC1701 ASSEMBLER OCR SOFTWARE REF MAN	91634000	A	22	04.00	80	
915/919 AN) 955/959 SETUP (VER.1.4) OCR SOFTWARE REFERENCE MANUAL	91674400	A		01.95	30	
955 GRASP (VER.2.3) OCR SOFTWARE REFERENCE	48430000	C	3	03.25	38	
915/919 GRASP (VER.2.2) OCR SFTWARE INSTALL.	91529600		3	01.00	42	
929 DRIVE(1784) SOFTWARE REF MANUAL	87971800	B	22	04.05	112	

3170/3300/3500 COMPUTER SYSTEMS						
* MASTER V4 *						

MASTER						
	DIAGNOSTIC HANDBOOK	60415500	C	22	09.75	539
	GTM	60134100	B	22	01.00	34
	INSTALLATION HANDBOOK	60415300	D	22	08.25	458
	INSTANT	60426000	A	22	01.35	102
	LTB GEN/MAINT MANUAL (INCLUDES COSY,CUP,GLIB, SYSGEN)	60415400	C	22	07.50	368
	OPERATORS GUIDE	60415200	A	22	02.00	108
	REFERENCE MANUAL	60415100	C	22	09.75	556
	USERS GUIDE	60425700	A	22	05.50	278
	UTILITIES REF MANUAL	60418900	B	22	02.00	107
ALGOL	REF MANUAL	60371800	C	22	04.00	190
COROL, ANSI	REF MANUAL	60417800	C	22	06.00	305
COROL, MS	REF MANUAL	60192000	B	22	04.00	188
COMPASS	REF MANUAL	60236800	C	22	06.40	314
FORTRAN, ANST	REF MAN V2	60281400	C	22	04.50	214
	REF MAN V1	60236500	B	22	03.50	168
FORTRAN, MS	REF MANUAL	60057600	G	22	05.00	254
LISA	REF MANUAL	60236900	B	22	02.50	122
L-SORT	REF MANUAL	60343500	B	22	01.50	64
MS-SORT	REF MANUAL	60418000	B	22	01.50	91
MARS-III	REF MANUAL	60372700	A	22	07.90	416
	USERS MANUAL	60372800	A	22	02.50	136
MOS-III	REF MANUAL	60282400	E	22	03.50	172
META	REF MANUAL	60236400	B	22	03.50	164
PERT/COST	REF MANUAL	60132500	A	22	01.50	78
PERT/TIME	REF MANUAL	60131100		22	01.00	58

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
RESPOND-EXP/IMP REF MANUAL	60372300	B	22	02.00	110
TAPE SORT/MERGE REF MANUAL	60282100	E	22	02.50	118
3170/3300/3500 COMPUTER SYSTEMS					

* MASTER V3 *					

MASTER					
DIAGNOSTIC HDBK V3	60280800	F	22	09.40	520
GIM	60134100	B	22	01.00	34
IHR	60372500	F	22	08.25	460
INSTANT	60227600	D		01.35	34
LIBRARY GEN/MAINT MANUAL (INCLUDES COSY,CUP,GLIB, SYSGEN)	60373100	D	22	07.15	370
OPERATORS GUIDE V3	60281300	E	22	04.00	208
REF MAN V3	60281000	D	22	09.00	494
USERS GUIDE V3	60371600	B	22	05.50	266
ALGOL	60134900			01.35	34
REF MANUAL	60371800	C	22	04.00	190
COBOL, ANSI	60213500	A	22	01.00	52
INSTANT	60229500	B		01.35	32
REF MANUAL	60281100	F	22	08.25	456
COBOL, MS	60056300		3	02.25	32
REF MANUAL	60192000	B	22	04.00	188
COMPASS	60176700	B		01.35	20
REF MANUAL	60236800	C	22	06.40	314
FORTRAN, ANSI	60229300	A		01.35	26
REF MAN V2	60281400	C	22	04.50	214
FORTRAN, MS	60055200	C	22	01.00	40
INSTANT	60131400	E		01.35	20
REF MANUAL	60057600	G	22	05.00	254
LISA	60236900	B	22	02.50	122
L-SORT	60343500	A	22	01.50	64
MAPS	60372700	A	22	07.90	416
USERS GUIDE V2	60372800		22	02.50	136
MCS III	60282400	E	22	03.50	172
META	60236000	A	22	01.00	56
REF MANUAL	60236400	B	22	03.50	164
MS SORT	60362400	A	22	02.50	116
PERT COST	60130000		22	01.00	16
REF MANUAL	60132500	A	22	01.50	78
ADV DEV BULLETIN	60179800			01.00	20
PERT TIME	60131100		22	01.00	58
APP DEV BULLETIN	60179700			01.00	14
APP DEV BULLETIN V2	60172800			01.00	22
TAPE SORT/MERGE REF MANUAL	60282100	E	22	02.50	118
RESPOND EXP/IMP REF MANUAL	60372300	B	22	02.00	110
INSTANT	60227700	A		01.35	36

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
3170/3700/3500 COMPUTER SYSTEMS					

* MASTER V3,V4 (MISC) *					

ANSI FORTRAN REF MAN V1 (FOR MASTER V3,V4)	60236500	B	22	03.50	168
MS SORT V2 (FOR REF MANUAL MASTER V3.0 AND V3.1)	60282200	B	22	02.00	100
L-SORT V1 (FOR REF MANUAL MASTER V3.0 AND V3.1)	60280200	A	22	01.00	28
DCP MARK 4 DIGI- REF MANUAL GRAPHICS (ONLY FOR MASTER V3.0)	60236600	A	22	03.00	156
MAPS REF MAN V1	60281900	B	22	08.25	446
USERS GUIDE V1	60282000	B	22	02.50	120
3170/3300/3500 COMPUTER SYSTEMS					

* MASTER V2 *					

MASTER					
REF MAN V2	60213600	D	22	07.50	388
DIAGNOSTIC HDBK V2	60206800	B	22	04.50	214
IHB V2	60214000	G	22	08.65	466
OPERATORS GUIDE V2	60178600	B	22	02.50	132
COSY REF MANUAL	60178800	B	22	01.00	36
3100/3150/3170/3200/3300/3500 COMPUTER SYSTEMS					

* MSOS V5 *					

MSOS					
DIAGNOSTIC HANDBOOK INSTANT	60410900	C	22	05.50	287
IHB	60411000	A		01.35	164
OPERATORS GUIDE	60410800	D	22	06.40	326
REF MANUAL	60410700	B	22	01.50	108
ADAPT REF MANUAL	60410600	C	22	07.50	405
ALGOL REF MANUAL	60173400	B	22	02.50	134
COROL, ANSI REF MANUAL	60371800	C	22	04.00	190
COROL, MS REF MANUAL	60417900	A	22	05.00	240
COMPASS REF MANUAL	60191100	C	22	03.50	170
COSY REF MANUAL	60236800	C	22	06.40	314
FORTAN, ANSI REF MANUAL	60207300	C	22	01.00	48
FORTAN, MS REF MANUAL	60281400	C	22	04.50	214
LISA/MSTR/MSOS REF MANUAL	60057600	G	22	05.00	254
REFI COST REF MANUAL	60236900	B	22	02.50	122
REFI TIME REF MANUAL	60132500	A	22	01.50	78
	60131100		22	01.00	58

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
SAINT	REF MANUAL	60213700	B	22	01.00	46
SORT MERGE	REF MANUAL	60281500	B	22	03.00	158
3100/3150/3170/3200/3300/3500 COMPUTER SYSTEMS						

* MSOS V4 *						

MSOS	DIAGNOSTIC HANDBOOK	60236700	D	22	06.75	340
	GIM	60176000		22	01.00	22
	INSTANT	60190300	B		01.35	44
	IHR	60280700	E	22	07.50	410
	OPERATORS GUIDE	60176100	D	22	04.95	168
	REF MANUAL	60173000	F	22	06.75	358
ADAPT	GIM	60135900			01.00	20
	REF MANUAL	60173400	B	22	02.50	134
	INSTANT	60174900			01.35	34
BSIPP	OPERATORS GUIDE	60190200			01.00	28
COROL	GIM	60056300		3	02.25	32
	REF MANUAL	60172900		3	03.50	176
	INSTANT	60131200	A		01.35	32
COBOL, ANSI	REF MAN V2	60281100	E	22	08.25	456
COBOL, MS	REF MANUAL	60191100	C	22	03.50	200
COMPASS	REF MANUAL	60236800	C	22	06.40	314
	INSTANT	60176700	B		01.35	20
COSY/MSOS/RTS	REF MANUAL	60207300	C		01.00	48
FORTRAN	GIM	60055200	C		01.00	40
	REF MAN V4	60057600	G	22	05.00	254
	INSTANT	60131400	E		01.35	20
FORTRAN, ANSI	REF MAN V2	60281400	C	22	04.50	214
LISA/MSTR/MSOS	REF MANUAL	60236900	B	22	02.50	122
MP	ADR	60192100			01.00	16
MSID	GIM	60189700			01.00	12
	REF MANUAL	60191300	B	3	02.00	112
PERT COST	GIM	60130000			01.00	16
	REF MANUAL	60132500	A		01.50	78
	ADR V2	60172800			01.00	22
	ADR	60177700			01.00	22
PERT TIME	REF MANUAL	60131100			01.00	58
	ADR	60177400			01.00	20
RESPOND	GIM	60190400			01.00	16
	REF MANUAL	60192800			01.00	60
	INSTANT	60229900			01.35	32
SAINT	GIM	60132100	A		01.00	20
	REF MANUAL	60213700	B		01.00	46
SOPS	REF MANUAL	60235900			02.00	96
SEP	REF MANUAL	60207200			01.00	36
SIPP	REF MANUAL	60130400	B		01.00	32
SORT/MERGE	REF MANUAL	60281500	B	22	03.00	158
SORT	REF MANUAL	60174100	A	3	01.50	78
TSORT/MERGE	GIM	60055800	A		01.00	20
UTILITY	REF MANUAL	60279400	B	22	01.00	22

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
3100/3150/3170/3200/3300/3500 COMPUTER SYSTEMS					

* REAL TIME SCOPE *					

REAL TIME SCOPE					
DIAGNOSTIC HANDBOOK	60236700	D	22	06.75	340
GIM	60134300		3	01.00	22
IHB	60237000	A		03.50	180
INSTANT	60191600			01.35	32
OPERATORS GUIDE	60170200	A	3	01.50	64
REF MANUAL	60172500			03.10	86
ADAPT GIM	60135900			01.00	20
REF MANUAL	60173400	B	22	02.50	134
BSIPP OPERATORS GUIDE	60190200			01.00	28
COBOL GIM	60056300		3	02.25	32
REF MANUAL	60132000			03.00	160
INSTANT	60131200	A		01.35	32
ADR V2	60137600			01.00	28
COBOL, GPTD GIM	60055100	R		01.00	20
REF MANUAL	60059300	A		01.50	66
COMPASS REF MANUAL	60236800	C	22	06.40	314
INSTANT	60176700	B		01.35	20
COMPASS 32 GIM	60055000	A		01.00	34
COSY/MSOS/RTS REF MANUAL	60207300	C		01.00	48
FORTAN GIM	60055200	C		01.00	40
REF MANUAL	60057600	G	22	05.00	254
INSTANT	60131400	E		01.35	20
FTN COMPAR 3/6 REF MANUAL	60236100			01.50	86
PERT COST GIM	60130000			01.00	16
REF MANUAL	60132500	A		01.50	78
ADR	60177700			01.00	22
ADR V2	60172800			01.00	20
PERT TIME REF MANUAL	60131100			01.00	58
ADR	60177400			01.00	20
PRT GENERATOR GIM	60133100			01.00	22
REF MANUAL	60134700			02.00	102
INSTANT	60133800			01.35	24
SAINT GIM	60132100	A		01.00	20
REF MANUAL	60213700	R		01.00	46
SIPP REF MANUAL	60130400	R		01.00	32
UTILITY, SCOPE REF MANUAL	60130200			01.00	26
3100/3150/3200 COMPUTER SYSTEMS					

* TAPE SCOPE *					

TAPE SCOPE					
ADR, RANDOM DISK DR.	60138300			01.00	32
GIM	60055400	A		01.00	16
INSTANT	60189000	A		01.35	36

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
	OPERATORS GUIDE	60059100			01.00	32
	REF MANUAL	60171200			04.50	220
BSIPP	OPERATORS GUIDE	60190200			01.00	28
COBOL	GTM	60056300		3	02.25	32
	REF MANUAL	60132000			03.00	160
	INSTANT	60131200	A		01.35	32
	ADB 42	60137600			01.00	28
COMPASS-32	GIM	60055000	A		01.00	34
	REF MANUAL	60236800	C	22	06.40	314
	INSTANT	60176700	B		01.35	20
COSY/MSOS/RTS	REF MANUAL	60207300	C		01.00	48
FORTRAN	GIM	60055200	C		01.00	40
	REF MANUAL	60057600	G	22	05.00	254
	INSTANT	60131400	E		01.35	20
FTN COMPAR 3/6	REF MANUAL	60236100			01.50	84
PERT COST	GIM	60130000			01.00	16
	REF MANUAL	60132500	A		01.50	78
	ADB V2	60172800			01.00	20
	ADB MSOS	60177700			01.00	22
PERT TIME	GTM	60130000			01.00	16
	REF MANUAL	60131100			01.00	58
	ADB/MSOS	60177400			01.00	20
PEGINA	REF MANUAL	60171800	A	3	01.00	60
REPORT PROG GEN	GIM	60133100			01.00	22
	REF MANUAL	60134700			02.00	102
	INSTANT	60133800			01.35	24
SAINT	GTM	60132100	A		01.00	20
	REF MANUAL	60213700	B		01.00	46
STP2	REF MANUAL	60130400	B		01.00	32
TAPE SORT MERGE	GIM	60055800	A		01.00	20
UTILITY, SCOPE	REF MANUAL	60130200			01.00	26
3100/3150/3200 COMPUTER SYSTEMS						

* BASIC DISK SCOPE *						

BASIC DISK SCOPE						
	REF GUIDE ADB	60175100			01.00	32
COMPASS-32	GIM	60055000	A		01.00	34
COMPASS	REF MANUAL	60236800	C	22	06.40	314
	INSTANT	60176700	B		01.35	20
COSY/MSOS/RTS	REF MANUAL	60207300	C		01.00	48
FORTRAN	GTM	60055200	C		01.00	40
	REF MANUAL	60057600	G	22	05.00	254
	INSTANT	60131400	E		01.35	20
FTN COMPAR 3/6	REF MANUAL	60236100			01.50	84
3100/3150/3200 COMPUTER SYSTEMS						

* DISK SCOPE *						

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
DISK SCOPE	REF MANUAL	60171200			04.50	220
	OPERATORS GUIDE	60059100			01.00	32
	INSTANT	60189000	A		01.35	36
COMPASS-32	GIM	60055000	A		01.00	34
COMPASS	REF MANUAL	60236800	C	22	06.40	314
	INSTANT	60176700	B		01.35	20
COSY/MSOS/RTS	REF MANUAL	60207300	C		01.00	48
FORTTRAN	GIM	60055200	C		01.00	40
	REF MANUAL	60057600	G	22	05.00	254
	INSTANT	60131400	F		01.35	18
FTN COMPAR 3/6	REF MANUAL	60236100		22	01.50	84
UTILITY SCOPE	REF MANUAL	60130200			01.00	26
3170/3300/3500 COMPUTER SYSTEMS						

* KRONOS III *						

KRONOS III						
	GIM	41614400	B	22	01.00	26
ASSEMBLE	REF MANUAL	41614800	A		01.00	50
BACKGROUND	REF MANUAL	41615100	A		01.00	22
BASIC	REF MANUAL	41615000			02.00	104
CAL	REF MANUAL	60361100	A		02.00	100
CENTRAL SITE	OPERATORS GUIDE	60342800	A		01.00	48
DEBUG	REF MANUAL	41615300	A		01.00	36
EDIT	REF MANUAL	41614900	A		01.00	52
FORTTRAN/FTN	REF MANUAL	41614700	A		03.00	140
GENERAL SYSTEM	USERS MANUAL	41614600	B	22	01.00	56
GO	REF MANUAL	41615200	A		02.45	28
INSTANT	REF MANUAL	41614500	A		01.35	82
NELIAC	REF MANUAL	60361200	A		02.15	60
3100/3150/3170/3200/3300/3500 COMPUTER SYSTEMS						

* MISCELLANEOUS						

ANALOG MAINT MONITOR (AMM30) SOFTWARE USERS MANUAL		84763300			03.00	138
AUTOLOAD UTILITY (3000L) REFERENCE		60170100			01.00	30
BASIC ASSEMBLER REFERENCE (3100/3200/3300)		60057100			01.50	64
BASIC ASSEMBLY PROG GENERAL REFERENCE MAN		60056800			01.00	20
BASIC FORTRAN REFERENCE MANUAL		60172000			02.50	116
BASIC SYSTEM GENERAL INFORMATION		60056800			01.00	20
BASIC II FORTRAN INSTANT (TAPE/SCOPE)		60189000	A		01.35	36
BASIC II FORTRAN REFERENCE MANUAL		60056900		22	01.00	56
BROKERAGE CONTROL OPERATORS GUIDE		59153300	A	22	03.00	148
BROKERAGE CONTROL OPERATORS GUIDE V4.0		59159100	A	22	03.00	162
BROKERAGE CONTROL REFERENCE MANUAL		59153200	A	22	01.50	80
BROKERAGE CONTROL REFERENCE MANUAL V4.0		59159000	A	22	02.00	88
DDP EQUIPMENT BULLETIN		60157500			01.00	28

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
DIGIGRAPHIC SUBSYSTEM FOR 3000 (STUDY)	60233700	A	22	01.50	78
ILP1/INTEGER LINNEAR PROGRAMMING	60084900	A		01.00	32
MASTER/PROFITS 1.0 INSTALLATION PROCEDURES	97400100	A	22	01.00	24
MASTER/OCS MANUAL	59158900	A	22	04.15	154
MASTER USERS UTILITIES REFERENCE MANUAL	00007300	A	22	01.50	76
MSOS ON-LINE CONTROL SUBSYSTEM (OCS) REF MAN	59158800	A	22	06.25	214
MSOS/PROFITS 1.0 INSTALLATION PROCEDURES	59159600	A	22	01.00	22
PARIMUTUEL WAGERING SYSTEM GIM	59155600	01	22	01.00	42
SASY/SATELLITE (3000L) OPERATORS REFERENCE	60133700			01.00	52
SASY/SATELLITE (3600) OPERATORS REFERENCE	60171100			01.00	48
TIME SHARING EQUIPMENT BULLETIN	60156000			01.00	40
3000L COMMUNICATIONS SYS AND EQUIP REF 1	41606600	01	22	02.00	108
3000L TO CYBER 70 - CONVERSION AIDS SYSTEM VERSION 1.0 - FORTRAN CONVERSION FOR SCOPE 3.4	19980600	B	22	03.00	140
31/32/3300 SYSTEM BULLETIN 61	60236300		3	01.00	16
31/32/33/3500 PRELIM MSOS APPLICATIONS BULL.	60174700		3	01.00	340
31/33/3500 HYBRID LINKAGE SYSTEM SOFTWARE USERS MANUAL	39083500		22	01.00	12
31/32/33/3500 REGINA I	60178000			01.00	7
3200 SASY OPERATORS GUIDE	60133700			01.00	52
3200 SCOPE/EXECUTION INTERROGATION PROG	60139300	A	3	01.00	22
3400/3600/3800 COMPUTER SYSTEMS					

* 3400 DRUM SCOPE *					

DRUM SCOPE					
GIM	60131900			01.00	32
REF MANUAL	60170100			04.00	196
OPERATORS GUIDE	60171900			01.00	52
ALGOL INSTANT	60131700			01.35	24
ALGOL-60 GIM	60173300			01.00	20
COBOL GIM	60170900			01.00	40
REF MANUAL	60170500	A		05.00	239
INSTANT	60057400	A		01.35	28
COMPASS GIM	60055700	A		01.00	32
3400 BASIC REFERENCE MANUAL	60057900			03.00	144
FORTRAN GIM	60055500	A		01.00	36
REF MANUAL	60132900	A		04.50	220
INSTANT	60057500	B		01.35	24
FTN LIB FUNCT REF MANUAL	60057200			02.00	98
GPTA GIM	60058900			01.00	16
REF MANUAL	60059400	A		01.00	44
PERT TIME/COST REF MANUAL	60059500			02.50	118
TAB (EXTENSION)	60139100			01.00	20
SORT III REF MANUAL	60059800	A		01.50	72
UTILITY PACKAGE ADR	60137100			01.00	26
UTILITY COSY ADR	60171500			01.00	12

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
* 3400 TAPE SCOPE *						

TAPE SCOPE						
	GIM	60055600	B		01.00	34
	REF MANUAL	60057800			04.50	228
	OPERATING GUIDE V3	60134200			01.00	56
	INSTANT	60059000	A		01.35	36
	ADB (ADDITION TO REF)	60137200			01.00	20
	ADR (LIB PREPARATION)	60137300			01.00	16
ALGOL	INSTANT	60131700			01.35	24
	ADB	60084800	A		01.50	86
ALGOL-60	GIM	60173300			01.00	20
CEM-4	REF MANUAL	60132300	A		03.35	112
COBOL	GTM	60170900			01.00	40
	REF MANUAL	60170500	A	22	05.00	239
	INSTANT	60057400	A		01.35	28
COMPASS	GIM	60055700	A		01.00	32
	REF MANUAL	60057800	A		04.50	228
	ADR (ADDITION TO REF)	60137200			01.00	20
COMPASS/FTN	MIXED DECKS (PSB)	60137000			01.00	20
FORTTRAN	GIM	60055500	A		01.00	36
	REF MANUAL	60132900	A		04.50	220
	REF MANUAL (GENERIC)	60214900	A		03.50	186
	INSTANT	60057500	B		01.35	24
FTN COMPAR 3/6	REF MANUAL	60236100			01.50	84
FTN LIB FUNCT	REF MANUAL	60057200			02.00	98
GRID	GIM	60058900			01.00	16
	REF MANUAL	60059400	A		01.00	44
INFOL	GIM	60132400			01.00	16
PERT TIME/COST	REF MANUAL	60059500			02.50	118
	TAR (EXTENSIONS)	60139100			01.00	20
SORT III	REF MANUAL	60059800	A		01.50	72
SORT MERGE	GTM	60058700			01.00	16
UTILITY PACKAGE	ADB	60137100			01.00	26
UTILITY COSY	ADR	60171500			01.00	12
	SR 24 (3400)	60192600			01.00	12
	SR 48 (36/3800)	SR001700			02.65	76
	SR 50 (36/3800)	60192700			01.00	12
	SP 51 (36/3800)	60193600			01.00	38
	SR 52 (36/3800)	60215200			01.00	60
	SR 54 (36/3800)	60279200			01.00	24
3400 SYSTEM	GIM	60058300			01.00	28

* 3600/3800 DRUM SCOPE *						

DRUM SCOPE						
	GIM	60131000			01.00	28
	REF MANUAL	60059200	B	22	04.50	222
	OPERATORS GUIDE V1	60171900			01.00	52
	OPERATORS GUIDE	60175000	A		01.00	54
	INSTANT	60131600	A		01.35	36

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
	ADB (BACKGROUND PRG)	60137900			02.60	26
	ADB (DRUM/TAPE SCOPE)	60137500			01.00	16
ALGOL	INSTANT	60131700			01.35	24
ALGOL-60	GIM	60173300			01.00	20
APT	GIM	60131500			01.00	20
	REF MANUAL	60132800	A		05.00	244
	ADB	60190100			01.00	34
	SUPPLEMENT	60192900			01.50	84
CDC KWIC	ADB	60175300			01.00	32
COM-4	REF MANUAL	60177000			02.00	108
COBOL	GIM	60170900			01.00	40
	REF MANUAL	60170500	A		05.00	239
	INSTANT	60057400	A		01.35	28
COMPASS	GIM	60131800			01.00	36
	REF MANUAL	60052500	C		02.00	102
DISK SORT	GIM	60177300			01.00	16
	REF MANUAL	60189600			01.00	48
FORTRAN	GIM	60053400			01.00	52
	REF MANUAL	60132900	A		04.50	220
	OPERATING GUIDE (PSB)	60138200			01.00	46
	INSTANT	60057500	B		01.35	24
FTN LIB FUNCT	REF MANUAL	60056400	B		02.50	118
FORTRAN	GIM	60132400			01.00	16
	34/38 INFO MAN	60170300			03.00	140
	INSTANT	60173600			01.35	20
FTN COMPAR 3/6	REF MANUAL	60236100			01.50	84
GPIQ	REF MANUAL	60130600			02.15	40
MSIQ	REF MANUAL	60174800	A		01.00	60
NETWORK FLOW	REF MANUAL	60130500			01.00	52
PERT COST	REF MANUAL	60214800			02.00	92
PERT TIME	REF MANUAL	60170800			01.50	74
PERT TIME/COST	GIM	60170400			01.00	16
SIMSCRIPT	GIM	60133000			01.00	28
	REF MANUAL	60134600			03.00	162
	INSTANT	60133500			01.35	28
SOPT II	GIM	60058600			01.00	20
	REF MANUAL	60058500	D		01.50	78

* 3600/3800 TAPE SCOPE *						

	TAPE SCOPE					
	GIM	60132200	A		01.00	20
	REF MANUAL	60053300	B		05.50	280
	INSTANT	60059000	A		01.35	36
	ADB	60171300	A		01.00	20
ALGOL	INSTANT	60131700			01.35	24
ALGOL-60	GIM	60173300			01.00	20
APT	GIM	60131500			01.00	20
	REF MANUAL	60132800	A		05.00	244
	ADB	60190100			01.00	34
	SUPPLEMENT	60192900			01.50	84

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
CDC KWIC	ADB	60175300			01.00	32
CEM-4	REF MANUAL	60132300	A		02.00	112
COBOL	GIM	60170900			01.00	40
	REF MANUAL	60170500	A		05.00	239
	REV A FOR 36/38 ONLY					
	INSTANT	60057400	A		01.35	28
	EXTENSIONS V2 (PSB)	60138400			01.00	12
	BIN ARITH 3600 COBOL	60083800			01.00	8
COMPASS	GIM	60131800			01.00	36
	REF MANUAL	60052500	C		02.00	102
	INSTANT	60056500	A		01.35	32
DISK SORT	REF MANUAL	60189600			01.00	48
FORTRAN	GIM	60053400			01.00	52
	REF MANUAL	60132900	A		04.50	220
	36/38 INFO REF MAN	60170300			03.00	140
	INSTANT	60173600			01.35	20
	INSTANT	60057500	B		01.35	24
FORTRAN II/3500	CONVERSION GUIDE	60081900	A		01.00	16
FORTRAN 63	CONVERSION GUIDE (PSB)	60082000			01.00	16
FTN LIB FUNCT	REF MANUAL	60056400	B		02.50	118
INFOL	GIM	60132400			01.00	16
	INSTANT	60173600			01.35	20
NETWORK FLOW	REF MANUAL	60130500			01.00	52
OPHELIE	ADB	60172200			02.00	96
PERT COST	REF MANUAL	60214800			02.00	92
PERT TIME	REF MANUAL	60170800			01.50	74
PERT TIME/COST	GTM	60170400			01.00	16
SIMSRIPT	GIM	60133000			01.00	28
	REF MANUAL	60134600			03.00	162
	INSTANT	60133500			01.35	28
SORT II	GIM	60058600			01.00	20
	REF MANUAL	60058500	D		01.50	78
MISCELLANEOUS						
LIBRARY PREPARATION AND MAINTENANCE FOR 3600 (CA-11)		60083500			01.00	24
OSAS-A MASTER TAPE (7681)		60138900			01.00	24
SCOPE MESSAGES AND DIAGNOSTICS (CA-03A)		60082400	A	3	01.00	44
SCOPE OPERATING GUIDE VERSION 2.0		60138800			01.00	28
SUMMIT-NRL 3800 SYSTEM						
COM-4	ADB	60179000			02.00	106
COMPASS	ADB	60177800			02.00	100
DEPEND SYS	ADB	60179500			01.00	28
FORTRAN	REF MANUAL	60177200		22	03.25	100
6000 SERIES OR CYBER 70 MODELS 72,73,74						

* KRONOS V2.1 *						

KRONOS						
	EXPORT/IMPORT REF MAN	59150500	D	22	01.00	32
	GTM	60407100	A	22	01.00	20

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
	IHB	60407500	K	22	09.40	531
	INSTANT	60407200	A		01.35	208
	OPERATORS GUIDE	60407700	D	22	05.00	216
	REF MAN VOL.1 (FOR APPLICATION ANALYST)	60407000	D	22	10.75	618
	REF MAN VOL.2 (FOR SYSTEM ANALYST)	60448200	D	22		
	TERMINAL USER INSTANT	60407800	A		01.35	50
	TEXT EDITOR REF MAN	60408200	B	22	01.50	70
	T-S USERS REF MAN	60407600	C	22	03.00	148
ALGOL	INSTANT V3	60192500	A		01.35	28
	REF MAN V3	60329000	D	22	05.00	240
	REF MAN V4	60384700	A	22	05.00	246
APEX III	REF MANUAL	76070000		22	03.50	244
APL* CYBER	REF MANUAL	19980400	C	22	04.50	204
BASIC	REF MANUAL	19980300	B	22	04.50	232
COBOL	GTM V4	60327800	A	22	01.00	52
	INSTANT V4	60328400	B		01.35	50
	REF MAN V4	60384100	E	22	06.00	598
COMMON UTILITIES	REF MANUAL	60493300	A	3	01.00	32
COMPASS	GTM V3	60343400	A	22	01.00	52
	INSTANT V3	60361000	B		01.35	104
	INSTR CARD V3	60361700	B		00.50	2
	REF MAN V3	60360900	E	22	06.75	356
CYBERLINK INTERCHANGE						
	REF MAN V1	60373300	B	22	01.50	82
	OPERATORS GUIDE	60408400	B	22	01.00	58
EXPORT/IMPORT	REF MANUAL	59150500	D	22	01.00	32
FORTPAN	INSTANT V2.3	60189500	E		01.35	32
	REF MAN V2.3	60174900	F	22	04.50	218
FORTPAN EXT	GTM V4	60327900	A	22	01.00	46
	INSTANT V4	60357900	B		01.35	56
	REF MAN V4	60305600	G	22	09.00	508
	DEBUG GUIDE V4	60329400	B	22	02.00	106
	COMMON LIBRARY MANUAL	60387900	B	22	03.50	166
GPSS V/6000	GTM	84003900	A	3	01.00	94
IGS	LCGT V1 GIM	17322700	B	22	01.20	28
	LCGT V1 REF	17322800	B	22	03.00	40
LOADER	INSTANT	60372200	B		01.35	56
	REF MANUAL	60344200	G	22	04.50	214
MODIFY	INSTANT	60283000	B		01.35	42
	REF MANUAL	60281700	D	22	01.50	78
ON-LINE MAINT	REFERENCE MANUAL	60436600	A	22	02.50	116
PERT/TIME	REF MAN V1.2	60133600	D	22	01.50	76
RECORD MANAGER	CYBER MULTIPLE INDEX PROCESSOR (PSP)	60492900	B	22	01.00	52
	REF MANUAL	60307300	G	22	05.00	254
SIMSRIPT	GTM V3	60173500	A	22	01.00	24
	REF MAN V3	60358500	E	22	04.00	198
STIMULA	GTM V1	60251900	A	22	01.00	30
	REF MAN V1	60234800	F	22	05.00	242
SORT/MERGE	GTM V4	60342400	A	22	01.00	18
	INSTANT V4	60344400	B		01.35	60

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
	REF MANUAL	60343900	G	22	03.00	146
SYMPL	REF MANUAL	60328800	C	22	03.00	172
TOTAL	REF MANUAL	76070300		3	03.50	180
TRANSACTION SUBSYSTEM						
	OPERATORS GUIDE	60408000	B	22	01.00	36
	REF MANUAL	60407900	B	22	04.00	200
	TRANEX USERS GUIDE	60436500	A	22		24
T-S FORTRAN	REF MANUAL	60408600	B	22	03.00	144
UPDATE	INSTANT	60360200	A	22	01.35	44
	REF MANUAL	60342500	E	22	02.00	102
8-BIT SUBROUTINE	REF MANUAL	60359400	C	22	03.00	158
6000 SERIES OR CYBER 70 MODELS 72,73,74						

* KRONOS V2.0 *						

KRONOS						
	EXPORT/IMPORT REF MAN	59150500	D		01.00	32
	GIM	59156600	01		01.00	36
	INSTANT	59152100	01		01.35	12
	OPERATORS GUIDE	59151600	A		03.50	186
	REF MANUAL	59150600	C		09.40	514
	TERMINAL USER INSTANT	59152000	R		01.35	24
	TEXT EDITOR REF MAN	59150700	B		01.00	30
	T-S USERS REF MAN	59151300	B		02.00	94
ALGOL	INSTANT V2	60192500	A		01.35	28
APT	GIM V2.2	60172100			01.00	20
	REF MAN V2.2	60174500	C		05.50	270
COBOL	REF MAN V3	60253000	F		07.50	402
	INSTANT V3	60327600	A		01.35	44
COMPASS	REF MAN V2	60279900	D	22	06.75	354
	INSTANT	60282900	B		01.35	96
FORTTRAN	REF MAN V2.3	60174900	F	22	04.50	218
	INSTANT V2.3	60189500	E		01.35	32
FORTTRAN EXT	INSTANT V3	60305900			01.35	40
FORTPAN TRANSLT	REF MANUAL	59151000	B	22	01.00	26
MODIFY	INSTANT	60283000	B		01.35	42
	REF MANUAL	60281700	D	22	01.50	78
PERT/TIME	REF MAN V1.2	60133600	D	22	01.50	76
SCOPE	INDEXED SEQUENTIAL RM	60305400	E	22	02.50	134
SIMSCRIPT	GIM V2	60173500	A	22	01.00	24
SIMULA	GIM V1	60251900	A	22	01.00	30
	REF MAN V1	60234800	F	22	05.00	242
SORT/MERGE	REF MAN V3	60252600	D	22	03.00	146
T-S BASIC	REF MANUAL	59150800	C	22	02.00	90
T-S FORTRAN	REF MANUAL	60408600	B	22	03.00	144
6000 SERIES OR CYBER 70 MODEL 72/73/74						
CYBER 170 MODELS 172,173,174,175						

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
* NOS V1.0 *					

NOS					
APPLICATIONS PROGRAM-	60436000	A			
MFRS INSTANT					
BATCH USERS GUIDE	60436300	A	22		
EXPORT/IMPORT REF	60436200	A	22	01.00	36
GIM	60435900	A	22	01.00	24
IHR	60435700	A	22		
OPERATORS GUIDE	60435600	A	22		
REF MAN VOL.1 (FOR	60435400	A	22		
APPLICATION ANALYST)					
REF MAN VOL.2 (FOR	60445300	A	22		
SYSTEM ANALYST)					
SYSTEMS PROGRAMMERS	60449200	A			
INSTANT					
TERMINAL USER INSTANT	60435800	A			
TEXT EDITOR REF	60436100	A	22	01.50	68
T-S REF	60435500	A	22		
T-S USERS GUIDE	60436400	A	22		
ALGOL REF MAN V4	60384700	A	22	05.00	246
APL*CYBER REFERENCE MANUAL	19980400				
APT IV GIM	17313200	C	22	01.00	20
REF MANUAL	17313600	C	22	05.50	286
BASIC REFERENCE MANUAL	19983900				
COROL GIM	60327800	A	22	01.00	52
INSTANT	60328400	B		01.35	50
REF MAN V4	60384100	E	22	10.50	598
COMMON UTILITIES REF MANUAL	60493300	A	3	01.00	32
COMPASS GIM	60343400	A	22	01.00	52
INSTANT	60361000	B		01.35	104
INSTRUCTION CARD	60361700	B		00.50	2
REF MAN V3	60360900	E	22	06.75	356
DOL REF MANUAL	60359000	B	22	03.50	182
USERS GUIDE	60384300	A	22	02.00	110
FORTRAN EXT GIM	60327900	A	22	01.00	46
GUIDE FOR USERS OF	60385200	A	22	02.50	136
FORTRAN EXTENDED					
INSTANT	60357900	B		01.35	56
REF MAN V4	60305600	G	22	09.00	508
DEBUG USER GUIDE	60329400	B	22	02.00	106
COMMON LIBRARY MANUAL	60387900	B	22	03.50	166
GPSS V/6000 GIM	84003900	A		01.00	94
IGS LOGT V1 GIM	17322700	A	22	01.00	28
LOGT V1 REF	17322800	B	22	13.00	40
LOADER INSTANT	60372200	B		01.35	56
REF MANUAL	60344200	G	22	04.50	214
MODIFY INSTANT	60283000	B		01.35	42
REF MANUAL	60281700	D	22	01.50	78
ON-LINE MAINT REFERENCE MANUAL	60436600	A	22	02.50	116
REPT/TIME GIM	60133300		22	01.00	16
REF MANUAL	60133600	D	22	01.50	76
QUERY UPDATE REF MANUAL	60307500	D	22	02.00	94

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
	REF MANUAL V2	60384900	D	22	06.40	290
QU DDL	MINI USERS GUIDE	60385500	C		01.35	73
	DATA DEFINITION					
	LANGUAGE FOR THE					
	QUERY UPDATE					
	SUB-SCHEMA					
	REFERENCE MANUAL	60359200	C	22	02.00	112
RECORD MANAGER	REF MANUAL	60307300	G	22	05.00	254
	CYBER MULTIPLE INDEX	60492900	B	22	01.00	52
	PROCESSOR (PSB)					
SIMSCRIPT	GIM	60173500	A	22	01.00	24
	REF MAN V3	60358500	E	22	04.00	198
SIMULA	GIM	60251900	A	22	01.00	30
	REF MANUAL	60234800	F	22	05.00	242
SORT MERGE	GIM	60342400	A	22	01.00	18
	REF MANUAL	60343900	G	22	03.00	146
	INSTANT V4	60344400	B		01.35	60
SYMPL	REF MANUAL	60328800	C	22	03.00	156
TOTAL	REF MANUAL	76070300		3	03.50	180
TRANSACTION SUBSYSTEM						
	OPERATORS GUIDE	60408000	B	22	01.00	36
	REF MANUAL	60407900	B	22	04.00	200
	TRANEX USERS GUIDE	60436500	A	22		24
UPDATE	INSTANT	60360200	A		01.35	44
	REF MANUAL	60342500	E	22	02.00	102
8-BIT SUBROUTINE	REF MANUAL	60359400	C	22	03.00	158
3001L TO CYBER	CONVERSION AIDS					
70	SYSTEM 1.2 FORTRAN	19980600	C	22	03.00	140
	SYSTEM 1.2 COBOL	19980700	B	22	05.50	264
	SYSTEM 1.2 LANGUAGE	19980900	B	22	03.50	178
	CONVERSION USERS					
	GUIDE					
6000 SERIES OR CYBER 70 MODEL 72,73,74						

* SCOPE V3.4 *						

	SCOPE					
	IHR	60307400	V	22	07.15	230
	REF MANUAL	60307200	H	22	09.00	462
	OPERATORS GUIDE	60327300	F	22	06.40	320
	CONV AIDS PSB	60358200	D	22	01.50	68
	USERS GUIDE	60358700	A	22	06.40	320
ALGOL	REF MAN V3	60329000	D	22	05.00	240
	REF MAN V4	60384700	C	22	05.00	246
APEX T	REF MANUAL	59158000	C	22	03.50	172
APEX II	REF MANUAL	59158100	B	22	06.40	318
APEX III	REF MANUAL	76070000		22	03.50	244
APT	GTM	60172100		22	01.00	20
	INSTANT	60193100			01.35	40
	REF MANUAL	60174500	C	22	05.50	270

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
APT IV	GTM	17313200	C	22	01.00	20
	REF MANUAL	17313600	C	22	05.50	286
BASIC	REF MANUAL	19980300	B	22	04.50	232
	REF MANUAL	60306200	C	22	02.00	108
CCP SUPPORT SOFTWARE 1	REF MAN	88988400	A	22	01.00	48
	DIAGNOSTIC HANDBOOK	88988700	A	22	01.00	30
	GTM	88988600	A	22	01.00	34
	MACRO ASSEMBLER REF	88988900	A	22	02.00	102
	MICRO ASSEMBLER REF	88988800	A	22	02.00	102
	PASCAL COMPILER REF	88988500	A	22	01.50	82
	GIM	60327800	A	22	01.00	52
COBOL	INSTANT	60328400	B		01.35	50
	REF MAN V4	60384100	E	22	06.00	598
COMMON UTILITIES	REF MANUAL	60493300	A	3	01.00	32
COMPASS	GIM	60343400	A	22	01.00	52
	INSTANT	60361000	B		01.35	104
	INSTRUCTION CARD	60361700	B		00.50	2
	REF MAN V3	60360900	E	22	06.75	356
DDL	REF MANUAL	60359000	B	22	03.50	182
	USERS GUIDE	60384300	A	22	02.00	110
DDS	REF MAN V3	17318900	A	22	01.50	76
EXPORT/IMPORT	HS REF MAN	60235400	D	22	02.00	106
	8231 REF MAN	60189100	A	22	01.00	48
FORM	REF MANUAL	60307000	F	22	02.50	122
FORTRAN	INSTANT	60189500	E		01.35	32
	REF MAN V2.3	60174900	F	22	04.50	218
FORTRAN EXT	GIM	60327900	A	22	01.00	46
	GUIDE FOR USERS OF FORTRAN EXTENDED	60385200	A	22	02.50	136
	INSTANT	60357900	B		01.35	56
	REF MAN V4	60305600	G	22	09.00	508
	DEBUG USER GUIDE	60329400	B	22	02.00	106
	STFT PSB	60358400	A		01.00	26
	COMMON LIBRARY MANUAL	60387900	B	22	03.50	166
	240 SERIES REF MAN	17307300	E	22	02.50	122
	274 SERIES OG	60359800	C	22	02.00	88
	777 VER 2.0 USERS GUIDE/TRAINING MAN	17322500	A	22	02.00	100
TGS	777 VER.2 OPERATORS GUIDE	17322600	B	22	01.00	40
	777 V2 QUICK DRAW PACKAGE REFERENCE	17325100	A	22	01.00	48
	274 SERIES REF MAN	60358800	C	22	03.50	172
	LOGT V1 GIM	17322700	B	22	01.20	28
	LOGT V1 REF	17322800	B	22	03.00	40
	777 3-D V1 REFERENCE	17326500	A	22	02.00	90
	CSSL III REFERENCE	17304400	F	22	04.50	228
	APT/IGS V1 REFERENCE	17310100	B	22	06.75	354
	APT/IGS V1 G.I.M.	17317400	B	22	01.00	20
	777 IGS V2 REFERENCE	17321800	A	22	05.00	254
INTERCOM	REF MANUAL	60307100	E	22	04.00	208
	MUJ PSB	60358300	C	22	01.00	36

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
	INTERACTIVE COMMAND SUMMARY	60384600	D		00.50	2
	INTERACTIVE INTERCOM GUIDE FOR USERS OF FORTRAN EXTENDED	60359700	B	22	03.50	174
	INTERACTIVE PROCEDURE GUIDE	60385600	B		01.35	15
	INTERACTIVE INTERCOM GUIDE FOR USERS OF COBOL	60385700	C	22	03.50	166
	REMOTE BATCH COMMAND SUMMARY	60387400	A		00.50	2
LOADER	INSTANT	60372200	B		01.35	72
	REF MANUAL	60344200	G	22	04.50	222
MARS VI	REF MAN (FULL INV)	17313000	A	22	05.00	262
	REF MAN (PART INV)	60385900	A	22	04.50	226
	REF MANUAL	17305100	A	22	03.00	156
PERT/TIME	GIM	60133300		22	01.00	16
	REF MANUAL	60133600	D	22	01.50	76
QUERY UPDATE	REF MANUAL	60307500	D	22	02.00	94
	REF MAN V2	60384900	D	22	06.40	290
	MTNI USERS GUIDE	60385500	C		01.35	73
QUIDOL QU DOL	REF MANUAL	60327200	D	22	02.00	92
	DATA DEFINITION LANGUAGE FOR THE QUERY UPDATE SUB-SCHEMA					
	REFERENCE MANUAL	60359200	C	22	02.00	112
RECORD MANAGER	REF MANUAL	60307300	G	22	05.00	254
	USERS GUIDE	60359600	C	22	07.50	428
	GUIDE FOR USERS OF FORTRAN EXTENDED	60385200	A	22	02.50	136
	GUIDE FOR COBOL USERS	60385300	A	22	03.00	150
	CYBER MULTIPLE INDEX PROCESSOR (PSB)	60492900	B	22	01.00	52
SIMSCRIPT	GIM	60173500	A	22	01.00	24
	REF MAN V3	60358500	E	22	04.00	198
STIMULA	GIM	60251900	A	22	01.00	30
	REF MANUAL	60234800	F	22	05.00	242
SORT MERGE	GIM	60342400	A	22	01.00	18
	REF MANUAL	60343900	G	22	03.00	146
SYMPL	REF MANUAL	60328800	C	22	03.00	156
UPDATE	INSTANT	60360200	A		01.35	44
	REF MANUAL	60342500	E	22	02.00	102
8 BIT SUBROUTINE	REF MANUAL	60359400	C	22	03.00	158
1700 MSOS	OPERATORS GUIDE	60359800	C	22	02.00	88
	EXPORT/IMPORT REF MANUAL	60305700	A	22	02.00	90
3000L TO CYBER 70	CONVERSION AIDS	19980600	C	22	03.00	140
	SYSTEM 1.0 FORTRAN CONVERSION FOR SCOPE 3.4					
	CONVERSION AIDS	19980700	B	22	05.50	264
	SYSTEM 1.0 COBOL					

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5	
CONVERSION FOR SCOPE 3.4 CONVERSION AIDS SYSTEM 1.0 LANGUAGE CONVERSION USER GUIDE	19980900	B	22	03.50	178	
6000 SERIES OR CYBER 70 MODEL 72,73,74						

* SCOPE V3.3 *						

SCOPE						
IHR	60305100	AC	22	09.00	506	
INDEXED SEQ REF MAN	60305400	E	22	02.50	134	
OPERATORS GUIDE	60306400	F	22	03.50	174	
OPHELIE GIM V1	59156800	A	22	01.00	48	
OPHELIE REF V1	59156900	C	22	05.50	270	
OPHELTE/MIXED REF V1	59157000	B	22	01.50	80	
REF MANUAL	60305200	F	22	07.15	376	
USERS GUIDE	60252700	C	22	06.00	302	
ALGOL	INSTANT	60192500	A	01.35	28	
	REF MAN V3	60329000	D	22	05.00	240
APT	APP DEV BULLETIN	60193100		01.00	40	
	GIM	60172100	22	01.00	20	
	REF MANUAL	60174500	C	22	05.50	270
APT IV	REF MANUAL	17313600	C	22	05.50	286
BASIC	REF MANUAL	60306200	C	22	02.00	108
COBOL	INSTANT	60327600	A	01.35	44	
	REF MANUAL	60253000	E	22	07.50	402
COMPASS	GIM	60174400	C	22	01.00	16
	INSTANT	60191900	B	01.35	26	
	INSTANT V2	60282900	B	01.35	96	
	REF MANUAL	60190900	C	22	04.00	196
	REF MAN V2	60279900	D	22	06.75	354
CSSL3	USERS GUIDE	17304400	F	22	04.50	228
(CONTINUOUS SYSTEM SIMULATION LANGUAGE III)						
EXPORT/IMPORT	HS REF MAN	60235400	D	22	02.00	106
	HS OG	17303100	A	22	01.50	72
	200 REF MAN	60234600	B	22	01.50	86
	8231 REF MAN	60189100	A	22	01.00	48
FORTRAN	INSTANT	60189500	E	01.35	32	
	REF MANUAL	60174900	F	22	04.50	218
FORTRAN EXTENDED	INSTANT	60305900	A	01.35	40	
	REF MANUAL	60329100	D	22	05.00	258
	DEBUG USERS GUIDE	60329400	B	22	02.00	106
TGS	240 SERIES REF MAN	17307300	F	22	02.50	122

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
(INTERACTIVE GRAPHICS SYSTEM)	274 SERIES OG	17303100	A	22	01.50	72
	274 SERIES GIM	44616700	A	22	01.00	46
	274 SERIES USER GUIDE	44629300	E	22	03.50	182
	274 SERIES REF MAN	17303600	F	22	04.50	218
INTERCOM	REF MAN V3	60252800	C	22	03.50	184
JOVIAL	REF MANUAL	17302500	A	22	06.00	300
MARS VI	REF MAN (FULL INV)	17313000	A	22	05.00	262
PERT	GIM	60133300		22	01.00	16
PERT/TIME	REF MANUAL	60133600	D	22	01.50	76
SIFT	PROGRAM SYSTEM BULL.	60358400	A		01.00	26
SIMSRIPT	GIM	60173500	A	22	01.00	24
	REF MAN V3	60358500	E	22	04.00	198
SIMULA	GIM	60251900	A	22	01.00	30
	REF MANUAL	60234800	F	22	05.00	242
SORT/MERGE	REF MANUAL	60252600	E	22	03.00	146
UPDATE	REF MANUAL	60342500	E	22	02.00	102
1700 MSOS	EXPORT/IMPORT	60305700	A	22	02.00	90
MISCELLANEOUS						
CYBER 70 COMPUTER SERIES NUCLEAR CODES MAN		20085400		3	01.20	73
CYBER 70 COMPUTER SYSTEM MODELS 72,73,74		60359800	C	22	02.00	88
6000/1700 COMPUTER SYSTEM 274 INTERACTIVE GRAPHICS SYSTEM OPERATORS GUIDE MODELS 72, 73,74 VERSION 2/6000 V2, MSOS IMPORT HIGH SPEED OPERATORS GUIDE 1700 VERSION 1						
6000/CYBER 70 COMPUTER SYSTEMS INTERACTIVE INTERCOM GUIDE FOR USERS OF FORTRAN EXT.		60359700	A	22	03.50	174
COROL 35 REFERENCE MANUAL		17308300	A	22	05.50	270
COMMAND GENERAL INFORMATION 6000/CYBER 70		97400300	A	22	01.00	32
DATA HANDLER VERSION 1 REFERENCE MANUAL		17322100	A	22	01.50	63
GRAPHICALLY ORIENTED DESIGN AND ANALYSIS SYSTEM (GODAS) V2 REFERENCE MANUAL		17317200	C	22	04.00	204
GIM		17326600	A	22	01.00	40
INTERACTIVE GRAPHICS REF MANUAL V1		44616800	D	22	03.50	186
INTERACTIVE GRAPHICS 274 SYSTEM USERS GUIDE		44629300	D	22	03.50	182
INTERCOM INTERACTIVE PROCEDURE GUIDE		60385600	B		01.35	15
JOVIAL COMPILER REFERENCE MANUAL		17302500	A	22	06.40	328
KRONOS WORKSHOP REFERENCE MANUAL V2.1		97404700	B	22	13.65	810
MARS V1 PART-INVERSION REF MANUAL		17305100	A		03.00	156
MARS V1 PART-INVERSION USERS GUIDE		17308100	A	22	02.50	134
PLATO SUBSYSTEM AUTHORS GUIDE		97404900	B1	22	01.50	56
OPERATING GUIDE		97405200	01	22	03.60	117
TUTOR REFERENCE MANUAL		97405100	01	22	04.50	204
USERS GUIDE		97404800	01	22	01.00	15
INSTALLATION HANDBOOK		97405000	01	22	01.00	22
SCOPE INTEGRATED SCHEDULER TUNING GUIDE PSR (CYBER 71/6000 SERIES)		60493500	A	22	01.50	66
SCOPE OPERATING SYSTEM SALES HANDBOOK V3.4.1		60425300		22	02.80	155
SCOPE 3.2/3.3 PERM FILE PRESERVATION BULL.		60327000	A		01.00	26
SORT TIMING PROGRAM		60083700			01.00	19
TRAFFIC GENERAL INFORMATION MANUAL		97405500	B	22	01.50	120

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
6000/CYBER 70 COMMAND BILL OF MATERIAL REFERENCE MANUAL	59159700	B	22	02.50	114
6000/CYBER 70 COMPUTER SYSTEM MULTI-ACCESS RETRIEVAL SYSTEM MARS VT FOR FULL INVERSION REFERENCE MANUAL VERSION 2.1	17313000	A	22	05.00	262
6000/CYBER 70 INTERCOM MULTI-USER JOB CAPABILITY PROGRAMMING SYSTEM BULLETIN FOR TIME-CRITICAL APPLICATIONS GIM	60358300	C	22	01.00	36
6000/CYBER 70 SERIES HIGH-PERFORMANCE SYSTEM	17309700	A	22	02.50	116
6000/CYBER 70 SERIES TIME-CRITICAL SIMULA- TION SYSTEMS GIM MODELS 72/73/74 V3-6000 V4	44629200	C	22	02.00	98
6000 INTERCOM MULTIUSER JOB CAPABILITY PSB VERSION 3	60327400	D	22	01.00	34
6000/240 SERIES INTERACTIVE GRAPHICS SYSTEM REFERENCE MANUAL	17307300	F	22	02.50	122
6000 KWIC APPLICATIONS DEV. BULLETIN	60137700			02.65	28
6000 MIMTC SIMULATION LANGUAGE REFERENCE	44610400	E	22	05.75	152
6000 SCOPE OPERATING SYSTEM TIME CRITICAL MODULE REF V2 (SCOPE 3.3 TC)	17304200	A	22	01.00	42
6000 SEISMIC DATA PROC. SYSTEM REF MANUAL	60342700		22	01.50	66
6000 SEISMIC DATA PROC. SYSTEM IHB	60343000	A	22	01.00	30
64/6500 ASSIST USERS GUIDE	60345100	03	22	02.50	132
64/65/6600 TTY RESPOND REF MAN	60199300	B	22	02.00	112
64/65/6600 TTY RESPOND INSTANT	60191500			01.35	28
7600					

* SCOPE V1.1 *					

SCOPE					
GIM	60280000	A	22	01.00	62
IHR	60282500	A	22	05.50	286
INSTANT	60343100	A		01.35	128
REF MANUAL	60281200	B	22	05.00	254
COMPASS REF MAN V2	60279900	D	22	06.75	354
GIM V2	60279600	A	22	01.00	40
OPU CARD V2	60279700	B		00.50	2
PPU CARD V2	60279800	B		00.50	2
INSTANT V2	60282900	B		01.35	96
FORTRAN EXT REF MANUAL	60329100	D	22	05.00	258
FOPTRAN RUN REF MANUAL	60280400	A	22	03.50	172
GIM	60279500		22	01.00	36
MODIFY REF MANUAL	60281700	D	22	01.50	78
INSTANT	60283000	B		01.35	42
MOX REF MANUAL	60237400	A	22	01.00	56
SOM/MCM OPERATORS GUIDE/REF	60372900	A	22	01.50	72
UPDATE INSTANT	60360200	A		01.35	44
REF MANUAL	60342500	E	22	02.00	102

* SCOPE V1.1 STATIONS *					

7611-1 I/O STN OG/REF	60281600	A	22	02.50	134
7611-1 I/O STN INSTNT	60283100			01.35	38

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
CYBER 70/MODEL 76 OR 7600 ***** * SCOPE V2.1 * ***** SCOPE					
REF MANUAL	60342600	H	22	06.40	322
USERS GUIDE	60372600	C	22	07.15	366
DIAGNOSTIC HANDBK	60344100	E	22	02.00	106
GIM	60342200	B	22	11.00	36
IHR V2.0	60344000	C	22	07.90	424
IHR V2.1	60426100	C	22	09.40	518
INSTANT	60344300	B	6	01.35	108
ALGOL REF MANUAL	60384700	C	22	05.00	246
APEX I REF MANUAL	59158000	C	22	03.50	172
APEX II REF MANUAL	59158100	B	22	06.40	318
GIM	59157900	A	22	01.00	26
APEX III REF MANUAL	76070000		22	03.50	244
APT IV REF MANUAL	17313600	C	22	05.50	286
COBOL REF MAN V2	60384200	B	22	09.40	522
GIM	60327800	A	22	01.00	52
INSTANT	60328400	B		01.35	50
COMMON UTILITIES REF MANUAL	60493300	A	3	01.00	32
COMPASS REF MAN V2	60279900	D	22	16.75	354
GIM V2	60279600	A	22	01.00	40
CPU CARD V2	60279700	B		00.50	2
PPU CARD V2	60279800	B		00.50	2
INSTANT V2	60282900	B		01.35	96
REF MAN V3	60360900	E	22	06.75	356
GIM V3	60343400	A	22	01.00	52
INST CARD	60361700	B		00.50	2
INSTANT V3	60361000	B		01.35	104
FORTRAN EXT REF MAN V4.1	60305600	G	22	09.00	508
GIM	60327900	A	22	01.00	46
INSTANT	60357900	B		01.35	56
DEBUG USERS GUIDE	60329400	B	22	02.00	106
COMMON LIBRARY MANUAL	60387900	A	22	03.00	166
FORTRAN RUN REF MAN V2	60360700	C	22	04.00	210
LOADER REF MANUAL	60344200	G	22	04.50	222
INSTANT	60372200	B		01.35	22
ON-LINE MAINT.					
REF MANUAL	60406200	D	22	01.50	70
RECORD MANAGER REF MANUAL	60307300	G	22	05.00	254
SIMSRIPT 1.5 REF MAN V3	97400200		22	04.50	214
SHM OPERATORS GUIDE V2	60361400	A	22	01.50	80
OPERATORS GUIDE V3	60373800	C	22	02.00	94
SORT/MERGE REF MANUAL	60343900	G	22	03.00	146
GIM	60342400	A	22	01.00	18
INSTANT	60344400	B		01.35	60
SYMBOL REF MANUAL	60328800	C	22	03.00	156
UPDATE REF MANUAL	60342500	E	22	02.00	102
INSTANT	60360200	A		01.35	44

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
* SCOPE V2 STATIONS *					
* AND SUBSYSTEMS *					

6000 STN 3.3 OG/REF MAN	60360400	A	22	03.50	164
6000 STN 3.4 OG/REF MAN	60343800	D	22	02.50	122
GTM	60342100	A	22	01.00	20
INSTANT	60360500	A		01.35	64
7611-1 I/O STN OG/REF MAN	60343600	C	22	03.00	156
GTM	60343300	A	22	01.00	24
INSTANT	60360100	A		01.35	41
7611-2 MAG TAPE STATION					
OG/REF MAN	60343700	B	22	01.50	76
GTM	60342300		22	01.00	20
MAG TAPE SUBSYSTEM					
REF MANUAL	60403900	C	22	02.50	114
MISCELLANEOUS					
6000/CYBER 70 COMMAND REFERENCE MANUAL	59159800	A	22	04.00	202
FORTPAN COMMON LIBRARY MATHEMATICAL ROUTINES	60387900	A	22		140
8090					
OSAS-A REF MANUAL	60130900			01.00	52
OSAS-ASSEMBLY SYSTEM	60058200			01.00	46
SIMULTANEOUS PERIPH PROCESS REF	60059900			01.00	32
915 GRASP OCR REF MANUAL V2.0	48996600			03.65	75
8092					
NIMP THR V2.1	87976700	A		06.05	54
REF MANUAL V2.1	48706201	B	3	05.50	91
TAS IHR V3.0	87976800	A	22	05.75	54
REF MANUAL V3.1	48704601	C	3	04.50	33
UTILITY ROUTINE REF MAN V1.0	48704901	A	3	03.55	56
915 GRASP THR V3.0	91661300	A		03.25	42
REF MAN V2.0	48704800	E	3	02.25	32
915 H/S GRASP PROGRAMMERS REF V1.0	48707800	B	3	05.00	70
915 KEYPUNCH REF MAN V2.1	48707900	E	3	01.70	18
SIMULATOR					
915 LIST PROC. REF MAN V1.0	48706101	C	3	04.50	75
921 DRIVE THR VER 3.1	87976600	A		10.50	28
REF MAN V3.1	48881400	D	3	05.25	36
921 MONITOR REF MAN V1.0	91681100	A	22	03.45	46
IHR	91649500	A		14.85	42

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

SECTION 4

TITLE	1	2	3	4	5
MISCELLANEOUS MANUALS					
A LIBRARY OF NUCLEAR CODES	60139500			01.25	
A STUDY OF METHODS OF ERROR DETECTION DURING TRANSMISSION OF BINARY INFORMATION	60426500	A	22	01.65	
AIDS - AUTOMATED INTEGRATED DESIGN SYSTEM GENERAL INFORMATION MANUAL	60427900			06.20	
AIDS - GENERAL PURPOSE WIRE WRAP USERS GUIDE	60443100	A	22	06.85	
AIDS - SEMIAUTOMATIC ARTWORK GENERATION USERS GUIDE	60441000	A	22	03.50	
ALPHA REFERENCE MANUAL	14142900	A	22	01.80	
ALPHA 1 COMPUTER SYSTEM - CPU DIAGRAMS MANUAL VOL. II	14143700	A	34	35.00	
ALPHA 1 COMPUTER SYSTEM GROUND SUPPORT EQUIP. DIAGRAMS MAN. VOL. 2	14143800	A	34	26.20	
ALPHA-1 MIMIC SOFTWARE MANUAL	14155000			01.20	
ALPHA-1 SOFTWARE REFERENCE MAN-ALPHA COMPASS	14123800	A		08.50	
A METHOD OF GENERATING UNIFORM RANDOM NUMBERS (AN APP. REPORT BY W.J.WESTLAKE)	60161200			01.25	
CARE AND HANDLING OF MAGNETIC TAPE	40812300			01.00	
CD CARRIER TRUCKING - ORIENTED TRANSPORTATION APPLICATIONS SOFTWARE GENERAL INFO	97401600	A	22	01.40	
CE ILLUSTRATED TOOL CATALOG	40860000	C	22		
COMMAND SYSTEMS INFORMATION MANUAL	97401500			06.15	
COMMUNICATIONS HANDBOOK	60405100	A	22	01.70	
COMMUNICATIONS SYSTEMS DIVISION TERMINAL UNIT AND DATA SET CE TECH INFO MANUAL	41605200	B	22	03.10	
COMPUTER AIDED MAINTENANCE SCHEDULER (CAMS VERSTON 2) CE MANUAL	60373500	C	22	02.00	
CORPORATE PHOTOGRAPHY CATALOG	20114600		22		
CYBER 1000 DATA COMMUNICATIONS SYSTEM MANUAL	00007500	A		01.95	
CYBER 1000 DCS GENERAL PROPOSAL TO AIRLINE INDUSTRY	73443000	A		02.35	
CYBER 1000 DCS GENERAL PROPOSAL TO BANKING INDUSTRY	73443100	A		02.10	
CYBER 1000 DCS GENERAL PROPOSAL TO MANUFACTURING	73933300	A		02.35	
CYBERDATA KEY-TO-DISK OPERATORS INSTANT	22261900	A		08.40	
SUPERVISORS INSTANT REFERENCE MANUAL	22262100	A		11.14	
22262200					
970-8 REFERENCE MANUAL	22267300	A	3	01.20	
970-8 CE MANUAL	22264500	A	3	04.40	
970-32 REFERENCE MANUAL	22267200	A	3	02.10	
970-32 CE MANUAL	22264600	A	3	03.00	
970-480 CE MANUAL	22264700	A	3	04.30	
970-480 REFERENCE MANUAL	22267100				
INSTALLATION KIT	22263600				

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched in manual for use with hard cover ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
DIAGNOSTIC CONFIGURATOR/CATALOG	00015000		3		
DIAGNOSTIC CONFIGURATOR CATALOG	60408100	B	22	01.80	
DISK STORAGE UNIT MAINTENANCE AIDS MANUAL	70616800	M	22	07.45	
DISK STORAGE UNIT 84-X,975-X MAINT AIDS CE	70619100	J	22	19.45	
DISK STORAGE UNIT 84X,975X-ENHANCED LOGIC CARDS CE MANUAL	70629100	G	22	12.70	
DTL INTEBRID LOGIC GENERAL INFO MANUAL	84785000		3	04.50	
ENGINEERING LOG BOOK	60272100			05.85	
EXTENDED COPE STORAGE DATA PATH AND STOCK SELECT MAINTENANCE AID CHART	59304600				
FORMS DESIGN MANUAL	00000200			02.40	
FIELD BULLETIN, POWER RECEPTACLE INSTALL	40816200		22	02.00	
HARDWARE DEVELOPMENT GUIDELINES INFORMATION	60429200	A	3	03.00	
HOW TO HANDPRINT FOR CONTROL DATA OCR READER	48299727			02.25	
KEY TO LOGIC SYMBOLS G.I.M.	88981500	B	22	05.40	
KEY TO LOGIC SYMBOLS - SYSTEM 17	89723700	-	22	04.90	
KEY TO LOGIC SYMBOLS - TTL	60406000	A	22	01.80	
MAGNETIC TAPE TRANSPORT SINGLE CAPSTON HIGH PERFORMANCE OPERATORS MANUAL	49751600	A	22	01.75	
MANAGEMENT GUIDE TO EFFECTIVE SELECTION PROCESS	60426700			01.35	
MATH SCIENCE LIBRARY GENERAL INFORMATION MAN	60328900	A		01.00	
MERCHANT USERS MANUAL	13797500			02.15	
MILITARY DISK STORAGE UNIT DESC., THEO OF OPER., DIAGRAMS AND WIRE LIST CE MANUAL	14237500		22	20.40	
PARTS SUPPORT FOR THE OEM CUSTOMER	15002900			00.80	
PLANIT AUTHORS GUIDE	59159400		3	08.30	
PLANIT LANGUAGE REFERENCE MANUAL	97401700			13.30	
POSTAL SOURCE DATA COLLECTION SYSTEM INSTALLATION MANUAL	36829400	C	22	02.55	
POSTAL SOURCE DATA COLLECTION SYSTEM DATA COLLECTION SITE REFERENCE MANUAL	13795600	A	22	01.80	
POSTAL SOURCE DATA COLLECTION SYSTEM TELECONCENTRATOR SITE REFERENCE MANUAL	13795700	A	22	01.00	
POSTAL SOURCE DATA COLLECTION SYSTEM DATA PROCESSING CENTER SITE REF MANUAL	13795500	A	22	02.00	
POSTAL SOURCE DATA SYSTEM REF MANUAL	13795400	C	22	01.00	
PRODUCT TO EQUIPMENT CROSS REFERENCE MANUAL	60071500	R	3	05.70	
PROFITS REFERENCE MANUAL	59158200	B	22	16.25	
PROFITS OPERATORS GUIDE 3000 PROFITS CRT	59158300	A	22	02.70	
PROFITS AN ON-LINE REAL-TIME ENG/MANUF. SYS	59156000			03.90	
PROGRAM MANAGEMENT HANDBOOK	60408300			20.90	
PROGRAMMING REFERENCE AIDS (CONTAINS CONVERSION TABLES, CONSTANTS, POWERS AND HEXADECIMAL INFORMATION)	60158600			04.00	
REVOLUTION IN PROGRAMMING	60417000			02.80	
SCOPE 3.1.6	00006300		3	04.85	
SOFTWARE DEVELOPMENT GUIDELINES	60418500			02.60	
QUALITY ASSURANCE MANUAL	60348600			14.55	
SEISMIC DATA PROCESSING SYSTEM REF. MANUAL	44623700	B	22	11.80	
TIME SLOTTED REQUIREMENTS APPLICATION REPORT	97403600			01.60	
TYPIING FOR CONTROL DATA OCR PAGE READERS	48299700			04.05	

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
EDUCATIONAL MANUALS					
AN INTRODUCTION TO BASIC COMPUTER CONCEPTS	44016000			03.70	
AN INTRODUCTION TO INTEGRATED CIRCUITS	60202000			02.55	
BIOLOGY-PHYSIOLOGY APPLIED TO DIGITAL COMPUTERS	22006700			01.25	
FORTRAN AUTOTESTER JOHN WILFY AND SONS, INC., NEW YORK)	60018600			04.75	
FORTRAN TRAINER STUDENT WORKBOOK (BY BRUCE THOMPSON)	44020500			05.15	
FORTRAN TRAINER PART 1 TEACHERS EDITION BY THOMPSON)	44020300			05.85	
FUNCTIONS, FUNCTION MACHINES AND COMPUTERS BY ROBERT L. ALBRECHT	44016800			01.50	
FUNDAMENTAL COMPUTER CONCEPTS BY DR. ROBERT E. SMITH	22008200			02.00	
INTRODUCTION TO DATA COMMUNICATIONS (BASIC SYSTEMS AND HARDWARE)	13798900	C	22	05.95	
MATHEMATICS OF CHEMISTRY AS APPLIED TO DIGITAL COMPUTERS	22006500			01.60	
SECONDARY LEVEL PHYSICS AS APPLIED TO DIGITAL COMPUTERS	22006600			01.25	
STATISTICS APPLIED TO DIGITAL COMPUTERS	22006900			01.00	
TRAINING MANUALS					
160-A TRAINING WORKBOOK (FORMERLY 082666)	60273400			07.50	
160-A FORTRAN TRAINING MANUAL	60165000			04.50	
360 ASSEMBLY LANGUAGE TRAINING MANUAL	60354600	B	3	03.70	
546 SUPPLEMENTAL MANUAL (FORMERLY A-095102)	60238400			01.40	
915 PAGE READER-A PROGRAMMED TEXT VOL. I (FORMERLY 020568)	60241000	A		01.00	
1500 SERIES SYSTEM CODES	76360010			01.90	
1604 TYPE CARDS	60314100			00.75	
1604 PRINTED CIRCUITS (FORMERLY 010367)	60240600			01.40	
1700 COMPUTER MAINTENANCE TRAINING MANUAL, VOL I, 2ND EDITION	60169500	B		03.40	
1700 COMPUTER MAINTENANCE TRAINING MANUAL, VOL II, 2ND EDITION	60169600	A		05.85	
1700 COMPUTER MAINTENANCE TRAINING MANUAL, VOL III	60184900			01.75	
1700 PRINTED CIRCUITS MANUAL	083066A0			12.00	
1700 PROGRAMMING TRAINING MANUAL	60207900	B		07.85	
1728 CARD READER/PUNCH TRAINING MANUAL (FIRST EDITION)	60241400			01.55	
1738 DISK CONTROLLER TRAINING MANUAL (FORMERLY 010268A)	60257900			02.55	
2013 BADGE READER ADAPTED TRAINING MANUAL, TEST EDITION (FORMERLY 041467)	60240400			01.00	
3L00 HARDWARE STUDENT MANUAL	60380500		3	11.85	
3000 PRINTED CIRCUITS (FORMERLY 092166)	60238500			02.25	
3000 TYPE CARDS	60314200			01.00	
3L00 SOFTWARE STUDENT MANUAL	60380400	A	3	01.80	

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
31/32/33/3500 COMPUTER SYSTEM COBOL TRAINING	60314900	C		05.15	
31/32/33/3500 FORTRAN TRAINING MANUAL	60199700	A		06.75	
3100/3200 TRAINING HANDOUTS (FORMERLY 042767)	60258100			03.90	
3100/3200/3300/3500 COMPASS PROGRAMMING TRAINING MANUAL VOLS 1 AND 2	60311500	A		05.40	
3200 TRAINING MANUAL, VOL I, 2ND EDITION, (FORMERLY 020968)	60257700			03.60	
3200 TRAINING MANUAL VOL 2, 2ND EDITION (FORMERLY 021068)	60257800			07.35	
3200/3300 DIFFERENCE COURSE WORKBOOK	01306700			02.20	
3203/3209 STORAGE MODULE TRAINING MANUAL	60143400		22	03.50	
3229 MAG TAPE CONTROLLER TRAINING MANUAL, FIRST EDITION (FORMERLY 021268)	60239200	A		03.00	
3234-A MASS STORAGE CONTROLLER TRAINING SUPPLEMENT	60249400			01.05	
3300 COMPUTER TRAINING MANUAL VOL 1	60158700	A		02.70	
3300 TRAINING MANUAL, VOL II, 2ND EDITION	60158800			07.50	
3312 BUSINESS DATA PROCESSING TRAINING MAN., VOL I, 2ND EDITION (FORMERLY 091566B)	60249900			02.65	
3312 BDP TRAINING MANUAL VOL II, 2ND EDITION (FORMERLY 020568)	60250000			13.40	
3400/3600/3800 COMPASS TRAINING MANUAL, VOLS I, II, III	60166700	B		15.65	
3447-A CARD READER CONTROLLER TRAINING MAN.	60273500			03.40	
3500 BLOCK CONTROL HANDBOOK	60274300			01.05	
3600 COMPUTER MAINTENANCE WORKBOOK	04266700			10.50	
3600/3800 DIFFERENCE TRAINING MANUAL (FORMERLY 032467)	60273600			04.35	
6000 ASCENT/COMPASS PROGRAMMING TRAINING	60183400			04.90	
6000/CYBER 74 COMPUTER MAINTENANCE CHARTS AND DIAGRAMS FOR TRAINING PURPOSES	60378600		34	08.55	
6000 INTRO. AND PERIPHERAL PROCESSOR TRNG. MANUAL (FORMERLY 020267)	60250400			02.00	
6000 SERIES ASPER/COMPASS PROGRAMMING	60183300			03.65	
6400 CENTRAL PROCESSOR TRAINING MANUAL (FORMERLY 011167)	60257200			04.15	
6600 CENTRAL PROCESSOR TRAINING MANUAL VOL 1 CONTROL AND MEMORY (FORMERLY 020167)	60241300			08.65	
6600 CENTRAL PROCESSOR, VOL II, FUNCTIONAL UNITS (FORMERLY 091466)	60239700			05.80	
6600 COMPUTER WORKBOOK AND TIMING DIAGRAMS (FORMERLY 042167)	60258000			03.80	
6600 STANDARD PERIPHERAL TRAINING MANUAL, TEST EDITION (FORMERLY 092967)	60239500			01.00	
6638 DISK FILE SUBSYSTEM TRAINING SUPPLEMENT	60250800	A		02.10	
6639 DISK CONTROLLER TRAINING MANUAL (FORMERLY 092867)	60273300			01.05	
8092 TELEPROGRAMMER TRAINING MANUAL	60183900			03.50	
ACTIVE ELECTRONICS STUDENT MANUAL (750 HR)	76360015	A	3	06.10	
ACTIVE NETWORKS EXPERIMENTS, REVISED (APL.) (FORMERLY A-012268)	60250500	C	3	01.80	
ACTIVE NETWORKS WORKBOOK, VOL. I	60274100			05.70	

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
(FORMERLY 082866A)					
ACTIVE NETWORKS WORKBOOK, VOL. II	082966A0			03.00	
ACTIVE NETWORKS WORKBOOK, VOL I (REVISED)	60250600			04.45	
(FORMERLY A-012368)					
ACTIVE NETWORKS WORKBOOK, VOL II (REVISED)	60250700			04.80	
(ARL) (FORMERLY A-012468)					
AN INTRODUCTION TO DIGITAL COMPUTERS, VOL 1	60241600			05.80	
(FORMERLY 081866A)					
AN INTRODUCTION TO DIGITAL COMPUTERS, VOL II	60241700			07.15	
(FORMERLY 091266A)					
AN INTRODUCTION TO DIGITAL COMPUTERS, VOL III	60241800			03.40	
(FORMERLY 032367)					
ASSEMBLY LANGUAGE TRAINING MANUAL	60354700		3	06.70	
ASSEMBLY LANGUAGE STUDENT MANUAL	60315100		3	02.75	
ASSEMBLY LANGUAGE TRAINING SUPPLEMENT	60355500			01.80	
BUSINESS APPLICATIONS STUDENT MANUAL	60315200	A		01.00	
BUSINESS CONCEPTS STUDENT MANUAL	60378900		3	02.75	
BUSINESS MATH AND ACCOUNTING STUDENT MANUAL	60355800		3	01.00	
CARD EQUIPMENT STUDENT MANUAL	60313100			01.00	
CDI CAREER EDUCATION STUDENT HANDBOOK (1975)	76360031			01.15	
CENTRAL PROCESSOR SOFTWARE STUDENT MANUAL	60353700			02.05	
CENTRAL PROCESSOR HARDWARE STUDENT MANUAL	60379200	A	3	12.00	
VOL. I-II					
COMMUNICATIONS AND CUSTOMER RELATIONS	60378100		3	01.00	
STUDENT MANUAL					
COMPASS STUDENT MANUAL BOOK I	60313600		3	01.00	
COMPASS STUDENT MANUAL PART II	60314300		3	01.00	
COMPUTER IN CREDIT STUDENT MANUAL	60378400		3	01.00	
COMPUTER SYSTEMS OPERATIONS STUDENT MANUAL	76360011		3	05.20	
COMPUTER TECHNOLOGY HARDWARE WORKBOOK	60241200	A		02.70	
COMPUTER TECHNOLOGY STUDENT MANUAL	60314800	A	3	01.00	
COMPUTER TECHNOLOGY SOFTWARE TRAINING SUPP.	60239600			01.00	
CONTROL DATA INSTITUTE PRODUCT CATALOG	60379000		3	04.05	
CREDIT PRINCIPLES AND PRACTICES I STUDENT	60378200		3	01.00	
MANUAL					
CREDIT PRINCIPLES AND PRACTICES II STUDENT	60378300		3	01.00	
MANUAL					
CYBER 72/73/74 SCOPE SYSTEM MAINTENANCE	76360012		3	05.35	
STUDENT MANUAL					
DATA PROCESSING CONCEPTS STUDENT MANUAL	60353100			01.20	
DATA TERMINALS AND COMMUNICATIONS SYSTEMS	76360023		3	10.10	
DIAGNOSTIC ROUTINES WORKBOOK (FORMERLY	60238700			01.45	
042467)					
DIGITAL COMPUTER OPERATOR	60312700			01.50	
DIGITAL ELECTRONICS STUDENT MANUAL	60353500	C	3	04.10	
DISK DRIVE STUDENT MANUAL	76360002		3	04.35	
ELECTRONICS REVIEW STUDENT MANUAL	60380100		3	02.15	
GLOSSARY FOR INFORMATION PROCESSING	60240700		3	01.60	
(FORMERLY 070367)					
HANDOUTS FOR POSTOFFICE COURSE	07046700			01.95	
INTEGRATED CIRCUITS STUDENT MANUAL	60380000		3	01.30	
INTRO TO DATA PROCESSING (DCO) STUDENT MAN	60354900			02.55	
INTRODUCTION TO CREDIT STUDENT MANUAL	60355700		3	01.00	

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
LINE PRINTER EQUIP. TRAINING MAN 2ND EDITION (FORMERLY 082166)	60257100	C		07.15	
LOGIC CIRCUIT EXPERIMENTS	60238800	A		02.00	
MAGNETIC RECORDING EQUIP.TAPE STUDENT MANUAL	60314400	A		01.00	
MAGNETIC RECORDING EQUIP. DISK STUDENT MAN	60354300	C	3	03.30	
MAGNETIC TAPE-ITS PRINCIPLES AND CERTIF. (FORMERLY 62466)	60256700			01.30	
MAGNETIC TAPE STORAGE TRAINING MANUAL (FORMERLY 081766B)	60239400	C		03.50	
MODEL 33 TELETYPEWRITER TRAINING MANUAL (FORMERLY 060167)	60273900			03.35	
MSOS PROGRAMMING TRAINING MANUAL	60257600			02.20	
OPTICAL CHARACTER RECOGNITION STUDENT MANUAL	60355400		3	01.00	
PASSIVE ELECTRONICS STUDENT MANUAL	60354500	G	3	06.70	
PASSIVE NETWORKS EXPERIMENTS (REVISED ED) (FORMERLY A-010468)	60250200		22	01.15	
PASSIVE NETWORKS WORKBOOK, REVISED, (ARL.) (FORMERLY A-010358 AND 090166B)	60250100			04.60	
PASSIVE NETWORKS WORKBOOK TRAINING SUPP.	60250300			04.05	
PHASE I PROGRAMMING TECHNOLOGY WORKBOOK	04036700			08.70	
PHASE II PROGRAMMING TECHNOLOGY WORKBOOK	04256700			05.60	
PROGRAMMING CONCEPTS WORKBOOK	60274400		3	07.50	
PUNCHED CARD EQUIPMENT STUDENT MANUAL	76360001	C	3	01.10	
PUNCHED CARD EQUIPMENT TRAINING MANUAL	60378700	B	3	05.85	
REPORT PROGRAM GENERATOR STUDENT MANUAL	60379100		3	01.35	
SELECTRIC MAINTENANCE ADMINISTRATION GUIDE	60380200		3	02.50	
SELECTRIC MAINTENANCE STUDENT GUIDE	60380300		3	01.70	
SELECTRIC TYPEWRITER TRAINING MANUAL, SECOND EDITION (FORMERLY 080566B)	60238300			02.40	
SMM3L MONITOR COMMAND AND MEMORY TEST LISTINGS (FORMERLY 030767)	60273800			01.35	
SYSTEM/360 COMPUTER OPERATION (DCO) STUDENT	60355200			01.35	
SYSTEM/360 ASSEMBLY LANGUAGE STUDENT MANUAL	60353000	B	3	07.20	
SYSTEM/360 INSTRUCTIONS	60379300			00.75	
SYSTEMS CONCEPTS STUDENT MANUAL	60353300			01.00	
SYSTEMS DESIGN STUDENT MANUAL	60379500		3	01.25	
UNIT RECORD EQUIPMENT (DCO) STUDENT MANUAL	60355100			04.35	
UTILITIES PROGRAMMING STUDENT MANUAL	60353200			01.00	
UTILITIES STUDENT MANUAL	60313500	A	3	01.00	
VISUAL DISPLAY TRAINING MANUAL	60355300		3	01.20	
VISUAL DISPLAYS / SYSTEMS MAINTENANCE STUDENT MANUAL	76360003		3	01.30	
VISUAL RECORDING EQUIP. STUDENT MANUAL	60313400	A		01.15	
WORK SIMULATION STUDENT MANUAL	60378500		3	01.00	
TECHNICAL REPORTS					
TER01- SOLVING DESIGN PROBLEMS IN GRAPHICAL CATALOGUE	00000021			04.95	
TER02- A GENERALIZED LANGUAGE FOR INFORMAT STORAGE AND RETRIEVAL APPLICATIONS	60175600			01.25	
TER03- USE OF INFOL FOR DOCUMENT AND RETRIEVAL APPLICATIONS	60175700			01.60	

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
TER04- DISPLAY CODED CHARACTER ARITHMETIC ON THE 6000 SERIES	60190500			01.50	
TER05-THE GPL LANGUAGE	60192400			04.00	
TER07- CONVERSATIONAL APT	60222400			07.65	
TER08-COMPUTER SIMULATION-AN INTRODUCTION	60228300			01.70	
TER09- COMPUTERS AND PUBLIC CONCERN	60229700		3	02.90	
TER10-APT/EXPEDITE A CONVERSATIONAL APT SYS FOR THE 6000 COMPUTER WITH 210/211/212 DISPLAY STATION	60234400		3	04.65	
TER-12 PROGRAMMING TECHNICAL REPORT	60235300			01.30	
TER11- THE CHART? FLOWCHARTING PROGRAM	60234700		3	01.85	
TER14 FUNDAMENTALS OF BASIC TIME SHARING	60252300			01.00	
TER-15 - SIMPL-A SIMULATION PROGRAMMING LANGUAGE. AUTHOR M. MACDOUGALL	60252400			02.00	
TER-16 - PACKED DATA IN FORTRAN EXTENDED UNDER 6000 SCOPE 3.AUTHOR JOHN O. NEUHAUS	60252500			01.45	
TER-17 PROGRAMMING TECHNICAL REPORT	60305800			02.00	
MATHEMATICAL APPROXIMATIONS (TR52)	60070900			08.00	
MATRIX ALGEBRA,GAMMA FUNCTION,ERROR FUNCTION BESSEL FUNCTIONS(TR53)	60071000			02.50	
BINARY ERROR DETECTION BY GENERALIZED PARITY CHECKING (TR54)	60071100		22	02.75	
ARITHMETIC ERRORS AND SINE APPROXIMATIONS (TR56)	60071300			02.20	
LOGIC FOR COMPUTER DESIGNERS AND PROGRAMMERS PART 1 INTRODUCTION TO MATHEMATICAL LOGIC (TR57)	60071400			04.30	
CELLS-BASIC STRUCTURAL UNITS OF DESIGN(TR51)	60070800			02.00	
VIDEO LECTURE MANUALS					
VIDEO LECTURE (7600 FEATURES)	00006100			01.80	
VIDEO LECTURE SCOPE 3.1.6 TCS	00006000			05.35	
SCM PUBLICATIONS					
T-330 PROGRAMMING OPER MODE DIAGS,ALIGN PROC POWER SUPPLY SERVICE/INSTR MANUAL	60244400	A	22	10.75	
S-550 SERVICE MANUAL	60242900			04.05	
2816 POINT TO POINT PROGRAMMING MANUAL	60244200	A	22	03.00	
2816 POWER SUPPLY INSTRUCTION MANUAL	60242500	A	22	01.50	
2816 SERVICE MANUAL (ADDENDUM D)	60243000	A	22	05.00	
2816/7816 VERTIPUNCH INSTRUCTION MANUAL	60244600	A	22	04.60	
6615 SERVICE MANUAL	60242000	A	22	17.20	
6615-02 POWER SUPPLY MANUAL	60244300	A	22	02.00	
7816 POINT TO POINT PROGRAMMING MANUAL	60244100	A	22	02.10	
CONTROL UNIT INSTRUCTION MANUAL	60242300	A	22	05.95	
CONTROL UNIT PARTS MANUAL	60243600	B	22	05.20	
CONTROL UNIT SERVICE MANUAL	60243100	A	22	08.40	
CPI SERVICE AND INSTRUCTION MANUAL	60242800			05.00	
DATA PROCESSING PROGRAMMING COURSE	60248700		3	12.25	
I/O TO PUNCH TRANSLATOR SERVICE MANUAL	60243300			05.35	

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched in manual for use with hard cover ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
I/O UNIT PARTS MANUAL	60243400			03.60	
INPUT/OUTPUT INSTRUCTION MANUAL	60242100	A	22	03.60	
PROCESSOR INSTRUCTION MANUAL	60242400	A	22	10.00	
PROCESSOR POWER SUPPLY INSTRUCTION MANUAL	60242600	A	22	01.05	
PROCESSOR SERVICE MANUAL	60241900	A	22	06.50	
READER PARTS MANUAL	60243500	A	22	02.50	
TCR-30 PARTS MANUAL	60243800		22	02.65	
TCR-30 SERVICE AND INSTRUCTION MANUAL	60242700	A	22	08.30	
TOOL LIST	60244000	A	22	01.20	
TYPETRONIC 330 PARTS INFORMATION CE MANUAL	60244900	A	22	02.10	
TYPETRONIC 2816/7816 AUX. FEATURE CONTROL UNIT, PARTS INFORMATION CE MANUAL	60286400	A	22	01.50	
TYPETRONIC 2816/7816 MODEL 02 READER INSTRUCTION MANUAL	60242200	A	22	02.10	
TYPETRONIC 7816 PROCESSOR PARTS CE MANUAL	60244800	A	22	05.20	
TYPETRONIC VERTIPUNCH PARTS MANUAL	60240300		22	02.65	
VERTIPUNCH SERVICE MANUAL	60244500	C		02.50	
SCM (OEM) MANUALS					
024-026 INSTRUCTION MANUAL - IBM	60245300			03.60	
024-026 MAINTENANCE MANUAL - IBM	60245400			04.05	
024-026 PARTS MANUAL - IBM	60245500			03.60	
024-026 REFERENCE MANUAL - IBM	60245200			01.00	
CS100 PARTS CATALOG - BULL CE	60245100			03.00	
HARD COVER BINDERS AND TEMPLATES					
34-RING FOR 11 X 17 DIAGRAM MANUALS					
3/4 IN BINDER	60086900			02.85	
1 1/4 IN BINDER	60087000			04.05	
22-RING FOR 8 1/2 X 11 MANUALS					
3/4 IN BINDER - DARK BLUE W/CDC LOGO	60087200			01.85	
1 1/4 IN BINDER-DARK BLUE W/CDC LOGO	60087400			02.00	
3-RING FOR 8 1/2 X 11 MANUALS					
3/4 IN BINDER-DARK BLUE W/CDC LOGO	60086000			01.50	
1 1/2 IN BINDER - DARK BLUE W/CDC LOGO	60086100			02.30	
2 IN BINDER - DARK BLUE W/CDC LOGO	60087500			02.50	
CYBER 70 1 1/2 3 RING - BUTTERSCOTCH CDC	60088800			02.30	
1700 SERIES 1 1/4 3 RING- BROWN W/CDC LOGO	60088600			03.00	
3000 SERIES 1 1/4 3 RING- ORANGE W/CDC LOGO	60087600			03.00	
6000 SERIES 1 1/4 3 RING LIGHT BLUE W/CDC LOGO	60088500			03.00	
CYBERNET SERVICES-LIGHT BLUE 1 INCH 3 RING	60089100		3	04.00	
CYBERNET SERVICES-LIGHT BLUE 1 1/2 IN 3 RING	60089200		3		
CYBERNET SERVICES LIGHT BLUE 2 INCH 3 RING	60089300		3		
7000 SERIES 1 1/2 3 RING- BROWN W/CDC LOGO	60297200			02.10	

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched in manual for use with hard cover ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
6-RING 3/4 INCH CODE BOOK BINDER-YELLOW	60088700		6	01.70	
PROGRAMMING REPORT SUMMARY BINDER RUST PRESSBOARD 9 X 5 3/4 (METAL FASTENER)	00004600			00.50	
TEMPLATES					
FORM DESIGN AID (915 PAGE READER)	48402800			04.35	
LOGIC TEMPLATE	60085100			03.20	
LOGIC SYMBOLOGY TEMPLATE	62181600			09.25	
LOGIC DRAWING TEMPLATE	82269600			06.60	
PROGRAMMING TEMPLATE	10124300			01.50	
6600 LOGIC TEMPLATE	60113200			03.60	
MOTOR GENERATOR SETS					
CE MANUAL DES, INSTL, OPR, MAINT AND REF DWGS (ELECTRIC MACH FREQ CONV-SETS PRIOR TO SER 65-1582 EXCEPT SER 65-1557)	60156900	C	22	05.10	
CE MAN-DESC, INSTL, OPR, MAINT AND REF DWGS (ELECTRIC MACHINE FREQ CONV-SER 65-1557, 65-1582 AND ABOVE)	60166800	B	22	09.85	
CE DIAGRAMS MANUAL	60423100	A	22	16.05	
KATO MOTOR GENERATOR SETS (SERIALS 55972 AND ABOVE)					
GEN DESC, OPERATION, INSTALLATION/CHECKOUT, THEORY OF OPERATION, MAINT, PARTS CE MAN. DIAGRAMS MANUAL	60420800	A	22	08.30	
	60419900	A	22	10.20	
REFRIGERATION MANUALS					
TRANE RECIPROCATING REFRIGERATION MANUAL	60240200			09.00	
REFRIGERATION THEORY MAINTENANCE MANUAL	60268100	H	22	06.60	
REFRIGERATION UNITS CORDWOOD MODULES PARTS LIST	60227400	B	22	01.50	
** SEE ALSO GH214-A, GH216-A, GH218-A **					
POWER SUPPLY MANUALS					
AULT POWER SUPPLIES FOR CDC SYSTEMS	60107300	D	22	11.00	
CONTROL DATA POWER SUPPLIES APPLICABLE TO ACTIVE 6000/CYBER SERIES COMPUTING EQUIP. DIAGRAMS, THEORY OF OPERATION, MAINTENANCE AND PARTS DATA CE MANUAL	60427200	A	22	01.50	
CONTROL DATA POWER SUPPLIES APPLICABLE TO ACTIVE 3000 SERIES COMPUTING EQUIPMENT DIAGRAMS, THEORY OF OPERATION, MAINTENANCE AND PARTS DATA CE MANUAL	60427300	A	22	03.35	
CONTROL DATA POWER SUPPLIES APPLICABLE TO INACTIVE COMPUTING EQUIPMENT DIAGRAMS, THEORY OF OPERATION, MAINTENANCE AND PARTS DATA CE MANUAL	60427400	A	22	16.05	

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
DISK FILE HYDRAULIC	40869500	C	22	03.80	
DISK FILE HYDRAULIC POWER SUPPLY GH202-B06 CE MANUAL	41245600	D	22	02.35	
DISK FILE HYDRAULIC POWER SUPPLY CE MANUAL	70615700	B	22	04.30	
PRINTED CIRCUIT MANUALS					
1604 DISK FILE LOGIC MANUAL	40829700	G	22	17.70	
1604 SERIES LOGIC MODULES (TAPE TRANSPORT) OEM CF MANUAL	40827900	E	22	05.90	
CORDWOOD MANUAL VOLUMES 1,2,3	60042700	AY	22	10.00	
DISK STORAGE DRIVE (OEM) 1604 SERIES LOGIC MODULE CE MANUAL	40826700	J	22	07.15	
PRINTED CIRCUIT CARD MODIFICATION PROCEDURES (DRIFT TO MESA)	60041600	A	3	01.25	
VOLS. 1,2 AND 3 (1604 AND 3600 TYPES)	60042900	U	22	13.10	
INTERID CIRCUITS MANUAL	60201000	A	22	03.15	
SITE PREPARATION MANUALS					
SECTION 1 - GENERAL INFORMATION					
LARGE AND MEDIUM SCALE COMPUTER SYSTEMS INCLUDES INFO FOR 3000, 6000 AND 7000 SYSTEMS	60275100	C	22	01.40	
SMALL SCALE COMPUTER SYSTEMS - INCLUDES INFO FOR 160, 160-A, 1700, SC17 (1770), AND 8090 SYSTEMS	60275200	R	22	03.35	
MINI COMPUTER SYSTEMS	60437000	A	22	02.60	
SECTION 2 SITE PREPARATION AND INSTALLATION INFORMATION (SYSTEM DATA)					
CYBER 70 - MODELS 72/73/74 COMP. SYSTEMS AND CYBER 70 - MODEL 7030 SYSTEMS DATA	60277700	A	22	07.00	
CYBER 70 - MODEL 76 SYSTEMS DATA	60277600	C	22	02.55	
CYBER 170 - MODELS 172/173/174 SYSTEMS DATA	19981400	A	22	04.80	
CYBER 170 - MODEL 175 SYSTEMS DATA	60420100	A	22	03.80	
CYBER 1000 MODELS IMX, PMX, CMX SYS DATA	60418200	A	22	01.40	
MINT COMPUTER SYSTEMS	60437100	A	22	04.70	
SC1700 SYSTEMS DATA SITE PREPARATION MANUAL 732-XX, 733-10, 791-X, 7077-1 AND 7X54/844	60277000	C	22	01.30	
SYSTEMS DATA SITE PREPARATION MANUAL	60277500	A	22	01.95	
8090 SYSTEMS DATA SITE PREPARATION MANUAL	60275500	B	22	01.45	
1700 SYSTEMS DATA SITE PREPARATION MANUAL	60275600	D	22	01.60	
3170 SYSTEMS DATA SITE PREPARATION MANUAL	60277400	A	22	01.30	
3300 SYSTEMS DATA SITE PREPARATION MANUAL	60275900	A	22	01.05	
3500 SYSTEMS DATA SITE PREPARATION MANUAL	60276100	C-E	22	01.15	
6200 SYSTEMS DATA SITE PREPARATION MANUAL	60277300	A	22	01.30	
6400 SYSTEMS DATA SITE PREPARATION MANUAL	60276400	B	22	01.00	
6500 SYSTEMS DATA SITE PREPARATION MANUAL	60276500	R	22	01.00	
6600 SYSTEMS DATA SITE PREPARATION MANUAL	60276600	B	22	01.00	
6700 SYSTEMS DATA SITE PREPARATION MANUAL	60277100	A	22	01.10	
7611-11 SERVICE STATION - SYSTEMS DATA	60277200	A	22	03.25	
7700 SYSTEMS DATA SITE PREPARATION MANUAL	60277800	B	22	06.00	

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
90100 SYSTEMS DATA SITE PREPARATION MANUAL (INCLUDES PRODUCT SPECIFICATION)	60286800	A	22	02.00	
SECTION 3 PERIPHERAL EQUIPMENT DATA SITE PREPARATION MANUAL	60275300	06	22	02.40	
SECTION 3 MINI COMPUTER SYSTEMS	60437200	A	22	05.35	
VENDOR MANUALS					
BENDIX MTA-3 MAGNETIC TAPE ACCESSORY (DRS)	AET05611		3	05.55	
BENDIX PROGRAM PREPARATION ROUTINE TECH MAN	APT45910		3	03.75	
BRYANT DRUM SERVICE MANUAL	60194200				
CALCOMP - MODEL 565 PLOTTER INSTRUCTION MANUAL - (SPECIAL ORDER ITEM-60 DAY DELIVERY) CONTAINS DESC., INSTAL., THEORY OF OP., OPERATING INSTRUCTIONS, MAINTENANCE AND PARTS LIST. (JUNE 1969)	60148100			30.00	
DATA PRODUCTS 5024/818 DISC FILE REFERENCE (SPECIAL ORDER ITEM-VENDOR COST 47.00)	60095600				
DIGITRONICS - MODEL R3000 PERFORATED TAPE READER - CONTAINS INSTALLATION, OPERATION, THEORY OF OP., MAINTENANCE, SCHEMATICS AND WIRING DIAGRAMS	60143200		22	09.75	
DIGITRONICS - MODEL B6090 PERFORATED TAPE HANDLER - CONTAINS DESCRIPTION, INSTAL., OPERATION, THEORY OF OP, MAINT., AND SCHEMATICS	60143100		22	02.70	
GENERAL PRECISION 4440 HIGH SPEED PUNCH MAINTENANCE AND TRAINING	ESD10504		3	10.20	
TRM MODEL 31 MONITOR TYPEWRITER WITH SOROBAN MODIFICATION - REF/INSTRUCTION MANUAL INCLUDES DESCRIPTION, OPERATION, MAINT.	60008300	B	22	07.90	
TRM SELECTRIC SERIES 73 I/O TYPEWRITER REFERENCE MANUAL - INCLUDES MAINT., ADJUSTMENTS, REMOVAL INFO, TIMING CHARTS, WIRING DIAGRAMS, PARTS LIST	60095900	B	22	15.95	
TRM 1311 CE INSTRUCTION MANUAL	60142000			04.35	
TRM 1311 CE MAINTENANCE MANUAL	60152100			03.60	
TRM 1407 CONSOLE INQUIRY CE REFERENCE MANUAL	60142100		22	03.40	
PAPER TAPE PUNCH HANDLER (NCR) CE MANUAL	60297300	A		05.00	
NCR FM-P3 PAPER TAPE PUNCH	60295600	A	22	04.80	
NCR PUNCH MANUAL FM-P2 MX-1027-7	60143600			02.55	
SUPPLEMENT NO.1 TO C.D.C. PAPER TAPE PUNCH (NCR FM-31/B2) (ADDENDUM TO 60143600)	60211600			01.00	
NCR CARD FM-02 (PE) CE MANUAL (REV. 12/67)	60161300	B	22	05.05	
REMEX PAPER TAPE SPOOLER (MODEL RS0502ARB/ S2R) CE MANUAL	60207700	B	22	01.90	
STINGER BUSINESS MACHINES LINE PRINTER EQUIPMENT MODELS 53/54/55/56 FIELD SERVICE MANUAL VOL I	59708600	A01	3	02.50	
FIELD SERVICE MANUAL VOL II	59709000	B01	34	08.25	
REFERENCE MANUAL (TRAINING)	59708500	B	3	02.00	
PARTS MANUAL	59708700	D	3	11.45	

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
TALLY PAPER TAPE READER, REF INSTRUCTION	60116900			04.60	
TELETYPE 147624 BRPE PUNCH INSTALLATION	13796300	A		01.00	
TELETYPE PAPER TAPE PUNCH TECH MANUAL BRPE 11(BULLETIN 215B)	60095700			07.50	
TELETYPE PAPER TAPE PUNCH PARTS MANUAL (BRPE-11) (BULLETIN 1154B)	60095800			03.60	
TELETYPE PARTS MANUAL MODELS 32 AND 33 (BULLETIN 1184B)	60144200			05.25	
TELETYPE TECH MANUAL TAPE READER SET (BULLETIN 267B)	41608700			03.60	
TELEX 5403 TRAIN PRINTER DIAGRAMS, W/L CE MANUAL VOLS 1-3	50578700	B		15.30	
DIAGRAMS, W/L, PARTS DATA CL7A2 VOLS 1-3	50581200	B	22	10.65	
5416 TELEX PRINT CART GEN. DFSC., MAINT., THEO. OF OPER., CE MANUAL	50581500	C	22	01.20	
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)					
AMPEX CDFP-400 TAPE TRANSPORT	60017400				
AMPEX COTM-2 TAPE TRANSPORT	60017500	A			
LONG LINE TRANSMISSION FOR 1604 TYPE I/O CE MANUAL					
	60013600	A	22	01.40	
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)					
COMPUTER BUFFER CHANNEL LONG LINE DRIVERS	60123100	A	22	00.75	
COMPUTER NORMAL CHANNEL LONG LINE DRIVERS	60123200	A	22	00.75	
LONG LINE TRANSMISSION FOR 3000 PERIPHERAL CE MANUAL					
	60317100	A	22	04.50	
MISCELLANEOUS EQUIPMENT MODIFICATIONS (PRIOR TO STANDARD OPT, SPECIAL OPT AND QSE.)					
NCR COMPUTER VOL III DIAGRAMS MANUAL	60010200	A	24	04.60	
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)					
CONTROL MONITOR C-2539/GTC	60011400				
DATA SELECT UNIT	60021100				
DIGITAL DATA TERMINAL	60105300				
FADE IN DIAGRAMS	60012000				
FADE IN DIAGRAMS(SERIAL 2)	60012700				
THOMPSON-RAMO-WOOLDRIDGE CX/IX400 EXCH. UNIT	60107700				

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
160-A TEST CONSOLE DIAGRAMS	60103600				
162-A TAPE SYNCHRONIZER(PROTOTYPE DIAGRAMS)	60103800				
163-A MAGNETIC TAPE SYSTEM (WEBSTER)	60008600				
164-A TAPE SIGNAL CONDITIONER	60025400				
924-B (SERIAL 3) 77 PASS DIAGRAMS	60109500				
924-B (SERIAL 9) BREAKPOINT SWITCH MOD	60102900				
924-B ITEK MODIFICATION	60109600				
1619X MAGNETIC DISK FILE CONTROLLER DIAG(AIL	60110300				
QSF					
PUBLICATIONS FOR QSF#S ARE NOT STOCKED.THEY ARE AVAILBLE IN OZALID FORM ONLY. WHEN ORDERING,FURNISH QSE NUMBER AND DESCRIPTION AND ALL AVAILABLE INFO WTLL BE SENT.					
STANDARD OPTIONS					
(NOTE 1. INFO FOR THIS OPTTON IS INCLUDED IN BASIC MANUALS FOR RESPECTIVE PRODUCT. SEE INDIVIDUAL EQUIPMENT LISTING)					
955 SEQUENTIAL NUMBERING DEVICE OPTION GEN DESC., THEORY OF OPER., DIAGRAMS AND PARTS DATA CE MANUAL	91503500	A	3	03.75	
10001 EIGHT 603 ON 162-1(MAPE 101)	60115800				
10003 1604-B MODIFICATION DIAGRAMS(SEE NOTE1					
10005 160-A INTERFACE FOR 3206 REFERENCE/ INSTRUCTION (MAPE 223)-SEE NOTE 1					
10006 924/924-A CORE STOR CONVERS 8K TO 16K SEE NOTE 1					
10007 924/924-A CORE STOR CONVERS 16K TO 32K (SEE NOTE 1)					
10008 924/924-A CORE STOR CONVERS 8K TO 32K (SEE NOTE 1)					
10009 1604A/P/C CORE STORAGE CONVERSION 16K TO 32K (SEE NOTE 1)					
10010-A LONG LINE DRIVER	60317100	A	22	04.50	
10012 SPECIAL 501 PRINT DRUM(SLOTTED OH)(SEE NOTE 1)					
10013 3200 CONSOLE FOR 3100 (SEE NOTE 1)					
10015 DUAL MOTOR/GENERATOR SET (NO PUBL NEED OR AVAILABLE FOR THIS OPTION)					
10040-10043 (INFO AVAILABLE IN 1700 DIAGRAMS MANUAL-60152700)					
10098-A SPEED IMPROVEMENT REF/CE MANUAL REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CE INFO (SEE 3304-A OR 3304-B)	60199800	D	22	02.90	
10103-A CEJ/MEJ FOR 6400/6500 COMPUTERS CE MANUAL	60202100	D	22	01.65	
REF INFO (USE 6000 REFERENCE MANUAL)					
10104-A/B/C/D CENTRAL AND MONITOR EXCHANGE JUMPS FOR 6600 DESC,OPER,PROG,REF MANUAL	60203200	D	22	01.00	

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
10104-C/D (CE INFO - USE 6613-D CENTRAL MEMORY CE MANUAL - 60246600)					
10115-A REFERENCE MANUAL	60180200	A	22	02.25	
10121 (AT105-A) ACCESS CHANNEL REF INFO (USE 3500 REF MANUAL)					
10123 (AT106-A, AT115-A) MEMORY PROTECT REF/CE INFO (USE AT106-A)					
10124-A 6603 DISK SPEED INCREASE REFERENCE/CE MANUAL	60227500	A	22	01.65	
10126 (GA103-A/B/C, GA104-A/B) TIME BASE SOURCE REFERENCE MANUAL	41600900	B	22	01.50	
10127 (DK502-A) EXPANDED MEMORY OPTION REF INFO (USE 3316-1 REFERENCE MAN.)					
10128 (DK501-A) DUAL MODE OPTION REFERENCE MANUAL	41603000	A	22	01.00	
10169 CENTRAL MEMORY ACCESS PRIORITY FOR 6400/6500-A/B/C CENTRAL COMP. (USE AT129-A 6600 SERIALS 1-47 CENT. COMP. (USE AT131-A 6400/6500/6600-D CENT. COMP. (USE AT130-A)					
10177-1 16K MEMORY INCREMENT FOR 6415-A/B/C COMPUTER SYSTEM (USE AT142-F) 6415-D COMPUTER SYSTEM (USE AT142-G) AA108-A COMPUTER SYSTEM (USE AT142-B)					
10178-1 32K MEMORY INCREMENT FOR 6414/6514-A/B/C COMPUTER SYS (USE AT140-F) 6414/6514-D COMPUTER SYSTEM (USE AT140-H) AA105-A COMPUTER SYSTEM (USE AT140-B)					
10179-1 16K MEMORY INCREMENT FOR 6615-D COMPUTER SYSTEM (USE RR365-B)					
10180-1 32K MEMORY INCREMENT FOR 6614-A/B/C COMPUTER SYSTEM (USE AT168-G) 6614-D COMPUTER SYSTEM (USE AT168-J) AA103-A COMPUTER SYSTEM (USE AT168-B)					
10194-1 (FV150-A) INTERNAL BCD TO ASCII HOLLERITH CONVERSION KIT FOR THE 3446-A/B CARD PUNCH CONTROLLER REF INFO (USE 3446-A/B REF MANUAL) CE INFO (USE FV150-A)					
10194-2 (FV149-A) ASCII HOLLERITH TO BCD CONVERSION KIT FOR THE 3447-B CARD READER CONTROLLER REF INFO (USE 3248-A REF MANUAL) CE INFO (USE FV149-A)					
10256-1 (AF101-B, AF104-A) 3200 BDP OPTION REFERENCE MANUAL	60347700	B	22	09.75	
10256-1 AND 10287-3 OR 10289-1 AND 10256-3 REFERENCE MANUAL CE INFO (USE AT146-A)	97402600	A	22		
10256-2 (AF101-B, AF104-B) 3100 BDP INTERFACE OPTION REFERENCE MANUAL	97401800	A	22	01.20	
10256-2 AND 10287-4 OR 10287-2 AND 10256-4					

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
REFERENCE MANUAL CE INFO (USE AF107-A) 10285-1 () DUAL CHANNEL SWITCH OPTION GENERAL INFO (USE 7054-1) OPERATION AND PROGRAMMING (USE 7054-1)	97402200	A	22	03.85	
10287-1 (AF105-A, BT193-A, CD124-A) 3200 ENHANCED BLOCK CONTROL OPTION REFERENCE MANUAL	97402400	A	22	03.60	
10287-2 (3106-A/B, AF106-A, CD124-A) 3100 ENHANCED BLOCK CONTROL OPTION REFERENCE MANUAL	97402000	A	22	01.80	
10293-1/2 (DT194-A, DT196-A) CHANNEL MODIFICATION REF/CF MANUAL	60406300	A	22	17.00	
10308-2 (AT292-A, AT293-A) GO MODE/SDL 10309-1 (AT289-A, AT294-A) GO MODE/SDL-AC104 10309-2 (AT289-A, AT295-A) GO MODE/SDL-AC106					
10336-1 (1784) REAL TIME CLOCK REF MANUAL	89638800	01	22	01.65	
10339-1 (FA103-A) MASS STORAGE CONTROLLER REF INFO (USE 7639-1)					
10348-1 (AT311-A) DATA CHANNEL CE INFO (USE AA106-A) REF INFO (USE CYBER 76 REF MANUAL PUBLICATION NO. 60367200)					
10348-2 (AT312-A) DATA CHANNEL CE INFO (USE AA106-A) REF INFO (USE CYBER 76 REF MANUAL PUBLICATION NO. 60367200)					
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)					
10078-A 3306 TO 160/160-A INTERFACE REF/CE	60166500	A	22		
SPECIAL OPTIONS					
60002-A 161-S TYPEWRITER UNIT MANUAL MAPE105	60041500				
60006-A 924 SPEED IMPRV.PKG (MAPE 245)	60102200				
60006-A 924-A SPEED IMPROV PKG(MAPE 245)	60102700				
60007 3637 DPUM CONTROLLER CE DIAGRAMS	60184600				
60008-A 8090 POWER FAILURE INTERRUPT(MAPE345	60120400				
60009-A 3256 ERROR CHECKING REF/DIAGRAMS MAN	60122800				
60009-A 3256 LINE PRINTER ECHO CHECK C/P-E/S	60142300				
60014-A 165-2 REFERENCE/INSTP(MAPE 112)	60113300			02.70	
60014/15-A (MAPE 111/114) CE DIAGRAMS	60097200		34	03.00	
60015-A 165-2 REFERENCE/INSTR(MAPE 113)	60113300			02.70	
60016-A 160/160-A EXCHANGE UNIT REF. MANUAL	36812800		22	02.70	
60016-A 160/160-A CARD PL AND EQ SUMMARY	36812900				
60017-A 603/604/606/607 CHAN SWITCH CONSOLE	60105200				
60018-A 603/604/606/607 CHAN SWITCH CONSOLE	60105200				
60022 DATA CHANNEL CONVERTER					

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
CE MANUAL	60390200				
60026 REFERENCE/CE MANUAL	38705100	D	22	04.40	
60028-A/B/C/D/E REFERENCE MANUAL	60333700	A	22	01.20	
CE MANUAL	60390300	A		22	
60029 405 CARD READER CONTROLLER REF MANUAL	60333800	A	22	01.00	
CE MANUAL	60390400	A	22		
60031 (CE601-A, CE602-A) 45 COLUMN CARD READ MODIFICATION					
60032-A 3604 DIAGRAMS PAGE 186	60042100	AT	34	08.45	
60064-A REFERENCE/CE MANUAL	60201300			03.10	
60076 CE MANUAL (2321 DATA CELL ADAPTOR FOR 3234 MASS STORAGE SUBSYSTEM)	60197400			06.45	
60118 MAGNETIC TAPE TRANSPORT MAINT, DIAGS.	41240200	B	22	01.45	
60126 3000/7000 DATA CHANNEL ADAPTER	60296900	A	22	08.40	
65005 DATA SET ADAPTER MODULE TESTER REF/ CE MANUAL	41607700	D	22	04.10	
65006 (GK111-A) TAPE EXERCISER SPECIAL OPTION 68091 INTRO. OPER. PROG. INSTL. CHKOUT., PRINCIPLES OF OPER., MAINT. DIAGS, W/L EQ SUM. PARTS DATA CE MANUAL	44977000	C	22	02.90	
65075 (DC401-A) MASS STORAGE EXTENDER					
65102 () BUS PARITY CHECKING CE INFO (USE AT281-A IN SECTION 1)					
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)					
60013-A 3200 STORAGE MOD CONNECTOR(MAPE 298)	35076500				
60016-B MAINTENANCE SUPPLEMENT	60196100				
60022 DATA CHANNEL CONVERTER 170 MODIFICATION REFERENCE MANUAL	60334700	A			
1612 MODIFICATION REFERENCE MANUAL	60334800	A			
60028-A/B/C/D/E CE MANUAL	60390300	A			
60029 405 CARD READER CONTROLLER CE MANUAL	60390400	A			
60032-A 3604-A/B BILLABLE TIME METER SUPPL	17632300				
CYBERNET PUBLICATIONS					
6400 KRONOS LIBRARY PROGRAMS	86605900	D	3	07.90	
6000 CYBERNET SCOPE 3.3 REFERENCE MANUAL	86618000		3	07.15	
6600 SCOPE 3.3 LIBRARY ROUTINES	86607700	A	3	01.00	
ADLPIPE-STATIC-THERMAL-DYNAMIC PIPE STRESS ANALYSIS USER INFORMATION MANUAL	86602800	B	3	02.00	
AID 6600 LEARNERS GUIDE SURVEY ANALYSIS WITH QA-PAK-CYBERNET SERVICES	86601800		3	01.50	
ANSYS EXAMPLES MANUAL	76070900		3	10.50	
ANSYS INTRODUCTORY MANUAL	84000900		3	01.50	
ANSYS USER INFORMATION MANUAL	86616800	C	3	15.30	
APT CYBERNET USER INFORMATION MANUAL	84000500	A	3	02.00	

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
APTURNS USER INFORMATION MANUAL	84002100		3	05.00	
ATHENA - ON-LINE INTERACTIVE RETRIEVAL/ UPDATE LANGUAGE U.I.M.	76071400	A	3	02.50	
AUTOFLEX USER INFORMATION MANUAL	84000800		3	04.90	
AVAS USER INFORMATION MANUAL	00015100	A	3	01.50	
BRIDGE ANALYSIS AND RATING SYSTEM MANUAL	86618500		3	07.50	
CYBERNET SERVICES PROGRAM LIBRARY CATALOG	86616900	A	3	02.00	
CC-TEGAS3 - TEST GENERATION AND SIMULATION SYSTEM USER INFORMATION MANUAL	76070700	A	3	05.00	
CELS USER INFORMATION MANUAL	86612300	B	3	07.15	
CELS PROGRAM ABSTRACTS	86612500		3	01.00	
CENSTAT-CENSUS STATISTICS-GENERAL INFORMATION MANUAL	86603700		3	01.00	
CENSTAT TEMPLATE	86613500			00.50	
CIVCO USER INFORMATION MANUAL	86603000	B	3	04.00	
CONPOL 2000 DEMONSTRATION SCRIPT	84003700		3	01.00	
CRYSPEAK-CRYSTALLOGRAPHY PACKAGE USER INFO	86605600	A	3	04.50	
CYBER 70/MODEL 76 TERMINAL USERS GUIDE	76072700		3	01.00	
CYBERLOAN GENERAL INFORMATION MANUAL	86616100	A	3	02.25	
CYBERNET/KRONOS 2.0 TO 2.1 CONVERSION GUIDE	84002600		3	02.00	
CYBERNET/KRONOS 2.1 BASIC PROGRAMMING LANGUAGE REFERENCE MANUAL	84001900	A	3	03.00	
CYBERNET/KRONOS 2.1 BATCH AND REMOTE BATCH REFERENCE MANUAL	84000600		3	10.90	
CYBERNET/KRONOS 2.1 TIME-SHARING FORTRAN REFERENCE MANUAL	84001700	B	3	03.00	
CYBERNET/KRONOS COMPILER SUBROUTINE AND SYSTEM UTILITY SUPPLEMENT	84002000	A	3	01.50	
CYBERNET/KRONOS PROCEDURE FILES REFERENCE	84001000	A	3	03.00	
CYBERNET/KRONOS TIME-SHARING USERS REFERENCE	84001800		3	03.00	
CYBERNET/PROSE CALCULUS OPERATIONS MANUAL	84003200	A	3	03.50	
CYBERNET/PROSE DEBUGGING OPERATIONS MANUAL	84003100		3	01.00	
CYBERNET/PROSE PROCEDURAL OPERATIONS MANUAL	84003000	A	3	02.00	
CYBERNET/PROSE SYSTEM GUIDE	84002900	A	3	02.20	
DCO/TRANPLAN USER INFORMATION MANUAL	86615700		3	09.00	
DD-PLOT USER INFORMATION MANUAL	86618400		3	02.50	
DECIDER USER INFORMATION MANUAL	86602900	A	3	01.00	
DISSPLA BEGINNERS USER INFORMATION MANUAL	84001200		3	03.50	
DISSPLA CYBERNET SUPPLEMENT	84001400		3	01.00	
DISSPLA INTERMEDIATE USER INFORMATION MANUAL	84001300		3	03.00	
DISSPLA ADVANCED USER INFORMATION MANUAL	84001500		3	06.40	
EAC/EASE-ELASTIC ANALYSIS FOR STRUCTURAL ENGINEERING-GENERAL INFORMATION MANUAL	86603100	A	3	01.00	
EAC/EASE-ELASTIC ANALYSIS FOR STRUCTURAL ENGINEERING-USER INFORMATION MANUAL	86603200	B	3	02.00	
EAC/EASE-ELASTIC ANALYSIS FOR STRUCTURAL ENGINEERING-DATA CARD DIGEST	86603300	A	3	01.00	
EAC/EASE-2 USER INFORMATION/THEORETICAL MAN	84002700	A	3	03.50	
E/CUBE ENERGY ANALYSIS CYBERNET SERVICE GUIDELINES	86608900	C	3	01.00	
EASE ADDENDUM A-ENGINEERING APPLICATIONS AND PROBLEM SOLUTIONS	86607100		3	02.35	
EASE ADDENDUM B - THEORETICAL REFERENCES	86607200		3	03.90	

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
ELECTRICAL ENGINEERING APPLICATION GUIDE	86619700		3	01.00	
FAAST USER INFORMATION MANUAL	84009800		3	02.50	
FASTIME/LOADFLOW POWER SYSTEM ANALYSIS U.I.M	76071200		3	03.40	
FINITE ELEMENT LEARNERS GUIDE	86616600		3	01.00	
GENERAL ACCOUNTING APPLICATIONS APRIL MINI-MANUAL	86613800			01.35	
GENERAL ACCOUNTING APPLICATIONS GENERAL LEDGER SYSTEMS MINI-MANUAL	86613600			01.35	
GENERAL ACCOUNTING APPLICATIONS PAYROLL MINI-MANUAL	86613700			01.35	
GENERAL PURPOSE SIMULATION SYSTEM GIM	84003900	A	3	02.00	
GENSAP USER INFORMATION MANUAL	86619900	B	3	02.00	
GINA-GENERATE INPUT FOR CDC/NASTRAN UIM	84006700		3	01.00	
IFMS-INTERACTIVE FINANCIAL MODELING SYST.UIM	76070400		3	01.00	
INIS-INTERACTIVE INTERFACE TO SCOPE USERS GUIDE	84002800		3	01.00	
KRONOS TIME-SHARING TUTORIAL MANUAL	86615800	C	3	04.50	
LOADFLOW-POWER SYSTEM PLANNING PROGRAM USER INFORMATION MANUAL	86604600		3	02.00	
MAGEN 6000 USER INFORMATION MANUAL	86604700	A	3	02.00	
MARC I SHADOW/SHADE TERMINAL USERS GUIDE	86607800	A	3	09.50	
MARC II SHADOW/SHADE TERMINAL USERS GUIDE	86607900		3	09.50	
MARC II TERMINAL-EXPORT/IMPORT TERMINAL USER GUIDE OPERATING SYSTEM REFERENCE LIBRARY	86606100	A	3	01.50	
MARC-CDC USER INFORMATION MANUAL VOL 1	17309500	F	3	05.50	
MARC-CDC USER INFORMATION MANUAL VOL II PROGRAM INPUT	17311600	E	3	05.50	
MARC-CDC USER INFORMATION MANUAL VOL III DEMONSTRATION PROBLEMS	17311700	F	3	05.50	
MARS VI REFERENCE MANUAL	76070100		3	04.50	
MATH PROGRAM GENERAL INFORMATION-CYBERNET SERVICES	86614100		3	01.00	
MATH SCIENCE LIBRARY CYBERNET USER GUIDE	86612100		3	01.00	
MEDISHARP GENERAL INFORMATION MANUAL	39771300	A	3	01.50	
MEDISHARP PATIENT ACCOUNTING	86618900		3	03.50	
MTIAS USER INFORMATION MANUAL	86615000	A	3	07.50	
MRI/STARDYNE-FINITE ELEMENT DEMONSTRATION PROBLEMS	84002500		3	01.00	
MRI/STARDYNE-DYNAMIC STRUCTURAL ANALYSIS SYSTEM-USER INFORMATION MANUAL	86603500	D	3	08.65	
MRI/STARDYNE THEORETICAL MANUAL	86616300	A	3	09.75	
NAR/SYSCAP-SYSTEM OF CIRCUIT ANALYSIS PROGRAMS-(DOMESTIC) SOLD IN SETS ONLY	86602000			14.00	
NAR/SYSCAP-SYSTEM OF CIRCUIT ANALYSIS PROGRAMS-(INTERNATIONAL)SOLD IN SETS ONLY	86602300		3	13.80	
NASTRAN APPLICATIONS MANUAL - FRONT MATTER	86616700	K	3	11.10	
NASTRAN-NASA STRUCTURAL ANALYSIS BASIC TRAINING MANUAL	86612600	A	3	02.00	
NASTRAN-GENERAL INFORMATION MANUAL	86614300	A	3	01.00	
NASTRAN-TECHNICAL ARTICLES	86619600		3	01.00	
NETFLOW II-NETWORK FLOW ROUTINE U.I.M.	86604900		3	02.75	
QQ/LP-RAPID LINEAR PROGRAMMING SYSTEM USER INFORMATION MANUAL	86604800		3	01.00	

- 1.Publication number of literature
- 2.The latest revision level
- 3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

- 4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
PDS/MAGEN - A GENERAL PURPOSE PROBLEM DESCRIPTOR SYSTEM UIM	84009900	A	3	02.50	
PERSONNEL DEMO SCRIPT	84003800		3	01.00	
PIPEFLEX USER MANUAL SUPP. CYBERNET SERVICE	86615100		3	01.00	
PMCS USER INFORMATION MANUAL	86615500	D	3	04.00	
PPS IV PROJECT PLANNING SYSTEM GENERAL INFORMATION MANUAL	86608400		3	01.00	
PPS IV PROJECT PLANNING SYSTEM USER INFORMATION MANUAL	86608500	A	3	03.00	
PIPEFLEX-PIPING FLEXIBILITY ANALYSIS-USER INFORMATION MANUAL	86614200		3	01.00	
PIPFSD-CYBERNET USER INFORMATION MANUAL	84000100	A	3	04.00	
PRICE SCHEDULE FOR CYBERNET SERVICE (FOR CDC USE ONLY)	86608000	C	3	01.00	
PISCES IDL MANUAL A USER INFORMATION MANUAL	86617100	B	3	01.00	
PISCES IDL MANUAL B USER INFORMATION MANUAL	86617200	A	3	03.50	
PISCES IDL MANUAL C USER INFORMATION MANUAL	86617300	B	3	01.50	
PISCES IDL MANUAL D USER INFORMATION MANUAL	86617400	A	3	01.00	
PISCES 2DL MANUAL A USER INFORMATION MANUAL	86617500	A	3	01.00	
PISCES 2DL MANUAL B USER INFORMATION MANUAL	86617600	A	3	03.50	
PISCES 2DL MANUAL C USER INFORMATION MANUAL	86617700	B	3	01.50	
PISCES GEOMETRIC RATIOS USER INFORMATION MAN	86617900		3	02.50	
PI/PLOT-USER INFORMATION MANUAL	86618300		3	01.00	
PLOT 10 TERMINAL CONTROL SYSTEM USER INFO	84002400		3	02.00	
A PRIMER TO QUESTAIRE AND MARKETING RESEARCH DATA PROCESSING TECHNIQUES	86607500	A	3	01.00	
QUESTIONNAIRE ANALYSIS PACKAGE-COMPTRAN LEARNERS GUIDE	86601700		3	01.00	
QUESTIONNAIRE ANALYSIS-MARGINAL LEARNERS GUIDE	86601600		3	01.00	
QUESTIONNAIRE ANALYSIS PACKAGE-GENERAL INFORMATION MANUAL	86604300	A	3	01.00	
QUESTAIRE II GENERAL INFORMATION MANUAL	86604100	A	3	01.00	
QUESTAIRE II USERS INFORMATION MANUAL	86604200	C	3	03.00	
RISK ANALYSIS USERS INFORMATION MANUAL	86604000	A	3	03.15	
SCOPE VERSION 3.3 TO VERSION 3.4 CONVERSION AIDS	84000700		3	01.50	
SCPLOT USER INFORMATION MANUAL	84000000		3	01.00	
SIMULATORS-1130 (II) SIMULATION OF A MARC II TERMINAL-F/I 200 TERMINAL USER GUIDE	86606200	A	3	03.10	
SPECIAL ADDENDUM FOR EASE (ELASTIC ANALYSIS FOR STRUCTURAL ENGINEERING)	86607000		3	01.00	
SPSS/ON LINE KRONOS VER2.1 U.T.M.	84009600		3	01.00	
SYSCAP TUTORIAL INTRODUCTION GUIDE TO BEGINNER USERS	84000400		3	06.00	
SYSCAP II-SYSTEMS OF CIRCUIT ANALYSIS PROGRAMS USER INFORMATION MANUAL	76070600		3	07.15	
SYSTEM 2000 LEVEL 2 - A MULTI-PURPOSE DATA MANAGEMENT SYSTEM					
DIAGNOSTIC MESSAGE SUPPLEMENT	76074300		3	01.50	
FORTAN PROCEDURAL LANGUAGE SUPPLEMENT	76074600		3	02.00	
IMMEDIATE ACCESS FEATURE SUPPLEMENT	76074400		3	02.00	
REPORT WRITER FEATURE SUPPLEMENT	76074700		3	02.00	

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
USER INFORMATION MANUAL	76074000		3	04.00	
TESS USER INFORMATION MANUAL	86615900		3	05.00	
TESS GENERAL INFORMATION MANUAL	86618200		3	01.00	
TESS-TTY USER INFORMATION MANUAL	84001100		3	01.00	
TOTAL-CDC REFERENCE MANUAL	76070300		3	03.50	
XEDIT - EXTENDED KRONOS TEXT EDITOR U.I.M.	76071000		3	01.50	

STRU-PAK - STRUCTURAL ANALYSIS PACKAGE					
MASTER INSTRUCTION GUIDE	86608600	C	3	01.00	
PROGRAM ABSTRACTS	86608700	B	3	01.00	
** USER INFORMATION MANUALS					
CENSECT - PLANAR SECTION PROPERTIES OF ARBITRARY CROSS SECTIONS	86609000		3	01.00	
STANSECTP - PLANAR SECTION PROPERTIES OF STANDARD CROSS SECTIONS	86609100		3	01.00	
BEAMCOL - BENDING ANALYSIS OF VARIABLE CROSS-SECTION BEAM COLUMNS	86609200	A	3	01.00	
STANBEAM - BENDING ANALYSIS OF VARIABLE CROSS-SECTION BEAMS	86609400	A	3	01.00	
MULTISPAN - BENDING ANALYSIS OF MULTISPAN BEAMS	86609500		3	01.00	
ELASTCOL - ELASTIC STABILITY OF END LOADED COLUMNS	86609300	A	3	01.00	
INRING - ELASTIC ANALYSIS OF RINGS WITH INPLANE LOADS	86609600	A	3	01.00	
OUTRING - ELASTIC ANALYSIS OF RINGS WITH OUT-OF-PLANE LOADS	86609700		3	01.00	
2DGENFRAME - TWO-DIMENSIONAL GENERAL FRAME ANALYSIS PROGRAM	86609800	B	3	01.00	
2DFSAP-TWO-DIMENSIONAL STRUCTURAL ANALYSIS PROGRAM	86609900	B	3	01.00	
3DFSAP-THREE-DIMENSIONAL STRUCTURAL ANALYSIS PROGRAM	86610000	B	3	01.00	
GRIDSAP - GRID STRUCTURAL ANALYSIS PROGRAM	86610100	A	3	01.00	
2DTSAP - TWO-DIMENSIONAL TRUSS STRUCTURAL ANALYSIS PROGRAM	86610200	B	3	01.00	
3DTSAP -THREE-DIMENSIONAL TRUSS STRUCTURAL ANALYSIS PROGRAM	86610300	B	3	01.00	
CIRCPLAT - BENDING ANALYSIS OF CIRCULAR PLATES	86610400	A	3	01.00	
HUBFLAGI - DESIGN AND ANALYSIS OF BOLTED FLANGE CONNECTIONS-INTEGRAL TYPE	86610500		3	01.00	
STIFSHLL - BUCKLING OF ORTHOTROPIC SHELLS	86610600		3	01.00	
CRITSPEED - CRITICAL SPEEDS ANALYSIS OF ROTATING SHAFTS	86610700		3	01.00	
2DFMAP - TWO-DIMENSIONAL FRAME MODAL ANALYSIS PROGRAM	86610800	B	3	01.00	
3DFMAP - THREE DIMENSIONAL FRAME MODAL ANALYSIS PROGRAM	86610900	C	3	01.00	
GRIDMAP - GRID MODAL ANALYSIS PROGRAM	86611000	A	3	01.00	

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
2DTMAP - TWO-DIMENSIONAL TRUSS MODAL ANALYSIS PROGRAM	86611100	B	3	01.00	
3DTMAP - THREE-DIMENSIONAL TRUSS MODAL ANALYSIS PROGRAM	86611200	B	3	01.00	
DYNPOSS - DYNAMIC RESPONSE OF SIMPLE SYSTEMS	86611300		3	01.00	
SHOCSPEC - SHOCK SPECTRA ANALYSIS OF A SINGLE-DEGREE-OF-FREEDOM SYSTEM	86611400	A	3	01.00	
SINSPONS - SINUSOIDAL RESPONSE OF A MULTI-DEGREE-OF-FREEDOM SYSTEM	86611500	A	3	01.00	
BELSPRING - DESIGN AND ANALYSIS OF BELLEVILLE SPRINGS	86611600	A	3	01.00	
COMSPRING - DESIGN AND ANALYSIS OF HELICAL COMPRESSION SPRINGS	86611700		3	01.00	
TESTRAIN - STRAIN GAGE DATA REDUCTION AND ANALYSIS	86611800		3	01.00	
TORCELL - TORSIONAL ANALYSIS OF SINGLE CELLAR MULTICELLULAR SECTIONS	86611900		3	01.00	
COMPLETE STRU-PAK COLLECTION WITH BINDER AND TABS	86612000		3	21.75	
STRU-PAK PROCESSING COSTS MANUAL	86614000		3	01.00	
SYSTEM 2000 (LEVEL II) MINI-MANUAL	86615600	B		01.35	
TRANPLAN II GENERAL INFORMATION MANUAL	86614400		3	02.50	
S-RAY 70-X-RAY SYSTEM OF CRYSTALLOGRAPHIC PROGRAMS USER INFORMATION PROGRAM	86605700		3	04.65	
ZIPTRAN USER INFORMATION MANUAL	86614600		3	03.25	
LIBRARY OF MATH SUBPROGRAMS - USER INFORMATION MANUAL	86614900	A	3	02.00	

SYSTEMS PROFESSIONAL PACKAGE					
COMPLETE SYSTEMS PROFESSIONAL PACKAGE (INCLUDING BINDER AND TABS)	84006800		3	27.65	
*** USERS GUIDES					
SYSTEMS PROFESSIONAL MASTER USER INFORMATION AND OPERATIONAL INSTRUCTIONS USERS GUIDE	84006900		3	01.00	
CONCRETE COLUMN ULTIMATE STRENGTH DESIGN	84007000		3	01.00	
NON-PRISMATIC CONTINUOUS BEAM DESIGN SERIES	84007100		3	02.50	
RETAINING WALL DESIGN WORKING STRENGTH	84007200		3	01.00	
PRISMATIC CONTINUOUS BEAM DESIGN SERIES	84007300		3	03.00	
PRESTRESSED CONCRETE BEAM DESIGN SERIES	84007400		3	01.00	
FLAT PLATE AND FRAME ANALYSIS AND DESIGN	84007500		3	01.50	
FOOTING DESIGN SERIES-RECTANGULAR OR COMBINED FOOTING DESIGN	84007600		3	01.00	
STEEL COLUMN INVESTIGATION AND DESIGN	84007700		3	01.00	
STEEL BEAM INVESTIGATION AND DESIGN SERIES	84007800		3	01.00	
COMPOSITE STEEL BEAM INVESTIGATION AND D.S.	84007900		3	01.00	
COLUMN BASE PLATE DESIGN	84008000		3	01.00	
WELDED STEEL GIRDER INVESTIGATION AND DESIGN	84008100		3	01.00	
MASONRY, BLOCK OR CONCRETE SHEAR WALL AND PEIR DESIGN	84008200		3	01.00	

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
MASONRY, BLOCK OR CONCRETE BEARING WALL DESIGN	84008300		3	01.00	
SAWN TIMBER BEAM DESIGN	84008400		3	01.00	
GLU-LAM TIMBER BEAM DESIGN	84008500		3	01.00	
REGULAR RIGID FRAME ANALYSIS	84008600		3	01.00	
SHEAR WALL-FRAME INTERACTION ANALYSIS	84008700		3	01.00	
MULTI-STORY COLUMN LOAD TAKE-OFF TABULATION	84008800		3	01.00	
SPSTRESS-GENERAL STRUCTURAL SYSTEMS ANALYSIS	84008900		3	02.00	
SIMPLE SPAN BEAM ANALYSIS OPTIONAL CANTILEVR	84009000		3	01.00	
MULTI-STORY WIND OR EARTHQUAKE ROTATIONAL ANALYSIS	84009100		3	02.00	
SMALL RIGID FRAME ANALYSIS	84009200		3	01.00	
DETERMINE TRUSS ANALYSIS	84009300		3	01.00	
THE TWO ITEMS BELOW ARE NOT INCLUDED IN THE COMPLETE PACKAGE AND MUST BE ORDERED SPTLY					
MODIFIED PCA FLAT PLATE, FLAT SLAB, WAFFLE SLAB AND FRAME ANALYSIS AND DESIGN USERS GD	84009400		3	01.50	
SYSTEMS PROFESSIONAL PROGRAMS COST GUIDE USER COST GUIDE	76070800		3	01.00	

LEAHS PRODUCT DESCRIPTION MANUALS					
LEAHS PHASE III OVERVIEW	84004300		3	01.00	
PWR SEQUENCE OVERVIEW	84004000		3	01.00	
BWR SEQUENCE OVERVIEW	84004200		3	01.00	
PWR BENCHMARKING	84005800		3	01.00	
LEAHS INDIVIDUAL CODE MANUALS					
CHEETAH-P	84004100		3	03.00	
NAHYDRO-B	84004400		3	01.00	
NAHYDRO-P	84004500		3	01.00	
FIT	84004600		3	01.00	
SHUFFLE	84004700		3	03.25	
INTREGAL	84004800		3	02.00	
EDIT-C	84004900		3	01.00	
EXPAND	84005000		3	01.00	
PUNCHER-P	84005100		3	01.00	
POO7LEAHS	84005200		3	03.35	
MODEL	84005300		3	01.00	
COPC-BLADE	84005400		3	01.00	
NAILASER	84005500		3	01.00	
COPC-PIN	84005600		3	01.00	
NAI3D-P	84005700		3	02.00	
PUNCHER-B	84005900		3	01.00	
PPFFIT	84006000		3	01.00	
CHEETAH-B	84006200		3	01.00	
NAI3D-B	84006300		3	01.50	

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
***** CYBERNET SERVICES BINDERS 1 INCH,3 RING,CYBERNET,LIGHT BLUE BINDER 1 1/2 INCH,3 RING,CYBERNET,LIGHT BLUE BINDER 2 INCH,3 RING,CYBERNET,LIGHT BLUE BINDER 4 INCH,NYLON POST,RED,SYSTEMS PROFESSIONAL BINDER	60089100 60089200 60089300 60089400		3 3 3 2P	04.00 04.40 04.70 06.50	

1.Publication number of literature
 2.The latest revision level
 3.Indicates number of holes punched
 in manual for use with hard cover
 ringed binder.

4.Price per manual.
 5. Manual page count.