

6741 VARIEL AVENUE - CANOGA PARK - CALIFORNIA 91303 - PHONE: (213) 348-1391

OPERATOR'S MANUAL

iCOM MICROPERIPHERALStm

FDOS-II FOR SBC/8800/ALTAIR/IMSAI/POLY88

iCOM Microperipheralstm

6741 Variel Avenue

Canoga Park, CA 91303

Rev. October 15, 1976
© September, 1976

✓

✓

CONTENTS

1. UNPACKING AND INSTALLATION
 - 1.1 Unpacking
 - 1.2 Installation
 - 1.3 Special Instructions for FDOS-II
 - 1.4 Use of Mini-Monitor
 - 1.5 Loading FDOS
2. SYSTEM ORGANIZATION
 - 2.1 FDOS-II Software Modules
 - 2.1.1 FDOS-II Resident Module
 - 2.1.2 FDOS-II Executive
 - 2.1.3 FDOS-II Text Editor
 - 2.1.4 FDOS-II Assembler
 - 2.2 FDOS-II Disk Layout
 - 2.2.1 System Diskette
 - 2.2.2 User Diskette
 - 2.3 FDOS-II Disk Files
 - 2.3.1 Definition
 - 2.3.2 Locations
 - 2.3.3 File Names
 - 2.3.4 Device Suffixes
 - 2.4 File Directory
 - 2.4.1 Location of the Directory
 - 2.4.2 Contents of the Directory
 - 2.5 System Device

3. FDOS-II OPERATION

3.1 Starting FDOS-II

3.2 FDOS-II Command Line

3.3 FDOS-II Error Message

4. FDOS-II RESIDENT MODULE

4.1 Disk Input/Output

4.1.1 Disk Input

4.1.2 Disk Output

4.2 Disk Sectoring

5. FDOS-II DIRECTIVES

5.1 FDOS-II Commands

APPENDIX A. FD360 DIAGNOSTIC OPERATION

APPENDIX B. FDOS-II RESIDENT MODULE ASSEMBLY LISTING

SECTION 1

UNPACKING AND INSTALLATION

1.1 UNPACKING

Remove the disk drive unit from the shipping box.

Remove the door bracing materials from the drive unit door(s).

Remove the chassis shroud by removing two screws in the upper rear and one screw on the lower rear of each side.

Remove all packing material from inside the unit.

Visually inspect for physical damage.

Insure that all connectors are firmly seated at the rear of each drive unit and on the top of the controller boards.

Replace the chassis shroud.

1.2 INSTALLATION

Insert the supplied interface board into any available slot in the microcomputer's chassis.

Insure that the board is firmly seated.

Plug the interfacing cable, from the rear of the disk drive unit, into the connector at the top of the interface board.

Plug the disk drive unit power cord into any 3-wire, grounded, 117 VAC, 50/60 HZ. outlet.

NOTE: Due to the volatility of magnetic storage media, it is advisable that a back-up copy of the supplied FDOS-II System Diskette be made as soon as possible. In the event that only a one disk drive unit system exists, copies of the files EDIT, ASMB, and EXEC should be made to some other storage media using the dumping command.

1.3 SPECIAL INSTRUCTIONS FOR INSTALLATION OF FDOS-II ON ALTAIR OR IMSAI BUS COMPATIBLE 8080 MICROCOMPUTER.

1.3.1 Initialization (Power Up)

To accomplish normal initialization of the vectors in the interface card's on-board ram, execute at address C3E7 hex. Subsequent entries to the mini-monitor may then be made at address C3E4 hex. Assumes ports 0 and 1 for console device.

1.3.2 If the user desires to operate in a different configuration, it is necessary to establish JMP instructions, in the interface card's on-board RAM, to external user supplied routines which provide input/output capability and a return to monitor vector. These entries must be made prior to booting FDOS-II.

1.3.3

FDOS-II RAM Location	User Supplied Contents	Routine Name	Description
C400	ØC3H	JMP	Subroutine to return one (1) character from console keyboard via the A-register, carry bit reset.
C401	CI Address (Lo Byte)	CI <i>E9</i>	
C402	CI Address (Hi Byte)	<i>82</i>	
C403	ØC3H	JMP	Subroutine which accepts a character from the C-register and outputs it to the console.
C404	CO Address (Lo Byte)	CO <i>FE</i>	
C405	CO Address (Hi Byte)	<i>57</i>	
C406	ØC3H	JMP	Subroutine to return one (1) byte from the reader device via the A-register. Carry bit must be reset if a byte is returned and carry bit must be set if no input byte is available.
C407	RI Address (Lo Byte)	RI	
C408	RI Address (Hi Byte)		
C409	ØC3H	JMP	Subroutine which accepts a character from the C-register and outputs it to the list device.
C40A	LO Address (Lo Byte)	LO	
C40B	LO Address (Hi Byte)		
C40C	ØC3H	JMP	Subroutine which accepts a byte from the C-register and outputs it to the punch device.
C40D	PO Address (Lo Byte)	PO	
C40E	PO Address (Hi Byte)		
C40F	ØC3H	JMP	Entry point to user's monitor program. Used by FDOS-II EXIT command and upon occurrence of fatal errors.
C410	EXIT Address (Lo Byte)	EXIT	
C411	EXIT Address (Hi Byte)		
C412	ØC3H	JMP	Disk read vector.
C413	ØØ9H	RI	
C414	ØC1H		
C415	ØC3H	JMP	Disk write vector.
C416	Ø94H	WRT	
C417	ØC1H		

1.3.3 (CONT.)

FDOS-II RAM Location	User Supplied Contents	Routine Name	Description
C418	0C3H	JMP	Asmbl/edit vector.
C419	040H	040H	
C41A	000H		
C41B	0C3H	JMP	Exec vector.
C41C	040H	040H	
C41D	000H		
C41E	0C3H	JMP	Update vector.
C41F	043H	043H	
C420	000H		

1.3.4 The user may create a permanent copy of FDOS-II which automatically initializes these vectors, by following the instructions below.

1.3.5 Using FDOS-II, assemble the following program and place the object into a file named XX:

```

                ORG      0C400H
CI              EQU          ; address of user CI routine
CO              EQU          ; " " " CO "
RI              EQU          ; " " " RI "
LO              EQU          ; " " " LO "
PO              EQU          ; " " " PO "
EXIT            EQU          ; address of user MONITOR routine
JMP             CI
JMP             CO
JMP             RI
JMP             LO
JMP             PO
JMP             EXIT
JMP             0C100H
JMP             0C194H
JMP             040H
JMP             040H
JMP             043H
END

```

1.3.6 Type the FDOS-II command:

EDIT,EXEC,ZZ

When the prompt @ is output by the editor, enter:

AAAB150PAAAS:00000001FF\$0L1KBE\$\$ (\$ = Escape)

This deletes the end file from EXEC.

1.3.7 Type the FDOS-II command: MERG,YY,ZZ,XX

- 1.3.8 Place the above diskette into drive unit 1 and a blank diskette into drive unit 0 and type the FDOS-II command:

XGEN,YY:1

- 1.3.9 The new diskette now contains a copy of FDOS-II which, as it is loading, will initialize the desired RAM locations.

- 1.3.10 The user may control the execution address of the RUNGO command for purposes of loading and executing programs (such as BASIC or user written programs), by adding the following to the program source code:

ORG 0C418H

JMP XXXX Where XXXX = start of user program.

If re-assembly of the user programs is not practical the technique described in paragraphs 2.1 through 2.4 above may be employed.

1.4 USE OF MINI-MONITOR.

1.4.1 Command Mode

When the prompt character > appears on the console, the mini-monitor is now ready to accept the following commands:

GOTO = GXXXX(cr) Where XXXX is the desired execution address.

Example: GC0000(cr) will cause the FDOS loader to execute.

MEMORY DISPLAY/ALTER = MXXXX(cr)

Where XXXX = the ram location to be displayed.

- 1.4.2 Entry of hex data (2) hex characters for each byte) through the console keyboard will cause the contents of the current ram location to be altered and will cause the contents of the next ram location to be displayed.

- 1.4.3 To leave the current location un-altered and to display the next locations, depress the space bar.

- 1.4.4 To terminate the MEMORY DISPLAY/ALTER function, depress carriage return.

1.4.5 TEST MEMORY = TXXXX,YYYY(cr)

Where XXXX is the low ram address and YYYY is the high ram address.

Memory failure will be displayed on the console device as:

XXXX = YY XX

Where XXXX is the address of the failure, YY is the data written and ZZ is the data read.

The memory test is a continuous test which may be interrupted only by depressing CTL-C or by manipulation of the front panel controls.

NOTE: Many FDOS-II failures are attributable to improperly functioning memory. To eliminate the possibility of such a failure recommended procedure is to test all of ram using the TEST MEMORY function prior to loading FDOS-II.

1.5 LOADING FDOS

Power up and executed at address C3E7 hex or user's monitor.

Change vectors if necessary.

Insert systems diskette in drive 0.

Type GC000(cr) or execute at address C000 hex via front panel.

The display of ! (FDOS-II prompt character) on the console device indicates FDOS-II is awaiting command input from the keyboard.

1

2

3

SECTION 2
SYSTEM ORGANIZATION

2.1 FDOS-II SOFTWARE MODULES

FDOS-II consists of the following modules:

- FDOS-II Resident Module
- FDOS-II Executive
- FDOS-II Text Editor
- FDOS-II Assembler

2.1.1 FDOS-II Resident Module

The FDOS-II Resident Module is that portion of FDOS-II which is contained in the PROM memory, usually located on the supplied interface board. In addition to containing the disk input/output handler and FDOS-II bootstrap loader, this resident module is available for use by a user program to perform disk read and disk write operations.

2.1.2 FDOS-II Executive

The FDOS-II Executive is transferred from disk memory into the micro-computer's RAM memory when program control is transferred to the FDOS-II Bootstrap Loader contained in the FDOS-II Resident Module. The FDOS-II Executive is in RAM memory, and is awaiting an FDOS-II directive, when it prints the character ! on the console device. The FDOS-II Executive performs all of the command line interpretation, file management, and FDOS-II operational functions.

2.1.3 FDOS-II Text Editor

With the FDOS-II Text Editor, text input is derived from a file on disk and edited text output is stored into a file on disk. The FDOS-II Text Editor is transferred from the disk memory file named EDIT into RAM memory when the FDOS-II editor command is executed. Upon completion of edit operations, the FDOS-II Executive is reloaded into RAM memory automatically.

2.1.4 FDOS-II Assembler

With the FDOS-II Assembler, source program input is derived from a file on disk, and assembled object output is stored into a file on disk. The FDOS-II Assembler is transferred from the disk memory file named ASMB into RAM memory when the FDOS-II assemble command is executed. Upon completion of the assembly operations, the FDOS-II Executive is reloaded into RAM memory automatically.

2.2 FDOS-II DISK LAYOUT

Except for the FDOS-II Resident Module, all FDOS-II programs have been stored on the diskette enclosed with the FDOS-II Software Package. Disk storage space is divided into two or three distinct regions, depending upon whether the diskette is a System Diskette or a User Diskette.

2.2.1 System Diskette

An FDOS-II System Diskette is divided into three distinct regions: file directory area, system area, and user file area. The diskette enclosed with the FDOS-II Software Package is a preloaded FDOS-II System Diskette. On a System Diskette, track 0 is reserved for the file directory, tracks 1-3 are reserved for the storage of the FDOS-II System Executive, and the balance of the disk storage area is available as user file area. It should be noted that the FDOS-II Text Editor and Assembler should reside on a System Diskette within the user file area, as they are on the supplied FDOS-II System Diskette.

2.2.2 User Diskette

An FDOS-II User Diskette is divided into two distinct regions: file directory area, and user file area. On a user diskette, track 0 is reserved for the file directory, and the balance of the disk storage area is available as user file area. Because the User Diskette does not contain the system area, a maximum amount of storage is available for storing user files.

2.3 FDOS-II DISK FILES

2.3.1 Definition

The term "file" applies to any collection of information. Typical examples are files which contain program object information, files which contain program source information, and files which contain user generated data information.

2.3.2 Locations

All disk files are contained within the user file region of a diskette. As disk files are created, an appropriate amount of contiguous disk storage space is reserved for that file, following which begins the next file and so on. The location of a file of information on a diskette as well as other information pertinent to that file, is contained within the file directory area of that diskette. When a file is deleted from a diskette, the disk storage space previously occupied by that file in the user file area, as well as the file directory entry for that file, is made available for later use by a disk packing

technique in which FDOS-II takes all file information, which succeeds the deleted file in the user area, and packs it "down" within the user area, thus filling the storage space gap created by the deletion of a file.

2.3.3 File Names

Each file in the user area of a diskette is accessible by "filename". This filename is stored, along with other information pertinent to that file, in the file directory area of the diskette on which the file is resident. The file name is a string of ASCII characters, which may be from 1 to 5 characters in length. A filename of any number of characters may be entered, however, the FDOS-II System considers only the first five characters to be significant. Examples of valid filenames are as follows:

JACK
JOE3
X
#SAM
BLOB5

2.3.4 Device Suffixes

File names may be suffixed by a device specifier. The device specifier is a drive unit number preceded by a colon that separates the specifier from the file name. For example:

JOE3:1
#SAM:3
X:Ø
JACK:2

A device suffix is used to reference a file which is contained on a diskette loaded into a specific disk drive unit: Ø, 1, 2, or 3. If the device suffix is omitted from the filename, the file is assumed, by FDOS-II, to reside on the diskette which is loaded into drive unit Ø, the System Diskette.

2.4 FILE DIRECTORY

2.4.1 Location of the Directory

Each diskette contains a directory of the files stored on that diskette. The directory is located on sectors 4 thru 26 of track Ø on the diskette, sectors 1 thru 3 being reserved for future FDOS-II usage. Beginning with sector 4, each sector contains 11 file control block (FCB) entries, each FCB being 11 bytes long. Thus a file directory has room to accommodate up to 253 unique files per diskette.

Track 0 Sector 1 - Reserved
2 - "
3 - "
4 - File Control Block (FCB) 1 thru 11
5 - FCB's 12 thru 22
. . .
26 - FCB's 243 thru 253

2.4.2 Contents of the Directory

Information required about files on a given diskette is kept in the file directory on that diskette. The information specific to one file is contained within that file's 11 byte File Control Block (FCB). The information contained within a file's FCB includes the file name, the file attributes, the length in sectors of the file, and the file's beginning disk track and sector. The 11 byte FCB layout is as follows:

BYTES 1-5 ;file name padded with spaces (code 20 hex)
BYTE 6 ;file attributes
BYTE 7 ;file's starting track address
BYTE 8 ;file's starting sector address
BYTE 9-10 ;file's length in sectors, most significant byte first
BYTE 11 ;(reserved for future FCB expansion)

Since all file names on a given diskette are contained in a single directory, each file name must be unique. An attempt to add a file name to the directory when the same file name already exists causes an error indication.

File attributes are characteristics of files that can be set and changed by the user. Those attributes already defined within FDOS-II are as follows:

00 - user file, no restrictions.
01 - permanent file, cannot be deleted.
80 - designates a deleted file.*
FF - designates end of directory.*

* These file attributes are automatically manipulated by FDOS-II and, therefore, are unavailable to the user.


A file may have a length of from one sector up to a maximum of 1,975 sectors (252,800 bytes).

2.5 SYSTEM DEVICE

The System Device is always assumed to be disk drive unit \emptyset . The diskette contained in disk drive unit \emptyset should always be a system diskette (see section 2.2.1). Disk drive units 1, 2, and 3 may contain either a system or a user diskette.

The System Device is used as the Bootstrap Device. That is to say, whenever FDOS-II attempts to bring the FDOS-II Executive, FDOS-II Text Editor, or FDOS-II Assembler from disk memory into RAM memory, it assumes that these modules are contained on the system diskette presently contained disk drive unit \emptyset .

The System Device is also considered to be the Default Directory Device. Thus, whenever a device suffix is omitted from an FDOS-II command or from a file name, disk drive unit \emptyset is assumed (see section 2.3.4).



Prior to terminating a command line the entire command line entry may be deleted by pressing the BREAK key on the console device. FDOS-II will respond by printing !.

3.3 FDOS-II ERROR MESSAGES

When the user issues a command that contains an error, an appropriate error message will be typed out. The error messages are as follows:

- FORMAT ERROR - the command line format was incorrect and command execution could not proceed.
- NO SUCH FILE - a filename, from which information was to be taken, does not exist in the file directory of the specified diskette.
- DUPL NAME - an attempt was made to cause an entry to be made, in the file directory, with a duplicate name to one which already exists in that directory.
- NO ROOM - FDOS-II was requested to allocate more disk space to a file than was remaining on the specified diskette, or a 254'th file directory entry was attempted.
- DISK NOT READY - the referenced disk drive unit is not ready. Either no diskette has been inserted, the drive unit door is not closed, or the diskette is not yet up to speed.
- MEDIA ERROR - FDOS-II has been unable to write to the specified media. A copy of this media should be made to recover all but the inaccessible regions.

There are three error messages which may emanate from the FDOS-II Resident Module. For brevity sake, the error message is a single digit, or a ?, followed by a return to the microcomputer's debug or monitor program. They are as follows:

- ? - a checksum error was incurred while loading an object file from disk.
- 1 - unable to read from the diskette media
- 2 - an attempt was made to write more information to a file than there was disk space allocated to that file.
- 3 - the referenced disk drive unit has become "not-ready" (see DISK NOT READY error message).

SECTION 4

FDOS-II RESIDENT MODULE

4.1 DISK INPUT/OUTPUT

Provisions have been made in the FDOS Resident Module (see appendix B) to enable the programmer to develop user oriented programs which utilize the FD360 as a peripheral mass storage device outside of the FDOS-II environment. Contained within the module is a disk read (RI) routine and a disk write (WRT) routine which provide byte oriented input and output capabilities, respectively, to the user.

In order to use the disk input and output routines RI and WRT, it is the programmer's responsibility to first set up pointers to the area on disk which is to be accessed. This is known as "opening" a disk file. Once a disk file has been opened, RI and WRT may be called any number of times in much the same fashion as the user would call the console input and console output routines in the microcomputer's debug or monitor program. The driver handles all maintenance of the file pointers once the file has been opened. It should be noted that only one input file and one output file may be opened at any given time.

The following RAM memory locations are used by the RI and WRT routines. Refer to Appendix B for the actual memory addresses of the locations.

<u>Location</u>	<u>Description</u>
ISIZE	Input file's size in sectors (2 bytes)
ITRK	Input file's beginning track address
ISCTR	Input file's beginning unit & sector address
ICNTR	Controller's read buffer counter
OSIZE	Output file's size in sectors (2 bytes)
OTRK	Output file's beginning track address
OSCTR	Output file's beginning unit & sector address
OCNTR	Controller's write buffer counter

4.1.1 Disk Input


To open an input file, the user simply stores the appropriate input file information into locations ISIZE, ITRK, ISCTR, and ICNTR. Then each call to RI will return the next byte of data, from the disk, into the same register that the microcomputer's debug or monitor program would normally return a console input data byte. If no more data exists (i.e. the input file size ISIZE has reached 0) the carry bit is returned as a "1", otherwise the carry bit is returned as a "0". The contents of ISIZE should be set to the number of sectors +1 that are to be read before RI is to return an end-of-file indication (carry bit set). If the programmer is going to perform his own end-of-file monitoring, the

file size may be set to some arbitrarily large number (i.e. FFFF). The contents of ITRK should be set to the track number (00-4C) from which input data is to begin being read. The contents of ISCTR should be set to contain the drive unit number (00-11) in bits 6 & 7, and the sector-1 (i.e. 00-19 hex) from which input data is to begin being read. The contents of ICNTR should be set to 00. Each call to RI will bring in the next sequential data byte from the disk. As a sector (128 bytes) of data is read, RI increments the disk address (ITRK and ISCTR) and decrements the input size (ISIZE). Any sector containing a DD mark is ignored, but it is computed in the input size.

4.1.2 Disk Output

To open an output file, the user simply stores the appropriate output file information into locations OSIZE, OTRK, OSCTR, and OCNTR. Then each call to WRT will output, to disk, the byte contained in the same register from which the microcomputer's debug or monitor program would normally output a console data byte. The contents of OSIZE should be set to the number of sectors that are allowed to be written before WRT terminates by printing error message 3 onto the console (see section 3.3). If the programmer is going to perform his own maximum file size monitoring, the file size may be set to some arbitrarily large number (i.e. FFFF). The contents of OTRK should be set to the track number (00-4C) to which output data is to begin being written. The contents of OSCTR should be set to contain the drive unit number (00-11) in bits 6 & 7, and the sector (01-1A) to which output data is to begin being written. The contents of OCNTR should be set to 00. Each call to WRT will output one byte to disk. When 128 bytes have been sent to the disk, WRT writes that data onto the disk and increments the disk address (OTRK and OSCTR) and decrements the output file size (OSIZE). WRT verifies each sector it has written and if, after 5 attempts, it is unable to write a sector, it writes a DD mark to that sector and advances to the next contiguous disk address and attempts the disk write again. OSIZE is also decremented for each sector written with a DD mark.

When the user has written all his data to the disk, using WRT, it is possible that a partial sector of data still remains in the controller's write buffer. To insure that all data has been written onto the media, the programmer should continue to output a pad character (i.e. 00) until the write buffer reaches 128 bytes and WRT writes it to the disk. A flow chart of such a fill routine is as follows:



4.2 DISK SECTORING

It should be noted that RI and WRT utilize a logical/physical technique of disk addressing. Sectors on a diskette are physically adjacent and contiguous from 1-26 (01-1A). After accessing physical sector 1, an entire revolution of the disk must occur if physical sector 2 cannot be accessed immediately. To overcome these rotational delays, RI and WRT translate the requested sector address (logical sector) into some other sector address (physical sector) which is then used by RI and WRT. For example, if sector 2 is requested, physical sector 10 (0A) is the area on disk actually accessed; if sector 20 (14) is requested, physical sector 16 (10) is the area on disk actually requested. This entire technique is normally transparent to the user if he remains under the control of RI and WRT. Of course, if desired, the contents of TBL may be altered, even to the point of providing a 1:1 translation of logical: physical sectoring.

✓

✓

SECTION 5

FDOS-II DIRECTIVES

5.1 FDOS-II COMMANDS

When an exclamation mark (!) is printed on the console device, FDOS-II is awaiting any one of the following directives. These commands are listed in alphabetical order followed by a summary list of the commands for quick reference.

Name: ASMB

Format: ASMB,sourcefilename,objectfilename,passoption)

Purpose: To assemble the contents of the source file and to direct the assembled object output, if any, to the object output file and the assembled listing, if any, to the list device or to a disk file.

Comments: All three operands must be specified. If no object or listing file is to be created, any dummy file name (i.e. X or Y or Z etc.) may be entered in this operand field since no file directory entry will be created.

The pass option operand field may contain the number 2, 3, 4, or 5.

2 = only an assembly listing is generated to the list device.

3 = only an object output is generated to the output object file.

4 = both an assembly listing and an object output are produced.

5 = only an assembly listing is generated to the disk file objectfilename.

Example: ASMB,JOES,JOEO,3)

Produce an object file named JOEO from the source file named JOES.

Name: BUILD

Format: BUILD,newfilename)

Purpose: To construct a new source file, using the FDOS-II editor, on the diskette from the console keyboard.

Comments: The BUILD directive is functionally equivalent to the EDIT directive except that FDOS-II assumes no pre-existent input file. The operator should use the editor I (insert) command, to enter data from the console keyboard, and the editor E (end) command to terminate the operation and return to FDOS-II.

Example: BUILD,SAM)

Produce a new file SAM from the console keyboard.

Name: CHGAT

Format: CHGAT,filename,newattributes)

Purpose: To change the present attributes of the designated file to those specified in the new attributes operand.

Comments: (see section 2.4.2)

Examples: CHGAT,MAIN,1)

Set the attributes of file MAIN to 01, thus setting it as a permanent, non-deletable, file.

```
CHGAT,MAIN,01)
CHGAT,MAIN)
```

Set the attributes of file MAIN to 00, thus placing no restrictions on its use or access.

Name: COPY

Format: COPY₂

Purpose: To copy the contents of the diskette in drive unit 0 onto the diskette in drive unit 1.

Comments: This is a one-for-one image copy; therefore, the contents of either diskette need not be of FDOS-II format.

If any sector of the source diskette is determined bad after 5 read tries, the last data read from that sector, whether good or bad, is written to the new diskette.

Name: CREAT

Format: CREAT,newfilename,newfilesize)

Purpose: To create a user designated file directory entry with the specified file name and file size in sectors.

Comments: The file size is specified in hexadecimal with a minimum size of 1 sector.

The designated disk space is allocated to this file, and this new file is then treated as any other user or FDOS-II created file entry.

Example: CREAT,JACK,1F)

Creates a new file directory entry with the file name JACK, attributes of 00, and an allocated disk space of 31 (1F hex) sectors.

Name: DELET

Format: DELET:unitnumber,filename1,filename2,.....,filenamen_n

Purpose: To delete the designated, non-permanent, files from the diskette, in the specified drive unit, and then to repack the contents of that diskette's user file area and file directory area, thus making the disk space available for additional files.

Comments: The file names need not be in any specific order.

The unit number refers to the drive unit in which the diskette, with the specified files to be deleted, is loaded. The unit number may be \emptyset , 1, 2, or 3. If the unit number is omitted, \emptyset is assumed.

Examples: DELET:2,JOE1,JOE7,AL,SAM,JACK_n

Deletes the specified files from the diskette loaded into drive unit 2.

DELET: \emptyset ,JOE1,JOE7,AL,SAM,JACK_n
DELET,JOE1,JOE7,AL,SAM,JACK_n

Deletes the specified files from the diskette loaded into drive unit \emptyset .

Name: DUMP

Format: DUMP,filename)

Purpose: To dump the contents of the specified file to the disignated punch device.

Comments: Leader and trailer (blank) paper tape is produced when applicable.

Example: DUMP,MAIN)

Transfers the contents of file MAIN to the punch output device.

Name: EDIT

Format: EDIT,inputfilename,newoutputfilename

Purpose: To enable editing of the contents of the input file, using the FDOS-II Text Editor. Edited data is stored into the new output file.

Comments: Data to be edited is brought from the disk input file into the text editor's RAM buffer by using the editor's A command. Edited data is transferred from the text editor's RAM buffer to the disk output file by using the editor's P command. The edit operation is terminated, the file directory updated, and control returned to FDOS-II when the editor's E command is executed.

Example: EDIT,BOB1,BOB2

Establishes a new file BOB2 which will receive the data edited from the contents of the existing file BOB1.

Name: EXIT

Format: EXIT↵

Purpose: To return control back to the microcomputer's debug or monitor program.

Name: HOME

Format: HOME,unitnumber)

Purpose: To position the disk head, on the specified drive unit, to track 0.

Comments: The unit number may be 0, 1, 2, or 3. If the unit number is omitted, 0 is assumed.

Examples: HOME,2)

Returns the disk head, on drive unit 2, to track 0.

HOME)

HOME,)

HOME,0)

Returns the disk head, on drive unit 0, to track 0.

Name: INIT

Format: INIT,unitnumber)

Purpose: To initialize the file directory area on the specified drive unit.

Comments: The unit number may be 1, 2, 3, or FF, where FF specified drive unit \emptyset .

All existing files, permanent or not, are cleared from the specified file directory.

This command must be used to prepare any non-FDOS-II diskette for use by FDOS-II.

The resultant of this command is a User Diskette (see section 2.2.2).
Caution should be observed if using this command on a System Diskette.

Examples: INIT,1)

Initializes the file area of the diskette in drive unit 1.

INIT,FF)

Initializes the file area of the diskette in drive unit \emptyset .

Name: LIST

Format: LIST,unitnumber↵

Purpose: To print out the contents of the file directory on the diskette in the specified drive unit. Lists the filenames, attributes, file's starting track and sector, and the file's size in sectors.

Comments: The unit number may be 0, 1, 2, or 3. If the unit number is omitted, 0 is assumed.

Examples: LIST,1↵

List's the file directory of the diskette in drive unit 1.

LIST↵

LIST,2↵

LIST,0↵

List's the file directory of the diskette in drive unit 0.

Name: LOAD

Format: LOAD,newfilename)

Purpose: To create the specified file entry and to transfer the contents of the reader input device into that file.

Name: MERGE

Format: MERGE,newfilename,filename1,filename2,.....,filenamen)

Purpose: To create a new file whose contents is the concatenation of the contents of the specified files, in the order in which they appear in the command.

Comments: The existing files are unaffected.

Examples: MERGE,MAIN,SUB1,SUB2,SUB3)

Creates the new file MAIN with the contents of files SUB1, SUB2, and SUB3, in that order.

MERGE,MAINC,MAIN)

Copies the contents of file MAIN into a new file MAINC.

Name: PRINT

Format: PRINT,filename)

Purpose: To print the contents of the specified file to the designated list device.

Name: RENAM

Format: RENAM,oldfilename,newfilename↵

Purpose: To modify the specified file's file directory entry by replacing its existing file name with a new file name.

Comments: Only the file name area of the file's file directory entry is affected.

Example: RENAM,MAIN5,MAIN↵

Renames the file MAIN5 with the name MAIN.

Name: RUN

Format: RUN,objectfilename,offsetbias)

Purpose: To load the contents of the object file into RAM memory for execution. The data is loaded into memory at locations which are the sum of the memory address specified in the object file plus the offset bias.

Comments: The offset bias address is specified in hexadecimal. If omitted, the offset bias is equal to 0.

Following the loading of the object file, control will return to the microcomputer's debug or monitor program, if no auto-start address exists in the object file, or to the specified auto-start address if it exists.

Examples: RUN,MAIN)
RUN,MAIN,)
RUN,MAIN,0)

Loads the contents of the object file MAIN into RAM memory with an offset bias of 0.

Run,MAIN,F000)

Loads the contents of the object file MAIN into RAM memory with an offset bias of F000 hex.

Name: RUNGO (FDOS-II/MDS Only)

Format: RUNGO, hexobjectfilename, inputfilename, outputfilename, n

Purpose: To load the contents of the object file into RAM memory for execution. In addition, inputfilename and outputfilename are opened and the number n is placed in location PASS. After loading program control is transferred to memory location ASMB.

Comments: Any or all of the last three fields may be omitted. If an omitted field is followed by a supplied field, the correct number of commas must exist in the command line.

n may be any hex number from 0 to FF.

By default, inputfile parameters are indeterminate, outputfile parameters are track=76 sector=1 size=1, and n parameter is 0.

Examples: To update the directory following outputs to outputfilename, do a JUMP to location UPDAT in the FDOS PROM driver.

RUNGO, MAIN

Loads the contents of the object file MAIN into RAM memory and transfers program control to memory location ASMB.

RUNGO, ICE80, LOADF, SAVEF

Opens the input file LOADF, creates and opens the output file SAVEF, loads the contents of file ICE80 into RAM memory, and transfers program control to memory location ASMB.

RUNGO, TRY, ,, 7

Sets memory location PASS to 7, then loads the contents of file TRY into RAM memory and transfers program control to memory location ASMB.

Notes: To "rewind" the input file, the user's program should perform a CALL RESTR, where RESTR is in the FDOS-II Resident (see Appendix).

Following completion of output to the output file, the user should terminate with a JMP UPDAT, where UPDAT is in the FDOS-II Resident (see Appendix). This JMP loads the FDOS-II Exec into RAM and updates the output file's directory entry.

Name: VIEW

Format: VIEW,filename,linesperframe,firstline)

Purpose: To display, onto the console device, the contents of the specified file one frame at a time. The number of lines per displayed frame, if not specified, is 14 by default. The first line displayed is line 1, if not specified otherwise.

Comments: "Lines per frame" and/or "first line number" may be omitted, and if so, are assumed to be 14 and 1 respectively. All numbers are in hex.

When in the VIEW command, the following four keys may be used:

N Causes the next frame to be displayed.

P Causes the previous frame to be displayed.

F Causes the first frame to be displayed (i.e. that frame whose first line is "first line").

B Causes the beginning frame to be displayed (i.e. that frame whose first line is 1).

CR (carriage return) Returns to FDOS-II executive.

Name: XGEN

Format: XGEN↵

Purpose: To generate the system region of a System Diskette (see section 2.2.1) in drive unit 0 from the copy of the FDOS-II Executive which is loaded into the reader input device.

Comments: This command is used primarily to generate new System Diskettes as new versions of the FDOS-II Executive become available or when no System Diskette exists.

If no system diskette exists, one can be generated as follows:

1. Load the copy of the FDOS-II Executive into RAM memory and execute it at memory location 20 hex.
2. Insert a new diskette into drive unit 0.
3. Place a copy of the FDOS-II Executive into the reader input device and type
XGEN↵
4. Using the LOAD command, transfer copies of the FDOS-II Text Editor and FDOS-II Assembler from the reader input device to files EDIT and ASMB respectively.

2

1

,

.

.

2

2

SUMMARY
OF
FDOS-II COMMANDS

ASMB,sourcefilename,destinationfilename,p

assembles the contents of the source file and directs the object to the destination file. p is the pass number which determines whether the assembly should produce a listing only, object only, or both.

BUILD,destinationfilename

enables the user to build a new source file onto the diskette from the console keyboard.

CHGAT,filename,newattributes

changes the present attributes of the designated file to those specified in the new attributes filed.

COPY

copies the contents of the diskette in drive unit "0" onto the diskette in drive unit "1".

CREAT,filename,size

creates the designated filename in the directory and allocates disk space equal to size.

DELET:u, filename1,filename2,.....,filenamen

deletes the designated files from the diskette in drive unit u, and then repacks the contents of that diskette, making the disk space available for additional files.

DUMP,filename

dumps the contents of the file to the punch output storage device.

EDIT,inputfilename,outputfilename

enables editing of the input file's contents. Edited data is stored into the output file.

EXIT

returns to the microcomputer system monitor.

HOME,u

positions the disk head on drive unit "u" to track 0.

INIT,u

initializes the file directory on the diskette in drive unit "u". Clears any existing user files on that diskette.

LIST,u

lists the contents of the file directory on the diskette in drive unit u. Lists the filenames, attributes, and file sizes in sectors.

LOAD,destinationfilename

loads the contents of the reader device into the specified file on diskette.

MERGE,newfilename,filename1,filename2,.....,filenamem

creates a new file which is a concatenation of filenames 1-n, in that order.

PRINT,filename

prints the contents of the file on the list output device.

RENAME,oldfilename,newfilename

renames the old file with the new filename.

RUN,filename,offsetbias

loads the contents of the file into RAM for execution.

RUNGO,hexobjectfilename,inputfilename,outputfilename,n

sets up the specified input, output, and n parameters, if given; loads the contents of the hex object file into RAM for execution; and then does a branch to location.

VIEW,filename,linesperframe, firstline

displays the contents of the specified file one frame at a time.

XGEN

enables system generation of other iCOM FDOS versions as might become available in the future.

APPENDIX A
FOR
FDOS-II/SBC
OPERATOR'S MANUAL

]

]


```

;
;
; ICOM, INC FD360 DIAGNOSTIC FOR GENERALIZED 8080 BASED SYSTEMS
;
; LOAD INTO RAM MEMORY AND START AT LOCATION 4000H for SBC-
; 80/10 and 100H for Altair/IMSAI and 2000H for Poly 88
; LOAD A SCRATCH DISKETTE INTO THE DRIVE UNIT TO
; BE TESTED

; TYPE THE DESIRED TEST TO BE PERFORMED

; CONTINUOUS TESTS MAY BE MANUALLY ABORTED

; OR BY PRESSING "CTL-C"

; U=UNIT NUMBER 0 (OR NOTHING), 1, 2, OR 3
; T=TRACK
; S=SECTOR

; A -CLEAR DRIVE ELECTRONICS
; BU, T -SEEK TO TRACK
; DU, S -READ TO BUFFER FROM PRESENT TRACK
; FU, S -WRITE FROM BUFFER TO PRESENT TRACK
; GU, S -RD/WRT (BFR) CONTINUOUS ON PRESENT TRACK
; HU -TRK0 TO TRK76 LOOP
; I -UNIT SELECT TEST
; JU -SEEK TEST ONCE(2 MIN)
; KU -SEEK TEST CONTINUOUS
; LU -SEEK TEST READ ONLY
; MU -DD MARK TEST ONCE
; N -RETURN TO MONITOR

; LIST OF ERRORS

; 01 - CRC ERROR ON READ 5 TIMES - 01(TRK)(UNIT/SCTR)
; 02 - CRC ERROR ON WRITE 5 TIMES - 02(TRK)(UNIT/SCTR)
; 03 - RD/WRT DATA ERROR - (REC'D)(EXP'D)(BYTE#)
; 04 - UNIT SELECT ERROR - (REC'D)(EXP'D)
; 05 - SEEK ERROR - (REC'D)(EXP'D)(TRK)(SCTR)
; 06 - DD MARK ERROR - (SCTR)
; 07 - DD MARK ERROR ON RD/WRT

; BUFFER = 1000H - 107FH

; 8080 FD360 DIAG VER. 1.0

```

```

E800      ORG      0E800H
          ;*****
          ;
          ;RESIDENT FDOSII FOR SBC-80/10 VERSION 0.1
          ;
          ;*****
          ;
          ;
0007      DATA0  EQU    7
0007      DATA1  EQU    7
0006      CNTRL   EQU    6
          ;
          ;
3CE0      BASE    EQU    3CE0H

3CE0      PASS    EQU    BASE
3CE1      OFILE   EQU    BASE+1
3CE2      OUNIT   EQU    BASE+2
3CE3      IUNIT   EQU    BASE+3
3CE4      ISIZE   EQU    BASE+4
3CE6      ITRK    EQU    BASE+6
3CE7      ISCTR   EQU    BASE+7
3CE8      ICNTR   EQU    BASE+8
3CE9      OSIZE   EQU    BASE+9
3CEB      OTRK    EQU    BASE+11
3CEC      OSCTR   EQU    BASE+12
3CED      OCNTR   EQU    BASE+13
3CDF      TITRK   EQU    BASE-1
3CEE      TISIZE  EQU    BASE+14

3CDD      STACK  EQU    3CDDH
4000      ASMB    EQU    4000H
          ;
          ;
          ;
          ;ENTRY POINT WHEN Q IS TYPED
          ;LOADS FDOS AND BRANCHES TO FDOS S. A.

E800 C315E8      JMP      FDOS

E803 C3FD03      CI:     JMP      3FDH      ;KEYBOARD INPUT VECTOR

E806 C3FA03      CO:     JMP      3FAH      ;CONSOLE OUTPUT VECTOR

E809 C30004      RDRIN:  JMP      400H      ;READER INPUT VECTOR

E80C C3FA03      LO:     JMP      03FAH     ;LIST OUTPUT VECTOR

```

```
E80F C30304 PO:    JMP    0403H ;PUNCH OUTPUT VECTOR

E812 CF      MNTR:  RST    1
E813 00      NOP
E814 00      NOP

E815 31DD3C FDOS:  LXI    SP,STACK
E818 CD5EE8      CALL   FDOS1
E81B C30040      JMP    4000H
;
E81E C354E8 RSTV:  JMP    RESET
E821 C3E8E9 XUSV:  JMP    XUS
E824 C3F7E9 XXUSV: JMP    XXUS
E827 C3FFE9 SEEKV: JMP    SEEK+1
E82A C30BEA RFLGV: JMP    RFLAG
E82D C30DEA LOOPV: JMP    LOOP
E830 C37AE8 RSTRV: JMP    RESTR
;
;
;
;
E833 C311E9 RIV:    JMP    RI
;
E836 C39CE9 WRTV:  JMP    WRT
;
;
E839 C340EA PASSV: JMP    IPASS ;ASMB INTERPASS FNC

E83C CD93E8 ASSEM: CALL   REDX
E83F CD7AE8      CALL   RESTR
E842 C30040      JMP    ASMB
;
;
E845 31DD3C UPDAT: LXI    SP,STACK
E848 CD5EE8      CALL   FDOS1
E84B C30340      JMP    4003H
;
;
E84E CD93E8 PROG:  CALL   REDX
E851 C312E8      JMP    MNTR
;
;
E854 3E81     RESET: MVI    A,81H
E856 CD0DEA      CALL   LOOP
E859 3E0D      MVI    A,0DH
E85B C30DEA      JMP    LOOP
```

```

;
E85E C054E8 FDOS1: CALL RESET
E861 210000 LXI H,0 ;SET BIAS=0
E864 E5 PUSH H
E865 216900 LXI H,105
E868 22E43C SHLD ISIZE
E86B 21E63C LXI H,ITRK
E86E 3601 MVI M,1 ;TRACK=1
E870 2C INR L
E871 3600 MVI M,0 ;SECTOR=0
E873 2C INR L ;READ BFR EMPTY
E874 3600 MVI M,0
E876 C093E8 CALL REDX
E879 09 RET ;GO TO FDOS
;
;
E87A 24EE3C RESTR: LHLD TISZE ;RESTORE IFILE POINTERS
E87D 22E43C SHLD ISIZE
E880 3ADF3C LDA TITRK
E883 32E63C STA ITRK
E886 34E33C LDA IUNIT
E889 0F RRC
E88A 0F RRC
E88B 32E73C STA ISCTR
E88E 97 SUB A
E88F 32E83C STA ICNTR
E892 09 RET
;
;
;SUBROUTINE TO READ A HEX FILE INTO MEMORY
;STARTS WITH ROUTINE REDO, USES ALL REGISTERS
;
;
E893 E1 REDX: POP H ;SWAP BIAS & RETURN
E894 E3 XTHL
E895 E5 PUSH H
E896 E1 REDO: POP H ;GET BIAS
E897 E5 PUSH H
E898 C008E9 CALL RIX ;GET CHAR INTO A
E89B 063A MVI B,' '
E89D 90 SUB B
E89E C296E8 JNZ REDO
E8A1 57 MOV D,A
E8A2 CDD7E8 CALL BYTE
E8A5 CAC8E8 JZ RED2
E8A8 5F MOV E,A
E8A9 CDD7E8 CALL BYTE
E8AC F5 PUSH PSW

```

```

E8A0 CDD7E8      CALL   BYTE
E8B0 01          POP    B
E8B1 4F          MOV    C,A
E8B2 09          DAD    B
E8B3 CDD7E8      CALL   BYTE
E8B6 CDD7E8      RED1:  CALL   BYTE
E8B9 77          MOV    M,A
E8BA 23          INX   H
E8BB 1D          DCR   E
E8BC C2B6E8      JNZ   RED1
E8BF CDD7E8      CALL   BYTE
E8C2 C2EEE8      JNZ   LER
E8C5 C396E8      JMP   RED0
E8C8 CDD7E8      RED2:  CALL   BYTE
E8CB 67          MOV    H,A
E8CC CDD7E8      CALL   BYTE
E8CF 6F          MOV    L,A
E8D0 B4          ORA   H
E8D1 CAD5E8      JZ    RED3
E8D4 E9          PCHL
E8D5 E1          RED3:  POP    H
E8D6 C9          RET

```

```

;
;
;
E8D7 CD08E9      BYTE:  CALL   R1X
E8DA CDF6E8      CALL   NBL
E8DD 07          RLC
E8DE 07          RLC
E8DF 07          RLC
E8E0 07          RLC
E8E1 4F          MOV    C,A
E8E2 CD08E9      CALL   R1X
E8E5 CDF6E8      CALL   NBL
E8E8 B1          ORA   C
E8E9 4F          MOV    C,A
E8EA 82          ADD   D
E8EB 57          MOV    D,A
E8EC 79          MOV    A,C
E8ED C9          RET

```

```

; SUBROUTINE IF LOAD ERROR OCCURRED

```

```

E8EE 0E3F      LER:  MVI   C,'?'
E8F0 CD06E8      CALL   CO
E8F3 C312E8      JMP   MNTR

```



```

E932 22E43C      SHLD  ISIZE
E935 21E63C      LXI   H,ICNTR
E938 3600        MVI   M,0
E93A 37          STC           ;SET EOF
E93B E1         RI2: POP   H           ;RESTORE D-L
E93C C1          POP   B
E93D C9          RET

;
E93E 21E73C      RI3: LXI   H,ISCTR ;XMIT UNIT/SECTOR
E941 CDE8E9      CALL  XUS
E944 CD30EA      CALL  CHK           ;MAKE SURE A DISK
E947 2C          INR   L           ;SET CNTR=128
E948 3680        MVI   M,128
E94A 0E05        MVI   C,5           ;SET TRY CNT=5
E94C 2EE6        MVI   L,ITRK AND OFFH ;SEEK TRACK
E94E CDFEE9      CALL  SEEK
E951 3E03        RI6: MVI   A,3           ;READ DATA
E953 CD0DEA      CALL  LOOP
E956 DB07        IN    DATAI ;DD MARK?
E958 E680        ANI   80H
E95A CA63E9      JZ    RI4           ;NO
E95D CD0BEA      CALL  RFLAG
E960 C31BE9      JMP   RI5
E963 DB07        RI4: IN    DATAI ;CRC ERROR?
E965 E608        ANI   8H
E967 CA76E9      JZ    RI10          ;NO
E96A CD0BEA      CALL  RFLAG
E96D 0D          DCR   C           ;DECR CNTR
E96E C251E9      JNZ   RI6
E971 3E01        MVI   A,1
E973 C337EA      JMP   CHK1

;
E976 3E40        RI10: MVI   A,40H ;READ BYTE INTO A
E978 D306        OUT   CNTRL
E97A DB07        IN    DATAI
E97C 4F          MOV   C,A
E97D 3E41        MVI   A,41H ;STROBE BUFFER
E97F CD0DEA      CALL  LOOP
E982 2EE8        MVI   L,ICNTR AND OFFH ;DECR READ COUNTER
E984 35          DCR   M
E985 79          MOV   A,C
E986 B7          ORA   A
E987 C33BE9      JMP   RI2

;
;
;
;ROUTINE TO INCREMENT DISK ADDRESS
;
E98A 34          INCDA: INR   M
E98B 7E          MOV   A,M
    
```

```

E990 E61F      ANI      1FH
E992 FE13      CPI      27
E993 C985E9    JZ       INCDB
E993 2D        DCR      L
E994 09        RET
E995 7E        INCDB.  MOV      A,M
E996 E601      ANI      0C1H
E998 77        MOV      M,A
E999 2D        DCR      L
E99A 34        INR      M
E99B 09        RET

;
;
;
; SUBROUTINE TO WRITE A BYTE TO DISK
; EXPECTS CHAR TO BE IN C-REG
;
E99C 79        WRT.   MOV      A,C
E99D E5        PUSH     H
E99E D807      OUT      DATA0 ; OUTPUT HAR
E9A0 3E31      MVI      A,31H
E9A2 CD0DEA    CALL     LOOP
E9A5 21ED3C    LXI      H,0CNTR
E9A6 34        INR      M ; INCREMENT BFR CNT
E9A9 7E        MOV      A,M
E9AA FE80      CPI      128 ; =128?
E9AC 02E6E9    JNZ      WRT4 ; NO
E9AF 3600      MVI      M,0 ; CLEAR COUNT
E9B1 21ED3C    WRT1.  LXI      H,0SCTR ; XMIT UNIT/SECTOR
E9B4 CD0DEA    CALL     XUS
E9B7 CD30EA    CALL     CHK ; MAKE SURE A DISK
E9BA 0E05      MVI      C,5 ; SET TRY CNT=5
E9BC 2D        DCR      L ; SEEK TRACK
E9BD CD0DEA    CALL     SEEK
E9C0 3E05      WRT2.  MVI      A,5 ; WRITE DATA
E9C2 CD0DEA    CALL     LOOP
E9C5 3E07      MVI      A,7 ; READ FOR CRC
E9C7 CD0DEA    CALL     LOOP
E9CA DE07      IN       DATA1 ; CRC ERROR?
E9CC E606      ANI      8H
E9CE CAE3E9    JZ       WRT3 ; NO
E9D1 CD0DEA    CALL     RFLAG
E9D4 0D        DCR      C ; DECR TRY CNT
E9D5 C2C0E9    JNZ      WRT2 ; TRY AGAIN
E9D8 3E0F      MVI      A,0FH ; WRITE AS DD
E9DA CD0DEA    CALL     LOOP
E9DD CD19EA    CALL     WRTN ; INCREMENT DA & CHK SIZE
E9E0 C3B1E9    JMP      WRT1
E9E3 CD19EA    WRT3.  CALL     WRTN ; INCREMENT DA & CHK SIZE
E9E6 E1        WRT4.  POP      H ; RESTORE D-L

```



```

E9E7 09          RET
;
;
; SUBROUTINE TO TRANSMIT UNIT/SECTOR BYTE
;
E9E8 7E      XUS:  MOV    A,M
E9E9 E61F    ANI    1FH    ;EXTRACT LOG SECTOR
E9EB E5      PUSH   H
E9EC 2166EA  LXI    H,TBL-1 ;GET TABLE PNTR
E9EF 85      ADD    L    ;MAKE SECTOR PNTR
E9F0 6F      MOV    L,A
E9F1 4E      MOV    C,M    ;GET PHYS SECTOR
E9F2 E1      POP    H
E9F3 7E      MOV    A,M
E9F4 E600    ANI    000H
E9F6 B1      ORA    C    ;MERGE UNIT & PHYS SCTR
E9F7 D307    XXUS:  OUT   DATA0
E9F9 3E21    MVI    A,21H
E9FB C30DEA  JMP    LOOP
;
;
; SUBROUTINE TO SEEK TRACK IN A
;
E9FE 7E      SEEK:  MOV    A,M
E9FF D307    OUT   DATA0
EA01 3E11    MVI    A,11H
EA03 CD0DEA  CALL   LOOP
EA06 3E09    MVI    A,09
EA08 C30DEA  JMP    LOOP
;
;
; SUBROUTINE TO RESET FLAG
;
EA0B 3E0B    RFLAG: MVI    A,0BH
; SUBROUTINE TO ISSUE CMD & LOOP ON BUSY
;
EA0D D306    LOOP:  OUT   CNTRL
EA0F 97      SUB    A
EA10 D306    OUT   CNTRL
EA12 DB07    LOOP1: IN   DATA1
EA14 1F      RAR
EA15 DA12EA  JC    LOOP1
EA18 09      RET
;
;
; SUBROUTINE TO INCR DISK ADDR & CHK OFILE SIZE

```

```

;
EA19 2EEC   WRTN:  MVI    L, OSCTR AND OFFH
EA1B 0D8AE9   CALL    INCDA
EA1E 2AE93C   WRTN2:  LHLD   DSIZE
EA21 2B       DCX    H
EA22 22E93C   SHLD   DSIZE
EA25 7D       MOV    A, L
EA26 A7       ANA    A
EA27 00       RNZ
EA28 7C       MOV    A, H
EA29 A7       ANA    A
EA2A 00       RNZ
EA2B 3E02     MVI    A, 2
EA2D 0337EA   JMP    CHK1
;
;
; SUBROUTINE TO CHECK IF A DISK, ELSE ERR03
;
EA30 DB07   CHK:   IN    DATAI
EA32 E620   ANI    20H
EA34 08     RZ
EA35 3E03   MVI    A, 3
; ROUTINE TO PRINT ERR(E)
EA37 F630   CHK1:  ORI    30H    ; CONVERT TO ASCII
EA39 4F     MOV    C, A
EA3A 0D06E8   CALL   CD
EA3D 0312E8   JMP    MNTR
;
;
; INTERPASS FUNCTIONS
; IF BIT 0 OF (PASS) IS EQUAL TO 1, THEN BIT 0 OF
; (PASS) IS SET TO 0 AND 31H, ASCII 1, IS RETURNED IN
; A-REG. IF BIT 0 OF (PASS) IS EQUAL TO 0, THEN (PASS)
; IS SET TO 00 AND 30H, ASCII 0, PLUS (PASS) SHIFTED
; RIGHT 1 BIT POSITION IS RETURNED IN A-REG. IF (PASS)
; IS EQUAL TO 00, JMP UPDAT OCCURS.

EA40 3AE03C   IPASS:  LDA    PASS
EA43 1F       RAR
EA44 D253EA   JNC    PASS2
EA47 3AE03C   LDA    PASS
EA4A 3D       DCR    A
EA4B 32E03C   STA    PASS
EA4E 3E01     MVI    A, 1
EA50 0364EA   JMP    PASS3
EA53 A7       PASS2: ANA    A
EA54 0A45E8   JZ     UPDAT
EA57 0D7AE8   CALL   RESTR

```

EA5A 3AE03C	LDA	PASS
EA5B 1F	RAR	
EA5E F5	PUSH	PSW
EA5F 97	SUB	A
EA60 32E03C	STA	PASS
EA63 F1	POP	PSW
EA64 C630	PASS3: ADI	30H
EA66 C9	RET	


PHYSICAL SECTOR TABLE IS IN ORDER
OF LOGICAL SECTOR NUMBER.

EA67 01	TBL:	DB	1
EA68 0A		DB	0AH
EA69 13		DB	13H
EA6A 02		DB	2
EA6B 0B		DB	0BH
EA6C 14		DB	14H
EA6D 03		DB	3
EA6E 0C		DB	0CH
EA6F 15		DB	15H
EA70 04		DB	4
EA71 0D		DB	0DH
EA72 16		DB	16H
EA73 05		DB	5
EA74 0E		DB	0EH
EA75 17		DB	17H
EA76 06		DB	6
EA77 0F		DB	0FH
EA78 18		DB	18H
EA79 07		DB	7
EA7A 10		DB	10H
EA7B 19		DB	19H
EA7C 08		DB	8
EA7D 11		DB	11H
EA7E 1A		DB	1AH
EA7F 09		DB	9
EA80 12		DB	12H
EA81 00		NOP	
EA82 00		NOP	
EA83 00		NOP	
		END	

APPENDIX B

FDOS-II FOR SBC/8800/ALTAIR/IMSAI/POLY88

OPERATOR'S MANUAL



```

0000      FROM      EQU      00000H
        .****+
        .
        .RESIDENT 5000 AND FDOS11 VERSION 1.0
        .****+
        .
        .ENTRY ADDRESS:-
        .      POWER UP = 03E7 HEX
        .      RE-ENTRY = 03E4 HEX
        .
0001      DATA0   EQU      001H
0002      DATA1   EQU      000H
0003      CNTRL    EQU      000H
0004      CTRL     EQU      0      ;CONSOLE CONTROL PORT
0005      QDATA    EQU      1      ;CONSOLE DATA PORT
0006      CRDY     EQU      1      ;CONSOLE DATA READY
0007      CTRDY    EQU      30H    ;CONSOLE XMTT READY
        .
0400      SOTCH    EQU      00400H  ;SCRATCH RAM
0401      VCTRS    EQU      SOTCH   ;I/O VECTORS
0402      BASE     EQU      SOTCH+30H
0403      STACK    EQU      SOTCH+7FH
        .
0404      PASS     EQU      BASE
0405      OFILE    EQU      BASE+1
0406      QUNIT    EQU      BASE+2
0407      TUNIT    EQU      BASE+3
0408      ISIZE    EQU      BASE+4
0409      ITRK     EQU      BASE+6
0410      ISCTR    EQU      BASE+7
0411      ICNTR    EQU      BASE+8
0412      OSIZE    EQU      BASE+9
0413      OTRK     EQU      BASE+11
0414      OSCTR    EQU      BASE+12
0415      OCNTR    EQU      BASE+13
0416      TITRK    EQU      BASE-1
0417      TISZE    EQU      BASE+14
        .
0418      ASMB     EQU      VCTRS+24
0419      START    EQU      VCTRS+27
0420      UPDTX    EQU      VCTRS+30

```

```

0000          ORG     FROM
;
;
; ENTRY POINT WHEN Q IS TYPED
; LOADS FDOS AND BRANCHES TO FDOS S. A.
0000 031500          JMP     FPOS
0003 030004  QJ:     JMP     VOTRS      ; KEYBOARD INPUT VECTOR
0007 030304  QO:     JMP     VOTRS+3    ; CONSOLE OUTPUT VECTOR
0009 030604  RDRIN   JMP     VOTRS+6    ; READER INPUT VECTOR
000C 030904  LO:     JMP     VOTRS+9    ; LIST OUTPUT VECTOR
000F 030C04  PO:     JMP     VOTRS+12   ; PUNCH OUTPUT VECTOR
0012 030F04  MNTR   JMP     VOTRS+15   ; SYSTEM MONITOR VECTOR
0015 317F04  FPOS   LXI     SP, STACK
0018 0D5E00          CALL    FPOS1
001B 031B04          JMP     START
;
;
001E 035400  RSTV   JMP     RESET
0021 03E001  XUSV   JMP     XUS
0024 03EF01  XXUSV  JMP     XXUS
0027 03F701  SEEKV  JMP     SEEK+1
002A 030307  RFLGV  JMP     RFLAG
002D 030502  LOOPV  JMP     LOOP
0030 037A00  RSTRV  JMP     RSTR
;
;
;
0033 030901  RIV    JMP     RI
;
;
0036 039401  WRTV  JMP     WRT
;
;
0039 033802  PASSV  JMP     IPASS      ; ASMB INTERPASS FNC
;
;
003C 0D9300  ASSEH  CALL    REDX
003F 0D7A00          CALL    RSTR
0042 031304          JMP     ASMB

```

```

0045 317FC4  UPDAT: LXI   SF, STACK
0046 CD5EC0          CALL  FDOS1
0048 C31EC4          JMP   UPDTX

;

004E CD93C0  PRGG:  CALL  REDX
0051 C312C0          JMP   MNTR

;

0054 3E81     RESET: MVI   A, 81H
0056 CD05C2          CALL  LOOP
0059 3E0B     MVI   A, 0BH
005B C305C2          JMP   LOOP

;

005E CD54C0  FDOS1: CALL  RESET
0061 210000          LXI   H, 0      ;SET BIAS=0
0064 E5         PUSH  H
0065 216900          LXI   H, 105
0068 2234C4          SHLD ISIZE
006B 2136C4          LXI   H, ITRK
006F 3601     MVI   M, 1      ;TRACK=1
0070 2C         INR   L
0071 3600     MVI   M, 0      ;SECTOR=0
0073 2C         INR   L      ;READ BFR EMPTY
0074 3600     MVI   M, 0
0076 CD93C0          CALL  REDX
0079 C9         RET      ;GO TO FDOS

;

007A 2A3EC4  RESTR: LHLD  TISZE ;RESTORE IFILE POINTERS
007D 2234C4          SHLD ISIZE
0080 3A2FC4          LDA   TITRK
0083 3236C4          STA   ITRK
0086 3A33C4          LDA   IUNIT
0089 0F         RRC
008A 0F         RRC
008B 3237C4          STA   ISCTR
008E 97         SUB   A
008F 3238C4          STA   ICNTR
0092 C9         RET

```

```

; SUBROUTINE TO READ A HEX FILE INTO MEMORY
; STARTS WITH ROUTINE REDO, USES ALL REGISTERS

```



```

0003 81      REDX  POP     H      ;SWAP BIAS & RETURN
0004 82              XTHL
0005 83              PUSH    H
0006 84      RED0  POP     H      ;GET BIAS
0007 85              PUSH    H
0008 860001    CALL    RIX      ;GET CHAR INTO A
0009 860A      MOV     R1,R1
000A 86      SUB     R
000B 869000    JNZ     RED0
000C 86      MOV     C,A
000D 86D700    CALL    BYTE
000E 86D800    JZ     RED2
000F 86      MOV     F,A
0010 86D700    CALL    BYTE
0011 86E0      PUSH    PSW
0012 86D700    CALL    BYTE
0013 86E0      POP     R
0014 86E1      MOV     C,A
0015 86E2      TAD     R
0016 86E3 00D700  CALL    BYTE
0017 86E4 00D700  RED1   CALL    BYTE
0018 86E5 77      MOV     M,A
0019 86E6 03      INX     H
001A 86E7 1B      DCR     E
001B 86E8 00B000  JNZ     RED1
001C 86E9 00D700  CALL    BYTE
001D 86EA 02D100  JNZ     LFR
001E 86EB 039A00  JMF     RED0
001F 86EC 00D700  RED2   CALL    BYTE
0020 86ED 67      MOV     H,A
0021 86EE 00D700  CALL    BYTE
0022 86EF 6F      MOV     L,A
0023 86F0 84      ORA     H
0024 86F1 0AD500  JZ     RED3
0025 86F2 89      RCHL
0026 86F3 09      RED3   POP     H
0027 86F4 09      RET

0027 860001    BYTE:  CALL    RIX
0028 860A 0DEE00    CALL    NBL
0029 86D0 07      RLC
002A 86DE 07      RLC
002B 86E6 07      RLC
002C 86E0 07      RLC
002D 86E1 4F      MOV     C,A
002E 86F2 0D0001    CALL    RIX

```

```

00E5 00E0D0      CALL  NBL
00E6 D1         ORA   C
00E7 4F         MOV   C,A
00E8 82         ADD  D
00E9 57         MOV  D,A
00EA 78         MOV  A,C
00EB 08         RET

```

```

;SUBROUTINE TO CONVERT TWO HEX CHARACTERS
; TO ONE BYTE

```

```

00EE D630      NBL,  R11, 10
00F0 D8       RC
00F1 C8E9     ADI  0E9H
00F2 D8       RC
00F4 CA06     ADI  6
00F4 F2F0D0   JP   N10
00F9 C607     ADI  7
00FB D8       RC
00FC CA0A     N10, ADI  10
00FE B7       ORA  A
00FF C9       RET

```

```

;SUBROUTINE TO READ A BYTE FROM DISK
; PLACES CHAR IN A-REG. ENTRY AT RI READS 8 BITS.
; ENTRY AT R1X READS 7 BITS

```

```

0100 DB09C1   R1X,  CALL  RI
0103 DA12C0   JC    MNTR
0106 E67F     ANI  7FH
0108 C9       RET

```

```

0109 C5      RI:  PUSH  B      ;SAVE REG D-L
010A E5      PUSH  H
010B 2138C4  LXI  H,ICNTR
010E 7E      MOV  A,M
010F A7      ANA  A      ;CNT=0?
0110 C26ED1  JNZ  R110   ;NO
0113 2E87    R15,  MVI  L,ISCTR AND OFFH ;YES-INCR D. A.

```

```

0115 000001      CALL    INCDA
0116 000404      LHLR   ISIZE
0118 78          DCX    H
011C 000404      SHLD  ISIZE
011F 78          MOV    A,L
0120 A7          ANA    A
0121 000601      JNZ   R13
0124 78          MOV    A,H
0125 A7          ANA    A
0126 000601      JNZ   R13
0129 08          INX    H
012A 000404      SHLD  ISIZE
012D 010004      LXI   H,CNTR
0130 0600        MVI   M,0
0132 07          STC           ;SET EOF
0133 E1      R12: POP    H           ;RESTORE D-L
0134 01          POP    B
0135 09          RET

;
0136 010704      RIS: LXI   H,ISCTR ;XMIT UNIT/SECTOR
0139 00E001      CALL  XUR
013C 002802      CALL  CHK           ;MAKE SURE A DISK
013F 2C          TNR    L           ;SET CNTR=128
0140 0600        MVI   M,128
0142 0E05        MVI   C,5           ;SET TRY CNT=5
0144 2E38        MVI   L,ITRK AND OFFH ;SEEK TRACK
014A 00F601      CALL  SEEK
0149 0F03      R16: MVI   A,3           ;READ DATA
014B 0D0502      CALL  LOOP
014E DB00        IN     DATA1 ;DD MARK?
0150 FA80        ANI   80H
0152 CA5BC1      JZ    R14           ;NO
0155 0D0302      CALL  RFLAG
0158 031301      JMP   R15
015B DB00      R14: IN     DATA1 ;CRC ERROR?
015D E608        ANI   8H
015F CA6EC1      JZ    R110          ;NO
0162 0D0302      CALL  RFLAG
0165 0D          DCR    C           ;DECR CNTR
0166 024901      JNZ  R16
0169 0E01        MVI   A,1
016B 032F02      JMP   CHK1

;
016E 0E40      R110: MVI   A,40H ;READ BYTE INTO A
0170 B300        OUT   CNTRL
0172 BB00        IN     DATA1
0174 4F          MOV    C,A
0175 0E41        MVI   A,41H ;STROBE BUFFER
0177 0D0502      CALL  LOOP
017A 2E38        MVI   L,CNTR AND OFFH ;DECR READ COUNTER

```

```

017C 35      DCR    M
017D 79      MOV    A,C
017E B7      ORA    A
017F C333D1  JMP    R12

```

```

;
;
; ROUTINE TO INCREMENT DISK ADDRESS
;

```

```

0182 34      INCD0: INR    M
0183 7E      MOV    A,M
0184 F61F    ANI    1FH
0186 FF1B    CPI    27
0188 C06D01  JZ     INCD0B
018B 2D      DCR    L
018C 09      RET
018D 7E      INCD0B: MOV    A,M
018E E6C1    ANI    0C1H
0190 77      MOV    M,A
0191 2D      DCR    L
0192 34      INR    M
0193 09      RET

```

```

;
;
; SUBROUTINE TO WRITE A BYTE TO DISK
; EXPECTS CHAR TO BE IN C-REG
;

```

```

0194 79      WRT    MOV    A,C
0195 E5      PUSH  H
0196 D3C1    OUT    DATA0 ;OUTPUT HAR
0198 3E31    MVI    A,31H
019A C05C02  CALL  LOOP
019D 213D04  LXI    H,CNTR
01A0 34      INR    M ;INCREMENT BFR CNT
01A1 7E      MOV    A,M
01A2 FE80    CPI    128 ;=128?
01A4 C2DEC1  JNZ    WRT4 ;NO
01A7 3600    MVI    M,0 ;CLEAR COUNT
01A9 213C04  WRT1: LXI    H,SCTR ;XMIT UNIT/SECTOR
01AC CDF001  CALL  XUS
01AF C02802  CALL  CHK ;MAKE SURE A DISK
01B2 0E05    MVI    C,5 ;SET TRY CNT=5
01B4 2D      DCR    L ;SEEK TRACK
01B5 CDF601  CALL  SEEK
01B8 3E05    WRT2: MVI    A,5 ;WRITE DATA
01BA C05C02  CALL  LOOP
01BD 3E07    MVI    A,7 ;READ FOR CRC
01BF C05C02  CALL  LOOP
01C2 DB00    IN     DATA1 ;CRC ERROR?

```

```

0104 EA08      ANI      RH
0105 C4BBD1     JZ       WRT3      ;NO
0106 C008C2     CALL     RFLAG
0107 00        DCR      C          ;DECR TRY CNT
0108 C2B8C1     JNZ      WRT2      ;TRY AGAIN
0109 3E0F      MVI      A,0FH      ;WRITE AS DD
010A C005C2     CALL     LOOP
010B C011C2     CALL     WRTN      ;INCREMENT DA & CHK SIZE
010C C3A9C1     JMP      WRT1
010D C011C2     WRT3:  CALL     WRTN      ;INCREMENT DA & CHK SIZE
010E E1        WRT4:  POP      H          ;RESTORE D-L
010F C3      RET

```

```

; SUBROUTINE TO TRANSMIT UNIT/SECTOR BYTE

```

```

01E0 7E      XUS      MOV      A,M
01E1 E61F      ANI      1FH      ;EXTRACT LOG SECTOR
01E2 E5      PUSH     H
01E3 215EC2   LXI      H,TBL-1 ;GET TABLE FNTR
01E4 85      AND      L          ;MAKE SECTOR PNTR
01E5 8F      MOV      L,A
01E6 4E      MOV      D,M      ;GET PHYS SECTOR
01E7 E1      POP      H
01E8 7E      MOV      A,M
01E9 E4C0     ANI      000H
01EA B1      ORA      C          ;MERGE UNIT & PHYS SCTR
01EB D3C1     XUS      OUT      DATA0
01EC 3E21     MVI      A,21H
01ED C305C2   JMP      LOOP

```

```

; SUBROUTINE TO SEEK TRACK IN A

```

```

01F6 7E      SEEK:  MOV      A,M
01F7 D3C1     OUT      DATA0
01F8 3E11     MVI      A,11H
01F9 C005C2   CALL     LOOP
01FA 3E09     MVI      A,09
01FB C305C2   JMP      LOOP

```

```

; SUBROUTINE TO RESET FLAG

```

```

0203 3E0B     RFLAG: MVI      A,0BH
; SUBROUTINE TO ISSUE CMD & LOOP ON BUSY

```

```

0205 D300 LOOP OUT CNTRL
0207 97     SHR A
0208 D300 OUT CNTRL
020A D800 LOOP1 IN DATAI
020C 1F     RAR
020D D40402 JC LOOP1
0210 09     RET

```

```

SUBROUTINE TO INCR DISK ADDR & CHK OFILE SIZE

```

```

0211 2E3C WRTN MVI L,05CTR AND OFFH
0213 0D8201 CALL INDDA
0216 2A3904 WRTN2 LHLB OSIZE
0219 2B     DCX H
021A 223904 SHLD OSIZE
021D 7D     MOV A,L
021E A7     ANA A
021F 00     RNZ
0220 7C     MOV A,H
0221 A7     ANA A
0222 00     RNZ
0223 3E02 MVI A,2
0225 032F02 JMP CHK1

```

```

SUBROUTINE TO CHECK IF A DISK, ELSE ERR03

```

```

0228 D800 CHK IN DATAI
022A E620 ANI 20H
022C 08     R7
022D 3E03 MVI A,3

```

```

ROUTINE TO PRINT ERR(E)

```

```

022F F630 CHK1 ORI 30H ,CONVERT TO ASCII
0231 4F     MOV C,A
0232 0D0600 CALL CD
0235 031200 JMP MNTR

```

```

INTERPASS FUNCTIONS

```

```

IF BIT 0 OF (PASS) IS EQUAL TO 1, THEN BIT 0 OF
(PASS) IS SET TO 0 AND 31H, ASCII 1, IS RETURNED IN
A-REG IF BIT 0 OF (PASS) IS EQUAL TO 0, THEN (PASS)
IS SET TO 00 AND 30H, ASCII 0, PLUS (PASS) SHIFTED
RIGHT 1 BIT POSITION IS RETURNED IN A-REG. IF (PASS)
IS EQUAL TO 00, JMP UPDAT OCCURS.

```

```

0238 3A30C4  IFASS LDA  PASS
023B 1F          RAR
023C 004B02          JNC  PASS2
023F 3A30C4          LDA  PASS
0242 30          DCR  A
0243 3230C4          STA  PASS
0246 3E01          MVI  A,1
0248 0350C2          JMP  PASS3
024B A7          PASS2 ANA  A
024C 0A45C0          JZ   UPDAT
024F 0D7AC0          CALL RESTR
0252 3A30C4          LDA  PASS
0255 1F          RAR
0256 F5          PUSH PSW
0257 97          SUB  A
0258 3230C4          STA  PASS
025B F1          POP  PSW
025C 0630          PASS3 ADI  30H
025E 09          RET

```

PHYSICAL SECTOR TABLE IS IN ORDER
OF LOGICAL SECTOR NUMBER.

```

025F 01          TBL  DB  1
0260 0A          DB  0AH
0261 13          DB  13H
0262 02          DB  2
0263 0B          DB  0BH
0264 14          DB  14H
0265 03          DB  3
0266 0C          DB  0CH
0267 15          DB  15H
0268 04          DB  4
0269 0D          DB  0DH
026A 16          DB  16H
026B 05          DB  5
026C 0E          DB  0EH
026D 17          DB  17H
026E 06          DB  6
026F 0F          DB  0FH
0270 18          DB  18H
0271 07          DB  7
0272 10          DB  10H
0273 19          DB  19H
0274 08          DB  8
0275 11          DB  11H
0276 1A          DB  1AH
0277 09          DB  9
0278 12          DB  12H

```


02B4 0E3E		MVI	C, 3EH
02B6 0D06C0		CALL	CG
02BF 0D09C2		CALL	CECHO
02C2 FE54		CPI	'T'
02C4 CA80C3		JZ	TSTM
02C7 FE4D		CPI	'M'
02C9 CA58C3		JZ	MEM
02CC FE47		CPI	'B'
02CE CAE1C2		JZ	GO
02D1 0E3F	LER:	MVI	C, 12'
02D3 0D06C0		CALL	CG
02D6 03B4C2		JMP	MNTRY
:			
02D9 0D03C0	CECHO	CALL	CI
02DC 4F		MOV	C, A
02DD 0D06C0		CALL	CG
02E0 09		RET	
:			
02E1 0DE8C2	GO:	CALL	PARAM
02E4 0D89C2		CALL	ORLF
02E7 E9		PCHL	
:			
02E8 210000	PARAM:	LXI	H, 0
02EB 0DD9C2	FARM1:	CALL	CECHO
02EE FE0D		CPI	0DH
02F0 08		RZ	
02F1 FE2C		CPI	'/'
02F3 08		RZ	
02F4 29		DAD	H
02F5 29		DAD	H
02F6 29		DAD	H
02F7 29		DAD	H
02F8 DAD1C2		JC	LER
02FB 0DEEC0		CALL	NBL
02FE DAD1C2		JC	LER
0301 B5		DRA	L
0302 6F		MOV	L, A
0303 03EEC2		JMP	FARM1
:			
0306 0DD9C2	BYTC0:	CALL	CECHO
0309 0DEEC0	BYTC1:	CALL	NBL
030C 07		RLC	
030D 07		RLC	
030E 07		RLC	
030F 07		RLC	
0310 F5		PUSH	PSW

```

0311 CDD9C2      CALL  CECHO
0314 CDEEC0      CALL  NEL
0317 C1          POP   B
0318 B0          ORA   B
0319 C9          RET

```

```

031A E5      BYTE0 PUSH  PSW
031B CD2AC3  CALL  BYT01
031E 4F      MOV   C,A
031F CD06C0  CALL  C0
0322 F1      POP   PSW
0323 CD2EC3  CALL  BYT02
0326 4F      MOV   C,A
0327 C306C0  JMP   C0

```

```

032A 0F      BYT01: RRC
032B 0F      RRC
032C 0F      RRC
032D 0F      RRC
032E E60F   BYT02: ANI  0FH
0330 FE0A   CPI  0AH
0332 FA37C3  JM   BYT03
0335 C607   ADI  7
0337 C630   BYT03: ADI  30H
0339 C9      RET

```

```

033A CD86C2  HLC0: CALL  CRLF
033D 7C      MOV   A,H
033E CD1AC3  CALL  BYTE0
0341 7D      MOV   A,L
0342 CD1AC3  CALL  BYTE0
0345 C9      RET

```

```

0346 CD3AC3  DSPYM: CALL  HLC0
0349 0E3D    MVI  C,'='
034B CD06C0  CALL  C0
034E 7E      MOV   A,M
034F CD1AC3  CALL  BYTE0
0352 0E20    MVI  C,20H
0354 CD06C0  CALL  C0
0357 C9      RET

```

```

0358 CDE8C2  MEM:  CALL  PARAM
035B CD46C3  MEM1: CALL  DSPYM
035E CDD9C2  CALL  CECHO

```

0361	FE0D		CPI	0DH
0363	0AB402		JZ	MNTRX
0366	FE20		CPI	20H
0368	0A6F03		JZ	MEM9
036B	0D0903		CALL	BYTC1
036E	77		MOV	N.A
036F	23	MEM9	INX	H
0370	035B03		JMP	MEM1
0373	0E00	KBINT	IN	CTRL
0375	E601		ANI	CRRDY
0377	00		RNZ	
0378	0E01		IN	CDATA
037A	FE05		CPI	5
037C	0A1200		JZ	MNTR
037F	09		RET	
0421		HIGH	EDU	SETCH+21H
0380	0DE802	TSTM	CALL	PARAM
0383	E5		PUSH	H
0384	EB		XCHG	
0385	0DE802		CALL	PARAM
0388	222104		SHLD	HIGH
038B	EB		XCHG	
038C	0D8602		CALL	CRLF
038F	3600	TSTM2	MVI	M.0
0391	7B		MOV	A.E
0392	BD		CMF	L
0393	029B03		JNZ	TSTM3
0396	7A		MOV	A.D
0397	BC		CMF	H
0398	0A9F03		JZ	TSTM4
039B	23	TSTM5	INX	H
039C	038F03		JMP	TSTM2
039F	1E01	TSTM4	MVI	E.1
03A1	E1	TSTM7	FOP	H
03A2	E5		PUSH	H
03A3	34	TSTM1	INR	M
03A4	7B		MOV	A.E
03A5	BE		CMF	M
03A6	04C203		CNZ	TSTM6
03A9	3A2104		LDA	HIGH
03AC	BD		CMF	L
03AD	02BEC3		JNZ	TSTM5
03B0	3A2204		LDA	HIGH+1

```

03B3 BC          CMP     H
03B4 C2BEC3     JNZ    TSTM5
03B7 1C          TNR     E
03B8 CD73C3     CALL   KBINT
03BB C3A1C3     JMP    TSTM7

03BE 23         TSTM5: INX   H
03BF C3A3C3     JMP    TSTM1

03C2 CD46C3     TSTM6: CALL  DSPYM
03C5 7B         MOV    A,E
03C6 CD1AC3     CALL  BYTE0
03C9 C388C2     JMP    CRLF

;
;
;
03CC C303C0     RDIX:  JMP    CI
;
03CF C306C0     LOX:   JMP    CO
;
03D2 C306C0     POX:   JMP    CO

03E4           ORG    PROM+3E4H

;
;
;
; I/O VECTOR TABLE
;
; ***** MONITOR RE-ENTRY ADDRESS *****
03E4 C3B4C2     JMP    MNTRX
;
;
; ***** MONITOR STARTING ADDRESS *****
03E7 C39DC2     JMP    INIT ;*****

VECTR: DW     CIY    ; CONSOLE IN VECTOR
        DW     COY    ; CONSOLE OUT VECTOR
03EC 92C2     DW     RDIX   ; PAPER TAPE READER VECTOR
03EE C0C3     DW     LOX    ; LINE PRINTER VECTOR
03F0 CFC3     DW     POX    ; PUNCH VECTOR
03F2 D2C3     DW     MNTRX  ; MONITOR VECTOR
03F4 B4C2     DW     RI     ; DISK READ VECTOR
03F6 09C1     DW     WRT    ; DISK WRITE VECTOR
03F8 94C1     DW     40H   ; ASSEM/EDIT VECTOR;
03FA 4000     DW     40H   ; EXECUTIVE VECTOR
03FC 4000     DW     43H   ; UPDAT VECTOR
03FE 4300

END

```

ASMB	C418	ASSEM	C030	BASE	C430	BYTC1	C309
BYTE	C0D7	BYTEC	C306	BYTEG	C31A	BYT01	C32A
BYT02	C32E	BYT03	C337	CTRL	C000	CDATA	C001
CECHO	C2D9	CHK	C226	CHK1	C22F	CI	C003
CIX	C27C	CNTRL	C000	CG	C006	COX	C292
CRLF	C288	CRRDY	C001	CTRDY	C080	DATAI	C0C0
DATA0	C0C1	DSPYM	C346	FDOS	C015	FDOS1	C05E
GO	C2E1	HIGH	C421	HLOC	C33A	ICNTR	C438
INCDA	C182	INCDB	C18D	INIT	C29D	INIT1	C2A6
IPASS	C238	ISCTR	C437	ISIZE	C434	ITRK	C436
IUNIT	C433	KBINT	C373	LER	C2D1	LD	C00C
LOOP	C205	LOOP1	C20A	LOOPV	C02D	LOX	C3CF
MEM	C358	MEM1	C35B	MEM9	C36F	MNTR	C012
MNTRX	C2B4	NBL	C0EE	NIO	C0FC	OCNTR	C43D
OFILE	C431	OSCTR	C43C	OSIZE	C439	OTRK	C43B
OUNIT	C432	PARAM	C2E8	PARM1	C2EB	PASS	C430
PASS2	C24B	PASS3	C25C	PASSV	C039	PG	C00F
POX	C3D2	PR0G	C04E	PRGM	C000	RDIX	C3CC
RDRIN	C009	RED0	C096	RED1	C0B6	RED2	C0C8
REDS	C0D5	REDX	C093	RESET	C054	RESTR	C07A
RFLAG	C203	RFLGV	C02A	RI	C109	RI10	C16E
RI2	C133	RI3	C136	RI4	C15B	RI5	C113
RI6	C149	RIV	C033	RIY	C100	RSTRV	C030
RSTV	C01E	SCTCH	C400	SEEK	C1F6	SEEKV	C027
STACK	C47F	START	C41B	TBL	C25F	TISZE	C43E
TITRK	C42F	TSTM	C380	TSTM1	C3A3	TSTM2	C38F
TSTM3	C39B	TSTM4	C39F	TSTM5	C3BE	TSTM6	C3C2
TSTM7	C3A1	UPDAT	C045	UPDTX	C41E	VCTRS	C400
VECTR	C3EA	WRT	C194	WRT1	C1A9	WRT2	C1B8
WRT3	C1DB	WRT4	C1DE	WRTN	C211	WRTN2	C216
WRTV	C036	XUS	C1E0	XUSV	C021	XXUS	C1EF
XXUSV	C024						