

.REMX

IDENTIFICATION

PRODUCT ID: AC-T779A-MC
PRODUCT TITLE: CZTKGA TK25 FRT END FUNC #3
PRODUCT DATE: MARCH, 1984
DEPARTMENT: TAPE DIAGNOSTIC ENGINEERING
AUTHOR: DICE SYSTEMS, INC.

COPYRIGHT (C) 1984 BY
DIGITAL EQUIPMENT CORPORATION,
WESTBORO, MASSACHUSETTS.
ALL RIGHTS RESERVED.

THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY TRANSFERRED.

THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

TABLE OF CONTENTS

1.0	ABSTRACT
2.0	REQUIREMENTS
2.1	HARDWARE REQUIREMENTS
2.2	SOFTWARE REQUIREMENTS
2.3	PREREQUISITES
3.0	OPERATING INSTRUCTIONS - OPERATOR COMMANDS
3.1	OPERATOR COMMANDS
3.2	HARDWARE PARAMETERS
3.3	SOFTWARE PARAMETERS
4.0	OPERATING INSTRUCTIONS - SAMPLE PRINTOUTS
4.1	SUCCESSFUL RUN EXAMPLES
4.2	ERROR MESSAGES
5.0	PROGRAM RUN TIMES
5.1	RUN TIME - CZTKG
6.0	TEST DESCRIPTIONS - CZTKG
6.1	TEST 1 - SPACE RECORDS TEST
6.2	TEST 2 - REREADS TEST
6.3	TEST 3 - WRITE DATA RETRY TEST
6.4	TEST 4 - WRITE/READ TAPE MARK

1.0 ABSTRACT

THIS IS A PDP-11/LSI RESIDENT DIAGNOSTIC WHICH CHECKS THE FUNCTIONALITY OF AN TK25 MAGTAPE SUBSYSTEM WHILE CONNECTED TO A PDP-11 SYSTEM (Q-BUS OR UNIBUS). THE PROGRAM HAS BEEN DIVIDED INTO FOUR MAJOR PIECES: CZTKE, CZTKF, CZTKG, CZTKH. SUCCESSFUL RUN EXAMPLES, AND TEST DESCRIPTIONS HAVE BEEN PROVIDED FOR EACH PROGRAM.

THE PROGRAMS PROVIDE ERROR MESSAGES WHICH IDENTIFY FAILING FUNCTIONS, AND AID IN DEVICE REPAIR. REFERENCE THE FOLLOWING DIGITAL EQUIPMENT DOCUMENTS:

1. CIQPMAO XXDP, PROGRAMMER'S MANUAL; DOCUMENT NUMBER AC-S296A-AC;
DATE: 14 JULY 1980.

1.1 REVISION HISTORY
NEW RELEASE APRIL 1984

2.0 REQUIREMENTS

2.1 HARDWARE REQUIREMENTS

PDP-11 FAMILY PROCESSOR WITH 32K WORDS OF MEMORY
TK25 MAGTAPE SUBSYSTEM (DRIVE AND CONTROLLER)
CAUTION: DIAGNOSTIC REQUIRES 32K WORDS OF MEMORY
(28K USEABLE I.E. 4K FOR I/O PAGE)

2.1.1 OPTIONAL HARDWARE -

FOUR TK25 CONTROLLERS PER PDP-11, ONE
DRIVE PER CONTROLLER

2.2 SOFTWARE REQUIREMENTS

PDP-11 DIAGNOSTIC SUPERVISOR (CIGPMA0 VERSION 34 OR LATER)
PDP-11 DIAGNOSTIC LOADER/MONITOR (XXDP+)

2.3 PREREQUISITES

FUNCTIONAL PDP-11/LSI FAMILY CENTRAL PROCESSOR AND MEMORY
FUNCTIONAL CONSOLE TERMINAL
FUNCTIONAL STANDALONE DIAGNOSTIC SUPERVISOR

3.0 OPERATING INSTRUCTIONS - OPERATOR COMMANDS

3.1 OPERATOR COMMANDS

THE TK25 DIAGNOSTICS ARE PDP-11 DIAGNOSTIC SUPERVISOR COMPATIBLE PROGRAMS.
ALL LOADING AND RUN TIME INSTRUCTIONS CAN BE REFERENCED IN THE PDP-11
PROGRAMMER'S MANUAL "CIQPMAO XXDP" PROGRAMMER'S MANUAL NUMBER AC-S296A-AC.

BOOT THE DIAGNOSTIC XXDP+ MEDIA (OPERATOR RESPONSES ARE UNDERLINED)

CHMDLEO XXDP+ DL MONITOR
BOOTED VIA UNIT 0
28K NON-UNIBUS SYSTEM

ENTER DATE <DD-~~MM~~-YY>: 29-JAN-82

RESTART ADDRESS: 152010 -----
THIS IS XXDP+ TYPE "H" OR "H/L" FOR HELP.

.R CZTKGA

CZTKGA.BIC

DRS-E0
CZTKG-A-0
CZTKGA TK-25 FRT END FUNC #3 UNIT IS TK25
RSTRT ADR 147642
DR>START/FLAG:PNT:HOE

THE ABOVE COMMAND WILL START THE DIAGNOSTIC. THE COMMAND HAS TWO
SWITCHES ON WHICH ARE "PRINT EACH TEST NBR. AS EXECUTED" AND "HALT ON
ERROR".

3.2 HARDWARE PARAMETERS

AFTER INITIAL STARTING OF THE PROGRAM (START COMMAND TO THE DIAGNOSTIC SUPERVISOR), THE PROGRAM WILL ISSUE THE "CHANGE HW?" QUESTION TO ASK IF THE HARDWARE PARAMETERS ARE TO BE CHANGED (BY THE OPERATOR).

ON A "N" (NO) RESPONSE TO THE QUESTION, THE PROGRAM WILL USE IT'S DEFAULT HARDWARE PARAMETER VALUES. IT WILL DEFAULT TO ONE UNIT SELECTED (UNIT 0), THE DEFAULT TSBA/TSDB WILL BE 172522 AND THE INTERRUPT VECTOR WILL BE 224.

ON A "Y" (YES) RESPONSE TO THE QUESTION, THE FOLLOWING QUESTIONS WILL THEN BE ASKED TO ALLOW THE OPERATOR TO SELECT THE UNITS TO BE TESTED. A VALUE, IF PRESENT, LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN ONLY IF A CARRIAGE RETURN IS TYPED AS A RESPONSE. A "(D)" IN A QUESTION INDICATES THAT A DECIMAL NUMBER IS REQUIRED AS A RESPONSE. AN "(O)" INDICATES AN OCTAL NUMBER IS BEING SOLICITED. AN "(L)" THAT A LOGICAL RESPONSE IS TO BE MADE: "Y" FOR YES, "N" FOR NO.

UNITS (D) ? < ENTER THE NUMBER OF CONTROLLERS
PRESENT TO BE TESTED >

UNIT 0

DEVICE ADDRESS (O) 172522 ? <ENTER THE ADDRESS OF THE
TSBA/TSDB REGISTER >

VECTOR (O) 224 ? <ENTER ADDRESS OF INTERRUPT
VECTOR >

THE ADDRESS AND VECTOR QUESTIONS WILL BE ASKED FOR EACH OF THE NUMBER OF UNITS (CONTROLLERS) SPECIFIED IN THE " UNITS ?" QUESTION. LOGICAL UNIT NUMBERS ARE ASSIGNED IN ORDR BEGINNING AT 0. UP TO EIGHT UNITS CAN BE SELECTED FOR TESTING.

3.3 SOFTWARE PARAMETERS

THE FOLLOWING QUESTIONS ARE ASKED ON A START, RESTART, OR CONTINUE. THEY ALLOW FLEXIBILITY IN THE WAY THE PROGRAM BEHAVES.

CHANGE SW (L) ? < TYPE "Y" TO CAUSE THE FOLLOWING
QUESTIONS TO BE ASKED.>

INHIBIT ITERATIONS (L) N ? < TYPE "Y" TO PREVENT MULTIPLE
ITERATIONS OF CERTAIN TESTS.
THIS CAUSES EACH TEST PASS TO
RUN AS QUICKLY AS POSSIBLE.
ONLY QUICK-RUNNING LOGIC
TESTS USE MULTIPLE ITERATIONS.>

ENABLE CONTROLLER RAM DUMP ON ERROR (L) N? < TYPE "Y" TO DUMP
SELECTED RAM CONTENTS IN THE
CONTROLLER MODULE.>

4.0 OPERATING INSTRUCTIONS - SAMPLE PRINTOUTS

4.1 SUCCESSUL RUN EXAMPLES

4.1.1 SUCCESSFUL RUN EXAMPLE - CZTKG -

TST: 001 SPACE RECORDS TEST
TST: 002 REREADS TEST
TST: 003 WRITE DATA RETRY TEST
TST: 004 WRITE TAPE MARK TEST
CZTKG EOP 1
 0 TOTAL ERRS

NOTE: PROGRAM NOW STARTS OVER AGAIN AT TEST 1

4.2 OPERATING INSTRUCTIONS - SAMPLE ERROR MESSAGES

ERROR MESSAGE EXAMPLE 1

TST: 001 SPACE RECORDS TEST
CZTKG WRD ERR 00120 ON UNIT 00 TST 001 SUB 003 PC: 025214
TAPE NOT AT BOT AFTER REWIND COMMAND

EXPD: 002022 RECV: 002020 XOR: 000002

ERROR MESSAGE EXAMPLE 2

CZTKG WRD ERR 00122 ON UNIT 00 TST 001 SUB 003 PC: 025332
TSSR NOT CORRECT AFTER POSITION (SPACE) COMMAND

TSSR=100306
TSSR BITS SET: SC, SSR, OFL
TERMINATION CODE = FUNCTION REJECT
*****CHECK CABLES BETWEEN CONTROLLER AND TRANSPORT*****
PACKET ADDRESS =030240
PACKET WORD #0 =140410
PACKET WORD #1 =000001
PACKET WORD #2 =000000
PACKET WORD #3 =000000

MESSAGE BUFFER ADDRESS =030130
MESSAGE BUFFER CONTENTS;
MESSAGE BUFFER HEADER =101021
DATA FIELD LENGTH =000012
RESIDUAL BYTE COUNTER =000000
XSTAT0 CONTENTS =000012
XSTAT1 CONTENTS =000000
XSTAT2 CONTENTS =001000
XSTAT3 CONTENTS =000040

5.0 PROGRAM RUN TIMES

THE AVERAGE RUN TIMES OF THE PROGRAMS ARE LISTED BELOW. THESE FIGURES ARE TO BE USED AS A GUIDE. THE TIMING WAS DONE ON A PDP-11/23 (LSI) PROCESSOR WITH A LA-120 CONSOLE.

THE PROGRAMS RUN IN NON-ITERATIVE MODE. EACH TEST IS RUN ONCE, WITH NO ITERATIONS. THEREFOR, THE DEFAULT MODE (NORMALLY ITERATIVE) AND THE NON-ITERATIVE MODE TIMES ARE IDENTICAL.

5.1 RUN TIMES - CZTKG

TEST NUMBER	N/I SECS.	DEF SECS.
1	65	65
2	130	130
3	120	120
4	35	35

THE TIMES REQUIRED TO RUN TESTS 1 THROUGH 4 TN ONE COMMAND:

Q.V.	5 MINS 50 SECONDS
DEFAULT	5 MINS 50 SECONDS

6.0 TEST DESCRIPTIONS - CZTKG

6.1 TEST 1 - SPACE RECORDS TEST

* NOTE: THIS TEST MUST HAVE A GOOD MAGTAPE IN THE DRIVE *
* ANY TAPE ERRORS WILL BE DISPLAYED AS TAPE STATUS ALERT *

THIS TEST VERIFIES THAT THE SPACE RECORDS FORWARD AND SPACE RECORDS REVERSE POSITION COMMANDS OPERATE PROPERLY WHEN SPACING OVER NORMAL DATA RECORDS. OPERATION WHEN SPACING OVER TAPE MARKS IS VERIFIED IN A SUBSEQUENT TEST. THE BASIC WRITE DATA TEST SHOULD HAVE BEEN RUN SUCCESSFULLY FOR THIS TEST TO PRODUCE MEANINGFUL RESULTS. THIS TEST CONSISTS OF A SERIES OF SUBTESTS. IN EACH OF THE SUBTESTS, THE TAPE IS ENTIRELY WRITTEN WITH RECORDS OF VARYING SIZES AND DATA CONTENT; THE FIRST 4 BYTES OF EACH RECORD INDICATE THAT RECORD'S RELATIVE POSITION ON TAPE. AFTER EACH SPACING OPERATION, THE TAPE POSITION IS VERIFIED BY READING THE NEXT OR PREVIOUS RECORD AND COMPARING THE POSITION DATA WITH THE EXPECTED RESULT.

6.1.1 TEST 1, SUBTEST 1: -

THIS SUBTEST VERIFIES THAT A SPACE RECORDS FORWARD COMMAND WITH THE CLEAR VOLUME CHECK (CVC) BIT CLEAR IS REJECTED IF THE VOLUME CHECK FLAG (VCK) IS SET.

6.1.2 TEST 1, SUBTEST 2: -

THIS SUBTEST VERIFIES THAT A SPACE RECORDS REVERSE COMMAND WITH THE CLEAR VOLUME CHECK (CVC) BIT CLEAR IS REJECTED IF THE VOLUME CHECK (VCK) FLAG IS SET.

6.1.3 TEST 1, SUBTEST 3: -

THIS SUBTEST VERIFIES THAT SPACE RECORDS FORWARD CAN SPACE ONE RECORD OFF BOT AND CAUSE BOT STATUS TO BE CLEARED.

6.1.4 TEST 1, SUBTEST 4: -

THIS SUBTEST VERIFIES THAT SPACE RECORDS REVERSE CAN SPACE BACK OVER THE FIRST RECORD ON TAPE.

6.1.5 TEST 1, SUBTEST 5: -

THIS SUBTEST VERIFIES THAT SPACE RECORDS FORWARD CAN SPACE A MULTIPLE NUMBER OF RECORDS (2 THROUGH 64K, OR THE MAXIMUM NUMBER OF RECORDS WRITTEN ON THE TAPE, WHICHEVER IS LESS.).

6.1.6 TEST 1, SUBTEST 6: -

THIS SUBTEST VERIFIES THAT SPACE RECORDS REVERSE CAN SPACE A MULTIPLE NUMBER OF RECORDS (2 THROUGH 64K, OR THE MAXIMUM NUMBER OF RECORDS WRITTEN ON THE TAPE, WHICH EVER IS LESS).

6.1.7 TEST 1, SUBTEST 7: -

THIS SUBTEST VERIFIES THAT SPACE RECORDS REVERSE ISSUED WHILE TAPE IS AT BOT RESULTS IN FUNCTION REJECT TERMINATION WITH THE NONEXECUTABLE FUNCTION (NEF) ERROR BIT SET.

6.1.8 TEST 1, SUBTEST 8: -

THIS SUBTEST VERIFIES THAT A SPACE RECORDS REVERSE COMMAND THAT CAUSES THE TAPE TO RUN INTO BOT (WITH THE TAPE NOT INITIALLY AT BOT) CAUSES A TAPE STATUS ALERT TERMINATION AND SETS THE REVERSE INTO BOT (RIB) STATUS BIT.

6.2 TEST 2 - REREADS TEST

THIS TEST VERIFIES THAT THE REREAD PREVIOUS AND REREAD NEXT COMMANDS OPERATE PROPERLY. VARIOUS COMBINATIONS OF ODD AND EVEN DATA BUFFER BOUNDARIES, RECORD SIZES (UP TO 64K BYTES IF MEMORY SPACE IS AVAILABLE), AND BYTE-SWAP (SWP) AND OPPOSITE (OPP) CONTROL ARE USED. ALSO TESTED ARE PROPER TERMINATIONS ON EXCEPTIONAL OR ERROR CONDITIONS: RECORD LENGTH LONG, RECORD LENGTH SHORT, READ REVERSE AT BOT, ILLEGAL DATA BUFFER ADDRESSES, AND DATA BUFFERS IN NONEXISTENT MEMORY.

6.2.1 TEST 2, SUBTEST 1: -

THIS SUBTEST VERIFIES THAT THE REREAD PREVIOUS COMMAND WITH OPP=0 AND SWB=0 OPERATES PROPERLY. THE TAPE IS FIRST REWOUND AND THEN WRITTEN WITH A SERIES OF TAPE RECORDS VARYING IN LENGTH AND DATA CONTENT. THE TAPE IS THEN REWOUND AGAIN. FOR EACH RECORD THE TAPE IS SPACED FORWARD ONE RECORD AND THE REREAD PREVIOUS COMMAND IS ISSUED. RESULTS (STATUS, DATA, ETC.) ARE VERIFIED. THE BYTE COUNT ON EACH REREAD PREVIOUS COMMAND IS SET TO THE LENGTH OF THE EXPECTED RECORD, SO NO EXCEPTIONAL CONDITIONS SHOULD OCCUR.

6.2.2 TEST 2, SUBTEST 2: -

THIS SUBTEST VERIFIES THAT THE REREAD PREVIOUS COMMAND WITH OPP=0 AND SWB=1 OPERATES PROPERLY. THE TEST SEQUENCE IS THE SAME AS THAT USED IN SUBTEST 1, BUT IT IS VERIFIED THAT DATA STORED BY THE COMMAND CONTAINS SWAPPED BYTES.

6.2.3 TEST 2, SUBTEST 3: -

THIS SUBTEST VERIFIES THAT THE REREAD PREVIOUS COMMAND WITH OPP=1 (READ REVERSE, SPACE FORWARD) AND SWB=0 OPERATES PROPERLY. THE TAPE IS FIRST REWOUND, AND THEN WRITTEN WITH A SERIES OF TEST RECORDS OF VARYING LENGTH AND DATA CONTENT; THE FIRST FOUR BYTES OF EACH RECORD CONTAIN ITS RECORD NUMBER (INDICATING POSITION ON TAPE). THE TAPE IS THEN REWOUND AGAIN. FOR EACH TEST RECORD THE FOLLOWING SEQUENCE IS EXECUTED:

1. THE REREAD PREVIOUS COMMAND WITH OPP=1 IS ISSUED AND THE RESULTS ARE CHECKED.
2. A READ FORWARD COMMAND IS THEN ISSUED AND THE DATA IS CHECKED TO VERIFY THAT THE TAPE WAS POSITIONED PROPERLY AFTER THE REREAD PREVIOUS COMMAND (E.G. THE TAPE SHOULD HAVE BEEN LEFT POSITIONED AT THE START OF THE TEST RECORD.). THE READ FORWARD COMMAND LEAVES THE TAPE POSITIONED PROPERLY AT THE START OF THE NEXT RECORD.

THE BYTE COUNT ON EACH REREAD PREVIOUS COMMAND IS SET TO THE LENGTH OF THE EXPECTED RECORD, SO NO EXCEPTIONAL CONDITIONS SHOULD OCCUR.

6.2.4 TEST 2, SUBTEST 4: -

THIS SUBTEST VERIFIES THAT THE REREAD PREVIOUS COMMAND WITH OPP=1 AND SWB=1 OPERATES PROPERLY. THE TEST SEQUENCE IS THE SAME AS THAT USED IN SUBTEST 3, BUT IT IS VERIFIED THAT DATA STORED BY THE COMMAND CONTAINS SWAPPED BYTES.

6.2.5 TEST 2, SUBTEST 5: -

THIS SUBTEST VERIFIES THAT A REREAD PREVIOUS COMMAND READING A RECORD LONGER THAN THE SPECIFIED BYTE COUNT CAUSES TAPE STATUS ALERT TERMINATION WITH THE RECORD LENGTH LONG (RL) BIT SET. RESULTS ARE VERIFIED FOR BOTH STATES OF OPP (0 AND 1).

6.2.6 TEST 2, SUBTEST 6: -

THIS SUBTEST VERIFIES THAT A REREAD PREVIOUS COMMAND READING A RECORD SHORTER THAN THE SPECIFIED BYTE COUNT CAUSES TAPE STATUS ALERT TERMINATION WITH THE RECORD LENGTH SHORT (RLS) BIT SET. IT IS VERIFIED THAT THE RESIDUAL BYTE COUNTER (RBPCR) IN THE MESSAGE BUFFER CONTAINS THE APPROPRIATE NONZERO VALUE (E.G THE DIFFERENCE BETWEEN THE ORIGINAL BYTE COUNT AND THE ACTUAL RECORD LENGTH). RESULTS ARE VERIFIED FOR BOTH STATES OF OPP (0 AND 1).

6.2.7 TEST 2, SUBTEST 7: -

THIS SUBTEST VERIFIES THAT THE REREAD NEXT COMMAND WITH OPP=0 AND SWB=0 OPERATES PROPERLY. THE TAPE IS FIRST REWOUND AND THEN WRITTEN WITH A SERIES OF TEST RECORDS OF VARYING LENGTH AND DATA CONTENT. THE TAPE IS THEN REWOUND AGAIN. FOR EACH TEST RECORD THE TAPE IS SPACED FORWARD ONE RECORD AND A REREAD NEXT COMMAND IS ISSUED. RESULTS (STATUS, DATA, ETC.) ARE VERIFIED. THE BYTE COUNT ON EACH REREAD NEXT COMMAND IS SET TO THE LENGTH OF THE EXPECTED RECORD, SO NO EXCEPTIONAL CONDITIONS SHOULD OCCUR.

6.2.8 TEST 2, SUBTEST 8: -

THIS SUBTEST VERIFIES THAT THE REREAD NEXT COMMAND WITH OPP=0 AND SWB=1 OPERATES PROPERLY. THE TEST SEQUENCE IS THE SAME AS THAT USED IN SUBTEST 1, BUT IT IS VERIFIED THAT DATA STORED BY THE COMMAND CONTAINS SWAPPED BYTES.

6.2.9 TEST 2, SUBTEST 9: -

THIS SUBTEST VERIFIES THAT THE REREAD NEXT COMMAND WITH OPP=1 (READ FORWARD, SPACE REVERSE) AND SWB=0 OPERATES PROPERLY. THE TAPE IS FIRST REWOUND AND THEN WRITTEN WITH A SERIES OF TAPE RECORDS VARYING IN LENGTH AND DATA CONTENT; THE FIRST FOUR BYTES OF EACH RECORD CONTAIN ITS RECORD NUMBER (INDICATING POSITION ON TAPE). THE TAPE IS THEN REWOUND AGAIN. FOR EACH TEST RECORD THE FOLLOWING SEQUENCE IS EXECUTED:

1. THE REREAD NEXT COMMAND WITH OPP=1 IS ISSUED AND THE RESULT IS CHECKED.
2. A READ FORWARD COMMAND IS THEN ISSUED AND THE DATA IS CHECKED TO VERIFY THAT THE TAPE WAS POSITIONED PROPERLY AFTER THE REREAD NEXT COMMAND (E.G. THE TAPE SHOULD HAVE BEEN LEFT POSITIONED AT THE START OF THE TEST RECORD). THE READ FORWARD COMMAND LEAVES THE TAPE POSITIONED PROPERLY AT THE START OF THE NEXT TEST RECORD.

THE BYTE COUNT ON EACH REREAD NEXT COMMAND IS SET TO THE LENGTH OF THE EXPECTED RECORD, SO NO EXCEPTIONAL CONDITIONS SHOULD OCCUR.

6.2.10 TEST 2, SUBTEST 10: -

THIS SUBTEST VERIFIES THAT THE REREAD NEXT COMMAND WITH OPP=1 AND SWB=1 OPERATES PROPERLY. THE TEST SEQUENCE IS THE SAME AS THAT USED IN SUBTEST 3, BUT IT IS VERIFIED THAT DATA STORED BY THE COMMAND CONTAINS SWAPPED BYTES.

6.2.11 TEST 2, SUBTEST 11: -

THIS SUBTEST VERIFIES THAT A REREAD NEXT COMMAND READING A RECORD LONGER THAN THE SPECIFIED BYTE COUNT CAUSES TAPE STATUS ALERT TERMINATION WITH THE RECORD LENGTH LONG (RLL) BIT SET. RESULTS ARE VERIFIED FOR BOTH STATES OF OPP (1 AND 0).

6.2.12 TEST 2, SUBTEST 12: -

THIS SUBTEST VERIFIES THAT A REREAD NEXT COMMAND READING A RECORD SHORTER THAN THE SPECIFIED BYTE COUNT CAUSES TAPE STATUS ALERT TERMINATION WITH THE RECORD LENGTH SHORT (RLS) BIT SET. IT IS VERIFIED THAT THE RESIDUAL BYTE COUNTER IN THE MESSAGE BUFFER CONTAINS THE PROPER NONZERO MESSAGE (E.G. THE DIFFERENCE BETWEEN THE ORIGINAL BYTE COUNT AND THE ACTUAL RECORD LENGTH). RESULTS ARE VERIFIED FOR BOTH STATES OF OPP (0 AND 1).

6.2.13 TEST 2, SUBTEST 13: -

THIS SUBTEST VERIFIES THAT A DATA BUFFER ADDRESS REFERENCING NONEXISTANT MEMORY RECOVERABLE ERROR TERMINATION (TC=4 OR 5) WITH NXM=1 AND THAT THE TAPE IS ULTIMATELY POSITIONED PROPERLY. ALL COMBINATIONS OF REREAD PREVIOUS/NEXT AND OPP=0/1 ARE TESTED.

6.2.14 TEST 2, SUBTEST 14: -

THIS SUBTEST VERIFIES THAT THE REREAD PREVIOUS WITH OPP=0 (SPACE REVERSE, READ FORWARD) AND REREAD PREVIOUS WITH OPP=1 (READ REVERSE SPACE FORWARD) ISSUED WHEN THE TAPE IS POSITIONED AT BOT CAUSES FUNCTION REJECT TERMINATION WITH THE NONEXECUTABLE FUNCTION (NEF) ERROR BIT SET.

6.2.15 TEST 2, SUBTEST 15: -

THIS SUBTEST VERIFIES THAT THE REREAD PREVIOUS WITH OPP=1 (SPACE REVERSE, READ FORWARD) AND REREAD PREVIOUS WITH OPP=0 (READ REVERSE, SPACE FORWARD) ISSUED WHEN THE TAPE POSITIONED JUST BEFORE THE FIRST RECORD ON TAPE (BUT NOT AT BOT) CAUSES TAPE STATUS ALERT TERMINATION WITH THE REVERSE INTO BOT (RIB) STATUS BIT SET.

6.3 TEST 3 - WRITE DATA RETRY TEST

* NOTE: THIS TAPE MUST HAVE A GOOD MAGTAPE IN THE DRIVE *
* ANY TAPE ERRORS WILL BE DISPLAYED AS TAPE STATUS ALERT. *

THIS TEST VERIFIES PROPER OPERATION OF THE WRITE DATA RETRY COMMAND (SPACE REVERSE, ERASE, WRITE DATA). THE TEST CONSISTS OF THE FOLLOWING FIVE SUBTESTS.

6.3.1 TEST 3, SUBTEST 1: -

THIS SUBTEST VERIFIES THAT A WRITE DATA RETRY COMMAND ISSUED WHILE THE TAPE IS POSITIONED AT BOT CAUSES FUNCTION REJECT TERMINATION WITH THE NON-EXECUTABLE FUNCTION (NEF) ERROR BIT SET.

6.3.2 TEST 3, SUBTEST 2: -

THIS SUBTEST VERIFIES THAT A WRITE DATA RETRY COMMAND ISSUED WHILE THE TAPE IS POSITIONED BEFORE THE FIRST RECORD ON TAPE (BUT NOT AT BOT) CAUSES TAPE STATUS ALERT TERMINATION, WITH THE REVERSE INTO BOT (RIB) STATUS ERROR BIT SET.

6.3.3 TEST 3, SUBTEST 3: -

THIS SUBTEST VERIFIES THAT A WRITE DATA RETRY COMMAND WITH SWB=0 TERMINATES PROPERLY AND WRITES CORRECT DATA ON TAPE (THE WRITTEN RECORD IS READ AND CHECKED). VARIOUS BYTE COUNTS AND DATA PATTERNS ARE USED.

6.3.4 TEST 3, SUBTEST 4: -

THIS SUBTEST VERIFIES THAT A WRITE DATA RETRY COMMAND WITH SWB=1 TERMINATES PROPERLY AND WRITES CORRECT DATA ON TAPE (THE WRITTEN RECORD IS READ AND CHECKED). VARIOUS BYTE COUNTS AND DATA PATTERNS ARE USED.

6.3.5 TEST 3, SUBTEST 5: -

THIS SUBTEST VERIFIES THAT A WRITE DATA RETRY COMMAND IS PERFORMING THE ERASE PART OF THE OPERATION BY COMPLETING THE FOLLOWING STEPS:

1. THE TAPE IS REWOUND AND A SERIES OF RECORDS ARE WRITTEN WITH THE NORMAL WRITE DATA COMMAND. THIS SHOULD RESULT IN RECORDS

SEPERATED BY THE STANDARD INTERRECORD GAP.

2. A PROGRAM TIMING VALUE IS CALIBRATED BY REWINDING THE TAPE AND THEN CONTINUING THE NUMBER OF CYCLES THROUGH A PROGRAMMED LOOP REQUIRED TO SPACE OVER THE SERIES OF RECORDS WRITTEN IN THE PREVIOUS STEP.
3. THE TAPE IS AGAIN REWOUND AND THE SAME SERIES OF RECORDS WRITTEN AGAIN, THIS TIME USING THE WRITE DATA RETRY COMMAND. THIS SHOULD RESULT IN RECORDS SEPERATED BY A A LONG INTERRECORD GAP.
4. THE TAPE IS AGAIN REWOUND, THE SPACING COMMAND ISSUED, AND THE NUMBER OF TIMING LOOP CYCLES COUNTED TO COMPLETE THE OPERATION.
5. THE TWO LOOPS ARE COMPARED, CHECKING TO SEE THAT THEY DIFFER BY A SIGNIFICANT AMOUNT.

6.4 TEST 4 - WRITE/READ TAPE MARK

* NOTE; THIS TEST MUST HAVE A GOOD MAGTAPE IN THE DRIVE *
* ANY TAPE ERRORS WILL BE DISPLAYED AS A TAPE STATUS ALERT *

THIS TEST VERIFIES THAT THE WRITE TAPE MARK COMMAND OPERATES PROPERLY. IT IS VERIFIED THAT THE TAPE MARK IS WRITTEN ONTO TAPE BY CHECKING THAT THE READ AND SPACE RECORDS COMMANDS DETECT THE TAPE MARK. IN ADDITION, SINCE WRITE TAPE MARK IS THE FIRST SUBCOMMAND UNDER THE FORMAT COMMAND BEING TESTED, IT IS VERIFIED THAT THE CLEAR VOLUME CHECK (CVC) BIT OPERATES PROPERLY AND THAT FORMAT COMMANDS WITH ILLEGAL MODE CODES ARE REJECTED.

6.4.1 TEST 4, SUBTEST 1: -

THIS SUBTEST VERIFIES THAT A FORMAT COMMAND (WITH ANY LEGAL MODE CODE) WITH THE CLEAR VOLUME CHECK (CVC) BIT CLEAR IS REJECTED IF THE VOLUME CHECK (VCK) FLAG IS SET. ALL VALID MODE CODES ARE CHECKED.

6.4.2 TEST 4, SUBTEST 2: -

THIS SUBTEST VERIFIES THAT A FORMAT COMMAND WITH AN ILLEGAL MODE CODE CAUSES FUNCTION REJECT TERMINATION WITH THE ILLEGAL COMMAND (ILC) ERROR BIT SET. ALL ILLEGAL MODE CODES ARE CHECKED.

6.4.3 TEST 4, SUBTEST 3: -

THIS SUBTEST VERIFIES THAT WRITE TAPE MARK COMMANDS OPERATE PROPERLY, AND THAT READ COMMANDS SUBSEQUENTLY ISSUED TO DETECT THE WRITTEN TAPE MARKS TERMINATE WITH TAPE STATUS ALERT AND THE TAPE MARK DETECTED (TMK) STATUS BIT SET. THE FOLLOWING SEQUENCE IS EXECUTED:

1. THE CONTROLLER IS INITIALIZED AND THE TAPE REWOUND. THIS SETS THE VOLUME CHECK (VCK) STATUS BIT.
2. A WRITE TAPE MARK COMMAND, WITH CVC=1, IS ISSUED AND PROPER TERMINATION AND STATUS IS VERIFIED (I.E. VCK=0, AND TMK=1).
3. SEVERAL MORE WRITE TAPE MARK COMMANDS, THESE WITH CVC=0, ARE ISSUED AND PROPER TERMINATION (NORMAL) AND STATUS (TMK) VERIFIED.
4. A READ REVERSE COMMAND IS ISSUED AND PROPER TERMINATION (TAPE STATUS ALERT) AND STATUS (TMK) VERIFIED. IT IS ALSO VERIFIED THAT NO DATA IS TRANSFERRED INTO MEMORY.
5. A SPACE RECORDS REVERSE COMMAND IS ISSUED AND PROPER TERMINATION

(TAPE STATUS ALERT) AND STATUS (TMK) VERIFIED.

6. THE TAPE IS REWOUND AND A READ FORWARD COMMAND IS ISSUED AND PROPER TERMINATION (TAPE STATUS ALERT) AND STATUS (TMK) VERIFIED. IT IS ALSO VERIFIED THAT NO DATA IS TRANSFERRED INTO MEMORY.
7. A SPACE RECORDS REVERSE COMMAND THAT CONTAINS A RECORD COUNT GREATER THAN 1 IS ISSUED, AND IT IS VERIFIED THAT TAPE STATUS ALERT TERMINATION OCCURED, TMK=1 AND THAT RBPCR (RESIDUAL BYTE/RECORD COUNTER) CONTAINS THE PROPER NONZERO VALUE. THIS OPERATION VERIFIES THAT DETECTION OF THE TAPE MARK CAUSE THE SPACE RECORDS OPERATION TO BE PREMATURELY TERMINATED. THIS SHOULD LEAVE THE DEVICE POSITIONED JUST BEFORE THE FIRST RECORD ON THE TAPE.
8. TAPE POSITION IS VERIFIED BY ISSUING ANOTHER SPACE RECORDS REVERSE COMMAND AND VERIFYING THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH THE REVERSE INTO BOT (RIB) ERROR STATUS BIT SET.
9. A SPACE RECORDS FORWARD COMMAND THAT CONTAINS A RECORD GREATER THAN 1 IS ISSUED AND IT IS VERIFIED THAT TAPE STATUS ALERT TERMINATION OCCURED, TMK=1, AND THAT RBPCR (RESIDUAL BYTE/RECORD COUNTER) CONTAINS THE PROPER NONZERO VALUE. THIS OPERATION VERIFIES THAT DETECTION OF THE TAPE MARK CAUSES THE SPACE RECORDS OPERATIONS TO PREMATURELY TERMINATE.

```

752          .SBTTL PROGRAM HEADER
758          .MCALL SVC
759 000000          SVC ; INITIALIZE SUPERVISOR MACROS
760          .ENABLE LC
761          .NLIST BEX,CND
767 000000          .ENABL AMA,ABS
768          . = 2000
769 002000          BGNMOD TUV2A
          002000          TUV2A::
770
771          ;++
772          ; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
773          ; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
774          ;--
775
776
777 002000          POINTER BGNSW,BGNSFT,BGNAU,BGNDU,BGNRPT,BGNSETUP
778 002000          HEADER CZTKG,A,0,655,.0
          002000          L$NAME:: ;DIAGNOSTIC NAME
          002000          103 .ASCII /C/
          002001          132 .ASCII /Z/
          002002          124 .ASCII /T/
          002003          113 .ASCII /K/
          002004          107 .ASCII /G/
          002005          000 .BYTE
          002006          000 .BYTE 0
          002007          000 .BYTE 0
          002010          L$REV:: ;REVISION LEVEL
          002010          101 .ASCII //
          002011          L$DEP:: ;0
          002011          060 .ASCII /0/
          002012          L$UNIT:: ;NUMBER OF UNITS
          002012          000001 .WORD T$PTHV
          002014          L$TIML:: ;LONGEST TEST TIME
          002014          001217 .WORD 655.
          002016          L$HPCP:: ;PTR. TO H.W. QUES.
          002016          065460 .WORD L$HARD
          002020          L$SPCP:: ;PTR. TO S.W. QUES.
          002020          065620 .WORD L$SOFT
          002022          L$HPTP:: ;PTR. TO DEF. H.W. PTABLE
          002022          002124 .WORD L$HW
          002024          L$SPTP:: ;PTR. TO S.W. PTABLE
          002024          002134 .WORD L$SW
          002026          L$LADP:: ;DIAG. END ADDRESS
          002026          066026 .WORD L$LAST
          002030          L$STA:: ;RESERVED FOR APT STATS
          002030          000000 .WORD 0
          002032          L$CO::
          002032          000000 .WORD 0
          002034          L$DTYP:: ;DIAGNOSTIC TYPE
          002034          000000 .WORD 0
          002036          L$APT:: ;APT EXPANSION
          002036          000000 .WORD 0
          002040          L$DTP:: ;PTR. TO DISPATCH TABLE
          002040          066012 .WORD L$DISPATCH
          002042          L$PRIO:: ;DIAGNOSTIC RUN PRIORITY
          002042          000000 .WORD 0

```

002044		L\$ENVI::			;FLAGS DESCRIBE HOW IT WAS SETUP
002044	000000		.WORD	0	
002046		L\$EXP1::			;EXPANSION WORD
002046	000000		.WORD	0	
002050		L\$MREV::			;SVC REV AND EDIT #
002050	003		.BYTE	C\$REVISION	
002051	003		.BYTE	C\$EDIT	
002052		L\$EF::			;DIAG. EVENT FLAGS
002052	000000		.WORD	0	
002054	000000		.WORD	0	
002056		L\$SPC::			
002056	000000		.WORD	0	
002060		L\$DEVP::			; POINTER TO DEVICE TYPE LIST
002060	003334		.WORD	L\$DVTYP	
002062		L\$REPP::			;PTR. TO REPORT CODE
002062	023066		.WORD	L\$RPT	
002064		L\$EXP4::			
002064	000000		.WORD	0	
002066		L\$EXP5::			
002066	000000		.WORD	0	
002070		L\$AUT::			;PTR. TO ADD UNIT CODE
002070	022560		.WORD	L\$AU	
002072		L\$DUT::			;PTR. TO DROP UNIT CODE
002072	022656		.WORD	L\$DU	
002074		L\$LUN::			;LUN FOR EXERCISERS TO FILL
002074	000000		.WORD	0	
002076		L\$DESP::			;POINTER TO DIAG. DESCRIPTION
002076	003342		.WORD	L\$DESC	
002100		L\$LOAD::			;GENERATE SPECIAL AUTOLOAD EMT
002100	104035		EMT	E\$LOAD	
002102		L\$ETP::			;POINTER TO ERRYBL
002102	000000		.WORD	0	
002104		L\$ICP::			;PTR. TO INIT CODE
002104	022000		.WORD	L\$INIT	
002106		L\$CCP::			;PTR. TO CLEAN-UP CODE
002106	023040		.WORD	L\$CLEAN	
002110		L\$ACP::			;PTR. TO AUTO CODE
002110	022764		.WORD	L\$AUTO	
002112		L\$PRT::			;PTR. TO PROTECT TABLE
002112	021770		.WORD	L\$PROT	
002114		L\$TEST::			;TEST NUMBER
002114	000000		.WORD	0	
002116		L\$DLY::			;DELAY COUNT
002116	000000		.WORD	0	
002120		L\$HIME::			;PTR. TO HIGH MEM
002120	000000		.WORD	0	

```

780                                     .SBTTL  DEFAULT HARDWARE P-TABLE
781
782                                     ;**
783                                     ; THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
784                                     ; THE TEST-DEVICE PARAMETERS. THE STRUCTURE OF THIS TABLE
785                                     ; IS IDENTICAL TO THE STRUCTURE OF THE RUN-TIME P-TABLE.
786                                     ;--
787 002122                               BGNHW   DFPTBL   ;DEFAULT HARD-P-TABLE
      002122 000003                       .WORD   L10000-L$HW/2
      002124                               L$HW::
      002124                               DFPTBL.:
788
789 002124 172522                       .WORD   172522   ; 2ND (OF 2) REGISTERS.
790 002126 000224                       .WORD   224     ; INTERRUPT VECTOR
791 002130 000240                       .WORD   PRI05  ; INTERRUPT PRIORITY.
792 002132                               ENDDHW
      002132                               L10000:

```

```

794          .SBTTL  SOFTWARE P-TABLE
795
796          ;**
797          ; THE SOFTWARE P-TABLE CONTAINS THE VALUES OF THE PROGRAM
798          ; PARAMETERS THAT CAN BE CHANGED BY THE OPERATOR.
799          ;--
800 002132      BGNSW   SFPTBL
          002132 000004 .WORD   L10001-L#SW/2
          002134
          002134
801
802 002134 000000  TRANSTST:: .WORD 0      ;ENABLE RAM DUMP IF =1
803 002136 000000  NOITS::   .WORD 0      ; INHIBIT ITERATION OPTION.
804
805          ; ... 0 = ITERATE.
806 002140 000031  LERRMAX:: .WORD 25.   ; ...NZ = INHIBIT ITERATE.
807 002142 000310  GERRMAX:: .WORD 200.  ; LOCAL (PER TEST) ERROR LIMIT
808 002144
          END SW      ; GLOBAL (PER UNIT) ERROR LIMIT
          L10001:
809

```


812
819
824
830
831
832
833
834
835
836
837
838
839

843 002144

.SBTTL GLOBAL EQUATES SECTION

.SBTTL GLOBAL EQUATES SECTION

;++
; THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
; ARE USED IN MORE THAN ONE TEST.
;--

EQUALS ; GET STANDARD EQUATES.

; BIT DEFINITIONS

100000	BIT15--	100000
040000	BIT14--	40000
020000	BIT13--	20000
010000	BIT12--	10000
004000	BIT11--	4000
002000	BIT10--	2000
001000	BIT09--	1000
000400	BIT08--	400
000200	BIT07--	200
000100	BIT06--	100
000040	BIT05--	40
000020	BIT04--	20
000010	BIT03--	10
000004	BIT02--	4
000002	BIT01--	2
000001	BIT00--	1

001000	BIT9--	BIT09
000400	BIT8--	BIT08
000200	BIT7--	BIT07
000100	BIT6--	BIT06
000040	BIT5--	BIT05
000020	BIT4--	BIT04
000010	BIT3--	BIT03
000004	BIT2--	BIT02
000002	BIT1--	BIT01
000001	BIT0--	BIT00

; EVENT FLAG DEFINITIONS

; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION

000040	EF.START--	32.	; START COMMAND WAS ISSUED
000037	EF.RESTART--	31.	; RESTART COMMAND WAS ISSUED
000036	EF.CONTINUE--	30.	; CONTINUE COMMAND WAS ISSUED
000035	EF.NEW--	29.	; A NEW PASS HAS BEEN STARTED
000034	EF.PWR--	28.	; A POWER-FAIL/POWER-UP OCCURRED

; PRIORITY LEVEL DEFINITIONS

000340	PRI07== 340
000300	PRI06== 300
000240	PRI05== 240
000200	PRI04== 200
000140	PRI03== 140
000100	PRI02== 100
000040	PRI01== 40
000000	PRI00== 0

; OPERATOR FLAG BITS

000004	EVL== 4
000010	LOT== 10
000020	ADR== 20
000040	IDU== 40
000100	ISR== 100
000200	UAM== 200
000400	BOE== 400
001000	PNT== 1000
002000	PRI== 2000
004000	IXE== 4000
010000	IGE== 10000
020000	IER== 20000
040000	LOE== 40000
100000	HOE== 100000

844
845 002144

KT11 ; DEFINE MEMORY MANAGEMENT REGISTERS

.SBITL MEMORY MANAGEMENT DEFINITIONS

; *KT11 VECTOR ADDRESS

000250 MMVEC= 250

; *KT11 STATUS REGISTER ADDRESSES

177572 SR0= 177572

177574 SR1= 177574

177576 SR2= 177576

172516 SR3= 172516

.IF NB

; *USER "I" PAGE DESCRIPTOR REGISTERS

UIPDR0= 177600

UIPDR1= 177602

UIPDR2= 177604

UIPDR3= 177606

UIPDR4= 177610

UIPDR5= 177612

UIPDR6= 177614

UIPDR7= 177616

.IF NB

; *USER "D" PAGE DESCRIPTOR REGISTERS

UDPDR0= 177620

UDPDR1= 177622

UDPDR2= 177624

UDPDR3= 177626

UDPDR4= 177630

UDPDR5= 177632

UDPDR6= 177634

UDPDR7= 177636

.ENCC

; *USER "I" PAGE ADDRESS REGISTERS

```
UIPAR0= 177640
UIPAR1= 177642
UIPAR2= 177644
UIPAR3= 177646
UIPAR4= 177650
UIPAR5= 177652
UIPAR6= 177654
UIPAR7= 177656
  .IF NB
  ;*USER "D" PAGE ADDRESS REGISTERS
  UDPAR0= 177660
  UDPAR1= 177662
  UDPAR2= 177664
  UDPAR3= 177666
  UDPAR4= 177670
  UDPAR5= 177672
  UDPAR6= 177674
  UDPAR7= 177676
  .ENDC
  .IF NB
  ;*SUPERVISOR "I" PAGE DESCRIPTOR REGISTERS
  SIPDR0= 172200
  SIPDR1= 172202
  SIPDR2= 172204
  SIPDR3= 172206
  SIPDR4= 172210
  SIPDR5= 172212
  SIPDR6= 172214
  SIPDR7= 172216
  .IF NB
  ;*SUPERVISOR "D" PAGE DESCRIPTOR REGISTERS
  SDPDR0= 172220
  SDPDR1= 172222
  SDPDR2= 172224
  SDPDR3= 172226
  SDPDR4= 172230
  SDPDR5= 172232
  SDPDR6= 172234
  SDPDR7= 172236
  .ENDC
  ;*SUPERVISOR "I" PAGE ADDRESS REGISTERS
  SIPAR0= 172240
  SIPAR1= 172242
  SIPAR2= 172244
  SIPAR3= 172246
  SIPAR4= 172250
  SIPAR5= 172252
  SIPAR6= 172254
  SIPAR7= 172256
  .IF NB
  ;*SUPERVISOR "D" PAGE ADDRESS REGISTERS
  SDPAR0= 172260
  SDPAR1= 172262
  SDPAR2= 172264
  SDPAR3= 172266
  SDPAR4= 172270
```

```

SDPAR5= 172272
SDPAR6= 172274
SDPAR7= 172276
.ENDC
.ENDC
; *KERNEL "I" PAGE DESCRIPTOR REGISTERS
172300 KIPDR0= 172300
172302 KIPDR1= 172302
172304 KIPDR2= 172304
172306 KIPDR3= 172306
172310 KIPDR4= 172310
172312 KIPDR5= 172312
172314 KIPDR6= 172314
172316 KIPDR7= 172316
; IF NB
; *KERNEL "D" PAGE
DESCRIPTOR REGISTERS
KDPDR0= 172320
KDPDR1= 172322
KDPDR2= 172324
KDPDR3= 172326
KDPDR4= 172330
KDPDR5= 172332
KDPDR6= 172334
KDPDR7= 172336
.ENDC
; *KERNEL "I" PAGE ADDRESS REGISTERS
172340 KIPAR0= 172340
172342 KIPAR1= 172342
172344 KIPAR2= 172344
172346 KIPAR3= 172346
172350 KIPAR4= 172350
172352 KIPAR5= 172352
172354 KIPAR6= 172354
172356 KIPAR7= 172356
; IF NB
; *KERNEL "D" PAGE ADDRESS REGISTERS
KDPAR0= 172360
KDPAR1= 172362
KDPAR2= 172364
KDPAR3= 172366
KDPAR4= 172370
KDPAR5= 172372
KDPAR6= 172374
KDPAR7= 172376
.ENDC

```

```

      .SBTTL TK-25 REGISTER AND PACKET DEFINITIONS
850
851
852
853      ; SOME GENERAL EQUATES.
854
855
856      000004      ERRVEC==      4      ; POINTER TO ERROR VECTOR FOR BUS TIME OUT.
857      000060      TTIVEC==     60      ; INTERRUPT VECTOR FOR CONSOLE INPUT
858      177560      TTICSR==    177560   ; BUS ADDRESS OF CONSOLE INPUT
859      177562      TTIBFR==    177562   ; CONSOLE INPUT DATA BUFFER
860
861
862      ;*
863      ;BIT DEFINITIONS FOR TSSR REGISTER
864      ;-
865      100000      SC=          BIT15     ;SPECIAL CONDITION
866      040000      BIE=        BIT14     ;BUS INTERFACE ERROR
867      020000      SCE=        BIT13     ;SANITY CHECK ERROR
868      010000      RMR=        BIT12     ;MODIFICATION REFUSED
869      004000      NXM=        BIT11     ;NONEXISTANT MEMORY ERROR
870      002000      NBA=        BIT10     ;NEED BUFFER ADDRESS
871      001400      HIADDR=    BIT9:BIT8  ;EXTENDED ADDRESS BITS
872      000200      SSR=        BIT7      ;SUB SYSTEM READY
873      000100      OFL=        BIT6      ;OFF LINE BIT
874      000060      FATERR=    BIT4:BIT5  ;FATAL TERMINATION ERROR CODES
875      000016      TERCLS=    BIT3:BIT2:BIT1 ;TERMINATION CODES
876
877
878
879      ;*
880      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 0
881      ;(XST0)
882      ;
883      ;-
884
885      100000      XSOTMK=     BIT15     ;TAPE MARK DETECTED
886      040000      XSORLS=    BIT14     ;RECORD LENGTH SHORT
887      020000      XSOLEY=    BIT13     ;LOGICAL END OF TAPE
888      010000      XSORLL=    BIT12     ;RECORD LENGTH LONG
889      004000      XSOWLE=    BIT11     ;WRITE LOCK ERROR
890      002000      XSONEF=    BIT10     ;NON EXECUTABLE FUNCTION
891      001000      XSILC=     BIT9      ;ILLEGAL COMMAND
892      000400      XSOILA=    BIT8      ;ILLEGAL ADDRESS
893      000200      XSOMOT=    BIT7      ;TAPE IN MOTION
894      000100      XSOONL=    BIT6      ;TRANSPORT ON LINE
895      000040      XSOIE=     BIT5      ;INTERRUPT ENABLE
896      000020      XSOVCK=    BIT4      ;VOLUME CHECK BIT
897      000010      XSOPED=    BIT3      ;PHASE ENCODED DRIVE
898      000004      XSOWLK=    BIT2      ;WRITE LOCKED
899      000002      XSOTOT=    BIT1      ;BEGINNING OF TAPE
900      000001      XSOEOT=    BIT0      ;END OF TAPE
901
902
903
904      ;*
905      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 1
906      ;(XST1)
907      ;-

```

```

907      100000      X1.DLT = BIT15      ;DATA LATE
908      040000      X1.SPARE= BIT14      ;NOT USED
909      020000      X1.COR = BIT13      ;CORRECTABLE DATA ERROR
910      017375      X1.MBZ = BIT12+BIT11+BIT10+BIT9+BIT7+BIT6+BIT5+BIT4+BIT3+BIT2+BIT0 ;ALWAYS 0
911      000400      X1.RBP = BIT8       ;READ BUS PARITY ERROR
912      000002      X1.UNC = BIT1       ;UNCORRECTABLE DATA OR HARD ERROR
913
914      ;+
915      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 2
916      ;(XST2)
917      ;-
918      100000      X2.OPM = BIT15      ;OPERATION IN PROGRESS (TAPE MOVING)
919      040000      X2.RCE = BIT14      ;RAM CHECKSUM ERROR
920      035400      X2.SPARE= BIT13+BIT12+BIT11+BIT9+BIT8 ;NOT USED BY TK-25 (ALWAYS=0)
921      002000      X2.WCF = BIT10      ;WRITE CLOCK FAILURE (FIFO NOT EMPTIED BY TRANSPORT)
922      000200      X2.EXTF = BIT7      ;IF WRITE CHAR CMD THEN = EXTENDED FEATURES ENABLED
923      000100      X2.BUFE = BIT6      ;IF WRITE CHAR CMD THEN = BUFFERING ENABLED
924      000077      X2.REV = 000077    ;IF WRITE CHAR CMD THEN = MICROCODE REVISION LEVEL
925      000007      X2.UNIT = BIT2+BIT1+BIT0 ;IF GET STATUS THEN = CURRENTLY SELECTED UNIT NO.
926
927      ;+
928      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 3
929      ;(XST3)
930      ;-
931      177400      X3.MDE = 177400    ;MICRO-DIAGNOSTIC ERROR CODE
932      000200      X3.SPARE= BIT7      ;NOT USED BY TK-25
933      000100      X3.OPI = BIT6      ;OPERATION INCOMPLETE
934      000040      X3.REV = BIT5      ;REVERSE
935      000020      X3.TRF = BIT4      ;TRANSPORT RESPONSE FAILURE
936      000010      X3.DCK = BIT3      ;DENSITY CHECK
937      000006      X3.MBZ =BIT2+BIT1  ;NOT USED ALWAYS 0
938      000001      X3.RIB = BIT0      ;REVERSE INTO BOT
939
940      ;+
941      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 4
942      ;(XST4)
943      ;-
944      100000      X4.HSP = BIT15      ;HIGH SPEED
945      040000      X4.RCE = BIT14      ;RETRY COUNT EXCEEDED
946      020000      X4.TSM = BIT13      ;TRANSPORT SPECIAL MODE
947      017400      X4.MBZ = BIT12+BIT11+BIT10+BIT9+BIT8 ;NOT USED ALWAYS 0
948      000377      X4.WRC = 000377    ;WRITE RETRY COUNT FIELD
949
950
951      ;+
952      ;
953      ;TSSR TERMINATION CODES (BIT 0-2)
954      ;
955      ;-
956
957      000006      TSREJ= 3*2          ;COMMAND REJECTED
958      000006      UNREC= 6           ;UNRECOVERABLE ERROR
959
960      ;+
961      ;
962      ;DEVICE REGISTER OFFSETS
963      ;

```

F3

```

964
965
966      177776      TSBA== -2
967      177776      TSBAL== -2
968      177776      TSDB== -2      ;TSDB/TSBA REGISTER
969      177776      TSDBL== -2     ;TSDB/TSBA REGISTER
970      177777      TSBAM== -1
971      177777      TSDBH== -1     ;TSDB/TSBA REGISTER HIGH BYTE
972      000000      TSSR== 0      ;TSSR REGISTER
973      000001      TSSRH== 1     ;TSSR REGISTER HIGH BYTE
974
975
976      ;+
976      ; TSDB ADDRESS BIT DEFINITIONS
977      ;+
977      ;-
978      000003      A1716 = BIT1+BIT0      ;ADDRESS BITS 17:16 ARE IN 1;0
979
980
981      ;+
981      ; COMMAND DEFINITIONS
982      ;+
982      ;-
983      000017      P.GETSTAT = 17      ;GET STATUS
984      000013      P.INIT = 13        ;INITIALIZE
985      000012      P.CONTROL = 12     ;CONTROL COMMANDS
986      000011      P.FORMAT = 11     ;FORMAT
987      000010      P.POSITION = 10   ;POSITION
988      000006      P.WRTSUB = 6      ;SUBSYSTEM WRITE
989      000005      P.WRITE = 5       ;WRITE
990      000004      P.WRTCHAR = 4     ;WRITE CHARACTERISTICS
991      000001      P.READ = 1        ;READ
992
993
994      ;+
994      ; COMMAND PACKET HEADER WORD BIT DEFINITIONS
995      ;+
995      ;-
996      100000      P.ACK = BIT15     ;BUFFER AVAIL FOR CONTROLLER
997      040000      P.CVC = BIT14    ;CLEAR VOLUME CHECK
998      020000      P.OPP = BIT13    ;REVERSE SEQUENCE OF DATA BITS
999      010000      P.SWB = BIT12    ;SWAP BYTES IN MEMORY
1000      007400      P.MODE = BIT11:BIT10:BIT9:BIT8 ;EXTENDED COMMAND MODE FIELD
1001      000200      P.IE = BIT7     ;INTERRUPT ENABLE
1002      000140      P.FMT= BIT6:BITS ;PACKET HEADER TYPE (ALWAYS=0)
1003      000037      P.CMD = 37      ;MAJOR COMMAND FIELD
1004
1005      ;+
1005      ; CONTROL COMMAND MODE CODES
1006      ;+
1006      ;-
1007      000000      PC.RELEASE = 0*256. ;RELEASE BUFFER
1008      000400      PC.REWIND = 1*256. ;REWIND
1009      001000      PC.NOOP = 2*256.  ;NO-OP
1010      002000      PC.IEREW = 4*256. ;REWIND IMMEDIATE INTERRUPT
1011      002400      PC.ERASE = 5*256. ;SECURITY ERASE
1012
1013
1014      ;+
1014      ; CONTROLLER RAM DEFINITIONS
1015      ;+
1015      ;-
1016      000167      RMCHBEG = 167     ;CHARACTERISTICS IO DATA BEGIN RAM ADDRESS
1017      000200      RMCHEND = 200    ;CHARACTERISTICS IO DATA END RAM ADDRESS
1018      000020      RMPKTBEG= 20     ;COMMAND PACKET BEGIN RAM ADDRESS
1019      000027      RMPKTEND= 27    ;COMMAND PACKET END RAM ADDRESS
1020      000104      RMMMSGBEG= 104   ;MESSAGE BUFFER BEGIN RAM ADDRESS

```

```

1021      000117      RMSGEND= 117      ;MESSAGE BUFFER END RAM ADDRESS
1022      ;*
1023      ;
1024      ;REGISTER DEFINITIONS IN THE MESSAGE BUFFER
1025      ;
1026      ;-
1027
1028      000006      XST0== 6      ;EXTENDED STATUS REGISTER 0 (WORD 4)
1029      000010      XST1== 8      ;EXTENDED STATUS REGISTER 1 (WORD 5)
1030      000012      XST2== 10     ;EXTENDED STATUS REGISTER 2 (WORD 6)
1031      000014      XST3== 12     ;EXTENDED STATUS REGISTER 3 (WORD 7)
1032      000016      XST4== 14     ;EXTENDED STATUS REGISTER 4 (WORD 8)
1033
1034
1035      ;*
1036      ;
1037      ;OFFSETS TO WORD LOCATIONS IN PACKET DEFINITIONS
1038      ;
1039      ;-
1040
1041      000002      PKLOW  = 2      ;LOW ORDER CHARACTERISTIC DATA POINTER
1042      000004      PKHI   = 4      ;HIGH ORDER CHARACTERISTIC DATA POINTER
1043      000006      PKBCNT = 6      ;NUMBER OF BYTES IN DATA PACKET
1044
1045      000010      EXBCNT=10      ;NUMBER OF BYTES IN EXTENDED DATA PACKET
1046
1047      ;*
1048      ;DATA PACKET OFFSETS FOR WRITE SUBSYSTEM COMMAND
1049      ;-
1050      000000      BSELO  = 0      ;BYTE 0
1051      000001      BSEL1  = 1      ;BYTE 1
1052      000002      SEL2   = 2      ;WORD 2
1053      000004      SELDATA = 4      ;WORD 3
1054
1055      ;*
1056      ;BSELO SELECT CODES FOR WRITE SUBSYSTEM COMMAND
1057      ;-
1058      000000      PW.NOP   = 0      ;NO-OP
1059      000001      PW.RDRAM = 1      ;READ RAM
1060      000002      PW.WTRAM = 2      ;WRITE RAM
1061      000003      PW.RFIFO = 3      ;READ FIFO
1062      000004      PW.WFIFO = 4      ;WRITE FIFO
1063      000005      PW.RDSTAT = 5     ;READ STATUS
1064      000006      PW.WCYL  = 6     ;WRITE TAPE CONTROL
1065      000007      PW.WFMT  = 7     ;WRITE TAPE FORMAT
1066      000010      PW.WMISC = 10     ;WRITE MISCELLANEOUS
1067      000011      PW.WNPR  = 11     ;WRITE NPR CONTROL
1068      000020      PW.D22   = 20     ;DO MICROTEST 22
1069      000021      PW.D11   = 21     ;DO MICROTEST 11
1070      000022      PW.D13   = 22     ;DO MICROTEST 13
1071      000023      PW.NO1311 = 23    ;DISABLE MICROTEST 11 AND 13
1072      000024      PW.RDXT  = 24     ;READ EXT. TAPE STATUS (NOT SUPPORTED BY ALL TRANSP
RTS
1073
1074      ;*
1075      ;BSEL1 CODES FOR WRITE TAPE CONTROL
1076      ;-
1077      000200      WC.IFAD  = BIT7   ;IFAD - FORMATTER ADDRESS

```



```

1078      000100      WC.IOTAD      - BIT6      ;ITADO - TRANSPORT ADDRESS BIT 0
1079      000040      WC.I1TAD      - BIT5      ;ITAD1 - TRANSPORT ADDRESS BIT 1
1080      000020      WC.I5RESV     - BIT4      ;IRESV5 - RESERVED #5
1081      000010      WC.IREW       - BIT3      ;IREW   - REWIND
1082      000004      WC.IRWU       - BIT2      ;IRWU   - REWIND AND UNLOAD
1083      000002      WC.IFEN       - BIT1      ;IFEN   - FORMATTER ENABLE
1084      000001      WC.IGO        - BIT0      ;GO
1085
1086      ;+
1087      ;BSEL1 CODES FOR WRITE FORMAT
1088      ;-
1089      000200      WF.IHISP      - BIT7      ;IHISP  - HIGH SPEED
1090      000100      WF.IWRT       - BIT6      ;IWRT   - WRITE
1091      000040      WF.IREV       - BIT5      ;IREV   - REVERSE
1092      000020      WF.IWFM       - BIT4      ;IWFM   - WRITE FILE MARK
1093      000010      WF.IEDIT      - BIT3      ;IEDIT  - EDIT
1094      000004      WF.IERASE     - BIT2      ;IERASE - ERASE
1095      000002      WF.I3RESV     - BIT1      ;IRESV3 - RESERVED #3
1096      000001      WF.I4RESV     - BIT0      ;IRESV4 - RESERVED #4
1097
1098
1099      ;+
1100      ;BSEL1 CODES FOR WRITE MISCELLANEOUS SUBCOMMAND
1101      ;-
1102      000200      MS.EXT        - BIT7      ;INVERT SENSE OF EXTENDED FEATURES SWITCH
1103      000020      MS.RSFIFO     - BIT4      ;RESET FIFO AND INPUT PARITY ERROR
1104      000010      MS.RSTAPE     - BIT3      ;RESET TAPE STATUS IN 2 FLIP-FLOPS
1105      000006      MS.ATTN       - BIT2!BIT1 ;ATTENTION TRIGGER FIELD
1106      000001      MS.RSD        - BIT0      ;RESET TIMER A,B THEN DELAY TIMES IN SEL2
1107
1108      ;+
1109      ; MS.ATTN SUBCODES
1110      ;-
1110      000000      MSA.NOP      - 0*2      ;NO-OP (NOTHING TRIGGERED)
1111      000002      MSA.VOL      - 1*2      ;SIMULATE ON-LINE/OFF-LINE TRANSITION
1112      000004      MSA.NRAM     - 2*2      ;FORCE NON-FATAL RAM ERROR (FORCES ERRCODE 54)
1113      000006      MSA.FRAME    - 3*2      ;FORCE FATAL RAM ERROR (CAUSES SCE TO SET)
1114
1115      ;+
1116      ; WRITE SUBSYSTEM WRITE NPR BSEL1 BIT DEFINITIONS
1117      ;-
1117      000200      NP.IR         - BIT7      ;INTERRUPT REQUEST (0-1 TRANSITION)
1118      000100      NP.OUT        - BIT6      ;TAPE DATA DIRECTION OUT (0= IN)
1119      000040      NP.LOOP      - BIT5      ;ENABLE TRANSPORT LOOPBACK
1120      000020      NP.WRP       - BIT4      ;WRITE CORRECT PARITY (SET=0 TO WRITE WRONG)
1121
1122      ;+
1123      ; READ STATUS MESSAGE BUFFER BIT DEFINITIONS
1124      ;-
1125      000200      S2.DIM        - BIT7      ;WORD #9 BYTE 2 DATA IN MISS
1126      000100      S2.ILW       - BIT6      ;           ILW H
1127      000040      S2.OUTRDY     - BIT5      ;           OUT RDY H
1128      000020      S2.INRDY     - BIT4      ;           IN RDY H
1129      000010      S2.ATIMR     - BIT3      ;           TIMER A FLAG H
1130      000004      S2.BTIMR     - BIT2      ;           TIMER B FLAG H
1131      000003      S2.UNDEF     - BIT1!BIT0 ;(UNDEFINED)
1132      000000      S1.PARIN     - BIT15     ;WORD #8 BYTE 1 PARIN H
1133      040000      S1.I2RESV    - BIT14     ;           IRESV2
1134      020000      S1.I1RESV    - BIT13     ;           IRESV1

```

1135	010000	S1.IEOT	= BIT12	:	IEOT L
1136	004000	S1.IIDENT	= BIT11	:	IIDENT H
1137	002000	S1.ICER	= BIT10	:	ICER H
1138	001000	S1.IFMK	= BIT9	:	IFMK H
1139	000400	S1.IHER	= BIT8	:	IHER H
1140	000200	SO.ISPEED	= BIT7	:	WORD #8 BYTE 0 ISPEED H
1141	000100	SO.IRDY	= BIT6	:	IRDY L
1142	000040	SO.IONL	= BIT5	:	IONL L
1143	000020	SO.ILDP	= BIT4	:	ILDP L
1144	000010	SO.IDBY	= BIT3	:	IDBY L
1145	000004	SO.IRWD	= BIT2	:	IRWD L
1146	000002	SO.IFBY	= BIT1	:	IFBY L
1147	000001	SO.IFPT	= BIT0	:	IFPT L
1148		:		:	
1149		:		:	
1150	177560	TKS	=177560	:	;KEYBOARD STATUS REGISTER
1151	177562	TKB	=177562	:	;KEYBOARD DATA REGISTER
1152	177564	TPS	=177564	:	;CONSOLE PRINTER STATUS REGISTER
1153	177566	TPB	=177566	:	;CONSOLE PRINTER DATA REGISTER
1154	007776	HIMEM	=007776	:	;HIGH MEMORY MASK VALUE
1155		:		:	
1156		:		:	
1157		:		:	
1158	174400	CSR	=174400	:	;STATUS AND CONTROL REGISTER
1159	174402	BAR	=174402	:	;DL ADDRESS REGISTER
1160	174404	DAR	=174404	:	;PLATTER ADDRESS
1161	174406	MPR	=174406	:	;MULTIPURPOSE REGISTER
1162		:		:	
1163		:		:	
1164		:		:	
1165		:		:	
1166		:		:	
1167		:		:	
1168		:		:	
1169		:		:	
1170	000004	DLGETS	=4	:	;GET STATUS COMMAND
1171	000006	SEEK	=6	:	;SEEK TRACK AND HEAD SELECT
1172	000010	DLRHD	=10	:	;READ SECTOR HEADER
1173	000014	READ	=14	:	;READ COMMAND
1174	000016	DLRDNH	=16	:	;READ SECTOR NO HEADER CHECK
1175		:		:	
1176		:		:	
1177		:		:	
1178		:		:	
1179		:		:	
1180		:		:	
1181	000001	READY	=1	:	;DRIVE READY BIT IN STATUS REG.
1182	000013	DLSR	=13	:	;STATUS AND RESET
1183	177730	DLERR	=177730	:	;MASK FOR COVER OPEN
1184	000006	DLUN	=6	:	;HEADS UNLOADED
1185	000177	DLCYL	=000177	:	;MASK FOR CYLINDER ADDRESS
1186	100200	DLDNER	=100200	:	;DONE SET OR ERROR SET BITS
1187		:		:	
1188		:		:	
1189		:		:	
1190		:		:	
1191	177560	TTICSR	= 177560	:	;KEYBOARD INPUT STATUS

J3

1192	177562	TTIBFR	=	177562	;KEYBOARD DATA REGISTER
1193	177564	TTOCSR	=	177564	;CONSOLE PRINTER STATUS REGISTER
1194	177566	TTOBFR	=	177566	;CONSOLE PRINTER DATA REGISTER
1195					

```

1197             .SBTTL  SPECIAL MACROS AND OPDEFS.
1198
1199
1200             ;+
1201             ;SAVE GENERAL REGS 1 TO 5
1202             ;-
1203
1204             .MACRO  SAVREG
1205             JSR    R5,REGSAV
1206             .ENDM
1207
1208             ;+
1209             ; MACRO TO FORCE AN ERROR
1210             ;-
1211             .MACRO  FORCERROR      TAG,NOTSSR
1212             .NLIST
1213             .IIF NDF LISTALL, .NLIST
1214             .LIST
1215             .IF 8 NOTSSR
1216             MOV    TSSR(R5),R1           ;READ TSSR
1217             .ENDC
1218             MOV    FORCER,FORCER       ;IS FORCER SET? (LEAVE C BIT ALONE)
1219             BNE   TAG                   ;BR IF YES
1220             .NLIST
1221             .IIF NDF LISTALL, .LIST
1222             .LIST
1223             .ENDM
1224
1225             ;+
1226             ; MACRO TO FORCE AN EXIT TO AVOID SECTION ITERATIONS
1227             ; WILL EXIT TO A LABEL IF FORCER IS NEGATIVE
1228             ; SO TO FORCE ERRORS AND EXIT ON 1 ERROR SET
1229             ; FORCER TO 177777
1230             ; TO FORCE ERRORS AND ITERATIONS SET FORCER TO 1.
1231             ;-
1232             .MACRO  FORCEEXIT      TAG
1233             .NLIST
1234             .IIF NDF LISTALL, .NLIST
1235             .LIST
1236             MOV    FORCER,FORCER       ;IS FORCER NEGATIVE?
1237             BMI   TAG                   ;BR IF YES
1238             .NLIST
1239             .IIF NDF LISTALL, .LIST
1240             .LIST
1241             .ENDM
1242             ;+
1243             ; MACRO TO INCREMENT ERROR COUNTS
1244             ;-
1245             .MACRO  NEXT,ERRNO
1246             .NLIST
1247             ;;;.IIF NDF LISTALL, .NLIST
1248             ERRNO=ERRNO+1
1249             ;;;.IIF NDF LISTALL, .LIST
1250             .LIST
1251             .ENDM
1252
1253             ;+
    
```

```

1254 ;MACRO TO PERFORM XOR
1255 ;-
1256
1257 .MACRO XOR A,B
1258 MOV A, -(SP)
1259 BIC B, (SP)
1260 BIC A,B
1261 BIS (SP)+,B
1262 .ENDM
1263
1264 000000 EN=0 ; INITIALIZE ERROR NUMBER
1265 .SBTTL FORCER - FORCE ERROR FLAG
1266
1267 ;
1268 ; THE FOLLOWING LOCATIONS MAY BE PATCHED BY THE USER
1269 ; TO OBTAIN THE RESULTS DESCRIBED FOR EACH.
1270 ;
1271
1272 002144 000000 FORCER:: 0 ; FORCE TYPE ALL HARD ERRORS (THE ONES CALLED -
1273 ; - BY THE MACRO "IFERROR"). AN ERROR NEED NOT -
1274 ; - EXIST, JUST ASSUME AND TYPE THE MESSAGE.
1275
1276
1277

```

```

1279                                     .SBTTL  GLOBAL DATA SECTION
1280
1281                                     ;++
1282                                     ;THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
1283                                     ;IN MORE THAN ONE TEST.
1284                                     ;--
1285
1286                                     ;
1287                                     ;THE FOLLOWING DATA ARE SET FOR EACH UNIT AT INIT TIME.
1288                                     ;SINGLE UNIT DEFAULTS (LISTED) ARE IN THE DEFAULT P-TABLE
1289                                     ;
1290 002146 000000  EPRTSW::          .WORD  0          ;PRINT SWITCH
1291 002150 000000  UNITN::          .WORD  0          ;UNIT # UNDER TEST.
1292 002152 000000  QVP::          .WORD  0          ;QUICK VERIFY FLAG.
1293 002154 000000  CSRADDR::      .WORD  0          ;ADDRESS OF CSR FOR CURRENT DEVICE
1294 002156 000224  IVEC::          .WORD  224        ;INTERRUPT VECTOR
1295 002160 000200  IPRI::          .WORD  PRI04      ;INTERRUPT PRIORITY.
1296 002162 000000  TSTCNT::       .WORD  0          ;NUMBER OF TESTS RUN IN THIS PASS
1297 002164 000000  LOOPCNT::      .WORD  0          ;REMAINING ITERATION COUNT FOR TEST
1298 002166 000000  DEVCNT::       .WORD  0          ;NUMBER OF DEVICE UNDER TEST
1299 002170 000000  FATFLG::       .WORD  0          ;SET IF FATAL ERROR IS DETECTED IN TEST
1300 002172 000000  INTRECV::      .WORD  0          ;SET IF TAPE INTERRUPT WAS RECEIVED
1301 002174 000000  BENBSW::       .WORD  0          ;BUFFER ENABLE SWITCH SW 0-OFF;1-ON
1302 002176 000000  EXPD::          .WORD  0          ;EXPECTED RAM DATA FOR PRAMPKT ROUTINE
1303 002200 000000  RECV::          .WORD  0          ;RECEIVED RAM DATA FOR PRAMPKT ROUTINE
1304 002202 000000  ERRHI::        .WORD  0          ;HIGH ADDRESS MEMORY ERROR
1305 002204 000000  ERRLO::        .WORD  0          ;LOW ADDRESS MEMORY ERROR
1306 002206 000000  RAMDATA::      .BLKW  16.        ;DATA READ FROM RAM PACKET OR MESSAGE BUF AREA
1307 002246 000000  RAMSIZ::       .WORD  0          ;RAM DATA SIZE FOR PRAMPKT ROUTINE
1308 002250 000000  RCVHIADD::     .WORD  0          ;RECEIVED BUFFER HIGH ADDRESS
1309 002252 000000  RCVLOADD::     .WORD  0          ;RECEIVED BUFFER LOW ADDRESS
1310 002254 000000  COUNT::        .WORD  0          ;TEST COUNT PATTERN
1311 002256 000000  DATA::         .WORD  0          ;TEST DATA
1312 002260 000000  TSTFLAG::      .WORD  0          ;TEST FLAG WORD
1313 002262 000000  TSTPTR::       .WORD  0          ;TSTBLK FOINTER
1314 002264 000000  PRMNO::        .WORD  0          ;PRINT ROUTINE TEMP
1315 002266 000000  EXPMSG::        .BLKB  100.       ;EXPECTED MESSAGE BUFFER DATA
1316 002432 000000  RECMMSG::      .BLKB  100.       ;RECEIVED MESSAGE BUFFER DATA
1317 002576 000000  TMPBFR::       .BLKB  80.        ;TEMPORARY STORAGE FOR PRINT
1318 002716 000000  MESBFA::       .WORD  0          ;STORES ADDRESS OF MESSAGE BUFFER FOR ERR PRT

```

1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336 002720
1337 002720 000000
1338 002722 177777
1339 002724 000001
1340 002726 000002
1341 002730 000004
1342 002732 000010
1343 002734 000020
1344 002736 000040
1345 002740 000100
1346 002742 000200
1347 002744 000400
1348 002746 001000
1349 002750 002000
1350 002752 004000
1351 002754 010000
1352 002756 020000
1353 002760 040000
1354 002762 100000
1355 002764 177776
1356 002766 177775
1357 002770 177773
1358 002772 177767
1359 002774 177757
1360 002776 177737
1361 003000 177677
1362 003002 177577
1363 003004 177377
1364 003006 176777
1365 003010 175777
1366 003012 173777
1367 003014 167777
1368 003016 157777
1369 003020 157777
1370 003022 077777
1371 003024 125252
1372 003026 052525
1373 003030

.SBTTL TSTBLK - TEST DATA TABLE

```

;+
; THIS TABLE CONTAINS TEST DATA USED IN SEVERAL TESTS
; IN SEQUENCE THE DATA IS:
;
;     ALL ZEROS
;     ALL ONES
;     WALKING ONES
;     WALKING ZEROS
;     ALTERNATING ONES AND ZEROS
;-

```

```

TSTBLK::
.WORD 0 ;ALL ZEROS
.WORD 177777 ;ALL ONES
.WORD BIT0 ;DATA FOR WALKING ONES
.WORD BIT1
.WORD BIT2
.WORD BIT3
.WORD BIT4
.WORD BIT5
.WORD BIT6
.WORD BIT7
.WORD BIT8
.WORD BIT9
.WORD BIT10
.WORD BIT11
.WORD BIT12
.WORD BIT13
.WORD BIT14
.WORD BIT15
.WORD +CBIT0 ;DATA FOR WALKING ZEROS
.WORD +CBIT1
.WORD +CBIT2
.WORD +CBIT3
.WORD +CBIT4
.WORD +CBIT5
.WORD +CBIT6
.WORD +CBIT7
.WORD +CBIT8
.WORD +CBIT9
.WORD +CBIT10
.WORD +CBIT11
.WORD +CBIT12
.WORD +CBIT13
.WORD +CBIT14
.WORD +CBIT15
.WORD 125252 ;ALTERNATING ONES, ZEROS
.WORD 052525 ;ALTERNATING ONES, ZERO OPPOSITE FROM ABOVE

TBLEND**

```

```

1375                                .SBTTL GLOBAL ENVIRONMENT STORAGE
1376                                ;
1377                                ; STORAGE FOR DEVICE REGISTERS
1378                                ;
1379 003030 000000 100000 000000 DUMMY: 0,100000,0,0          ; DUMMY DEVICE REGISTERS...
1380 003040 000000 000000 000000      0,0,0,0,0,0,0,0,0,0 ; ...FOR MULTI-UNIT CHECKOUT.
1381
1382
1383
1384 003060 000000          DUFLG::      .WORD 0          ; "DROPPED UNIT" FLAG.
1385                                ; INHIBITS CODE IN "CLEAN-UP".
1386 003062 000000          NODEV::      .WORD 0          ; FLAG TO SAY NO DEVICE.
1387
1388 003064 000000          TEMP1::      .WORD 0          ; SOME TEMP LOCATIONS.
1389 003066 000000          TEMP2::      .WORD 0
1390 003070 000000          XXCOMM::     .WORD 0
1391 003072 000000          FREE::      .WORD 0          ; XXDP* COMM BLOCK POINTER.
1392 003074 000000          FRESIZ::    .WORD 0          ; 1ST FREE MEMORY ADDRESS...
1393 003076 000000          FREEHI::    .WORD 0          ; ...AND SIZE (IN WORDS).
1394 003100 000000          KTFLG::      .WORD 0          ; LAST WORD IN FREE SPACE
1395                                ; KT11, MEM AVAIL FLAG -
1396                                ; - .WORD 0 = <24K OR NO KT -
1397 003102 000000          KTENABLE::   .WORD 0          ; - NZ = >24K AND KT.
1398 003104 002000          PST32W::     .WORD 2000       ; SET BY TEST ROUTINES TO FLAG >28K UNDER TEST
1399 003106 000000          SIFLAG::     .WORD 0          ; 32W BLOCK ADDRESS FOR 32K START
1400 003110 000000          BDDAT::     .WORD 0
1401 003112 000000          GDDAT::     .WORD 0          ; ACTUAL DATA
1402 003114 000000          LOOPFL::    .WORD 0          ; EXPECTED DATA
1403 003116
1404 003116 000000          CTAB::       .WORD 0          ; CONFIGURATION TABLES.
1405 003120 000000          CT:ABM::     .WORD 0          ; CONFIG WORK.
1406 003122 000000
1407 003124 000000
1408 003126 177777
1409 003130          CTABE::            .WORD -1          ; END OF MEM TABLE.
1410                                ;
1411                                ; ERROR STATISTICS TABLE (1 WORD PER UNIT), 64 UNITS MAX;
1412                                ;
1413                                ; 0 = UNIT NOT TESTED
1414                                ; 100000 = UNIT ONLINE, NO ERRORS
1415                                ; 10XXXX = UNIT ONLINE, ENCOUNTERED XXXX ERRORS
1416                                ; 160000 = UNIT DROPPED, NON-EXISTENT DEVICE REGISTER
1417                                ; 160001 = UNIT DROPPED, NOT IDLE AT START
1418                                ; 14XXXX = UNIT DROPPED, ENCOUNTERED XXXX ERRORS
1419 003130          ERTABL:             .BLKW 64,
1420 003330 000000          ERTABE:      .WORD 0
1421
1422 003332 000000          SKIPT:       .WORD 0          ; 1*SKIP SUBTEST 0=NO SKIP OF SUBTEST

```



```

1424 .SBTTL GLOBAL TEXT MESSAGES
1425
1426 ;;;
1427 ; THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
1428 ; MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
1429 ; MORE THAN ONE TEST.
1430 ;--
1431
1432
1433 ;*
1434 ; NAMES OF DEVICES SUPPORTED
1435 ;-
1436
1437 003334          DEVTYP <TK-25>
      003334          L#DVTYP::
      003334      124      113      055      .ASCIZ /TK-25/
      .EVEN
1438
1439
1440 ;*
1441 ; TEST DESCRIPTION
1442 ;-
1443
1444          003342          DESCRIPT <CZTKGA TK-25 FRT END FUNC 03>
      003342          L#DESC::
      003342      103      132      124      .ASCIZ /CZTKGA TK-25 FRT END FUNC 03/
      .EVEN
1445
1446 ;*
1447 ; BIT TO ASCII CONVERSION FOR TSSR REGISTER
1448 ;-
1448 003400 003440 003443 003447 TSSRBIT:: .WORD 1#,2#,3#,4#,5#,6#,7#,8#
1449 003420 003501 003505 003511 .WORD 9#,10#,11#,12#,13#,14#,15#,16#
1450 003440          123      103      000      1#: .ASCIZ 'SC'
1451 003443          102      111      105      2#: .ASCIZ 'BIE'
1452 003447          123      103      105      3#: .ASCIZ 'SCE'
1453 003453          122      115      122      4#: .ASCIZ 'RMR'
1454 003457          116      130      115      5#: .ASCIZ 'NXM'
1455 003463          116      102      101      6#: .ASCIZ 'NBA'
1456 003467          102      111      124      7#: .ASCIZ 'BIT9'
1457 003474          102      111      124      8#: .ASCIZ 'BIT8'
1458 003501          123      123      122      9#: .ASCIZ 'SSR'
1459 003505          117      106      114      10#: .ASCIZ 'OFL'
1460 003511          102      111      124      11#: .ASCIZ 'BIT5'
1461 003516          102      111      124      12#: .ASCIZ 'BIT4'
1462 003523          102      111      124      13#: .ASCIZ 'BIT3'
1463 003530          102      111      124      14#: .ASCIZ 'BIT2'
1464 003535          102      111      124      15#: .ASCIZ 'BIT1'
1465 003542          102      111      124      16#: .ASCIZ 'BIT0'
1466          .EVEN
1467 003550          124      123      123      SFIERR: .ASCIZ 'TSSR ERROR AFTER SOFT INIT'
1468 003603          124      123      123      SFHERR: .ASCIZ 'TSSR ERROR AFTER BUS RESET'
1469 003636          040      040      116      NXR: .ASCIZ / NON-EXISTANT DEVICE REGISTER/
1470 003675          045      101      040      NXR: .ASCIZ /#A ADDRESS: #06/
1471 003716          045      101      040      TSSX: .ASCII /#A TSBA,TSSR EXP'D: #06#A,#06#N/
1472 003756          045      101      040      TSSX: .ASCII /#A TSBA,TSSR REC'D: #06#A,#06#N/
1473 004015          045      116      045      FUSI: .ASCII /#N#A/
1474 004021          040      040      125      USI: .ASCIZ / UNEXPECTED INTERRUPT/

```

```

1475 004050      040      040      111 NSI:      .ASCIZ / INTERRUPT EXPECTED, NOT RECEIVED/
1476 004113      045      116      045 FNOINTR:  .ASCII /#N#A/
1477 004117      040      040      116 NOINTR:  .ASCIZ / NO INTERRUPT WAS GENERATED/
1478 004154      040      040      111 IFAULT: .ASCIZ / INTERRUPT FAULT/
1479 004176      045      101      040 INTX:     .ASCIZ /#A CPU PC: #06#A TSBA: #06/
1480 004233      040      040      042 NOINIT:  .ASCIZ / "BUS-INIT" DIDN'T INITIALIZE CONTROLLER/
1481 004305      040      040      042 NSINIT:  .ASCIZ / "SOFT-INIT" DIDN'T INITIALIZE THE DPU/
1482 004355      040      040      042 BRINIT:  .ASCIZ / "BUS-RESET" DIDN'T INITIALIZE THE DPU/
1483
1484 004425      000
1485 004426      045      116      000 MULCR:   .ASCIZ //
1486 004431      045      101      040 EXPGOT:  .ASCIZ /#N#A EXP'D: #06#A, REC'D: #06/
1487 004465      045      116      045 EXPGT2:  .ASCIZ /#N#A EXP'D: #06#A, #06#N#A REC'D: #0#A, #06/
1488 004541      045      101      040 DUAD12: .ASCIZ /#A REG(W) WRITTEN TO: #06#A REG(R) READ, EXP'D: #06#A, REC'D: #06/
1489 004643      122      101      115 PKTRAM:  .ASCIZ 'RAM Contents Do Not Match Packet Sent'
1490 004711      040      040      103 SCHE:   .ASCIZ / CONFIG DOESN'T MATCH MFG. MASTER/
1491 004754      127      122      111 WRTHSG: .ASCIZ 'WRITE CHARACTERISTICS Failed'
1492 005011      124      123      123 WRTERR: .ASCIZ 'TSSR Incorrect After WRITE Command, More Bits Set Than SSR'
1493 005104      124      123      123 RDERR:  .ASCIZ 'TSSR Incorrect After READ Command, More Bits Set Than SSR'
1494
1495
1496
1497

```

```

1499
1500
1501
1502
1503
1504
1505
1506
1507 005176
1508 005176
005176 013746 003062
005202 012746 003675
005205 012746 000002
005212 010600
005214 104415
005216 062706 000006
1509 005222 004737 005230
1510 005226
005226 104423
1511
1512
1513
1514
1515
1516
1517 005230 005727
1518 005232 000000
1519 005234 001402
1520 005236 004777 177770
1521 005242
005242 012746 004426
005246 012746 000001
005252 010600
005254 104415
005256 062706 000004
1522 005252 000207

.SBTTL GLOBAL ERROR REPORT SECTION
;
; THE GLOBAL ERROR REPORT SECTION CONTAINS THE PRINTB AND PRINTX
; CALLS THAT ARE USED IN MORE THAN ONE TEST.
; ASCII TEXT STRINGS ARE FOUND IN THE GLOBAL TEXT SECTION.
;
NXRERR: BGNMSG NXRERR ;NON-EXISTANT DEVICE REGISTER.
;NODEV = NEXM ADDRESS.
PRINTX #NXRX,NODEV
MOV NODEV,-(SP)
MOV #NXRX,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C#PNTX
ADD #6,SP
JSR PC,EXTEND ; PRINT EXTENSION IF REQUIRED.
ENOMSG
L10002: TRAP C#MSG

;
; THIS ROUTINE APPENDS A UNIQUE EXTENSION (IF REQUIRED)
; TO ANY OF THE ABOVE ERROR SIGNATURES.
;
EXTEND: TST (PC)+
EXTA: 0 ; 0 = NO EXTENSION.
BEG 1#
JSR PC,BEXTA ; APPEND EXTENSION TEXT.
1#: PRINTX #NULCR ; PRINT A BLANK LINE
MOV #NULCR,-(SP)
MOV #1,-(SP)
MOV SP,R0
TRAP C#PNTX
ADD #4,SP
RTS PC

```

```

1525                                .SBTTL PRITSSR - PRINT TSSR CONTENTS
1526
1527                                ;*
1528                                ;
1529                                ;ROUTINE TO DISPLAY THE CONTENTS, AND BIT DEFINITIONS, OF
1530                                ;THE TSSR REGISTER. THIS ROUTINE IS NORMALLY CALLED ONLY
1531                                ;BY A MESSAGE PRINTING ROUTINE
1532                                ;
1533                                ;INPUTS:
1534                                ;
1535                                ;      R1      CONTENTS OF TSSR
1536                                ;
1537                                ;SUBORDINATE ROUTINES:
1538                                ;
1539                                ;      CHKAMB  CHECK FOR AMBIGUOUS CONTENTS
1540                                ;
1541                                ;-
1542
1543 PRITSSR:
1544     SAVREG                                ;SAVE GENERAL REGISTERS
1545     MOV      R1,R4                          ;SAVE THE TSSR CONTENTS
1546     PRINTB  #TSSRFOR,R4                    ;PRINT THE CONTENTS OF TSSR
1547     MOV      R4,-(SP)
1548     MOV      #TSSRFOR,-(SP)
1549     MOV      #2,-(SP)
1550     MOV      SP,R0
1551     TRAP    C#PNTB
1552     ADD     #6,SP
1553     MOV     R4,R0                                ;GET TSSR BACK FOR CHKAMB
1554     JSR    PC,CHKAMB                            ;ARE CONTENTS AMBIGUOUS ?
1555     BCS   5#                                  ;BRANCH IF NOT
1556     PRINTX #AMBTSSR                            ;SHOW CONTENTS ARE AMBIGUOUS
1557     MOV    #AMBTSSR,-(SP)
1558     MOV    #1,-(SP)
1559     MOV    SP,R0
1560     TRAP  C#PNTX
1561     ADD   #4,SP
1562     MOV   R4,R3                                ;CONTENTS OF TSSR
1563     BIC   #HIADDR!FATERR!TERCLS,R3            ;CLEAR ALL MULTIPLE BIT FIELDS
1564     BEQ   20#                                  ;NO BITS ARE SET
1565     MOV   #TMPBFR,R2                            ;TEMPORARY ASCII BUFFER
1566     MOV   #TSSRBIT,R1                          ;ASCII EQUIVALENT OF BITS
1567     TST   R3                                    ;REMAINING BITS TO CONVERT
1568     BEQ   15#                                  ;BRANCH WHEN ALL ARE DONE
1569     CLC                                       ;CLEAR CARRY FOR SHIFT
1570     ROL   R3                                    ;SHIFT NEXT BIT TO CARRY
1571     BCC   13#                                  ;BRANCH IF BIT NOT SET
1572     MOV   (R1),R0                                ;POINTER TO BIT DEFINITION
1573     MOV   (R0)+,(R2)+                            ;MOVE ASCII TO BUFFER
1574     BNE   11#                                  ;MOVE ALL BITS
1575     MOV   #' , -(R2)                            ;INSERT A COMMA TO TERMINATE
1576     TST   (R1)+                                ;POINT TO NEXT DESCRIPTION
1577     BR    10#                                  ;GET THE REMAINING BITS
1578     CLRB  -(R2)                                ;TERMINATE THE LINE
1579     PRINTX #TSSDEF,#TMPBFR                    ;PRINT THE BIT DEFINITIONS
1580     MOV   #TMPBFR,-(SP)
1581     MOV   #TSSDEF,-(SP)
1582
1543 005264
1544 005264 010104
1545 005270 010446 006123
1546 005272 012746 000002
1547 005274 012746 000002
1548 005300 010600
1549 005304 104414
1550 005306 104414
1551 005310 062706 000006
1552 005314 010400
1553 005316 004737 016730
1554 005322 103410
1555 005324 012746 006343
1556 005330 012746 000001
1557 005334 010600
1558 005336 104415
1559 005340 062706 000004
1560 005344 010403 5#
1561 005346 042703 001476
1562 005352 001434
1563 005354 012702 002576
1564 005360 012701 003400
1565 005364 005703 10#
1566 005368 001413
1567 005370 000241
1568 005372 006103
1569 005374 103006
1570 005376 011100
1571 005400 112022 11#
1572 005402 001376
1573 005404 112762 000054 177777
1574 005412 005721 13#
1575 005414 000763
1576 005416 105042 15#
1577 005420
1578 005424 012746 002576
1579 005424 012746 006314

```

```

005430 012746 000002      MOV    #2,-(SP)
005431 010600      MOV    SP,R0
005432 104415      TRAP  C#PNTX
005433 062706 000006      ADD    #6,SP
1569
1570 005434 010403      20$:  MOV    R4,R3      ;GET THE TSSR CONTENTS
1571 005435 042703 177761      BIC    #+CTERCLS,R3 ;CLEAR ALL BUT TERMINATION
1572 005436 016303 006404      MOV    TCOOD(R3),R3 ;GET THE TERMINATION CODE MEANING
1573 005437 010346      PRINTX #TCOASC,R3 ;PRINT THE TERMINATION CODE
005438 010346      MOV    R3,-(SP)
005439 012746 006204      MOV    #TCOASC,-(SP)
005440 012746 000002      MOV    #2,-(SP)
005441 010600      MOV    SP,R0
005442 104415      TRAP  C#PNTX
005443 062706 000006      ADD    #6,SP
1574 005500 010403      MOV    R4,R3      ;TSSR CONTENTS AGAIN
1575 005501 042703 177717      BIC    #+CFATERR,R3 ;CLEAR ALL BUT FATAL TERMINATION
1576 005502 001421      BEQ    25$ ;DON'T PRINT IF ZERO
1577 005503 006203      ASR    R3
1578 005504 006203      ASR    R3
1579 005505 006203      ASR    R3      ;ALIGN TERMINATION CODE FOR INDEX
1580 005506 016303 006744      MOV    TFCOD(R3),R3 ;GET THE FATAL TERMINATION CODE
1581 005507 010346      PRINTX #TFCASC,R3 ;PRINT THE FATAL TERMINATION CODE
005508 010346      MOV    R3,-(SP)
005509 012746 006245      MOV    #TFCASC,-(SP)
005510 012746 000002      MOV    #2,-(SP)
005511 010600      MOV    SP,R0
005512 104415      TRAP  C#PNTX
005513 062706 000006      ADD    #6,SP
1582 005514 012737 000031 002170      MOV    #25,FATFLG ;DROP THIS UNIT AFTER ERROR MESSAGE
1583 005515 010403      25$:  MOV    R4,R3      ;GET TSSR CONTENTS
1584 005516 042703 176377      BIC    #+CHIADDR,R3 ;CLEAR ALL BUT EXTENDED ADDRESS
1585 005517 001411      BEQ    30$ ;DON'T PRINT IF ZERO
1586 005518 010346      PRINTX #TEXASC,R3 ;PRINT THE EXTENDED ADDRESS BITS
005519 010346      MOV    R3,-(SP)
005520 012746 006143      MOV    #TEXASC,-(SP)
005521 012746 000002      MOV    #2,-(SP)
005522 010600      MOV    SP,R0
005523 104415      TRAP  C#PNTX
005524 062706 000006      ADD    #6,SP
1587 005525 022704 100210      30$:  CMP    #100210,R4 ;CHECK FOR MEDIA ERROR
1588 005526 001003      BNE    31$ ;BR, IF PROBABLY NOT TAPE ERROR
1589 005527 012737 006032 002146      MOV    #EPRT3,EPRTSW ;"PROBABLY MEDIA RELETED ERROR - BAD TAPE"
1590 005528 005737 002146      31$:  TST    EPRTSW ;CHECK FOR THE SWITCH EMPTY
1591 005529 001003      BNE    310$ ;BR, IF SWITCH IS NOT EMPTY
1592 005530 012737 005672 002146      MOV    #EPRT1,EPRTSW ;SET SWITCH TO DEFAULT
1593 005531 013737 002146 005644      310$: MOV    EPRTSW,32#+2 ;PUT REAL SWITCHABLE MESSAGE IN PLACE
1594 005532 012746 005672      32$:  PRINTB #EPRT1 ;PRINT THE ERROR MESSAGE
005533 012746 000001      MOV    #EPRT1,-(SP)
005534 010600      MOV    #1,-(SP)
005535 104414      MOV    SP,R0
005536 062706 000004      TRAP  C#PNTB
1595 005537 012737 005672 002146      ADD    #4,SP ;RESET TO NORMAL ERROR POINTER
1596 005538 000207      MOV    #EPRT1,EPRTSW ;RETURN TO CALLER
1597
1598 005539 045 116 045 EPRT1: .ASCIZ '*****CHECK CABLES BETWEEN CONTROLLER AND TRANSPORT*****'

```

ANSPO

```

1599 005771      045      116      045  EPRT2:  .ASCIZ  'NNA *****CHECK TRANSPORT*****S'
1600 006032      045      116      045  EPRT3:  .ASCIZ  'NNA *****POSSIBLE MEDIA RELATED ERROR - BAD TAPE*****S'
1601 006183      045      116      045  TSSRFOR: .ASCIZ  'NNA TSSR = #06'
1602 006183      045      116      045  TEXASC:  .ASCIZ  'NNA Extended Address Bits = #06'
1603 006283      045      116      045  TCOASC:  .ASCIZ  'NNA Termination Class Code = #T'
1604 006283      045      116      045  TFCASC:  .ASCIZ  'NNA Fatal Termination Class Code = #T'
1605 006314      045      116      045  TSSDEF:  .ASCIZ  'NNA TSSR Bits Set: #T'
1606 006343      045      116      045  AMBTSSR: .ASCIZ  'NNA TSSR Contents Are Ambiguous'
1607                                     .EVEN
1608 006404      006424  006447  006475  TCOCOD: .WORD   1$,2$,3$,4$,5$,6$,7$,8$
1609 006424      116      157      162      1$:  .ASCIZ  'Normal Termination'
1610 006447      124      145      162      2$:  .ASCIZ  'Termination Condition'
1611 006475      124      141      160      3$:  .ASCIZ  'Tape Status Alert'
1612 006517      106      165      156      4$:  .ASCIZ  'Function Reject'
1613 006537      122      145      143      5$:  .ASCIZ  'Recoverable Error - Tape Position One Record Down'
1614 006621      122      145      143      6$:  .ASCIZ  'Recoverable Error - Tape Was Not Moved'
1615 006670      125      156      162      7$:  .ASCIZ  'Unrecoverable Error'
1616 006714      106      141      164      8$:  .ASCIZ  'Fatal Controller Error'
1617                                     .EVEN
1618
1619 006734      006754  007010  007021  TSFCOD: .WORD   1$,2$,3$,4$
1620 006754      111      156      164      1$:  .ASCIZ  'Internal Diagnostic Failure'
1621 007010      122      145      163      2$:  .ASCIZ  'Reserved'
1622 007021      102      165      163      3$:  .ASCIZ  'Bus Interface or Sanity Check Error'
1623 007065      122      145      163      4$:  .ASCIZ  'Reserved'
1624                                     .EVEN

```

```

1626 .SBTTL PRIPKT - PRINT THE ADDRESS/CONTENTS OF COMMAND PACKET
1627
1628
1629 ; THIS ROUTINE PRINTS THE ADDRESS AND CONTENTS OF A COMMAND PACKET.
1630 ; THIS ROUTINE IS NORMALLY ONLY CALLED FROM A PRINT ROUTINE.
1631 ;
1632 ; INPUT:
1633 ;
1634 ; R0 NUMBER OF WORDS IN PACKET
1635 ; R3 HIGH ORDER COMMAND PACKET ADDRESS
1636 ; R4 ADDRESS OF COMMAND PACKET
1637 ;
1638 ; NOTE: R3 IS IGNORED IF THE KTENABLE FLAG IS CLEAR.
1639 ;
1640
1641 PRIPKT:
1642     SAVREG                                ;SAVE THE REGISTERS
1643     MOV R0,R5                             ;SAVE NO. OF WORDS IN PACKET
1644     TST KTENABLE                          ;ABOVE 28K UNDER TEST?
1645     BNE 10$                               ;BR IF YES
1646     CLR R3                               ;SET HIGH ORDER ADDRESS TO 0
1647     MOV R3,R1                             ;COPY HIGH ORDER ADDRESS
1648     MOV R4,R0                             ;GET LOWER ADDRESS
1649     ROL R0                                ;SHIFT BIT 15 INTO C BIT
1650     ROL R1                                ;AND INTO HIGH ORDER.
1651     PRINTB #PKTADD,R1,R4                 ;PRINT PACKET ADDRESS
1652     MOV R4,-(SP)
1653     MOV R1,-(SP)
1654     MOV #PKTADD,-(SP)
1655     MOV #3,-(SP)
1656     MOV SP,R0
1657     C#PNTB
1658     MOV #10,SP
1659     MOV R3,R0                             ;GET HIGH ORDER ADDRESS
1660     BEQ 20$                               ;BR IF NOT ABOVE 28K.
1661     MOV R4,R1                             ;GET LOW ORDER ADDRESS
1662     JSR PC,SETHAP                         ;SETUP PAR6 MAPPING FOR 18 BIT ADDRESS
1663     MOV R0,R4                             ;GET RETURNED PAR6 ADDRESS BIAS
1664     CLR R1                                ;SAVE WORD NUMBER
1665     MOV (R4),R2                           ;GET PACKET CONTENTS
1666     PRINTB #PKTFRM,R1,R2                 ;PRINT THE DATA
1667     MOV R2,-(SP)
1668     MOV R1,-(SP)
1669     MOV #PKTFRM,-(SP)
1670     MOV #3,-(SP)
1671     MOV SP,R0
1672     TRAP C#PNTB
1673     ADD #10,SP
1674     INC R1                                ;NEXT WORD NUMBER
1675     CMP R1,R5                             ;DONE ALL PACKET WORDS?
1676     BLT 25$                               ;LOOP TILL ALL DONE
1677     PRINTB #PKTNEW
1678     MOV #PKTNEW,-(SP)
1679     MOV #1,-(SP)
1680     MOV SP,R0
1681     TRAP C#PNTB
1682     ADD #4,SP

```

J4

CZIKGA 11-25 FR1 END FUNC 03 MACRO M1200 20-APR-84 08:13 PAGE 36-1
PRIPKT - PRINT THE ADDRESS/CONTENTS OF COMMAND PACKET

SEQ 48

			RTS	PC		,RETURN
166	007242	000207				
167						
167	007244	045	116	045	PKTFRM: .ASCIZ	'#N#A Packet Word 0#D1#A = #06'
168	007302	045	116	045	PKTADD: .ASCIZ	'#N#A Packet Address = #01#05'
168						
169	007337	045	116	045	PKTNEW: .ASCIZ	'#N#N#A '
1670					.EVEN	
1671						


```

1673 .SBTTL PRIBXOR - PRINT EXPD, RECV AND XOR BYTE
1674
1675
1676 ;
1677 ;PRINT EXPECTED DATA, RECEIVED DATA, AND XOR OF THE DATA BYTE
1678 ;THIS ROUTINE IS NORMALLY CALLED ONLY FOR PRINT ROUTINES.
1679 ;
1680 ;INPUTS:
1681 ;
1682 ; R1 RECEIVED DATA
1683 ; R2 EXPECTED DATA
1684 ;
1685 ;OUTPUT:
1686 ;
1687 ; R0 XOR OF EXPECTED/RECEIVED DATA
1688 ;
1689 ;-
1690
1691 PRIBXOR::
1692 SAVREG ;SAVE THE REGISTERS
1693 MOV R2,R3 ;EXPECTED DATA
1694 XOR R1,R3 ;FORM THE EXCLUSIVE OR
1695 MOV #C<377>,R0 ;BYTE MASK
1696 BIC R0,R1 ;SAVE LOW BYTE RECV
1697 BIC R0,R2 ;SAVE LOW BYTE EXPD
1698 BIC R0,R3 ;SAVE LOW BYTE XOR
1699 PRINTB #XORBFOR,R2,R1,R3 ;PRINT THE MESSAGE
007400 MOV R3,-(SP)
007402 MOV R1,-(SP)
007404 MOV R2,-(SP)
007406 MOV #XORBFOR,-(SP)
007412 MOV #4,-(SP)
007416 MOV SP,R0
007420 TRAP C#PNTB
007422 ADD #12,SP
1700 MOV R3,R0 ;R0 HAS XOR ON RETURN
1701 RTS ;RETURN TO CALLER
1702
1703 007432 045 116 045 XORBFOR: .ASCIZ 'NNA EXPD: #03NA RECV: #03NA XOR: #03'
1704 .EVEN
1705

```

```

1707          .SBTTL  PRI XOR - PRINT EXPD, RECV AND XOR
1708
1709          ;*
1710          ;
1711          ;PRINT EXPECTED DATA, RECEIVED DATA, AND XOR OF THE TWO
1712          ;THIS ROUTINE IS NORMALLY CALLED ONLY FOR PRINT ROUTINES.
1713          ;
1714          ;INPUTS:
1715          ;
1716          ;      R1      RECEIVED DATA
1717          ;      R2      EXPECTED DATA
1718          ;
1719          ;OUTPUT:
1720          ;
1721          ;      R0      XOR OF EXPECTED/RECEIVED DATA
1722          ;
1723          ;-
1724
1725 007500      PRI XOR::
1726 007500          SAVREG          ;SAVE THE REGISTERS
1727 007504      010203          MOV      R2,R3          ;EXPECTED DATA
1728 007506          XOR      R1,R3          ;FORM THE EXCLUSIVE OR
1729 C07516          PRINTB  *XORFOR,R2,R1,R3 ;PRINT THE MESSAGE
1730          007516      010346          MOV      R3,-(SP)
1731          007520      010146          MOV      R1,-(SP)
1732          007522      010246          MOV      R2,-(SP)
1733          007524      012746      007550          MOV      *XORFOR,-(SP)
1734          007530      012746      000004          MOV      *4,-(SP)
1735          007534      010600          MOV      SP,R0
1736          007536      104414          TRAP    C#PNTB
1737          007540      062706      000012          ADD      *12,SP
1738          007544      010300          MOV      R3,R0          ;R0 HAS XOR ON RETURN
1739          007546      000207          RTS      FC          ;RETURN TO CALLER
1740
1741          1730 007544      010300          MOV      R3,R0
1742          1731 007546      000207          RTS      FC
1743          1733 007550          045      116      045  XORFOR: .ASCIZ '##A EXPD: #06A RECV: #06A XOR: #06'
1744          1734          .EVEN

```

```

1736 .SBTTL PRIEQU - PRINT BIT NUMBERS AS ASCII EQUIVALENT
1737
1738 ;*
1739 ;
1740 ;ROUTINE TO CONVERT BIT VALUES TO ASCII AND PRINT THE STRING
1741 ;THIS ROUTINE IS NORMALLY CALLED FROM A PRINT ROUTINE
1742 ;
1743 ;INPUTS:
1744 ;
1745 ; R0 OCTAL VALUE TO CONVERT
1746 ; R1 TABLE OF POINTERS TO ASCII EQUIVALENT
1747 ;
1748 ;-
1749
1750 007616 PRIEQU: SAVREG ;SAVE THE REGISTERS
1751 007616 RTS PC ;RETURN TO CALLER
1752 007622 000207
1753
1754 .SBTTL PRIRAM - PRINT RAM ADDRESS
1755
1756 ;*
1757 ;
1758 ;PRINT CONTROLLER RAM ADDRESS.
1759 ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
1760 ;
1761 ;INPUTS:
1762 ;
1763 ; R4 RAM ADDRESS
1764 ;
1765 ;-
1766
1767 PRIRAM: SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
1768 007624 PRINTB #RAMFOR,R4 ;PRINT RAM ADDRESS IN ERROR
1769 007624 MOV R4,-(SP)
1770 007630 010446 MOV #RAMFOR,-(SP)
1771 007632 012746 007654 MOV #2,-(SP)
1772 007636 012746 000002 MOV SP,R0
1773 007642 010600 TRAP C#PNTB
1774 007644 104414 ADD #6,SP
1775 007646 062706 000006 RTS PC ;RETURN
1776
1777 1771 007654 045 116 045 RAMFOR: .ASCII 'MMA CONTROLLER RAM ADDRESS = #06'
1778 .EVEN
1779
1780 .SBTTL PRIADD - PRINT MEMORY ERROR ADDRESS
1781
1782 ;*
1783 ;
1784 ;PRINT MEMORY ADDRESS
1785 ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
1786 ;
1787 ; IMPLICIT INPUTS
1788 ;
1789 ; ERRHI - HIGH ORDER ADDRESS
1790 ; ERRLO - LOW ORDER ADDRESS

```

```

1787
1788
1789 007716
1790 007716
1791 007722 013700 002202
1792 007726 013701 002204
1793 007732 010102
1794 007734 006101
1795 007736 006100
1796 007740
    007740 010246
    007742 010046
    007744 012746 007766
    007750 012746 000003
    007754 010600
    007756 104414
    007760 062706 000010
1797 007764 000207
1798
1799 007766 045 116 045 PRIA0: .ASCIZ 'NWA MEMORY ERROR ADDRESS = #01#05'
1800 .EVEN
1801
1802
1803 .SBTTL PRITADD - PRINT MEMORY TEST ADDRESS
1804
1805 ;+
1806 ;PRINT MEMORY ADDRESS
1807 ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
1808 ;
1809 ; IMPLICIT INPUTS
1810 ;
1811 ; ERRHI - HIGH ORDER ADDRESS
1812 ; ERRLO - LOW ORDER ADDRESS
1813 ;
1814 ;-
1815 PRITADD:
1816 010032 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
1817 010036 MOV ERRHI,R0 ;GET HIGH ADDRESS
1818 010042 MOV ERRLO,R1 ;GET LOW ADDRESS
1819 010046 MOV R1,R2 ;COPY LOW ADDRESS
1820 010050 ROL R1 ;SHIFT BIT 15 TO C BIT
1821 010052 ROL R0 ;SHIFT INTO HIGH ORDER
1822 010054 PRINTB #PRIT0,R0,R2 ;PRINT MEMORY ADDRESS IN ERROR
    010054 MOV R2,-(SP)
    010056 MOV R0,-(SP)
    010060 MOV #PRIT0,-(SP)
    010064 MOV #3,(SP)
    010070 MOV SP,R0
    010072 TRAP C#PNTB
    010074 ADD #10,SP
1823 010100 RTS PC ;RETURN
1824
1825 010102 045 116 045 PRIT0: .ASCIZ 'NWA MEMORY TEST ADDRESS = #01#05'
1826 .EVEN
1827
1828
1829
    
```

```

1831                                     ,SBTTL SPACE - SPACE RECORDS (FORWARD AND REVERSE) COMMAND
1832
1833
1834
1835 ;ROUTINE TO ISSUE A SPACE RECORDS
1836 ;COMMAND (FORWARD OR REVERSE)
1837
1838 ;INPUT:
1839
1840 ;       R3      NUMBER OF RECORDS TO BE SPACED OVER
1841 ;             BIT15 CONTROLS DIRECTION
1842 ;             BIT15 = 0 IS FORWARD
1843 ;             BIT15 = 1 IS REVERSE
1844 ;       R5      FIRST DEVICE UNIBUS ADDRESS
1845
1846 ;             REQUIRES A WRITE CHARACTERISTICS DONE PREVIOUSLY
1847
1848 ;OUTPUT:
1849
1850 ;       CARRY   SET - SPACE RECORDS COMMAND OK
1851 ;             CLR - SPACE RECORDS FAILED
1852
1853
1854 ;       R0      THE CONTENTS OF R4 IS MOVED TO R0
1855
1856
1857 ;IMPLICIT OUTPUT:
1858
1859 ;             TAPE HAS BEEN MOVED
1860
1861 ;SIDE EFFECTS:
1862
1863
1864
1865
1866 010144 SPACE:: SAVREG ;SAVE THE GENERAL REGISTERS
1867 010144 MOV #500.,SDELAY ;SET UP DELAY
1868 010150 012737 000764 010340 MOV #140010,801 ;SET UP COMMAND, SPACE FORWARD
1869 010156 012737 140010 010330 TST R3 ;CHECK FOR DIRECTION
1870 010164 005703 BMI 51 ;BR, IF REVERSE INDICATED
1871 010166 100403 MOV R3,901 ;LOAD UP NUMBER OF RECORDS TO SPACE
1872 010170 010337 010332 BR 101 ;GO DO COMMAND
1873 010174 000407 BR 101 ;CLEAR DIRECTION BIT
1874 010176 042703 100000 51: BIC #BIT15,R3 ;LOAD UP NUMBER OF RECORDS TO SPACE
1875 010202 010337 010332 MOV R3,901 ;SET REVERSE BIT IN COMMAND PACKET
1876 010206 052737 000400 010330 BIS #BIT8,801 ;SET UP R4 WITH PACKET ADDRESS
1877 010214 012704 010330 101: MOV #801,R4 ;SEND OUT COMMAND
1878 010220 010465 177776 MOV R4,TSDB(R5) ;WAIT FOR SSR
1879 010224 004737 017134 151: JSR PC,WAITF ;BR, IF SSR IS SET AND OK
1880 010230 103420 BCS 201 ;DELAY ABOUT .25 SECONDS
1881 010232 DELAY 250
      010232 012727 000250 MOV #250,(PC),
      010236 000000 .WORD 0
      010240 013727 002116 MOV L#DLY,(PC),
      010244 000000 .WORD 0
      010246 005367 177772 DEC -6(PC)
      010252 001375 BNE , -4

```

C5

	010254	005367	177756		DEC	-2(PC)	
	010260	001367			BNE	-20	
1882	010262	005337	010340		DEC	SDELAY	!BUMP DELAY COUNTER DOWN
1883	010266	001356			BNE	15!	!BR, IF MORE DELAY
1884	010270	000411			BR	60!	!BR IF TROUBLE CARRY = CLEAR
1885	010272	016501	000000	20!:	MOV	TSSR(R5),R1	!READ TSSR
1886	010276	012702	000200		MOV	*SSR,R2	!SET UP EXPECTED
1887	010302	020201		25!:	CMP	R2,R1	!ARE THEY OK
1888	010304	001401			BEQ	40!	!BR, IF EQUAL = OK
1889	010306	000402			BR	60!	!TROUBLE EXIT
1890	010310	000261		40!:	SEC		!SET CARRY NO TROUBLE
1891	010312	000401			BR	70!	!EXIT
1892	010314	000241		60!:	CLC		!CARRY CLEAR = ERROR
1893	010316			70!:			
1894	010316	010400			MOV	R4,R0	!PASS PACKET ADDRESS
1895	010320	000207			RTS	PC	!RETURN

D5

1897			:		
1898			:		
1899			:		
1900			:	PACKET FOR SPACE COMMAND	
1901			:		
1903	010322		:	.BLKB 10-<.-TUV2A&7>	
1905			:		
1906			:	COMMAND WORD	
1907	010330	000000	:	80: .WORD	
1908			:	NUMBER OF RECORDS TO BE SPACED OVER WORD	
1909	010332	000000	:	90: .WORD	
1910	010334	000000	:	.WORD	
1911	010336	000000	:	.WORD	
1912	010340	000000	:	SDELAY: .WORD 0	:DELAY COUNTER
1913			:	.EVEN	

```

1915          .SBTTL WRTCHR - WRITE CHARACTERISTICS COMMAND
1916
1917
1918
1919          ;ROUTINE TO ISSUE A WRITE CHARACTERISTICS
1920          ;COMMAND SO THAT OTHER COMMANDS WILL BE ACCEPTED
1921
1922          ;INPUT:
1923
1924          R4      ADDRESS OF PACKET FROM TEST
1925          R5      FIRST DEVICE UNIBUS ADDRESS
1926          ;REQUIRES A CALL TO SOFINIT BE DONE PREVIOUSLY
1927
1928          ;OUTPUT:
1929
1930          R0      TSSR CONTENTS
1931          CARRY   SET - WRITE CHARACTERISTICS COMMAND OK
1932          CLR     - WRITE CHARACTERISTICS FAILED
1933
1934          ;IMPLICIT OUTPUT:
1935
1936          ;MESSAGE BUFFER AND OTHER BUFFERS ALL SET UP
1937          ;SOFTWARE SWITCHES SET AS FOLLOWS:
1938          ;BENBSW = BUFFER ENABLE SWITCH ON OR OFF
1939
1940
1941          ;SIDE EFFECTS:
1942
1943
1944
1945
1946 010342      WRTCHR::
1947 010342      SAVREG
1948 010346      CLR     BENBSW          ;SAVE THE GENERAL REGISTERS
1949 010352      MOV     R4,TSD8(R5)    ;CLEAR BUFFER ENABLE SWITCH
1950 010356      JSR     PC,CHKTSSR    ;SEND OUT COMMAND
1951 010362      BCS    20$           ;WAIT FOR SSR
1952 010364      BR     60$           ;BR, IF SSR IS SET AND OK
1953 010366      MOV     TSSR(R5),R1   ;BR IF TROUBLE CARRY = CLEAR
1954 010372      MOV     #SSR,R2      ;READ TSSR
1955 010376      BIT     #OFL,R1      ;SET UP EXPECTED
1956 010402      BEQ    25$           ;WAS OFF LINE SET IN TSSR
1957 010404      BIS     #OFL,R2      ;BR, IF NO OFL SET
1958 010410      CMP     R0,R1        ;MAKE THEM LOOK ALIKE
1959 010412      BEQ    40$           ;ARE THEY OK
1960 010414      BR     60$           ;BR, IF EQUAL = OK
1961 010416      ADD     #8.,R4        ;TROUBLE EXIT
1962 010422      MOV     (R4),R3      ;POINT TO WRT CHARA DATA PACKET
1963 010424      MOV     R3,MESBFA    ;GET ADDRESS OF MESSAGE BUFFER
1964 010430      SEC     SEC          ;STORE FOR PRINT ROUTINES
1965 010432      BR     70$           ;SET CARRY NO TROUBLE
1966 010434      CLC     CLC          ;EXIT
1967 010436      MOV     TSSR(R5),R0  ;CARRY CLEAR = ERROR
1968 010442      RTS     RTS          ;RETURN TSSR CONTENTS
1969
1970          ;RETURN

```



```

1972 .SBTTL REWIND - POSITION TAPE (REWIND) COMMAND
1973
1974
1975 ; THIS ROUTINE WILL REWIND THE SELECTED TAPE.
1976
1977 ; CAUTION: THE ROUTINE DOES NOT WAIT FOR BOT
1978 ; TO ARRIVE. ALSO THE CALLER MUST CHECK FOR
1979 ; SSR TO SET IN THE TSSR
1980
1981
1982 ; CALLING SEQUENCE:
1983
1984 ; DO A SOFT INIT
1985 ; DO A WRITE CHARACTERISTICS
1986 ; JSR PC,REWIND
1987
1988 ; INPUT:
1989
1990 ; R5 FIRST DEVICE UNIBUS ADDRESS
1991
1992
1993 ; OUTPUT
1994
1995 ; R0 THE CONTENTS OF R4 IS PASSED TO R0
1996
1997 010444
1998 010444
1999 010450 012704 010540
2000 010454 010465 177776
2001 010460 012703 000550
2002 010464 004737 017134
2003 010470 103417
2004 010472
    010472 012727 000372
    010476 000000
    010500 013727 002116
    010504 000000
    010506 005367 177772
    010512 001375
    010514 005367 177756
    010520 001367
2005 010522 005303
2006 010524 001357
2007 010526 000241
2008 010530 010400
2009 010532 000207
2011 010534
2013 010540
2014 010540 102010
2015 010542 000000

; REWIND:
; SAVREG
; MOV #RWPACK,R4 ;SAVE R1-R5 UNTIL NEXT RETURN
; MOV R4,TSD8(R5) ;GET PACKET ADDRESS
; MOV #360.,R3 ;SEND PACKET ADDRESS TO EXECUTE
; JSR PC,WAITF ;ENOUGH TIME FOR 2400' REEL TO REWIND
; BCS 20 ;WAIT FOR SSR TO SET
; DELAY 250. ;LEAVE WHEN SSR IS SET
; MOV #250.,(PC)+ ;WAIT FOR .25 SECONDS
; .WORD 0
; MOV L#DLY,(PC)+
; .WORD 0
; DEC -6(PC)
; BNE .-4
; DEC -22(PC)
; BNE .-20
; DEC R3 ;BUMP COUNTER DOWN
; BNE 10 ;KEEP GOING
; CLC ;CLEAR CARRY TO SET ERROR
; MOV R4,R0 ;PASS THE PACKET ADDRESS
; RTS PC ;RETURN
; .BLKB 10-<.-TUV2A&7>

RWPACK:
; .WORD 102010 ;POSITION COMMAND (REWIND)
; .WORD 0 ;NOT USED
    
```

```

2017 .SBTTL CKRAM - COMPARE RAM TO I/O PACKET
2018
2019
2020
2021 ;ROUTINE TO READ THE FIRST 8 BYTES FROM RAM
2022 ;MEMORY AND COMPARE THIS DATA TO A COMMAND PACKET.
2023
2024 ;INPUT:
2025
2026 ; R4 ADDRESS OF THE COMMAND PACKET
2027 ; R5 FIRST DEVICE UNIBUS ADDRESS
2028
2029 ;OUTPUT:
2030
2031 ; CARRY SET - RAM MATCHES PACKET
2032 ; CLR - RAM DOES NOT MATCH PACKET
2033
2034 ;IMPLICIT OUTPUT:
2035
2036 ; THE TABLE RAMDATA IS FILLED WITH THE
2037 ; DATA HELD IN RAM.
2038 ; RAMSIZ IS SET TO 8. FOR PRAMPKT ROUTINE
2039
2040 ;SIDE EFFECTS:
2041
2042
2043
2044
2045 010544 CKRAM:: SAVREG ;SAVE THE GENERAL REGISTERS
2046 010544 MOV #RAMDATA,R1 ;ADDRESS TO SAVE THE RAM DATA
2047 010550 012701 002206 MOV #RMPKTBEG,R2 ;BYTE ADDRESS OF FIRST RAM DATA
2048 010554 012702 000020 CLR R3 ;CLEAR THE ERROR FLAG
2049 010560 005003 JSR PC,CHKTSSR ;WAIT FOR SSR
2050 010562 004737 017252 10$: JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
2051 010566 004737 017252 MOV# R2,TSDBH(R5) ;SELECT NEXT RAM ADDRESS
2052 010572 110265 177777 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
2053 010576 004737 017252 MOV# TSBAL(R5),(R1) ;READ THE RAM DATA
2054 010602 116511 177776 CMPB (R1)+,(R4)+ ;COMPARE TO EXPECTED
2055 010606 122124 BEQ 20$ ;BRANCH IF OK
2056 010610 001401 INC R3 ;SET ERROR FLAG
2057 010612 005203 20$: INC R2 ;ADDRESS OF NEXT RAM LOCATION
2058 010614 005202 CMP R2,#RMPKTEND ;REACHED END YET ?
2059 010616 020227 000027 BLE 10$ ;BRANCH TILL ALL READ
2060 010622 003761 TST R3 ;WAS AN ERROR FOUND ?
2061 010624 005703 BEQ 30$ ;BRANCH IF NOT
2062 010626 001402 CLC ;CLEAR CARRY TO SHOW ERROR
2063 010630 000241 BR 50$ ;AND EXIT
2064 010632 000401 SEC ;SHOW GOOD COMPARE
2065 010634 000261 30$: MOV #8,,RAMSIZ ;SETUP RAMSIZ FOR PRAMPKT ROUTINE
2066 010636 012737 000010 002246 50$: MOV PC ;RETURN
2067 010644 000207

```

2070				.SBTTL RAMER - READ AND DISPLAY SELECTED RAM	
2071				;	
2072				;	
2073				ROUTINE TO READ THE SELECTED RAM LOCATIONS	
2074				;	
2075				INPUT:	
2076				;	
2077				R5 FIRST DEVICE UNIBUS ADDRESS	
2078				CONSOLE WILL ALSO BE PRINTED TO	
2079				;	
2080				IMPLICIT OUTPUT:	
2081				;	
2082				THE TABLE RAMDATA IS FILLED WITH THE	
2083				DATA HELD IN RAM.	
2084				;	
2085				SIDE EFFECTS:	
2086				;	
2087				;	
2088				;	
2089				;	
2090	010646			RAMER::	
2091	010646			SAVREG	SAVE THE GENERAL REGISTERS
2092	010652	013705	011032	MOV RAMR5H,R5	RESET R5 TO FIRST DEVICE REGISTER
2093	010656	012701	002206	MOV #RAMDATA,R1	ADDRESS TO SAVE THE RAM DATA
2094	010662	013702	011030	MOV RAMLD,R2	BYTE ADDRESS OF THE FIRST RAM DATA
2095	010666	013703	002246	MOV RAMSIZ,R3	SET THE SIZE OF THE READ UP
2096	010672	004737	017252	10\$: JSR PC,CHKTSSR	WAIT FOR THE SSR TO SET
2097	010676	110265	177777	MOV R2,TSDBH(R5)	SELECT NEXT RAM ADDRESS
2098	010702	004737	017252	JSR PC,CHKTSSR	WAIT FOR SSR TO SET
2099	010706	116521	177776	MOV R2,TSDBH(R5),(R1)+	READ THE RAM DATA
2100	010712	062702	000001	20\$: ADD #1,R2	ADDRESS OF THE NEXT RAM LOCATION
2101	010716	077313		SOB R3,10	NUMBER OF LOCATIONS COUNTER
2102	010720	013704	002246	MOV RAMSIZ,R4	GET THE RAM SIZE
2103	010724	013702	011030	MOV RAMLD,R2	GET THE STARTING RAM ADDRESS
2104	010730	060204		ADD R2,R4	CALCULATE THE END ADDRESS
2105	010732	162704	000001	SUB #1,R4	CORRECT VALUE OF PRINTOUT
2106	010736			PRINTX #RAMIOP,R2,R4	RAM ADDRESS = 10 - 17, ETC.
	010736	010446		MOV R4,-(SP)	
	010740	010246		MOV R2,-(SP)	
	010742	012746	011034	MOV #RAMIOP,-(SP)	
	010746	012746	000003	MOV #3,-(SP)	
	010752	010600		MOV SP,R0	
	010754	104415		TRAP C#PNTX	
	010756	062706	000010	ADD #10,SP	
2107	010762	012701	002206	MOV #RAMDATA,R1	ADDRESS OF WHERE RAM DATA IS
2108	010766	013703	002246	MOV RAMSIZ,R3	THE SIZE OF THE RAM FIELD READ
2109	010772	005304		30\$: CLR R4	NO EXTRA DATA LEFT OVER
2110	010774	112104		MOV R4,(R1)+,R4	PICK UP BYTE OF RAM DATA
2111	010776	042704	177400	BIC #177400,R4	GET RID OF SIGN EXTEND
2112	011002			PRINTX #RAMPD,R4	"010 211 111 222 377 000 123 134 ETC."
	011002	010446		MOV R4,-(SP)	
	011004	012746	011105	MOV #RAMPD,-(SP)	
	011010	012746	000002	MOV #2,-(SP)	
	011014	010600		MOV SP,R0	
	011016	104415		TRAP C#PNTX	
	011020	062706	000006	ADD #6,SP	
2113	011024	077316		SOB R3,30	LOOP UNTIL ALL PRINTED

```

2114 011026 000207          504:  RTS      PC          ;RETURN
2115
2116 011030 000000          RAM#LD: .WORD 0          ;RAM ADDR HOLDER 1ST ADDRESS
2117 011032 000000          RAM#5H: .WORD 0          ;HOLDS R5 FOR LATER
2118 011034      045      116      045  RAMIOP: .ASCIZ '##A Ram Address (Octal) = #03##A - #03##N'
2119 011105      045      101      040  RAMPD: .ASCIZ '#A #03##A '
2120
2121

```

```

2123 .SBTTL CKRAM2 - COMPARE RAM TO I/O CHARACTERISTICS DATA
2124 ;*
2125 ;
2126 ;ROUTINE TO READ THE FIRST 8 OR 10 BYTES FROM RAM
2127 ;MEMORY AND COMPARE THIS DATA TO A CHARACTERISTICS DATA BLOCK.
2128 ;
2129 ;INPUT:
2130 ;
2131 ; R4 ADDRESS OF THE CHARACTERISTICS DATA
2132 ; R5 FIRST DEVICE UNIBUS ADDRESS
2133 ;
2134 ;OUTPUT:
2135 ;
2136 ; CARRY SET - RAM MATCHES PACKET
2137 ; CLR - RAM DOES NOT MATCH PACKET
2138 ;
2139 ;IMPLICIT OUTPUT:
2140 ;
2141 ; THE TABLE RAMDATA IS FILLED WITH THE
2142 ; DATA HELD IN RAM,
2143 ; RAMSIZ IS SET TO 8, OR 10, FOR PRAMPKT ROUTINE
2144 ;
2145 ;SIDE EFFECTS:
2146 ;
2147 ;
2148 ;-
2149
2150 011120 CKRAM2::
2151 011120 SAVREG ;SAVE THE GENERAL REGISTER
2152 011124 012701 002206 MOV #RAMDATA,R1 ;ADDRESS TO SAVE THE RAM DATA
2153 011130 012702 000167 MOV #RMCHBEG,R2 ;BYTE ADDRESS OF FIRST RAM DATA
2154 011134 005003 CLR R3 ;CLEAR THE ERROR FLAG
2155 011136 004737 017252 JSR PC,CHKTSSR ;WAIT FOR SSR
2156 011142 004737 017252 10$: JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
2157 011146 110265 177777 MOVB R2,TSDBH(R5) ;SELECT NEXT RAM ADDRESS
2158 011152 004737 017252 JSR PC,CHKTSSR ;WAIT FOR SSR TO SET
2159 011156 116511 177776 MOVB TSBAL(R5),(R1) ;READ THE RAM DATA
2160 011162 122124 CMPEB (R1)+,(R4)+ ;COMPARE TO EXPECTED
2161 011164 001401 BEQ 20$ ;BRANCH IF OK
2162 011166 005203 INC R3 ;SET ERROR FLAG
2163 011170 005202 20$: INC R2 ;ADDRESS OF NEXT RAM LOCATION
2164 011172 012737 000010 002246 MOV #8, RAMSIZ ;ASSUME NORMAL NOT SET
2165 011200 020227 000176 CMP R2,#RMCHEND-2 ;REACHED END YET ?
2166 011204 005756 BLE 10$ ;BRANCH TILL ALL READ
2167 011206 005703 27$: TST R3 ;WAS AN ERROR FOUND ?
2168 011210 001402 BEQ 30$ ;BRANCH IF NOT
2169 011212 000241 CLC ;CLEAR CARRY TO SHOW ERROR
2170 011214 000401 BR 50$ ;AND EXIT
2171 011216 000251 30$: SEC ;SHOW GOOD COMPARE
2172 011220 000207 50$: RTS PC ;RETURN

```

```

2174          .SBTTL  CKMSG  - COMPARE WRITE CHAR. MESSAGE BUFFERS
2175          ;+
2176          ;
2177          ;ROUTINE TO COMPARE A WRITE CHARACTERISTICS EXPD AND RECV
2178          ;BUFFER. THE EXPECTED AND RECEIVED BUFFERS ARE STORED FOR
2179          ;ERROR PRINT ROUTINES.
2180          ;
2181          ;INPUT:
2182          ;
2183          ;      R0      RECV MESSAGE BUFFER HIGH ORDER ADDRESS
2184          ;      R1      RECV MESSAGE BUFFER LOW ORDER ADDRESS
2185          ;      R2      EXPD MESSAGE BUFFER ADDRESS
2186          ;OUTPUT:
2187          ;
2188          ;      CARRY   SET - MESSAGE BUFFERS MATCH
2189          ;             CLR -MESSAGE BUFFERS DON'T MATCH
2190          ;
2191          ;IMPLICIT OUTPUT:
2192          ;
2193          ;      EXPMSG   BUFFER IS SET TO EXPD DATA
2194          ;      RECMMSG  BUFFER IS SET TO RECV DATA
2195          ;      RCVHIADD SET TO HIGH ORDER ADDRESS OF RECV
2196          ;      RCVLOADD SET TO LOW ORDER ADDRESS OF RECV
2197          ;
2198          ;-
2199          CKMSG::
2200          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
2201          MOV      R0,RCVHIADD ;SAVE RECV HIGH ADDRESS
2202          MOV      R1,RCVLOADD ;SAVE RECV LOW ADDRESS
2203          TST      KTENABLE    ;TESTING ABOVE 28K?
2204          BEQ      10$         ;BR IF NO
2205          JSR      PC,SETMAP    ;RETURN ADDRESS BIASED TO PAR6 IN R0
2206          MOV      R0,R1      ;GET RETURNED ADDRESS BIASED TO PAR6
2207          10$:  CLR      R4      ;WORD IN BUFFER
2208          CLR      R3          ;CLEAR ERROR SEEN FLAG
2209          MOV      R2,R5      ;GET EXPD BUFFER ADDRESS
2210          15$:  MOV      (R2),EXPMSG(R4) ;SAVE EXPD FOR ERROR REPORT
2211          MOV      (R1),RECMMSG(R4) ;SAVE RECV FOR ERROR REPORT
2212          CMP      (R2)+,(R1)+ ;EXPD EQUAL RECV?
2213          BEQ      25$         ;BR IF YES
2214          INC      R3          ;SET ERROR SEEN FLAG
2215          25$:  ADD      #2,R4    ;POINT TO NEXT WORD ADDRESS
2216          CMP      R4,#14     ;DONE FIRST 7 WORDS?
2217          BLE     15$         ;BR IF NO
2218          BIT      #X2.EXTF,XST2(R5);IS EXTENDED FEATURES SET IN EXPD?
2219          BEQ      50$         ;BR IF NO
2220          CMP      R4,#16     ;DONE EXTENDED FEATURES WORD?
2221          BLE     15$         ;BR IF NO
2222          50$:  TST      R3          ;ANY ERRORS SEEN?
2223          BEQ      55$         ;BR IF NO
2224          CLC          ;SET FAILURE
2225          BR      60$         ;
2226          55$:  SEC          ;SET SUCCESS
2227          60$:  RTS      PC      ;RETURN
2228

```

```

2230          .SBTTL  CKMSG2  - COMPARE EXPD RECV MESSAGE BUFFERS
2231          ;*
2232          ;
2233          ;ROUTINE TO COMPARE AN EXPECTED AND RECEIVED MESSAGE
2234          ;BUFFER. THE EXPECTED AND RECEIVED BUFFERS ARE STORED FOR
2235          ;ERROR PRINT ROUTINE'S.
2236          ;
2237          ;INPUT:
2238          ;
2239          ;       R0      RECV MESSAGE BUFFER HIGH ORDER ADDRESS
2240          ;       R1      RECV MESSAGE BUFFER LOW ORDER ADDRESS
2241          ;       R2      EXPD MESSAGE BUFFER ADDRESS
2242          ;       R3      NUMBER OF BYTES TO COMPARE
2243          ;
2244          ;OUTPUT:
2245          ;
2246          ;       CARRY   SET - MESSAGE BUFFER; MATCH
2247          ;              CLR - MESSAGE BUFFERS DON'T MATCH
2248          ;
2249          ;IMPLICIT OUTPUT:
2250          ;
2251          ;       EXPMSG   BUFFER IS SET TO EXPD DATA
2252          ;       RECVMSG  BUFFER IS SET TO RECV DATA
2253          ;       RCVHIADD SET TO HIGH ORDER ADDRESS OF RECV
2254          ;       RCVLOAD  SET TO LOW ORDER ADDRESS OF RECV
2255          ;
2256          ;-
2257 011342      CKMSG2::
2258 011342      SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
2259 011346      CMP            R3,#RECVMSG-EXPMSG,#000  ;COUNT ABOVE MAX ALLOWED?
2260 011352      BLE            5#          ;000 BR IF NO
2261 011354      MOV            #RECVMSG-EXPMSG,R3,#000
2262 011360      PRINTF         #DEBUGMSG          ;000
2263          011360      MOV            #DEBUGMSG,-(SP)
2264          011364      MOV            #1,-(SP)
2265          011370      MOV            SP,R0
2266          011372      TRAP         C#PNTF
2267          011374      ADD            #4,SP
2268 011400      5#:          MOV            R0,RCVHIADD      ;SAVE RECV HIGH ADDRESS
2269 011404      MOV            R1,RCVLOAD      ;SAVE RECV LOW ADDRESS
2270 011410      TST            KTENABLE      ;TESTING ABOVE 28K?
2271 011414      BEQ            10#          ;BR IF NO
2272 011416      JSR            PC,SETMAP      ;RETURN ADDRESS BIASED TO PAR6 IN R0
2273 011422      MOV            R0,R1      ;GET RETURNED ADDRESS BIASED TO PAR6
2274 011424      10#:       CLR            R4      ;WORD IN BUFFER
2275 011426      CLR            R5      ;CLEAR ERROR SEEN FLAG
2276 011430      15#:       MOVB         (R2),EXPMSG(R4) ;SAVE EXPD FOR ERROR REPORT
2277 011434      MOVB         (R1),RECVMSG(R4) ;SAVE RECV FOR ERROR REPORT
2278 011440      CMPEB        (R2)+,(R1)+ ;EXPD EQUAL RECV?
2279 011442      BEQ            25#          ;BR IF YES
2280 011444      INC            R5      ;SET ERROR SEEN FLAG
2281 011446      25#:       ADD            #1,R4      ;POINT TO NEXT BYTE
2282 011452      CMP            R4,R3      ;DONE ALL BYTES?
2283 011454      BGE            50#          ;BR IF YES
2284 011456      BR            15#          ;DO NEXT BYTE
2285 011460      50#:       TST            R5      ;ANY ERRORS SEEN?
2286 011462      BEQ            55#          ;BR IF NO

```

M5

```
2282 011464 000241          CLC          ;SET FAILURE
2283 011466 000401          BR          60$          ;
2284 011470 000261          55$: SEC          ;SET SUCCESS
2285 011472 000207          60$: RTS          PC          ;RETURN
2286
2287 011474          120          122          117 DEBUGMSG: .ASCIZ 'PROGRAM INTERNAL ERROR -CKMSG2 MESSAGE BUFFER EXCEEDED-' ;000
2288 011564          045          116          045 FERCM: .ASCII /*N/A ***/
2289 011575          040          040          124 ERCM: .ASCIZ / TSSR ERROR CODE REC'D - /
2290 011630          056          056          056 SIMSG: .ASCIZ /... AFTER DOING SOFT INIT/
2291 011663          124          105          123 TINERR: .ASCIZ /TEST: .../
2292 .EVEN
```



```

2294
2295
2296
2297
2298
2299
2300
2301
2302
2303
2304
2305
2306
2307
2308
2309
2310 011676
      011676
2311 011676 004737 005264
2312 011702 004737 020170
2313 011706
      011706
      011706 104423
2314
2315
2316
2317
2318
2319
2320
2321
2322
2323
2324
2325
2326 011710
      011710
2327 011710 004737 005264
2328 011714 012700 009004
2329 011720 004737 007076
2330 011724 013700 002716
2331 011730 005001
2332 011732 004737 014072
2333 011736
      011736
      011736 104423
2334
2335
2336
2337
2338
2339
2340
2341
2342
2343
2344

;+
;PRINT ROUTINE TO FATAL SOFT INIT ERRORS
;
;INPUT:
;
;   R1      CONTENTS OF TSSR AT ERROR
;
;SIDE EFFECTS:
;
;   EXECUTES DROP UNIT TO CEASE TESTING
;
;-

      BGNMSG  SFMSG
SFMSG:: JSR    PC,PRITSSR    ;PRINT CONTENTS OF TSSR REGISTER
        JSR    PC,CKDROP   ;DROP UNIT, IF ALLOWED
        ENDMSG
L10003: TRAP    C#MSG

;+
;PRINT ROUTINE TO PRINT THE CONTENTS OF
;TSSR AND A COMMAND PACKET OTHER THAN GET STATUS COMMAND PACKET.
;
;INPUTS:
;
;   R1      TSSR CONTENTS
;   R4      ADDRESS OF COMMAND PACKET
;
;-

      BGNMSG  PKTSSR
PKTSSR:: JSR    PC,PRITSSR    ;PRINT THE CONTENTS OF TSSR REGISTER
         MOV    #4,R0        ;NO. OF WORDS IN PACKET
         JSR    PC,PRIPKT   ;PRINT THE CONTENTS OF COMMAND PACKET
         MOV    MESBFA,R0   ;ADDRESS OF MESSAGE BUFFER
         CLR    R1          ;ASSUME NO HIGH MEMORY
         JSR    PC,PRMESS   ;PRINT THE MESSAGE BUFFER ALSO
         ENDMSG
L10004: TRAP    C#MSG

;+
;PRINT ROUTINE TO PRINT THE CONTENTS OF
;TSSR AND A GET STATUS COMMAND PACKET.
;
;INPUTS:
;
;   R1      TSSR CONTENTS
;   R4      ADDRESS OF COMMAND PACKET
;
;-

```

B6

```

2345
2346 011740          BGNMSG  PKTGETS
      011740          PKTGETS:
2347 011740 004737 005264      JSR    PC,PRITSSR      ;PRINT THE CONTENTS OF TSSR REGISTER
2348 011744 012700 000002      MOV    #2,R0          ;NO. OF WORDS IN GET STATUS PACKET
2349 011750 004737 007076      JSR    PC,PRIPKT      ;PRINT THE CONTENTS OF COMMAND PACKET
2350 011754          ENDMMSG
      011754          L10005:
      011754 104423      TRAP   C#MSG

2351
2352
2353
2354          ;PRINT TSSR ERRORS FOR INITIALIZATION TESTS
2355          ;
2356          ;INPUTS:
2357          ;
2358          ;      R1      TSSR CONTENTS
2359          ;      R4      ADDRESS OF COMMAND PACKET
2360          ;
2361          ;
2362 011756          BGNMSG  SFFMSG
      011756          SFFMSG:
2363 011756 004737 005264      JSR    PC,PRITSSR      ;PRINT CONTENTS OF TSSR REGISTER
2364 011762          ENDMMSG
      011762          L10006:
      011762 104423      TRAP   C#MSG

2365
2366
2367          .SBTTL  PKTMES - PRINT TSSR AND MESSAGE BUFFER
2368          ;
2369          ;
2370          ;PRINT ROUTINE TO PRINT THE CONTENTS OF TSSR AND MESSAGE
2371          ;BUFFER FOR ERROR REPORTS
2372          ;
2373          ;INPUTS:
2374          ;
2375          ;      R1      CONTENTS OF TSSR
2376          ;      R2      LOW ORDER MESSAGE BUFFER
2377          ;      R3      HIGH ORDER MESSAGE BUFFER ADDRESS
2378          ;      NOTE: R3 IS IGNORED IF KTENABLE FLAG IS CLEAR
2379          ;
2380 011764          BGNMSG  PKTMES
      011764          PKTMES:
2381 011764 004737 005264      JSR    PC,PRITSSR      ;PRINT CONTENTS OF TSSR
2382 011770 010200          MOV    R2,R0          ;LOW ORDER ADDRESS
2383 011772 010301          MOV    R3,R1          ;HIGH ORDER ADDRESS
2384 011774 004737 014072      JSR    PC,PRMESS      ;PRINT THE MESSAGE BUFFER
2385 012000          ENDMMSG
      012000          L10007:
      012000 104423      TRAP   C#MSG

2386

```



```

2426 .SBTTL FIFEXP - PRINT FIFO EXP/RECV DATA
2427
2428
2429 ;PRINT ROUTINE TO PRINT FIFO EXP/RECV DATA
2430
2431 ; R1 - BYTE COUNT
2432
2433 ;IMPLICIT INPUTS:
2434
2435 ; EXPMSG - EXPECTED MESSAGE BUFFER (CONTAINS FIFO DATA ONLY)
2436 ; RECVMSG - RECEIVED MESSAGE BUFFER (CONTAINS FIFO DATA ONLY)
2437
2438 012032 BGNMSG FIFEXP
012032
2439 012032 FIFEXP::
012032 010146 PRINTX #FIF1MSG,R1 ;PRINT BYTES TRANSFERRED
012034 012746 012104 MOV R1,-(SP)
012040 012746 000002 MOV #FIF1MSG,-(SP)
012044 010600 MOV #2,-(SP)
012046 104415 MOV SP,R0
012050 062706 000006 TRAP C#PNTX
2440 012054 ADD #6,SP
012054 012746 012153 PRINTX #FIF2MSG ;PRINT HEADER MSG
012060 012746 000001 MOV #FIF2MSG,-(SP)
012064 010600 MOV #1,-(SP)
012066 104415 MOV SP,R0
012070 062706 000004 TRAP C#PNTX
2441 012074 010100 ADD #4,SP
2442 012076 004737 016006 MOV R1,R0 ;GET BYTE COUNT
2443 012102 JSR PC,PRBYTEXP ;PRINT FIFO BYTES IN ERROR
012102 ENDMSG
012102
012102 104423 L10012: TRAP C#MSG
2444 012104 045 116 045 FIF1MSG: .ASCIZ '#N#A NUMBER OF BYTES TRANSFERRED = #D2'
2445 012153 045 116 045 FIF2MSG: .ASCIZ '#N#A FIFO DATA BYTES IN ERROR:'
2446 .EVEN
2447

```

```

2449          .SBTTL MSGSTAT - PRINT STATUS HEADER AND MESSAGE BUFFERS
2450          ;*
2451          ;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RCV
2452          ;
2453          ;
2454          ;
2455          ;IMPLICIT INPUTS:
2456          ;
2457          ;   EXPMSG - EXPECTED MESSAGE BUFFER
2458          ;   RECMSG - RECEIVED MESSAGE BUFFER
2459          ;   RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
2460          ;   RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
2461          ;
2462          ;-
2462 012212      BGNMSG MSGSTAT
2463 012212      MSGSTAT:
2463 012212 012701 012254      MOV     #STATCOD,R1      ;ASCII ADDRESS TABLE
2464 012216 012100      10#:  MOV     (R1)+,RO      ;DONE ALL MSG LINES?
2465 012220 001410      BEQ     20#      ;BR IF YES
2466 012222      PRINTX RO      ;PRINT STATUS BIT NAMES
2466 012222 010046      MOV     RO,-(SP)
2466 012224 012746 000001      MOV     #1,-(SP)
2466 012230 010600      MOV     SP,RO
2466 012232 104415      TRAP   C#PNTX
2466 012234 062706 000004      ADD     #4,SP
2467 012240 000766      BR     10#      ;DO ANOTHER MSG LINE
2468 012242 012700 000012      20#:  MOV     #10.,RO      ;NUMBER OF WORDS IN A READ STATUS BUFFER
2469 012246 004737 015436      JSR     PC,PRMSGEXP      ;PRINT EXPD/RCV MESSAGE BUFFERS
2470 012252      ENDMMSG
2470 012252      L10013:
2470 012252 104423      TRAP   C#MSG
2471
2472 012254 012272 012334 012425 STATCOD: .WORD 1#,2#,3#,4#,5#,6#,0
2473 012272 045 116 045 1#: .ASCIZ 'MMA Tape Bus Signals in Word #8:'
2474
2475
2476 012334 045 116 045 2#: .ASCIZ 'MMA PARERR<15> IEOT <12> IFMK <9> IRDY<6> IRWD<2>'
2477 012425 045 116 045 3#: .ASCIZ 'MMA IRESV2<14> IIDENT<11> IHER <8> IONL<5> IFBY<1>'
2478 012516 045 116 045 4#: .ASCIZ 'MMA IRESV1<13> ICER <10> ISPEED<7> ILDP<4> IFPT<0>'
2479 012607 045 116 045 5#: .ASCIZ 'MMA Tape Bus Signals in Word #9:'
2480 012651 045 116 045 6#: .ASCIZ 'MMA DATMIS<7> ILW<6> OUTRDY<5> INRDY<4>'
2481          .EVEN
2482
2483          .SBTTL MSGLOOP - PRINT LOOPBACK HEADER AND MESSAGE BUFFERS
2484          ;*
2485          ;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RCV
2486          ;
2487          ;
2488          ;
2489          ;IMPLICIT INPUTS:
2490          ;
2491          ;   EXPMSG - EXPECTED MESSAGE BUFFER
2492          ;   RECMSG - RECEIVED MESSAGE BUFFER
2493          ;   RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
2494          ;   RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
2495          ;
2496          ;-
2497 012726      BGNMSG MSGLOOP

```

F6

```

012726
2498 012726 012701 012770
2499 012732 012100
2500 012734 001410
2501 012736
    012736 010046
    012740 012746 000001
    012744 010600
    012746 104415
    012750 062706 000004
2502 012754 000766
2503 012756 012700 000012
2504 012762 004737 015436
2505 012766
    012766
    012766 104423
2506
2507 012770 013010 013063 013162
2508 013010 045 116 045
2509 013063 045 116 045
2510 013162 045 116 045
2511 013261 045 116 045
2512 013360 045 116 045
2513 013457 045 116 045
2514 013556 045 116 045
2515
2516
MSGLOOP:
10: MOV @LOOPCOD,R1 ;ASCII ADDRESS TABLE
    MOV (R1)+,R0 ;DONE ALL MSG LINES?
    BEQ 20$ ;BR IF YES
    PRINTX R0 ;PRINT STATUS BIT NAMES
    MOV R0,-(SP)
    MOV #1,-(SP)
    MOV SP,R0
    TRAP C#PNTX
    ADD #4,SP
    BR 10$ ;DO ANOTHER MSG LINE
20: MOV #10,R0 ;NUMBER OF WORDS IN A READ STATUS BUFFER
    JSR PC,PRMSGEXP ;PRINT EXPD/RECV MESSAGE BUFFERS
    ENDMMSG
L10014:
    TRAP C#MSG
LOOPCOD: .WORD 1$,2$,3$,4$,5$,6$,7$,0
1$: .ASCIZ 'NNA Tape Bus Loopback Signals in Word #8:'
2$: .ASCIZ 'NNA PARERR<15> IRESV2<14> IRESV1<13>'
3$: .ASCIZ 'NNA IHISP=>IEOT<12> IWRT=>IIDENT<11> IREV =>ICER <10>'
4$: .ASCIZ 'NNA IWM =>IFMK<09> IEDIT=>IHER <08> IFAD =>ISPEED<07>'
5$: .ASCIZ 'NNA ITADO=>IRDY<06> ITAD1=>IONL <05> IERASE=>ILDOP <04>'
6$: .ASCIZ 'NNA IREW =>IDBY<03> IRWU =>IRWD <02> IFEN =>IFBY <01>'
7$: .ASCIZ 'NNA IGO =>IFPT<00>'
    .EVEN

```

G6

```
2518 .SBTTL MSGSUB - PRINT WRITE SUBSYSTEM MESSAGE BUFFER
2519 ;+
2520 ;
2521 ;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RCV
2522 ;
2523 ;
2524 ;IMPLICIT INPUTS:
2525 ;
2526 ; EXPMSG - EXPECTED MESSAGE BUFFER
2527 ; RECMMSG - RECEIVED MESSAGE BUFFER
2528 ; RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
2529 ; RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
2530 ;-
2531 013604 BGNMSG MSGSUB
      013604 MSGSUB::
2532 013604 012700 000012 MOV #10.,R0 ;SIZE OF WRITE SUBSYSTEM BUFFER
2533 013610 004737 015436 JSR PC,PRMSGEXP ;PRINT EXPD/RCV MESSAGE BUFFERS
2534 013614 ENDMMSG
      013614 L10015:
      013614 104423 TRAP C#MSG
2535
2536
2537
2538
2539
2540 .SBTTL MEMADD - PRINT MEMORY ADDRESS DATA ERROR
2541 ;+
2542 ;
2543 ;PRINT ROUTINE TO PRINT MEMORY ADDRESS DATA COMPARE ERROR
2544 ;
2545 ;IMPLICIT INPUTS:
2546 ;
2547 ; ERRHI - MEMORY ERROR HIGH ORDER ADDRESS
2548 ; ERRLO - MEMORY ERROR LOW ORDER ADDRESS
2549 ; EXP - EXPECTED DATA
2550 ; RECV - RECEIVED DATA
2551 ;-
2552 013616 BGNMSG MEMADD
      013616 MEMADD::
2553 013616 004737 007716 JSR PC,PRIADD ;PRINT MEMORY ADDRESS IN ERROR
2554 013622 013701 002176 MOV EXPD,R1 ;GET EXPD DATA
2555 013626 013702 002200 MOV RECV,R2 ;GET RECEIVED DATA
2556 013632 004737 007500 JSR PC,PRIXOR ;PRINT EXPD/RCV
2557 013636 ENDMMSG
      013636 L10016:
      013636 104423 TRAP C#MSG
2558
```

```

2560 .SBTTL PRAMPKT - PRINT RAM AND PACKET DATA
2561 ;*
2562 ;
2563 ;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
2564 ;WHEN THE RAM DATA DOES NOT MATCH.
2565 ;
2566 ;INPUTS:
2567 ;
2568 ; R4 POINTER TO COMMAND PACKET
2569 ;
2570 ;IMPLICIT INPUTS:
2571 ;
2572 ; RAMDATA DATA AS READ FROM THE RAM
2573 ; RAMSIZ NUMBER OF BYTES IN PACKET
2574 ; IF RAMSIZ=0 THEN DEFAULT TO 8.
2575 ;
2576 ;IMPLICIT OUTPUTS:
2577 ;
2578 ; RAMSIZ SET TO 0
2579 ;
2580 ;
2581 PRAMPKT:
2582 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
2583 MOV #RAMDATA,R1 ;DATA FROM THE RAM
2584 CLR R2 ;INIT BYTE NUMBER
2585 5$: CMPB (R1)+,(R4)+ ;COMPARE EXPECTED, RECEIVED
2586 BNE 7$ ;BR IF NO MATCH
2587 7$: MOVB -1(R1),R5 ;GET RECV RAM DATA
2588 MOVB -1(R4),R3 ;GET EXPD PACKET DATA
2589 XOR R5,R3 ;XOR EXPD/RECV
2590 BIC #177400,R3 ;LOW BYTE ONLY
2591 MOVB -1(R1),RECV ;GET RECEIVED RAM DATA
2592 MOVB -1(R4),EXPD ;GET EXPECTED RAM DATA
2593 PRINTB #RAMASC,R2,RECV,EXPD,R3
2594 MOV R3,-(SP)
2595 MOV EXPD,-(SP)
2596 MOV RECV,-(SP)
2597 MOV R2,-(SP)
2598 MOV #RAMASC,-(SP)
2599 MOV #5,-(SP)
2600 TRAP C#PNTB
2601 ADD #14,SP
2602 10$: INC R2 ;UPDATE BYTE COUNT
2603 TST RAMSIZ ;DEFAULT TO 8.?
2604 BEQ 15$ ;BR IF YES
2605 CMP R2,RAMSIZ ;DONE ALL BYTES?
2606 BLE 5$ ;BR IF NO
2607 BR 25$ ;
2608 15$: CMP R2,#8. ;DONE DEFAULT NUMBER OF BYTES?
2609 20$: BLT 5$ ;BR IF NO
2610 25$: CLR RAMSIZ ;SET DEFAULT RAMSIZ
2611 RTS PC ;RETURN
2612 045 RAMASC: .ASCIZ '#N#A BYTE: #D2#A RAM: #03#A Packet: #03#A XOR:#03#
2613 .EVEN
    
```



```

2607          .SBTTL PRMESS - PRINT CONTENTS OF MESSAGE BUFFER
2608
2609          ;+
2610          ; THIS ROUTINE PRINTS THE CONTENTS OF
2611          ; THE 7 WORD MESSAGE BUFFER RETURNED BY THE
2612          ; TK-25.
2613          ;
2614          ; INPUT:
2615          ;
2616          ;     R0     LOW ORDER ADDRESS OF MESSAGE BUFFER
2617          ;     R1     HIGH ORDER ADDRESS OF MESSAGE BUFFER
2618          ;     NOTE: R1 IS IGNORED IF KTENABLE FLAG IS CLEAR
2619          ;
2620          ; THIS ROUTINE IS NORMALLY CALLED FROM A PRINT ROUTINE
2621          ;
2622          ;-
2623
2624          PRMESS:
2625          SAVRLG          ;SAVE THE REGISTERS
2626          MOV R5,RAMR5H  ;SAVE DEVICE REGISTER POINTER
2627          MOV R0,R5      ;SAVE LOW ORDER ADDRESS
2628          TST KTENABLE  ;ADDRESS ABOVE 28K?
2629          BNE 10$       ;BR IF YES
2630          CLR R1        ;SET HIGH ORDER ADDRESS TO 0
2631          MOV R1,R3     ;SAVE HIGH ORDER ADDRESS
2632          ROL R0        ;SHIFT BIT15 TO C BIT
2633          ROL R1        ;SHIFT TO HIGH ORDER FOR PRINTOUT
2634          PRINTX #PROASC,R1,R5 ;PRINT MESSAGE BUFFER ADDRESS
          MOV R5,-(SP)
          MOV R1,-(SP)
          MOV #PROASC,-(SP)
          MOV #3,-(SP)
          MOV SP,R0
          TRAP C:PNTX
          ADD #10,SP
2635          CMP #177777,(R5) ;MESSAGE BUFFER FULL OF ONES
2636          BNE 15$       ;BR IF BUFFER IS PROBABLY OKAY
2637          PRINTX #MESBFN ;"MESSAGE BUFFER PROBABLY NOT VALID"
          MOV #MESBFN,-(SP)
          MOV #1,-(SP)
          MOV SP,R0
          TRAP C:PNTX
          ADD #4,SP
2638          PRINTX #PRIASC ;PRINT HEADER FOR CONTENTS
          MOV #PRIASC,-(SP)
          MOV #1,-(SP)
          MOV SP,R0
          TRAP C:PNTX
          ADD #4,SP
          CLR R4          ;NUMBER OF THE NEXT WORD
2639          MOV R5,R1    ;COPY LOW ORDER ADDRESS
2640          MOV R3,R0    ;COPY HIGH ORDER ADDRESS
2641          BEQ 20$     ;BR IF NOT ABOVE 28K
2642          JSR PC,SETMAP ;SETUP PAR ADDRESS IN R0
2643          MOV R0,R5   ;GET PAR FORMAT ADDRESS ABOVE 28K
2644
2645          20$:
2646          PRINTX #MESHEA,(R5)+ ;PRINT "MESSAGE BUFFER HEADER "

```

	014232	012546		MOV	(R5)+, -(SP)	
	014234	012746	015033	MOV	#MESHEA, -(SP)	
	014240	012746	000002	MOV	#2, -(SP)	
	014244	010600		MOV	SP, R0	
	014246	104415		TRAP	C#PNTX	
2647	014250	062706	000006	ADD	#6, SP	
	014254			PRINTX	#DATAFL, (R5)+	;PRINT "DATA FIELD LENGTH ="
	014254	012546		MOV	(R5)+, -(SP)	
	014256	012746	015100	MOV	#DATAFL, -(SP)	
	014262	012746	000002	MOV	#2, -(SP)	
	014266	010600		MOV	SP, R0	
	014270	104415		TRAP	C#PNTX	
2648	014272	062706	000006	ADD	#6, SP	
	014276			PRINTX	#RBPORA, (R5)+	;PRINT "RESIDUAL BYTE COUNTER ="
	014276	012546		MOV	(R5)+, -(SP)	
	014300	012746	015145	MOV	#RBPORA, -(SP)	
	014304	012746	000002	MOV	#2, -(SP)	
	014310	010600		MOV	SP, R0	
	014312	104415		TRAP	C#PNTX	
2649	014314	062706	000006	ADD	#6, SP	
	014320			PRINTX	#XSOCON, (R5)+	;PRINT "XSTAT0 CONTENTS ="
	014320	012546		MOV	(R5)+, -(SP)	
	014322	012746	015212	MOV	#XSOCON, -(SP)	
	014326	012746	000002	MOV	#2, -(SP)	
	014332	010600		MOV	SP, R0	
	014334	104415		TRAP	C#PNTX	
2650	014336	062706	000006	ADD	#6, SP	
	014342			PRINTX	#XS1CON, (R5)+	;PRINT "XSTAT1 CONTENTS ="
	014342	012546		MOV	(R5)+, -(SP)	
	014344	012746	015257	MOV	#XS1CON, -(SP)	
	014350	012746	000002	MOV	#2, -(SP)	
	014354	010600		MOV	SP, R0	
	014356	104415		TRAP	C#PNTX	
2651	014360	062706	000006	ADD	#6, SP	
	014364			PRINTX	#XS2CON, (R5)+	;PRINT "XSTAT2 CONTENTS ="
	014364	012546		MOV	(R5)+, -(SP)	
	014366	012746	015324	MOV	#XS2CON, -(SP)	
	014372	012746	000002	MOV	#2, -(SP)	
	014376	010600		MOV	SP, R0	
	014400	104415		TRAP	C#PNTX	
2652	014402	062706	000006	ADD	#6, SP	
	014406			PRINTX	#XS3CON, (R5)+	;PRINT "XSTAT3 CONTENTS ="
	014406	012546		MOV	(R5)+, -(SP)	
	014410	012746	015371	MOV	#XS3CON, -(SP)	
	014414	012746	000002	MOV	#2, -(SP)	
	014420	010600		MOV	SP, R0	
	014422	104415		TRAP	C#PNTX	
	014424	062706	000006	ADD	#6, SP	
2653	014430	022737	000001	CMP	#1, TRANSTST	;CHECK FOR RAM DUMP REQUIRED
2654	014436	001407		BEQ	40#	;BR, IF DUMP REQUIRED
2655	014440	000137	014550	JMP	50#	;NO DUMP
2656	014444			PRINTX	#RAMFHR	
	014444	012746	014552	MOV	#RAMFHR, -(SP)	
	014450	012746	000001	MOV	#1, -(SP)	
	014454	010600		MOV	SP, R0	
	014456	104415		TRAP	C#PNTX	
	014460	062706	000004	ADD	#4, SP	

002134

40#:

```

2657 014464 012737 000010 002246      MOV      #8.,RAMSIZ      ;RAM FIELD IS 8 BYTES LONG
2658 014472 012737 000020 011030      MOV      #20,RAM#LD    ;FIELD STARTS AT 20 OCTAL (10 HEX)
2659 014500 004737 010646      JSR      PC,RAMER      ;READ AND PRINT THEM
2660 014504 012737 000040 011030      MOV      #40,RAM#LD    ;FIELD STARTS AT 40 OCTAL (20 HEX)
2661 014512 004737 010646      JSR      PC,RAMER      ;READ AND PRINT THEM
2662 014516 012737 000060 011030      MOV      #50,RAM#LD    ;FIELD STARTS AT 60 OCTAL (30 HEX)
2663 014524 004737 010646      JSR      PC,RAMER      ;READ AND PRINT THEM
2664 014530 012737 000020 002246      MOV      #16.,RAMSIZ   ;RAM FIELD IS SIXTEEN BYTES LONG
2665 014536 012737 000100 011030      MOV      #100,RAM#LD   ;FIELD STARTS AT 100 OCTAL (40 HEX)
2666 014544 004737 010646      JSR      PC,RAMER      ;READ AND PRINT THEM
2667 014550 000207          E04:      RTS      PC            ;RETURN
2668 014552          045      116      045  RAMFHR: .ASCIZ '###A ***** SPECIAL CONTROLLER RAM MEMORY DUMP *****'
2669 014650          045      116      045  MESBFN: .ASCIZ '###A MESSAGE BUFFER CONTENTS PROBABLY NOT VALID'
2670 014730          045      116      045  PROASC: .ASCIZ '###A Message Buffer Address = #01#05'
2671 014775          045      116      045  PR1ASC: .ASCIZ '###A Message Buffer Contents:'
2672
2673 015033          045      116      045  MESMEA: .ASCIZ '###A Message Buffer Header      = #06'
2674 015100          045      116      045  DATAFL: .ASCIZ '###A Data Field Length      = #06'
2675 015145          045      116      045  RBPCRA: .ASCIZ '###A Residual Byte Counter    = #06'
2676 015212          045      116      045  XSOCON: .ASCIZ '###A XSTAT0 Contents        = #06'
2677 015257          045      116      045  XS1CON: .ASCIZ '###A XSTAT1 Contents        = #06'
2678 015324          045      116      045  XS2CON: .ASCIZ '###A XSTAT2 Contents        = #06'
2679 015371          045      116      045  XS3CON: .ASCIZ '###A XSTAT3 Contents        = #06'
2680

```

```

2682          .SBTTL PRMSGEXP - PRINT EXPD/RECV MESSAGE BUFFERS
2683          ;+[B
2684          ;
2685          ;ROUTINE TO PRINT EXPECTED AND RECEIVED MESSAGE BUFFERS
2686          ;
2687          ;      RO      - NUMBER OF WORDS IN BUFFER
2688          ;
2689          ;IMPLICIT INPUTS:
2690          ;
2691          ;      EXPMSG - EXPECTED MESSAGE BUFFER
2692          ;      RECMG  - RECEIVED MESSAGE BUFFER
2693          ;      RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
2694          ;      RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
2695          ;
2696          PRMSGEXP:
2697          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
2698          MOV            R0,R5          ;SAVE NUMBER OF WORDS
2699          MOV            RCVLOADD,R0    ;GET RECV LOW ADDRESS
2700          MOV            R0,R4          ;COPY LOW ADDRESS
2701          MOV            RCVHIADD,R1   ;GET RECV HIGH ADDRESS
2702          ROL            R0             ;SHIFT BIT15 TO C BIT
2703          ROL            R1             ;SHIFT TO HIGH ORDER FOR PRINTOUT
2704          PRINTX        *PRMSG0,R1,R4  ;PRINT MESSAGE BUFFER ADDRESS
2705          MOV            R4,-(SP)
2706          MOV            R1,-(SP)
2707          MOV            *PRMSG0,-(SP)
2708          MOV            *3,-(SP)
2709          MOV            SP,R0
2710          TRAP          C#PNTX
2711          ADD            *10,SP
2712          PRINTX        *PRMSG1          ;PRINT HEADER FOR CONTENTS
2713          MOV            *PRMSG1,-(SP)
2714          MOV            *1,-(SP)
2715          MOV            SP,R0
2716          TRAP          C#PNTX
2717          ADD            *4,SP
2718          CLR            R4             ;NUMBER OF THE CURRENT WORD
2719          MOV            *EXPMSG,R1     ;GET EXPD BUFFER ADDRESS
2720          MOV            *RECMG,R2     ;GET RECV BUFFER ADDRESS
2721          MOV            (R1),R0       ;GET EXPD
2722          MOV            (R2),R3       ;GET RECV
2723          XOR            R0,R3         ;XOR EXPD/RECV
2724          PRINTX        *PRMSG2,R4,(R1)+,(R2)+,R3
2725          MOV            R3,-(SP)
2726          MOV            (R2)+,-(SP)
2727          MOV            (R1)+,-(SP)
2728          MOV            R4,-(SP)
2729          MOV            *PRMSG2,-(SP)
2730          MOV            *5,-(SP)
2731          MOV            SP,R0
2732          TRAP          C#PNTX
2733          ADD            *14,SP
2734          INC            R4             ;NUMBER OF THE NEXT
2735          CMP            R4,R5         ;DONE ALL YET?
2736          BGE            50$          ;BR IF YES
2737          BR             20$          ;DO ANOTHER
2738          BR             20$          ;DO ANOTHER
2739          RTS            PC           ;RETURN

```

M6

2718
2719 015616 045 116 045 PRMSG0: .ASCIZ 'N/A Message Buffer Address - 0105'
2720 015663 045 116 045 PRMSG1: .ASCIZ 'N/A Message Buffer Contents:'
2721 015721 045 116 045 PRMSG2: .ASCIZ 'N/A WORD 020A EXPD: 060A RECV: 060A XOR: 06'
2722 .EVEN
2723

```

2725          .SBTTL PRBYTEXP - PRINT ERROR BYTES IN EXP/REC MESSAGE BUFFER
2726          ;+
2727          ;
2728          ;ROUTINE TO PRINT ERROR BYTES IN MESSAGE BUFFERS
2729          ; ONLY THE FIRST 8 ERRORS ENCOUNTERED ARE PRINTED DUE TO SCREEN SPACE
2730          ;
2731          ; R0 - NUMBER OF BYTES IN BUFFER
2732          ;
2733          ;IMPLICIT INPUTS:
2734          ;
2735          ; EXPMSG - EXPECTED MESSAGE BUFFER
2736          ; RECMG  - RECEIVED MESSAGE BUFFER
2737          ;
2738          PRBYTEXP::
2739          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
2740          MOV R0,R5       ;SAVE NUMBER OF BYTES
2741          CLR PRMNO       ;INIT ERROR COUNT
2742          CLR R4         ;NUMBER OF THE CURRENT BYTE
2743          MOV #EXPMSG,R1 ;GET EXPD BUFFER ADDRESS
2744          MOV #RECMG,R2  ;GET REC/ BUFFER ADDRESS
2745          20$: MOVB (R1),R0 ;GET EXPD BYTE
2746          BIC #C<377>,R0 ;CLEAR UPPER BYTE
2747          MOVB R0,PRBEXP ;SAVE FOR ERROR REPORT
2748          MOVB (R2),R3   ;GET RECV BYTE
2749          BIC #C<377>,R3 ;CLEAR UPPER BYTE
2750          MOVB R3,PRBREC ;FOR ERROR REPORT
2751          XOR R0,R3      ;XOR EXPD/RECV
2752          CMPB (R1)+,(R2)+ ;EXPD = RECV?
2753          BEQ 30$       ;BR IF YES
2754          INC PRMNO     ;UPDATE ERROR COUNT
2755          CMP PRMNO,#8. ;PRINTED 8?
2756          BFI 30$      ;BR IF YES
2757          27$: PRINTX #PRBMSG,R4,PRBEXP,PRBREC,R3
                MOV R3,-(SP)
                MOV PRBREC,-(SP)
                MOV PRBEXP,-(SP)
                MOV R4,-(SP)
                MOV #PRBMSG,-(SP)
                MOV #5,-(SP)
                MOV SP,R0
                TRAP C:PNTX
                ADD #14,SP
                FORCEXIT 50$ ;BBD
                BR 35$      ;BBD
30$:          FORCERRR 27$.NOTSSR ;BBD
35$:          INC R4       ;NUMBER OF THE NEXT
                CMP R4,R5  ;DONE ALL YET?
                BGE 50$    ;BR IF YES
                BR 20$     ;DO ANOTHER
50$:          PRINTX #PRBTOT,PRMNO ;PRINT TOTAL ERROR COUNT
                MOV PRMNO,-(SP)
                MOV #PRBTOT,-(SP)
                MOV #2,-(SP)
                MOV SP,R0
                TRAP C:PNTX
  
```


C7

2777
2778
2779
2780
2781
2782
2783
2784
2785
2786
2787
2788
2789 016360
016360
2790 016360 004737 007500
2791 016364
016364
016364 104423
2792
2793

```
.SBTTL EXPREC - PRINT EXPD/RECV WORD DATA
|*
|PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
|INPUTS:
|
|      R1      RECEIVED DATA
|      R2      EXPECTED DATA
|-
|
|      BGNMSG  EXPREC
EXPREC::  JSR    PC,PRIXOR      ;PRINT THE DATA
|      ENDMSG
L10017:  TRAP   C#MSG
```


D7

2795
2796
2797
2798
2799
2800
2801
2802
2803
2804
2805
2806
2807
2808 016366
016366
2809 016366 004737 007350
2810 016372
016372
016372 104423
2811
2812
2813
2814
2815
2816
2817
2818
2819
2820
2821
2822
2823
2824
2825
2826
2827
2828
2829
2830
2831
2832
2833
2834
2835 016374
016374
2836 016374 004737 013640
2837 016400
016400
016400 104423
2838
2839
2840
2841
2842
2843
2844
2845

```

      .SBTTL  EXPBREC - PRINT EXPD/RECV BYTE DATA
      ;*
      ;PRINT ROUTINE TO DISPLAY BYTE EXPD/RECV DATA
      ;
      ;INPUTS:
      ;
      ;      R1      RECEIVED DATA BYTE
      ;      R2      EXPECTED DATA BYTE
      ;
      ;-
      BGNMSG  EXPBREC
EXPBREC::
      JSR     PC,PRIBXOR      ;PRINT THE DATA
      ENDMMSG
L10020:
      TRAP   C#MSG

```

```

      .SBTTL  RAMERR - PRINT RAM AND PACKET DATA
      ;*
      ;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
      ;
      ;INPUTS:
      ;
      ;      R4      POINTER TO COMMAND PACKET
      ;
      ;IMPLICIT INPUTS:
      ;
      ;      RAMDATA  DATA AS READ FROM THE RAM
      ;      RAMSIZ   NUMBER OF BYTES IN PACKET
      ;                IF RAMSIZ=0 THEN DEFAULT TO 8.
      ;
      ;IMPLICIT OUTPUTS:
      ;
      ;      RAMSIZ  SET TO 0
      ;
      ;-
      BGNMSG  RAMERR
RAMERR::
      JSR     PC,PRAMPKT      ;PRINT RAM/PACKET DATA
      ENDMMSG
L10021:
      TRAP   C#MSG

```

```

      .SBTTL  RAMTADD - PRINT TEST ADDRESS, RAM AND PACKET DATA
      ;*
      ;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
      ;
      ;INPUTS:

```

E7

```

2846
2847
2848
2849
2850
2851
2852
2853
2854
2855
2856
2857
2858
2859
2860
2861
2862 016402
      016402
2863 016402 004737 010032
2864 016406 004737 013640
2865 016412
      016412
      016412 104423
2866
2867
2868
2869
2870
2871
2872
2873
2874
2875
2876
2877
2878
2879
2880 016414
      016414
2881 016414 042701 177400
2882 016420 042702 177400
2883 016424 004737 007624
2884 016430 004737 007500
2885 016434
      016434
      016434 104423
2886
2887
2888
2889
2890
2891
2892
2893
2894
2895
2896

;
; R4 POINTER TO COMMAND PACKET
;
; IMPLICIT INPUTS:
;
; RAMDATA DATA AS READ FROM THE RAM
; RAMSIZ NUMBER OF BYTES IN PACKET
; IF RAMSIZ=0 THEN DEFAULT TO 8.
; ERRHI HIGH ORDER TEST ADDRESS
; ERRLO LOW ORDER TEST ADDRESS
;
; IMPLICIT OUTPUTS:
;
; RAMSIZ SET TO 0
;
;
; BGNMSG RAMTADD
RAMTADD:
; JSR PC,PRITADD ;PRINT TEST ADDRESS
; JSR PC,PRAMPKT ;PRINT RAM/PACKET DATA
; ENDMMSG
L10022:
; TRAP C#MSG
;
; .SBTTL RAMEXP - PRINT RAM EXPD/RECV DATA
;+
; PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
;
; INPUTS:
;
; R1 RECEIVED DATA
; R2 EXPECTED DATA
; R4 CONTROLLER RAM ADDRESS
;
;
; BGNMSG RAMEXP
RAMEXP:
; BIC #+C<377>,R1 ;SAVE EXPD RAM DATA BYTE
; BIC #+C<377>,R2 ;SAVE EXPD RAM DATA BYTE
; JSR PC,PRIRAM ;PRINT THE RAM ADDRESS
; JSR PC,PRIXOR ;PRINT THE DATA
; ENDMMSG
L10023:
; TRAP C#MSG
;
; .SBTTL TIMEXP - PRINT TIMER A,B AND EXP/REC
;+
; PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
; AND TIMER A,B HEADER MESSAGE
;
; INPUTS:
;
; R1 RECEIVED DATA
; R2 EXPECTED DATA

```

F7

```

2897
2898
2899 016436
      016436
2900 016436
      016436 012746 016464
      016442 012746 000001
      016446 010600
      016450 104415
      016452 062706 000004
2901 016456 004737 007500
2902 016462
      016462
      016462 104423
2903
2904
2905 016464 045 116 045 TIMSGO: .ASCIZ 'NNA TIMER A STATUS IS IN BIT 3NNA TIMER B STATUS IS IN BIT 2'
2906 .EVEN

```

```

      1-
      BGNMSG TIMEXP
TIMEXP:: PRINTX @TIMSGO ;PRINT HEADER
          MOV @TIMSGO, -(SP)
          MOV @1, -(SP)
          MOV SP, RO
          TRAP C#PNTX
          ADD @4, SP
          JSR PC, PRIXOR ;PRINT THE DATA
          ENDMMSG
L10024: TRAP C#MSG

```

G7

```

2908 .SBTTL BADSSR - PRINT TSSR ERRORS ON DATA TRANSFERS
2909
2910 ;+
2911 ;
2912 ;PRINT ROUTINE FOR TSSR ERRORS ON DATA TRANSFERS
2913 ;
2914 ;INPUTS:
2915 ;
2916 ; R1 CONTENTS OF TSSR
2917 ; R2 DATA WRITTEN (8 BITS)
2918 ;
2919 ;-
2920
2921 016564 BGNMSG BADSSR
016564 BADSSR::
2922 016564 010246 MOV R2,-(SP) ;SAVE DATA TRANSFERRED
2923 016566 042702 177400 BIC #177400,R2 ;GET JUST ONE BYTE
2924 016572 PRINTB #XFERASC,R2
016572 010246 MOV R2,-(SP)
016574 012746 016624 MOV #XFERASC,-(SP)
016600 012746 000002 MOV #2,-(SP)
016604 010600 MOV SP,R0
016606 104414 TRAP C#PNTB
016610 062706 000006 ADD #6,SP
2925 016614 012602 MOV (SP)+,R2 ;RESTORE R2
2926 016616 004737 005264 JSR PC,PRITSSR ;DECODE TSSR CONTENTS
2927 016622 ENDMMSG
016622 L10025:
016622 104423 TRAP C#MSG
2928 016624 045 116 045 XFERASC: .ASCIZ '#N#A Data Transferred = #03'
2929

```

H7

CZTKGA TK-25 FRT END FUNC #3
GLOBAL SUBROUTINES SECTION

MACRO M1200 20-APR-84 08:13 PAGE 61

SEQ 85

2931
2932
2933
2934
2935
2936
2937

.SBTTL GLOBAL SUBROUTINES SECTION

!++
; THE GLOBAL SUBROUTINES SECTION CONTAINS THE SUBROUTINES
; THAT ARE USED IN MORE THAN ONE TEST.
!--

```

2939          .SBTTL  SOFINIT - SOFT INITIALIZE OF CONTROLLER
2940
2941          ;+
2942          ;
2943          ;ROUTINE TO DO A SOFT INITIALIZE OF THE CONTROLLER
2944          ;BY WRITING INTO THE TSSR REGISTER. AFTER THE INIT,
2945          ;THE TSSR REGISTER IS TESTED FOR ERRORS. ANY ERRORS
2946          ;DETECTED SHOULD BE TREATED AS DEVICE FATAL ERRORS.
2947          ;
2948          ;INPUTS:
2949          ;
2950          ;      R5      ADDRESS OF FIRST REGISTER
2951          ;
2952          ;OUTPUTS:
2953          ;
2954          ;      R0      CONTENTS OF TSSR, IF ERROR
2955          ;      CARRY   SET IF INIT WAS OKAY
2956          ;              CLEAR IF FATAL ERROR
2957          ;
2958          ;CALLING SEQUENCE:
2959          ;
2960          ;      MOV      #ADDRESS,R5
2961          ;      JSR      PC,SOFINIT
2962          ;      BCS      CONTINUE
2963          ;      ERRDF                    ;REPORT FATAL ERROR
2964          ;
2965          ;-
2966
2967 016660      SOFINIT::
2968 016660      SAVREG                    ; SAVE THE REGISTERS
2969 016664 012765 0C0000 000000      MOV      #0,TSSR(R5)        ; DO THE INIT.
2970 016672 004737 017134            JSR      PC,WAITF          ; WAIT FOR SSR
2971 016676 016500 000000      MOV      TSSR(R5),R0      ; GET THE TSSR REGISTER
2972 016702 010004            MOV      R0,R4              ; START SETUP OF EXPECTED TSSR
2973 016704 042704 176277      BIC      #+C<HIADDR!OFL>,R4 ; CLEAR OUT UNUSED BITS
2974 016710 052704 002200      BIS      #SSR!NBA,R4    ; R4 HAS EXPECTED CONTENTS
2975 016714 020400            CMP      R4,R0              ; ONLY EXPECTED BITS SET ?
2976 016716 001402            BEQ      5$                ; BRANCH IF OKAY
2977 016720 000241            CLC                    ; CLEAR THE CARRY FOR ERROR
2978 016722 000401            BR      10$                ; GO TO EXIT
2979 016724 000261            5$: SEC                ; SET THE CARRY BIT
2980 016726 000207            10$: RTS PC              ; RETURN TO CALLER

```

```

2982          .SBTTL  CHKAMB  - CHECK TSSR FOR AMBIGUITY
2983
2984
2985          ;*
2986          ; THIS ROUTINE TESTS THE CONTENTS OF THE TSSR REGISTER
2987          ; FOR AMBIGUITY
2988          ;
2989          ; INPUT:
2990          ;
2991          ;     R0      CONTENTS OF TSSR
2992          ;
2993          ; OUTPUT:
2994          ;
2995          ;     R0      CONTENTS OF TSSR
2996          ;
2997          ;     CARRY   SET - NO AMBIGUITY
2998          ;           CLR - AMBIGUOUS CONTENTS
2999          ;
3000          ;
3001          ;
3002          CHKAMB:
3003          SAVREG          ;SAVE THE GENERAL REGISTERS
3004          MOV            R0,R4          ;CONTENTS OF TSSR
3005          BIT            #SC,R0        ;IS BIT 15 SET ?
3006          RNE            5#           ;BRANCH IF YES
3007          BIT            #C<NBA!OFL!SSR!HIADDR>,R0 ;ANY OTHER BITS SET ?
3008          BNE            40#         ;MUST BE AN ERROR
3009          BR             45#         ;RETURN WITH SUCCESS
3010          5#:          BIT            #SSR,R0        ;IS READY BIT SET ?
3011          BNE            10#         ;BRANCH IF READY BIT IS SET.
3012          BIT            #BIT5,R0     ;IS FATAL ERROR BIT SET ?
3013          BEQ            40#         ;ERROR IF NOT
3014          RIC            #CTERCLS,R4  ;CLEAR ALL BUT TERMINATION CODE
3015          CMP            R4,#16      ;ALL THREE BITS MUST BE SET
3016          BNE            40#         ;ERROR IF NOT SET
3017          BR             45#         ;OK IF ALL ARE SET
3018          10#:        BIT            #BIT5,R0     ;IS FATAL ERROR BIT SET ?
3019          BEQ            45#         ;ERROR IF BIT IS SET WITH SSR
3020          BIT            #BIT2!BIT1,R0 ;IS THIS A FUNCTION REJECT
3021          BNE            45#         ;BR. IF TSSR IS OK
3022          40#:        CLC              ;AMBIGUOUS CONTENTS
3023          BR             50#
3024          45#:        SEC              ;SHOW SUCCESS - NO AMBIGUITY
3025          50#:        RTS             PC          ;RETURN TO CALLER
3026

```

```

3028          .SBTTL ENAIN,DSBINT - ENABLE/DISABLE INTERRUPTS
3029          ;
3030          ; DEFAULT DISPLAY INTERRUPT HANDLERS.
3031          ; IF DISPLAY TIME-OUT, REPORT DEV FATAL, AND ABORT PASS.
3032          ; OTHERWISE, SAVE DPU REGISTERS AND DISMISS.
3033          ;
3034          ;
3035          ; BIT DEFINITIONS FOR "INTMASK" AND "INTFLAG" BYTES:
3036          ;
3037          000200          IOKCKIN=BIT7          ; DON'T CHECK FOR BAD INTERRUPTS -- TEST WILL.
3038          000001          IOKSTP=BIT0          ; EXPECT "STOP" INTERRUPT.
3039          ;
3040          ; INTERRUPT MASK -- SAYS EXPECTING INTERRUPTS
3041          017030          000          INTMASK: .BYTE 0
3042          ; INTERRUPT FLAG -- SAYS WE GOT ONE (IF POSITIVE)
3043          017031          000          INTFLAG: .BYTE 0
3044          ;
3045          ; SAVED INTERRUPT VECTOR:
3046          017032          000000          INTVEC: .WORD 0
3047          ; SAVE CPU PC
3048          017034          000000          INTCP: .WORD 0
3049          ;
3050          ; SUBROUTINE TO ENABLE INTERRUPTS:
3051          017036          010046          ENAIN: MOV RO,-(SP)          ; SAVE RO
3052          017040          013700          002156          MOV IVEC,RO          ; GET POINTER TO VECTORS
3053          017044          012720          017102          MOV @INTR,(RO)+          ; SET UP INTERRUPT VECTOR
3054          017050          012720          000340          MOV @PRI07,(RO)+
3055          017054          012600          MOV (SP)+,RO          ; RESTORE RO
3056          017056          011646          MOV (SP),-(SP)
3057          017060          012766          000000          000002          MOV @0,2(SP)          ; SET CPU TO LEVEL 0
3058          017066          000002          RTI
3059          ;
3060          ; SUBROUTINE TO DISABLE INTERRUPTS (RAISE PRIORITY TO LEVEL 7)
3061          017070          011646          DSBINT: MOV (SP),-(SP)
3062          017072          012766          000340          000002          MOV @PRI07,2(SP)
3063          017100          000002          RTI
3064

```



```

3066          .SBTTL  INTR  - INTERRUPT HANDLERS
3067
3068 017102    BGNSRV  INTR          ;DEFINE INTERRUPT ENTRY
          017102    INTR::
3069 017102    012737  000001  002172  MOV      #1,INTRECV      ;SET FLAG TO SHOW INTERRUPT RECEIVED
3070 017110    105037  017031          CLRB    INTFLAG        ;CLEAR FLAG TO SAY WE GOT INTERRUPT
3071 017114    132737  000001  017030  DIB     #IOKSTP,INTMASK ;EXPECTING STOP INTERRUPT?
3072 017122    001003          BNE     1$              ;BR IF YES
3073 017124    152737  000001  017031  BISB    #IOKSTP,INTFLAG ;NO. SET THE ERROR FLAG.
3074
3075          ;SAVE REGISTERS, MSG BUFFER, ETC.
3076 017132    1$:
3077 017132          ENDSRV
          017132    L10026:
          017132    000002  RTI
3078
3079

```

```

3081          .SBTTL  WAITF  - WAIT FOR SUBSYSTEM READY
3082          ;
3083          ; SUBROUTINE TO WAIT FOR THE SUBSYSTEM READY FLAG
3084          ;
3085          ; INPUTS:
3086          ;
3087          ;     R5      ADDRESS OF FIRST DEVICE REGISTER
3088          ;
3089          ; OUTPUTS:
3090          ;
3091          ;     R0      CONTENTS OF LAST TSSR READ
3092          ;     CARRY   SET - READY BIT SET
3093          ;             CLR - TIMEOUT WAITING FOR READY
3094          ;
3095          WAITF:: BREAK          ; DO A SUPVSR BREAK FIRST.
                 TRAP            C#BRK
3096          017134 104422          MOV          #177776,-(SP) ;BIG MSEC TIMER
                 DELAY          1 ;DELAY 100US
3097          017142 012727 000001  MOV          #1,(PC)+
                 .WORD          0
                 MOV            L#DLY,(PC)+
                 .WORD          0
                 DEC            -6(PC)
                 BNE            -.4
                 DEC            -22(PC)
                 BNE            -.20
3098          017172 016500 000000 2$:  MOV          TSSR(R5),R0 ;READ THE TSSR REGISTER
3099          017176 105700          TSTB         R0 ;TEST FOR READY BIT SET
3100
                 BMI            3$ ; EXIT ON STOP FLAG.
                 DELAY          1 ; WAIT 100 USEC
3101          017200 100421          MOV          #1,(PC)+
                 .WORD          0
                 MOV            L#DLY,(PC)+
                 .WORD          0
                 DEC            -6(PC)
                 BNE            -.4
                 DEC            -22(PC)
                 BNE            -.20
3103          017232          BREAK          ; DO A SUPVSR BREAK FIRST.
                 TRAP            C#BRK
3104          017234 005316          DEC          (SP) ;REDUCE DELAY COUNT
3105          017236 001355          BNE          2$ ;RETRY UNTIL TIMER EXPIRES
3106          017240 000241          CLC          ; C = 0, CONTROLLER STILL RUNNING...
3107          017242 000401          BR          4$ ;...OR HUNG-UP AFTER 300 MSEC.
3108          017244 000261          SEC          ; C = 1, CONTROLLER IS STOPPED.
3109          017246 005326          DEC          (SP)+ ;RESTORE STACK WITHOUT CHANGING CARRY BIT
3110          017250 000207          RTS          PC
    
```

3112
3113
3114
3115
3116
3117
3118
3119
3120
3121
3122
3123
3124
3125
3126
3127
3128
3129
3130
3131 017252
3132 017252 004737 017134
3133 017256 103014
3134 017260 004737 016730
3135 017264 103006
3136 017266 032700 100000
3137 017272 001405
3138 017274 032700 074000
3139 017300 001402
3140 017302 000241
3141 017304 000401
3142 017306 000261
3143 017310 000207

```

.SBTTL  CHK TSSR - CHECK TSSR FOR READY
;
; THIS ROUTINE WAITS FOR READY IN THE TSSR
; AND TESTS FOR AMBIGUOUS BIT SETTINGS IN TSSR.
;
; INPUT:
;
; R5      ADDRESS OF CSR REGISTERS
;
; OUTPUT:
;
; R0      CONTENTS OF TSSR
; CARRY   SET - OKAY
;         CLR - NOT READY AMBIGUOUS, OR SC SET
;
;
CHKTSSR:
    JSR    PC, WAITF      ; WAIT FOR READY
    BCC    20$           ; BRANCH IF TIME OUT
    JSR    PC, CHKAMB     ; TSSR AMBIGUOUS?
    BCC    10$           ; BR IF YES
    BIT    @SC, R0        ; SPECIAL CONDITION SET?
    BEQ    15$           ; BR IF NO
    BIT    @<SCE!BIE!RMR!NXM>, R0 ; ANY ERROR BITS SET?
    BEQ    15$           ; BR IF NO
10$:    CLC              ; SET FAILURE
    BR     20$           ;
15$:    SEC              ; SET SUCCESS
20$:    RTS             PC ; RETURN TO CALLER

```

```

3145 .SBTTL XNXM - CHECK FOR NONEXISTENT MEMORY
3146
3147 ;
3148 ; ROUTINE TO TEST FOR A NEXM IN THE RANGE (R1) THRU (R2).
3149 ; ON RETURN, IF "C" = 1, (R1) = NEXM ADDRESS.
3150 ; "C" = 0, ALL ADDRESSES OK.
3151 ;
3152 ; CALL: MOV ADR1,R1
3153 ; MOV ADR2,R2
3154 ; JSR PC,NXM
3155 ; RETURN
3156 017312 012737 017344 000004 XNXM: MOV #21,004 ; TEST "C" AND PROCEED.
3157 017320 012737 000200 000006 MOV #PRIO4,006 ; SET BUSERR VECTOR.
3158 017326 005003 CLR R3 ; FLAG.
3159 017330 005711 10: TST (R1) ; TEST THE ADDRESS(ES).
3160 ; IF ANY TRAP, CONTINUE AT 20.
3161 017332 020102 CMP R1,R2 ; OTHERWISE, CONTINUE HERE.
3162 017334 001407 BEQ 30 ; BR IF FINISHED (NO NEXM'S).
3163 017336 062701 000002 ADD #2,R1 ; SET NEXT ADDRESS...
3164 017342 000772 BR 10 ; ...AND CONTINUE.
3165
3166 017344 005103 20: COM R3 ; GOT ONE, SET FLAG...
3167 017346 012716 017354 MOV #30,(SP)
3168 017352 000002 RTI ; ...AND DISMISS INTERRUPT...
3169 017354 012700 000004 30: CLRVEC #4 ; ...AND GIVE BACK THE VECTOR.
3170 017362 005703 MOV #4,R0
3171 017364 001401 TRAP C0VEC
3172 017366 000261 TST R3 ; DID WE CATCH ONE ??
3173 017370 000207 BEQ .+4 ; NO, "C" = 0, SKIP NEXT.
3174 ; YES, "C" = 1, (R1) = NEXM ADDR.
3175
3176
3177
3178 .SBTTL TSTLOOP - CHECK ITERATION COUNT
3179
3180 ;
3181 ; SUBROUTINE TO EXECUTE TEST ITERATIONS.
3182 ; EXIT WITH "C" SET IF LOOPS ALLOWED AND LOOP COUNT NON-ZERO.
3183 ; LOOP COUNTER IS SET BY "BEGIN,TEST" MACRO.
3184 ;
3185 ; CALL: LOOPTO ARG
3186 017372 TSTLOOP:
3187 017372 005737 002136 TST NOITS ; ITERATIONS INHIBITED?
3188 017376 001006 BNE 10 ; YES.
3189 017400 005737 002152 TST QVP ; NO.
3190 017404 100403 BMI 10 ; LOOPS DISALLOWED IN QUICK PASS.
3191 017406 005337 002164 DEC LOOPCNT ; BUMP LOOP COUNTER.
3192 017412 001002 BNE 20
3193 017414 000241 10: CLC ; LOOP DISALLOWED, OR DONE.
3194 017416 000401 BR 30
3195 017420 000261 20: SEC ; LOOP ENABLED.
3196 017422 000207 30: RTS PC
  
```

3198
3199
3200
3201
3202
3203
3204
3205
3206
3207
3208
3209
3210
3211
3212
3213
3214
3215
3216
3217
3218
3219
3220
3221
3222
3223
3224
3225
3226 017424
3227 017424 010046
3228 017426 005037 003106
3229 017432 005037 017672
3230 017436 005037 005232
3231 017442 105037 017030
3232 017446 013700 002150
3233 017452 006300
3234 017454 005737 003062
3235 017460 001430
3236 017462 100010
3237 017464 052760 160000 003130
3238 017472
017472 104455
017474 000001
017476 003636
017500 005176
3239 017502 000407
3240 017504 052760 160001 003130 3#;
3241 017512
017512 104455
017514 000002
017516 004233
017520 000000
3242 017522 012737 177777 003060 2#;
3243 017530
017530 013700 002150
017534 104451
3244 017536

```
.SBTTL TSTSETUP - PRINT TEST NAME AND INIT ERROR COUNTS
;
; PRINT THE NUMBER AND NAME OF EACH TEST AS WE GO ALONG.
; INCREMENT "TESTK" TO INDICATE THE NUMBER OF TESTS
; IN THE CURRENT RUN SEQUENCE.
; CLEAR THE ERROR COUNTER AND SIGNATURE EXTENSION FLAGS.
;
; INPUT:
;
; R0 POINTER TO TEST ID ASCIZ STRING
;
; OUTPUT:
;
; R5 ADDRESS OF FIRST DEVICE REGISTER
;
; IMPLICIT OUTPUTS:
;
; TSTCNT UPDATED TO COUNT TESTS PERFORMED SINCE START OR RESTART
;
; SIDE EFFECTS:
;
; INTERRUPT LEVEL IS RAISED TO LEVEL OF
; THE DEVICE UNDER TEST
;
;-
```

```
TSTSETUP:;
MOV R0, -(SP) ; SAVE THE TEST ID MESSAGE
CLR SIFLAG ; CLEAR "SOFT INIT" FLAG
CLR ERRK ; CLEAR LOCAL ERROR COUNTER.
CLR EXTA ; CLEAR ERROR EXTENSION FLAG.
CLRB INTMASK ; CLEAR INTERRUPT MASK (CHECK ERROR)
MOV UNITN, R0 ; GET THE UNIT NUMBER,
ASL R0 ; ... AND MAKE IT A WORD OFFSET.
TST N0DEV ; DID STARTUP FIND THE DEVICE?
BCQ 4# ; BR IF YES
BPL 3# ; BR IF NOT IDLE
BIS #160000, ERTABL(R0) ; FLAG ERROR IN THE ERROR TABLE
ERRDF 1, NXR, NXRERR ; NO DEVICE HERE -- PRINT IT
TRAP C#ERRDF
.WORD 1
.WORD NXR
.WORD NXRERR
BR 2#
BIS #160001, ERTABL(R0) ; FLAG ERROR IN THE ERROR TABLE
ERRDF 2, NOINIT ; DEVICE NOT IDLE
TRAP C#ERRDF
.WORD 2
.WORD NOINIT
.WORD 0
MOV # -1, DUFLG ; DROP THE UNIT
DODU UNITN
MOV UNITN, R0
TRAP C#DODU
DOCLN ; ABORT THE PASS
```



```

3260 .SBTTL TSTEND - PRINT ERRORS RECEIVED
3261 ;
3262 ; AT END OF EACH TEST, PRINT THE NUMBER OF ERRORS RECEIVED
3263 ; IF NORMAL ERROR REPORTING IS DISABLED (FLA:IER).
3264 ;
3265 TSTEND: RFLAGS RO
          TRAP C#RFLA
          BIT RO,#IER
          BEQ 1# ; BR IF "IER" NOT SET.
          PRINTF #ESUM,ERRK ; PRINT ERROR COUNT.
          MOV ERRK,-(SP)
          MOV #ESUM,-(SP)
          MOV #2,-(SP)
          MOV SP,RO
          TRAP C#PNTF
          ADD #6,SP
1#: RTS PC

3266 017634 104421
3266 017636 030027 020000
3267 017642 001412
3268 017644
          017644 013746 017672
          017650 012746 017674
          017654 012746 000002
          017660 010600
          017662 104417
          017664 062706 000006
3269 017670 000207
3270
3271 017672 000000
3272 017674 045 101 040
3273 017713 105 122 122
3274
3275
3276 .SBTTL INCERK - INCREMENT LOCAL ERROR COUNT
3277 ;
3278 ; ROUTINES TO INCREMENT LOCAL ERROR COUNT AND CHECK FOR LIMIT:
3279 ;
3280 INCERK: INC ERRK ; INCREMENT LOCAL ERROR COUNT
3281 MOV RO,-(SP) ; SAVE RO
3282 MOV UNITN,RO ; GET UNIT NUMBER
3283 ASL RO ; ... AND MAKE IT A WORD OFFSET
3284 ADD #ERTABL,RO ; RO GETS ADDRESS OF ERROR TABLE ENTRY.
3285 INC (RO) ; INCREMENT THE DEVICE ERROR COUNT
3286 BIT #7777,(RO) ; DID WE OVERFLOW THE FIELD?
3287 BNE 1# ; BR IF NO.
3288 DEC (RO) ; YES -- BACK IT UP TO 7777.
3289 MOV (SP)+,RO ; RESTORE RO
3290 RTS PC ; RETURN TO CALLER.
3291
3292 CKEMAX: MOV RO,-(SP) ; SAVE RO
3293 MOV UNITN,RO ; GET UNIT NUMBER
3294 ASL RO ; ... AND MAKE IT A WORD OFFSET
3295 MOV ERTABL(RO),RO ; GET ERROR TABLE ENTRY
3296 BIC #170000,RO ; EXTRACT ERROR COUNT FIELD
3297 CMP RO,GERRMAX ; IS GLOBAL LIMIT EXCEEDED FOR THIS UNIT?
3298 BHIS 1# ; BR IF YES
3299 CMP ERRK,LERRMAX ; IS LOCAL LIMIT EXCEEDED FOR THIS TEST?
3300 BLO 2# ; BR IF NO
3301 RFLAGS RO ; GET OPERATOR FLAGS
1#: TRAP C#RFLA
          BIT #IDU,RO ; IS DROPPING INHIBITED?
          BNE 2# ; BR IF YES.
          MOV #-1,DUFLG ; NO -- DROP THE UNIT
          ERDF 4,EMAXDU
          TRAP C#ERDF
          .WORD 4
          .WORD EMAXDU
3302 020054 104421
3302 020056 032700 000040
3303 020062 001013
3304 020064 012737 177777 003060
3305 020072
          020072 104455
          020074 000004
          020076 017713

```

```

3306 020100 000000          .WORD 0
      020102          DODU UNITN
      020102 013700 002150 MOV UNITN,R0
      020106 104451      TRAP C#DODU
3307 020110          DOCLN
      020110 104444      TRAP C#DCLN
3308 020112 012600      2$: MOV (SP)+,R0      ; RESTORE R0
3309 020114 000207      RTS PC      ; RETURN TO CALLER
3310          .SBTTL FATCHK - INC FATAL ERRORS AND CHECK FOR LIMIT
3311          ;
3312          ;
3313          ; CHECK FATAL COUNTER, AFTER INC, FOR MORE THAN 25
3314          ; ERRORS AND IF OVER CALL UNIT DROP ROUTINE
3315          ;
3316          ;
3317 020116          FATCHK:
3318 020116          SAVREG
3319 020122 013701 002150 MOV UNITN,R1      ; BETTER SAVE THE REGISTERS
3320 020126 006301      ASL R1      ; PICK UP THE UNIT NUMBER
3321 020130 062761 000001 003130 ADD #1,ERTABL(R1) ; MAKE IT INTO A BYTE OFFSET
3322 020136 005237 002170 INC FATFLG      ; ADD 1 TO THE PROPER UNIT'S ERROR COUNTER
3323 020142 023727 002170 000031 CMP FATFLG,#25. ; BUMP FATAL ERROR COUNTER
3324 020150 002406      BLT 9$      ; CHECK AGAINST 25
3325 020152          RFLAGS R0      ; BR, IF LESS THAN 25 ERRORS
      020152 104421      TRAP C#RFLA ; READ THE FLAGS INTO R0
3326 020154 032700 040000 BIT #BIT14,R0      ; BR, IF LOOP ON ERROR IS SET
3327 020160 001002      BNE 9$      ; OTHERWISE NEVER BE ABLE TO SCOPE ETC.
3328 020162 004737 020170 JSR PC,CKDROP      ; DROP UNIT IF ALLOWED
3329 020166 000207      RTS PC      ; RETURN ETC.
3330          ;
3331          ;
3332          ;

```



```

3334 .SBTTL CKDROP - CHECK IF UNIT SHOULD BE DROPPED
3335 ;+
3336 ; CHECK IF UNIT SHOULD BE DROPPED
3337 ;-
3338 020170 010046
3339 020172
3340 020202
      020202 104421
3341 020204 032700 000040
3342 020210 001010
3343 020212 011600
3344 020214 012737 177777 003060
3345 020222
      020222 013700 002150
      020226 104451
3346 020230
      020230 104444
3347 020232 012600
3348 020234 000207
3349
3350
3351
3352
3353 .SBTTL CONFIG - DETERMINE CONFIGURATION OF SYSTEM
3354 ;
3355 ; SUBROUTINE - DETERMINE CONFIGURATION OF TK-25 SYSTEM.
3356 ;
3357 020236
3358 020236 004737 016660
3359 020242 000207
3360
3361
3362

      CKDROP: MOV     RO, -(SP)
              FORCERROR 1$,NOTSSR
              RFLAGS RO
              TRAP  C#RFLA
              BIT  #IDU,RO
              BNE  1$
              MOV  (SP),RO
              MOV  #-1,DUFLG
              DODU UNITN
              MOV  UNITN,RO
              TRAP C#DODU
              DOCLN
              TRAP C#DCLN ;ABORT THE PASS
1$: MOV  (SP)+,RO
   RTS  PC

```

H8

```

3364 .SBTTL KTON,KTOFF - ENABLE/DISABLE MEMORY MANAGEMENT
3365 ;
3366 ; SUBROUTINE - ENABLE MEM MGT.
3367 ;
3368 020244 005737 003100 KTON: TST KFLG ; GOT KT?
3369 020250 001403 BEQ 1$ ; NO.
3370 020252 012737 000001 177572 MOV #1,SRO ; YES. ENABLE KT11.
3371 020260 000207 1$: RTS PC
3372
3373
3374
3375 ;
3376 ; SUBROUTINE - DISABLE MEM MGT.
3377 ;
3378 020262 005737 003100 KTOFF: TST KFLG ; GOT KT11?
3379 020266 001405 BEQ 1$ ; NO.
3380 020270 000240 NOP
3381 020272 000240 NOP
3382 020274 012737 000000 177572 MOV #0,SRO ; DISABLE KT.
3383 020302 000207 1$: RTS PC
3384
3385

```

```

3387                                     .SBTTL SETMAP - SETUP PAR6 MAPPING
3388
3389                                     ;*
3390                                     ;
3391                                     ; THIS ROUTINE SETS UP KERNEL PAR6 TP HANDLE
3392                                     ; AN 18 BIT ADDRESS. THE OFFSET INTO THE PAGE
3393                                     ; IS RETURNED BIASED TO PAR6.
3394                                     ;
3395                                     ; INPUTS:
3396                                     ;
3397                                     ;     R0     HIGH ORDER ADDRESS BITS
3398                                     ;     R1     LOW ORDER ADDRESS BITS
3399                                     ;
3400                                     ; OUTPUTS:
3401                                     ;
3402                                     ;     R0     OFFSET INTO BLOCK WITH PAR6 BIAS (I.E. THE ADDRESS)
3403                                     ;     CARRY  SET IF SUCCESS
3404                                     ;           CLR IF ERROR
3405                                     ;
3406                                     ;-
3406 020304 SETMAP:
3407 020304 SAVREG                                ;SAVE R1-R4 UNTIL NEXT RETURN
3408 020310 005737 003100 TST KTF LG      ;SYSTEM HAVE ABOVE 28K?
3409 020314 001433 BEQ 10$                ;BR IF NO
3410 020316 010102 MOV R1,R2              ;SAVE LOW ORDER BITS
3411          000006 .REPT 6
3412          ASR R0                                ;CONVERT WORD ADDRESS TO 32W BLOCKS
3413          ROR R1                                ;MAKE IT DOUBLE PRECISION
3414          .ENDR
3415 020350 042701 000177 BIC #177,R1      ;ALINE FOR LOWER 4K BOUNDARY
3416 020354 020137 003100 CMP R1,KTF LG    ;HIGHER THAN EXISTING MEMORY?
3417 020360 103011 BHIS 10$                ;BR IF YES
3418 020362 010137 172354 MOV R1,#KIPAR6  ;SETUP MAPPING REGISTER PAR6
3419 020366 042702 160000 BIC #160000,R2  ;SETUP DISPLACEMENT IN PAGE
3420 020372 062702 140000 ADD #140000,R2  ;ADD IN PAR6 BIAS
3421 020376 010200 MOV R2,R0          ;RETURN IN R0
3422 020400 000261 SEC                    ;SET SUCCESS
3423 020402 000401 BR 15$
3424 020404 000241 10$: CLC                ;SET FAILURE
3425 020406 000207 15$: RTS PC            ;RETURN
3426

```

```

3428 .SBTTL FILLMEM - FILL MEMORY WITH BACKGROUND PATTERN
3429 ;
3430 ; FILL MEMORY WITH A BACKGROUND PATTERN
3431 ;
3432 ; INPUTS:
3433 ;
3434 ; RO = BACKGROUND PATTERN
3435 ; FREE = FIRST LOCATION AVAILABLE TO DIAGNOSTIC
3436 ; KTFLG = SET TO HIGHEST MEMORY LOCATION IF > 28K.
3437 ;
3438 ; OUTPUTS:
3439 ;
3440 ; NONE
3441 ;
3442 ;
3443 ; FILLMEM:
3444 020410 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
3445 020414 004737 020262 JSR PC,KTOFF ;DISABLE KT.
3446 020420 010003 MOV R0,R3 ;COPY TEST PATTERN
3447 020422 013701 003072 MOV FREE,R1 ;GET FIRST FREE LOCATION
3448 020426 013702 003074 MOV FRESIZ,R2 ;SIZE OF FREE SPACE BELOW 28K.
3449 020432 010321 10$: MOV R3,(R1)+ ;STORE A BACKGROUND WORD
3450 020434 005302 DEC R2 ;DONE ALL MEMORY IN FREE SPACE?
3451 020436 003375 RGT 10$ ;BR IF NO
3452 020440 005737 003100 TST KTFLG ; GOT KT?
3453 020444 001452 BEQ 55$ ; NO. GET OUT.
3454 020446 004737 020244 JSR PC,KTON ; YES. ENABLE KT.
3455 020452 005000 CLR R0 ;HIGH ORDER ADDRESS START
3456 020454 013701 003104 MOV PST32W,R1 ;GET >28K START ADDRESS (IN 32W BLOCKS)
3457 000006 .REPT 6
3458 CLC ;CLEAR C BIT
3459 ROL R1 ;CONVERT BLOCKS TO WORDS
3460 ROL R0 ;MAKE IT DOUBLE PRECISION
3461 .ENDR
3462 020524 004737 020304 JSR PC,SETMAP ;SET UP PAR6 MAPPING REGISTER
3463 020530 010320 30$: MOV R3,(R0)+ ;STORE TEST PATTERN IN >28K ADDRESS
3464 020532 020027 160000 CMP R0,#160000 ;END OF PAR6 MAPPING AREA?
3465 020536 103774 BLO 30$ ;BR IF NO
3466 020540 162700 020000 SUB #20000,R0 ;BACKUP INTO PAR6 MAPPING BEGIN
3467 020544 062737 000200 172354 ADD #200,#*KIPAR6 ;POINT TO NEXT 4K BLOCK >28K.
3468 020552 023737 172354 003100 CMP #*KIPAR6,KTFLG ;END OF MEMORY?
3469 020560 001402 BEQ 50$ ;BR IF YES
3470 020562 000137 020530 JMP 30$ ;KEEP GOING ON ETC.
3471 020566 004737 020262 50$: JSR PC,KTOFF ;DISABLE KT.
3472 020572 000207 55$: RTS PC
3473
3474

```

```

3476          .SBTTL  CMPMEM  - COMPARE MEMORY TO BACKGROUND PATTERN
3477          ;+
3478          ; COMPARE MEMORY WITH A BACKGROUND PATTERN
3479          ;
3480          ; INPUTS:
3481          ;
3482          ;     RO = BACKGROUND PATTERN
3483          ;     FREE  = FIRST LOCATION AVAILABLE TO DIAGNOSTIC
3484          ;     KTFLG = SET TO HIGHEST MEMORY LOCATION IF > 28K.
3485          ;
3486          ; OUTPUTS:
3487          ;
3488          ;     CARRY  - SET IF NO ERROR
3489          ;     CARRY  - CLR IF ERROR
3490          ;
3491          ; IMPLICIT OUTPUTS:
3492          ;
3493          ;     ERRHI  - ERROR HIGH ADDRESS
3494          ;     ERRLO  - ERROR LOW ADDRESS
3495          ;     EXPD   - EXPECTED DATA
3496          ;     RECV   - RECEIVED DATA
3497          ;
3498          CMPMEM:
3499          SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
3500          MOV             RO,R3          ;COPY TEST PATTERN
3501          JSR             PC,KTOFF       ;DISABLE KT.
3502          MOV             FREE,R1        ;GET FIRST FREE LOCATION
3503          MOV             FRESIZ,R2     ;SIZE OF FREE SPACE BELOW 28K.
3504          10$:          CMP             R3,(R1) ;FREE SPACE LOCATION EQUAL TO EXPD?
3505          BEQ             15$           ;BR IF YES
3506          MOV             R1,ERRLO      ;SAVE ADDRESS IN ERROR
3507          CLR             ERRHI         ;NO HIGH ADDRESS
3508          MOV             R3,EXPD        ;SAVE EXPD FOR ERROR REPORT
3509          MOV             (R1),RECV     ;SAVE RECV FOR ERROR REPORT
3510          BR             50$           ;
3511          15$:          TST             (R1)+ ;POINT TO NEXT ADDRESS
3512          DEC             R2            ;DONE ALL MEMORY IN FREE SPACE?
3513          BGT             10$           ;BR IF NO
3514          TST             KTFLG         ; GOT KT?
3515          BEQ             55$           ; NO. GET OUT.
3516          JSR             PC,KTON       ; YES. ENABLE KT.
3517          CLR             RO            ;HIGH ORDER ADDRESS START
3518          MOV             PST32W,R1     ;GET >28K START ADDRESS (IN 32W BLOCKS)
3519          .REPT          6
3520          ROL             R1            ;CONVERT BLOCKS TO WORDS
3521          ROL             RO            ;MAKE IT DOUBLE PRECISION
3522          .ENDR
3523          BIC             #177,R1        ;ALINE 4K BOUNDARY
3524          MOV             RO,-(SP)       ;SAVE HIGH ORDER
3525          MOV             R1,-(SP)       ;SAVE LOW ORDER
3526          JSR             PC,SETMAP     ;SETUP PAR6 MAPPING REGISTER
3527          MOV             RO,R4         ;COPY ADDRESS BIASED TO PAR6
3528          MOV             (SP)+,R1      ;RESTORE LOW ORDER IN NON PAR6 FORMAT
3529          MOV             (SP)+,RO      ;RESTORE HIGH ORDER IN NON PAR6 FORMAT
3530          30$:          CMP             R3,(R4) ;ABOVE 28K LOCATION EQUAL EXPD?
3531          BEQ             32$           ;BR IF YES
3532          MOV             RO,ERRHI      ;SAVE HIGH ORDER IN ERROR
  
```

L8

```
3533 020754 010137 002204      MOV      R1,ERRLO      ;SAVE LOW ORDER IN ERROR
3534 020760 010337 002176      MOV      R3,EXPD      ;SAVE EXPD FOR ERROR REPORT
3535 020764 011437 002200      MOV      (R4),RECV    ;SAVE RECV FOR ERROR REPORT
3536 020770 000421              BR        50$         ;
3537 020772 062701 000002      32$:    ADD      #2,R1      ;UPDATE NON PAR6 ADDRESS
3538 020776 005500              ADC      R0           ;MAKE IT DOUBLE PRECISION ADD
3539 021000 062704 000002      ADD      #2,R4        ;UPDATE PAR FORMAT ADDRESS
3540 021004 020427 160000      CMP      R4,#160000   ;END OF PAR6 MAPPING AREA?
3541 021010 103755              BLO     30$         ;BR IF NO
3542 021012 162704 020000      SUB      #20000,R4    ;BACKUP INTO PAR6 MAPPING BEGIN
3543 021016 062737 000200 172354  ADD      #200,#KIPAR6 ;POINT TO NEXT 4K BLOCK >28K.
3544 021024 023737 172354 003100  CMP      #KIPAR6,KTFLG ;END OF MEMORY?
3545 021032 101744              BLOS   30$         ;BR IF NO
3546 021034 004737 020262      50$:    JSR      PC,KTOFF    ;TURN OFF MEMORY MAPPING
3547 021040 000241              CLC                    ;SET FAILURE
3548 021042 000403              BR        60$         ;
3549 021044 004737 020262      55$:    JSR      PC,KTOFF    ;TURN OFF MEMORY MAPPING
3550 021050 000261              SEC                    ;SET SUCCESS
3551 021052 000207      60$:    RTS      PC
3552
```

3554
3555
3556
3557
3558
3559
3560
3561
3562
3563
3564
3565
3566
3567
3568
3569
3570
3571
3572
3573
3574 021054
3575 021054
3576 021056 010446
3577 021060 010346
3578 021062 010246
3579 021064 010146
3580 021066 010546
3581 021070 016605 000012
3582 021074 004736
3583 021076 012601
3584 021100 012602
3585 021102 012603
3586 021104 012604
3587 021106 012605
3588 021110
3589 021112 000207
3590

```

        .SBTTL  REGSAV  - SAVE R1-R5 ON STACK
;+
;
;ROUTINE TO
;SAVE R1 THROUGH R5 ON THE STACK
;
;CALLING SEQUENCE:
;
;       JSR      R5,REGSAV
;
;THIS IS A COOROUTINE WHICH TRANSFER CONTROL BACK TO
;THE CALLING ROUTINE. AT THE END OF THE CALLING ROUTINE,
;THE RTS PC RETURNS CONTROL TO THIS ROUTINE TO RESTORE
;REGISTERS.
;
;THIS ROUTINE SHOULD ONLY BE CALLED FROM ROUTINES WHICH ARE
;CALLED VIA A JSR PC INSTRUCTION
;
;-
REGSAV:
        BREAK
        TRAP      C$BRK           ;LOOK FOR CNTL C
        MOV       R4,-(SP)
        MOV       R3,-(SP)
        MOV       R2,-(SP)
        MOV       R1,-(SP)
        MOV       R5,-(SP)
        MOV       10.(SP),R5
        JSR      PC,@(SP)+
        MOV       (SP)+,R1
        MOV       (SP)+,R2
        MOV       (SP)+,R3
        MOV       (SP)+,R4
        MOV       (SP)+,R5
        BREAK
        TRAP      C$BRK           ;LOOK FOR CNTL C
        RTS      PC
    
```

```

3592 .SBTTL GETPAT - GET 8 BIT PATTERN FROM OPERATOR
3593 ;+
3594 ;ROUTINE TO REQUEST AN 8 BIT DATA PATTERN FROM THE OPERATOR
3595 ;
3596 ;INPUTS:
3597 ;
3598 ; NONE.
3599 ;
3600 ;OUTPUTS:
3601 ;
3602 ; RO OCTAL NUMBER FROM THE OPERATOR
3603 ;
3604 ;CALLING SEQUENCE:
3605 ;
3606 ; JSR PC,GETPAT
3607 ;
3608 ;-
3609 ;
3610 ;
3611 021114 GETPAT::
3612 021114 SAVREG ;SAVE THE GENERAL REGISTERS
3613 021120 1# : GMANID DATASC,PATDAT,0,377,0,377,NO
      021120 104443 TRAP C#GMAN
      021122 000406 BR 10000#
      021124 021150 .WORD PATDAT
      021126 000022 .WORD T#CODE
      021130 021152 .WORD DATASC
      021132 000377 .WORD 377
      021134 000000 .WORD T#LOLIM
      021136 000377 .WORD T#HILIM
      021140 10000# :
3614 021140 B#COMPLETE 1# ;RETRY IF ERROR
      021140 103367 BCC 1#
3615 021142 013700 021150 MOV PATDAT,RO ;DATA PATTERN FROM OPERATOR
3616 021146 000207 RTS PC ;RETURN TO CALLER
3617 ;
3618 ;+
3619 ;LOCAL DATA AREA
3620 ;
3621 ;-
3622 021150 000000 PATDAT: .WORD 0 ;TEMPORARY STORAGE FOR DATA
3623 021152 105 116 124 DATASC: .ASCIZ 'ENTER DATA PATTERN'
3624 .EVEN
  
```



```

3626 .SBTTL GETSEL - ISSUE MENU AND GET OPERATOR RESPONSE
3627
3628 ;ROUTINE TO ISSUE A MENU AND GET
3629 ;THE OPERATOR'S RESPONSE.
3630 ;INPUTS:
3631
3632 ; R0 ADDRESS OF ASCIZ STRING OF MENU
3633 ; R1 MAXIMUM ALLOWABLE OPERATOR RESPONSE
3634 ;OUTPUTS:
3635
3636 ; R0 NUMBER OF THE OPERATOR'S SELECTION
3637
3638 GETSEL::
3639 021176 SAVREG ;SAVE GENERAL REGISTERS
3640 021202 010002 MOV R0,R2 ;SAVE THE MENU ADDRESS
3641 021204 010203 1#: MOV R2,R3 ;START OF MENU STRING
3642 021206 005713 2#: TST (R3) ;END OF ASCII ?
3643 021210 001412 BEQ 3# ;BRANCH IF ALL LINES DISPLAYED
3644 021212 PRINTF @SELASC,(R3) ;DISPLAY THE MENU
      021214 012746 021362 MOV (R3),-(SP)
      021220 012746 000002 MOV @SELASC,-(SP)
      021224 010600 MOV @2,-(SP)
      021226 104417 MOV SP,R0
      021230 062706 000006 TRAP CIPNTF
3645 021234 000764 ADD @6,SP
3646 021236 3#: BR 2#
      021236 104443 GMANID MENASC,MENRES,D,-1,0,-1,NO
      021240 000406 TRAP CIGMAN
      021242 021416 JR 10001#
      021244 000042 .WORD MENRES
      021246 021367 .WORD TICODE
      021250 177777 .WORD MENASC
      021252 000000 .WORD -1
      021254 177777 .WORD TLOLIM
      021256 10001# .WORD THILIM
3647 021256 BNCOMPLETE 1# ;RETRY IF ERROR
      021256 103352 BCC 1#
3648 021260 013700 021416 MOV MENRES,R0 ;GET THE OPERATOR'S REPLY
3649 021264 020001 CMP R0,R1 ;COMPARE TO MAXIMUM ALLOWED
3650 021266 101411 BLOS 5# ;BRANCH IF OK
3651 021270 PRINTF @MENERR ;DISPLAY ERROR MESSAGE
      021270 012746 021314 MOV @MENERR,-(SP)
      021274 012746 000001 MOV @1,-(SP)
      021300 010600 MOV SP,R0
      021302 104417 TRAP CIPNTF
      021304 062706 000004 ADD @1,SP
3652 021310 000735 BR 1# ;RETRY
3653 021312 000207 RTS PC ;RETURN TO CALLER
3654 021314 045 116 045 MENERR: .ASCIZ '### Menu Selection Too Large ###'
3655 021362 045 116 045 SELASC: .ASCIZ '###'
3656 021367 105 156 164 MENASC: .ASCIZ 'Enter Menu Selection: '
3657
3658 021416 000000 MENRES: .WORD 0

```

```

3660          .SBTTL  CHKMAN  - CHECK MANUAL INTERVENTION LEGALITY
3661          ;*
3662          ;
3663          ;ROUTINE TO TEST FOR MANUAL INTERVENTION LEGALITY.
3664          ;
3665          ;INPUT:
3666          ;
3667          ;      NONE.
3668          ;
3669          ;OUTPUT:
3670          ;
3671          ;      CARRY    0      MANUAL INTERVENTION NOT ALLOWED
3672          ;              1      MANUAL INTERVENTION IS OK
3673          ;
3674          ;SIDE EFFECTS:
3675          ;
3676          ;      A MESSAGE IS DISPLAYED WARNING THAT TEST IS
3677          ;      NOT EXECUTED IF MANUAL INTERVENTION IS NOT
3678          ;      ALLOWED.
3679          ;
3680          ;
3681          ;-
3682 021420      CHKMAN::
3683 021420      SAVREG          ;SAVE THE REGISTERS
3684 021424      MANUAL          ;SEE IF MANUAL INTERVENTION OK
3685 021424      104450          TRAP    C#MANI
3686 021426      103411          BCOMPLETE 1#          ;BRANCH IF ALLOWED
3687 021430      012746 021454    PRINTF  #NOMAN          ;PRINT THE WARNING MESSAGE
3688 021434      012746 000001    MOV     #NOMAN, -(SP)
3689 021440      010600          MOV     #1, -(SP)
3690 021442      104417          MOV     SP, R0
3691 021444      062706 000004    TRAP    C#PNTF
3692 021450      000241          ADD     #4, SP
3693 021452      000207          CLC          ;CLEAR CARRY FOR ERROR
3694          ;
3695          ;*
3696          ;
3697          ;
3698          ;
3699          ;
3700          ;
3701          ;
3702          ;
3703          ;
3704          ;
3705          ;
3706          ;
3707          ;
3708          ;
3709          ;
3710          ;
3711          ;
3712          ;
3713          ;
3714          ;
3715          ;
3716          ;
3717          ;
3718          ;
3719          ;
3720          ;
3721          ;
3722          ;
3723          ;
3724          ;
3725          ;
3726          ;
3727          ;
3728          ;
3729          ;
3730          ;
3731          ;
3732          ;
3733          ;
3734          ;
3735          ;
3736          ;
3737          ;
3738          ;
3739          ;
3740          ;
3741          ;
3742          ;
3743          ;
3744          ;
3745          ;
3746          ;
3747          ;
3748          ;
3749          ;
3750          ;
3751          ;
3752          ;
3753          ;
3754          ;
3755          ;
3756          ;
3757          ;
3758          ;
3759          ;
3760          ;
3761          ;
3762          ;
3763          ;
3764          ;
3765          ;
3766          ;
3767          ;
3768          ;
3769          ;
3770          ;
3771          ;
3772          ;
3773          ;
3774          ;
3775          ;
3776          ;
3777          ;
3778          ;
3779          ;
3780          ;
3781          ;
3782          ;
3783          ;
3784          ;
3785          ;
3786          ;
3787          ;
3788          ;
3789          ;
3790          ;
3791          ;
3792          ;
3793          ;
3794          ;
3795          ;
3796          ;
3797          ;
3798          ;
3799          ;
3800          ;
3801          ;
3802          ;
3803          ;
3804          ;
3805          ;
3806          ;
3807          ;
3808          ;
3809          ;
3810          ;
3811          ;
3812          ;
3813          ;
3814          ;
3815          ;
3816          ;
3817          ;
3818          ;
3819          ;
3820          ;
3821          ;
3822          ;
3823          ;
3824          ;
3825          ;
3826          ;
3827          ;
3828          ;
3829          ;
3830          ;
3831          ;
3832          ;
3833          ;
3834          ;
3835          ;
3836          ;
3837          ;
3838          ;
3839          ;
3840          ;
3841          ;
3842          ;
3843          ;
3844          ;
3845          ;
3846          ;
3847          ;
3848          ;
3849          ;
3850          ;
3851          ;
3852          ;
3853          ;
3854          ;
3855          ;
3856          ;
3857          ;
3858          ;
3859          ;
3860          ;
3861          ;
3862          ;
3863          ;
3864          ;
3865          ;
3866          ;
3867          ;
3868          ;
3869          ;
3870          ;
3871          ;
3872          ;
3873          ;
3874          ;
3875          ;
3876          ;
3877          ;
3878          ;
3879          ;
3880          ;
3881          ;
3882          ;
3883          ;
3884          ;
3885          ;
3886          ;
3887          ;
3888          ;
3889          ;
3890          ;
3891          ;
3892          ;
3893          ;
3894          ;
3895          ;
3896          ;
3897          ;
3898          ;
3899          ;
3900          ;
3901          ;
3902          ;
3903          ;
3904          ;
3905          ;
3906          ;
3907          ;
3908          ;
3909          ;
3910          ;
3911          ;
3912          ;
3913          ;
3914          ;
3915          ;
3916          ;
3917          ;
3918          ;
3919          ;
3920          ;
3921          ;
3922          ;
3923          ;
3924          ;
3925          ;
3926          ;
3927          ;
3928          ;
3929          ;
3930          ;
3931          ;
3932          ;
3933          ;
3934          ;
3935          ;
3936          ;
3937          ;
3938          ;
3939          ;
3940          ;
3941          ;
3942          ;
3943          ;
3944          ;
3945          ;
3946          ;
3947          ;
3948          ;
3949          ;
3950          ;
3951          ;
3952          ;
3953          ;
3954          ;
3955          ;
3956          ;
3957          ;
3958          ;
3959          ;
3960          ;
3961          ;
3962          ;
3963          ;
3964          ;
3965          ;
3966          ;
3967          ;
3968          ;
3969          ;
3970          ;
3971          ;
3972          ;
3973          ;
3974          ;
3975          ;
3976          ;
3977          ;
3978          ;
3979          ;
3980          ;
3981          ;
3982          ;
3983          ;
3984          ;
3985          ;
3986          ;
3987          ;
3988          ;
3989          ;
3990          ;
3991          ;
3992          ;
3993          ;
3994          ;
3995          ;
3996          ;
3997          ;
3998          ;
3999          ;
4000          ;

```

```

3693                                     .SBTTL  ENVIRN  - SETUP FREE DIAGNOSTIC SPACE
3694                                     ;
3695                                     ; SUBROUTINE TO SET-UP VARIOUS ENVIRONMENTAL PARAMETERS.
3696                                     ;
3697 021550  ENVIRN: MEMORY R0
      021550 104431      TRAP  C#MEM
3698 021552 010037 003072      MOV  R0,FREE      ; GET 1ST FREE ADDRESS...
3699 021556 062737 000002 003072      ADD  #2,FREE
3700 021564 011037 003074      MOV  (R0),FRESIZ ; ...AND WORD COUNT.
3701 021570 162737 000004 003074      SUB  #4,FRESIZ
3702 021576 013702 002012      MOV  L#UNIT,R2   ; GET NUMBER OF UNITS
3703 021602 162737 000007 003074 10#;  SUB  #7,FRESIZ   ; TAKE AWAY 7 WORDS PER UNIT
3704 021610 005302      DEC  R2
3705 021612 001373      BNE  10#
3706 021614 013700 003072      MOV  FREE,R0    ;GET FIRST FREE ADDRESS
3707 021620 063700 003074      ADD  FRESIZ,R0  ;POINT TO LAST FREE ADDRESS
3708 021624 162700 000002      SUB  #2,R0      ;BACKUP 1 WORD
3709 021630 010037 003076      MOV  R0,FREEHI ;STORE LAST FREE ADDRESS
3710 021634 000207      RTS   PC       ;RETURN
3711

```

```

3713 .SBTTL KTINIT - SETUP KT11 MEMORY MANAGEMENT REGISTERS
3714 ;*
3715 ;
3716 ;ROUTINE TO INIT KT-11
3717 ;
3718 ;-
3719
3720 KTINIT:
3721 021636 005037 003100 CLR KTF LG ; INIT >28K MEMORY FLAG
3722 021642 005037 003102 CLR K TENABLE ; INIT TEST >28K FLAG
3723 021646 023727 002120 001577 CMP L#HIME,#1577 ; GOT ENOUGH MEMORY (>28K)?
3724 021654 101444 BLOS 9# ; NO.
3725 021656 013700 000004 MOV @ERRVEC,RO ; SAVE OLD ERR VEC PTR.
3726 021662 012737 021754 000004 MOV #2#,@ERRVEC ; SET ERR VEC PTR.
3727 021670 005737 177572 TST @SRO ; GOT KT11?
3728 021674 000240 NOP ; (TRAP IF NO).
3729 021676 013737 002120 003100 MOV L#HIME,KTF LG ; YES. SET KT FLAG.
3730 021704 042737 000177 003100 BIC #177,KTF LG ;
3731 021712 010037 000004 MOV RO,@ERRVEC ; RESTORE OLD ERR VEC PTR.
3732 021716 005000 CLR RO ; RO = AR DATA.
3733 021720 012701 172340 MOV #KIPAR,R1 ; R1 = KI REGS PTR.
3734 021724 012761 077406 177740 1#; MOV #77406,-40(R1) ; SET DESCRIPTOR REG.
3735 021732 010021 MOV RO,(R1)+ ; SET KIPAR REG.
3736 021734 062700 000200 ADD #200,RO ; BUMP AR DATA BY "4K".
3737 021740 020027 002000 CMP RO,#2000 ; AT "I/O"?
3738 021744 001367 BNE 1# ; NO.
3739 021746 012741 177600 MOV #177600,-(R1) ; YES. SET KTPAR7 FOR I/O.
3740 021752 000405 BR 9#
3741
3742 021754 012716 021762 2#; MOV #6#,(SP) ; SET UP RETURN
3743 021760 000002 RTI ; RTI TO NEXT LOCATION
3744
3745 021762 010037 000004 6#; MOV RO,@ERRVEC ; RESTORE OLD ERR VEC PTR.
3746
3747 021766 000207 9#; RTS PC
3756
3757
3763

```

F9

CZTKGA TK-25 FRT END FUNC #3 MACRO M1200 20-APR-84 08:13 PAGE 82
PROTECTION TABLE

SEQ 109

```
3765 .SBTTL PROTECTION TABLE
3766 021770 BGNPROT
      021770
3767 021770 177777 177777 177777 L$PROT::
3768 022000 .WORD -1, -1, -1, -1 ;NO DEVICE PROTECTION REQUIRED.
3769 ENDPROT
```

```

3771 .SBTTL INITIALIZE SECTION
3772
3773
3774 ;**
3775 ;THE INITIALIZE SECTION CONTAINS THE CODING THAT IS PERFORMED
3776 ;AT THE BEGINNING OF EACH PASS.
3777
3778 ;IF "START" OR "RESTART", SET QUICK-PASS FLAG AND BUS-INIT.
3779 ;IF "CONTINUE", NOTHING IS REQUIRED.
3780
3781 ;--
3782 ;*
3783 ;INSERT TEMPORARY JUMP TO ODT
3784 ;-
022000 BGNINIT
022000
3785 022000
022000 L$INIT:;
022000 40$:
3786 022000 012737 005672 002146 MOV #EPRT1,EPRTSW ;SET UP PRIMARY MESSAGE FOR REPLACEMENT
3787 022006 005037 003106 CLR SIFLAG ;CLEAR "SOFT INIT" FLAG
3788 022012 005037 003102 CLR KTENABLE ;CLEAR TEST ABOVE 28K FLAG
3789 022016 005037 002246 CLR RAMSIZ ;CLEAR RAM SIZE FOR RAMERR ROUTINE
3790 022022
022022 012700 000036 READEF #EF.CONTINUE
022026 104447 MOV #EF.CONTINUE,R0
3791 022030 TRAP C$REFG
022030 BNCOMPLETE 1$
3792 022032 103023 BCC 1$
3793 022040 023737 002150 002012 CMP UNITN,L$UNIT ;UNIT IN RANGE?
3794 022042 103064 BHIS 4$ ;BR IF NO.
3795 022046 005737 003060 TST DUFLG ;DROPPED UNIT?
3796 022050 013701 002150 BMI NXTU ;BR IF YES
3797 022054 006301 MOV UNITN,R1
3798 022056 005761 003130 ASL R1
3799 022062 001512 TST ERTABL(R1)
3800 022064 032761 040000 003130 BEQ SETU
3801 022072 001054 BIT #BIT14,ERTABL(R1) ;DROPPED?
3802 022074 BNE NXTU
022074 EXIT INIT ;DO NOTHING IF "CONTINUE".
022074 104432 TRAP C$EXIT
022076 000412 .WORD L10030-
3803 022100 1$: READEF #EF.NEW
022100 012700 000035 MOV #EF.NEW,R0
022104 104447 TRAP C$REFG
3804 022106 BNCOMPLETE NXTU ;TAKE NEXT UNIT IF NOT NEW PASS.
022106 103046 BCC NXTU
3805 022110 READEF #EF.START
022110 012700 000040 MOV #EF.START,R0
022114 104447 TRAP C$REFG
3806 022116 BCOMPLETE 2$
022116 103404 BCS 2$
3807 022120 READEF #EF.RESTART
022120 012700 000037 MOV #EF.RESTART,R0
022124 104447 TRAP C$REFG
3808 022126 BNCOMPLETE 31$
022126 103025 BCC 31$
3809 022130 2$: BRESET ;1ST PASS, BUS-INIT...
3810 022130 TRAP C$RESET ;BUS RESET.
022130 104433
3811 022132 005037 002162 CLR TSTCNT ;NUMBER OF TESTS RUN IN PASS

```

```

3812 022136 005037 002170          CLR    FATFLG      ;RESET FLAG TO ZERO "FATAL ERRORS"
3813 022142 005037 003332          CLR    SKIPT      ;CLEAR THE SUBTEST "SKIPPER"
3814 022146                                19#:
3815 022146 012737 177777 002152  20#:          MOV    *-1,QVP    ;...QUICK VERIFY...
3816 022154 004737 021550          JSR    PC,ENVIRN  ;SET ENVIRONMENT.
3817 022160 004737 021636          JSR    PC,KTINIT  ;INITIALIZE KT MEMORY MANAGEMENT
3818 022164 012700 003130          MOV    *ERTABL,RO
3819 022170 005020          30#:          CLR    (RO)+      ;CLEAR THE ERROR TABLE
3820 022172 020027 003330          CMP    RO,*ERTABE
3821 022176 103774          BLO   30#
3822 022200 000404          BR    4#
3823 022202 005037 002152          31#:          CLR    QVP
3824 022206 000137 022256          JMP    PASRPT     ;GO REPORT THE STATUS
3825
3826 022212                                4#:
3827 022212 012737 177777 002150  NEWPAS: MOV    *-1,UNITN  ;INIT UNIT NUMBER...
3828 022220 005037 002166          CLR    DEVCNT    ;CLEAR COUNT OF DEVICES RUNNING
3829 022224                                NXTU:
3830 022226 104422          TRAP  C#BRK
3831 022232 005237 002150          INC   UNITN
3832 022240 103423          CMP   UNITN,L#UNIT ;...AND SET NEXT UNIT NUMBER.
3833 022242 012737 177777 003060  BLO   SETU
3834 022250 000401          MOV   *-1,DUFLG
3835 022252          BR    11#
3836 022252 104444          DOCLN
3837 022254 000240          TRAP  C#DOCLN    ;ABORT, NO MORE UNITS.
3838 022256          NOP
3839 022256 023727 002012 000001  11#:          PASRPT:
3840 022264 101752          CMP   L#UNIT,*1  ;HOW MANY UNITS SELECTED?
3841 022266 005737 002166          BLOS  NEWPAS     ;BR IF ONLY 1
3842 022272 001747          TST  DEVCNT     ;ARE ANY STILL RUNNING?
3843 022274 104421          BEQ  NEWPAS     ;BR IF NO
3844 022276 032700 000100          RFLAGS RO
3845 022302 001343          TRAP  C#RFLA
3846 022304          BIT  *ISR,RO  ;SHOULD WE PRINT STATISTICS
3847 022306 104424          BNE  NEWPAS     ;BR IF NO
3848 022310          DORPT
3849          TRAP  C#DRPT
3850 022310          BR    NEWPAS
3851 022310          10#:
3852 022310 013700 002150  SETU:  GPHARD UNITN,RO  ;GET UNIT N P-TABLE POINTER.
3853 022314 104442          MOV   UNITN,RO
3854 022316          TRAP  C#GPHARD
3855 022316 103342          BNCOMPLETE NXTU ;BR IF UNIT NOT AVAILABLE.
3856 022320 005037 003060          BCC  NXTU
3857 022324 005237 002166          CLR  DUFLG      ;CLEAR "DROPPED" FLAG.
3858 022330 012001          INC  DEVCNT
3859 022332 010137 002154          MOV  (RO)+,R1   ;GET 1ST REGISTER ADDRESS.
3860 022336 012001          MOV  R1,CSRADDR ;ADDRESS OF REGISTERS OF UNIT UNDER TEST
3861 022340 011002          MOV  (RO)+,R1   ;GET VECTOR ADDRESS.
3862 022342 010237 000160          MOV  (RO),R2   ;GET INTERRUPT PRIORITY
3863 022344 010137 002156          MOV  R2,IPRI   ;SET INTERRUPT PRIORITY.
3864 022346 012721 017102          MOV  R1,IVEC   ;SET INTERRUPT VECTOR POINTER...
3865 022352          MOV  *INTR,(R1)+ ;...VECTOR...

```

```

3862 022356 010221          MOV     R2,(R1)+      ;...AND PRIORITY.
3863
3864 022360          1$:
3865          ;          TST     QVP          ;1ST PASS ??
3866          ;          BEQ     5$          ;NO, SKIP THE PASS 1 STUFF.
3867
3868          ;
3869          ;1ST PASS, CHECK THAT DEVICE ADDRESSES ARE VALID, AND
3870          ;THAT THE DISPLAY STATUS IS PROPERLY INITIALIZED.
3871          ;
3872 022360 013701 002150          MOV     UNITN,R1
3873 022364 006301          ASL     R1
3874 022366 052761 100000 003130  BIS     #BIT15,ERTABL(R1) ;SAY DEVICE RUNNING
3875 022374 005037 005232          CLR     EXTA          ;CLEAR ERROR EXTENSION FLAG.
3876 022400 023727 002012 000001  CMP     L$UNIT,#1      ;ARE WE TESTING MULTIPLE UNITS?
3877 022406 101416          BLOS   10$           ;BR IF NO.
3878 022410          RFLAGS  R0          ;YES -- GET OPERATOR FLAGS.
3879 022412 032700 001000          TRAP   C$RFLA
3880 022416 001412          BIT     #PNT,R0       ;SHOULD WE PRINT UNIT #?
3881 022420          BEQ     10$           ;BR IF NOT.
3882 022420 013746 002150          PRINTF #PUNIT,UNITN ;PRINT THE UNIT #
3883 022424 012746 022512          MOV     UNITN,-(SP)
3884 022430 012746 000002          MOV     #PUNIT,-(SP)
3885 022434 010600          MOV     #2,-(SP)
3886 022436 104417          MOV     SP,R0
3887 022440 062706 000006          TRAP   C$PNTF
3888 022444          ADD     #6,SP
3889 022444          10$:
3890 022450 013701 002154          CLR     NODEV
3891 022454 010102          MOV     CSRADDR,R1   ;ADDRESS OF FIRST REGISTER
3892 022456 062702 000000          MOV     R1,R2        ;START OF REGISTERS
3893 022462 004737 017312          ADD     #TSSR,R2     ;ADDRESS OF TSSR REGISTER
3894 022466 103005          JSR     PC,XNXM      ;TEST BOTH CONTROLLER REGISTERS...
3895 022470 010137 003062          BCC    2$            ;...AND BR IF ALL OK.
3896 022474 012737 177777 003060  MOV     R1,NODEV     ;FLAG DEVICE AS NON-EXISTENT
3897 022502          MOV     #-1,DUFLG   ;DROP THIS UNIT.
3898
3899          ;
3900          ;FINALLY, SET CPU PRIORITY AND WE'RE DONE.
3901          ;
3902          ;
3903          ;5$:
3904          SETPRI  #PRI00          ;ENABLE INTERRUPTS.
3905          MOV     #PRI00,R0
3906          TRAP   C$SPRI
3907          ENDINIT
3908          L10030:
3909          TRAP   C$INIT
3910
3911          045 PUNIT: .ASCIZ /#N#N#A***** TESTING UNIT #D2#A *****/
3912          .EVEN

```


K9

CZTKGA TK-25 FRT END FUNC #3
ADD AND DROP UNITS SECTIONS

MACRO M1200 20-APR-84 08:13 PAGE 84-1

SEQ 114

3938	022732	045	116	045	1\$:	.ASCIZ /#N#A UNIT #D#A DROPPED/ .EVEN ENDDU	
3939							
3940	022762				L10032:	TRAP C#DU	
	022762	104453					
3941					!++		
3942					! AUTO-DROP CODE SECTION.		
3943					!--		
3944	022764				BGNAUTO		
	022764				L\$AUTO:;		
3945	022764	012703	000550		MOV #360.,R3		;ENOUGH TIME FOR 2400' REEL TO REWIND
3946	022770	004737	017134		JSP: PC,WAITF		;WAIT FOR SSR TO SET
3947	022774	103420			BCS 20\$;LEAVE WHEN SSR IS SET
3948	022776				DELAY 250.		;WAIT FOR .25 SECONDS
	022776	012727	000372		MOV #250.,(PC)+		
	023002	000000			.WORD 0		
	023004	013727	002116		MOV L\$JLY,(PC)+		
	023010	000000			.WORD 0		
	023012	005367	177772		DEC -6(PC)		
	023016	001375			BNE .-4		
	023020	005367	177756		DEC -22(PC)		
	023024	001367			BNE .-20		
3949	023026	005303			DEC R3		;BUMP COUNTER DOWN
3950	023030	001357			BNE 10\$;KEEP GOING
3951	023032	004737	020170		JSR PC,CKDROP		;TRY AND DROP UNIT
3952	023036				20\$:		
3953	023036				ENDAUTO		; UNUSED.
	023036	104461			L10033:	TRAP C\$AUTO	

```

3955                                     .SBTTL  CLEAN-UP AND REPORT CODING SECTIONS
3956
3957
3958                                     ; **
3959                                     ; THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS
3960                                     ; EXECUTED AT THE END OF EACH PASS (OR SUB-PASS).
3961                                     ; USE TO RETURN DEVICE UNDER TEST TO A NEUTRAL STATE.
3962                                     ; **
3962 023040                                     BGNCLN
3963 023040                                     L#CLEAN::
3964 023040 005737 003060                       TST     DUFLG           ; "DROPPED" FLAG IS SET ON...
3965 023044 100407                               BMI     1#             ; ...AND GROSS CONTROLLER FAULT...
3966                                                                   ; ...DON'T TRY TO XCT CLEANUP CODE.
3967 023046 013705 002154                       MOV     CSRADDR,R5     ; ADDRESS OF TSV REGISTERS ON UNIBUS
3968 023052 012765 000000 000000             MOV     #0,TSSR(R5)    ; DO SOFT INIT
3969 023060 004737 017134                       JSR     PC,WAITF
3970 023064                                     1#:
3971 023064                                     2#:
3971 023064                                     L10034:
3971 023064 104412                               TRAP   C#CLEAN
3972
3973                                     ; **
3974                                     ; THE REPORT CODING SECTION CONTAINS THE
3975                                     ; "PRINTS" CALLS THAT GENERATE STATISTICAL REPORTS.
3976                                     ; **
3976 023066                                     BGNRPT
3977 023066                                     L#RPT::
3977 023066 012746 023330                       PRINTS #DEVSUM
3977 023072 012746 000001                       MOV     #DEVSUM,-(SP)
3977 023076 010600                               MOV     #1,-(SP)
3977 023100 104416                               MOV     SP,R0
3977 023102 062706 000004                       TRAP   C#PNTS
3978 023106 010246                               ADD     #4,SP
3979 023110 010346                               MOV     R2,-(SP)
3980 023112 010446                               MOV     R3,-(SP)
3981 023114 012704 003130                       MOV     R4,-(SP)
3982 023120 005003                               MOV     #ERTABL,R4     ; GET START OF ERROR TABLE.
3983 023122 011402                               CLR     R3             ; CLEAR UNIT NUMBER
3984 023124 001467                               1#: MOV     (R4),R2     ; GET ERROR TABLE ENTRY & TEST IT.
3985 023126 100066                               BEQ     4#             ; ZERO IF UNIT NOT RUN
3986 023130 032702 040000                       BPL     4#
3987 023134 001015                               BIT     #BIT14,R2     ; WAS UNIT DROPPED?
3988 023136 042702 170000                       BNE     2#             ; BR IF YES
3989 023142                                     BIC     #C7777,R2     ; GET ERROR COUNT FIELD
3989 023142 010246                               PRINTS #DEVONL,R3,R2  ; PRINT
3989 023144 010346                               MOV     R2,-(SP)
3989 023146 012746 023365                       MOV     R3,-(SP)
3989 023152 012746 000003                       MOV     #DEVONL,-(SP)
3989 023156 010600                               MOV     #3,-(SP)
3989 023160 104416                               MOV     SP,R0
3989 023162 062706 000010                       TRAP   C#PNTS
3990 023166 000446                               ADD     #10,SP
3991 023170 020227 160000                       BR     4#
3992 023174 001012                               2#: CMP     R2,#160000  ; WAS UNIT NON-EXISTENT?
3993 023176 010346                               BNE     3#             ; BR IF NO
3993 023176 010346                               PRINTS #DEVNXR,R3
3993 023200 012746 023435                       MOV     R3,-(SP)
3993 023200 012746 023435                       MOV     #DEVNXR,-(SP)

```

```

023204 012746 000002      MOV      #2,-(SP)
023210 010600      MOV      SP,R0
023212 104416      TRAP     C#PNTS
023214 062706 000006      ADD      #6,SP
3994 023220 000431      BR       4#
3995 023222 020227 150001  3#:      CMP      R2,#160001      ; WAS UNIT NOT READY AT STARTUP?
3996 023226 001012      BNE      30#           ; BR IF NO.
3997 023230      PRINTS  #DEVNRD,R3
023230 010346      MOV      R3,-(SP)
023232 012746 023517      MOV      #DEVNRD,-(SP)
023236 012746 000002      MOV      #2,-(SP)
023242 010600      MOV      SP,R0
023244 104416      TRAP     C#PNTS
023246 062706 000006      ADD      #6,SP
3998 023252 000414      BR       4#
3999 023254 042702 170000  30#:     BIC      #C7777,R2
4000 023260      PRINTS  #DEVDR0,R3,R2
023260 010246      MOV      R2,-(SP)
023262 010346      MOV      R3,-(SP)
023264 012746 023600      MOV      #DEVDR0,-(SP)
023270 012746 000003      MOV      #3,-(SP)
023274 010600      MOV      SP,R0
023276 104416      TRAP     C#PNTS
023300 062706 000010      ADD      #10,SP
4001 023304 062704 000002  4#:      ADD      #2,R4
4002 023310 005203      INC      R3
4003 023312 020427 003330      CMP      R4,#ERTABE
4004 023316 103701      BLO     1#
4005 023320 012604      MOV      (SP)+,R4
4006 023322 012603      MOV      (SP)+,R3
4007 023324 012602      MOV      (SP)+,R2
4008 023326      ENDRPT      ; UNUSED.
023326 104425  L10035:    TRAP     C#RPT
4009
4010
4011 023330      045      116      045  DEVSUM: .ASCIZ /#N#ADEVICE STATUS SUMMARY;#N/
4012 023365      045      101      040  DEVONL: .ASCIZ /#A UNIT #D3#A ONLINE, ERRORS = #D#N/
4013 023435      045      101      040  DEVNXR: .ASCIZ /#A UNIT #D3#A DROPPED, NON-EXISTENT REGISTER#N/
4014 023517      045      101      040  DEVNRD: .ASCIZ /#A UNIT #D3#A DROPPED, NOT READY AT STARTUP#N/
4015 023600      045      101      040  DEVDR0: .ASCIZ /#A UNIT #D3#A DROPPED, ERRORS = #D#N/
4016
4019
4026
4032
4040

```



```

4100
4101
4102 023740 004737 016660
4103 023744 103427
4104 023746
      023746 012727 000250
      023752 000000
      023754 013727 002116
      023760 000000
      023762 005367 177772
      023766 001375
      023770 005367 177756
      023774 001367
4105 023776 005337 030272
4106 024002 001356
4107 024004 004737 020116
4111 024010 016501 000000
4112 024014
      024014 104455
      024016 000145
      024020 003550
      024022 011676
4113 024024
4114
4115 024024 012704 030110
4116
4117
4118
4119
4120
4121
4122
4123 024030 004737 010342
4124 024034 103407
4125 024036 004737 020116
4129 024042 010001
4130 024044
      024044 104456
      024046 000146
      024050 004754
      024052 011676
4131
4132
4133
4134
4135 024054 016501 000000
4136 024060 032701 000100
4137 024064 001406
4141 024066
      024066 104455
      024070 000147
      024072 030274
      024074 016360
4142 024076 004737 020170
4143
4144
4145

```

```

|*****|
51: JSR PC,SOFINIT ;DO INITIALIZE ON CONTROLLER
      BCS 101 ;BR IF INIT WAS OK
      DELAY 250 ;DELAY IF REQUIRED
                                MOV #250,(PC)+
                                .WORD 0
                                MOV L1DLY,(PC)+
                                .WORD 0
                                DEC -6(PC)
                                BNE .-4
                                DEC -22(PC)
                                BNE .-20
                                DEC T25DLY ;DEC DELAY COUNTER
                                BNE 51 ;BR, IF LOOP IS REQUIRED
      JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
      MOV TSSR(R5),R1 ;CONTENTS OF TSSR REGISTER
      ERROF ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
                                TRAP CIERDF
                                .WORD 101
                                .WORD SFIERR
                                .WORD SFIMSG
101: MOV #T25PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
|*****|
;WRITE CHARACTERISTICS COMMAND (CALL TO WRTPHR)
|*****|
      JSR PC,WRTPHR ;ISSUE WRITE CHARACTERISTICS
      BCS 141 ;BR, IF COMMAND ISSUED OK
      JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
      MOV R0,R1 ;SAVE CONTENTS OF TSSR
      ERROF ERRNO,WRTPMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP CIERROF
                                .WORD 102
                                .WORD WRTPMSG
                                .WORD SFIMSG
;
; CHECK FOR DRIVE OFF-LINE
141: MOV TSSR(R5),R1 ;READ THE TSSR
      BIT #OFL,R1 ;CHECK FOR DRIVE OFF LINE
      BEQ 151 ;BR, IF DRIVE IS ON LINE (GOOD)
      ERROF ERRNO,T21OFL,EXPREC ;"DRIVE IS OFF-LINE" (BAD)
                                TRAP CIERDF
                                .WORD 103
                                .WORD T21OFL
                                .WORD EXPREC
      JSR PC,CKDROP ;TRY AND DROP UNIT
|*****|

```

```

4146 ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
4147 ;
4148 ;*****
4149
4150 024102 004737 010444 15#: JSR PC,REWIND ;CALL TAPE REWIND COMMAND
4151 024106 103407 BCS 30# ;BR, IF NO PROBLEM
4152 024110 010001 MOV R0,R1 ;SAVE TSSR
4153 024112 004757 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4157 024116 ERRHRD ERRNO,T25RWN,PKTSSR ;REWIND NOT ACCEPTED
; TRAP C#ERHRD
; .WORD 104
; .WORD T25RWN
; .WORD PKTSSR
024116 104456
024120 000150
024122 031267
024124 011710
4158 024126 104406 30#: CKLOOP ;LOOP IF SELECTED
; TRAP C#CLP1
024126 104406
4159
4160 ;*****
4161 ;
4162 ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
4163 ;
4164 ;*****
4165
4166 024130 013701 030136 MOV T25BFR+6,R1 ;PICK UP XSTO
4167 024134 010102 MOV R1,R2 ;SET UP EXPECTED
4168 024136 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
4169 024142 020102 CMP R1,R2 ;DOES EXP = REC'D
4170 024144 001406 BEQ 40# ;BR, IF EQUAL (OK)
4171 024146 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4175 024152 ERRHRD ERRNO,T25BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
; TRAP C#ERHRD
; .WORD 105
; .WORD T25BOT
; .WORD EXPREC
024152 104456
024154 000151
024156 030457
024160 016360
4176 024162 104406 40#: CKLOOP ;LOOP IF SELECTED
; TRAP C#CLP1
024162 104406
4177 024164 012703 000400 MOV #256.,R3 ;RECORD SIZE
4178 024170 013737 003072 030242 MOV FREE,T25RB ;STARTING WRITE BUFFER ADDRESS
4179
4180 ;*****
4181 ;
4182 ;WRITE DATA,ACK,CVC=1 COMMAND
4183 ;
4184 ;*****
4185
4186 024176 012737 140005 030240 MOV #140005,T25PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
4187 024204 012704 030240 MOV #T25PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4188 024210
4189 024210 010337 030246 65#: MOV R3,T25SZ ;SET UP RECORD SIZE IN PACKET
4190 024214 013777 030270 154650 MOV T25CNT,DFREE ;LOAD UP RECORD COUNTER IN WRT BUFFER
4191 024222 062737 000001 030270 ADD #1,T25CNT ;GET READY FOR NEXT RECORD
4192 024230 010465 177776 MOV R4,TSDB(R5) ;ISSUE COMMAND
4193 024234 004737 017134 JSR PC,WAITF ;WAIT FOR SSR TO SET
4194 024240 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
4195 024244 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
4196 024250 020102 CMP R1,R2 ;ARE THEY EQUAL
4197 024252 001411 BEQ 75# ;BR, IF OK
4198 024254 032701 000004 BIT #BIT2,R1 ;CHECK FOR TAPE STATUS ALERT

```

D10

CZTKGA TK-25 FRT END FUNC #3
TEST 1: SPACE RECORDS

MACRO M1200 20-APR-84 08:13 PAGE 86-3

SEQ 120

```

4199 024260 001014          BNE      120#          ;BR, IF TSA IS SET (SUSPECT IS EOT)
4200 024262 004737 020116  JSR      PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
4204                                     ;SOFT ERROR GENERATED BECAUSE THE
4205                                     ;WRITE COMMAND IS NOT BEING CHECKED
4206                                     ;HERE, IT WAS CHECKED IN LEAH2
4207 024266          ERRSOFT ERRNO,WRTErr,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      024266 104457          TRAP      C#ERSOFT
      024270 000152          .WORD    106
      024272 005011          .WORD    WRTErr
      024274 011710          .WORD    PKTSSR
4208 024276          75#:   CKLOOP          ;LOOP IF SELECTED
      024276 104406          TRAP      C#CLP1
4209 024300 005203          INC      R3          ;BUMP RECORD SIZE
4210 024302 022703 001000  CMP      #512.,R3    ;END OF RECORD YET
4211 024306 001340          BNE      65#          ;BR, IF MORE RECORDS TO WRITE
4212 024310 000415          BR       125#        ;ENOUGH RECORDS
4213 024312          120#:
4214          ;*****
4215          ;
4216          ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XST0)
4217          ;
4218          ;*****
4219
4220 024312 013701 030136  MOV      T258FR+6,R1 ;QUICK CHECK FOR EOT SET
4221 024316 010102          MOV      R1,R2          ;SET UP EXPECTED
4222 024320 052702 000001  BIS      #BIT0,R2    ;SET THE EOT BIT XST0
4223 024324 020102          CMP      R1,R2          ;IS THE EOT BIT SET IN XST0
4224 024326 001406          BEQ      125#        ;BR, IF SET (GOOD)
4225 024330 004737 020116  JSR      PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
4229 024334          ERRDF  ERRNO,T25NET,EXPREC ;DEVICE FATAL NOT EOT FOUND ETC.
      024334 104455          TRAP      C#ERDF
      024336 000153          .WORD    107
      024340 030613          .WORD    T25NET
      024342 016360          .WORD    EXPREC

```



```

4231 024344
4232
4233
4234
4235
4236
4237
4238 024344 004737 010444      JSR      PC,REWIND      ;CALL TAPE REWIND COMMAND
4239 024350 103407             BCS      130$          ;BR, IF NO PROBLEM
4240 024352 010001             MOV      R0,R1         ;SAVE TSSR
4241 024354 004737 020116     JSR      PC,FATCH*     ;INC AND CHECK FOR MORE THAN 25 ERRORS
4245 024360             ERRHRD  ERRNO,T25RWN,PKTSSR ;REWIND NOT ACCEPTED
                024360 104456             TRAP    C$ERHRD
                024362 000154             .WORD  108
                024364 031267             .WORD  T25RWN
                024366 011710             .WORD  PKTSSR
4246 024370             130$:  CKLOOP            ;LOOP IF SELECTED
                024370 104406             TRAP    C$CLP1
4247 024372             ENDSUB           ;>>>>>>>>> END SUBTEST >>>>>>>>>
                024372 104403             L10037:
4248 024374 023727 002170 000031  CMP      FATFLG,#25.   ;IS ERROR COUNT AT 25
4249 024402 002402             BLT      999$         ;BR, IF LESS THAN 25
4250 024404 004737 020170     JSR      PC,CKDROP    ;TRY TO DROP THE UNIT
4251 024410             999$:

```



```

4306
4307 024502 004737 010444      15$: JSR    PC,REWIND          ;CALL TAPE REWIND COMMAND
4308 024506 103407              BCS    30$                  ;BR, IF NO PROBLEM
4309 024510 010001              MOV    R0,R1                ;SAVE TSSR
4310 024512 004737 020116      JSR    PC,FATCHK           ;INC AND CHECK FOR MORE THAN 25 ERRORS
4314 024516              ERRHRD  ERRNO,T25RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP   C$ERHRD
                                .WORD  111
                                .WORD  T25RWN
                                .WORD  PKTSSR
                                TRAP   C$CLP1
4315 024526 104406              30$:  CKLOOP                ;LOOP IF SELECTED
                                TRAP   C$CLP1
4316
4317
4318
4319
4320
4321
4322
                                ;*****
                                ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
                                ;*****
4323 024530 013701 030136      MOV    T25BFR+6,R1         ;PICK UP XSTO
4324 024534 010102              MOV    R1,R2                ;SET UP EXPECTED
4325 024536 052702 000002      BIS    #BIT1,R2            ;SET BOT BIT IN EXPECTED
4326 024542 020102              CMP    R1,R2                ;DOES EXP = REC'D
4327 024544 001406              BEQ    40$                  ;BR, IF EQUAL (OK)
4328 024546 004737 020116      JSR    PC,FATCHK           ;INC AND CHECK FOR MORE THAN 25 ERRORS
4332 024552              ERRHRD  ERRNO,T25BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP   C$ERHRD
                                .WORD  112
                                .WORD  T25BOT
                                .WORD  EXPREC
4333 024562 104406              40$:  CKLOOP                ;LOOP IF SELECTED
                                TRAP   C$CLP1
4334 024564 012737 000001 030242  MOV    #000001,T25R8       ;NUMBER OF RECORDS TO SPACE OVER
4335
4336
4337
4338
4339
4340
4341
                                ;*****
                                ;SPACE FORWARD,ACK,CVC=1 COMMAND
                                ;*****
4342 024572 012737 140010 030240  MOV    #140010,T25PK3      ;SPACE FORWARD,ACK,CVC=1 COMMAND
4343 024600 012704 030240      MOV    #T25PK3,R4          ;SET UP R4 WITH PACKET ADDRESS
4344 024604
4345 024604 010465 177776      65$:  MOV    R4,T5DB(R5)      ;ISSUE COMMAND
4346 024610 004737 017134      JSR    PC,WAITF            ;WAIT FOR SSR TO SET
4347 024614 016501 000000      MOV    TSSR(R5),R1         ;GET TSSR CONTENTS
4348 024620 012702 000200      MOV    #SSR,R2             ;SET UP EXPECTED
4349 024624 020102              CMP    R1,R2                ;ARE THEY EQUAL
4350 024626 001411              BEQ    75$                  ;BR, IF OK
4351 024630 032701 000004      BIT    #BIT2,R1            ;CHECK FOR TAPE STATUS ALERT
4352 024634 001006              BNE    75$                  ;BR, IF TSA IS SET (SUSPECT IS EOT)
4353 024636 004737 020116      JSR    PC,FATCHK           ;INC AND CHECK FOR MORE THAN 25 ERRORS
4357 024642              ERRHRD  ERRNO,T25WDE,EXPREC ;TSSR INCORRECT AFTER READ DATA
                                TRAP   C$ERHRD
                                .WORD  113
                                .WORD  T25WDE
                                .WORD  EXPREC
024642 104456
024644 000161
024646 030377
024650 016360

```

```

4358 024652 75$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
      024652 104406
4359 024654 120$:
4360
4361 ;*****
4362 ;
4363 ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
4364 ;
4365 ;*****
4366
4367 024654 013701 030136 MOV T25BFR+6,R1 ;QUICK CHECK FOR BOT SET
4368 024660 010102 MOV R1,R2 ;SET UP EXPECTED
4369 024662 042702 000002 BIC #BIT1,R2 ;CLEAR THE BOT BIT (XSTO)
4370 024666 020102 CMP R1,R2 ;IS THE EOT BIT SET IN XSTO
4371 024670 001406 BEQ 125$ ;BR, IF SET (GOOD)
4372 024672 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4376 024676 ERRHRD ERRNO,T25BNC,EXPREC ;BOT NOT CLEARED AFTER SPACE FROM BOT
      024676 104456 TRAP C$ERRHRD
      024700 000162 .WORD 114
      024702 030752 .WORD T25BNC
      024704 016360 .WORD EXPREC
4377 024706 004737 031634 125$: JSR PC,T25RT3 ;CLEAN UP PACKET
4378 024712 012737 000401 030246 MOV #257.,T25SZ ;SET THE CORRECT SIZE UP
4379
4380 ;*****
4381 ;
4382 ;READ DATA COMMAND IN PLACE
4383 ;
4384 ;*****
4385
4386 024720 012737 140001 030240 MOV #140001,T25PK3 ;READ DATA COMMAND IN PLACE
4387 024726 013737 003072 030242 MOV FREE,T25R8 ;READ BUFFER ADDRESS TO PACKET
4388 024734 012704 030240 MOV #T25PK3,R4 ;R4 - POINTER TO PACKET
4389 024740 010465 177776 MOV R4,TSD8(R5) ;ISSUE COMMAND
4390 024744 004737 017134 JSR PC,WAITF ;WAIT FOR SSR TO SET
4391 024750 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
4392 024754 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
4393 024760 020102 CMP R1,R2 ;ARE THEY EQUAL
4394 024762 001406 BEQ 190$ ;BR, IF OK ESP. FUNCTION REJECT
4395 024764 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4399 024770 ERRHRD ERRNO,RDERR,PKTSSR ;TSSR INCORRECT AFTER READ DATA CMD
      024770 104456 TRAP C$ERRHRD
      024772 000163 .WORD 115
      024774 005104 .WORD RDERR
      024776 011710 .WORD PKTSSR
4400 025000 190$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
      025000 104406
4401 025002 017701 156064 MOV #FREE,R1 ;GET FIRST WORD FROM BUFFER
4402 025006 012702 000001 MOV #1,R2 ;SET UP EXPECTED
4403 025012 020102 CMP R1,R2 ;WAS RECORD NUMBERED 1
4404 025014 001406 BEQ 200$ ;BR, IF CORRECT RECORD
4405 025016 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4409 025022 ERRHRD ERRNO,T25WNG,EXPREC ;SHOULD HAVE BEEN RECORD NUMBER 1
      025022 104456 TRAP C$ERRHRD
      025024 000164 .WORD 116
      025026 030667 .WORD T25WNG
      025030 016360 .WORD EXPREC

```

4410 025032
4411 025032
 025032
 025032
4412 025034
4413 025042
4414 025044
4415 025050

104403
023727 002170 000031
002402
004737 020170

200\$:
ENDSUB
999\$:

 CMP FATFLG.#25.
 BLT 999\$
 JSR PC,CKDROP

```
>>>>>>>>>>> END SUBTEST >>>>>>>>>>>>>>>>
L10040:
                  TRAP      C$ESUB
;IS ERROR COUNT AT 25
;BR, IF LESS THAN 25
;TRY TO DROP THE UNIT
```



```

4469
4470
4471
4472 025144 004737 010444      JSR      PC,REWIND      ;CALL TAPE REWIND COMMAND
4473 025150 103407              BCS      30$            ;BR, IF NO PROBLEM
4474 025152 010001              MOV      R0,F1          ;SAVE TSSR
4475 025154 004737 020116      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
4479 025160              ERRHRD   ERRNO,T2SRWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP      C$ERHRD
                                .WORD     119
                                .WORD     T2SRWN
                                .WORD     PKTSSR
4480 025170 30$: CKLOOP              ;LOOP IF SELECTED
                                TRAP      C$CLP1
4481
4482
4483
4484
4485
4486
4487
4488 025172 013701 030136      MOV      T258FR+6,R1    ;PICK UP XSTO
4489 025176 010102              MOV      R1,R2          ;SET UP EXPECTED
4490 025200 052702 000002      BIS      #BIT1,R2       ;SET BOT BIT IN EXPECTED
4491 025204 020102              CMP      R1,R2          ;DOES EXP = REC'D
4492 025206 001406              BEQ      40$            ;BR, IF EQUAL (OK)
4493 025210 004737 020116      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
4497 025214              ERRHRD   ERRNO,T25BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C$ERHRD
                                .WORD     120
                                .WORD     T25BOT
                                .WORD     EXPREC
4498 025224 40$: CKLOOP              ;LOOP IF SELECTED
                                TRAP      C$CLP1
4499
4500
4501
4502
4503
4504
4505
4506
4507 025226 012703 000001      MOV      #000001,R3     ;NUMBER OF RECORDS TO SPACE FORWARD
4508 025232 004737 010144      JSR      PC,SPACE       ;CALL SPACE COMMAND
4509 025236 103410              BCS      50$            ;CHECK FOR ERROR
4510 025240 016501 000000      MOV      TSSR(R5),R1    ;GET TSSR CONTENTS
4511 025244 004737 020116      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
4515 025250              ERRHRD   ERRNO,T25WDE,SFFMSG ;SPACE FORWARD FAILED
                                TRAP      C$ERHRD
                                .WORD     121
                                .WORD     T25WDE
                                .WORD     SFFMSG
4516 025260 50$: CKLOOP              ;LOOP IF SELECTED
                                TRAP      C$CLP1
4517 025262 012737 000001 030242  MOV      #1,T25RB       ;NUMBER OF RECORDS TO SPACE OVER
4518
4519

```

```

4520
4521 ;SPACE REVERSE,ACK,CVC=1 COMMAND
4522 ;
4523 ;*****
4524
4525 025270 012737 140410 030240      MOV      #140410,T25PK3      ;SPACE REVERSE,ACK,CVC=1 COMMAND
4526 025276 012704 030240      MOV      #T25PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
4527 025302
4528 025302 010465 177776      65$:    MOV      R4,TSDB(R5)        ;ISSUE COMMAND
4529 025306 004737 017134      JSR      PC,WAITF          ;WAIT FOR SSR TO SET
4530 025312 016501 000000      MOV      TSSR(R5),R1       ;GET TSSR CONTENTS
4531 025316 012702 000200      MOV      #SSR,R2          ;SET UP EXPECTED
4532 025322 020102      CMP      R1,R2            ;ARE THEY EQUAL
4533 025324 001406      BEQ      75$              ;BR, IF OK
4534 025326 004737 020116      JSR      PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
4538 025332      ERRHRD  ERRNO,T25WDE,PKTSSR ;TSSR INCORRECT AFTER READ DATA
                                TRAP      C$ERHRD
                                .WORD    122
                                .WORD    T25WDE
                                .WORD    PKTSSR
                                TRAP      C$CLP1
4539 025342      75$:    CKLOOP                ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD    104406
4540 025344      120$:
4541 025344 012703 000400      MOV      #256.,R3         ;RECORD SIZE
4542 025350 013737 003072 030242      MOV      FREE,T25RB       ;STARTING READ BUFFER ADDRESS
4543
4544 ;*****
4545 ;
4546 ;READ DATA,ACK,CVC=1 COMMAND
4547 ;
4548 ;*****
4549
4550 025356 012737 140001 030240      165$:  MOV      #140001,T25PK3    ;READ DATA,ACK,CVC=1 COMMAND
4551 025364 012704 030240      MOV      #T25PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
4552 025370 010337 030246      MOV      R3,T25SZ         ;SET UP RECORD SIZE IN PACKET
4553 025374 010465 177776      MOV      R4,TSDB(R5)      ;ISSUE COMMAND
4554 025400 004737 017134      JSR      PC,WAITF          ;WAIT FOR SSR TO SET
4555 025404 016501 000000      MOV      TSSR(R5),R1       ;GET TSSR CONTENTS
4556 025410 012702 000200      MOV      #SSR,R2          ;SET UP EXPECTED
4557 025414 020102      CMP      R1,R2            ;ARE THEY EQUAL
4558 025416 001406      BEQ      170$             ;BR, IF OK
4559 025420 004737 020116      JSR      PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
4563 025424      ERRHRD  ERRNO,RDERR,PKTSSR ;TSSR INCORRECT AFTER READ DATA
                                TRAP      C$ERHRD
                                .WORD    123
                                .WORD    RDERR
                                .WORD    PKTSSR
                                TRAP      C$CLP1
4564 025434      170$:  CKLOOP                ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD    104406
4565 025436 017701 155430      MOV      #FREE,R1         ;GET FIRST WORD FROM BUFFER
4566 025442 012702 000000      MOV      #0,R2            ;SET UP EXPECTED
4567 025446 020102      CMP      R1,R2            ;WAS RECORD NUMBERED 1
4568 025450 001406      BEQ      200$             ;BR, IF CORRECT RECORD
4569 025452 004737 020116      JSR      PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
4573 025456      ERRHRD  ERRNO,T25WNG,EXPREC ;SHOULD HAVE BEEN RECORD NUMBER 1
                                TRAP      C$ERHRD
                                .WORD    124
                                .WORD    104456
                                .WORD    000174

```


	025462	030667						
	025464	016360						
4574	025466			200\$:				
4575	025466				ENDSUB			
	025466							
	025466	104403						
4576	025470	023727	002170	000031	CMP	FATFLG,#25.		
4577	025476	002402			BLT	999\$		
4578	025500	004737	020170		JSR	PC,CKDROP		
4579	025504			999\$:				

	.WORD	T25WNG
	.WORD	EXPREC
;>>>>>>>>>> END SUBTEST >>>>>>>>>>		
	L10041:	
		TRAP
		C#ESUB
		;IS ERROR COUNT AT 25
		;BR. IF LESS THAN 25
		;TRY TO DROP THE UNIT

```

4581
4582
4583
4584
4585
4586
4587
4588
4589
4590
4591
4592
4593
4594 025504             BGNSUB                ;>>>>>>>>>>>> BEGIN SUBTEST >>>>>>>>>>>>
      025504             T1.4:
      025504 104402          TRAP      C$BSUB
4595 025506 004737 031500   JSR      PC,T25REST      ;SET COMMAND PACKET
4596 025512 004737 031572   JSR      PC,T25RT2      ;SET UP OTHER COMMAND PACKET
4597 025516 004737 031634   JSR      PC,T25RT3      ;SET UP OTHER COMMAND PACKET
4598 025522 013737 030270 030266  MOV      T25CNT,T25CN2   ;HOLD NUMBER OF RECORDS
4599 025530 162737 000002 030266  SUB      #2,T25CN2      ;ACTUAL NUMBER OF RECORDS ON TAPE
4600 025536 013737 030270 030272  MOV      T25CNT,T25DLY  ;SET UP REWIND DELAY COUNTER
4601
4602
4603
4604
4605
4606
4607
      ;*****
      ;
      ;ISSUE CONTROLLER "SOFT" INITIALIZE - CARRY BIT CLEAR IF ERROR
      ;
      ;*****
4608 025544 004737 016660 10$:   JSR      PC,SOFINIT      ;DO INITIALIZE ON CONTROLLER
4609 025550 103427          BCS      20$             ;BR IF INIT WAS OK
4610 025552          DELAY    250           ;WAIT ABOUT .25 SECONDS
      MOV      #250,(PC)+
      .WORD    0
      MOV      L$DLY,(PC)+
      .WORD    0
      DEC      -6(PC)
      BNE     .-4
      DEC      -22(PC)
      BNE     .-20
4611 025602 005337 030272   DEC      T25DLY          ;DEC COUNTER
4612 025606 001356          BNE     10$             ;BR. IF MORE LOOPS REQUIRED
4613 025610 016501 000000   MOV      TSSR(R5),R1     ;CONTENTS OF TSSR REGISTER
4614 025614 004737 020116   JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
4618 025620          ERRDF   ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
      TRAP    C$ERDF
      .WORD   125
      .WORD   SFIERR
      .WORD   SFIMSG
4619 025630 20$:
4620
4621 025630 012704 030110          MOV      #T25PACKET,R4   ;SUBROUTINE NEEDS PACKET ADDRESS
4622
4623
4624
4625
4626
      ;*****
      ;
      ;WRITE CHARACTERISTICS COMMAND (CALL TO WRCHR)
      ;
  
```

```

4627
4628
4629 025634 004737 010342
4630 025640 103407
4631 025642 004737 020116
4635 025646 010001
4636 025650
      025650 104456
      025652 000176
      025654 004754
      025656 011676
4637 025660
      025660 104406
4638
4639
4640
4641
4642
4643
4644
4645 025662 004737 010444
4646 025666 103407
4647 025670 010001
4648 025672 004737 020116
4652 025676
      025676 104456
      025700 000177
      025702 031267
      025704 011710
4653 025706
      025706 104406
4654 025710 013701 030266
4655 025714 012702 177776
4656 025720 020201
4657 025722 003002
4658 025724 010103
4659 025726 000401
4660 025730 010203
4661 025732 162703 000001
4662 025736 010337 030242
4663
4664
4665
4666
4667
4668
4669
4670 025742 012737 140010 030240
4671 025750 012704 030240
4672 025754
4673 025754 013737 030266 030272
4674 025762 010465 177776
4675 025766 004737 017134
4676 025772 016501 000000
4677 025776 012702 000200
4678 026002 020102
4679 026004 001425

;*****
;
;      JSR      PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
;      BCS      25#           ;BR, IF COMMAND ISSUED OK
;      JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
;      MOV      R0,R1         ;SAVE CONTENTS OF TSSR
;      ERRHRD   ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
;
;      TRAP     CIERHRD
;      .WORD    126
;      .WORD    WRTMSG
;      .WORD    SFIMSG
25# :   CKLOOP                ;LOOP IF SELECTED
;
;      TRAP     C:CLP1
;*****
;
;      ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
;
;*****
;
;      JSR      PC,REWIND     ;CALL TAPE REWIND COMMAND
;      BCS      30#           ;BR, IF NO PROBLEM
;      MOV      R0,R1         ;SAVE TSSR
;      JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
;      ERRHRD   ERRNO,T25RWN,PKTSSR ;REWIND NOT ACCEPTED
;
;      TRAP     CIERHRD
;      .WORD    127
;      .WORD    T25RWN
;      .WORD    PKTSSR
30# :   CKLOOP                ;LOOP IF SELECTED
;
;      TRAP     C:CLP1
;
;      MOV      T25CN2,R1     ;NUMBER OF RECORDS ON TAPE
;      MOV      #65534.,R2    ;MAX IT CAN SPACE OVER
;      CMP      R2,R1         ;WHICH VALUE CAN WE USE
;      BGT      46#           ;BR, IF # WRITTEN > 64K
;      MOV      R1,R3         ;# WRITTEN CAN BE USED
;      BR       47#           ;MOVE ON
;      MOV      R2,R3         ;USE MAX NUMBER
;      SUB      #1,R3         ;DON'T GO ALL THE WAY YET
;      MOV      R3,T25RB      ;NUMBER OF RECORDS TO SPACE OVER
;*****
;
;      ;SPACE FORWARD,ACK,CVC=1 COMMAND
;
;*****
;
;      MOV      #140010,T25PK3 ;SPACE FORWARD,ACK,CVC=1 COMMAND
;      MOV      #T25PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
65# :
;
;      MOV      T25CN2,T25DLY ;NUMBER OF RECORDS USED AS DELAY COUNTER
;      MOV      R4,T25D(R5)   ;ISSUE COMMAND
67# :   JSR      PC,WAITF     ;WAIT FOR SSR TO SET
;      MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
;      MOV      #SSR,R2       ;SET UP EXPECTED
;      CMP      R1,R2         ;ARE THEY EQUAL
;      BEQ     75#           ;BR, IF OK

```

```

4680 026006          DELAY 250          ;DELAY .25 SECONDS          MOV    #250,(PC),
      026006 012727 000250          .WORD 0
      026012 000000          MOV    L#DLY,(PC),
      026014 013727 002116          .WORD 0
      026020 000000          DEC    -6(PC)
      025022 005367 177772          BNE   -4
      026026 001375          DEC    -22(PC)
      026030 005367 177756          BNE   -20
      026034 001367
4681 026036 005337 030272          DEC    T25DLY          ;BUMP DOWN COUNTER
4682 026042 001351          BNE   67#          ;BR, IF NOT AT END OF DELAY
4683 026044 004737 020116          JSR   PC,FATCHK          ;INC AND CHECK FOR MORE THAN 25 ERRORS
4687 026050          ERRHRD ERRNO,T25WDE,PKTSSR          ;TSSR INCORRECT AFTER READ DATA
      026050 104456          TRAP  C#ERRRD
      026052 000200          .WORD 128
      026054 030377          .WORD T25WDE
      026056 011710          .WORD PKTSSR
4688 026060          75#; CKLOOP          ;LOOP IF SELECTED          TRAP  C#CLP1
      026060 104406
4689 026062 012703 010000          MOV    #4096,R3          ;RECORD SIZE
4690 026066 013737 003072 030242          MOV    FREE,T25RB          ;STARTING READ BUFFER ADDRESS
4691
4692          ;*****
4693          ;READ DATA,ACK COMMAND
4694          ;
4695          ;*****
4696
4697
4698 026074 012737 100001 030240          165#; MOV    #100001,T25PK3          ;READ DATA,ACK COMMAND
4699 026102 012704 030240          MOV    #T25PK3,R4          ;SET UP R4 WITH PACKET ADDRESS
4700 026106 010337 030246          MOV    R3,T25SZ          ;SET UP RECORD SIZE IN PACKET
4701 026112 010465 177776          MOV    R4,T25DB(R5)          ;ISSUE COMMAND
4702 026116 004737 017134          JSR   PC,WAITF          ;WAIT FOR SSR TO SET
4703 026122 016501 000000          MOV    TSSR(R5),R1          ;GET TSSR CONTENTS
4704 026126 012702 000200          MOV    #SSR,R2          ;SET UP EXPECTED
4705 026132 020102          CMP    R1,R2          ;ARE THEY EQUAL
4706 026134 001411          BEQ   170#          ;BR, IF OK
4707 026136 032701 000004          BIT    #BIT2,R1          ;CHECK FOR TAPE STATUS ALERT
4708 026142 001006          BNE   170#          ;IF SET ALL IS WELL
4709 026144 004737 020116          JSR   PC,FATCHK          ;INC AND CHECK FOR MORE THAN 25 ERRORS
4713 026150          ERRHRD ERRNO,RDERR,PKTSSR          ;TSSR INCORRECT AFTER READ DATA
      026150 104456          TRAP  C#ERRRD
      026152 000201          .WORD 129
      026154 005104          .WORD RDERR
      026156 011710          .WORD PKTSSR
4714 026160          170#; CKLOOP          ;LOOP IF SELECTED          TRAP  C#CLP1
      026160 104406          ;GET FIRST WORD FROM BUFFER
4715 026162 017701 154704          MOV    #FREE,R1          ;SET UP EXPECTED
4716 026166 013702 030266          MOV    T25CN2,R2          ;SHOULD BE LAST RECORD
4717 026172 162702 000001          SUB    #1,R2          ;WAS RECORD NUMBERED R3
4718 026176 020102          CMP    R1,R2          ;BR, IF CORRECT RECORD
4719 026200 001406          BEQ   200#          ;INC AND CHECK FOR MORE THAN 25 ERRORS
4720 026202 004737 020116          JSR   PC,FATCHK          ;SHOULD HAVE BEEN RECORD NUMBER 1
4724 026206          ERRHRD ERRNO,T25WNG,EXPREC          TRAP  C#ERRRD
      025206 104456          .WORD 130
      026210 000202          .WORD T25WNG
      026212 030667

```

D11

CZIKGA TK-25 ERT END FUNC #3
TEST 1: SPACE RECORDS

MACRO M1200 20-APR-84 08:13 PAGE 90-3

SEQ 133

4725 026214 016360
4726 026216
026216
4727 026220 104403
4728 026226 023727 002170 000031
4729 026230 004737 020170
4730 026234

2001:

ENDSUB

CMP FATFLG, #25.
BLT 999#
JSR PC, CKDROP

999#:

.WORD EXPREC

; >>>>>>>>>> END SUBTEST >>>>>>>>>>

L10042:

TRAP C#ESUB
; IS ERROR COUNT AT 25
; BR, IF LESS THAN 25
; TRY TO DROP THE UNIT

E11

```

4733
4734
4735
4736
4737
4738
4739
4740
4741
4742
4743
4744
4745 026234          ;
         026234          ;
         026234      104402          ;
4746 026236      004737      031500          JSR      PC,T25REST          ;SET COMMAND PACKET
4747 026242      013737      030270      030266      MOV      T25CNT,T25CN2          ;SET UP RECORD COUNTER
4748 026250      004737      031572          JSR      PC,T25RT2          ;SET UP OTHER COMMAND PACKET
4749 026254      004737      031634          JSR      PC,T25RT3          ;SET UP OTHER COMMAND PACKET
4750 026260      013737      030270      030272      MOV      T25CNT,T25DLY          ;SET UP REWIND DELAY COUNTER
4751
4752
4753
4754
4755
4756
4757
4758 026266      004737      016660          10$:   JSR      PC,SOFINIT          ;DO INITIALIZE ON CONTROLLER
4759 026272      103427          BCS     20$          ;BR IF INIT WAS OK
4760 026274          012727      000250          DELAY   250          ;WAIT ABOUT .25 SECONDS
         026300      000000          MOV     #250,(PC)+
         026302      013727      002116          MOV     L#DLY,(PC)+
         026306      000000          .WORD  0
         026310      005367      177772          DEC     -6(PC)
         026314      001375          BNE     -4
         026316      005367      177756          DEC     -22(PC)
         026322      001367          BNE     -20
4761 026324      005337      030272          DEC     T25DLY          ;DEC COUNTER
4762 026330      001356          BNE     10$          ;BR, IF MORE LOOPS REQUIRED
4763 026332      016501      000000          MOV     TSSR(R5),R1          ;CONTENTS OF TSSR REGISTER
         64 026336      004737      020116          JSR     PC,FATCHK          ;INC AND CHECK FOR MORE THAN 25 ERRORS
4768 026342          026342      104455          ERROF  ERRNO,SFIERR,SFIMSG          ;FATAL ERROR TSSR WAS NOT OK
         026344      000203          TRAP   C#ERDF
         026346      003550          .WORD 131
         026350      011676          .WORD SFIERR
4769 026352          20$:
4770
4771 026352      012704      030110          MOV     #T25PACKET,R4          ;SUBROUTINE NEEDS PACKET ADDRESS
4772
4773
4774
4775
4776
4777
4778

```

```

4779 026356 004737 010342      JSR    PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
4780 026362 103407              BCS    25$           ;BR, IF COMMAND ISSUED OK
4781 026364 004737 020116      JSR    PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
4785 026370 010001              MOV    R0,R1         ;SAVE CONTENTS OF TSSR
4786 026372              ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP    C$ERHRD
                                .WORD   132
                                .WORD   WRTMSG
                                .WORD   SFIMSG
4787 026402 104406      25$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP    C$CLP1
4788
4789
4790
4791
4792
4793
4794
                                ;*****
                                ;
                                ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
                                ;
                                ;*****
4795 026404 004737 010444      JSR    PC,REWIND     ;CALL TAPE REWIND COMMAND
4796 026410 103407              BCS    30$           ;BR, IF NO PROBLEM
4797 026412 010001              MOV    R0,R1         ;SAVE TSSR
4798 026414 004737 020116      JSR    PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
4802 026420              ERRHRD  ERRNO,T25RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP    C$ERHRD
                                .WORD   133
                                .WORD   T25RWN
                                .WORD   PKTSSR
4803 026430 104406      30$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP    C$CLP1
4804
4805
4806
4807
4808
4809
4810
                                ;*****
                                ;
                                ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
                                ;
                                ;*****
4811 026432 013701 030136      MOV    T25BFR+6,R1   ;PICK UP XSTO
4812 026436 010102              MOV    R1,R2         ;SET UP EXPECTED
4813 026440 052702 000002      BIS    #BIT1,R2      ;SET BOT BIT IN EXPECTED
4814 026444 020102              CMP    R1,R2         ;DOES EXP = REC'D
4815 026446 001406              BEQ    40$           ;BR, IF EQUAL (OK)
4816 026450 004737 020116      JSR    PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
4820 026454              ERRHRD  ERRNO,T25BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP    C$ERHRD
                                .WORD   134
                                .WORD   T25BOT
                                .WORD   EXPREC
4821 026464 104406      40$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP    C$CLP1
4822 026466 013701 030266      MOV    T25CN2,R1     ;NUMBER OF RECORDS ON TAPE
4823 026472 012702 177776      MOV    #65534.,R2    ;MAX IT CAN SPACE OVER
4824 026476 020201              CMP    R2,R1         ;WHICH VALUE CAN WE USE
4825 026500 003002              BGT    46$           ;BR, IF # WRITTEN > 64K
4826 026502 010103              MOV    R1,R3         ;# WRITTEN CAN BE USED
4827 026504 000401              BR     47$           ;MOVE ON
4828 026506 010203      46$:  MOV    R2,R3     ;USE MAX NUMBER
4829 026510      47$:

```

```

4830 026510 010337 030242          MOV      R3,T25RB          ;NUMBER OF RECORDS TO SPACE OVER
4831
4832          ;*****
4833          ;
4834          ;SPACE FORWARD,ACK,CVC=1 COMMAND
4835          ;
4836          ;*****
4837
4838 026514 012737 140010 030240    MOV      #140010,T25PK3    ;SPACE FORWARD,ACK,CVC=1 COMMAND
4839 026522 012704 030240          MOV      #T25PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
4840 026526 010465 177776          MOV      R4,TSDB(R5)     ;ISSUE COMMAND
4841 026532 013737 030266 030272    MOV      T25CN2,T25DLY   ;SET UP DELAY COUNTER
4842 026540 004737 017134 48$:    JSR      PC,WAITF        ;WAIT FOR SSR TO SET
4843 026544 016501 000000          MOV      TSSR(R5),R1     ;GET TSSR CONTENTS
4844 026550 012702 000200          MOV      #SSR,R2        ;SET UP EXPECTED
4845 026554 020102          CMP      R1,R2          ;ARE THEY EQUAL
4846 026556 001425          BEQ      50$            ;BR, IF OK
4847 026560          DELAY    250           ;WAIT .25 SECONDS
          MOV      #250,(PC)+
          .WORD    0
          MOV      L$DLY,(PC)+
          .WORD    0
          DEC      -6(PC)
          BNE      -4
          DEC      -22(PC)
          BNE      -20
4848 026610 005337 030272          DEC      T25DLY         ;DEC THE DELAY COUNTER
4849 026614 001351          BNE      48$           ;BR, IF COUNTER HASN'T EXPIRED
4850 026616 004737 020116          JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
4854 026622          ERRHRD  ERRNO,T25WDE,EXPREC ;TSSR INCORRECT AFTER READ DATA
          TRAP    C$ERHRD
          .WORD    135
          .WORD    T25WDE
          .WORD    EXPREC
4855 026632 013701 030266 50$:  MOV      T25CN2,R1      ;NUMBER OF RECORDS ON TAPE
4856 026636 012702 177776          MOV      #65534.,R2     ;MAX IT CAN SPACE OVER
4857 026642 020201          CMP      R2,R1          ;WHICH VALUE CAN WE USE
4858 026644 003002          BGT      55$            ;BR, IF # WRITTEN > 64K
4859 026646 010103          MOV      R1,R3          ;# WRITTEN CAN BE USED
4860 026650 000401          BR       60$            ;MOVE ON
4861 026652 010203 55$:  MOV      R2,R3          ;USE MAX NUMBER
4862 026654 162703 000001 60$:  SUB      #1,R3          ;DON'T GO ALL THE WAY YET
4863 026660 010337 030242          MOV      R3,T25RB      ;NUMBER OF RECORDS TO SPACE OVER
4864
4865          ;*****
4866          ;
4867          ;SPACE REVERSE,ACK,CVC=1 COMMAND
4868          ;
4869          ;*****
4870
4871 026664 012737 140410 030240    MOV      #140410,T25PK3  ;SPACE REVERSE,ACK,CVC=1 COMMAND
4872 026672 012704 030240          MOV      #T25PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
4873 026676 010465 177776          MOV      R4,TSDB(R5)   ;ISSUE COMMAND
4874 026702 013737 030266 030272    MOV      T25CN2,T25DLY  ;SET UP COUNTER
4875 026710 004737 017134 70$:  JSR      PC,WAITF        ;WAIT FOR SSR TO SET
4876 026714 016501 000000          MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
4877 026720 012702 000200          MOV      #SSR,R2        ;SET UP EXPECTED

```



```

4878 026724 020102          CMP      R1,R2          ;ARE THEY EQUAL
4879 026726 001425          BEQ      75$           ;BR, IF OK
4880 026730          DELAY    250           ;WAIT ABOUT .25 SECONDS
      026730 012727 000250          MOV      #250,(PC)+
      026734 000000          .WORD   0
      026736 013727 002116          MOV      L$DLY,(PC)+
      026742 000000          .WORD   0
      026744 005367 177772          DEC      -6(PC)
      026750 001375          BNE     .-4
      026752 005367 177756          DEC      -22(PC)
      026756 001367          BNE     .-20
4881 026760 005337 030272          DEC      T25DLY        ;BUMP COUNTER DOWN
4882 026764 001351          BNE     70$           ;BR, IF COUNTER HASN'T EXPIRED
4883 026766 004737 020116          JSR     PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
4887 026772          ERRHRD  ERRNO,T25WDE,EXPREC ;TSSR INCORRECT AFTER READ DATA
      026772 104456          TRAP   C$ERHRD
      026774 000210          .WORD  136
      026776 030377          .WORD  T25WDE
      027000 016360          .WORD  EXPREC
4888 027002          75$:   CKLOOP          ;LOOP IF SELECTED
      027002 104406          TRAP   C$CLP1
4889 027004 012703 010000          MOV     #4096.,R3     ;RECORD SIZE
4890 027010 013737 003072 030242          MOV     FREE,T25RB    ;STARTING READ BUFFER ADDRESS
4891
4892          ;*****
4893          ;
4894          ;READ DATA,ACK COMMAND
4895          ;
4896          ;*****
4897
4898 027016 012737 100001 030240          MOV     #100001,T25PK3 ;READ DATA,ACK COMMAND
4899 027024 012704 030240          165$:  MOV     #T25PK3,R4   ;SET UP R4 WITH PACKET ADDRESS
4900 027030 012700 177777          MOV     #177777,R0    ;SET ALL ONES INTO CORRECT REGISTER
4901 027034 004737 020410          JSR     PC,FILLMEM    ;FILL MEMORY WITH RECORD SIZE
4902 027040 010337 030246          MOV     R3,T25SZ     ;SET UP RECORD SIZE IN PACKET
4903 027044 010465 177776          MOV     R4,T5DB(R5)  ;ISSUE COMMAND
4904 027050 004737 017134          JSR     PC,WAITF      ;WAIT FOR SSR TO SET
4905 027054 016501 000000          MOV     T5SR(R5),R1  ;GET T5SR CONTENTS
4906 027060 012702 000200          MOV     #5SR,R2     ;SET UP EXPECTED
4907 027064 020102          CMP     R1,R2        ;ARE THEY EQUAL
4908 027066 001411          BEQ     170$         ;BR, IF OK
4909 027070 032701 000004          BIT     #BIT2,R1     ;CHECK FOR TAPE STATUS ALERT
4910 027074 001006          BNE     170$         ;BR, IF BIT SET
4911 027076 004737 020116          JSR     PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
4915 027102          ERRHRD  ERRNO,RDERR,EXPREC ;TSSR INCORRECT AFTER READ DATA
      027102 104456          TRAP   C$ERHRD
      027104 000211          .WORD  137
      027106 005104          .WORD  RDERR
      027110 016360          .WORD  EXPREC
4916 027112          170$:  CKLOOP          ;LOOP IF SELECTED
      027112 104406          TRAP   C$CLP1
4917 027114 017701 153752          MOV     #FREE,R1     ;GET FIRST WORD FROM BUFFER
4918 027120 012702 000001          MOV     #1,R2        ;SET UP EXPECTED
4919 027124 020102          CMP     R1,R2        ;WAS RECORD NUMBERED R3
4920 027126 001406          BEQ     200$         ;BR, IF CORRECT RECORD
4921 027130 004737 020116          JSR     PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
4925 027134          ERRHRD  ERRNO,T25WNH,EXPREC ;SHOULD HAVE BEEN RECORD NUMBER 1

```

027134 104456
027136 000212
027140 031042
027142 016360
4926 027144 200\$:
4927 027144
027144
027144 104403
4928 027146 023727 002170 000031
4929 027154 002402
4930 027156 004737 020170
4931 027162 999\$:

ENDSUB

CMP FATFLG,#25.
BLT 999\$
JSR PC,CKDROP

TRAP C\$ERHRD
.WORD 138
.WORD T25WNH
.WORD EXPREC

; >>>>>>>>>> END SUBTEST >>>>>>>>>>
L10043:

TRAP C\$ESUB
; IS ERROR COUNT AT 25
; BR, IF LESS THAN 25
; TRY TO DROP THE UNIT


```

4985 ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
4986 ;
4987 ;*****
4988
4989 027256 004737 010444 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
4990 027262 103407 BCS 30$ ;BR, IF NO PROBLEM
4991 027264 010001 MOV R0,R1 ;SAVE TSSR
4992 027266 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
4996 027272 ERRHRD ERRNO,T25RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP C$ERHRD
                                .WORD 141
                                .WORD T25RWN
                                .WORD PKTSSR
                                TRAP C$CLP1
4997 027302 30$: CKLOOP ;LOOP IF SELECTED
                                TRAP C$CLP1
                                .WORD 104406
4998 ;*****
4999 ;
5000 ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
5001 ;
5002 ;*****
5003
5004
5005 027304 013701 030136 MOV T25BFR+6,R1 ;PICK UP XSTO
5006 027310 010102 MOV R1,R2 ;SET UP EXPECTED
5007 027312 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
5008 027316 020102 CMP R1,R2 ;DOES EXP = REC'D
5009 027320 001406 BEQ 40$ ;BR, IF EQUAL (OK)
5010 027322 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5014 027326 ERRHRD ERRNO,T25BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP C$ERHRD
                                .WORD 142
                                .WORD T25BOT
                                .WORD EXPREC
5015 027336 40$: CKLOOP ;LOOP IF SELECTED
                                TRAP C$CLP1
                                .WORD 104406
5016 027340 012737 000001 030242 MOV #1,T25RB ;NUMBER OF RECORDS TO SPACE OVER
5017 ;*****
5018 ;
5019 ;SPACE REVERSE,ACK COMMAND
5020 ;
5021 ;*****
5022
5023
5024 027346 012737 100410 030240 MOV #100410,T25PK3 ;SPACE REVERSE,ACK COMMAND
5025 027354 012704 030240 MOV #T25PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
5026 027360
5027 027360 010465 177776 65$: MOV R4,T5DB(R5) ;ISSUE COMMAND
5028 027364 004737 017134 JSR PC,WAITF ;WAIT FOR SSR TO SET
5029 027370 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
5030 027374 012702 100206 MOV #SSR!SC!BIT1!BIT2,R2 ;SET UP EXPECTED
5031 027400 020102 CMP R1,R2 ;ARE THEY EQUAL
5032 027402 001406 BEQ 75$ ;BR, IF OK
5033 027404 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5037 027410 ERRHRD ERRNO,T25WDE,PKTSSR ;TSSR INCORRECT AFTER READ DATA
                                TRAP C$ERHRD
                                .WORD 143
                                .WORD T25WDE
                                TRAP C$CLP1
                                .WORD 104456
                                .WORD 000217
                                .WORD 030377

```

```

5038 027416 011710
      027420
      027420 104406
5039
5040
5041
5042
5043
5044
5045
5046 027422 013701 030136
5047 027426 010102
5048 027430 052702 002000
5049 027434 020102
5050 027436 001406
5051 027440 004737 020116
5055 027444
      027444 104456
      027446 000220
      027450 031125
      027452 016360
5056 027454
5057 027454
      027454
      027454 104403
5058 027456 023727 002170 000031
5059 027464 002402
5060 027466 004737 020170
5061 027472

75$:  CKLOOP .
      ;LOOP IF SELECTED
      .WORD  PKTSSR
      TRAP   C#CLP1

;*****
;
;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
;
;*****

MOV    T25BFR+6,R1    ;GET XSTO STATUS WORD
MOV    R1,R2          ;SET UP EXPECTED
BIS    #BIT10,R2      ;SET THE NEF BIT
CMP    R1,R2          ;ARE THEY EQUAL
BEQ    170$           ;BR, IF EQUAL (GOOD)
JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
ERRHRD ERRNO,T25NEF,EXPREC ;NEF SHOULD BE SET
      TRAP   C#ERHRD
      .WORD  144
      .WORD  T25NEF
      .WORD  EXPREC

170$:  ENDSUB
      L10044:
      TRAP   C#ESUB

CMP    FATFLG,#25.    ;IS ERROR COUNT AT 25
BLT    999$           ;BR, IF LESS THAN 25
JSR    PC,CKDROP      ;TRY TO DROP THE UNIT

999$:

```



```

5115 ;*****
5116 ;
5117 ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
5118 ;
5119 ;*****
5120
5121 027566 004737 010444 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
5122 027572 103407 BCS 30$ ;BR, IF NO PROBLEM
5123 027574 010001 MOV R0,R1 ;SAVE TSSR
5124 027576 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5128 027602 ERRHRD ERRNO,T25RWN,PKTSSR ;REWIND NOT ACCEPTED
      027602 104456 TRAP C$ERHRD
      027604 000223 .WORD 147
      027606 031267 .WORD T25RWN
      027610 011710 .WORD PKTSSR
5129 027612 30$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
      027612 104406
5130 ;*****
5131 ;
5132 ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
5133 ;
5134 ;*****
5135 ;*****
5136
5137 027614 013701 030136 MOV T25BFR+6,R1 ;PICK UP XSTO
5138 027620 010102 MOV R1,R2 ;SET UP EXPECTED
5139 027622 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
5140 027626 020102 CMP R1,R2 ;DOES EXP = REC'D
5141 027630 001406 BEQ 40$ ;BR, IF EQUAL (OK)
5142 027632 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5146 027636 ERRHRD ERRNO,T25BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      027636 104456 TRAP C$ERHRD
      027640 000224 .WORD 148
      027642 030457 .WORD T25BOT
      027644 016360 .WORD EXPREC
5147 027646 012737 000001 030242 40$: MOV #1,T25RB ;NUMBER OF RECORDS TO SPACE OVER
5148
5149 ;*****
5150 ;
5151 ;SPACE FORWARD, IE, ACK, CVC=1 COMMAND
5152 ;
5153 ;*****
5154 ;*****
5155 027654 012737 140210 030240 MOV #140210,T25PK3 ;SPACE FORWARD, IE, ACK, CVC=1 COMMAND
5156 027662 012704 030240 MOV #T25PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
5157 027666 010465 177776 MOV R4,TSD8(R5) ;ISSUE COMMAND
5158 027672 004737 017134 JSR PC,WAITF ;WAIT FOR SSR TO SET
5159 027676 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
5160 027702 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
5161 027706 020102 CMP R1,R2 ;ARE THEY EQUAL
5162 027710 001406 BEQ 75$ ;BR, IF OK
5163 027712 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5167 027716 ERRHRD ERRNO,T25WDE,EXPREC ;TSSR INCORRECT AFTER READ DATA
      027716 104456 TRAP C$ERHRD
      027720 000225 .WORD 149
      027722 030377 .WORD T25WDE
      027724 016360 .WORD EXPREC

```

51

B12

CZTKGA TK-25 FRT END FUNC #3
TEST 1: SPACE RECORDS

MACRO M1700 20-APR-84 08:13 PAGE 94-2

SEQ 144

```

5168 027726          750:  CKLOOP          ;LOOP IF SELECTED
          027726 104406          TRAP      C#CLP1
5169 027730 012737 000020 030242      MOV      #20,T25RB      ;NUMBER OF RECORDS TO SPACE OVER
5170
5171          ;*****
5172          ;
5173          ;SPACE REVERSE,IE,ACK COMMAND
5174          ;
5175          ;*****
5176
5177 027736 012737 100610 030240      MOV      #100610,T25PK3 ;SPACE REVERSE,IE,ACK COMMAND
5178 027744 012704 030240      MOV      #T25PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
5179 027750 010465 177776      MOV      R4,T25DB(R5)  ;ISSUE COMMAND
5180 027754 004737 017134      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
5181 027760 016501 000000      MOV      T25SR(R5),R1 ;GET T25SR CONTENTS
5182 027764 012702 100204      MOV      #25SR!BIT2!SC,R2 ;SET UP EXPECTED
5183 027770 020102      CMP      R1,R2        ;ARE THEY EQUAL
5184 027772 001406      BEQ      1750         ;BR, IF OK
5185 027774 004737 020116      JSR      PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
5189 030000      ERRMRD  ERRNO,T25WDE,EXPREC ;T25SR INCORRECT AFTER READ DATA
          030000 104456          TRAP      C#ERRMRD
          030002 000226          .WORD    150
          030004 030377          .WORD    T25WDE
          030006 016360          .WORD    EXPREC
5190 030010          1750:  CKLOOP          ;LOOP IF SELECTED
          030010 104406          TRAP      C#CLP1
5191 030012 013701 030144      MOV      T25BFR+14,R1 ;GET XST3 STATUS WORD
5192 030016 010102      MOV      R1,R2        ;SET UP EXPECTED
5193 030020 052702 000001      BIS      #BIT0,R2     ;SET THE RIB BIT
5194 030024 020102      CMP      R1,R2        ;ARE THEY EQUAL
5195 030026 001406      BEQ      1800         ;BR, IF EQUAL (GOOD)
5196 030030 004737 020116      JSR      PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
5200 030034      ERRMRD  ERRNO,T25NEF,EXPREC ;NEF SHOULD BE SET
          030034 104456          TRAP      C#ERRMRD
          030036 000227          .WORD    151
          030040 031125          .WORD    T25NEF
          030042 016360          .WORD    EXPREC
5201 030044          1800:
5202 030044      ENDSUB          ;***** END SUBTEST *****
          030044 104403          L10045:
          030046 023727 002170 000031  CMP      FATFLG,#25,   TRAP      C#ESUB
5204 030054 002402          ;IS ERROR COUNT AT 25
5205 030056 004737 020170      BLT      9990         ;BR, IF LESS THAN 25
5206 030062          JSR      PC,CKDROP    ;TRY TO DROP THE UNIT
5207
5208
5209
5210 030062 004737 017372      JSR      PC,TSTLOOP   ;DO WE NEED TO ITERATE TEST
5211 030066 103002          BCC      1930         ;BR, IF NO LOOP REQUIRED
5212 030070 000137 023710      JMP      T25LQOP      ;EXECUTE AGAIN
5213 030074          1930:
5214 030074      EXIT      TST      ;ALL DONE THIS TEST
          030074 104432          TRAP      C#EXIT
          030076 001566          .WORD    L10036-

```


5216			;;		
5217			;LOCAL STORAGE FOR THIS TEST		
5218			;-		
5220	030100		.BLKB 10-<.-TUV2A&7>		
5222	030110		T25PACKET:		;COMMAND PACKET FOR TEST
5223	030110	100004	.WORD 100004		;WRITE CHARACTERISTICS COMMAND, WITH ACK
5224	030112	030120	.WORD T25DATA		;ADDRESS OF CHARACTERISTICS BLOCK
5225	030114	000000	.WORD 0		
5226	030116	000010	.WORD 8.		;STARTING VALUE OF BLOCK SIZE
5227	030120		T25DATA:		;CHARACTERISTICS DATA BLOCK
5228	030120	030130	.WORD T25BFR		;ADDRESS OF MESSAGE BUFFER
5229	030122	000000	.WORD 0		
5230	030124	000012	.WORD 10.		;LENGTH OF MESSAGE BUFFER
5231	030126	000000	.WORD 0		
5232	030130		T25BFR: .BLKW 25.		;MESSAGE BUFFER
5233			;		
5234			;WRITE SUBSYSTEM MEMORY COMMAND PACKET		
5235			;		
5237	030212		.BLKB 10-<.-TUV2A&7>		
5239	030220		T25PK2:		
5240	030220	100006	.WORD 100006		;WRITE SUB SYS MEM COMMAND, AND ACK
5241	030222	030250	.WORD T25BF2		;ADDRESS OF SELECT BLOCK DATA
5242	030224	000000	.WORD 0		
5243	030226	000006	.WORD 6.		;SIZE OF DATA PACKET
5244					
5246	030230		.BLKB 10-<.-TUV2A&7>		
5248	030240		T25PK3:		
5249	030240	100005	.WORD 100005		;READ COMMAND, AND ACK
5250	030242		T25RB:		
5251	030242	003072	T25WB: .WORD FREE		;ADDRESS OF WRITE BUFFER
5252	030244	000000	.WORD 0		
5253	030246	000000	T25SZ: .WORD 0		;SIZE OF BUFFER (EXTENT)
5254			.EVEN		
5255			;		
5256			;		
5257			;		
5258	030250		T25BF2:		
5259	030250	010	T25BS0: .BYTE 10		;BSELO AREA
5260	030251	200	T25BS1: .BYTE 200		;BSEL1 AREA
5261	030252	000000	T25S2: .WORD 0		;SEL 2 AREA
5262	030254	000000	T25S3: .WORD 0		;DATA AREA
5263			;		
5264			;		
5265			.EVEN		
5266			;TAPE MOTION PACKET COMMAND VALUES		
5267					
5268	030256	100005	T25RN: .WORD 100005		;READ DATA (NEXT)
5269	030260	100405	T25WR: .WORD 100405		;READ DATA RETRY
5270	030262	102005	T25CON: .WORD 102005		;WRITE CONTINUOUS
5271	030264	177777	.WORD 177777		;END OF DATA
5272					
5273					

```

5275 030266 000000      T25CN2: .WORD 0      ;COUNTER FOR RECORDS
5276 030270 000000      T25CNT: .WORD 0      ;COUNTER FOR RECORDS
5277 030272 000000      T25DLY: .WORD 0      ;COUNTER FOR RECORDS
5278
5279
5280                      ; LOCAL TEXT MESSAGES FOR TEST
5281                      ; -
5282
5283
5284 030274      104      122      111  T21OFL: .ASCIZ 'DRIVE IS OFF-LINE'
5285 030316      127      122      111  T25SSR: .ASCIZ 'WRITE SUBSYSTEM Miscellaneous Read Status Failed'
5286 030377      124      123      123  T25WDE: .ASCIZ 'TSSR Not Correct After POSITION (SPACE) Command'
5287 030457      124      141      160  T25BOT: .ASCIZ 'Tape Not At BOT After REWIND Command'
5288 030524      124      123      123  T25TM: .ASCIZ 'TSSR Not Correct After POSITION (Space Command) Reject'
5289 030613      127      162      151  T25NET: .ASCIZ 'Write Tape, Status Alert, But No EOT Sensed'
5290 030667      123      160      141  T25WNG: .ASCIZ 'Space Forward Failed To Position On Correct Record'
5291 030752      123      160      141  T25BNC: .ASCIZ 'Space Forward, From BOT, Failed To Clear BOT Indication'
5292 031042      123      160      141  T25WNH: .ASCIZ 'Space Reverse Failed To Position On Correct Record'
5293 031125      123      160      141  T25NEF: .ASCIZ 'Space Reverse, At BOT, Failed To Set NEF (XST0)'
5294 031205      123      160      141  T25RIB: .ASCIZ 'Space Reverse, Into BOT, Failed To Set RIB (XST3)'
5295 031267      122      145      167  T25RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
5296 031336      104      162      151  T25OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
5297 031411      124      123      123  T25WDC: .ASCIZ 'TSSR Not Correct After READ DATA Command'
5298 031462      123      160      141  T25ID: .ASCIZ 'Space Records'
5299                      .EVEN
5300
5301                      ; +
5302                      ; ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
5303                      ; WRITE SUBSYSTEM MEMORY COMMAND
5304                      ;
5305                      ; -
5306
5307 031500
5308 031500
5309 031504 012701 030110      T25REST: SAVREG      ;SAVE THE REGISTERS
5310 031510 012721 100004      MOV      #T25PACKET,R1  ;START OF THE PACKET
5311 031514 012721 030120      MOV      #100004,(R1)  ;WRITE SUBSYSTEM MEM. WITH ACK
5312 031520 005021      CLR      (R1)+          ;ADDRESS OF CHARACTERISTICS DATA BLOCK
5313 031522 012721 000012      MOV      #10,(R1)+     ;EXTENDED ADDRESS
5314 031526 012721 030130      MOV      #T25BFR,(R1)+ ;SIZE OF DATA BLOCK IN BYTES
5315 031532 005021      CLR      (R1)+          ;ADDRESS OF MESSAGE BUFFER
5316 031534 012721 000024      MOV      #20,(R1)+     ;LENGTH OF MESSAGE BUFFER
5317 031540 005021      CLR      (R1)+
5318 031542 012711 000000      MOV      #0,(R1)       ;SELECT DRIVE ZERO
5319 031546 012702 000030      MOV      #24,R2        ;NUMBER OF LOCATIONS TO BE CLEARED
5320 031552 012762 177777 030130 64# : MOV      #177777,T25BFR(R2) ;ALL ONES TO MESSAGE BUFFER
5321 031560 005742      LST      -(R2)         ;NEXT LOCATION
5322 031562 022702 000000      CMP      #0,R2         ;IS R2 AT ZERO YET
5323 031566 001371      BNE      64#          ;KEEP GOING UNTIL DONE
5324 031570 000207      RTS      PC           ;RETURN
5325
5326 031572
5327 031572
5328 031576 012701 030220      T25RT2: SAVREG      ;SAVE THE REGISTERS
5329 031602 012721 100006      MOV      #T25PK2,R1    ;START OF THE PACKET
5330 031606 012721 030250      MOV      #100006,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK
5331 031612 005021      MOV      #T25BF2,(R1)+ ;ADDRESS OF DATA BLOCK
                    CLR      (R1)+ ;EXTENDED ADDRESS

```

E12

CZTKGA TK-25 FRT END FUNC #3
TEST 1: SPACE RECORDS

MACRO M1200 20-APR-84 08:13 PAGE 96-1

SEQ 147

5332	031614	012721	000006
5333	031620	005021	
5334	031622	012701	030250
5335	031626	005021	
5336	031630	005011	
5337	031632	000207	
5338	031634		
5339	031634		
5340	031640	012701	030240
5341	031644	012721	000000
5342	031650	012721	000000
5343	031654	005021	
5344	031656	012721	000000
5345	031662	000207	
5346	031664		
	031664		
	031664	104401	

T25RT3:

```

MOV    #6.,(R1)+
CLR    (R1)+
MOV    #T25BF2,R1
CLR    (R1)+
CLR    (R1)
RTS    PC

SAVREG
MOV    #T25PK3,R1
MOV    #0,(R1)+
MOV    #0,(R1)+
CLR    (R1)+
MOV    #0,(R1)+
RTS    PC
ENDTST

```

;SIZE OF DATA BLOCK IN BYTES

;POINT TO DATA SEL AREA

;RETURN

;SAVE THE REGISTERS

;START OF THE PACKET

;WRITE SUBSYSTEM MEM. WITH ACK,

;ADDRESS OF DATA BLOCK

;EXTENDED ADDRESS

;SIZE OF DATA BLOCK IN BYTES

;RETURN

L10036:

TRAP

C#ETST


```

5406 ;*****
5407 ;
5408 ;ISSUE CONTROLLER "SOFT" INITIALIZE - CARRY BIT CLEAR IF ERROR
5409 ;
5410 ;*****
5411
5412 031756 004737 016660 10$: JSR PC,SOFINIT ;DO INITIALIZE ON CONTROLLER
5413 031762 103426 BCS 20$ ;BR IF INIT WAS OK
5414 031764 DELAY 250 ;DELAY FOR A REWIND TO FINISH
      031764 012727 000250 MOV #250,(PC)+
      031770 000000 .WORD 0
      031772 013727 002116 MOV L$DLY,(PC)+
      031776 000000 .WORD 0
      032000 005367 177772 DEC -6(PC)
      032004 001375 BNE .-4
      032006 005367 177756 DEC -22(PC)
      032012 001367 BNE .-20
5415 032014 005337 046114 DEC T26DLY ;DEC COUNTER
5416 032020 001356 BNE 10$ ;BR, IF DELAY NOT READY
5417 032022 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5421 032026 010001 MOV R0,R1 ;CONTENTS OF TSSR REGISTER
5422 032030 ERRDF ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
      032030 104455 TRAP C$ERDF
      032032 000311 .WORD 201
      032034 003550 .WORD SFIERR
      032036 011676 .WORD SFIMSG
5423 032040
5424
5425 032040 012704 045730 20$: MOV #T26PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
5426
5427 ;*****
5428 ;
5429 ;WRITE CHARACTERISTICS COMMAND (CALL TO WRTPHR)
5430 ;
5431 ;*****
5432
5433 032044 004737 010342 JSR PC,WRTPHR ;ISSUE WRITE CHARACTERISTICS
5434 032050 103407 BCS 26$ ;BR, IF COMMAND ISSUED OK
5435 032052 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5439 032056 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
5440 032060 ERRHRD ERRNO,WRTPHR,SFIMSG ;WRITE CHARACTERISTICS FAILED
      032060 104456 TRAP C$ERHRD
      032062 000312 .WORD 202
      032064 004754 .WORD WRTPHR
      032066 011676 .WORD SFIMSG
5441 032070 26$: CKLOOP ;LOOP IF SELECTED
      032070 104406 TRAP C$CLP1
5442
5443 ;*****
5444 ;
5445 ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
5446 ;
5447 ;*****
5448
5449 032072 004737 010444 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
5450 032076 103413 BCS 30$ ;BR, IF NO PROBLEM
5451 032100 016501 000000 MOV TSSR(R5),R1 ;GET TSSR

```

```

5452 032104 012702 000200      MOV     #SSR,R2      ;SET UP EXPECTED TSSR
5453 032110 010004      MOV     R0,R4       ;PACKET ADDRESS SET UP
5454 032112 004737 020116      JSR     PC,FATCHK   ;INC AND CHECK FOR MORE THAN 25 ERRORS
5458 032116      ERRHRD  ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
      032116 104456
      032120 000313      TRAP   C$ERHRD
      032122 047414      .WORD 203
      032124 011710      .WORD T26RWN
5459 032126      30$:   CKLOOP      ;LOOP IF SELECTED      .WORD  PKTSSR
      032126 104406      TRAP   C$CLP1

5460
5461      ;*****
5462      ;
5463      ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
5464      ;
5465      ;*****
5466
5467 032130 013701 045756      MOV     T26BFR+6,R1 ;PICK UP XSTO
5468 032134 010102      MOV     R1,R2       ;SET UP EXPECTED
5469 032136 052702 000002      BIS     #BIT1,R2    ;SET BOT BIT IN EXPECTED
5470 032142 020102      CMP     R1,R2       ;DOES EXP = REC'D
5471 032144 001406      BEQ    40$         ;BR, IF EQUAL (OK)
5472 032146 004737 020116      JSR     PC,FATCHK   ;INC AND CHECK FOR MORE THAN 25 ERRORS
5476 032152      ERRHRD  ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      032152 104456      TRAP   C$ERHRD
      032154 000314      .WORD 204
      032156 047125      .WORD T26BOT
      032160 016360      .WORD  EXPREC
5477 032162      40$:   CKLOOP      ;LOOP IF SELECTED      TRAP   C$CLP1
      032162 104406
5478 032164 012703 000400      MOV     #256,R3     ;RECORD SIZE
5479 032170 013737 003072 046062  MOV     FREE,T26RB  ;STARTING WRITE BUFFER ADDRESS
5480
5481      ;*****
5482      ;
5483      ;WRITE DATA,ACK,CVC=1 COMMAND
5484      ;
5485      ;*****
5486
5487 032176 012737 140005 046060      MOV     #140005,T26PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
5488 032204 012704 046060      MOV     #T26PK3,R4  ;SET UP R4 WITH PACKET ADDRESS
5489 032210
5490 032210 010300      65$:   MOV     R3,R0       ;SET PATTERN IN CORRECT REGISTER
5491 032212 004737 020410      JSR     PC,FILLMEM  ;FILL MEMORY WITH RECORD SIZE
5492 032216 010337 046066      MOV     R3,T26SZ    ;SET UP RECORD SIZE IN PACKET
5493 032222 010465 177776      MOV     R4,TSD8(R5) ;ISSUE COMMAND
5494 032226 004737 017134      JSR     PC,WAITF    ;WAIT FOR SSR TO SET
5495 032232 016501 000900      MOV     TSSR(R5),R1 ;GET TSSR CONTENTS
5496 032236 012702 000200      MOV     #SSR,R2     ;SET UP EXPECTED
5497 032242 020102      CMP     R1,R2       ;ARE THEY EQUAL
5498 032244 001406      BEQ    75$         ;BR, IF OK
5499 032246 004737 020116      JSR     PC,FATCHK   ;INC AND CHECK FOR MORE THAN 25 ERRORS
5503
5504      ;SOFT ERROR GENERATED BECAUSE THE
5505      ;WRITE COMMAND IS NOT BEING CHECKED
5506 032252      ERRSOFT ERRNO,WRTErr,EXPREC ;HERE, IT WAS CHECKED IN LEAK2
      032252 104457      ;TSSR INCORRECT AFTER WRITE DATA
      TRAP   C$ERSOFT

```

```

032254 000315 .WORD 205
032256 005011 .WORD WRTERR
032260 016360 .WORD EXPREC
5507 032262 75$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
032262 104406 ;BUMP RECORD SIZE
5508 032264 005723 ;END OF RECORD YET
5509 032266 022703 000414 CMP #268.,R3 ;BR, IF MORE RECORDS TO WRITE
5510 032272 001346 BNE 65$ ;LOOP IF SELECTED
5511 032274 80$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
032274 104406
5512 032276 120$:
5513 ;*****
5514 ;
5515 ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
5516 ;
5517 ;
5518 ;*****
5519 ;
5520 032276 004737 010444 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
5521 032302 103413 BCS 130$ ;BR, IF NO PROBLEM
5522 032304 016501 000000 MOV TSSR(R5),R1 ;GET TSSR
5523 032310 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED TSSR
5524 032314 010004 MOV R0,R4 ;PACKET ADDRESS SET UP
5525 032316 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5529 032322 ERRHRD ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
032322 104456 TRAP C$ERHRD
032324 000316 .WORD 206
032326 047414 .WORD T26RWN
032330 011710 .WORD PKTSSR
5530 032332 130$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
032332 104406
5531 ;*****
5532 ;
5533 ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERU (XSTO)
5534 ;
5535 ;
5536 ;*****
5537 ;
5538 032334 013701 045756 MOV T26BFR+6,R1 ;PICK UP XSTO
5539 032340 010102 MOV R1,R2 ;SET UP EXPECTED
5540 032342 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
5541 032346 020102 CMP R1,R2 ;DOES EXP = REC'D
5542 032350 001406 BEQ 140$ ;BR, IF EQUAL (OK)
5543 032352 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5547 032356 ERRHRD ERRNO,T26BOT,PKTSSR ;TAPE NOT AT BOT AFTER REWIND
032356 104456 TRAP C$ERHRD
032360 000317 .WORD 207
032362 047125 .WORD T26BOT
032364 011710 .WORD PKTSSR
5548 032366 140$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
032366 104406
5549 032370 012737 000400 046112 MOV #256.,T26RSZ ;SET RECORD SIZE
5550 ;*****
5551 ;
5552 ;ISSUE SPACE RECORDS COMMAND - VALUE IN R3 SETS NUMBER OF RECORDS
5553 ;BIT 15 SETS DIRECTION - 0=FORWARD 1=REVERSE
5554

```

```

5555
5556
5557
5558 032376 012703 000001
5559 032402 004737 010144
5560 032406 103412
5561 032410 016501 000000
5562 032414 012702 000200
5563 032420 004737 020116
5567 032424
      032424 104456
      032426 000320
      032430 046527
      032432 016360
5568 032434
5569 032434 013703 046112
5570 032440 013737 003072 046062
5571
5572
5573
5574
5575
5576
5577
5578 032446 012737 141001 046060
5579 032454 012704 046060
5580 032460 010337 046066
5581 032464 010465 177776
5582 032470 004737 017134
5583 032474 016501 000000
5584 032500 012702 000200
5585 032504 020102
5586 032506 001406
5587 032510 004737 020116
5591 032514
      032514 104456
      032516 000321
      032520 047750
      032522 011710
5592 032524
      032524 104406
5593 032526 013702 003072
5594 032532 010304
5595 032534 162704 000400
5596 032540 060204
5597 032542 021403
5598 032544 001410
5599 032546 011401
5600 032550 010302
5601 032552 004737 020116
5605 032556
      032556 104456
      032560 000322
      032562 047172
      032564 016360
5606 032566
      032566 104406

```

```

;
;*****
145$:  MOV    #1,R3                ;SPACE ONE RECORD PARAMETER
      JSR    PC,SPACE            ;CALL SPACE ROUTINE
      BCS    150$               ;BR, IF NO PROBLEM WITH SPACE COMMAND
      MOV    TSSR(R5),R1        ;GET TSSR
      MOV    #SSR,R2           ;SET UP EXPECTED TSSR
      JSR    PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
      ERRHRD ERRNO,T26SC,EXPREC ;POSITION (SPACE RECORDS) FAILED
                                TRAP   C$ERHRD
                                .WORD  208
                                .WORD  T26SC
                                .WORD  EXPREC
150$:  MOV    T26RSZ,R3          ;RECORD SIZE
      MOV    FREE,T26RB        ;STARTING READ BUFFER ADDRESS
;*****
;
;REREAD DATA,CVC=1,ACK COMMAND
;
;*****
165$:  MOV    #141001,T26PK3     ;REREAD DATA,CVC=1,ACK COMMAND
      MOV    #T26PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
      MOV    R3,T26SZ         ;SET UP RECORD SIZE IN PACKET
      MOV    R4,TSD8(R5)      ;ISSUE COMMAND
      JSR    PC,WAITF         ;WAIT FOR SSR TO SET
      MOV    TSSR(R5),R1     ;GET TSSR CONTENTS
      MOV    #SSR,R2         ;SET UP EXPECTED
      CMP    R1,R2           ;ARE THEY EQUAL
      BEQ    170$           ;BR, IF OK
      JSR    PC,FATCHK       ;INC AND CHECK FOR MORE THAN 25 ERRORS
      ERRHRD ERRNO,T26WDC,PKTSSR ;TSSR INCORRECT AFTER REREAD DATA
                                TRAP   C$ERHRD
                                .WORD  209
                                .WORD  T26WDC
                                .WORD  PKTSSR
170$:  CKLOOP                   ;LOOP IF SELECTED
                                TRAP   C$CLP1
      MOV    FREE,R2         ;CURRENT BUFFER ADDRESS TO R2
      MOV    R3,R4          ;CURRENT RECORD SIZE
      SUB    #256.,R4       ;FIRST LOCATION IN BUFFER
173$:  ADD    R2,R4           ;SET UP POINTER
      CMP    (R4),R3        ;CHECK DATA READ (R3=DATA ALSO)
      BEQ    180$           ;BR, IF ALL IS WELL
      MOV    (R4),R1       ;RECD DATA
      MOV    R3,R2         ;EXPECTED DATA
      JSR    PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
      ERRHRD ERRNO,T26DTA,EXPREC ;DATA READ NOT * WRITTEN
                                TRAP   C$ERHRD
                                .WORD  210
                                .WORD  T26DTA
                                .WORD  EXPREC
180$:  CKLOOP                   ;LOOP IF SELECTED
                                TRAP   C$CLP1

```



```

5622
5623
5624
5625
5626
5627
5628
5629
5630
5631
5632
5633
5634
5635 032634
032634
032634 104402
5636 032636 004737 050650
5637 032642 004737 050742
5638 032646 004737 051004
5639
5640
5641
5642
5643
5644
5645
5646 032652 004737 016660
5647 032656 103407
5648 032660 004737 020116
5652 032664 010001
5653 032666
032666 104455
032670 000323
032672 003550
032674 011676
5654 032676
5655
5656 032676 012704 045730
5657
5658
5659
5660
5661
5662
5663
5664 032702 004737 010342
5665 032706 103407
5666 032710 004737 020116
5670 032714 010001
5671 032716
032716 104456
032720 000324
032722 004754
032724 011676
5672 032726
032726 104406
5673

```

```

;
; TEST 2, SUBTEST 2
;
; VERIFIES THAT THE REREAD PREVIOUS COMMAND WITH OPP=0
; AND SWB=1 OPERATES PROPERLY. THE TEST SEQUENCE IS
; THE SAME AS THAT USED IN SUBTEST 1, BUT IT IS
; VERIFIED THAT DATA STORED BY THE COMMAND CONTAINS
; SWAPPED BYTES.
;
;
;
; BGNSUB                                  ; >>>>>>>>>> BEGIN SUBTEST >>>>>>>>>>
;                                  T2,2:
;                                  TRAP C$BSUB
; JSR PC,T26REST                       ; SET COMMAND PACKET
; JSR PC,T26RT2                          ; SET UP OTHER COMMAND PACKET
; JSR PC,T26RT3                          ; SET UP OTHER COMMAND PACKET
;
; *****
; ISSUE CONTROLLER "SOFT" INITIALIZE - CARRY BIT CLEAR IF ERROR
; *****
; JSR PC,SOFINIT                         ; DO INITIALIZE ON CONTROLLER
; BCS 20$                                ; BR IF INIT WAS OK
; JSR PC,FATCHK                          ; INC AND CHECK FOR MORE THAN 25 ERRORS
; MOV RO,R1                               ; CONTENTS OF TSSR REGISTER
; ERRDF ERRNO,SFIERR,SFIMSG              ; FATAL ERROR TSSR WAS NOT OK
;                                  TRAP C$ERDF
;                                  .WORD 211
;                                  .WORD SFIERR
;                                  .WORD SFIMSG
20$:
; MOV @T26PACKET,R4                     ; SUBROUTINE NEEDS PACKET ADDRESS
;
; *****
; WRITE CHARACTERISTICS COMMAND (CALL TO WRTCHR)
; *****
; JSR PC,WRTCHR                          ; ISSUE WRITE CHARACTERISTICS
; BCS 26$                                ; BR IF COMMAND ISSUED OK
; JSR PC,FATCHK                          ; INC AND CHECK FOR MORE THAN 25 ERRORS
; MOV RO,R1                               ; SAVE CONTENTS OF TSSR
; ERRHRD ERRNO,WRTMSG,SFIMSG             ; WRITE CHARACTERISTICS FAILED
;                                  TRAP C$ERHRD
;                                  .WORD 212
;                                  .WORD WRTMSG
;                                  .WORD SFIMSG
26$:  CKLOOP                              ; LOOP IF SELECTED
;                                  TRAP C$CLP1

```

```

5674
5675
5676
5677
5678
5679
5680 032730 004737 010444
5681 032734 103413
5682 032736 016501 000000
5683 032742 012702 000200
5684 032746 010004
5685 032750 004737 020116
5689 032754
      032754 104456
      032756 000325
      032760 047414
      032762 011710
5690 032764
      032764 104406
5691
5692
5693
5694
5695
5696
5697
5698 032766 013701 045756
5699 032772 010102
5700 032774 052702 000002
5701 033000 020102
5702 033002 001406
5703 033004 004737 020116
5707 033010
      033010 104456
      033012 000326
      033014 047125
      033016 016360
5708 033020
      033020 104406
5709 033022 012703 000400
5710 033026 013737 003072 046062
5711
5712
5713
5714
5715
5716
5717
5718 033034 012737 110005 046060
5719 033042 012704 046060
5720 033045
5721 033046 010300
5722 033050 004737 020410
5723 033054 010337 046066
5724 033060 010465 177776
5725 033064 004737 017134
5726 033070 016501 000000

```

```

;*****
;
;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
;
;*****
      JSR      PC,REWIND          ;CALL TAPE REWIND COMMAND
      BCS     30$                ;BR, IF NO PROBLEM
      MOV     TSSR(R5),R1        ;GET TSSR
      MOV     #SSR,R2           ;SET UP EXPECTED TSSR
      MOV     R0,R4              ;PACKET ADDRESS SET UP
      JSR     PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
      ERRHRD ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
                                     TRAP C$ERHRD
                                     .WORD 213
                                     .WORD T26RWN
                                     .WORD PKTSSR
30$:   CKLOOP                    ;LOOP IF SELECTED
                                     TRAP C$CLP1
;*****
;
;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
;
;*****
      MOV     T26BFR+6,R1        ;PICK UP XSTO
      MOV     R1,R2              ;SET UP EXPECTED
      BIS     @BIT1,R2           ;SET BOT BIT IN EXPECTED
      CMP     R1,R2              ;DOES EXP = REC'D
      BEQ     40$                ;BR, IF EQUAL (OK)
      JSR     PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
      ERRHRD ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                     TRAP C$ERHRD
                                     .WORD 214
                                     .WORD T26BOT
                                     .WORD EXPREC
40$:   CKLOOP                    ;LOOP IF SELECTED
                                     TRAP C$CLP1
      MOV     #256,R3            ;RECORD SIZE
      MOV     FREE,T26RB         ;STARTING WRITE BUFFER ADDRESS
;*****
;
;WRITE DATA,ACK,SWB COMMAND
;
;*****
      MOV     #110005,T26PK3     ;WRITE DATA,ACK,SWB COMMAND
      MOV     #T26PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
65$:   MOV     R3,R0              ;SET PATTERN IN CORRECT REGISTER
      JSR     PC,FILLMEM        ;FILL MEMORY WITH RECORD SIZE
      MOV     R3,T26SZ          ;SET UP RECORD SIZE IN PACKET
      MOV     R4,T26SZ          ;ISSUE COMMAND
      JSR     PC,WAITF          ;WAIT FOR SSR TO SET
      MOV     TSSR(R5),R1      ;GET TSSR CONTENTS

```

```

5727 033074 012702 000200      MOV    #SSR,R2      ;SET UP EXPECTED
5728 033100 020102      CMP    R1,R2      ;ARE THEY EQUAL
5729 033102 001406      BEQ   75$         ;BR, IF OK
5730 033104 004737 020116      JSR   PC,FATCHK   ;INC AND CHECK FOR MORE THAN 25 ERRORS
5734                                ;SOFT ERROR GENERATED BECAUSE THE
5735                                ;WRITE COMMAND IS NOT BEING CHECKED
5736                                ;HERE, IT WAS CHECKED IN LEAH2
5737 033110      ERRSOFT ERRNO,WRTErr,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP   C$ERRSOFT
                                .WORD  215
                                .WORD  WRTErr
                                .WORD  PKTSSR
                                TRAP   C$CLP1
033110 104457
033112 000327
033114 005011
033116 011710
5738 033120      75$: CKLOOP      ;LOOP IF SELECTED
                                TRAP   C$CLP1
033120 104406
5739 033122 005723      TST   (R3)+      ;BUMP RECORD SIZE
5740 033124 022703 000414      CMP   #268.,R3  ;END OF RECORD YET
5741 033130 001346      BNE   65$         ;BR, IF MORE RECORDS TO WRITE
5742 033132 104406      80$: CKLOOP      ;LOOP IF SELECTED
                                TRAP   C$CLP1
033132 104406
5743 033134      120$:
5744
5745      ;*****
5746      ;
5747      ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
5748      ;
5749      ;*****
5750
5751 033134 004737 010444      JSR   PC,REWIND  ;CALL TAPE REWIND COMMAND
5752 033140 103415      BCS   130$       ;BR, IF NO PROBLEM
5753 033142 016501 000000      MOV   TSSR(R5),R1 ;GET TSSR
5754 033146 012702 000200      MOV   #SSR,R2   ;SET UP EXPECTED TSSR
5755 033152 010004      MOV   R0,R4     ;PACKET ADDRESS SET UP
5756 033154 004737 020116      JSR   PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5760 033160      ERRHRD ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP   C$ERRHRD
                                .WORD  216
                                .WORD  T26RWN
                                .WORD  PKTSSR
033160 104456
033162 000330
033164 047414
033166 011710
5761 033170      130$: CKLOOP      ;LOOP IF SELECTED
                                TRAP   C$CLP1
033170 104406
5762
5763      ;*****
5764      ;
5765      ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
5766      ;
5767      ;*****
5768
5769 033172 013701 045756      MOV   T26BFR+6,R1 ;PICK UP XSTO
5770 033176 010102      MOV   R1,R2     ;SET UP EXPECTED
5771 033200 052702 000002      BIS   #BIT1,R2  ;SET BOT BIT IN EXPECTED
5772 033204 020102      CMP   R1,R2     ;DOES EXP = RECD
5773 033206 001406      BEQ   140$       ;BR, IF EQUAL (OK)
5774 033210 004737 020116      JSR   PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5778 033214      ERRHRD ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP   C$ERRHRD
                                .WORD  217
                                .WORD  T26BOT
033214 104456
033216 000331
033220 047125

```

```

5779 033222 016360
033224
033224 104406
5780 033226 012737 000400 046112      MOV      #256.,T26RSZ      ;SET UP RECORD SIZE
5781
5782
5783
5784
5785
5786
5787
5788
5789 033234 012703 000001      1451:  MOV      #1,R3      ;SPACE ONE RECORD PARAMETER
5790 033240 004737 010144      JSR      PC,SPACE        ;CALL SPACE ROUTINE
5791 033244 103412      BCS      1501            ;BR, IF NO PROBLEM WITH SPACE COMMAND
5792 033246 016501 000000      MOV      TSSR(R5),R1     ;GET TSSR
5793 033252 012702 000200      MOV      #SSR,R2        ;SET UP EXPECTED TSSR
5794 033256 004737 020116      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
5798 033262      ERRHRD  ERRNO,T26SC,EXPREC ;POSITION (SPACE RECORDS) FAILED
033262 104456      TRAP      C1ERHRD
033264 000332      .WORD    218
033266 046527      .WORD    T26SC
033270 016360      .WORD    EXPREC
5799 033272
5800 033272 013703 046112      1501:  MOV      T26RSZ,R3      ;RECORD SIZE
5801 033276 013737 003072 046062      MOV      FREE,T26RB      ;STARTING READ BUFFER ADDRESS
5802
5803
5804
5805
5806
5807
5808
5809 033304 012737 151001 046060      1651:  MOV      #151001,T26PK3  ;REREAD DATA,CVC=1,ACK,SWB COMMAND
5810 033312 012704 046060      MOV      #T26PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
5811 033316 010337 046066      MOV      R3,T26S7       ;SET UP RECORD SIZE IN PACKET
5812 033322 010465 177776      MOV      R4,TSD8(R5)    ;ISSUE COMMAND
5813 033326 004737 017134      JSR      PC,WAITF       ;WAIT FOR SSR TO SET
5814 033332 016501 000000      MOV      TSSR(R5),R1     ;GET TSSR CONTENTS
5815 033336 012702 000200      MOV      #SSR,R2        ;SET UP EXPECTED
5816 033342 020102      CMP      R1,R2          ;ARE THEY EQUAL
5817 033344 001406      BEQ      1701            ;BR, IF OK
5818 033346 004737 020116      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
5822 033352      ERRHRD  ERRNO,T26WDC,PKTSSR ;TSSR INCORRECT AFTER REREAD DATA
033352 104456      TRAP      C1ERHRD
033354 000333      .WORD    219
033356 047750      .WORD    T26WDC
033360 011710      .WORD    PKTSSR
5823 033362
033362 104406      1701:  CKLOOP      ;LOOP IF SELECTED
5824 033364 013702 003072      MOV      FREE,R2        ;CURRENT BUFFER ADDRESS TO R2
5825 033370 010304      MOV      R3,R4          ;CURRENT RECORD SIZE
5826 033372 162704 000400      SUB      #256.,R4       ;FIRST LOCATION IN BUFFER
5827 033376 060204      1731:  F7D      R2,R4          ;SET UP POINTER
5828 033400 021403      CMP      (R4),R3        ;CHECK DATA READ (R3=DATA ALSO)
5829 033402 001410      BEQ      1801            ;BR, IF ALL IS WELL
5830 033404 011401      MOV      (R4),R1        ;RECD DATA

```

C13

CZIKGA TK 25 FBI END FUNC #3
TEST 2: HEREADS

MACRO M1200 20-APR-84 08:13 PAGE 98-4

SEQ 158

```

5831 033406 010302          MOV   R3,R2
5832 033410 004737 020116  JSR   PC,FATCHK
5836 033414          ERRHRD  ERRNO,T26DTA,EXPREC
      033414 104456
      033416 000334
      033420 047172
      033422 016360
5837 033424          1804:  CKLOOP
      033424 104406
5838 033426 005724          TST   (R4)+
5839 033430 160204          SUB   R2,R4
5840 033432 020403          CMP   R4,R3
5841 033434 001360          BNE   1734
5842 033436 005723          TST   (R3)+
5843 033440 010337 046112  MOV   R3,T26RSZ
5844 033444 022703 000412  CMP   #266,,R3
5845 033450 001271          BNE   1454
5846 033452          1904:  CKLOOP
      033452 104406
5847 033454          ENDSUB
      033454
      033454 104403
5848 033456 023727 002170 000031  CMP   FATFLG,#25.
5849 033464 002402          BLT   9994
5850 033466 004737 020170  JSR   PC,CKDROP
5851 033472          9994:

```

```

;EXPECTED DATA
;INC AND CHECK FOR MORE THAN 25 ERRORS
;DATA READ NOT = WRITTEN
                                  TRAP   C#ERHRD
                                  .WORD   220
                                  .WORD   T26DTA
                                  .WORD   EXPREC
;LOOP IF SELECTED
                                  TRAP   C#CLP1
;BUMP TO NEXT LOCATION
;CORRECT RECORDS SIZE VALUE
;END OF RECORD YET
;BR, IF NOT AT END OF RECORD
;BUMP RECORD SIZE
;STORE RECORD SIZE
;END OF RECORD YET
;BR, IF MORE RECORDS TO READ
;LOOP IF SELECTED
                                  TRAP   C#CLP1
;>>>>>>>>> END SUBTEST >>>>>>>>>>>
                                  L10050:
                                  TRAP   C#ESUB
;IS ERROR COUNT AT 25
;BR, IF LESS THAN 25
;TRY TO DROP THE UNIT

```



```

5907
5908 033540 012704 045730          MOV      #T26PACKET,R4          ;SUBROUTINE NEEDS PACKET ADDRESS
5909
5910          ;*****
5911          ;
5912          ;WRITE CHARACTERISTICS COMMAND (CALL TO WRTPCHR)
5913          ;
5914          ;*****
5915
5916 033544 004737 010342          JSR      PC,WRTPCHR          ;ISSUE WRITE CHARACTERISTICS
5917 033550 103407          BCS     26$                ;BR, IF COMMAND ISSUED OK
5918 033552 004737 020116          JSR      PC,FATCHK          ;INC AND CHECK FOR MORE THAN 25 ERRORS
5922 033556 010001          MOV     R0,R1              ;SAVE CONTENTS OF TSSR
5923 033560          ERRHRD  ERRNO,WRTPMSG,SFMSG ;WRITE CHARACTERISTICS FAILED
          033560 104456          TRAP    C$ERRHRD
          033562 000336          .WORD  222
          033564 004754          .WORD  WRTPMSG
          033566 011676          .WORD  SFMSG
5924 033570          26$:   CKLOOP            ;LOOP IF SELECTED
          033570 104406          TRAP    C$CLP1
5925
5926          ;*****
5927          ;
5928          ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
5929          ;
5930          ;*****
5931
5932 033572 004737 010444          JSR      PC,REWIND          ;CALL TAPE REWIND COMMAND
5933 033576 103413          BCS     30$                ;BR, IF NO PROBLEM
5934 033600 016501 000000          MOV     TSSR(R5),R1        ;GET TSSR
5935 033604 012702 000200          MOV     #SSR,R2            ;SET UP EXPECTED TSSR
5936 033610 010004          MOV     R0,R4              ;PACKET ADDRESS SET UP
5937 033612 004737 020116          JSR      PC,FATCHK          ;INC AND CHECK FOR MORE THAN 25 ERRORS
5941 033616          ERRHRD  ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
          033616 104456          TRAP    C$ERRHRD
          033620 000337          .WORD  223
          033622 047414          .WORD  T26RWN
          033624 011710          .WORD  PKTSSR
5942 033626          30$:   CKLOOP            ;LOOP IF SELECTED
          033626 104406          TRAP    C$CLP1
5943
5944          ;*****
5945          ;
5946          ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XST0)
5947          ;
5948          ;*****
5949
5950 033630 013701 045756          MOV     T26BFR+6,R1        ;PICK UP XST0
5951 033634 010102          MOV     R1,R2              ;SET UP EXPECTED
5952 033636 052702 000002          BIS     #BIT1,R2            ;SET BOT BIT IN EXPECTED
5953 033642 020102          CMP     R1,R2              ;DOES EXP = REC'D
5954 033644 001406          BEQ     40$                ;BR, IF EQUAL (OK)
5955 033646 004737 020116          JSR      PC,FATCHK          ;INC AND CHECK FOR MORE THAN 25 ERRORS
5959 033652          ERRHRD  ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
          033652 104456          TRAP    C$ERRHRD
          033654 000340          .WORD  224
          033656 047125          .WORD  T26BOT

```



```

033660 016360
5960 033662 104406 040$: CKLOOP ;LOOP IF SELECTED .WORD EXPREC
033662 104406 ;TRAP C$CLP1
5961 033664 012703 000400 MOV #256.,R3 ;RECORD SIZE
5962 033670 013737 003072 046062 MOV FREE,T26R6 ;STARTING WRITE BUFFER ADDRESS
5963
5964 ;*****
5965 ;
5966 ;WRITE DATA,CVC=1,ACK COMMAND
5967 ;
5968 ;*****
5969
5970 033676 012737 140005 046060 MOV #140005,T26PK3 ;WRITE DATA,CVC=1,ACK COMMAND
5971 033704 012704 046060 MOV #T26PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
5972 033710 65$:
5973 033710 010300 MOV R3,R0 ;SET PATTERN IN CORRECT REGISTER
5974 033712 004737 020410 JSR PC,FILLMEM ;FILL MEMORY WITH RECORD SIZE
5975 033716 010337 046066 MOV R3,T26SZ ;SET UP RECORD SIZE IN PACKET
5976 033722 013777 046106 147142 MOV T26CNT,#FREE ;MOVE TAPE RECORD NUMBER TO BUFFER
5977 033730 062737 000001 046106 ADD #1,T26CNT ;NUMBER READY FOR NEXT RECORD
5978 033736 010465 177776 MOV R4,TSSB(R5) ;ISSUE COMMAND
5979 033742 004737 017134 JSR PC,WAITF ;WAIT FOR SSR TO SET
5980 033746 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
5981 033752 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
5982 033756 020102 CMP R1,R2 ;ARE THEY EQUAL
5983 033760 001406 BEQ 75$ ;BR. IF OK
5984 033762 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
5988 ;SOFT ERROR GENERATED BECAUSE THE
5989 ;WRITE COMMAND IS NOT BEING CHECKED
5990 ;HERE. IT WAS CHECKED IN LEAH2
5991 033766 ERRSOFT ERRNO,WRTErr,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
033766 104457 TRAP C$ERSOFT
033770 000341 .WORD 225
033772 005011 .WORD WRTErr
033774 011710 .WORD PKTSSR
5992 033776 75$: CKLOOP ;LOOP IF SELECTED .WORD
033776 104406 ;TRAP C$CLP1
5993 034000 005723 TST (R3), ;BUMP THE RECORD SIZE
5994 034002 022703 000414 CMP #268.,R3 ;MAXIMUM SIZE YET
5995 034006 001401 BEQ 120$ ;BR. IF AT END OF WRITE SEQUENCE
5996 034010 000737 BR 65$ ;WRITE MORE RECORDS
5997 034012 120$:
5998 034012 005037 046106 CLR T26CNT ;SET RECORD COUNTER BACK TO ZERO
5999
6000 ;*****
6001 ;
6002 ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
6003 ;
6004 ;*****
6005
6006 034016 004737 010444 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
6007 034022 103413 BCS 130$ ;BR. IF NO PROBLEM
6008 034024 016501 000000 MOV TSSR(R5),R1 ;GET TSSR
6009 034030 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED TSSR
6010 034034 010004 MOV R0,R4 ;PACKET ADDRESS SET UP
6011 034036 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
6015 034042 ERRHRD ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED

```

	034042	104456							TRAP	C\$ERHRD
	034044	000342							.WORD	226
	034046	047414							.WORD	T26RWN
	034050	011710							.WORD	PKTSSR
6016	034052			130\$:	CKLOOP					
	034052	104406								
6017									TRAP	C\$CLP1
6018										
6019										
6020										
6021										
6022										
6023										
6024	034054	013701	045756							
6025	034060	010102			MOV	T26BFR+6,R1				
6026	034062	052702	000002		MOV	R1,R2				
6027	034066	020102			BIS	#BIT1,R2				
6028	034070	001406			CMP	R1,R2				
6029	034072	004737	020116		BEQ	140\$				
6033	034076				JSR	PC,FATCHK				
	034076	104456			ERRHRD	ERRNO,T26BOT,EXPREC				
	034100	000343							TRAP	C\$ERHRD
	034102	047125							.WORD	227
	034104	016360							.WORD	T26BOT
6034	034106			140\$:	CKLOOP				.WORD	EXPREC
	034106	104406								
6035									TRAP	C\$CLP1
6036										
6037										
6038										
6039										
6040										
6041										
6042										
6043	034110	012703	000001		MOV	#1,R3				
6044	034114	004737	010144		JSR	PC,SPACE				
6045	034120	012703	000400		MOV	#256,R3				
6046	034124	013737	003072	046062	150\$:	MOV	FREE,T26RB			
6047										
6048										
6049										
6050										
6051										
6052										
6053										
6054	034132	012737	161001	046060		MOV	#161001,T26PK3			
6055	034140	012704	046060		165\$:	MOV	#T26PK3,R4			
6056	034144	010337	046066		MOV	R3,T26SZ				
6057	034150	010465	177776		MOV	R4,TSDB(R5)				
6058	034154	004737	017134		JSR	PC,WAITF				
6059	034160	016501	000000		MOV	TSSR(R5),R1				
6060	034164	012702	000200		MOV	#SSR,R2				
6061	034170	020102			CMP	R1,R2				
6062	034172	001406			BEQ	170\$				
6063	034174	004737	020116		JSR	PC,FATCHK				
6067	034200				ERRHRD	ERRNO,T26RRG,PKTSSR				
	034200	104456							TRAP	C\$ERHRD


```

6112                               ;*
6113                               ;
6114                               ; TEST 2, SUBTEST 4
6115                               ;
6116                               ; VERIFIES THAT THE REREAD PREVIOUS COMMAND WITH OPP=1
6117                               ; AND SWB=1 OPERATES PROPERLY. THE TEST SEQUENCE IS
6118                               ; THE SAME THAT IS USED IN SUBTEST 3, BUT IT IS
6119                               ; VERIFIED THAT DATA STORED BY THE COMMAND CONTAINS
6120                               ; SWAPPED BYTES.
6121                               ;
6122                               ;
6123                               ;
6124                               ;
6125                               ; -
6126                               ;
6127 034356                         BGNSUB                               ;>>>>>>>>>>>> BEGIN SUBTEST >>>>>>>>>>
                                   034356                               T2.4:
                                   034356 104402                               TRAP      C#BSUB
6128 034360 004737 050650           JSR      PC,T26REST             ;SET COMMAND PACKET
6129 034364 005037 046106           CLR      T26CNT             ;CLEAR TAPE RECORD COUNTER
6130 034370 004737 050742           JSR      PC,T26RT2         ;SET UP OTHER COMMAND PACKET
6131 034374 004737 051004           JSR      PC,T26RT3         ;SET UP OTHER COMMAND PACKET
6132
6133                               ;*****
6134                               ;
6135                               ; ISSUE CONTROLLER "SOFT" INITIALIZE - CARRY BIT CLEAR IF ERROR
6136                               ;
6137                               ;*****
6138
6139 034400 004737 016660           JSR      PC,SOFINIT       ;DO INITIALIZE ON CONTROLLER
6140 034404 103407                               BCS      20$              ;BR IF INIT WAS OK
6141 034406 004737 020116           JSR      PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
6145 034412 010001                               MOV      R0,R1            ;CONTENTS OF TSSR REGISTER
6146 034414                               ERROF   ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
                                   034414 104455                               TRAP      C#ERDF
                                   034416 000347                               .WORD    231
                                   034420 003550                               .WORD    SFIERR
                                   034422 011676                               .WORD    SFIMSG
6147 034424                               20$:
6148
6149 034424 012704 045730           MOV      #T26PACKET,R4    ;SUBROUTINE NEEDS PACKET ADDRESS
6150
6151                               ;*****
6152                               ;
6153                               ; WRITE CHARACTERISTICS COMMAND (CALL TO WRTCHR)
6154                               ;
6155                               ;*****
6156
6157 034430 004737 010342           JSR      PC,WRTCHR        ;ISSUE WRITE CHARACTERISTICS
6158 034434 103407                               BCS      26$              ;BR, IF COMMAND ISSUED OK
6159 034436 004737 020116           JSR      PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
6163 034442 010001                               MOV      R0,R1            ;SAVE CONTENTS OF TSSR
6164 034444                               ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                   034444 104456                               TRAP      C#ERHRD
                                   034446 000350                               .WORD    232
                                   034450 004754                               .WORD    WRTMSG
                                   034452 011676                               .WORD    SFIMSG

```

J13

```

6165 034454          26$:  CKLOOP                ;LOOP IF SELECTED
      034454 104406                                TRAP      C#CLP1
6166
6167 ;*****
6168 ;
6169 ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
6170 ;
6171 ;*****
6172
6173 034456 004737 010444      JSR      PC,REWIND          ;CALL TAPE REWIND COMMAND
6174 034462 103413          BCS      30$              ;BR. IF NO PROBLEM
6175 034464 016501 000000      MOV      TSSR(R5),R1      ;GET TSSR
6176 034470 012702 000200      MOV      #SSR,R2        ;SET UP EXPECTED TSSR
6177 034474 010004          MOV      R0,R4           ;PACKET ADDRESS SET UP
6178 034476 004737 020116      JSR      PC,FATCH#       ;INC AND CHECK FOR MORE THAN 25 ERRORS
6182 034502          ERRHRD  ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
      034502 104456                                TRAP      C#ERHRD
      034504 000351                                .WORD    233
      034506 047414                                .WORD    T26RWN
      034510 011710                                .WORD    PKTSSR
6183 034512          30$:  CKLOOP                ;LOOP IF SELECTED
      034512 104406                                TRAP      C#CLP1
6184
6185 ;*****
6186 ;
6187 ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XST0)
6188 ;
6189 ;*****
6190
6191 034514 013701 045756      LJM     T26BFR+6,R1      ;PICK UP XST0
6192 034520 010102          MOV      R1,R2           ;SET UP EXPECTED
6193 034522 052702 000002      BIL     #BIT1,R2        ;SET BOT BIT IN EXPECTED
6194 034526 020102          CMP     R1,R2           ;DOES EXP = REC'D
6195 034530 001406          BEQ     40$             ;BR. IF EQUAL (OK)
6196 034532 004737 020116      JSR      PC,FATCH#       ;INC AND CHECK FOR MORE THAN 25 ERRORS
6200 034536          ERRHRD  ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      034536 104456                                TRAP      C#ERHRD
      034540 000352                                .WORD    234
      034542 047125                                .WORD    T26BOT
      034544 016360                                .WORD    EXPREC
6201 034546          40$:  CKLOOP                ;LOOP IF SELECTED
      034546 104406                                TRAP      C#CLP1
6202 034550 012703 000400      MOV     #256.,R3        ;RECORD SIZE
6203 034554 013737 003072 046062  MOV     FREE,T26RB       ;STARTING WRITE BUFFER ADDRESS
6204
6205 ;*****
6206 ;
6207 ;WRITE DATA,CVC=1,ACK COMMAND
6208 ;
6209 ;*****
6210
6211 034562 012737 140005 046060  MOV     #140005,T26PK3   ;WRITE DATA,CVC=1,ACK COMMAND
6212 034570 012704 046060      MOV     #T26PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
6213 034574
6214 034574 010300          65$:  MOV     R3,R0         ;SET PATTERN IN CORRECT REGISTER
6215 034576 004737 020410      JSR     PC,FILLMEM       ;FILL MEMORY WITH RECORD SIZE
6216 034602 010337 046066      MOV     R3,T26SZ        ;SET UP RECORD SIZE IN PACKET

```

```

6217 034606 013777 046106 146256      MOV    T26CNT,0FREE      ;MOVE TAPE RECORD NUMBER TO BUFFER
6218 034614 062737 000001 046106      ADD    #1,T26CNT        ;NUMBER READY FOR NEXT RECORD
6219 034622 010465 177776      MOV    R4,1SDB(R5)     ;ISSUE COMMAND
6220 034626 004737 017134      JSR    PC,WAITF        ;WAIT FOR SSR TO SET
6221 034632 016501 000000      MOV    TSSR(R5),R1     ;GET TSSR CONTENTS
6222 034636 012702 000200      MOV    #SSR,R2        ;SET UP EXPECTED
6223 034642 020102      CMP    R1,R2          ;ARE THEY EQUAL
6224 034644 001406      BEQ    75$            ;BR, IF OK
6225 034646 004737 020116      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
6229      ;SOFT ERROR GENERATED BECAUSE THE
6230      ;WRITE COMMAND IS NOT BEING CHECKED
6231      ;HERE. IT WAS CHECKED IN LEAH2
6232 034652      ERRSOFT ERRNO,WRTErr,PKTSSR ;TSSR INCORRECT AFTER REREAD DATA
        034652 104457      TRAP   C$ERSOFT
        034654 000353      .WORD 235
        034656 005011      .WORD WRTErr
        034660 011710      .WORD PKTSSR
6233 034662 104406 75$: CKLOOP      ;LOOP IF SELECTED
        034662 104406      TRAP   C$CLP1
6234 034664 005723      TST    (R3)+          ;BUMP THE RECORD SIZE
6235 034666 022703 000412      CMP    #266.,R3      ;MAXIMUM SIZE YET
6236 034672 001401      BEQ    120$          ;BR, IF AT END OF WRITE SEQUENCE
6237 034674 000737      BR     65$            ;WRITE MORE RECORDS
6238 034676
6239 034676 005037 046106 120$: CLR    T26CNT      ;SET RECORD COUNTER BACK TO ZERO
6240
6241      ;*****
6242      ;
6243      ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
6244      ;
6245      ;*****
6246
6247 034702 004737 010444      JSR    PC,REWIND      ;CALL TAPE REWIND COMMAND
6248 034706 103413      BCS    130$          ;BR, IF NO PROBLEM
6249 034710 016501 000000      MOV    TSSR(R5),R1     ;GET TSSR
6250 034714 012702 000200      MOV    #SSR,R2        ;SET UP EXPECTED TSSR
6251 034720 010004      MOV    R0,R4          ;PACKET ADDRESS SET UP
6252 034722 004737 020116      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
6256 034726      ERRHRD ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
        034726 104456      TRAP   C$ERHRD
        034730 000354      .WORD 236
        034732 047414      .WORD T26RWN
        034734 011710      .WORD PKTSSR
6257 034736 104406 130$: CKLOOP      ;LOOP IF SELECTED
        034736 104406      TRAP   C$CLP1
6258
6259      ;*****
6260      ;
6261      ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
6262      ;
6263      ;*****
6264
6265 034740 013701 045756      MOV    T26BFR+6,R1     ;PICK UP XSTO
6266 034744 010102      MOV    R1,R2          ;SET UP EXPECTED
6267 034746 052702 000002      BIS    #BIT1,R2       ;SET BOT BIT IN EXPECTED
6268 034752 020102      CMP    R1,R2          ;DOES EXP = REC'D
6269 034754 001406      BEQ    140$          ;BR, IF EQUAL (OK)

```

```

6270 034756 004737 020116      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
6274 034762      ERRHRD  ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      034762 104456      TRAP    C$ERHRD
      034764 000355      .WORD  237
      034766 047125      .WORD  T26BOT
      034770 016360      .WORD  EXPREC
6275 034772      140$:  CKLOOP      ;LOOP IF SELECTED
      034772 104406      TRAP    C$CLP1
6276
6277      ;*****
6278      ;
6279      ;ISSUE SPACE RECORDS COMMAND - VALUE IN R3 SETS NUMBER OF RECORDS
6280      ;BIT 15 SETS DIRECTION - 0=FORWARD 1=REVERSE
6281      ;
6282      ;*****
6283
6284 034774 012703 000001      MOV    #1,R3          ;SET UP SPACE FORWARD 1
6285 035000 004737 010144      JSR    PC,SPACE      ;ISSUE SPACE COMMAND
6286 035004 012703 000400      MOV    #256.,R3     ;RECORD SIZE
6287 035010 013737 003072 046062 150$:  MOV    FREE,T26RB    ;STARTING READ BUFFER ADDRESS
6288
6289      ;*****
6290      ;
6291      ;REREAD DATA,CVC=1,ACK, OPP COMMAND
6292      ;
6293      ;*****
6294
6295 035016 012737 171001 046060 165$:  MOV    #171001,T26PK3 ;REREAD DATA,CVC=1,ACK, OPP COMMAND
6296 035024 012704 046060      MOV    #T26PK3,R4   ;SET UP R4 WITH PACKET ADDRESS
6297 035030 010337 046066      MOV    R3,T26SZ     ;SET UP RECORD SIZE IN PACKET
6298 035034 010465 177776      MOV    R4,TSDB(R5)  ;ISSUE COMMAND
6299 035040 004737 017134      JSR    PC,HAITF     ;WAIT FOR SSR TO SET
6300 035044 016501 000000      MOV    TSSR(R5),R1  ;GET TSSR CONTENTS
6301 035050 012702 000200      MOV    #SSR,R2      ;SET UP EXPECTED
6302 035054 020102      CMP    R1,R2        ;ARE THEY EQUAL
6303 035056 001406      BEQ   170$         ;BR, IF OK
6304 035060 004737 020116      JSR    PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
6308 035064      ERRHRD  ERRNO,T26RRF,PKTSSR ;TSSR INCORRECT AFTER REREAD DATA
      035064 104456      TRAP    C$ERHRD
      035066 000356      .WORD  238
      035070 046335      .WORD  T26RRF
      035072 011710      .WORD  PKTSSR
6309 035074      170$:  CKLOOP      ;LOOP IF SELECTED
      035074 104406      TRAP    C$CLP1
6310 035076 017701 145770      MOV    #FREE,R1     ;FIRST WORD FROM READ BUFFER
6311 035102 015702 046106      MOV    T26CNT,R2    ;SET UP EXPECTED
6312 035106 000302      SWAB   R2           ;SWAP BYTES IN EXPECTED
6313 035110 020102      CMP    R1,R2        ;IS TAPE POSITION CORRECT
6314 035112 001406      BEQ   190$         ;KEEP GOING POSITION OK
6315 035114 004737 020116      JSR    PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
6319 035120      ERRHRD  ERRNO,T26WNG,EXPREC ;TAPE POSITION INCORRECT
      035120 104456      TRAP    C$ERHRD
      035122 000357      .WORD  239
      035124 046116      .WORD  T26WNG
      035126 016360      .WORD  EXPREC
6320 035130      190$:  CKLOOP
      035130 104406      TRAP    C$CLP1

```

```

6321 035132 005723          TST      (R3),           ;NEXT RECORD SIZE
6322 035134 062737 000001 046106  ADD      @1,T26CNT       ;BUMP TAPE RECORD COUNTER
6323
6324
6325          ;*****
6326          ;READ DATA, CVC=1, ACK COMMAND
6327          ;
6328          ;*****
6329
6330 035142 012737 140001 046060  MOV      @140001,T26PK3   ;READ DATA, CVC=1, ACK COMMAND
6331 035150 010337 046056          MOV      R3,T26SZ         ;SET SIZE INTO PACKET
6332 035154 010465 177776          MOV      R4,TSDB(R5)     ;ISSUE READ DATA COMMAND
6333 035160 004737 017134          JSR      PC,WAITF        ;WAIT FOR SSR
6334 035164 015501 000000          MOV      TSSR(R5),R1    ;PICK UP THE TSSR
6335 035170 012702 000200          MOV      @SSR,R2        ;SET UP EXPECTED
6336 035174 020102          CMP      R1,R2           ;IS THE TSSR OK
6337 035176 001406          BEQ      215$           ;BR, IF TSSR OK (GOOD)
6338 035200 004737 020116          JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
6342 035204 104456          ERRHRD  ERRND,T26RDF,PKTSSR ;READ DATA COMMAND FAILED
           035204 104456          TRAP    C$ERHRD
           035206 000360          .WORD  240
           035210 046266          .WORD  T26RDF
           035212 011710          .WORD  PKTSSR
6343 035214 104406          215$:  CKLOOP          ;LOOP IF SELECTED
           035214 104406          TRAP    C$CLP1
6344 035216 017701 145650          MOV      @FREE,R1        ;FIRST WORD FROM READ BUFFER
6345 035222 013702 046106          MOV      T26CNT,R2      ;SET UP EXPECTED
6346 035226 020102          CMP      R1,R2           ;IS TAPE POSITION CORRECT
6347 035230 001406          BEQ      217$           ;KEEP GOING POSITION OK
6348 035232 004737 020116          JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
6352 035236 104456          ERRHRD  ERRND,T26WNG,EXPREC ;TAPE POSITION INCORRECT
           035236 104456          TRAP    C$ERHRD
           035240 000361          .WORD  241
           035242 046116          .WORD  T26WNG
           035244 016360          .WORD  EXPREC
6353 035246 104406          217$:  CKLOOP          ;LOOP IF SELECTED
           035246 104406          TRAP    C$CLP1
6354 035250 022703 000410          CMP      @264.,R3        ;AT MAX SIZE YET
6355 035254 001401          BEQ      220$           ;BR, IF AT END OF THE SUBTEST
6356 035256 000654          BR       150$           ;KEEP GOING MORE RECORDS
6357 035260
6358 035260          ENDSUB              ;>>>>>>>>>> END SUBTEST >>>>>>>>>>>>>
           035260 104403          L10052:
           035260 023727 002170 000031  CMP      FATELG,@25,     ;IS ERROR COUNT AT 25
           035270 002402          BLT     999$           ;BR, IF LESS THAN 25
6361 035272 004737 020170          JSR      PC,CKDRUP      ;TRY TO DROP THE UNIT
6362 035276          999$:

```



```

6364
6365
6366
6367
6368
6369
6370
6371
6372
6373
6374
6375
6376
6377
6378
6379 035276      BGNSUB                    ;>>>>>>>>>> BEGIN SUBTEST >>>>>>>>>>
      035276      T2.5:
      035276 104402      TRAP          C#BSUB
6380 035300 004737 050650      JSR      PC,T26REST      ;SET COMMAND PACKET
6381 035304 004737 050742      JSR      PC,T26RT2      ;SET UP OTHER COMMAND PACK. T
6382 035310 004737 051004      JSR      PC,T26RT3      ;SET UP OTHER COMMAND PACKET
6383
6384 ;*****
6385 ;
6386 ;ISSUE CONTROLLER "SOFT" INITIALIZE - CARRY BIT CLEAR IF ERROR
6387 ;
6388 ;*****
6389
6390 035314 004737 016660      JSR      PC,SOFINIT      ;DO INITIALIZE ON CONTROLLER
6391 035320 103407      BCS     20$              ;BR IF INIT WAS OK
6392 035322 004737 020116      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
6396 035326 010001      MOV     R0,R1            ;CONTENTS OF TSSR REGISTER
6397 035330      ERRDF  ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
      035330 104455      TRAP          C#ERRDF
      035332 000362      .WORD       242
      035334 003550      .WORD       SFIERR
      035336 011676      .WORD       SFIMSG
6398 035340      20$:
6399
6400 035340 012704 045730      MOV     #T26PACKET,R4   ;SUBROUTINE NEEDS PACKET ADDRESS
6401
6402 ;*****
6403 ;
6404 ;WRITE CHARACTERISTICS COMMAND (CALL TO WRTCHR)
6405 ;
6406 ;*****
6407
6408 035344 004737 010342      JSR      PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
6409 035350 103407      BCS     26$              ;BR, IF COMMAND ISSUED OK
6410 035352 004737 020116      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
6414 035356 010001      MOV     R0,R1            ;SAVE CONTENTS OF TSSR
6415 035360      ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
      035360 104456      TRAP          C#ERRHRD
      035362 000363      .WORD       243
      035364 004754      .WORD       WRTMSG
      035366 011676      .WORD       SFIMSG
6416 035370      26$:      CKLUOP                    ;LOOP IF SELECTED
  
```

```

035370 104406
6417
6418
6419
6420
6421
6422
6423
6424 035372 004737 010444 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
6425 035376 103413 BCS 301 ;BR, IF NO PROBLEM
6426 035400 016501 000000 MOV TSSR(R5),R1 ;GET TSSR
6427 035404 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED TSSR
6428 035410 010004 MOV R0,R4 ;PACKET ADDRESS SET UP
6429 035412 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
6433 035416 ERRHRD ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
035416 104456 TRAP C#ERHRD
035420 000364 .WORD 244
035422 047414 .WORD T26RWN
035424 011710 .WORD PKTSSR
6434 035426 300: CKLOOP ;LOOP IF SELECTED
035426 104406 TRAP C#CLP1
6435
6436
6437
6438
6439
6440
6441
6442 035430 013701 045756 MOV T26BFR+6,R1 ;PICK UP XSTO
6443 035434 010102 MOV R1,R2 ;SET UP EXPECTED
6444 035436 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
6445 035442 020102 CMP R1,R2 ;DOES EXP = REC'D
6446 035444 001406 BEQ 401 ;BR, IF EQUAL (OK)
6447 035446 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
6451 035452 ERRHRD ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
035452 104456 TRAP C#ERHRD
035454 000365 .WORD 245
035456 047125 .WORD T26BOT
035460 016360 .WORD EXPREC
6452 035462 400: CKLOOP ;LOOP IF SELECTED
035462 104406 TRAP C#CLP1
6453 035464 012703 001000 MOV #512,R3 ;RECORD SIZE
6454 035470 013737 003072 046062 MOV FREE,T26RB ;STARTING WRITE BUFFER ADDRESS
6455
6456
6457
6458
6459
6460
6461
6462 035476 012737 140005 046060 MOV #140005,T26PK3 ;WRITE DATA,CVC=1,ACK COMMAND
6463 035504 012704 046060 MOV #T26PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
6464 035510
6465 035510 010357 046066 MOV R3,T26SZ ;SET UP RECORD SIZE IN PACKET
6466 035514 010465 177776 MOV R4,TSDB(R5) ;ISSUE COMMAND
6467 035520 004737 017134 JSR PC,WAITF ;WAIT FOR SSR TO SET
6468 035524 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS

```

```

6469 035530 012702 000200      MOV      #SSR,R2      ;SET UP EXPECTED
6470 035534 020102      CMP      R1,R2      ;ARE THEY EQUAL
6471 035536 001406      BEQ      751        ;BR, IF OK
6472 035540 004737 020116      JSR      PC,FATCHK  ;INC AND CHECK FOR MORE THAN 25 ERRORS
6476                                ;SOFT ERROR GENERATED BECAUSE THE
6477                                ;WRITE COMMAND IS NOT BEING CHECKED
6478                                ;HERE, IT WAS CHECKED IN LEAH2
6479 035544                                ERRSOFT ERRNO,WRTERR,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP      C#ERSOFT
                                .WORD    246
                                .WORD    WRTERR
                                .WORD    PKTSSR
                                TRAP      C#CLP1
                                .WORD    247
                                .WORD    T26TRL
                                .WORD    PKTSSR
6480 035554 751:      CKLOOP      ;LOOP IF SELECTED
                                TRAP      C#CLP1
                                .WORD    247
                                .WORD    T26TRL
                                .WORD    PKTSSR
6481 035556 005303      DEC      R3          ;SET RECORD SIZE TO 511.
6482 035560 013737 003072 046062      MOV      FREE,T26RB  ;STARTING READ BUFFER ADDRESS
6483
6484 ;*****
6485 ;
6486 ;REREAD DATA,CVC-1,ACK,OPP-1 COMMAND
6487 ;
6488 ;*****
6489
6490 035566 012737 161001 046060      MOV      #161001,T26PK3 ;REREAD DATA,CVC-1,ACK,OPP-1 COMMAND
6491 035574 012704 046060      1651:   MOV      #T26PK3,R4   ;SET UP R4 WITH PACKET ADDRESS
6492 035600 010337 046066      MOV      R3,T26SZ    ;SET UP RECORD SIZE IN PACKET
6493 035604 010465 177776      MOV      R4,TSD8(R5) ;ISSUE COMMAND
6494 035610 004737 017134      JSR      PC,WAITF    ;WAIT FOR SSR TO SET
6495 035614 016501 000000      MOV      TSSR(R5),R1 ;GET TSSR CONTENTS
6496 035620 012702 100204      MOV      #SSR!SC!BIT2,R2 ;SET UP EXPECTED
6497 035624 020102      CMP      R1,R2      ;ARE THEY EQUAL
6498 035626 001406      BEQ      1701       ;BR, IF OK
6499 035630 004737 020116      JSR      PC,FATCHK  ;INC AND CHECK FOR MORE THAN 25 ERRORS
6503 035634      ERRMRD  ERRNO,T26TRL,PKTSSR ;TSSR INCORRECT AFTER REREAD DATA
                                TRAP      C#ERRMRD
                                .WORD    247
                                .WORD    T26TRL
                                .WORD    PKTSSR
6504 035644 1701:   CKLOOP      ;LOOP IF SELECTED
                                TRAP      C#CLP1
                                .WORD    247
                                .WORD    T26TRL
                                .WORD    PKTSSR
6505
6506 ;*****
6507 ;
6508 ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XST0)
6509 ;
6510 ;*****
6511
6512 035646 013701 045756      MOV      T26BFR+6,R1 ;GET MESSAGE BUFFER
6513 035652 010102      MOV      R1,R2      ;SET UP EXPECTED
6514 035654 052702 010000      BIS      #BIT112,R2  ;SET THE RLL BIT IN EXPECTED
6515 035660 020102      CMP      R1,R2      ;ARE THEY EQUAL
6516 035662 001406      BEQ      1801       ;BR, IF EQUAL (ALL IS WELL)
6517 035664 004737 020116      JSR      PC,FATCHK  ;INC AND CHECK FOR MORE THAN 25 ERRORS
6521 035670      ERRMRD  ERRNO,T26LUN,EXPREC ;THE RLL BIT WAS NOT SET IN XST0
                                TRAP      C#ERRMRD
                                .WORD    248
                                .WORD    T26LUN

```

D14

CZKGA, TK-25, FBI END FUNC #3
TEST 2: REREADS

MACRO M1200 20-APR-84 08:13 PAGE 101-3

SEQ 172

```

    035676 016360
6522 035700 1801: CKLOOP                      ;LOOP IF SELECTED          .WORD   EXPREC
    035700 104406                               ;                          TRAP     C#CLP1
6523 035702 012703 000777                   MOV     #511.,R3          ;SET RECORD SIZE
6524 035706 013737 003072 046062           MOV     FREE,T26RB        ;STARTING READ BUFFER ADDRESS
6525
6526                                         ;*****
6527                                         ;
6528                                         ;REREAD DATA,CVC-1,ACK COMMAND
6529                                         ;
6530                                         ;*****
6531
6532 035714 012737 141001 046060           MOV     #141001,T26PK3    ;REREAD DATA,CVC-1,ACK COMMAND
6533 035722 012704 046060 3651: MOV     #T26PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
6534 035726 010537 046066                   MOV     R3,T26SZ         ;SET UP RECORD SIZE IN PACKET
6535 035732 010465 177776                   MOV     R4,T26DB(R5)    ;ISSUE COMMAND
6536 035736 004737 017134                   JSR     PC,WAITF         ;WAIT FOR SSR TO SET
6537 035742 016501 000000                   MOV     TSSR(R5),R1     ;GET TSSR CONTENTS
6538 035746 012702 100204                   MOV     #SSR!SC!BIT2,R2 ;SET UP EXPECTED
6539 035752 020102                           CMP     R1,R2           ;ARE THEY EQUAL
6540 035754 001406                           BEQ     3701            ;BR, IF OK
6541 035756 004737 020116                   JSR     PC,FATCHK       ;INC AND CHECK FOR MORE THAN 25 ERRORS
6545 035762 ERRHRD ERRNO,T26TRL,PKTSSR     ;TSSR INCORRECT AFTER REREAD DATA
    035762 104456                               TRAP   C#ERHRD
    035764 000371                               .WORD 249
    035766 050472                               .WORD T26TRL
    035770 011710                               .WORD PKTSSR
6546 035772 3701: CKLOOP                      ;LOOP IF SELECTED          .WORD   EXPREC
    035772 104406                               ;                          TRAP     C#CLP1
6547
6548                                         ;*****
6549                                         ;
6550                                         ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XST0)
6551                                         ;
6552                                         ;*****
6553
6554 035774 013701 045756                   MOV     T26BFR+6,R1     ;GET MESSAGE BUFFER
6555 036000 010102                           MOV     R1,R2           ;SET UP EXPECTED
6556 036002 052702 010000                   BIS     #BIT12,R2       ;SET THE RLL BIT IN EXPECTED
6557 036006 020102                           CMP     R1,R2           ;ARE THEY EQUAL
6558 036010 001406                           BEQ     3801            ;BR, IF EQUAL (ALL IS WELL)
6559 036012 004737 020116                   JSR     PC,FATCHK       ;INC AND CHECK FOR MORE THAN 25 ERRORS
6563 036016 ERRHRD ERRNO,T26LON,EXPREC     ;THE RLL BIT WAS NOT SET IN XST0
    036016 104456                               TRAP   C#ERHRD
    036020 000372                               .WORD 250
    036022 050240                               .WORD T26LON
    036024 016360                               .WORD EXPREC
6564 036026 3801:
6565 036026 ENDSUB                          ;>>>>>>>>>> END SUBTEST >>>>>>>>
    036026 104403                               L10053:
6566 036030 023727 002170 000031           CMP     FATFLG,#25      ;IS ERROR COUNT AT 25
6567 036036 002402                           BLT    9991            ;BR, IF LESS THAN 25
6568 036040 004737 020170                   JSR     PC,CKDROP      ;TRY TO DROP THE UNIT
6569 036044 9991:

```

```

6571
6572
6573
6574
6575
6576
6577
6578
6579
6580
6581
6582
6583
6584
6585
6586
6587
6588 036044          ;
      036044          ;
      036044 104402   ;
6589 036046 004737 050650   JSR      PC,T26REST      ;SET COMMAND PACKET
6590 036052 004737 050742   JSR      PC,T26RT2       ;SET UP OTHER COMMAND PACKET
6591 036056 004737 051004   JSR      PC,T26RT3       ;SET UP OTHER COMMAND PACKET
6592
6593
6594
6595
6596
6597
6598
6599 036062 004737 016660   JSR      PC,SOFINIT      ;DO INITIALIZE ON CONTROLLER
6600 036066 103407          BCS      20$             ;BR IF INIT WAS OK
6601 036070 004737 020116   JSR      PC,FATCHK       ;INC AND CHECK FOR MORE THAN 25 ERRORS
6605 036074 010001          MOV      R0,R1           ;CONTENTS OF TSSR REGISTER
6606 036076 104455          ERRDF    ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
      036100 000373          .TRAP    C1ERRDF        ;
      036102 003550          .WORD   251            ;
      036104 011676          .WORD   SFIERR         ;
6607 036106          .WORD   SFIMSG         ;
6608
6609 036106 012704 045730   MOV      @T26PACKET,R4   ;SUBROUTINE NEEDS PACKET ADDRESS
6610
6611
6612
6613
6614
6615
6616
6617 036112 004737 010342   JSR      PC,WRTCHR       ;ISSUE WRITE CHARACTERISTICS
6618 036116 103407          BCS      26$             ;BR, IF COMMAND ISSUED OK
6619 036120 004737 020116   JSR      PC,FATCHK       ;INC AND CHECK FOR MORE THAN 25 ERRORS
6623 036124 010001          MOV      R0,R1           ;SAVE CONTENTS OF TSSR
6624 036126 104456          ERRHRD   ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
      036130 000374          .TRAP    C1ERRRD        ;
      036132 004754          .WORD   252            ;
                                     .WORD   WRTMSG         ;

```

```

;
;TEST 2, SUBTEST 6
;
;VERIFIES THAT A REREAD PREVIOUS COMMAND READING A
;RECORD SHORTER THAN THE SPECIFIED BYTE COUNT CAUSES
;TAPE STATUS ALERT TERMINATION WITH THE RECORD LENGTH
;SHORT (RLS) BIT SET. IT IS VERIFIED THAT THE
;RESIDUAL BYTE COUNTER (RBPGR) IN THE MESSAGE BUFFER
;CONTAINS THE PROPER NONZERO VALUE (E.G., THE
;DIFFERENCE BETWEEN THE ORIGINAL BYTE COUNT AND THE
;ACTUAL RECORD LENGTH). RESULTS ARE VERIFIED FOR BOTH
;STATES OF OPP (0 AND 1).
;
;
;
;
;

```

```

;-----
;
;-----
;
;

```

```

;*****
;
;ISSUE CONTROLLER "SOFT" INITIALIZE - CARRY BIT CLEAR IF ERROR
;
;*****

```

```

;*****
;
;*****
;
;

```

```

;*****
;
;WRITE CHARACTERISTICS COMMAND (CALL TO WRTCHR)
;
;*****

```

```

;*****
;
;*****
;
;

```

```

        036134 011676
6625 036136          26$:  CKLOOP                ;LOOP IF SELECTED          .WORD  SFIMSG
        036136 104406                                TRAP  C#CLP1
6626
6627 ;*****
6628 ;
6629 ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
6630 ;
6631 ;*****
6632
6633 036140 004737 010444          JSR    PC,REWIND)          ;CALL TAPE REWIND COMMAND
6634 036144 103413          BCS    30$                ;BR, IF NO PROBLEM
6635 036146 016501 000000          MOV    TSSR(R5),R1        ;GET TSSR
6636 036152 012702 000200          MOV    #SSR,R2           ;SET UP EXPECTED TSSR
6637 036156 010004          MOV    R0,R4             ;PACKET ADDRESS SET UP
6638 036160 004737 020116          JSR    PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
6642 036164          ERRHRD  ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
        036164 104456                                TRAP  C#ERHRD
        036166 000375                                .WORD 253
        036170 047414                                .WORD T26RWN
        036172 011710                                .WORD PKTSSR
6643 036174          30$:  CKLOOP                ;LOOP IF SELECTED          .WORD  SFIMSG
        036174 104406                                TRAP  C#CLP1
6644
6645 ;*****
6646 ;
6647 ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
6648 ;
6649 ;*****
6650
6651 036176 013701 045756          MOV    T26BFR+6,R1        ;PICK UP XSTO
6652 036202 010102          MOV    R1,R2             ;SET UP EXPECTED
6653 036204 052702 000002          BIS    #BIT1,R2          ;SET BOT BIT IN EXPECTED
6654 036210 020102          CMP    R1,R2             ;DOES EXP = REC'D
6655 036212 001406          BEQ    40$                ;BR, IF EQUAL (OK)
6656 036214 004737 020116          JSR    PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
6660 036220          ERRHRD  ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
        036220 104456                                TRAP  C#ERHRD
        036222 000376                                .WORD 254
        036224 047125                                .WORD T26BOT
        036226 016360                                .WORD EXPREC
6661 036230          40$:  CKLOOP                ;LOOP IF SELECTED          .WORD  SFIMSG
        036230 104406                                TRAP  C#CLP1
6662 036232 012703 000400          MOV    #256.,R3          ;RECORD SIZE
6663 036236 013737 003072 046062  MOV    FREE,T26RB        ;STARTING WRITE BUFFER ADDRESS
6664
6665 ;*****
6666 ;
6667 ;WRITE DATA,CVC=1,ACK COMMAND
6668 ;
6669 ;*****
6670
6671 036244 012737 140005 046060  MOV    #140005,T26PK3    ;WRITE DATA,CVC=1,ACK COMMAND
6672 036252 012704 046060  MOV    #T26PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
6673 036256
6674 036256 010337 046066  65$:  MOV    R3,T26SZ        ;SET UP RECORD SIZE IN PACKET
6675 036262 010465 177776  MOV    R4,T5DB(R5)       ;ISSUE COMMAND

```

```

6676 036266 004737 017134 JSR PC,WAITF ;WAIT FOR SSR TO SET
6677 036272 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
6678 036276 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
6679 036302 020102 CMP R1,R2 ;ARE THEY EQUAL
6680 036304 001406 BEQ 75# ;BR, IF OK
6681 036306 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
6685 ;SOFT ERROR GENERATED BECAUSE THE
6686 ;WRITE COMMAND IS NOT BEING CHECKED
6687 ;HERE, IT WAS CHECKED IN LEAH2
6688 036312 ERRSOFT ERRNO,WRTErr,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
        036312 104457 TRAP C#ERSOFT
        036314 000377 .WORD 255
        036316 005011 .WORD WRTErr
        036320 011710 .WORD PKTSSR
6689 036322 75#; CKLOOP ;LOOP IF SELECTED TRAP C#CLP1
        036322 104406
6690 036324 012703 001000 MOV #512,R3 ;RECORD SIZE
6691 036330 013737 003072 046062 MOV FREE,T26R8 ;STARTING READ BUFFER ADDRESS
6692
6693 ;*****
6694 ;
6695 ;REREAD PREVIOUS,ACK,CVC=1,OPP=1
6696 ;
6697 ;*****
6698
6699 036336 012737 161001 046060 MOV #161001,T26PK3 ;REREAD PREVIOUS,ACK,CVC=1,OPP=1
6700 036344 012704 046060 165#; MOV #T26PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
6701 036350 010337 046066 MOV R3,T26SZ ;SET UP RECORD SIZE IN PACKET
6702 036354 010465 177776 MOV R4,TSD8(R5) ;ISSUE COMMAND
6703 036360 004737 017134 JSR PC,WAITF ;WAIT FOR SSR TO SET
6704 036364 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
6705 036370 012702 100204 MOV #SSR!SC!BIT2,R2 ;SET UP EXPECTED
6706 036374 020102 CMP R1,R2 ;ARE THEY EQUAL
6707 036376 001406 BEQ 170# ;BR, IF OK
6708 036400 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
6712 036404 ERRHRD ERRNO,T26TRL,PKTSSR ;TSSR INCORRECT AFTER READ DATA
        036404 104456 TRAP C#ERHRD
        036406 000400 .WORD 256
        036410 050472 .WORD T26TRL
        036412 011710 .WORD PKTSSR
6713 036414 170#; CKLOOP ;LOOP IF SELECTED TRAP C#CLP1
        036414 104406
6714
6715 ;*****
6716 ;
6717 ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
6718 ;
6719 ;*****
6720
6721 036416 013701 045756 MOV T26BFR+6,R1 ;GET MESSAGE BUFFER
6722 036422 010102 MOV R1,R2 ;SET UP EXPECTED
6723 036424 052702 040000 BIS #BIT14,R2 ;SET THE RLS BIT IN EXPECTED
6724 036430 020102 CMP R1,R2 ;ARE THEY EQUAL
6725 036432 001406 BEQ 180# ;BR, IF EQUAL (ALL IS WELL)
6726 036434 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
6730 036440 ERRHRD ERRNO,T26L0P,EXPREC ;THE RLL BIT WAS NOT SET IN XSTO
        036440 104456 TRAP C#ERHRD

```

```

036442 000401
036444 050322
036446 016360
6731 036450 180$:
6732 036450 013701 045754 MOV T26BFR+4,R1 ;PICK UP RESIDUAL BYTE COUNTER
6733 036454 012702 000400 MOV #256.,R2 ;THIS SHOULD BE THE DIFFERENCE
6734 036460 020102 CMP R1,R2 ;IS THE DIFFERENCE CORRECT
6735 036462 001406 BEQ 190$ ;BR. IF CORRECT
6736 036464 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
6740 036470 ERRHRD ERRNO,T26PBP,EXPREC ;RBPOR NOT CORRECT
036470 104456 TRAP C#ERHRD
036472 000402 .WORD 258
036474 050404 .WORD T26PBP
036476 016360 .WORD EXPREC
6741 036500 190$: CKLOOP ;LOOP IF SELECTED TRAP C#CLP1
036500 104406
6742 036502 012703 001000 MOV #512.,R3 ;RECORD SIZE
6743 036506 013737 003072 046062 MOV FREE,T26RB ;STARTING READ BUFFER ADDRESS
6744
6745 ;*****
6746 ;
6747 ;REREAD PREVIOUS,ACK,CVC=1,OPP=0
6748 ;
6749 ;*****
6750
6751 036514 012737 141001 046060 MOV #141001,T26PK3 ;REREAD PREVIOUS,ACK,CVC=1,OPP=0
6752 036522 012704 046060 MOV #T26PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
6753 036526 010337 046066 MOV R3,T26SZ ;SET UP RECORD SIZE IN PACKET
6754 036532 010465 177776 MOV R4,TSD8(R5) ;ISSUE COMMAND
6755 036536 004737 017134 JSR PC,WAITF ;WAIT FOR SSR TO SET
6756 036542 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
6757 036546 012702 100204 MOV #SSR!SC!BIT2,R2 ;SET UP EXPECTED
6758 036552 020102 CMP R1,R2 ;ARE THEY EQUAL
6759 036554 001406 BEQ 270$ ;BR. IF OK
6760 036556 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
6764 036562 ERRHRD ERRNO,T26TRL,PKTSSR ;TSSR INCORRECT AFTER READ DATA
036562 104456 TRAP C#ERHRD
036564 000403 .WORD 259
036566 050472 .WORD T26TRL
036570 011710 .WORD PKTSSR
6765 036572 270$: CKLOOP ;LOOP IF SELECTED TRAP C#CLP1
036572 104406
6766
6767 ;*****
6768 ;
6769 ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
6770 ;
6771 ;*****
6772
6773 036574 013701 045756 MOV T26BFR+6,R1 ;GET MESSAGE BUFFER
6774 036600 010102 MOV R1,R2 ;SET UP EXPECTED
6775 036602 052702 040000 BIS #BIT14,R2 ;SET THE RLS BIT IN EXPECTED
6776 036606 020102 CMP R1,R2 ;ARE THEY EQUAL
6777 036610 001406 BEQ 280$ ;BR. IF EQUAL (ALL IS WELL)
6778 036612 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
6782 036616 ERRHRD ERRNO,T26LOP,EXPREC ;THE RLL BIT WAS NOT SET IN XSTO
036616 104456 TRAP C#ERHRD

```


J14

```

6799
6800
6801
6802
6803
6804
6805
6806
6807
6808
6809
6810
6811
6812
6813
6814
6815
6816
6817
6818
6819 036674           BGNSUB                   ;>>>>>>>>>>>> BEGIN SUBTEST >>>>>>>>>>>>
        036674           ;
        036674 104402           T2.7:
6820 036676 004737 050650         JSR     PC,T26REST           ;SET COMMAND PACKET      TRAP    C#BSUB
6821 036702 004737 050742         JSR     PC,T26RT2           ;SET UP OTHER COMMAND PACKET
6822 036706 004737 051004         JSR     PC,T26RY3           ;SET UP OTHER COMMAND PACKET
6823
6824
6825
6826
6827
6828
6829
6830 036712 004737 016660         JSR     PC,SOFINIT           ;DO INITIALIZE ON CONTROLLER
6831 036716 103407                   BCS     20$                   ;BR IF INIT WAS OK
6832 036720 004737 020116         JSR     PC,FATCHK           ;INC AND CHECK FOR MORE THAN 25 ERRORS
6833 036724 010001                   MOV     R0,R1                 ;CONTENTS OF TSSR REGISTER
6834 036726 104455                   ERRRDF ERRNO,SFIERR,SFIMSG    ;FATAL ERROR TSSR WAS NOT OK
        036730 000405                   ;
        036732 003550                   ;
        036734 011676                   ;
6838 036736                   20$:                           TRAP    C#ERDF
6839
6840 036736 012704 045730         MOV     #T26PACKET,R4       ;SUBROUTINE NEEDS PACKET ADDRESS
6841
6842
6843
6844
6845
6846
6847
6848 036742 004737 010342         JSR     PC,WRTCHR           ;ISSUE WRITE CHARACTERISTICS
6849 036746 103407                   BCS     26$                   ;BR, IF COMMAND ISSUED OK
6850 036750 004737 020116         JSR     PC,FATCHK           ;INC AND CHECK FOR MORE THAN 25 ERRORS
6851 036754 010001                   MOV     R0,R1                 ;SAVE CONTENTS OF TSSR
6852 036756                   ERRHRD ERRNO,WRTMSG,SFIMSG    ;WRITE CHARACTERISTICSC FAILED

```

```

036756 104456
036760 000406
036762 004754
036764 011676
6856 036766 104406 26$: CKLOOP ;LOOP IF SELECTED TRAP C$ERHRD
036766 104406 ;.WORD 262
; .WORD WRTMSG
; .WORD SFIMSG
6857 TRAP C$CLP1
6858 ;*****
6859 ;
6860 ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
6861 ;
6862 ;*****
6863
6864 036770 004737 010444 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
6865 036774 103413 BCS 30$ ;BR, IF NO PROBLEM
6866 036776 016501 000000 MOV TSSR(R5),R1 ;GET TSSR
6867 037002 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED TSSR
6868 037006 010004 MOV R0,R4 ;PACKET ADDRESS SET UP
6869 037010 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
6873 037014 ERRHRD ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
037014 104456 TRAP C$ERHRD
037016 000407 ;.WORD 263
037020 047414 ;.WORD T26RWN
037022 011710 ;.WORD PKTSSR
6874 037024 104406 30$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
037024 104406 ;*****
6875 ;
6876 ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
6877 ;
6878 ;*****
6879 ;
6880 ;*****
6881
6882 037026 013701 045756 MOV T26BFR+6,R1 ;PICK UP XSTO
6883 037032 010102 MOV R1,R2 ;SET UP EXPECTED
6884 037034 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
6885 037040 020102 CMP R1,R2 ;DOES EXP = REC'D
6886 037042 001406 BEQ 40$ ;BR, IF EQUAL (OK)
6887 037044 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
6891 037050 ERRHRD ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
037050 104456 TRAP C$ERHRD
037052 000410 ;.WORD 264
037054 047125 ;.WORD T26BOT
037056 016360 ;.WORD EXPREC
6892 037060 104406 40$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
037060 104406 ;RECORD SIZE
6893 037062 012703 000400 MOV #256.,R3 ;STARTING WRITE BUFFER ADDRESS
6894 037066 013737 003072 046062 MOV FREE,T26RB
6895 ;*****
6896 ;
6897 ;WRITE DATA,CVC=1,ACK COMMAND
6898 ;
6899 ;*****
6900 ;
6901
6902 037074 012737 140005 046060 MOV #140005,T26PK3 ;WRITE DATA,CVC=1,ACK COMMAND
6903 037102 012704 046060 MOV #T26PK3,R4 ;SET UP R4 WITH PACKET ADDRESS

```

```

6904 037106          65$:      MOV      R3,R0          ;SET PATTERN IN CORRECT REGISTER
6905 037106 010300      JSR      PC,FILLMEM      ;FILL MEMORY WITH RECORD SIZE
6906 037110 004737 020410  MOV      R3,T26SZ        ;SET UP RECORD SIZE IN PACKET
6907 037114 010337 046066  MOV      R4,TSSB(R5)     ;ISSUE COMMAND
6908 037120 010465 177776  JSR      PC,WAITF        ;WAIT FOR SSR TO SET
6909 037124 004737 017154  MOV      TSSR(R5),R1     ;GET TSSR CONTENTS
6910 037130 016501 000000  MOV      #SSR,R2        ;SET UP EXPECTED
6911 037134 012702 000200  CMP      R1,R2          ;ARE THEY EQUAL
6912 037140 020102          BEQ      75$            ;BR, IF OK
6913 037142 001406          JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
6914 037144 004737 020116          ;SOFT ERROR GENERATED BECAUSE THE
6918          ;WRITE COMMAND IS NOT BEING CHECKED
6919          ;HERE, IT WAS CHECKED IN LEAH2
6920          ;TSSR INCORRECT AFTER WRITE DATA
6921 037150          ERRSOF  ERRNO,WRTErr,PKTSSR
        037150 104457          TRAP    C$ERSOFT
        037152 000411          .WORD  265
        037154 005011          .WORD  WRTErr
        037156 011710          .WORD  PKTSSR
6922 037160          75$:      CKLOOP          ;LOOP IF SELECTED
        037160 104406          TRAP    C$CLP1
6923 037162 005723          TST     (R3),          ;BUMP RECORD SIZE
6924 037164 022703 000414  CMP     #268.,R3      ;END OF RECORD YET
6925 037170 001346          BNE     65$            ;BR, IF MORE RECORDS TO WRITE
6926 037172          80$:      CKLOOP          ;LOOP IF SELECTED
        037172 104406          TRAP    C$CLP1
6927 037174          120$:
6928          ;*****
6929          ;
6930          ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
6931          ;
6932          ;*****
6933          ;*****
6934          ;*****
6935 037174 004737 010444      JSR      PC,REWIND      ;CALL TAPE REWIND COMMAND
6936 037200 103413          BCS     130$          ;BR, IF NO PROBLEM
6937 037202 016501 000000  MOV      TSSR(R5),R1     ;GET TSSR
6938 037206 012702 000200  MOV      #SSR,R2        ;SET UP EXPECTED TSSR
6939 037212 010004          MOV      R0,R4          ;PACKET ADDRESS SET UP
6940 037214 004737 020116  JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
6944 037220          ERRHRD  ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
        037220 104456          TRAP    C$ERRRD
        037222 000412          .WORD  266
        037224 047414          .WORD  T26RWN
        037226 011710          .WORD  PKTSSR
6945 037230          130$:      CKLOOP          ;LOOP IF SELECTED
        037230 104406          TRAP    C$CLP1
6946          ;*****
6947          ;
6948          ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
6949          ;
6950          ;*****
6951          ;*****
6952          ;*****
6953 037232 013701 045756      MOV      T26BFR+6,R1     ;PICK UP XSTO
6954 037236 010102          MOV      R1,R2          ;SET UP EXPECTED
6955 037240 052702 000002  BIS     #BIT1,R2        ;SET BOT BIT IN EXPECTED

```

M14

CZIKGA TK-25 FRI END FUNC #3
TEST 2: REREADS

MACRO M1200 20-APR-84 08:13 PAGE 103-3

SEQ 181

```

6956 037244 020102          CMP      R1,R2          ;DOES EXP = REC'D
6957 037246 001406          BEQ      140$          ;BR, IF EQUAL (OK)
6958 037250 004737 020116    JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
6962 037254          ERRHRD  ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
        037254 104456          TRAP    C$ERHRD
        037256 000413          .WORD  267
        037260 047125          .WORD  T26BOT
        037262 016360          .WORD  EXPREC
6963 037264          140$:  CKLOOP          ;LOOP IF SELECTED
        037264 104406          TRAP    C$CLP1
6964 037266 012737 000400 046112  MOV      #256.,T26RSZ   ;STORE START RECORD SIZE
6965 037274 000420          BR       150$          ;SKIP THE SPACE THIS TIME
6966
6967
6968
6969
6970
6971
6972
6973
        ;*****
        ;ISSUE SPACE RECORDS COMMAND - VALUE IN R3 SETS NUMBER OF RECORDS
        ;BIT 15 SETS DIRECTION - 0=FORWARD 1=REVERSE
        ;*****
6974 037276 012703 000001    145$:  MOV      #1,R3          ;SPACE ONE RECORD PARAMETER
6975 037302 004737 010144    JSR      PC,SPACE      ;CALL SPACE ROUTINE
6976 037306 103413          BCS     150$          ;BR, IF NO PROBLEM WITH SPACE COMMAND
6977 037310 016501 000000    MOV      TSSR(R5),R1   ;GET TSSR
6978 037314 012702 000200    MOV      #SSR,R2      ;SET UP EXPECTED TSSR
6979 037320 010004          MOV      R0,R4        ;PACKET ADDRESS SET UP
6980 037322 004737 020116    JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
6984 037326          ERRHRD  ERRNO,T26SC,EXPREC ;POSITION (SPACE RECORDS) FAILED
        037326 104456          TRAP    C$ERHRD
        037330 000414          .WORD  268
        037332 046527          .WORD  T26SC
        037334 016360          .WORD  EXPREC
6985 037336          150$:
6986 037336 013703 046112 046062  MOV      T26RSZ,R3     ;RECORD SIZE
6987 037342 013737 003072 046062  MOV      FREE,T26RB    ;STARTING READ BUFFER ADDRESS
6988
6989
6990
6991
6992
6993
6994
        ;*****
        ;REREREAD DATA,CVC=1,ACK COMMAND
        ;*****
6995 037350 012737 141401 046060  MOV      #141401,T26PK3 ;REREREAD DATA,CVC=1,ACK COMMAND
6996 037356 012704 046060  165$:  MOV      #T26PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
6997 037362 010337 046066  MOV      R3,T26SZ      ;SET UP RECORD SIZE IN PACKET
6998 037366 010465 177776  MOV      R4,TSDB(R5)   ;ISSUE COMMAND
6999 037372 004737 017134  JSR      PC,WAITF      ;WAIT FOR SSR TO SET
7000 037376 016501 000000  MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
7001 037402 012702 000200  MOV      #SSR,R2      ;SET UP EXPECTED
7002 037406 020102  CMP      R1,R2        ;ARE THEY EQUAL
7003 037410 001406  BEQ      170$          ;BR, IF OK
7004 037412 004737 020116  JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
7008 037416          ERRHRD  ERRNO,T26WDC,PKTSSR ;TSSR INCORRECT AFTER REREAD DATA
        037416 104456          TRAP    C$ERHRD
        037420 000415          .WORD  269
        037422 047750          .WORD  T26WDC
        037424 011710          .WORD  PKTSSR

```

```

7009 037426            170$:   CKLOOP                ;LOOP IF SELECTED
        037426      104406
7010 037430      013702 003072          MOV      FREE,R2          ;CURRENT BUFFER ADDRESS TO R2
7011 037434      010304          MOV      R3,R4          ;CURRENT RECORD SIZE
7012 037436      162704 000400          SLB      0256.,R4        ;FIRST LOCATION IN BUFFER
7013 037442      060204          173$:   ADD      R2,R4        ;SET UP POINTER
7014 037444      021403          CMP      (R4),R3        ;CHECK DATA READ (R3=DATA ALSO)
7015 037446      001410          BEQ      180$           ;BR, IF ALL IS WELL
7016 037450      011401          MOV      (R4),R1        ;RECD DATA
7017 037452      010302          MOV      R3,R2          ;EXPECTED DATA
7018 037454      004737 020116          JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
7022 037460          ERRHRD  ERRNO,T26DTA,EXPREC ;DATA READ NOT = WRITTEN
        037460      104456
        037462      000416          TRAP    C$ERHRD
        037464      047172          .WORD  270
        037466      016360          .WORD  T26DTA
7023 037470          180$:   CKLOOP                ;LOOP IF SELECTED
        037470      104406
7024 037472      005724          TST      (R4)+          ;BUMP TO NEXT LOCATION
7025 037474      160204          SUB      R2,R4          ;CORRECT RECORDS SIZE. VALUE
7026 037476      020403          CMP      R4,R3          ;END OF RECORD YET
7027 037500      001360          BNE      173$           ;BR, IF NOT AT END OF RECORD
7028 037502      005723          TST      (R3)+          ;BUMP RECORD SIZE
7029 037504      010337 046112          MOV      R3,T26RSZ      ;STORE PRESENT RECORD SIZE
7030 037510      022703 000410          CMP      0264.,R3       ;END OF RECORD YET
7031 037514      001270          BNE      145$           ;BR, IF MORE RECORDS TO READ
7032 037516          190$:   CKLOOP                ;LOOP IF SELECTED
        037516      104406
7033 037520          ENDSUB
        037520
        037520      104403          TRAP    C$CLP1
7034 037522      023727 002170 000031          CMP      FATFLG,025.    ;IS ERROR COUNT AT 25
7035 037530      002402          BLT     999$           ;BR, IF LESS THAN 25
7036 037532      004737 020170          JSR      PC,CKDRUP      ;TRY TO DROP THE UNIT
7037 037536          999$:
    
```



```

7091
7092
7093
7094
7095
7096
7097 037632 004737 010444
7098 037636 105413
7099 037640 016501 000000
7100 037644 012702 000200
7101 037650 010004
7102 037652 004737 020116
7106 037656
      037656 104456
      037660 000421
      037662 047414
      037664 011710
7107 037666
      037666 104406
7108
7109
7110
7111
7112
7113
7114
7115 037670 013701 045756
7116 037674 010102
7117 037676 052702 000002
7118 037702 020102
7119 037704 001406
7120 037706 004737 020116
7124 037712
      037712 104456
      037714 000422
      037716 047125
      037720 016360
7125 037722
      037722 104406
7126 037724 012703 000400
7127 037730 013737 003072 046062
7128
7129
7130
7131
7132
7133
7134
7135 037736 012737 150005 046060
7136 037744 012704 046060
7137 037750
7138 037750 010300
7139 037752 004737 020410
7140 037756 010337 046066
7141 037762 010465 177776
7142 037766 004737 017134
7143 037772 016501 000000

```

```

|*****|
|ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE|
|*****|
      JSR      PC,REWIND          ;CALL TAPE REWIND COMMAND
      BCS      30$              ;BR, IF NO PROBLEM
      MOV      TSSR(R5),R1      ;GET TSSR
      MOV      #SSR,R2         ;SET UP EXPECTED TSSR
      MOV      R0,R4           ;PACKET ADDRESS SET UP
      JSR      PC,FATCHK       ;INC AND CHECK FOR MORE THAN 25 ERRORS
      ERRHRD  ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
                                     TRAP  C#ERHRD
                                     .WORD 273
                                     .WORD T26RWN
                                     .WORD PKTSSR
30$:  CKLOOP                      ;LOOP IF SELECTED
                                     TRAP  C#CLP1
|*****|
|READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)|
|*****|
      MOV      T26BFR+6,R1      ;PICK UP XSTO
      MOV      R1,R2           ;SET UP EXPECTED
      BIS      #BIT1,R2        ;SET BOT BIT IN EXPECTED
      CMP      R1,R2           ;DOES EXP = REC'D
      BEQ      40$              ;BR, IF EQUAL (OK)
      JSR      PC,FATCHK       ;INC AND CHECK FOR MORE THAN 25 ERRORS
      ERRHRD  ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                     TRAP  C#ERHRD
                                     .WORD 274
                                     .WORD T26BOT
                                     .WORD EXPREC
40$:  CKLOOP                      ;LOOP IF SELECTED
                                     TRAP  C#CLP1
      MOV      #256,R3         ;RECORD SIZE
      MOV      FREE,T26RB      ;STARTING WRITE BUFFER ADDRESS
|*****|
|WRITE DATA,CVC=1,ACK,SWB COMMAND|
|*****|
65$:  MOV      #150005,T26PK3    ;WRITE DATA,CVC=1,ACK,SWB COMMAND
      MOV      #T26PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
      MOV      R3,R0           ;SET PATTERN IN CORRECT REGISTER
      JSR      PC,FILLMEM      ;FILL MEMORY WITH RECORD SIZE
      MOV      R3,T26SZ        ;SET UP RECORD SIZE IN PACKET
      MOV      R4,TSD8(R5)     ;ISSUE COMMAND
      JSR      PC,WAITF        ;WAIT FOR SSR TO SET
      MOV      TSSR(R5),R1     ;GET TSSR CONTENTS

```



```

7144 037776 012702 000200      MOV      #SSR,R2      ;SET UP EXPECTED
7145 040002 020102      CMP      R1,R2      ;ARE THEY EQUAL
7146 040004 001406      BEQ      751        ;BR, IF OK
7147 040006 004737 020116      JSR      PC,FATCHK  ;INC AND CHECK FOR MORE THAN 25 ERRORS
7151                                ;SOFT ERROR GENERATED BECAUSE THE
7152                                ;WRITE COMMAND IS NOT BEING CHECKED
7153                                ;HERE, IT WAS CHECKED IN LEAH2
7154 040012      ERRSFT ERRNC,WRERR,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP      C#ERSOFT
                                .WORD    275
                                .WORD    WRERR
                                .WORD    PKTSSR
                                TRAP      C#CLP1
7155 040022      751:    CKLOOP      ;LOOP IF SELECTED
                                TRAP      C#CLP1
                                .WORD    104406
7156 040024 005723      TST      (R3),      ;BUMP RECORD SIZE
7157 040026 022703 000414      CMP      #268,,R3  ;END OF RECORD YET
7158 040032 001346      BNE      651        ;BR, IF MORE RECORDS TO WRITE
7159 040034      801:    CKLOOP      ;LOOP IF SELECTED
                                TRAP      C#CLP1
                                .WORD    104406
7160 040036      1201:
;*****
;
;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
;
;*****
7168 040036 004737 010444      JSR      PC,REWIND  ;CALL TAPE REWIND COMMAND
7169 040042 103413      BCS      1301      ;BR, IF NO PROBLEM
7170 040044 016501 000000      MOV      TSSR(R5),R1 ;GET TSSR
7171 040050 012702 000200      MOV      #SSR,R2   ;SET UP EXPECTED TSSR
7172 040054 010004      MOV      R0,R4     ;PACKET ADDRESS SET UP
7173 040056 004737 020116      JSR      PC,FATCHK  ;INC AND CHECK FOR MORE THAN 25 ERRORS
7177 040062      ERRHRD ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP      C#ERHRD
                                .WORD    276
                                .WORD    T26RWN
                                .WORD    PKTSSR
7178 040072      1301:    CKLOOP      ;LOOP IF SELECTED
                                TRAP      C#CLP1
                                .WORD    104406
7179
7180 ;*****
7181 ;
7182 ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
7183 ;
7184 ;*****
7185
7186 040074 013701 045756      MOV      T26BFR+6,R1 ;PICK UP XSTO
7187 040100 010102      MOV      R1,R2     ;SET UP EXPECTED
7188 040102 052702 000002      HIS      #BIT1,R2  ;SET BOT BIT IN EXPECTED
7189 040106 020102      CMP      R1,R2     ;DOES EXP = REC'D
7190 040110 001406      BEQ      1401      ;BR, IF EQUAL (OK)
7191 040112 004737 020116      JSR      PC,FATCHK  ;INC AND CHECK FOR MORE THAN 25 ERRORS
7195 040116      ERRHRD ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C#ERHRD
                                .WORD    277
                                .WORD    T26BOT
040120 000425
040122 047125

```

```

040124 016360
7196 040126 104406 140#: CKLOOP ;LOOP IF SELECTED .WORD EXPREC
040126 104406 ;TRAP C1CLP1
7197 040130 012737 000400 046112 MOV #256.,T26RSZ ;START RECORD SIZE
7198 040136 000420 BR 150# ;SKIP SPACE THIS TIME
7199
7200 ;*****
7201 ;
7202 ;ISSUE SPACE RECORDS COMMAND - VALUE IN R3 SETS NUMBER OF RECORDS
7203 ;BIT 15 SETS DIRECTION - 0=FORWARD 1=REVERSE
7204 ;
7205 ;*****
7206
7207 040140 012703 000001 145#: MOV #1,R3 ;SPACE ONE RECORD PARAMETER
7208 040144 004737 010144 JSR PC,SPACE ;CALL SPACE ROUTINE
7209 040150 103413 BCS 150# ;BR, IF NO PROBLEM WITH SPACE COMMAND
7210 040152 01E501 000000 MOV TSSR(R5),R1 ;GET TSSR
7211 040156 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED TSSR
7212 040162 010004 MOV R0,R4 ;PACKET ADDRESS SET UP
7213 040164 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7217 040170 ERRHRD ERRNO,T26SC,EXPREC ;POSITION (SPACE RECORDS) FAILED
040170 104456 ;TRAP C1ERHRD
040172 000426 .WORD 278
040174 046527 .WORD T26SC
040176 016360 .WORD EXPREC
7218 040200 150#:
7219 040200 013703 046112 MOV T26RSZ,R3 ;RECORD SIZE
7220 040204 013737 003072 046062 MOV FREE,T26RB ;STARTING READ BUFFER ADDRESS
7221
7222 ;*****
7223 ;
7224 ;REREAD DATA,ACK,CVC-1,SWB COMMAND
7225 ;
7226 ;*****
7227
7228 040212 012737 151401 046060 MOV #151401,T26PK3 ;REREAD DATA,ACK,CVC-1,SWB COMMAND
7229 040220 012704 046060 165#: MOV #T26PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
7230 040224 010337 046066 MOV R3,T26SZ ;SET UP RECORD SIZE IN PACKET
7231 040230 010465 177776 MOV R4,T5DB(R5) ;ISSUE COMMAND
7232 040234 004737 017134 JSR PC,WAITF ;WAIT FOR SSR TO SET
7233 040240 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
7234 040244 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
7235 040250 020102 CMP R1,R2 ;ARE THEY EQUAL
7236 040252 001406 BCL 170# ;BR, IF OK
7237 040254 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7241 040260 ERRHRD ERRNO,T26WDC,PKTSSR ;TSSR INCORRECT AFTER REREAD DATA
040260 104456 ;TRAP C1ERHRD
040262 000427 .WORD 279
040264 047750 .WORD T26WDC
040266 011710 .WORD PKTSSR
7242 040270 170#: CKLOOP ;LOOP IF SELECTED
040270 104406 ;TRAP C1CLP1
7243 040272 013702 003072 MOV FREE,R2 ;CURRENT BUFFER ADDRESS TO R2
7244 040276 010304 MOV R3,R4 ;CURRENT RECORD SIZE
7245 040300 162704 000400 SUB #256.,R4 ;FIRST LOCATION IN BUFFER
7246 040304 060204 173#: ADD R2,R4 ;SET UP POINTER
7247 040306 021403 CMP (R4),R3 ;CHECK DATA READ (R3=DATA ALSO)

```

7248	040310	001410			BEQ	180\$							
7249	040312	011401			MOV	(R4),R1							
7250	040314	010302			MOV	R3,R2							
7251	040316	004737	020116		JSR	PC,FATCHK							
7255	040322				ERRHRD	ERRNO,T26DTA,EXPREC							
	040322	104456											
	040324	000430											
	040326	047172											
	040330	016360											
7256	040332			180\$:	CKLOOP								
	040332	104406											
7257	040334	005724			TST	(R4),							
7258	040336	160204			SUB	R2,R4							
7259	040340	020403			CMP	R4,R3							
7260	040342	001350			BNE	175\$							
7261	040344	005723			TST	(R3),							
7262	040346	010337	046112		MOV	R3,I26RSZ							
7263	040352	022703	000410		CMP	#264,,R3							
7264	040356	001270			BNE	145\$							
7265	040360			190\$:	CKLOOP								
	040360	104406											
7266	040362				ENDSUB								
	040362												
	040362	104403											
7267	040364	023727	002170	000031	CMP	FATELG,#25,							
7268	040372	002402			BLT	999\$							
7269	040374	004737	020170		JSR	PC,CKDROP							
7270	040400			999\$:									

```

;BR, IF ALL IS WELL.
;RECD DATA
;EXPECTED DATA
;INC AND CHECK FOR MORE THAN 25 ERRORS
;DATA READ NOT = WRITTEN
                                TRAP C#ERHRD
                                .WORD 280
                                .WORD T26DTA
                                .WORD EXPREC
;LOOP IF SELECTED
                                TRAP C#CLP1
;BUMP TO NEXT LOCATION
;CORRECT RECORDS SIZE VALUE
;END OF RECORD YET
;BR, IF NOT AT END OF RECORD
;BUMP RECORD SIZE
;STORE RECORD SIZE
;END OF RECORD YET
;BR, IF MORE RECORDS TO WRITE
;LOOP IF SELECTED
                                TRAP C#CLP1
; >>>>>>>>>> END SUBTEST >>>>>>>>>>>
                                L:10056:
                                TRAP C#ESUB
;IS ERROR COUNT AT 25
;BR, IF LESS THAN 25
;TRY TO DROP THE UNIT

```

```

7272
7273
7274
7275
7276
7277
7278
7279
7280
7281
7282
7283
7284
7285
7286
7287
7288
7289
7290
7291
7292
7293
7294
7295
7296
7297
7298
7299
7300
7301
7302
7303
7304
7305 040400          BGNSUB          ; >>>>>>>>>> BEGIN SUBTEST >>>>>>>>>>
          040400          T2.9:          TRAP      C18SUB
          040400 104402          JSR      PC,T26REST      ;SET COMMAND PACKET
7306 040402 004737 050650          CLR      T26CNT      ;CLEAR TAPE RECORD COUNTER
7307 040406 005037 046106          JSR      PC,T26RT2   ;SET UP OTHER COMMAND PACKET
7308 040412 004737 050742          JSR      PC,T26RT3   ;SET UP OTHER COMMAND PACKET
7309 040416 004737 051004
7310
7311
7312
7313
7314
7315
7316
7317 040422 004737 016660          JSR      PC,SOFINIT   ;DO INITIALIZE ON CONTROLLER
7318 040426 103407          BCS      201          ;BR IF INIT WAS OK
7319 040430 004737 020116          JSR      PC,FATCHK   ;INC AND CHECK FOR MORE THAN 25 ERRORS
7323 040434 010001          MOV      R0,R1       ;CONTENTS OF TSSR REGISTER
7324 040436          ERRDF   ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
          040436 104455          TRAP      C18RDF
          040440 000431          .WORD    281
          040442 003550          .WORD    SFIERR
          040444 011676          .WORD    SFIMSG
7325 040446          201:

```

```

;+
;
; TEST 2, SUBTEST 9
;
; VERIFIES THAT THE REREAD NEXT COMMAND WITH OPP=1
; (READ FORWARD, SPACE REVERSE) AND SWB=0 OPERATES
; PROPERLY. THE TAPE IS FIRST REWOUND AND THEN WRITTEN
; WITH A SERIES OF TEST RECORDS VARYING IN LENGTH AND
; DATA CONTENT; THE FIRST FOUR BYTES OF EACH RECORD
; CONTAIN ITS RECORD NUMBER (INDICATING POSITION ON
; TAPE). THE TAPE IS THEN REWOUND AGAIN, FOR EACH
; TEST RECORD, THE FOLLOWING SEQUENCE IS EXECUTED.
;
; 1. THE REREAD NEXT COMMAND IS ISSUED
; AND THE RESULTS CHECKED
;
; 2. A READ FORWARD COMMAND IS THEN ISSUED AND THE
; DATA IS CHECKED TO VERIFY THAT THE TAPE WAS
; POSITIONED PROPERLY AFTER THE REREAD NEXT
; COMMAND (E.G. THE TAPE SHOULD HAVE BEEN LEFT
; POSITIONED AT THE START OF THE TEST RECORD). THE
; READ FORWARD COMMAND LEAVES THE TAPE POSITIONED
; PROPERLY AT THE START OF THE NEXT TEST RECORD.
;
; THE BYTE COUNT ON EACH REREAD NEXT COMMAND IS SET
; TO THE LENGTH OF THE EXPECTED RECORD, SO NO
; EXCEPTIONAL CONDITIONS SHOULD OCCUR.
;
;
;
; -

```

```

7326
7327 040446 012704 045730          MOV      *T26PACKET,R4          ;SUBROUTINE NEEDS PACKET ADDRESS
7328
7329          ;*****
7330          ;
7331          ;WRITE CHARACTERISTICS COMMAND (CALL TO WRTPCHR)
7332          ;
7333          ;*****
7334
7335 040452 004737 010342          JSR      PC,WRTPCHR          ;ISSUE WRITE CHARACTERISTICS
7336 040456 103407          BCS     26$                ;BR, IF COMMAND ISSUED OK
7337 040460 004737 020116          JSR      PC,FATCHK          ;INC AND CHECK FOR MORE THAN 25 ERRORS
7341 040464 010001          MOV     RO,R1              ;SAVE CONTENTS OF TSSR
7342 040466          ERRHRD  ERRNO,WRMSG,SFMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP     C$ERRRD
                                .WORD    282
                                .WORD    WRMSG
                                .WORD    SFMSG
                                040466 104456
                                040470 000432
                                040472 004754
                                040474 011676
7343 040476          26$:      CKLOOP          ;LOOP IF SELECTED
                                TRAP     C$CLP1
                                040476 104406
7344
7345          ;*****
7346          ;
7347          ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
7348          ;
7349          ;*****
7350
7351 040500 004737 010444          JSR      PC,REWIND          ;CALL TAPE REWIND COMMAND
7352 040504 103413          BCS     30$                ;BR, IF NO PROBLEM
7353 040506 016501 000000          MOV     TSSR(R5),R1        ;GET TSSR
7354 040512 012702 000200          MOV     *SSR,R2           ;SET UP EXPECTED TSSR
7355 040516 010004          MOV     RO,R4             ;PACKET ADDRESS SET UP
7356 040520 004737 020116          JSR      PC,FATCHK          ;INC AND CHECK FOR MORE THAN 25 ERRORS
7360 040524          ERRHRD  ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP     C$ERRRD
                                .WORD    283
                                .WORD    T26RWN
                                .WORD    PKTSSR
                                040524 104456
                                040526 000433
                                040530 047414
                                040532 011710
7361 040534          30$:      CKLOOP          ;LOOP IF SELECTED
                                TRAP     C$CLP1
                                040534 104406
7362
7363          ;*****
7364          ;
7365          ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
7366          ;
7367          ;*****
7368
7369 040536 013701 045756          MOV     T26BFR+6,R1        ;PICK UP XSTO
7370 040542 010102          MOV     R1,R2             ;SET UP EXPECTED
7371 040544 052702 000002          BIS     *BIT1,R2          ;SET BOT BIT IN EXPECTED
7372 040550 020102          CMP     R1,R2             ;DOES EXP = REC'D
7373 040552 001406          BEQ     40$               ;BR, IF EQUAL (OK)
7374 040554 004737 020116          JSR      PC,FATCHK          ;INC AND CHECK FOR MORE THAN 25 ERRORS
7378 040560          ERRHRD  ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP     C$ERRRD
                                .WORD    284
                                .WORD    T26BOT
                                040560 104456
                                040562 000434
                                040564 047125

```

```

040566 016360
7379 040570 104406 40$: CKLOOP ;LOOP IF SELECTED .WORD EXPREC
040570 104406 ;TRAP C#CLP1
7380 040572 012703 000400 MOV #256.,R3 ;RECORD SIZE
7381 040576 013737 003072 046062 MOV FREE,T26RB ;STARTING WRITE BUFFER ADDRESS
7382
7383 ;*****
7384 ;
7385 ;WRITE DATA,CVC=1,ACK COMMAND
7386 ;
7387 ;*****
7388
7389 040604 012737 140005 046060 MOV #140005,T26PK3 ;WRITE DATA,CVC=1,ACK COMMAND
7390 040612 012704 046060 MOV #T26PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
7391 040616 65$:
7392 040616 010337 046066 MOV R3,T26SZ ;SET UP RECORD SIZE IN PACKET
7393 040622 013777 046106 142242 MOV T26CNT,DFREE ;MOVE TAPE RECORD NUMBER TO BUFFER
7394 040630 062737 000001 046106 ADD #1,T26CNT ;NUMBER READY FOR NEXT RECORD
7395 040636 010465 177776 MOV R4,TSDB(R5) ;ISSUE COMMAND
7396 040642 004737 017134 JSR PC,WAITE ;WAIT FOR SSR TO SET
7397 040646 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
7398 040652 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
7399 040656 020102 CMP R1,R2 ;ARE THEY EQUAL
7400 040660 001406 BEQ 75$ ;BR. IF OK
7401 040662 004737 020116 JSR PC,FATCH# ;INC AND CHECK FOR MORE THAN 25 ERRORS
7405 ;SOFT ERROR GENERATED BECAUSE THE
7406 ;WRITE COMMAND IS NOT BEING CHECKED
7407 ;HERE. IT WAS CHECKED IN LEAH2
7408 040666 ERRSFT ERRNO,WRTErr,PKTSSR ;TSSR INCORRECT AFTER REREAD DATA
040666 104457 TRAP C#ERSOFT
040670 000435 .WORD 285
040672 005011 .WORD WRTErr
040674 011710 .WORD PKTSSR
7409 040676 75$: CKLOOP ;LOOP IF SELECTED .WORD C#CLP1
040676 104406 ;TRAP C#CLP1
7410 040700 005723 TST (R5) ;BUMP THE RECORD SIZE
7411 040702 022703 000414 CMP #268.,R3 ;MAXIMUM SIZE YET
7412 040706 001401 BEQ 120$ ;BR. IF AT END OF WRITE SEQUENCE
7413 040710 000742 BR 65$ ;WRITE MORE RECORDS
7414 040712 120$:
7415 040712 005037 046106 CLR T26CNT ;SET RECORD COUNTER BACK TO ZERO
7416
7417 ;*****
7418 ;
7419 ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
7420 ;
7421 ;*****
7422
7423 040716 004737 010444 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
7424 040722 103411 BCS 130$ ;BR. IF NO PROBLEM
7425 040724 016501 000000 MOV TSSR(R5),R1 ;GET TSSR
7426 040730 010004 MOV R0,R4 ;PACKET ADDRESS SET UP
7427 040732 004737 020116 JSR PC,FATCH# ;INC AND CHECK FOR MORE THAN 25 ERRORS
7431 040736 ERRHRD ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
040736 104456 TRAP C#ERRHD
040740 000436 .WORD 286
040742 047414 .WORD T26RWN

```

JL5

```

040744 011710
7432 040746 104406 130$: CKLOOP ;LOOP IF SELECTED .WORD PKTSSR
040746 104406 TRAP C$CLP1
7433
7434 ;*****
7435 ;
7436 ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
7437 ;
7438 ;*****
7439
7440 040750 013701 045756 MOV T26BFR+6,R1 ;PICK UP XSTO
7441 040754 010102 MOV R1,R2 ;SET UP EXPECTED
7442 040756 052702 000002 HIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
7443 040762 020102 CMP R1,R2 ;DOES EXP = REC'D
7444 040764 001406 BEQ 135$ ;BR, IF EQUAL (OK)
7445 040766 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7449 040772 ERRHRD ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
040772 104456 TRAP C$ERHRD
040774 000437 .WORD 287
040776 047125 .WORD T26BOT
041000 016360 .WORD EXPREC
7450 041002 135$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
041002 104406
7451 041004 012737 000400 046112 MOV #256.,T26RSZ ;STARTING RECORD SIZE
7452 041012 000420 BR 140$ ;SKIP OVER THE SPACE THIS TIME
7453
7454 ;*****
7455 ;
7456 ;ISSUE SPACE RECORDS COMMAND - VALUE IN R3 SETS NUMBER OF RECORDS
7457 ;BIT 15 SETS DIRECTION - 0=FORWARD 1=REVERSE
7458 ;
7459 ;*****
7460
7461 041014 012703 000001 132$: MOV #000001,R3 ;SET UP SPACE COMMAND (1 FORWARD)
7462 041020 004737 010144 JSR PC,SPACE ;CALL SPACE ROUTINE
7463 041024 103413 BCS 140$ ;BR, IF NO TROUBLE
7464 041026 016501 000000 MOV TSSR(R5),R1 ;GET TSSR
7465 041032 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED TSSR
7466 041036 010004 MOV R0,R4 ;PACKET ADDRESS SET UP
7467 041040 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7471 041044 ERRHRD ERRNO,T26SC,PKTSSR ;SPACE (FORWARD) FAILED
041044 104456 TRAP C$ERHRD
041046 000440 .WORD 288
041050 046527 .WORD T26SC
041052 011710 .WORD PKTSSR
7472 041054 140$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
041054 104406
7473 041056 013703 046112 150$: MOV T26RSZ,R3 ;RECORD SIZE
7474 041062 013737 003072 046062 MOV FREE,T26RB ;STARTING READ BUFFER ADDRESS
7475
7476 ;*****
7477 ;
7478 ;REREAD DATA,CVC=1,ACK, OPP COMMAND
7479 ;
7480 ;*****
7481
7482 041070 012737 161401 046060 MOV #161401,T26P#3 ;REREAD DATA,CVC=1,ACK, OPP COMMAND

```



```

7520 ;+
7521 ;
7522 ;TEST 2, SUBTEST 10
7523 ;
7524 ;VERIFIES THAT THE REREAD NEXT COMMAND WITH OPP=1
7525 ;AND SWB-1 OPERATES PROPERLY. THE TEST SEQUENCE IS
7526 ;THE SAME THAT IS USED IN SUBTEST 3, BUT IT IS
7527 ;VERIFIED THAT DATA STORED BY THE COMMAND CONTAINS
7528 ;SWAPPED BYTES.
7529 ;
7530 ;
7531 ;
7532 ;
7533 ;-
7534 ;
7535 041246          BGNSUB                      ;>>>>>>>>>> BEGIN SUBTEST >>>>>>>>>
      041246                      T2.10:
      041246 104402          TRAP          C#BSUB
7536 041250 004737 050650          JSR      PC,T26REST          ;SET COMMAND PACKET
7537 041254 005037 046106          CLR      T26CNT          ;CLEAR TAPE RECORD COUNTER
7538 041260 004737 050742          JSR      PC,T26RT2          ;SET UP OTHER COMMAND PACKET
7539 041264 004737 051004          JSR      PC,T26RT3          ;SET UP OTHER COMMAND PACKET
7540 ;
7541 ;*****
7542 ;
7543 ;ISSUE CONTROLLER "SOFT" INITIALIZE - CARRY BIT CLEAR IF ERROR
7544 ;
7545 ;*****
7546 ;
7547 041270 004737 016660          JSR      PC,SOFINIT          ;DO INITIALIZE ON CONTROLLER
7548 041274 103407          BCS      20$
7549 041276 004737 020116          JSR      PC,FATCHK          ;INC AND CHECK FOR MORE THAN 25 ERRORS
7553 041302 010001          MOV      R0,R1          ;CONTENTS OF TSSR REGISTER
7554 041304          ERRDF   ERRNO,SFIERR,SFIMSG          ;FATAL ERROR TSSR WAS NOT OK
      041304 104455          TRAP          C#ERDF
      041306 000443          .WORD      291
      041310 003550          .WORD      SFIERR
      041312 011676          .WORD      SFIMSG
7555 041314          20$:
7556 ;
7557 041314 012704 045730          MOV      @T26PACKET,R4          ;SUBROUTINE NEEDS PACKET ADDRESS
7558 ;
7559 ;*****
7560 ;
7561 ;WRITE CHARACTERISTICS COMMAND (CALL TO WRTCHR)
7562 ;
7563 ;*****
7564 ;
7565 041320 004737 010342          JSR      PC,WRTCHR          ;ISSUE WRITE CHARACTERISTICS
7566 041324 103407          BCS      26$
7567 041326 004737 020116          JSR      PC,FATCHK          ;INC AND CHECK FOR MORE THAN 25 ERRORS
7571 041332 010001          MOV      R0,R1          ;SAVE CONTENTS OF TSSR
7572 041334          ERRHRD  ERRNO,WRTMSG,SFIMSG          ;WRITE CHARACTERISTIC FAILED
      041334 104456          TRAP          C#ERRRD
      041336 000444          .WORD      291
      041340 004754          .WORD      WRTMSG
      041342 011676          .WORD      SFIMSG

```

```

7573 041344      26$:  CKLOOP                ;LOOP IF SELECTED
      041344 104406                                TRAP  C$CLP1
7574
7575 ;*****
7576 ;
7577 ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
7578 ;
7579 ;*****
7580
7581 041346 004737 010444      JSR    PC,REWIND          ;CALL TAPE REWIND COMMAND
7582 041352 016501 000000      MOV    TSSR(R5),R1      ;GET TSSR
7583 041356 012702 000200      MOV    #SSR,R2         ;SET UP EXPECTED TSSR
7584 041362 103407              BCS    30$              ;BR, IF NO PROBLEM
7585 041364 010004              MOV    R0,R4           ;PACKET ADDRESS SET UP
7586 041366 004737 020116      JSR    PC,FATCHK       ;INC AND CHECK FOR MORE THAN 25 ERRORS
7590 041372              ERRHRD  ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
      041372 104456                                TRAP  C$ERRHRD
      041374 000445                                .WORD 293
      041376 047414                                .WORD T26RWN
      041400 011710                                .WORD PKTSSR
7591 041402      30$:  CKLOOP                ;LOOP IF SELECTED
      041402 104406                                TRAP  C$CLP1
7592
7593 ;*****
7594 ;
7595 ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
7596 ;
7597 ;*****
7598
7599 041404 013701 045756      MOV    T26BFR+6,R1     ;PICK UP XSTO
7600 041410 010102              MOV    R1,R2           ;SET UP EXPECTED
7601 041412 052702 000002      BIS    #BIT1,R2        ;SET BOT BIT IN EXPECTED
7602 041416 020102              CMP    R1,R2           ;DUES EXP = REC'D
7603 041420 001406              BEQ    40$              ;BR, IF EQUAL (OK)
7604 041422 004737 020116      JSR    PC,FATCHK       ;INC AND CHECK FOR MORE THAN 25 ERRORS
7608 041426              ERRHRD  ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      041426 104456                                TRAP  C$ERRHRD
      041430 000446                                .WORD 294
      041432 047125                                .WORD T26BOT
      041434 016360                                .WORD EXPREC
7609 041436      40$:  CKLOOP                ;LOOP IF SELECTED
      041436 104406                                TRAP  C$CLP1
7610 041440 012703 000400      MOV    #256,R3         ;RECORD SIZE
7611 041444 013737 003072 046062  MOV    FREE,T26RB      ;STARTING WRITE BUFFER ADDRESS
7612
7613 ;*****
7614 ;
7615 ;WRITE DATA,CVC-1,ACK COMMAND
7616 ;
7617 ;*****
7618
7619 041452 012737 140005 046060      MOV    #140005,T26PK3 ;WRITE DATA,CVC-1,ACK COMMAND
7620 041460 012704 046060      MOV    #T26PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
7621 041464
7622 041464 010337 046066      65$:  MOV    R3,T26SZ      ;SET UP RECORD SIZE IN PACKET
7623 041470 013777 046106 141374      MOV    T26CNT,#REE    ;MOVE TAPE RECORD NUMBER TO BUFFER
7624 041476 062737 000001 046106      ADD    #1,T26CNT       ;NUMBER READY FOR NEXT RECORD

```

```

7625 041504 010465 177776      MOV      R4,TSDB(R5)      ;ISSUE COMMAND
7626 041510 004737 017134      JSR      PC,WAITE        ;WAIT FOR SSR TO SET
7627 041514 016501 000000      MOV      TSSR(R5),R1    ;GET TSSR CONTENTS
7628 041520 012702 000200      MOV      #SSR,R2        ;SET UP EXPECTED
7629 041524 020102              CMP      R1,R2           ;ARE THEY EQUAL
7630 041526 001406              BEQ      75$             ;BR, IF OK
7631 041530 004737 020116      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
7635                                ;SOFT ERROR GENERATED BECAUSE THE
7636                                ;WRITE COMMAND IS NOT BEING CHECKED
7637                                ;HERE, IT WAS CHECKED IN LEAH2
7638 041534              ERRSOFT ERRNO,WRTErr,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP      C$ERSOFT
                                .WORD    295
                                .WORD    WRTErr
                                .WORD    PKTSSR
7639 041544              75$: CKLOOP           ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD    104457
                                .WORD    000447
                                .WORD    005011
                                .WORD    011710
7640 041546 005723              TST      (R3)+           ;BUMP THE RECORD SIZE
7641 041550 022703 000414      CMP      #268.,R3      ;MAXIMUM SIZE YET
7642 041554 001401              BEQ      120$           ;BR, IF AT END OF WRITE SEQUENCE
7643 041556 000742              BR       65$            ;WRITE MORE RECORDS
7644 041560              120$: CLR      T26CNT      ;SET RECORD COUNTER BACK TO ZERO
7645 041560 005037 046106
7646
7647 ;*****
7648 ;
7649 ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
7650 ;
7651 ;*****
7652
7653 041564 004737 010444      JSR      PC,REWIND      ;CALL TAPE REWIND COMMAND
7654 041570 103411              BCS      130$           ;BR, IF NO PROBLEM
7655 041572 016501 000000      MOV      TSSR(R5),R1    ;GET TSSR
7656 041576 010004              MOV      R0,R4          ;PACKET ADDRESS SET UP
7657 041600 004737 020116      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
7661 041604              ERRHRD ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP      C$ERHRD
                                .WORD    296
                                .WORD    T26RWN
                                .WORD    PKTSSR
7662 041614              130$: CKLOOP           ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD    104456
                                .WORD    000450
                                .WORD    047414
                                .WORD    011710
7663 041614 104406
7664 ;*****
7665 ;
7666 ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
7667 ;
7668 ;*****
7669
7670 041616 013701 045756      MOV      T26BFR+6,R1    ;PICK UP XSTO
7671 041622 010102              MOV      R1,R2          ;SET UP EXPECTED
7672 041624 052702 000002      BIS      #BIT1,R2       ;SET BOT BIT IN EXPECTED
7673 041630 020102              CMP      R1,R2          ;DOES EXP = REC'D
7674 041632 001406              BEQ      135$           ;BR, IF EQUAL (OK)
7675 041634 004737 020116      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
7679 041640              ERRHRD ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C$ERHRD
                                .WORD    104456

```


C16

CZIKGA TK 25 FBI END FUNC #3 MACRO M1200 20-APR-84 08:13 PAGE 106-4

SEQ 197

TEST 2: REREADS

7729	042026	020102			CMP	R1,R2				
7730	042030	001406			BEQ	190#				
7751	042032	004737	020116		JSR	PC,FATCHK				
7735	042036				ERRHRD	ERRNO,T26WNG,EXPREC				
	042036	104456								
	042040	000454								
	042042	046116								
	042044	016360								
7736	042046			190#:	CKLOOP					
	042046	104406								
7737	042050	062737	000001	046106	ADD	#1,T26CNT				
7738	042056	005723			TST	(R3),				
7739	042060	010337	046112		MOV	R3,T26RSZ				
7740	042064	022703	000412		CMP	#266.,R3				
7741	042070	001402			BEQ	220#				
7742	042072	000137	041662		JMP	136#				
7743	042076			220#:						
7744	042076				ENDSUB					
	042076	104403								
7745	042100	023727	002170	000031	CMP	FATFLG,#25,				
7746	042106	002402			BLT	999#				
7747	042110	004737	020170		JSR	PC,CKDROP				
7748	042114			999#:						

;

IS TAPE POSITION CORRECT
;KEEP GOING POSITION OK
;INC AND CHECK FOR MORE THAN 25 ERRORS
;TAPE POSITION INCORRECT TRAP C#ERHRD
.WORD 300
.WORD T26WNG
.WORD EXPREC

TRAP C#CLP1

;BUMP TAPE RECORD COUNTER
;NEXT RECORD SIZE
;STORE RECORD SIZE
;AT MAX SIZE YET
;BR, IF AT END OF THE SUBTEST
;KEEP GOING MORE RECORDS

;>>>>>>>>>> END SUBTEST >>>>>>>>>>
L10060;

TRAP C#ESUB

;IS ERROR COUNT AT 25
;BR, IF LESS THAN 25
;TRY TO DROP THE UNIT


```

7803 042206 104406 TRAP C#CLP1
7804
7805 ;*****
7806 ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
7807 ;
7808 ;*****
7809
7810 042210 004737 010444 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
7811 042214 016501 000000 MOV TSSR(R5),R1 ;GET TSSR
7812 042220 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED TSSR
7813 042224 103407 BCS 301 ;BR, IF NO PROBLEM
7814 042226 010004 MOV R0,R4 ;PACKET ADDRESS SET UP
7815 042230 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7819 042234 ERRHRD ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
042234 104456 TRAP C#ERRHRD
042236 000457 .WORD 303
042240 047414 .WORD T26RWN
042242 011710 .WORD PKTSSR
7820 042244 301: CKLOOP ;LOOP IF SELECTED TRAP C#CLP1
042244 104406
7821
7822 ;*****
7823 ;
7824 ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
7825 ;
7826 ;*****
7827
7828 042246 013701 045756 MOV T26BFR+6,R1 ;PICK UP XSTO
7829 042252 010102 MOV R1,R2 ;SET UP EXPECTED
7830 042254 052702 0C0002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
7831 042260 020102 CMP R1,R2 ;DOES EXP = REC'D
7832 042262 001406 BEQ 401 ;BR, IF EQUAL (OK)
7833 042264 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
7837 042270 ERRHRD ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
042270 104456 TRAP C#ERRHRD
042272 000460 .WORD 304
042274 047125 .WORD T26BOT
042276 016360 .WORD EXPREC
7838 042300 401: CKLOOP ;LOOP IF SELECTED TRAP C#CLP1
042300 104406
7839 042302 012703 001000 MOV #512,R3 ;RECORD SIZE
7840 042306 013737 003072 046062 MOV FREE,T26RB ;STARTING WRITE BUFFER ADDRESS
7841
7842 ;*****
7843 ;
7844 ;WRITE DATA,CVC=1,ACK COMMAND
7845 ;
7846 ;*****
7847
7848 042314 012737 140005 046060 MOV #140005,T26PK3 ;WRITE DATA,CVC=1,ACK COMMAND
7849 042322 012704 046060 MOV #T26PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
7850 042326
7851 042326 010337 046066 651: MOV R3,T26SZ ;SET UP RECORD SIZE IN PACKET
7852 042332 010465 177776 MOV R4,TSDB(R5) ;ISSUE COMMAND
7853 042336 004737 017134 JSR PC,WAITF ;WAIT FOR SSH TO SET
7854 042342 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS

```

```

7855 042346 012702 000200      MOV      #SSR,R2      ;SET UP EXPECTED
7856 042352 020102      CMP      R1,R2      ;ARE THEY EQUAL
7857 042354 001406      BEQ      75#        ;BR, IF OK
7858 042356 004737 020116      JSR      PC,FATCHK   ;INC AND CHECK FOR MORE THAN 25 ERRORS
7862                                ;SOFT ERROR GENERATED BECAUSE THE
7863                                ;WRITE COMMAND IS NOT BEING CHECKED
7864                                ;HERE. IT WAS CHECKED IN LEAH2
7865                                ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP      C#ERSOFT
                                .WORD    305
                                .WORD    WRTERR
                                .WORD    PKTSSR
                                TRAP      C#CLP1
                                .WORD    104457
                                .WORD    000461
                                .WORD    005011
                                .WORD    011710
7866 042372 104406      75# :   CKLOOP      ;LOOP IF SELECTED
                                TRAP      C#CLP1
7867                                ;*****
7868                                ;
7869                                ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
7870                                ;
7871                                ;*****
7872                                ;
7873                                ;
7874 042374 004737 010444      JSR      PC,REWIND   ;CALL TAPE REWIND COMMAND
7875 042400 016501 000000      MOV      TSSR(R5),R1 ;GET TSSR
7876 042404 012702 000200      MOV      #SSR,R2      ;SET UP EXPECTED TSSR
7877 042410 103407      BCS      130#        ;BR, IF NO PROBLEM
7878 042412 010004      MOV      R0,R4      ;PACKET ADDRESS SET UP
7879 042414 004737 020116      JSR      PC,FATCHK   ;INC AND CHECK FOR MORE THAN 25 ERRORS
7883 042420      ERRHRD   ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP      C#ERHRD
                                .WORD    306
                                .WORD    T26RWN
                                .WORD    PKTSSR
                                TRAP      C#CLP1
                                .WORD    104456
                                .WORD    000462
                                .WORD    047424
                                .WORD    011710
7884 042430 104406      130# :  CKLOOP      ;LOOP IF SELECTED
                                TRAP      C#CLP1
7885                                ;*****
7886                                ;
7887                                ;
7888                                ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
7889                                ;
7890                                ;*****
7891                                ;
7892 042432 013701 045756      MOV      T26BFR+6,R1 ;PICK UP XSTO
7893 042436 010102      MOV      R1,R2      ;SET UP EXPECTED
7894 042440 052702 000002      BIS      #BIT1,R2    ;SET BOT BIT IN EXPECTED
7895 042444 020102      CMP      R1,R2      ;DOES EXP = REC'D
7896 042446 001406      BEQ      140#        ;BR, IF EQUAL (OK)
7897 042450 004737 020116      JSR      PC,FATCHK   ;INC AND CHECK FOR MORE THAN 25 ERRORS
7901 042454      ERRHRD   ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C#ERHRD
                                .WORD    307
                                .WORD    T26BOT
                                .WORD    EXPREC
                                TRAP      C#CLP1
                                .WORD    104456
                                .WORD    000463
                                .WORD    047125
                                .WORD    016360
7902 042464 104406      140# :  CKLOOP      ;LOOP IF SELECTED
                                TRAP      C#CLP1
7903 042466 005303      DEC      R3          ;SET RECORD SIZE TO 511.
7904 042470 013737 003072 046062      MOV      FREE,T26RB  ;STARTING READ BUFFER ADDRESS
7905

```



```

7906 ;*****
7907 ;
7908 ;REREAD DATA,CVC=1,ACK,OPP=1 COMMAND
7909 ;
7910 ;*****
7911
7912 042476 012737 161401 046060      MOV      #161401,T26PK3      ;REREAD DATA,CVC=1,ACK,OPP=1 COMMAND
7913 042504 012704 046060      165$:  MOV      #T26PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
7914 042510 010337 046066      MOV      R3,T26SZ        ;SET UP RECORD SIZE IN PACKET
7915 042514 010465 177776      MOV      R4,TSDB(R5)     ;ISSUE COMMAND
7916 042520 004737 017134      JSR      PC,WAITF        ;WAIT FOR SSR TO SET
7917 042524 016501 000000      MOV      TSSR(R5),R1     ;GET TSSR CONTENTS
7918 042530 012702 100204      MOV      #SSR!SC!BIT2,R2 ;SET UP EXPECTED
7919 042534 020102                CMP      R1,R2           ;ARE THEY EQUAL
7920 042536 001406                BEQ      170$           ;BR. IF OK
7921 042540 004737 020116      JSR      PC,FATCHK       ;INC AND CHECK FOR MORE THAN 25 ERRORS
7925 042544                ERRHRD  ERRNO,T26TRL,PKTSSR ;TSSR INCORRECT AFTER REREAD DATA
                                TRAP      C#ERRHRD
                                .WORD    308
                                .WORD    T26TRL
                                .WORD    PKTSSR
7926 042554                170$:  CKLOOP                ;LOOP IF SELECTED
                                TRAP      C#CLP1
                                .WORD    104406
7927
7928 ;*****
7929 ;
7930 ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
7931 ;
7932 ;*****
7933
7934 042556 013701 045756      MOV      T26BFR+6,R1     ;GET MESSAGE BUFFER
7935 042562 010102                MOV      R1,R2           ;SET UP EXPECTED
7936 042564 052702 010000      BIS      #BIT12,R2      ;SET THE RLL BIT IN EXPECTED
7937 042570 020102                CMP      R1,R2           ;ARE THEY EQUAL
7938 042572 001406                BEQ      180$           ;BR. IF EQUAL (ALL IS WELL)
7939 042574 004737 020116      JSR      PC,FATCHK       ;INC AND CHECK FOR MORE THAN 25 ERRORS
7943 042600                ERRHRD  ERRNO,T26LON,EXPREC ;THE RLL BIT WAS NOT SET IN XSTO
                                TRAP      C#ERRHRD
                                .WORD    309
                                .WORD    T26LON
                                .WORD    EXPREC
7944 042610                180$:  MOV      #511.,R3        ;SET UP SIZE OF RECORD
7945 042610 012703 000777      MOV      FREE,T26RB      ;STARTING READ BUFFER ADDRESS
7946 042614 013737 003072 046062
7947
7948 ;*****
7949 ;
7950 ;REREAD DATA,CVC=1,ACK COMMAND
7951 ;
7952 ;*****
7953
7954 042622 012737 141401 046060      MOV      #141401,T26PK3  ;REREAD DATA,CVC=1,ACK COMMAND
7955 042630 012704 046060      365$:  MOV      #T26PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
7956 042634 010337 046066      MOV      R3,T26SZ        ;SET UP RECORD SIZE IN PACKET
7957 042640 010465 177776      MOV      R4,TSDB(R5)     ;ISSUE COMMAND
7958 042644 004737 017134      JSR      PC,WAITF        ;WAIT FOR SSR TO SET
7959 042650 016501 000000      MOV      TSSR(R5),R1     ;GET TSSR CONTENTS

```

```

7960 042654 012702 100204          MOV    #SSR!SC!BIT2,R2      ;SET UP EXPECTED
7961 042660 020102                CMP    R1,R2              ;ARE THEY EQUAL
7962 042662 001406                BEQ    370$              ;BR, IF OK
7963 042664 004737 020116        JSR    PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
7967 042670                ERRHRD  ERRNO,T26TRL,PKTSSR ;TSSR INCORRECT AFTER REREAD DATA
                                TRAP    C$ERRHRD
                                .WORD   310
                                .WORD   T26TRL
                                .WORD   PKTSSR
                                7968 042700 104406          370$: CKLOOP              ;LOOP IF SELECTED
                                TRAP    C$CLP1
7969                                ;*****
7970                                ;
7971                                ; READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
7972                                ;
7973                                ;*****
7974                                ;
7975                                ;
7976 042702 013701 045756          MOV    T26BFR+6,R1       ;GET MESSAGE BUFFER
7977 042706 010102                MOV    R1,R2              ;SET UP EXPECTED
7978 042710 052702 010000        BIS    #BIT12,R2         ;SET THE RLL BIT IN EXPECTED
7979 042714 020102                CMP    R1,R2              ;ARE THEY EQUAL
7980 042716 001406                BEQ    380$              ;BR, IF EQUAL (ALL IS WELL)
7981 042720 004737 020116        JSR    PC,FATCHK         ;INC AND CHECK FOR MORE THAN 25 ERRORS
7985 042724                ERRHRD  ERRNO,T26LON,EXPREC ;THE RLL BIT WAS NOT SET IN XSTO
                                TRAP    C$ERRHRD
                                .WORD   311
                                .WORD   T26LON
                                .WORD   EXPREC
7986 042734                380$: ENDSUB
7987 042734                                ;>>>>>>>>>> END SUBTEST >>>>>>>>>>
                                ;10061:
                                TRAP    C$ESUB
7988 042736 023727 002170 000031  CMP    FATELG,#25,      ;IS ERROR COUNT AT 25
7989 042744 002402                BLT    999$              ;BR, IF LESS THAN 25
7990 042746 004737 020170        JSR    PC,CKDRUP         ;TRY TO DROP THE UNIT
7991 042752                999$:

```



```

      043042 011676
8047 043044          26$: CKLOOP          ;LOOP IF SELECTED          .WORD SFIMSG
      043044 104406          TRAP          C$CLP1
8048
8049          ;*****
8050          ;
8051          ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
8052          ;
8053          ;*****
8054
8055 043046 004737 010444          JSR      PC,REWIND          ;CALL TAPE REWIND COMMAND
8056 043052 016501 000000          MOV      TSSR(R5),R1          ;GET TSSR
8057 043056 012702 000200          MOV      #SSR,R2          ;SET UP EXPECTED TSSR
8058 043062 103407          BCS      30$          ;BR, IF NO PROBLEM
8059 043064 010004          MOV      R0,R4          ;PACKET ADDRESS SET UP
8060 043066 004737 020116          JSR      PC,FATCHK          ;INC AND CHECK FOR MORE THAN 25 ERRORS
8064 043072          ERRHRD  ERRNO,T26RWN,PKTSSR          ;REWIND NOT ACCEPTED
      043072 104456          TRAP          C$ERHRD
      043074 000472          .WORD          314
      043076 047414          .WORD          T26RWN
      043100 011710          .WORD          PKTSSR
8065 043102          30$: CKLOOP          ;LOOP IF SELECTED          TRAP          C$CLP1
      043102 104406
8066
8067          ;*****
8068          ;
8069          ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XST0)
8070          ;
8071          ;*****
8072
8073 043104 013701 045756          MOV      T26BFR+6,R1          ;PICK UP XST0
8074 043110 010102          MOV      R1,R2          ;SET UP EXPECTED
8075 043112 052702 000002          BIS      #BIT1,R2          ;SET BOT BIT IN EXPECTED
8076 043116 020102          CMP      R1,R2          ;DOES EXP = REC'D
8077 043120 001406          BEQ      40$          ;BR, IF EQUAL (OK)
8078 043122 004737 020116          JSR      PC,FATCHK          ;INC AND CHECK FOR MORE THAN 25 ERRORS
8082 043126          ERRHRD  ERRNO,T26BOT,EXPREC          ;TAPE NOT AT BOT AFTER REWIND
      043126 104456          TRAP          C$ERHRD
      043130 000473          .WORD          315
      043132 047125          .WORD          T26BOT
      043134 016360          .WORD          EXPREC
8083 043136          40$: CKLOOP          ;LOOP IF SELECTED          TRAP          C$CLP1
      043136 104406
8084 043140 012703 000400          MOV      #256,R3          ;RECORD SIZE
8085 043144 013737 003072 046062          MOV      FREE,T26RB          ;STARTING WRITE BUFFER ADDRESS
8086
8087          ;*****
8088          ;
8089          ;WRITE DATA,CVC=1,ACK COMMAND
8090          ;
8091          ;*****
8092
8093 043152 012737 140005 046060          MOV      #140005,T26PK3          ;WRITE DATA,CVC=1,ACK COMMAND
8094 043160 012704 046060          MOV      #T26PK3,F.4          ;SET UP R4 WITH PACKET ADDRESS
8095 043164
8096 043164 010357 046066          65$: MOV      R3,T26SZ          ;SET UP RECCRD SIZE IN PACKET
8097 043170 010465 177776          MOV      R4,T50B(R5)          ;ISSUE COMMAND

```

```

8098 043174 004737 017134      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
8099 043200 016501 000000      MOV      TSSR(R5),R1  ;GET TSSR CONTENTS
8100 043204 012702 000200      MOV      #SSR,R2     ;SET UP EXPECTED
8101 043210 020102              CMP      R1,R2       ;ARE THEY EQUAL
8102 043212 001406              BEQ      75#         ;BR, IF OK
8103 043214 004737 020116      JSR      PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
8107                                ;SOFT ERROR GENERATED BECAUSE THE
8108                                ;WRITE COMMAND IS NOT BEING CHECKED
8109                                ;HERE. IT WAS CHECKED IN LEAH2
8110 043220              ERRSFT ERRNO,WRERR,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      043220 104457              TRAP      C#ERSOFT
      043222 000474              .WORD    316
      043224 005011              .WORD    WRERR
      043226 011710              .WORD    PKTSSR
8111 043230 104406      75# :   CKLOOP              ;LOOP IF SELECTED
      043230 104406              TRAP      C#CLP1
8112 043232              120# :
8113                                ;*****
8114                                ;
8115                                ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
8116                                ;
8117                                ;*****
8118                                ;
8119                                ;
8120 043232 004737 010444      JSR      PC,REWIND    ;CALL TAPE REWIND COMMAND
8121 043236 016501 000000      MOV      TSSR(R5),R1  ;GET TSSR
8122 043242 012702 000200      MOV      #SSR,R2     ;SET UP EXPECTED TSSR
8123 043246 103407              BCS      130#        ;BR, IF NO PROBLEM
8124 043250 010004              MOV      R0,R4       ;PACKET ADDRESS SET UP
8125 043252 004737 020116      JSR      PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
8129 043256              ERRHRD ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
      043256 104456              TRAP      C#ERHRD
      043260 000475              .WORD    317
      043262 047414              .WORD    T26RWN
      043264 011710              .WORD    PKTSSR
8130 043266 104406      130# :  CKLOOP              ;LOOP IF SELECTED
      043266 104406              TRAP      C#CLP1
8131                                ;*****
8132                                ;
8133                                ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
8134                                ;
8135                                ;*****
8136                                ;
8137                                ;
8138 043270 013701 045756      MOV      T26BFR+6,R1  ;PICK UP XSTO
8139 043274 010102              MOV      R1,R2       ;SET UP EXPECTED
8140 043276 052702 000002      BIS      #BIT1,R2    ;SET BOT BIT IN EXPECTED
8141 043302 020102              CMP      R1,R2       ;DOES EXP = REC'D
8142 043304 001406              BEQ      135#        ;BR, IF EQUAL (OK)
8143 043306 004737 020116      JSR      PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
8147 043312              ERRHRD ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      043312 104456              TRAP      C#ERHRD
      043314 000475              .WORD    318
      043316 047125              .WORD    T26BOT
      043320 016350              .WORD    EXPREC
8148 043322 104406      135# :  CKLOOP              ;LOOP IF SELECTED
      043322 104406              TRAP      C#CLP1

```

```

8149 043324 012703 001000          MOV    #512.,R3          ;RECORD SIZE
8150 043330 013737 003072 046062  MOV    FREE,T26RB      ;STARTING READ BUFFER ADDRESS
8151
8152 ;*****
8153 ;
8154 ;REREAD NEXT,ACK,CVC=1,OPP=1
8155 ;
8156 ;*****
8157
8158 043336 012737 161401 046060 165$: MOV    #161401,T26PK3  ;REREAD NEXT,ACK,CVC=1,OPP=1
8159 043344 012704 046060          MOV    #T26PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
8160 043350 010337 046066          MOV    R3,T26SZ       ;SET UP RECORD SIZE IN PACKET
8161 043354 010465 177776          MOV    R4,TSDB(R5)    ;ISSUE COMMAND
8162 043360 004737 017134          JSR    PC,WAITF       ;WAIT FOR SSR TO SET
8163 043364 016501 000000          MOV    TSSR(R5),R1    ;GET TSSR CONTENTS
8164 043370 012702 100204          MOV    #SSR!SC!BIT2,R2 ;SET UP EXPECTED
8165 043374 020102          CMP    R1,R2         ;ARE THEY EQUAL
8166 043376 001406          BEQ    170$         ;BR, IF OK
8167 043400 004737 020116          JSR    PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
8171 043404          ERRHRD ERRNO,T26TRL,PKTSSR ;TSSR INCORRECT AFTER READ DATA
                                TRAP    C$ERHRD
                                .WORD  319
                                .WORD  T26TRL
                                .WORD  PKTSSR
                                TRAP    C$CLP1
                                .WORD  104456
                                .WORD  000477
                                .WORD  050472
                                .WORD  011710
8172 043414 104406 170$: CKLOOP          ;LOOP IF SELECTED
                                TRAP    C$CLP1
                                .WORD  104406
8173
8174 ;*****
8175 ;
8176 ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
8177 ;
8178 ;*****
8179
8180 043416 013701 045756          MOV    T26BFR+6,R1    ;GET MESSAGE BUFFER
8181 043422 010102          MOV    R1,R2         ;SET UP EXPECTED
8182 043424 052702 040000          BIS    #BIT14,R2     ;SET THE RLS BIT IN EXPECTED
8183 043430 020102          CMP    R1,R2         ;ARE THEY EQUAL
8184 043432 001406          BEQ    180$         ;BR, IF EQUAL (ALL IS WELL)
8185 043434 004737 020116          JSR    PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
8189 043440          ERRHRD ERRNO,T26LOP,EXPREC ;THE RLL BIT WAS NOT SET IN XSTO
                                TRAP    C$ERHRD
                                .WORD  320
                                .WORD  T26LOP
                                .WORD  EXPREC
                                TRAP    C$ERHRD
                                .WORD  104456
                                .WORD  000500
                                .WORD  050322
                                .WORD  016360
8190 043450 180$:
8191 043450 013701 045754          MOV    T26BFR+4,R1    ;PICK UP RESIDUAL BYTE COUNTER
8192 043454 012702 000400          MOV    #256.,R2      ;THIS SHOULD BE THE DIFFERENCE
8193 043460 020102          CMP    R1,R2         ;IS THE DIFFERENCF CORRECT
8194 043462 001405          BEQ    190$         ;BR, IF CORRECT
8198 043466          ERRHRD ERRNO,T26PBP,EXPREC ;RBPCT NOT CORRECT
                                TRAP    C$ERHRD
                                .WORD  320
                                .WORD  T26PBP
                                .WORD  EXPREC
                                TRAP    C$CLP1
                                .WORD  104456
                                .WORD  000500
                                .WORD  050404
                                .WORD  016360
8199 043476 104406 190$: CKLOOP          ;LOOP IF SELECTED
8200 043500 012703 001000          MOV    #512.,R3      ;RECORD SIZE

```


USER DOCUMENTATIONB1	SPACE - SPACE RECO....B5	GETSEL - ISSUE MENU....B9	TEST 2: REREADSB13	
USER DOCUMENTATIONC1	SPACE - SPACE RECO....C5	CHKMAN - CHECK MANU....C9	TEST 2: REREADSC13	
USER DOCUMENTATIOND1	SPACE - SPACE RECO....D5	ENVIRN - SETUP FREE....D9	TEST 2: REREADSD13	
USER DOCUMENTATIONE1	WRTPHR - WRITE CHAR....E5	KTINIT - SETUP KT11....E9	TEST 2: REREADSE13	
USER DOCUMENTATIONF1	REWIND - POSITION T....F5	PROTECTION TABLEF9	TEST 2: REREADSF13	
USER DOCUMENTATIONG1	CKRAM - COMPARE RA....G5	INITIALIZE SECTIONG9	TEST 2: REREADSG13	
USER DOCUMENTATIONH1	RAMER - READ AND DIS....H5	INITIALIZE SECTIONH9	TEST 2: REREADSH13	
USER DOCUMENTATIONI1	RAMER - READ AND DIS....I5	INITIALIZE SECTIONI9	TEST 2: REREADSI13	
USER DOCUMENTATIONJ1	CKRAM2 - COMPARE RA....J5	ADD AND DROP UNITS S....J9	TEST 2: REREADSJ13	
USER DOCUMENTATIONK1	CKMSG - COMPARE WR....K5	ADD AND DROP UNITS S....K9	TEST 2: REREADSK13	
USER DOCUMENTATIONL1	CKMSG2 - COMPARE EX....L5	CLEAN-UP AND REPORTL9	TEST 2: REREADSL13	
USER DOCUMENTATIONM1	CKMSG2 - COMPARE EX....M5	CLEAN-UP AND REPORTM9	TEST 2: REREADSM13	
USER DOCUMENTATIONN1	CKMSG2 - COMPARE EX....N5	TEST 1: SPACE RECOR....N9	TEST 2: REREADSN13	
USER DOCUMENTATIONB2	CKMSG2 - COMPARE EX... B6	TEST 1: SPACE RECOR....B10	TEST 2: REREADSB14	
USER DOCUMENTATIONC2	ADDSSR - PRINT TEST....C6	TEST 1: SPACE RECOR....C10	TEST 2: REREADSC14	
USER DOCUMENTATIOND2	FIFEXP - PRINT FIFO....D6	TEST 1: SPACE RECOR....D10	TEST 2: REREADSD14	
USER DOCUMENTATIONE2	MSGSTAT - PRINT STAT....E6	TEST 1: SPACE RECOR....E10	TEST 2: REREADSE14	
USER DOCUMENTATIONF2	MSGLOOP - PRINT LOOP....F6	TEST 1: SPACE RECOR....F10	TEST 2: REREADSF14	
USER DOCUMENTATIONG2	MSGSUB - PRINT WRITE....G6	TEST 1: SPACE RECOR....G10	TEST 2: REREADSG14	
USER DOCUMENTATIONH2	PRAMPKT - PRINT RAM ...H6	TEST 1: SPACE RECOR....H10	TEST 2: REREADSH14	
PROGRAM HEADERI2	PRMESS - PRINT CONT....I6	TEST 1: SPACE RECOR....I10	TEST 2: REREADSI14	
PROGRAM HEADERJ2	PRMESS - PRINT CONT....J6	TEST 1: SPACE RECOR....J10	TEST 2: REREADSJ14	
DEFAULT HARDWARE P-T....K2		PRMESS - PRINT CONT....K6	TEST 1: SPACE RECOR....K10	TEST 2: REREADSK14	
SOFTWARE P-TABLEL2	PRMSGEXP - PRINT EXP....L6	TEST 1: SPACE RECOR....L10	TEST 2: REREADSL14	
SOFTWARE P-TABLEM2	PRMSGEXP - PRINT EXP....M6	TEST 1: SPACE RECOR....M10	TEST 2: REREADSM14	
GLOBAL EQUATES SECTI....N2		PRBYTEXP - PRINT ERR....N6	TEST 1: SPACE RECOR....N10	TEST 2: REREADSN14	
MEMORY MANAGEMENT DE....B3		PRBYTEXP - PRINT ERR....B7	TEST 1: SPACE RECOR....B11	TEST 2: REREADSB15	
MEMORY MANAGEMENT DE....C3		EXPREC - PRINT EXPD....C7	TEST 1: SPACE RECOR....C11	TEST 2: REREADSC15	
TK-25 REGISTER AND P....D3		EXPREC - PRINT EXPD....D7	TEST 1: SPACE RECOR....D11	TEST 2: REREADSD15	
TK-25 REGISTER AND P....E3		RAMTADD - PRINT TEST....E7	TEST 1: SPACE RECOR....E11	TEST 2: REREADSE15	
TK-25 REGISTER AND P....F3		TIMEXP - PRINT TIME....F7	TEST 1: SPACE RECOR....F11	TEST 2: REREADSF15	
TK-25 REGISTER AND P....G3		BADSSR - PRINT TSSRG7	TEST 1: SPACE RECOR....G11	TEST 2: REREADSG15	
TK-25 REGISTER AND P....H3		GLOBAL SUBROUTINES S....H7	TEST 1: SPACE RECOR....H11	TEST 2: REREADSH15	
TK-25 REGISTER AND P....I3		SOFINIT - SOFT INITI....I7	TEST 1: SPACE RECOR....I11	TEST 2: REREADSI15	
TK-25 REGISTER AND P....J3		CHKAMB - CHECK TSSR....J7	TEST 1: SPACE RECOR....J11	TEST 2: REREADSJ15	
SPECIAL MACROS AND U....K3		ENAINIT,DSBINT - ENAB....K7	TEST 1: SPACE RECOR....K11	TEST 2: REREADSK15	
SPECIAL MACROS AND U....L3		INTR - INTERRUPTL7	TEST 1: SPACE RECOR....L11	TEST 2: REREADSL15	
GLOBAL DATA SECTIONM3		WAIT - WAIT FOR S....M7	TEST 1: SPACE RECOR....M11	TEST 2: REREADSM15	
TSTBLK - TEST DATAN3		CHKTSSR - CHECK TSSR....N7	TEST 1: SPACE RECOR....N11	TEST 2: REREADSN15	
GLOBAL ENVIRONMENT S....B4		XNXM - CHECK FORB8	TEST 1: SPACE RECOR....B12	TEST 2: REREADSB16	
GLOBAL TEXT MESSAGES....C4		TSTLOOP - CHECK ITER....C8	TEST 1: SPACE RECOR....C12	TEST 2: REREADSC16	
GLOBAL TEXT MESSAGES....D4		TSTSETUP - PRINT TES....D8	TEST 1: SPACE RECOR....D12	TEST 2: REREADSD16	
GLOBAL ERROR REPORTE4		TSTEND - PRINT ERRO....E8	TEST 1: SPACE RECOR....E12	TEST 2: REREADSE16	
PRITSSR - PRINT TSSR....F4		INCERK - INCREMENT ...F8	TEST 2: REREADSF12	TEST 2: REREADSF16
PRITSSR - PRINT TSSR....G4		CKDROP - CHECK IF U....G8	TEST 2: REREADSG12	TEST 2: REREADSG16
PRITSSR - PRINT TSSR....H4		KTON,KTOFF - EN....H8	TEST 2: REREADSH12	TEST 2: REREADSH16
PRTPKT - PRINT THEI4		SETMAP - SETUP PAR6....I8	TEST 2: REREADSI12	TEST 2: REREADSI16
PRIPKT - PRINT THEJ4		FILLMEM - FILL MEMOR....J8	TEST 2: REREADSJ12	TEST 2: REREADSJ16
PRIBXOR - PRINT EXPD....K4		CMPMEM - COMPARE ME....K8	TEST 2: REREADSK12	TEST 2: REREADSK16
PRI XOR - PRINT EXPD....L4		CMPMEM - COMPARE ME....L8	TEST 2: REREADSL12	TEST 2: REREADSL16
PRIEQU - PRINT BITM4		REGSAV - SAVE R1-R5....M8	TEST 2: REREADSM12	TEST 2: REREADSM16
PRIADD - PRINT MEMO....N4		GETPAT - GET 8 BITN8	TEST 2: REREADSN12	TEST 2: REREADSN16

D1

CZIKGA TK-25 FBI END FUNC #3
TEST 2: REREADS

MACRO M1200 20-APR-84 08:13 PAGE 109-1

SEQ 210

```

8311 043764 004737 020116      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
8315 043770 010001              MOV    R0,R1          ;SAVE CONTENTS OF TSSR
8316 043772              ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP    C#ERHRD
                                .WORD   324
                                .WORD   WRTMSG
                                .WORD   SFIMSG
8317 044002 104406      26$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP    C#CLP1
8318
8319
8320
8321
8322
8323
8324
8325 044004 004737 010444      JSR    PC,REWIND      ;CALL TAPE REWIND COMMAND
8326 044010 103411              BCS    30$            ;BR, IF NO PROBLEM
8327 044012 016501 000000      MOV    TSSR(R5),R1   ;GET TSSR
8328 044016 010004              MOV    R0,R4          ;PACKET ADDRESS SET UP
8329 044020 004737 020116      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
8333 044024              ERRHRD  ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP    C#ERHRD
                                .WORD   325
                                .WORD   T26RWN
                                .WORD   PKTSSR
8334 044034 104406      30$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP    C#CLP1
8335
8336
8337
8338
8339
8340
8341
8342 044036 013701 045756      MOV    T26BFR+6,R1   ;PICK UP XSTO
8343 044042 010102              MOV    R1,R2          ;SET UP EXPECTED
8344 044044 052702 000002      BIS    #BIT1,R2      ;SET BOT BIT IN EXPECTED
8345 044050 020102              CMP    R1,R2          ;DOES EXP = REC'D
8346 044052 001406              BEQ    40$            ;BR, IF EQUAL (OK)
8347 044054 004737 020116      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
8351 044060              ERRHRD  ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP    C#ERHRD
                                .WORD   326
                                .WORD   T26BOT
                                .WORD   EXPREC
8352 044070 104406      40$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP    C#CLP1
8353 044072 013737 003072 046062      MOV    FREE,T26RB    ;STARTING WRITE BUFFER ADDRESS
8354
8355
8356
8357
8358
8359
8360
8361 044100 012737 140005 046060      MOV    #140005,T26PK3 ;WRITE DATA,CVC=1,ACK COMMAND

```

KIPDR7=	172316	L\$SOFT	065620 G	L10061	042734	NXRK	003675	PRMESS	014072
KTENAB	003102 G	L\$SPC	002056 G	L10062	043654	NXTU	022224	PRMNO	002264 G
KTFLG	003100 G	L\$SPCP	002020 G	L10063	044652	OFL	= 000100	PRMSGE	015436 G
KTINIT	021636	L\$SPTP	002024 G	L10064	045222	ONEFIL	= 000000	PRMSG0	015616
KTOFF	020262	L\$STA	002030 G	L10065	045664	O\$APTS	= 000000	PRMSG1	015663
KTON	020244	L\$SW	002134 G	L10066	061032	O\$AU	= 000001	PRMSG2	015721
LERRMA	002140 G	L\$TEST	002114 G	L10067	051456	O\$BGNR	= 000001	PROASC	014730
LISTAL	= 000001	L\$TIML	002014 G	L10070	052230	O\$BGNS	= 000001	PR1ASC	014775
LOE	= 040000 G	L\$UNIT	002012 G	L10071	053044	O\$DU	= 000001	PST32W	003104 G
LOOPCN	002164 G	L10000	002132	L10072	053740	O\$ERRT	= 000000	PUNIT	022512
LOOPCO	012770	L10001	002144	L10073	055456	O\$GNSW	= 000001	PW.D11	= 000021
LOOPFL	003114 G	L10002	005226	L10074	065454	O\$POIN	= 000001	PW.D13	= 000022
LOT	= 000010 G	L10003	011706	L10075	063150	O\$SETU	= 000001	PW.D22	= 000020
L\$ACP	002110 G	L10004	011736	L10076	065512	PASRPT	022256	PW.NOP	= 000000
L\$APT	002036 G	L10005	011754	L10077	065634	PATCH	006022 G	PW.N01	= 000023
L\$AU	022560 G	L10006	011762	L10100	066032	PATDAT	021150	PW.RDE	= 000024
L\$AUT	002070 G	L10007	012000	L10102	066040	PC.ERA	= 002400	PW.RDR	= 000001
L\$AUTO	022764 G	L10010	012016	MEMADD	013616 G	PC.IER	= 002000	PW.RDS	= 000005
L\$CCP	002106 G	L10011	012030	MENASC	021367	PC.N00	= 001000	PW.RFI	= 000003
L\$CLEA	023040 G	L10012	012102	MENERR	021314	PC.REL	= 000000	PW.WCT	= 000006
L\$CO	002032 G	L10013	012252	MENRES	021416	PC.REW	= 000400	PW.WFI	= 000004
L\$DEPO	002011 G	L10014	012766	MESBFA	002716 G	PKBCNT	= 000006	PW.WFM	= 000007
L\$DESC	003342 G	L10015	013614	MESBFN	014650	PKHI	= 000004	PW.WMI	= 000010
L\$DESP	002076 G	L10016	013636	MESHEA	015033	PKLOW	= 000002	PW.WNP	= 000011
L\$DEVP	002060 G	L10017	016364	MMVEC	= 000250	PKTADD	007302	PW.WTR	= 000002
L\$DISP	066012 G	L10020	016372	MPR	= 174406	PKTFRM	007244	P.ACK	= 100000
L\$DLY	002116 G	L10021	016400	MSA.FR	= 000006	PKTGET	011740 G	P.CMD	= 000037
L\$DTP	002040 G	L10022	016412	MSA.NO	= 000000	PKTMES	011764 G	P.CONT	= 000012
L\$DTYP	002034 G	L10023	016434	MSA.NR	= 000004	PKTNEW	007337	P.CVC	= 040000
L\$DU	022656 G	L10024	016462	MSA.VO	= 000002	PKTRAM	004643 G	P.FMT	= 000140
L\$DUT	002072 G	L10025	016622	MSGEXP	012020 G	PKTSSR	011710 G	P.FORM	= 000011
L\$DVTY	003334 G	L10026	017132	MSGLOO	012726 G	PNT	= 001000 G	P.GETS	= 000017
L\$EF	002052 G	L10030	022510	MSGSTA	012212 G	PRAMPK	013640	P.IE	= 000200
L\$ENVI	002044 G	L10031	022654	MSGSUB	013604 G	PRBEXP	016354	P.INIT	= 000013
L\$ETP	002102 G	L10032	022762	MS.ATT	= 000006	PRBMSG	016222	P.MODE	= 007400
L\$EXP1	002046 G	L10033	023036	MS.EXT	= 000200	PRBREC	016356	P.OPP	= 020000
L\$EXP4	002064 G	L10034	023064	MS.RSD	= 000001	PRBTOT	016307	P.POSI	= 000010
L\$EXP5	002066 G	L10035	023326	MS.RSF	= 000020	PRBYTE	016006 G	P.READ	= 000001
L\$HARD	065460 G	L10036	031664	MS.RST	= 000010	PRI	= 002000 G	P.SMB	= 010000
L\$HIME	002120 G	L10037	024372	NBA	= 002000	PRIADD	007716	P.WRIT	= 000005
L\$HPCP	002016 G	L10040	025032	NEWPAS	022212	PRIAO	007766	P.WRTC	= 000004
L\$HPTP	002022 G	L10041	025466	NODEV	003062 G	PRIBXO	007350 G	P.WRTS	= 000006
L\$HW	002124 G	L10042	026216	NOINIT	004233	PRIEQU	007616	QVP	002152 G
L\$ICP	002104 G	L10043	027144	NOINTR	004117	PRIPKT	007076 G	RAMASC	014006
L\$INIT	022000 G	L10044	027454	NOITS	002136 G	PRIRAM	007624	RAMDAY	002206 G
L\$LADP	002026 G	L10045	030044	NOMAN	021454	PRITAD	010032	RAMER	010646 G
L\$LAST	066026 G	L10046	051034	NP.IR	= 000200	PRITSS	005264	RAMERR	016374 G
L\$LOAD	002100 G	L10047	032616	NP.LOO	= 000040	PRITO	010102	RAMEXP	016414 G
L\$LUN	002074 G	L10050	033454	NP.OUT	= 000100	PRIOR	007500 G	RAMFHR	014552
L\$MREV	002050 G	L10051	034340	NP.WRP	= 000020	PRI00	= 000000 G	RAMFOR	007654
L\$NAME	002000 G	L10052	035260	NSI	004050	PRI01	= 000040 G	RAMILD	011030
L\$PRIO	002042 G	L10053	036026	NSINIT	004305	PRI02	= 000100 G	RAMIOP	011034
L\$PROT	021770 G	L10054	036656	NUL	004425	PRI03	= 000140 G	RAMPD	011105
L\$PRT	002112 G	L10055	037520	NULCR	004426	PRI04	= 000200 G	RAMR5H	011032
L\$REPP	002062 G	L10056	040362	NXM	= 004000	PRI05	= 000240 G	RAMSIZ	002246 G
L\$REV	002010 G	L10057	041230	NXR	003636	PRI06	= 000300 G	RAMTAD	016402 G
L\$RPT	023066 G	L10060	042076	NXRERR	005176 G	PRI07	= 000340 G	RBPORA	015145

F1

CZTKGA TK-25 FRT END FUNC #3
TEST 2: REREADS

MACRO M1200 20-APR-84 08:13 PAGE 109-3

SEQ 212

```

8415 044264 004737 020116      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
8419 044270      ERRHRD  ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      044270 104456      TRAP      C$ERHRD
      044272 000511      .WORD    329
      044274 047125      .WORD    T26BOT
      044276 016360      .WORD    EXPREC
8420 044300      140$:  CKLOOP      ;LOOP IF SELECTED
      044300 104406      TRAP      C$CLP1
8421 044302 012703 046076      MOV      #T26RN,R3      ;COMMAND BUFFER ADDRESS
8422 044306 012737 177376 046062 150$:  MOV      #177376,T26RB  ;STARTING READ BUFFER ADDRESS
8423 044314 012737 000077 046064  MOV      #000077,T26RB+2 ;SET UP HIGH ORDER ADDRESS BITS
8424
8425 ;*****
8426 ;
8427 ;REREAD DATA,IE,ACK, OPP COMMAND
8428 ;
8429 ;*****
8430
8431 044322 011337 046060      MOV      (R3),T26PK3    ;REREAD DATA,IE,ACK, OPP COMMAND
8432 044326 012704 046060      MOV      #T26PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
8433 044332 012737 000400 046066 165$:  MOV      #256.,T26SZ    ;SET UP RECORD SIZE IN PACKET
8434 044340 010465 177776      MOV      R4,TSDB(R5)    ;ISSUE COMMAND
8435 044344 004737 017134      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
8436 044350 016501 000000      MOV      TSSR(R5),R1    ;GET TSSR CONTENTS
8437 044354 012702 104210      MOV      #SSR!NXM!SC!BIT3,R2 ;SET UP EXPECTED
8438 044360 020102      CMP      R1,R2          ;ARE THEY EQUAL
8439 044362 001414      BEQ      170$          ;BR, IF OK
8440 044364 031327 001000      BIT      (R3),#BIT9    ;CHECK FOR A READ COMMAND
8441 044370 001403      BEQ      168$          ;BR, IF IT WAS A READ COMMAND
8442 044372 030127 000002      BIT      R1,#BIT1     ;WAS BIT1 SET
8443 044376 001006      BNE      170$          ;BR, IF REREAD AND BIT1 SET
8444 044400
8445 044400 004737 020116      168$:  JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
8449 044404      ERRHRD  ERRNO,T26RRF,PKTSSR ;TSSR INCORRECT AFTER REREAD DATA
      044404 104456      TRAP      C$ERHRD
      044406 000512      .WORD    330
      044410 046335      .WORD    T26RRF
      044412 011710      .WORD    PKTSSR
8450 044414      170$:  CKLOOP      ;LOOP IF SELECTED
      044414 104406      TRAP      C$CLP1
8451
8452 ;*****
8453 ;
8454 ;READ DATA, ACK,CVC=1 COMMAND
8455 ;
8456 ;*****
8457
8458 044416 012737 140001 046060      MOV      #140001,T26PK3 ;READ DATA, ACK,CVC=1 COMMAND
8459 044424 012737 000400 046066      MOV      #256.,T26SZ    ;SET SIZE INTO PACKET
8460 044432 005037 046064      CLR      T26RB+2        ;CLEAR OUT HIGH ADDRESS BITS
8461 044436 013737 003072 046062      MOV      FREE,T26RB     ;GIVE READ A GOOD BUFFER
8462 044444 010465 177776      MOV      R4,TSDB(R5)    ;ISSUE READ DATA COMMAND
8463 044450 004737 017134      JSR      PC,WAITF      ;WAIT FOR SSR
8464 044454 016501 000000      MOV      TSSR(R5),R1    ;PICK UP THE TSSR
8465 044460 012702 000200      MOV      #SSR,R2        ;SET UP EXPECTED
8466 044464 020102      CMP      R1,R2          ;IS THE TSSR OK
8467 044466 001406      BEQ      180$          ;BR, IF TSSR OK (GOOD)

```

```

8468 044470 004737 020116      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
8472 044474      ERRHRD  ERRNO,RDERR,PKTSSR ;READ DATA COMMAND FAILED
      044474 104456      TRAP      C$ERHRD
      044476 000513      .WORD    331
      044500 005104      .WORD    RDERR
      044502 011710      .WORD    PKTSSR
8473 044504      180$:  CKLOOP      ;LOOP IF SELECTED
      044504 104406      TRAP      C$CLP1
8474 044506 017701 136360      MOV      @FREE,R1      ;FIRST WORD FROM READ BUFFER
8475 044512 012702 000001      MOV      @1,R2        ;SET UP EXPECTED
8476 044516 020102      CMP      R1,R2        ;IS TAPE POSITION CORRECT
8477 044520 001406      BEQ      190$        ;KEEP GOING POSITION OK
8478 044522 004737 020116      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
8482 044526      ERRHRD  ERRNO,T26WNG,EXPREC ;TAPE POSITION INCORRECT
      044526 104456      TRAP      C$ERHRD
      044530 000514      .WORD    332
      044532 046116      .WORD    T26WNG
      044534 016360      .WORD    EXPREC
8483 044536      190$:  CKLOOP
      044536 104406      TRAP      C$CLP1
8484
8485      ;*****
8486      ;
8487      ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
8488      ;
8489      ;*****
8490
8491 044540 004737 010444      JSR      PC,REWIND      ;CALL TAPE REWIND COMMAND
8492 044544 103411      BCS      194$        ;BR, IF NO PROBLEM
8493 044546 016501 000000      MOV      TSSR(R5),R1   ;GET TSSR
8494 044552 010004      MOV      RO,R4        ;PACKET ADDRESS SET UP
8495 044554 004737 020116      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
8499 044560      ERRHRD  ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
      044560 104456      TRAP      C$ERHRD
      044562 000515      .WORD    333
      044564 047414      .WORD    T26RWN
      044566 011710      .WORD    PKTSSR
8500 044570      194$:  CKLOOP      ;LOOP IF SELECTED
      044570 104406      TRAP      C$CLP1
8501
8502      ;*****
8503      ;
8504      ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
8505      ;
8506      ;*****
8507
8508 044572 013701 045756      MOV      T268FR+6,R1   ;PICK UP XSTO
8509 044576 010102      MOV      R1,R2        ;SET UP EXPECTED
8510 044600 012702 000002      B15     @BIT1,R2      ;SET BOT BIT IN EXPECTED
8511 044604 020102      CMP      R1,R2        ;DOES EXP = REC'D
8512 044606 001406      BEQ      196$        ;BR, IF EQUAL (OK)
8513 044610 004737 020116      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
8517 044614      ERRHRD  ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      044614 104456      TRAP      C$ERHRD
      044616 000516      .WORD    334
      044620 047125      .WORD    T26BOT
      044622 016360      .WORD    EXPREC

```


H5

CZTKGA TK-25 FRI END FUNC 03
TEST 4: WRITE/READ TAPE MARK

MACRO M1200 20-APR-84 08:13 PAGE 124-9

SEQ 266

10907 063174 000137 061100
10908 063200
10909 063200
 063200 104432
 063202 002252

1634: JMP T28LOOP
 EXIT TST

;EXECUTE AGAIN
;ALL DONE THIS TEST

TRAP C#EXIT
.WORD L10074-.

J1

```

8593
8594
8595
8596
8597
8598
8599
8600 044766 004737 010444
8601 044772 016501 000000
8602 044776 012702 000200
8603 045002 103407
8604 045004 010004
8605 045006 004737 020116
8609 045012
      045012 104456
      045014 000521
      045016 047414
      045020 011710
8610 045022
      045022 104406
8611
8612
8613
8614
8615
8616
8617
8618 045024 013701 045756
8619 045030 010102
8620 045032 052702 000002
8621 045036 020102
8622 045040 001406
8623 045042 004737 020116
8627 045046
      045046 104456
      045050 000522
      045052 047125
      045054 016360
8628 045056
      045056 104406
8629 045060 012737 000400 046066
8630 045066 013737 003072 046062
8631 045074 005703
8632 045076 001404
8633
8634
8635
8636
8637
8638
8639
8640 045100 012737 161001 046060
8641 045106 000403
8642
8643
8644
8645

;*****
;
;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
;
;*****
26$: JSR    PC,REWIND          ;CALL TAPE REWIND COMMAND
      MOV    TSSR(R5),R1      ;GET TSSR
      MOV    #SSR,R2          ;SET UP EXPECTED TSSR
      BCS    30$              ;BR, IF NO PROBLEM
      MOV    R0,R4            ;PACKET ADDRESS SET UP
      JSR    PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
      ERRHRD ERRNO,T26RWN,PKTSSR ;REWIND NOT ACCEPTED
                                     TRAP    C$ERHRD
                                     .WORD   337
                                     .WORD   T26RWN
                                     .WORD   PKTSSR
30$:  CKLOOP                  ;LOOP IF SELECTED
                                     TRAP    C$CLP1
;*****
;
;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
;
;*****
      MOV    T26BFR+6,R1      ;PICK UP XSTO
      MOV    R1,R2            ;SET UP EXPECTED
      BIS    #BIT1,R2        ;SET BOT BIT IN EXPECTED
      CMP    R1,R2            ;DOES EXP = REC'D
      BEQ    40$              ;BR, IF EQUAL (OK)
      JSR    PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
      ERRHRD ERRNO,T26BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                     TRAP    C$ERHRD
                                     .WORD   338
                                     .WORD   T26BOT
                                     .WORD   EXPREC
40$:  CKLOOP                  ;LOOP IF SELECTED
                                     TRAP    C$CLP1
      MOV    #256.,T26SZ      ;SET UP RECORD SIZE IN PACKET
      MOV    FREE,T26RB       ;ADDRESS OF READ BUFFER
      TST    R3                ;CHECK NUMBER OF TIMES THROUGH HERE
      BEQ    50$              ;BR, IF FIRST TIME THROUGH HERE
;*****
;
;REREAD,CVC=1,ACK COMMAND
;
;*****
      MOV    #161001,T26PK3   ;REREAD,CVC=1,ACK COMMAND
      BR     55$              ;SKIP NEXT COMMAND
;*****
;
;REREAD,ACK COMMAND

```

J5

CZTKGA TK-25 FRT END FUNC #3
TEST 4: WRITE/READ TAPE MARK

MACRO M1200 20-APR-84 08:13 PAGE 125-1

SEQ 268

10974 063376 000000
10975 063400 000000
10976 063402 000000
10977
10978

T28CNT: .WORD 0
T28CNU: .WORD 0
T28DLY: .WORD 0
.EVEN

;TAPE TIMER COUNTER STORAGE AREA
;TAPE TIMER COUNTER STORAGE AREA
;DELAY COUNTER

```

8691      ;
8692      ;
8693      ;
8694      ;
8695      ;
8696      ;
8697      ;
8698      ;
8699      ;
8700      ;
8701      ;
8702      ;
8703      ;
8704      ;
8705      045240      ;
           045240      ;
           045240      104402      ;
8706      045242      005037      046110      CLR      T26CNU      ;CLEAR OUT COUNTER
8707      045246      004737      050650      JSR      PC,T26REST  ;SET COMMAND PACKET
8708      045252      004737      050742      JSR      PC,T26RT2   ;SET UP OTHER COMMAND PACKET
8709      045256      004737      051004      JSR      PC,T26RT3   ;SET UP OTHER COMMAND PACKET
8710      ;
8711      ;
8712      ;
8713      ;
8714      ;
8715      ;
8716      ;
8717      045262      004737      016660      JSR      PC,SOFINIT  ;DO INITIALIZE ON CONTROLLER
8718      045266      103407      ;BCS      20$        ;BR IF INIT WAS OK
8719      045270      004737      020116      JSR      PC,FATCHK   ;INC AND CHECK FOR MORE THAN 25 ERRORS
8723      045274      010001      ;MOV      R0,R1      ;CONTENTS OF TSSR REGISTER
8724      045276      ;ERRDF   ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
           045276      104457      ;
           045300      000522      ;
           045302      003550      ;
           045304      011676      ;
8725      045306      ;
8726      ;
8727      045306      012704      045730      MOV      @T26PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
8728      ;
8729      ;
8730      ;
8731      ;
8732      ;
8733      ;
8734      ;
8735      045312      004737      010342      JSR      PC,WRTCHR   ;ISSUE WRITE CHARACTERISTICS
8736      045316      103407      ;BCS      25$        ;BR, IF COMMAND ISSUED OK
8737      045320      004737      020116      JSR      PC,FATCHK   ;INC AND CHECK FOR MORE THAN 25 ERRORS
8741      045324      010001      ;MOV      R0,R1      ;SAVE CONTENTS OF TSSR
8742      045326      ;ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
           045326      104456      ;
           045330      000526      ;
           045332      004754      ;
           045334      011676      ;
8743      045336      ;
           25$:      CKLOOP      ;LOOP IF SELECTED

```

11037	065400	012721	100006	MOV	#100006,(R1)+	;WRITE SUBSYSTEM MEM. WITH ACK,
11038	065404	012721	063350	MOV	#T28BF2,(R1)+	;ADDRESS OF DATA BLOCK
11039	065410	005021		CLR	(R1)+	;EXTENDED ADDRESS
11040	065412	012721	000006	MOV	#6,(R1)+	;SIZE OF DATA BLOCK IN BYTES
11041	065416	005021		CLR	(R1)+	
11042	065420	012701	063350	MOV	#T28BF2,R1	;POINT TO DATA SEL AREA
11043	065424	005021		CLR	(R1)+	
11044	065426	005011		CLR	(R1)	
11045	065430	000207		RTS	PC	;RETURN
11046	065432					
11047	065432			T28RT3:		
11048	065436	012701	063340	SAVREG		
11049	065442	005021		MOV	#T28PK3,R1	;GET PACKET ADDRESS
11050	065444	005021		CLR	(R1)+	;CLEAR COMMAND AREA
11051	065446	005021		CLR	(R1)+	;CLEAR ADDRESS AREA
11052	065450	005011		CLR	(R1)+	;CLEAR EXTENDED ADDRESS AREA
11053	065452	000207		CLR	(R1)	;SIZE OF DATA TRANSFER
11054	065454			RTS	PC	;RETURN
	065454			ENDTST		
	065454	104401				L10074: TRAP C\$ETST
11060						
11065						
11071						
11072						
11073						
11074						
11075						
11076						
11077						
11078						
11079						
11080						
11081						
11082						
11083						
11084	065456					
	065456	000015		BGNHRD		
	065460			.WORD	L10076-L\$HARD/?	
11085				L\$HARD::		
11086	065460			GPRMA	HPM1,0,0,160000,177776,YES	;GET TSBA/TSDB REGISTER ADDRESS.
	065460	000031		.WORD	T\$CODE	
	065462	065512		.WORD	HPM1	
	065464	160000		.WORD	T\$LOLIM	
	065466	177776		.WORD	T\$HILIM	
11087	065470			GPRMA	HPM2,2,0,0,776,YES	;GET VECTOR ADDRESS.
	065470	001051		.WORD	I\$CODE	
	065472	065541		.WORD	HPM2	
	065474	000000		.WORD	T\$LOLIM	
	065476	000776		.WORD	T\$HILIM	
11088	065500			GPRMD	HPM3,4,0,340,0,7,YES	;GET INTERRUPT PRIORITY.
	065500	002032		.WORD	T\$CODE	
	065502	065565		.WORD	HPM3	
	065504	000340		.WORD	340	
	065506	000000		.WORD	T\$LOLIM	
	065510	000007		.WORD	T\$HILIM	
11089	065512			ENDHRD		
				.EVEN		

.SBTTL HARDWARE PARAMETER CODING SECTION

```

; **
; THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
; WITH THE OPERATOR.
; --

```

```

BGNHRD
.WORD L10076-L$HARD/?
L$HARD::

```

```

      045460 047053
      045462 011710
8798 045164
      045464 104406
      75$: CKLOOP ;LOOP IF SELECTED
                                     .WORD T26WDE
                                     .WORD PKTSSR
                                     TRAP C$CLP1
8800
8801
8802 ;*****
8803 ;ISSUE SPACE RECORDS COMMAND - VALUE IN R3 SETS NUMBER OF RECORDS
8804 ;BIT 15 SETS DIRECTION - 0=FORWARD 1=REVERSE
8805 ;
8806 ;*****
8807 045466 012703 100001      MOV    #100001,R3      ;SET SPACE REVERSE 1 RECORD
8808 045472 004737 010144      JSR    PC,SPACE      ;ISSUE COMMAND
8809 045476 103411              BCS    175$          ;GO ON IF ALL IS WELL
8810 045500 016501 000000      MOV    TSSR(R5),R1   ;GET TSSR CONTENTS
8811 045504 010004              MOV    R0,R4         ;SET UP EXPECTED (PACKET CONTENTS)
8812 045506 004737 020116      JSR    PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
8816 045512              ERRHRD ERRNO,T26WDE,PKTSSR ;TSSR INCORRECT AFTER READ DATA
      045512 104456
      045514 000532
      045516 047053
      045520 011710
      8817 045522              175$: CKLOOP ;LOOP IF SELECTED
      045524 104406
      8818 045524 013737 003072 046062      MOV    FREE,T26RB    ;ADDRESS OF BUFFER
      8819 045532 005737 046110      TST    T26CNU        ;CHECK FOR TIMES THROUGH HERE
      8820 045536 001404              BEQ    176$          ;BR, IF FIRST TIME THROUGH
8821
8822 ;*****
8823 ;
8824 ;REREAD (PREVIOUS), IE, ACK, OPP=1 CMD.
8825 ;
8826 ;*****
8827
8828 045540 012737 161001 046060      MOV    #161001,T26PK3 ;REREAD (PREVIOUS), IE, ACK, OPP=1 CMD.
8829 045546 000403              BR     178$          ;SKIP NEXT COMMAND
8830
8831 ;*****
8832 ;
8833 ;REREAD ,ACK,OPP=1 COMMAND
8834 ;
8835 ;*****
8836
8837 045550 012737 141001 046060      176$: MOV    #141001,T26PK3 ;REREAD ,ACK,OPP=1 COMMAND
8838 045556
      8839 045556 012704 046060      178$: MOV    #T26PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
      8840 045562 010465 177776      MOV    R4,T26DB(R5) ;ISSUE COMMAND
      8841 045566 004737 017134      JSR    PC,WAITF     ;WAIT FOR SSR TO SET
      8842 045572 016501 000000      MOV    TSSR(R5),R1 ;GET TSSR CONTENTS
      8843 045576 012702 100204      MOV    #SSR!SC!BIT2,R2 ;SET UP EXPECTED
      8844 045602 020102              CMP    R1,R2        ;ARE THEY EQUAL
      8845 045604 001406              BEQ    180$          ;BR, IF OK
      8846 045606 004737 020116      JSR    PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
8850 045612              ERRHRD ERRNO,T26WDE,PKTSSR ;TSSR INCORRECT AFTER READ DATA
      045612 104456
      045614 000532
                                     TRAP C$ERHRD
                                     .WORD 347

```


8879			!* ;LOCAL STORAGE FOR THIS TEST		
8880			;-		
8881					
8883	045720		.BLKB 10-<.-TUV2A&7>		
8885	045730		T26PACKET:		;COMMAND PACKET FOR TEST
8886	045730	014004	.WORD 14004		;WRITE CHARACTERISTICS COMMAND, WITH CVC=1, ACK
8887	045732	045740	.WORD T26DATA		;ADDRESS OF CHARACTERISTICS BLOCK
8888	045734	000000	.WORD 0		
8889	045736	000012	.WORD 10.		;STARTING VALUE OF BLOCK SIZE
8890	045740		T26DATA:		;CHARACTERISTICS DATA BLOCK
8891	045740	045750	.WORD T26BFR		;ADDRESS OF MESSAGE BUFFER
8892	045742	000000	.WORD 0		
8893	045744	000024	.WORD 20.		;LENGTH OF MESSAGE BUFFER
8894	045746	000000	.WORD 0		
8895	045750		T26BFR: .BLKW 25.		;MESSAGE BUFFER
8896			;		
8897			;WRITE SUBSYSTEM MEMORY COMMAND PACKET		
8898			;		
8900	046032		.BLKB 10-<.-TUV2A&7>		
8902	046040		T26PK2:		;WRITE SUB SYS MEM COMMAND, AND ACK
8903	046040	100006	.WORD 100006		;ADDRESS OF SELECT BLOCK DATA
8904	046042	046070	.WORD T26BF2		
8905	046044	000000	.WORD 0		
8906	046046	000006	.WORD 6.		;SIZE OF DATA PACKET
8908	046050		.BLKB 10-<.-TUV2A&7>		
8910	046060		T26PK3:		
8911	046060	140005	.WORD 140005		;REREAD COMMAND, CVC=1 AND ACK
8912	046062		T26RB:		
8913	046062	003072	T26WB: .WORD FREE		;ADDRESS OF WRITE BUFFER
8914	046064	000000	.WORD 0		
8915	046066	000000	T26SZ: .WORD 0		;SIZE OF BUFFER (EXTENT)
8916			.EVEN		
8917			;		
8918	046070		T26BF2:		
8919	046070	010	T26BS0: .BYTE 10		;BSELO AREA
8920	046071	200	T26BS1: .BYTE 200		;BSEL1 AREA
8921	046072	000000	T26S2: .WORD 0		;SEL 2 AREA
8922	046074	000000	T26S3: .WORD 0		;DATA AREA
8923			;		
8924			.EVEN		
8925			;TAPE MOTION PACKET COMMAND VALUES		
8926					
8927	046076	140001	T26RN: .WORD 140001		;READ DATA
8928	046100	141401	.WORD 141401		;REREAD NEXT OPP=0
8929	046102	161401	.WORD 161401		;REREAD NEXT OPP=1
8930	046104	177777	.WORD 177777		;END OF DATA
8931			;		
8932	046106	000000	T26CNT: .WORD 0		;TAPE RECORD COUNTER STORAGE AREA
8933	046110	000000	T26CMU: .WORD 0		;TAPE RECORD COUNTER STORAGE AREA
8934	046112	000000	T26RSZ: .WORD 0		;RECORD STORAGE SIZE AREA
8935	046114	000000	T26DLY: .WORD 0		;DELAY COUNTER AREA

```

8937
8938
8939
8940
8941
8942
8943 046116      124      141      160 T26WNG: .ASCIZ 'Tape Position Incorrect After REREAD Previous (OPP=1)'
8944 046204      122      105      122 T26NEF: .ASCIZ 'REREAD PREVIOUS, At BOT, Failed To Set NEF (XSTO)'
8945 046266      124      123      123 T26RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
8946 046335      122      105      122 T26RRF: .ASCIZ 'REREAD Previous (Space Reverse, Read Forward) Command Failed'
8947 046432      122      105      122 T26RRG: .ASCIZ 'REREAD Previous (Read Reverse, Space Forward) Command Failed'
8948 046527      120      117      123 T26SC:  .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
8949 046611      122      111      102 T26LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'
8950 046661      124      123      123 T26WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
8951 046736      111      154      154 T26LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XSTO'
8952 047017      122      105      122 T26SSR: .ASCIZ 'REREAD COMMAND Not Accepted'
8953 047053      124      123      123 T26WDE: .ASCIZ 'TSSR Not Correct After WRITE DATA Command'
8954 047125      124      141      160 T26BOT: .ASCIZ 'Tape Not At BOT After REWIND Command'
8955 047172      104      141      164 T26DTA: .ASCIZ 'Data Written To Tape Not Equal To Data Read From Tape'
8956 047260      122      105      122 T26EOT: .ASCIZ 'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
8957 047337      124      123      123 T26TM:  .ASCIZ 'TSSR Not Correct After REREAD COMMAND Reject'
8958 047414      122      145      167 T26RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
8959 047463      122      101      115 T26RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
8960 047536      124      123      123 T26AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
8961 047605      104      162      151 T26OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
8962 047660      124      123      123 T26WDD: .ASCIZ 'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
8963 047750      124      123      123 T26WDC: .ASCIZ 'TSSR Not Correct After REREAD DATA Command'
8964 050023      103      126      103 T26VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
8965 050076      124      123      102 T26BA:  .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
8966 050151      127      122      111 T26WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
8967 050240      122      145      141 T26LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XSTO'
8968 050322      122      145      141 T26LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XSTO'
8969 050404      122      145      163 T26PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
8970 050472      122      145      141 T26TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
8971 050560      104      141      164 T26NEQ: .ASCIZ 'Data REREAD From Tape Not Correct, After SWB=1'
8972 050637      122      145      162 TST26ID: .ASCIZ 'Rereads'
8973
8974
8975
8976
8977
8978
8979
8980
8981 050650
8982 050650
8983 050654      012701      045730
8984 050660      012721      140004
8985 050664      012721      045740
8986 050670      005021
8987 050672      012721      000012
8988 050676      012721      045750
8989 050702      005021
8990 050704      012721      000024
8991 050710      005021
8992 050712      012711      000000
8993 050716      012702      000030

;
; LOCAL TEXT MESSAGES FOR TEST
;
T26REST:
      SAVREG
      MOV      #T26PACKET,R1
      MOV      #140004,(R1)
      MOV      #T26DATA,(R1)
      CLR      (R1)
      MOV      #10,(R1)
      MOV      #T26BFR,(R1)
      CLR      (R1)
      MOV      #20,(R1)
      CLR      (R1)
      MOV      #0,(R1)
      MOV      #24,,R2

;SAVE THE REGISTERS
;START OF THE PACKET
;WRITE SUBSYSTEM MEM. WITH ACK, CVC=1
;ADDRESS OF CHARACTERISTICS DATA BLOCK
;EXTENDED ADDRESS
;SIZE OF DATA BLOCK IN BYTES
;ADDRESS OF MESSAGE BUFFER

;LENGTH OF MESSAGE BUFFER

;SELECT DRIVE ZERO (0)
;NUMBER OF LOCATIONS TO BE CLEARED

```


E2

```

8994 050722 012762 177777 045750 64#: MOV #177777,T26BFR(R2) ;ALL ONES TO MESSAGE BUFFER
8995 050730 005742 TST -(R2) ;NEXT LOCATION
8996 050732 020227 000000 CMP R2,#0 ;CHECK FOR END OF LOOP
8997 050736 001371 BNE 64# ;KEEP GOING UNTIL DONE
8998 050740 000207 RTS PC ;RETURN
8999
9000
9001 050742 T26RT2: SAVREG ;SAVE THE REGISTERS
9002 050742 MOV #T26PK2,R1 ;START OF THE PACKET
9003 050746 012701 046040 MOV #140006,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK,CVC=1.
9004 050752 012721 140006 MOV #T26BF2,(R1)+ ;ADDRESS OF DATA BLOCK
9005 050756 012721 046070 CLR (R1)+ ;EXTENDED ADDRESS
9006 050762 005021 MOV #6,(R1)+ ;SIZE OF DATA BLOCK IN BYTES
9007 050764 012721 000006 CLR (R1)+
9008 050770 005021 MOV #T26BF2,R1 ;POINT TO DATA SEL AREA
9009 050772 012701 046070 CLR (R1)+
9010 050776 005021 CLR (R1)
9011 051000 005011 RTS PC ;RETURN
9012 051002 000207
9013 051004 T26RT3: SAVREG ;SAVE THE REGISTERS
9014 051004 MOV #T26PK3,R1 ;START OF THE PACKET
9015 051010 012701 046060 MOV #0,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK,
9016 051014 012721 000000 MOV #0,(R1)+ ;ADDRESS OF DATA BLOCK
9017 051020 012721 000000 CLR (R1)+ ;EXTENDED ADDRESS
9018 051024 005021 MOV #0,(R1) ;SIZE OF DATA BLOCK IN BYTES
9019 051026 012711 000000 RTS PC ;RETURN
9020 051032 000207
9021 051034 ENDTST
051034
051034 104401 L10046: TRAP C#ETST

```



```

051152 013727 002116          MOV      L#DLY,(PC)+
051156 000000          .WORD   0
051160 005367 177772          DEC      -6(PC)
051164 001375          BNE     .-4
051166 005367 177756          DEC      -22(PC)
051172 001367          BNE     .-20
9079 051174 005337 055702      DEC      T27DLY          ;BUMP COUNTER
9080 051200 001356          BNE     10$             ;BR, IF COUNTER NOT DONE
9081 051202 004737 020116      JSR     PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
9085 051206 010001          MOV     R0,R1          ;CONTENTS OF TSSR REGISTER
9086 051210          ERROF  ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
051210 104455          TRAP   C$ERDF
051212 000455          .WORD  301
051214 003550          .WORD  SFIERR
051216 011676          .WORD  SFIMSG
9087 051220          20$:
9088 051220 012704 055520      MOV     @T27PACKET,R4  ;SUBROUTINE NEEDS PACKET ADDRESS
9089
9090          ;*****
9091          ;
9092          ;WRITE CHARACTERISTICS COMMAND (CALL TO WRTCHR)
9093          ;
9094          ;*****
9095
9096 051224 004737 010342      JSR     PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
9097 051230 103407          BCS    25$             ;BR, IF COMMAND ISSUED OK
9098 051232 004737 020116      JSR     PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
9102 051236 010001          MOV     R0,R1          ;SAVE CONTENTS OF TSSR
9103 051240          ERHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICSC FAILED
051240 104456          TRAP   C$ERHRD
051242 000456          .WORD  302
051244 004754          .WORD  WRTMSG
051246 011676          .WORD  SFIMSG
9104 051250          25$:
9105 051250 104406          CKLOOP          ;LOOP IF SELECTED
9106          TRAP   C$CLP1
9107          ;*****
9108          ;
9109          ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
9110          ;
9111          ;*****
9112 051252 004737 010444      JSR     PC,REWIND      ;CALL TAPE REWIND COMMAND
9113 051256 103407          BCS    30$             ;BR, IF NO PROBLEM
9114 051260 010004          MOV     R0,R4          ;SET UP REWIND PACKET ADDRESS
9115 051262 004737 020116      JSR     PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
9119 051266          ERHRD  ERRNO,T27RWN,PKTSSR ;REWIND NOT ACCEPTED
051266 104456          TRAP   C$ERHRD
051270 000457          .WORD  303
051272 057055          .WORD  T27RWN
051274 011710          .WORD  PKTSSR
9120 051276          30$:
9121 051276 104406          CKLOOP          ;LOOP IF SELECTED
9122          TRAP   C$CLP1
9123          ;*****
9124          ;
          ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XST0)

```

H2

CZTKGA TK-25 FRT END FUNC #3
TEST 3: WRITE DATA RETRY

MACRO M1200 20-APR-84 08:13 PAGE 114-2

SEQ 227

```

9125
9126
9127
9128 051300 013701 055546
9129 051304 010102
9130 051306 052702 000002
9131 051312 020102
9132 051314 001776
9133 051316 004737 020116
9137 051322
      051322 104456
      051324 000460
      051326 056551
      051330 016360
9138 051332
      051332 104406
9139 051334 012737 000400 055656
9140 051342 013737 003072 055652
9141
9142
9143
9144
9145
9146
9147
9148 051350 012737 141005 055650
9149 051356 012704 055650
9150 051362 010465 177776
9151 051366 004737 017134
9152 051372 016501 000000
9153 051376 012702 100206
9154 051402 020102
9155 051404 001406
9156 051406 004737 020116
9160 051412
      051412 104456
      051414 000461
      051416 056462
      051420 011710
9161 051422
      051422 104406
9162
9163
9164
9165
9166
9167
9168
9169 051424 013701 055546
9170 051430 010102
9171 051432 052702 002000
9172 051436 020102
9173 051440 001406
9174 051442 004737 020116
9178 051446
      051446 104456
      051450 000462

```

```

;*****
;
;PICK UP XSTO
;SET UP EXPECTED
;SET BOT BIT IN EXPECTED
;DOES EXP = REC'D
;BR, IF EQUAL (OK)
;INC AND CHECK FOR MORE THAN 25 ERRORS
;TAPE NOT AT BOT AFTER REWIND
      TRAP      C$ERRHRD
      .WORD     304
      .WORD     T27BOT
      .WORD     EXPREC
40$:  CKLOOP                                ;LOOP IF SELECTED
      TRAP      C$CLP1
      MOV      #256.,T27SZ                    ;SET UP RECORD SIZE
      MOV      FREE,T27WB                    ;ADDRESS OF WRITE BUFFER
;*****
;
;WRITE DATA RETRY,ACK,CVC-1 COMMAND
;
;*****
;
;WRITE DATA RETRY,ACK,CVC-1 COMMAND
;SET UP R4 WITH PACKET ADDRESS
;ISSUE COMMAND
;WAIT FOR SSR TO SET
;GET TSSR CONTENTS
;SET UP EXPECTED
;ARE THEY EQUAL
;BR, IF OK
;INC AND CHECK FOR MORE THAN 25 ERRORS
;TSSR INCORRECT AFTER READ DATA
      TRAP      C$ERRHRD
      .WORD     305
      .WORD     T27WDE
      .WORD     PKTSSR
75$:  CKLOOP                                ;LOOP IF SELECTED
      TRAP      C$CLP1
;*****
;
;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
;
;*****
;
;GET XSTO STATUS WORD
;SET UP EXPECTED
;SET THE NEF BIT
;ARE THEY EQUAL
;BR, IF EQUAL (GOOD)
;INC AND CHECK FOR MORE THAN 25 ERRORS
;NEF SHOULD BE SET
      TRAP      C$ERRHRD
      .WORD     306

```

CZTKGA TK-25 FRT END FUNC #3
TEST 3: WRITE DATA RETRY

MACRO M1200 20-APR-84 08:13 PAGE 114-3

SEQ 228

051452	060221								.WORD	T27NEF
051454	016360								.WORD	EXPREC
9179	051456			170\$:						
9180	051456				ENDSUB					
	051456	104403							L10067:	
9181	051460	023727	002170	000031	CMP	FATFLG,#25.			TRAP	C\$ESUB
9182	051466	002402			BLT	999\$;IS ERROR COUNT AT 25	
9183	051470	004737	020170		JSR	PC,CKDROP			;BR, IF LESS THAN 25	
9184	051474								;TRY TO DROP THE UNIT	
				999\$:						

K2

CZTKGA TK-25 FRT END FUNC #3
TEST 3: WRITE DATA RETRY

MACRO M1200 20-APR-84 08:13 PAGE 115-1

SEQ 230

```

9238
9239 ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
9240 ;
9241 ;*****
9242
9243 051570 004737 010444 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
9244 051574 103411 BCS 26$ ;BR, IF NO PROBLEM
9245 051576 010004 MOV R0,R4 ;SET UP REWIND PACKET ADDRESS
9246 051600 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
9247 051604 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
9251 051610 ERRHRD ERRNO,T27RWN,PKTSSR ;REWIND NOT ACCEPTED
          051610 104456 TRAP C$ERRHRD
          051612 000465 .WORD 309
          051614 057055 .WORD T27RWN
          051616 011710 .WORD PKTSSR
9252 051620 26$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
          051620 104406 ;STARTING RECORD SIZE
9253 051622 012703 000400 MOV #256.,R3 ;STARTING WRITE BUFFER ADDRESS
9254 051626 013737 003072 055652 MOV FREE,T27WB
9255
9256 ;*****
9257 ;WRITE DATA,CVC=1,ACK COMMAND
9258 ;
9259 ;*****
9260
9261
9262 051634 012737 140005 055650 MOV #140005,T27PK3 ;WRITE DATA,CVC=1,ACK COMMAND
9263 051642 012704 055650 MOV #T27PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
9264 051646 010337 055656 MOV R3,T27SZ ;SET UP RECORD SIZE IN PACKET
9265 051652 010465 177776 MOV R4,TSD8(R5) ;ISSUE COMMAND
9266 051656 004737 017134 JSR PC,WAITF ;WAIT FOR SSR TO SET
9267 051662 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
9268 051666 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
9269 051672 020102 CMP R1,R2 ;ARE THEY EQUAL
9270 051674 001406 BEQ 28$ ;BR, IF OK
9271 051676 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
9275 ;SOFT ERROR GENERATED BECAUSE THE
9276 ;WRITE COMMAND IS NOT BEING CHECKED
9277 ;HERE, IT WAS CHECKED IN LEAH2
9278 ERRSOFT ERRNO,WRTErr,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
          051702 TRAP C$ERSOFT
          051702 104457 .WORD 310
          051704 000466 .WORD WRTErr
          051706 005011 .WORD PKTSSR
          051710 011710
9279 051712 28$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
          051712 104406
9280
9281 ;*****
9282 ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
9283 ;
9284 ;*****
9285
9286
9287 051714 004737 010444 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
9288 051720 103411 BCS 30$ ;BR, IF NO PROBLEM
9289 051722 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
9290 051726 010004 MOV R0,R4 ;SET UP REWIND PACKET ADDRESS

```

L2

CZTKGA TK-25 FRT END FUNC #3
TEST 3: WRITE DATA RETRY

MACRO M1200 20-APR-84 08:13 PAGE 115-2

SEQ 231

```

9291 051730 004737 020116      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
9295 051734      ERRHRD   ERRNO,T27RWN,PKTSSR ;REWIND NOT ACCEPTED
      051734 104456
      051736 000467      TRAP     C$ERHRD
      051740 057055      .WORD   311
      051742 011710      .WORD   T27RWN
      .WORD   PKTSSR
9296 051744      30$:    CKLOOP      ;LOOP IF SELECTED
      051744 104406      TRAP     C$CLP1
9297
9298
9299      ;*****
9300      ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
9301      ;
9302      ;*****
9303
9304 051746 013701 055546      MOV      T27BFR+6,R1    ;PICK UP XSTO
9305 051752 010102      MOV      R1,R2          ;SET UP EXPECTED
9306 051754 052702 000002      BIS      #BIT1,R2      ;SET BOT BIT IN EXPECTED
9307 051760 020102      CMP      R1,R2          ;DOES EXP = REC'D
9308 051762 001406      BEQ      40$           ;BR, IF EQUAL (OK)
9309 051764 004737 020116      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
9313 051770      ERRHRD   ERRNO,T27BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      051770 104456      TRAP     C$ERHRD
      051772 000470      .WORD   312
      051774 056551      .WORD   T27BOT
      051776 016360      .WORD   EXPREC
9314 052000      40$:    CKLOOP      ;LOOP IF SELECTED
      052000 104406      TRAP     C$CLP1
9315
9316      ;*****
9317      ;
9318      ;ISSUE SPACE RECORDS COMMAND - VALUE IN R3 SETS NUMBER OF RECORDS
9319      ;BIT 15 SETS DIRECTION - 0=FORWARD 1=REVERSE
9320      ;
9321      ;*****
9322
9323 052002 012703 000001      MOV      #1,R3          ;PARAMETER SPACE FORWARD 1 RECORD
9324 052006 004737 010144      JSR      PC,SPACE      ;CALL SPACE RECORDS ROUTINE
9325 052012 103413      BCS      50$           ;BR, IF NO ERRORS
9326 052014 016501 000000      MOV      TSSR(R5),R1    ;GET TSSR CONTENTS
9327 052020 012702 000200      MOV      #SSR,R2       ;SET UP EXPECTED
9328 052024 010004      MOV      R0,R4          ;SET UP REWIND PACKET ADDRESS
9329 052026 004737 020116      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
9333 052032      ERRHRD   ERRNO,T27SCF,PKTSSR ;SPACE RECORDS COMMAND FAILED
      052032 104456      TRAP     C$ERHRD
      052034 000471      .WORD   313
      052036 060317      .WORD   T27SCF
      052040 011710      .WORD   PKTSSR
9334 052042      50$:    CKLOOP      ;LOOP IF SELECTED
      052042 104406      TRAP     C$CLP1

```



```

9336 ;*****
9337 ;
9338 ;ISSUE SPACE RECORDS COMMAND - VALUE IN R3 SETS NUMBER OF RECORDS
9339 ;BIT 15 SETS DIRECTION - 0=FORWARD 1=REVERSE
9340 ;
9341 ;*****
9342
9343 052044 012703 100001      MOV     #100001,R3      ;PARAMETER SPACE REVERSE 1 RECORD
9344 052050 004737 010144      JSR     PC,SPACE      ;CALL SPACE RECORDS ROUTINE
9345 052054 103413              BCS     60$           ;BR, IF NO ERRORS
9346 052056 016501 000000      MOV     TSSR(R5),R1   ;GET TSSR CONTENTS
9347 052062 012702 000200      MOV     #SSR,R2      ;SET UP EXPECTED
9348 052066 010004              MOV     R0,R4        ;SET UP REWIND PACKET ADDRESS
9349 052070 004737 020116      JSR     PC,FATCHK    ;INC AND CHECK FOR MORE THAN 25 ERRORS
9353 052074              ERRHRD  ERRNO,T27SCF,PKTSSR ;SPACE RECORDS COMMAND FAILED
                                TRAP     C$ERHRD
                                .WORD    314
                                .WORD    T27SCF
                                .WORD    PKTSSR
9354 052104              60$:  CKLOOP        ;LOOP IF SELECTED
                                TRAP     C$CLP1
9355 052106 013737 003072 055652  MOV     FREE,T27RB   ;ADDRESS OF BUFFER

```



```

9447 ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
9448 ;
9449 ;*****
9450
9451 052342 004737 010444 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
9452 052346 103407 BCS 30# ;BR, IF NO PROBLEM
9453 052350 010004 MOV R0,R4 ;SET UP REWIND PACKET ADDRESS
9454 052352 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
9458 052356 ERRHRD ERRNO,T27RWN,PKTSSR ;REWIND NOT ACCEPTED
; TRAP C#ERHRD
; .WORD 319
; .WORD T27RWN
; .WORD PKTSSR
9459 052366 104406 30#: CKLOOP ;LOOP IF SELECTED
; TRAP C#CLP1
9460
9461 ;*****
9462 ;
9463 ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
9464 ;
9465 ;*****
9466
9467 052370 013701 055546 MOV T27BFR+6,R1 ;PICK UP XSTO
9468 052374 010102 MOV R1,R2 ;SET UP EXPECTED
9469 052376 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
9470 052402 020102 CMP R1,R2 ;DOES EXP = REC'D
9471 052404 001406 BEQ 40# ;BR, IF EQUAL (OK)
9472 052406 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
9476 052412 ERRHRD ERRNO,T27BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
; TRAP C#ERHRD
; .WORD 320
; .WORD T27BOT
; .WORD EXPREC
9477 052422 104406 40#: CKLOOP ;LOOP IF SELECTED
; TRAP C#CLP1
9478 052424 012703 000024 MOV #20.,R3 ;STARTING RECORD SIZE
9479 052430 013737 003072 055652 MOV FREE,T27WB ;STARTING WRITE BUFFER ADDRESS
9480
9481 ;*****
9482 ;
9483 ;WRITE DATA,CVC=1,ACK COMMAND
9484 ;
9485 ;*****
9486
9487 052436 012737 140005 055650 65#: MOV #140005,T27PK3 ;WRITE DATA,CVC=1,ACK COMMAND
9488 052444 012704 055650 MOV #T27PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
9489 052450 010300 MOV R3,R0 ;SET PATTERN IN CORRECT REGISTER
9490 052452 004737 020410 JSR PC,FILLMEM ;FILL MEMORY WITH RECORD SIZE
9491 052456 010337 055656 MOV R3,T27SZ ;SET UP RECORD SIZE IN PACKET
9492 052462 010465 177776 MOV R4,TSD8(R5) ;ISSUE COMMAND
9493 052466 004737 017134 JSR PC,WAITF ;WAIT FOR SSR TO SET
9494 052472 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
9495 052476 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
9496 052502 020102 CMP R1,R2 ;ARE THEY EQUAL
9497 052504 001406 BEQ 80# ;BR, IF OK
9498 052506 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
9502 ;SOFT ERROR GENERATED BECAUSE THE

```

ACK

```

9503                                     ;WRITE COMMAND IS NOT BEING CHECKED
9504                                     ;HERE, IT WAS CHECKED IN LEAH2
9505 052512                               ERRSOF ERRNO,WRERR,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      052512 104457                       TRAP C$ERRSOF
      052514 000501                       .WORD 321
      052516 005011                       .WORD WRERR
      052520 011710                       .WORD PKTSSR
9506 052522                               80$: CKLOOP ;LOOP IF SELECTED
      052522 104406                       TRAP C$CLP1
9507
9508                                     ;*****
9509                                     ;
9510                                     ;WRITE DATA RETRY,CVC=1,ACK COMMAND
9511                                     ;
9512                                     ;*****
9513
9514 052524 012737 141005 055650          MOV #141005,T27PK3 ;WRITE DATA RETRY,CVC=1,ACK COMMAND
9515 052532 010465 177776                MOV R4,TSDB(R5) ;ISSUE COMMAND
9516 052536 004737 017134                JSR PC,WAITF ;WAIT FOR SSR TO SET
9517 052542 016501 000000                MOV TSSR(R5),R1 ;GET TSSR CONTENTS
9518 052546 012702 000200                MOV #SSR,R2 ;SET UP EXPECTED
9519 052552 020102                       CMP R1,R2 ;ARE THEY EQUAL
9520 052554 001406                       BEQ 90$ ;BR, IF OK
9521 052556 004737 020116                JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
9525 052562                               ERRHRD ERRNO,T27WRF,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA RETRY
      052562 104456                       TRAP C$ERRHRD
      052564 000502                       .WORD 322
      052566 060456                       .WORD T27WRF
      052570 011710                       .WORD PKTSSR
9526 052572                               90$: CKLOOP ;LOOP IF SELECTED
      052572 104406                       TRAP C$CLP1
9527 052574 005723                       TST (R3); ;BUMP RECORD SIZE COUNTER
9528 052576 020327 000050                CMP R3,#40. ;AT 40 SIZE YET
9529 052602 001315                       BNE 65$ ;BR, IF MORE RECORDS TO WRITE
9530
9531                                     ;*****
9532                                     ;
9533                                     ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
9534                                     ;
9535                                     ;*****
9536
9537 052604 004737 010444                JSR PC,REWIND ;CALL TAPE REWIND COMMAND
9538 052610 103407                       BCS 230$ ;BR, IF NO PROBLEM
9539 052612 010001                       MOV R0,R1 ;SAVE TSSR
9540 052614 004737 020116                JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
9544 052620                               ERRHRD ERRNO,T27RWN,EXPREC ;REWIND NOT ACCEPTED
      052620 104456                       TRAP C$ERRHRD
      052622 000503                       .WORD 323
      052624 057055                       .WORD T27RWN
      052626 016360                       .WORD EXPREC
9545 052630                               230$: CKLOOP ;LOOP IF SELECTED
      052630 104406                       TRAP C$CLP1
9546
9547                                     ;*****
9548                                     ;
9549                                     ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XST0)
9550                                     ;

```

```

9551
9552
9553 052632 013701 055546
9554 052636 010102
9555 052640 052702 000002
9556 052644 020102
9557 052646 001406
9558 052650 004737 020116
9562 052654
      052654 104456
      052656 000504
      052660 056551
      052652 016360
9563 052664
      052664 104406
9564 052666 012703 000024
9565 052672 013737 003072 055652
9566
9567
9568
9569
9570
9571
9572
9573 052700 012737 100001 055650
9574 052706 012704 055650
9575 052712 010337 055656
9576 052716 010465 177776
9577 052722 004737 017134
9578 052726 016501 000000
9579 052732 012702 000200
9580 052736 020102
9581 052740 001406
9582 052742 004737 020116
9586 052746
      052746 104456
      052750 000505
      052752 005104
      052754 011710
9587 052756
      052756 104406
9588 052760 013702 003072
9589 052764 010374
9590 052766 162704 000024
9591 052772 060204
9592 052774 021403
9593 052776 001410
9594 053000 011401
9595 053002 010302
9596 053004 004737 020116
9600 053010
      053010 104456
      053012 000506
      053014 060536
      053016 016360
9601 053020
      053020 104406

```

```

;*****
;PICK UP XSTO
;SET UP EXPECTED
;SET BOT BIT IN EXPECTED
;DOES EXP = REC'D
;BR, IF EQUAL (OK)
;INC AND CHECK FOR MORE THAN 25 ERRORS
;TAPE NOT AT BOT AFTER REWIND
      TRAP C$ERRHRD
      .WORD 324
      .WORD T27BOT
      .WORD EXPREC
240$: CKLOOP ;LOOP IF SELECTED
      TRAP C$CLP1
      MOV #20.,R3 ;STARTING RECORD SIZE
      MOV FREE,T27RB ;STARTING READ BUFFER ADDRESS
;*****
;READ DATA,ACK COMMAND
;*****
265$: MOV #100001,T27PK3 ;READ DATA,ACK COMMAND
      MOV #T27PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
      MOV R3,T27SZ ;SET UP RECORD SIZE IN PACKET
      MOV R4,TSD8(R5) ;ISSUE COMMAND
      JSR PC,WAITF ;WAIT FOR SSR TO SET
      MOV TSSR(R5),R1 ;GET TSSR CONTENTS
      MOV #SSR,R2 ;SET UP EXPECTED
      CMP R1,R2 ;ARE THEY EQUAL
      BEQ 280$ ;BR, IF OK
      JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
      ERRHRD ERRNO,RDERR,PKTSSR ;TSSR INCORRECT AFTER READ DATA
      TRAP C$ERRHRD
      .WORD 325
      .WORD RDERR
      .WORD PKTSSR
280$: CKLOOP ;LOOP IF SELECTED
      TRAP C$CLP1
      MOV FREE,R2 ;GET BUFFER ADDRESS
      MOV R3,R4 ;GET RECORD SIZE
      SUB #20.,R4 ;POINT BACK TO 1ST RECORD
285$: ADD R2,R4 ;POINT TO 1ST LOC IN BUFFER
      CMP (R4),R3 ;DATA WRITTEN = READ
      BEQ 290$ ;BR, IF DATA OK (GOOD)
      MOV (R4),R1 ;PICK UP BAD DATA
      MOV R3,R2 ;SET UP EXPECTED
      JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
      ERRHRD ERRNO,T27DTA,EXPREC ;DATA IN BUFFER NOT CORRECT
      TRAP C$ERRHRD
      .WORD 326
      .WORD T27DTA
      .WORD EXPREC
290$: CKLOOP ;LOOP IF SELECTED
      TRAP C$CLP1

```

F3

CZTKGA TK-25 FRT END FUNC #3
TEST 3: WRITE DATA RETRY

MACRO M1200 20-APR-84 08:13 PAGE 118-4

SEQ 238

```
9602 053022 005724          TST      (R4)+      ;BUMP TO NEXT ADDRESS
9603 053024 160204          SUB      R2,R4      ;BACK TO RECORD SIZE
9604 053026 020403          CMP      R4,R3      ;AT END OF RECORD YET
9605 053030 001360          BNE      285$       ;BR, IF MORE DATA TO CHECK
9606 053032 005723          TST      (R3)+      ;BUMP RECORD SIZE
9607 053034 020327 000050      CMP      R3,#40     ;DONE YET
9608 053040 001317          BNE      265$       ;BR, IF NOT DONE YET (MORE READS)
9609 053042          300$: CKLOOP      ;LOOP IF SELECTED
          053042 104406          TRAP     C#CLP1
9610 053044          330$:
9611 053044          ENDSUB
          053044
          053044 104403
9612 053046 023727 002170 000031  CMP      FATFLG,#25,
9613 053054 002402          BLT      999$       ;IS ERROR COUNT AT 25
9614 053056 004737 020170      JSR      PC,CKDROP ;BR, IF LESS THAN 25
9615 053062          999$:          ;TRY TO DROP THE UNIT
```


H3

CZTKGA TK-25 FRT END FUNC #3
TEST 3: WRITE DATA RETRY

MACRO M1200 20-APR-84 08:13 PAGE 119-1

SEQ 240

```

9663 053202 004737 020116      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
9667 053206 010001              MOV    RO,R1          ;SAVE CONTENTS OF TSSR
9668 053210              ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP    C$ERHRD
                                .WORD   328
                                .WORD   WRTMSG
                                .WORD   SFIMSG
9669 053220 104406      23$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP    C$CLP1
9670
9671
9672      ;*****
9673      ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
9674      ;
9675      ;*****
9676
9677 053222 004737 010444      JSR    PC,REWIND      ;CALL TAPE REWIND COMMAND
9678 053226 103411              BCS    30$           ;BR, IF NO PROBLEM
9679 053230 016501 000000      MOV    TSSR(R5),R1   ;GET TSSR CONTENTS
9680 053234 010004              MOV    RO,R4          ;GET PACKET ADDRESS
9681 053236 004737 020116      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
9685 053242              ERRHRD  ERRNO,T27RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP    C$ERHRD
                                .WORD   329
                                .WORD   T27RWN
                                .WORD   PKTSSR
9686 053252 104406      30$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP    C$CLP1
9687
9688      ;*****
9689      ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
9690      ;
9691      ;*****
9692
9693
9694 053254 013701 055546      MOV    T27BFR+6,R1   ;PICK UP XSTO
9695 053260 010102              MOV    R1,R2          ;SET UP EXPECTED
9696 053262 052702 000002      BIS    #BIT1,R2      ;SET BOT BIT IN EXPECTED
9697 053266 020102              CMP    R1,R2          ;DOES EXP = REC'D
9698 053270 001406              BEQ    40$           ;BR, IF EQUAL (OK)
9699 053272 004737 020116      JSR    PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
9703 053276              ERRHRD  ERRNO,T27BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP    C$ERHRD
                                .WORD   330
                                .WORD   T27BOT
                                .WORD   EXPREC
9704 053306 104406      40$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP    C$CLP1
9705 053310 012703 000024      MOV    #20.,R3       ;STARTING RECORD SIZE
9706 053314 013737 003072 055652  MOV    FREE,T27WB     ;STARTING WRITE BUFFER ADDRESS
9707
9708      ;*****
9709      ;WRITE DATA,CVC+1,ACK COMMAND
9710      ;
9711      ;*****
9712
9713

```

```

9714 053322 012737 140005 055650 65$: MOV      0140005,T27PK3      ;WRITE DATA,CVC-1,ACK COMMAND
9715 053330 012704 055650      MOV      0T27PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
9716 053334 010300      MOV      R3,R0           ;SET PATTERN IN CORRECT REGISTER
9717 053336 004737 020410      JSR      PC,FILLMEM      ;FILL MEMORY WITH RECORD SIZE
9718 053342 010337 055656      MOV      R3,T27S2       ;SET UP RECORD SIZE IN PACKET
9719 053346 010465 177776      MOV      R4,TSDB(R5)     ;ISSUE COMMAND
9720 053352 004737 017134      JSR      PC,WAITF        ;WAIT FOR SSR TO SET
9721 053356 016501 000000      MOV      TSSR(R5),R1     ;GET TSSR CONTENTS
9722 053362 012702 000200      MOV      0SSR,R2        ;SET UP EXPECTED
9723 053366 020102      CMP      R1,R2           ;ARE THEY EQUAL
9724 053370 001406      BEQ      80$            ;BR, IF OK
9725 053372 004737 020116      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
9729      ;SOFT ERROR GENERATED BECAUSE THE
9730      ;WRITE COMMAND IS NOT BEING CHECKED
9731      ;HERE, IT WAS CHECKED IN LEAH2
9732 053376      ERRSOF  ERRNO,WRTERR,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
          053376 104457      TRAP    C$ERSOFT
          053400 000513      .WORD  331
          053402 005011      .WORD  WRTERR
          053404 011710      .WORD  PKTSSR
9733 053406 80$:   CKLOOP      ;LOOP IF SELECTED
          053406 104406      TRAP    C$CLP1
9734
9735      ;*****
9736      ;
9737      ;WRITE DATA RETRY,ACK,SWB=1 COMMAND
9738      ;
9739      ;*****
9740
9741 053410 012737 111005 055650      MOV      0111005,T27PK3 ;WRITE DATA RETRY,ACK,SWB=1 COMMAND
9742 053416 010465 177776      MOV      R4,TSDB(R5)    ;ISSUE COMMAND
9743 053422 004737 017134      JSR      PC,WAITF        ;WAIT FOR SSR TO SET
9744 053426 016501 000000      MOV      TSSR(R5),R1    ;GET TSSR CONTENTS
9745 053432 012702 000200      MOV      0SSR,R2        ;SET UP EXPECTED
9746 053436 020102      CMP      R1,R2           ;ARE THEY EQUAL
9747 053440 001406      BEQ      90$            ;BR, IF OK
9748 053442 004737 020116      JSR      PC,FATCHK      ;INC AND CHECK FOR MORE THAN 25 ERRORS
9752 053446      ERRHRD  ERRNO,T27WRF,EXPREC ;TSSR INCORRECT AFTER WRITE DATA RETRY
          053446 104456      TRAP    C$ERHRD
          053450 000514      .WORD  332
          053452 060456      .WORD  T27WRF
          053454 016360      .WORD  EXPREC
9753 053456 90$:   CKLOOP      ;LOOP IF SELECTED
          053456 104406      TRAP    C$CLP1
9754 053460      TST     (R3),           ;BUMP RECORD SIZE COUNTER
9755 053462 020327 000050      CMP      R3,040         ;AT 40 SIZE YET
9756 053466 001315      BNE     65$            ;BR, IF MORE RECORDS TO WRITE
9757
9758      ;*****
9759      ;
9760      ;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
9761      ;
9762      ;*****
9763
9764 053470 004737 010444      JSR      PC,REWIND      ;CALL TAPE REWIND COMMAND
9765 053474 103411      BCS     230$           ;BR, IF NO PROBLEM
9766 053476 016501 000000      MOV      TSSR(R5),R1    ;GET TSSR CONTENTS

```

J3

CZIKGA TK-25 FRT END FUNC #3
TEST 3: WRITE DATA RETRY

MACRO M1200 20-APR-84 08:13 PAGE 119-3

SEQ 242

```

9767 053502 010004          MOV      R0,R4          ;GET PACKET ADDRESS
9768 053504 004737 020116  JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
9772 053510          ERRHRD  ERRNO,T27RWN,PKTSSR ;REWIND NOT ACCEPTED
          053510 104456          TRAP    C$ERHRD
          053512 000515          .WORD  333
          053514 057055          .WORD  T27RWN
          053516 011710          .WORD  PKTSSR
9773 053520          230$:  CKLOOP          ;LOOP IF SELECTED
          053520 104406          TRAP    C$CLP1
9774
9775          ;*****
9776          ;
9777          ;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
9778          ;
9779          ;*****
9780
9781 053522 013701 055546          MOV      T27BFR+6,R1    ;PICK UP XSTO
9782 053526 010102          MOV      R1,R2          ;SET UP EXPECTED
9783 053530 052702 000002          BIS      #BIT1,R2       ;SET BOT BIT IN EXPECTED
9784 053534 020102          CMP      R1,R2          ;DOES EXP = REC'D
9785 053536 001406          BEQ      240$           ;BR, IF EQUAL (OK)
9786 053540 004737 020116  JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
9790 053544          ERRHRD  ERRNO,T27BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
          053544 104456          TRAP    C$ERHRD
          053546 000516          .WORD  334
          053550 056551          .WORD  T27BOT
          053552 016360          .WORD  EXPREC
9791 053554          240$:  CKLOOP          ;LOOP IF SELECTED
          053554 104406          TRAP    C$CLP1
9792 053556 012703 000024          MOV      #20.,R3       ;STARTING R ORD SIZE
9793 053562 013737 003072 055652  MOV      FREE,T27RB     ;STARTING READ BUFFER ADDRESS
9794
9795          ;*****
9796          ;
9797          ;READ DATA,ACK COMMAND
9798          ;
9799          ;*****
9800
9801 053570 012737 100001 055650 265$:  MOV      #100001,T27PK3 ;READ DATA,ACK COMMAND
9802 053576 012704 055650          MOV      #T27PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
9803 053602 010337 055656          MOV      R3,T27SZ      ;SET UP RECORD SIZE IN PACKET
9804 053606 010465 177776          MOV      R4,TSD8(R5)   ;ISSUE COMMAND
9805 053612 004737 017134          JSR      PC,WAITF      ;WAIT FOR SSR TO SET
9806 053616 016501 000000          MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
9807 053622 012702 000200          MOV      #SSR,R2       ;SET UP EXPECTED
9808 053626 020102          CMP      R1,R2          ;ARE THEY EQUAL
9809 053630 001406          BEQ      280$           ;BR, IF OK
9810 053632 004737 020116  JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
9814 053636          ERRHRD  ERRNO,RDERR,PKTSSR ;TSSR INCORRECT AFTER READ DATA
          053636 104456          TRAP    C$ERHRD
          053640 000517          .WORD  335
          053642 005104          .WORD  RDERR
          053644 011710          .WORD  PKTSSR
9815 053646          280$:  CKLOOP          ;LOOP IF SELECTED
          053646 104406          TRAP    C$CLP1
9816 053650 013702 003072          MOV      FREE,R2       ;GET BUFFER ADDRESS
9817 053654 010304          MOV      R3,R4         ;GET RECORD SIZE

```



```

9946
9947 ; READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
9948 ;
9949 ; *****
9950
9951 054164 013701 055546          MOV     T27BFR+6,R1          ; PICK UP XSTO
9952 054170 010102              MOV     R1,R2              ; SET UP EXPECTED
9953 054172 052702 000002        BIS     @BIT1,R2          ; SET BOT BIT IN EXPECTED
9954 054176 020102              CMP     R1,R2              ; DOES EXP = REC'D
9955 054200 001406              BEQ     40$                ; BR, IF EQUAL (OK)
9956 054202 004737 020116        JSR     PC,FATCHK         ; INC AND CHECK FOR MORE THAN 25 ERRORS
9960 054206                      ERRHRD  ERRNO,T27BOT,EXPREC ; TAPE NOT AT BOT AFTER REWIND
                                TRAP     C$ERHRD
                                .WORD    340
                                .WORD    T27BOT
                                .WORD    EXPREC
                                054206 104456
                                054210 000524
                                054212 056551
                                054214 016360
9961 054216                      40$:  CKLOOP                ; LOOP IF SELECTED
                                TRAP     C$CLP1
                                054216 104406
9962 054220 012703 000144        MOV     @100.,R3          ; NUMBER OF RECORDS TO BE WRITTEN
9963 054224 013737 003072 055652 MOV     FREE,T27WB        ; STARTING WRITE BUFFER ADDRESS
9964
9965 ; *****
9966 ;
9967 ; WRITE DATA,ACK,CVC=1 COMMAND
9968 ;
9969 ; *****
9970
9971 054232 012737 140005 055650 65$:  MOV     @140005,T27PK3     ; WRITE DATA,ACK,CVC=1 COMMAND
9972 054240 012704 055650        MOV     @T27PK3,R4       ; SET UP R4 WITH PACKET ADDRESS
9973 054244 012737 000024 055656    MOV     @20.,T27SZ       ; SET UP RECORD SIZE IN PACKET
9974 054252 010465 177776        MOV     R4,TSDBC(25)    ; ISSUE COMMAND
9975 054256 004737 017134        JSR     PC,WAITF         ; WAIT FOR SSR TO SET
9976 054262 016501 000000        MOV     TSSR(R5),R1     ; GET TSSR CONTENTS
9977 054266 012702 000200        MOV     @SSR,R2         ; SET UP EXPECTED
9978 054272 020102              CMP     R1,R2           ; ARE THEY EQUAL
9979 054274 001406              BEQ     70$             ; BR, IF OK
9980 054276 004737 020116        JSR     PC,FATCHK         ; INC AND CHECK FOR MORE THAN 25 ERRORS
9984
9985 ; SOFT ERROR GENERATED BECAUSE THE
9986 ; WRITE COMMAND IS NOT BEING CHECKED
9987 ; HERE, IT WAS CHECKED IN LEA12
                                ERRSOFT ERRNO,WRERR,PKTSSR ; TSSR INCORRECT AFTER WRITE DATA
                                TRAP     C$ERSOFT
                                .WORD    341
                                .WORD    WRERR
                                .WORD    PKTSSR
9988 054312                      70$:  CKLOOP                ; LOOP IF SELECTED
                                TRAP     C$CLP1
                                054312 104406
9989 054314 005303              DEC     R3                ; DEC RECORD COUNTER
9990 054316 001345              BNE     65$             ; BR, IF MORE RECORDS TO WRITE
9991
9992 ; *****
9993 ;
9994 ; ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
9995 ;
9996 ; *****
9997
9998 054320 004737 010444          JSR     PC,REWIND        ; CALL TAPE REWIND COMMAND

```

```

9999 054324 103411
10000 054326 016501 000000
10001 054332 010004
10002 054334 004737 020116
10005 054340
      054340 104456
      054342 000526
      054344 057055
      054346 011710
10007 054350
      054350 104406
10008
10009
10010
10011
10012
10013
10014
10015 054352 013701 055546
10016 054356 010102
10017 054360 052702 000002
10018 054364 020102
10019 054366 001406
10020 054370 004737 020116
10024 054374
      054374 104456
      054376 000527
      054400 056551
      054402 016360
10025 054404
      054404 104406
10026 054406 012704 055650
10027 054412 012737 000010 055652
10028
10029
10030
10031
10032
10033
10034
10035 054420 012737 140010 055650
10036 054426 010465 177776
10037 054432 005237 055676
10038 054436
      054436 012727 000001
      054442 000000
      054444 013727 002116
      054450 000000
      054452 005367 177772
      054456 001375
      054460 005367 177756
      054464 001367
10039 054466 016501 000000
10040 054472 032701 000200
10041 054476 001755
10042 054500 016501 000000
10043 054504 012702 000200

      BCS      1301      ;BR. IF NO PROBLEM
      MOV      TSSR(R5),R1 ;GET TSSR CONTENTS
      MOV      R0,R4      ;GET PACKET ADDRESS
      JSR      PC,FATCHK  ;INC AND CHECK FOR MORE THAN 25 ERRORS
      ERRHRD   ERRNO,T27RWN,PKTSSR ;REWIND NOT ACCEPTED
                                     TRAP   C1ERHRD
                                     .WORD  342
                                     .WORD  T27RWN
                                     .WORD  PKTSSR
1301:  CKLOOP      ;LOOP IF SELECTED
                                     TRAP   C1CLP1
;*****
;
;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
;
;*****
      MOV      T27BFR+6,R1 ;PICK UP XSTO
      MOV      R1,R2      ;SET UP EXPECTED
      BIS      #BIT1,R2   ;SET BOT BIT IN EXPECTED
      CMP      R1,R2      ;DOES EXP = REC'D
      BEQ      1401      ;BR. IF EQUAL (OK)
      JSR      PC,FATCHK  ;INC AND CHECK FOR MORE THAN 25 ERRORS
      ERRHRD   ERRNO,T27BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                     TRAP   C1ERHRD
                                     .WORD  343
                                     .WORD  T27BOT
                                     .WORD  EXPREC
1401:  CKLOOP      ;LOOP IF SELECTED
                                     TRAP   C1CLP1
      MOV      #T27PK3,R4 ;SET UP PACKET ADDRESS
      MOV      #10,T27RB  ;SET UP RECORDS TO SPACE OVER
;*****
;
;ACK,CVC=1,SPACE FORWARD COMMAND
;
;*****
      MOV      #140010,T27PK3 ;ACK,CVC=1,SPACE FORWARD COMMAND
1501:  MOV      R4,T50B(R5) ;ISSUE COMMAND
1521:  INC      T27CNT      ;BUMP TIMER
      DELAY    1          ;DELAY ABOUT 100US
                                     MOV     #1,(PC)+
                                     .WORD  0
                                     MOV     L#DLY,(PC)+
                                     .WORD  0
                                     DEC     -6(PC)
                                     BNE    -4
                                     DEC     -22(PC)
                                     BNE    -20
      MOV      TSSR(R5),R1 ;GET TSSR
      BIT      #BIT7,R1   ;CHECK FOR TSSR'S SSR SET
      BEQ      1521      ;KEEP COUNTING UNTIL SET
      MOV      TSSR(R5),R1 ;GET STATUS FROM TSSR
      MOV      #SSR,R2   ;SET UP EXPECTED

```


C4

CZTKGA TK-25 FRT END FUNC #3
TEST 3: WRITE DATA RETRY

MACRO M1200 20-APR-84 08:13 PAGE 120-4

SEQ 248

```

10044 054510 020201          CMP      R2,R1          ;WAS EVERYTHING OK
10045 054512 001406          BEQ      160#          ;BR, IF ALL IS WELL
10046 054514 004737 020116    JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
10050 054520          ERRHRD  ERRNO,T27SCF,PKTSSR ;SPACE FORWARD DIDN'T WORK OUT
                                TRAP      C#ERHRD
                                .WORD    344
                                .WORD    T27SCF
                                .WORD    PKTSSR
10051 054530          160#;  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C#CLP1
10052 054530 104406
10053
10054
10055
10056
10057
10058
10059 054532 004737 010444    JSR      PC,REWIND     ;CALL TAPE REWIND COMMAND
10060 054536 004737 017252    JSR      PC,CHKTSSR    ;SEE HOW TSSR IS
10061 054542 103407          BCS      170#          ;BR, IF NO PROBLEM
10062 054544 010001          MOV      R0,R1         ;SAVE TSSR
10063 054546 004737 020116    JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
10067 054552          ERRHRD  ERRNO,T27RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP      C#ERHRD
                                .WORD    345
                                .WORD    T27RWN
                                .WORD    PKTSSR
10068 054562          170#;  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C#CLP1
10069 054562 104406
10070
10071
10072
10073
10074
10075
10076 054564 013701 055546    MOV      T27BFR+6,R1   ;PICK UP XSTO
10077 054570 010102          MOV      R1,R2         ;SET UP EXPECTED
10078 054572 052702 000002    BIS      #BIT1,R2     ;SET BOT BIT IN EXPECTED
10079 054576 020102          CMP      R1,R2         ;DOES EXP = REC'D
10080 054600 001406          BEQ      175#          ;BR, IF EQUAL (OK)
10081 054602 004737 020116    JSR      PC,FATCHK     ;INC AND CHECK FOR MORE THAN 25 ERRORS
10085 054606          ERRHRD  ERRNO,T27BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C#ERHRD
                                .WORD    346
                                .WORD    T27BOT
                                .WORD    EXPREC
10086 054616          175#;  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C#CLP1
10087 054620 012703 000144    MOV      #100.,R3      ;STARTING RECORD SIZE
10088 054624 013737 003072 055652 177#;  MOV      FREE,T27WB    ;STARTING WRITE BUFFER ADDRESS
10089
10090
10091
10092
10093
10094

```

```

10095
10096 054632 012737 140005 055650      MOV      #140005,T27PK3      ;WRITE DATA,CVC=1,ACK COMMAND
10097 054640 012704 055650              MOV      #T27PK3,R4         ;SET UP R4 WITH PACKET ADDRESS
10098 054644 012737 000024 055656      MOV      #20.,T27SZ        ;SET UP RECORD SIZE IN PACKET
10099 054652 010465 177776              MOV      R4,T27SDB(R5)     ;ISSUE COMMAND
10100 054656 004737 017134              JSR      PC,WAITF          ;WAIT FOR SSR TO SET
10101 054662 016501 000000              MOV      TSSR(R5),R1       ;GET TSSR CONTENTS
10102 054666 012702 000200              MOV      #SSR,R2          ;SET UP EXPECTED
10103 054672 020102                      CMP      R1,R2             ;ARE THEY EQUAL
10104 054674 001406                      BEQ      180#              ;BR, IF OK
10105 054676 004737 020116              JSR      PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
10109
10110
10111
10112 054702                      ERRSOFT ERRNO,WRERR,PKTSSR ;SOFT ERROR GENERATED BECAUSE THE
                                ;WRITE COMMAND IS NOT BEING CHECKED
                                ;HERE. IT WAS CHECKED IN LEAH2
                                ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP      C#ERSOFT
                                .WORD    347
                                .WORD    WRERR
                                .WORD    PKTSSR
                                054702 104457
                                054704 000533
                                054706 005011
                                054710 011710
10113 054712 101406 180#; CKLOOP          ;LOOP IF SELECTED
                                TRAP      C#CLP1
                                054712 101406
10114 054714 005303          DEC      R3                ;COUNT NUMBER OF RECORDS
10115 054716 001342          BNE     177#              ;BR, IF MORE RECORDS TO WRITE
10116
10117
10118
10119
10120
10121
10122
10123 054720 004737 010444          JSR      PC,REWIND        ;ISSUE REWIND
10124 054724 103411          BCS     182#              ;BR, IF ALL IS WELL
10125 054726 010004          MOV     R0,R4             ;GET PACKET ADDRESS
10126 054730 016501 000000          MOV     TSSR(R5),R1       ;GET TSSR CONTENTS
10127 054734 004737 020116          JSR     PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
10131 054740          ERRHRD ERRNO,T27RWN,PKTSSR ;REWIND FAILED
                                TRAP      C#ERHRD
                                .WORD    348
                                .WORD    T27RWN
                                .WORD    PKTSSR
                                054740 104456
                                054742 000534
                                054744 057055
                                054746 012710
10132 054750 104406 182#; CKLOOP          ;SELECT LOOP MAYBE
                                TRAP      C#CLP1
10133
10134
10135
10136
10137
10138
10139
10140
10141 054752 012703 000001          MOV     #1.,R3            ;SPACE 1 RECORD FORWARD
10142 054756 004737 010144          JSR     PC,SPACE         ;ISSUE SPACE COMMAND
10143 054762 103411          BCS     185#              ;BR, IF COMMAND OK
10144 054764 010004          MOV     R0,R4             ;GET PACKET ADDRESS
10145 054768 016501 000000          MOV     TSSR(R5),R1       ;GET TSSR STATUS
10146 054772 004737 020116          JSR     PC,FATCHK        ;INC AND CHECK FOR MORE THAN 25 ERRORS
10150 054776          ERRHRD ERRNO,T27SCF,PKTSSR ;SPACE FORWARD COMMAND FAILED

```

E4

CZTKGA JK-25 FRT END FLNC #3
TEST 3: WRITE DATA RETRY

MACRO M1200 20-APR-84 08:13 PAGE 120-6

SEQ 250

```

054776 104456 TRAP C#ERHRD
055000 000535 .WORD 349
055002 060317 .WORD T27SCF
055004 011710 .WORD PKTSSR
10151 055006 185$: CKLOOP ;LOOP IF SELECTED TRAP C#CLP1
055008 104406 ;NUMBER OF RECORDS TO BE WRITTEN
10152 055010 012703 000144 MOV #100.,R3 ;STARTING WRITE BUFFER ADDRESS
10153 055014 013737 003072 055652 MOV FREE,T27WB
10154
10155 ;*****
10156 ;
10157 ;WRITE DATA RETRY,ACK COMMAND
10158 ;
10159 ;*****
10160
10161 055022 012737 101005 055650 190$: MOV #101005,T27PK3 ;WRITE DATA RETRY,ACK COMMAND
10162 055030 012704 055650 MOV #T27PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
10163 055034 012737 000024 055656 MOV #20.,T27SZ ;SET UP RECORD SIZE IN PACKET
10164 055042 010465 177776 MOV R4,TSDB(R5) ;ISSUE COMMAND
10165 055046 004737 017134 JSR PC,WAITF ;WAIT FOR SSR TO SET
10166 055052 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
10167 055056 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
10168 055062 020102 CMP R1,R2 ;ARE THEY EQUAL
10169 055064 001406 BEQ 200$ ;BR. IF OK
10170 055066 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
10174 055072 ERRHRD ERRNO,T27WDC,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
055072 104456 TRAP C#ERHRD
055074 000536 .WORD 350
055076 057411 .WORD T27WDC
055100 011710 .WORD PKTSSR
10175 055102 200$: CKLOOP ;LOOP IF SELECTED TRAP C#CLP1
055102 104406 ;STARTING WRITE BUFFER ADDRESS
10176 055104 013737 003072 055652 MOV FREE,T27WB
10177
10178 ;*****
10179 ;
10180 ;WRITE DATA,CVC=1,ACK COMMAND
10181 ;
10182 ;*****
10183
10184 055112 012737 140005 055650 MOV #140005,T27PK3 ;WRITE DATA,CVC=1,ACK COMMAND
10185 055120 012704 055650 MOV #T27PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
10186 055124 012737 000024 055656 MOV #20.,T27SZ ;SET UP RECORD SIZE IN PACKET
10187 055132 010465 177776 MOV R4,TSDB(R5) ;ISSUE COMMAND
10188 055136 004737 017134 JSR PC,WAITF ;WAIT FOR SSR TO SET
10189 055142 016501 000000 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
10190 055146 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
10191 055152 020102 CMP R1,R2 ;ARE THEY EQUAL
10192 055154 001406 BEQ 210$ ;BR. IF OK
10193 055156 004737 020116 JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
10194
10195 ;SOFT ERROR GENERATED BECAUSE THE
10196 ;WRITE COMMAND IS NOT BEING CHECKED
10197 ;HERE, IT WAS CHECKED IN LEAH2
10198
10199 ERRSOFT ERRNO,WRERR,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
10200 055162 ERRSOFT ERRNO,WRERR,PKTSSR TRAP C#ERSOFT
055162 104457 .WORD 351
055164 000537 .WORD WRERR
055166 005011

```

```

10201 055170 011710
10201 055172
10202 055172 104406
10202 055174 005303
10203 055176 001311
10204
10205
10206
10207
10208
10209
10210
10211 055200 004737 010444
10212 055204 103411
10213 055206 016501 000000
10214 055212 010004
10215 055214 004737 020116
10219 055220
10219 055220 104456
10219 055222 000540
10219 055224 057055
10219 055226 011710
10220 055230
10220 055230 104406
10221
10222
10223
10224
10225
10226
10227
10228 055232 013701 055546
10229 055236 010102
10230 055240 052702 000002
10231 055244 020102
10232 055246 001406
10233 055250 004737 020116
10237 055254
10237 055254 104456
10237 055256 000541
10237 055260 056551
10237 055262 016360
10238 055264
10238 055264 104406
10239 055266 012704 055650
10240 055272 012737 000010 055652
10241
10242
10243
10244
10245
10246
10247
10248 055300 012737 140010 055650
10249 055306 010465 177776
10250 055312 005237 055700
10251 055316

210*: CKLOOP ;LOOP IF SELECTED .WORD PKTSSR
;BUMP DOWN RECORD COUNTER TRAP C$CLP1
DEC R3 ;BR, IF MORE RECORDS TO WRITE RETRY
BNE 190$

;*****
;ISSUE REWIND COMMAND TO SELECTED TAPE DRIVE
;*****

JSR PC,REWIND ;CALL TAPE REWIND COMMAND
BCS 230$ ;BR, IF NO PROBLEM
MOV TSSR(R5),R1 ;GET TSSR CONTENTS
MOV R0,R4 ;GET PACKET ADDRESS
JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
ERRHRD ERRNO,T27RWN,PKTSSR ;REWIND NOT ACCEPTED
TRAP C$ERHRD
.WORD 352
.WORD T27RWN
.WORD PKTSSR

230*: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
;*****
;READ MESSAGE BUFFER EXTENDED STATUS REGISTER ZERO (XSTO)
;*****

MOV T27BFR+6,R1 ;PICK UP XSTO
MOV R1,R2 ;SET UP EXPECTED
BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
CMP R1,R2 ;DOES EXP = REC'D
BEQ 240$ ;BR, IF EQUAL (OK)
JSR PC,FATCHK ;INC AND CHECK FOR MORE THAN 25 ERRORS
ERRHRD ERRNO,T27BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
TRAP C$ERHRD
.WORD 353
.WORD T27BOT
.WORD EXPREC

240*: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
MOV #T27PK3,R4 ;SET UP PACKET ADDRESS
MOV #10,T27RB ;SET UP RECORDS TO SPACE OVER
;*****
;ACK,CVC=1,SPACE FORWARD COMMAND
;*****

MOV #140010,T27PK3 ;ACK,CVC=1,SPACE FORWARD COMMAND
250$: MOV R4,TSDB(R5) ;ISSUE COMMAND
252$: INC T27CNU ;BUMP TIMER
DELAY 1 ;DELAY ABOUT 100US

```


10290			!+			
10291			!LOCAL STORAGE FOR THIS TEST			
10292			!-			
10294	055512		.BLKB	10-<.-TUV2A&7>		
10296	055520		T27PACKET:			;COMMAND PACKET FOR TEST
10297	055520	100004	.WORD	100004		;WRITE CHARACTERISTICS COMMAND, WITH , ACK
10298	055522	055530	.WORD	T27DATA		;ADDRESS OF CHARACTERISTICS BLOCK
10299	055524	000000	.WORD	0		
10300	055526	000012	.WORD	10.		;STARTING VALUE OF BLOCK SIZE
10301	055530		T27DATA:			;CHARACTERISTICS DATA BLOCK
10302	055530	055540	.WORD	T27BFR		;ADDRESS OF MESSAGE BUFFER
10303	055532	000000	.WORD	0		
10304	055534	000024	.WORD	20.		;LENGTH OF MESSAGE BUFFER
10305	055536	000000	.WORD	0		
10306	055540		T27BFR: .BLKW	25.		;MESSAGE BUFFER
10307			;			
10308			!WRITE SUBSYSTEM MEMORY COMMAND PACKET			
10309			!			
10311	055622		.BLKB	10-<.-TUV2A&7>		
10313	055630		T27PK2:			
10314	055630	100006	.WORD	100006		;WRITE SUB SYS MEM COMMAND, AND ACK
10315	055632	055660	.WORD	T27BF2		;ADDRESS OF SELECT BLOCK DATA
10316	055634	000000	.WORD	0		
10317	055636	000006	.WORD	6.		;SIZE OF DATA PACKET
10318						
10320	055640		.BLKB	10-<.-TUV2A&7>		
10322	055650		T27PK3:			
10323	055650	100005	.WORD	100005		;REREAD COMMAND, AND ACK
10324	055652		T27RB:			
10325	055652	003072	T27WB: .WORD	FREE		;ADDRESS OF WRITE BUFFER
10326	055654	000000	.WORD	0		
10327	055656	000000	T27SZ: .WORD	0		;SIZE OF BUFFER (EXTENT)
10328			.EVEN			
10329	055660		T27BF2:			
10330	055660	010	T27BS0: .BYTE	10		;BSEL0 AREA
10331	055661	200	T27BS1: .BYTE	200		;BSEL1 AREA
10332	055662	000000	T27S2: .WORD	0		;SEL 2 AREA
10333	055664	000000	T27S3: .WORD	0		;DATA AREA
10334			.EVEN			
10335			!TAPE MOTION PACKET COMMAND VALUES			
10336						
10337	055670	100205	T27RN: .WORD	100205		;REREAD DATA (NEXT)
10338	055670	100605	T27RR: .WORD	100605		;REREAD DATA RETRY
10339	055672	102205	T27CON: .WORD	102205		;WRITE CONTINUOUS
10340	055674	177777	.WORD	177777		;END OF DATA
10341	055676	000000	T27CNT: .WORD	0		;TAPE TIMER COUNTER STORAGE AREA
10342	055678	000000	T27CNU: .WORD	0		;TAPE TIMER COUNTER STORAGE AREA
10343	055702	000000	T27DLY: .WORD	0		;DELAY COUNTER

```

10345
10346
10347
10348
10349
10350
10351 055704 124 141 150 T27WNG: .ASCIZ 'Tape Position Incorrect After REREAD Previous (OPP=1)'
10352 055772 124 123 123 T27RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
10353 056001 122 105 122 T27RRF: .ASCIZ 'REREAD Previous (Space Reverse, Read Forward) Command Failed'
10354 056155 120 117 123 T27SC: .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
10355 056220 122 111 102 T27LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'
10356 056270 124 123 123 T27WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
10357 056345 111 154 154 T27LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
10358 056426 122 105 122 T27SSR: .ASCIZ 'REREAD COMMAND Not Accepted'
10359 056462 124 123 123 T27WDE: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY Command, At BOT'
10360 056551 124 141 160 T27EOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
10361 056644 127 122 111 T27TIM: .ASCIZ 'WRITE DATA RETRY'S Erase Tape Not Long Enough'
10362 056721 122 105 122 T27EOT: .ASCIZ 'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
10363 056800 124 123 123 T27TM: .ASCIZ 'TSSR Not Correct After REREAD COMMAND Reject'
10364 057055 122 145 167 T27RWV: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
10365 057124 122 101 115 T27RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
10366 057177 124 123 123 T27AMS: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
10367 057246 104 162 151 T27OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
10368 057321 124 123 123 T27WDD: .ASCIZ 'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
10369 057411 124 123 123 T27WDC: .ASCIZ 'TSSR Not Correct After REREAD DATA Command'
10370 057454 103 126 103 T27VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
10371 057557 124 123 102 T27HSA: .ASCIZ 'TSSA Not Correct After REREAD DATA Command'
10372 057612 127 122 111 T27WMS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
10373 057701 122 145 141 T27RLS: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XST0'
10374 057753 122 145 141 T27RLS: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XST0'
10375 060055 122 145 163 T27RBC: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
10376 060133 122 145 141 T27TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
10377 060211 127 122 111 T27NEF: .ASCIZ 'WRITE DATA RETRY, At First Record, Failed To Set RIB Bit XST3'
10378 060277 124 123 123 T27SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
10379 060374 124 123 123 T27TSA: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY, Into BOT'
10380 060456 124 123 123 T27WRF: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY Command'
10381 060538 104 141 164 T27DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
10382 060633 127 162 151 T27ID: .ASCIZ 'Write Data Retry'
10383
10384 .EVEN
10385
10386
10387
10388
10389
10390
10391 060754
10392 060852
10393 060900 012701 055520
10394 060964 012721 100004
10395 061070 012721 055530
10396 061174 005021
10397 061276 012721 000012
10398 061332 012721 055540
10399 061406 005021
10400 061470 012721 000024
10401 061514 005021

;+
;LOCAL TEXT MESSAGES FOR TEST
;-

T27REST:
SAVREG
MOV @T27PACKET,(R1) ;SAVE THE REGISTERS
MOV @100004,(R1)+ ;START OF THE PACKET
MOV @T27DATA,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK,
;ADDRESS OF CHARAISTICS DATA BLOCK
CLR (R1)+ ;EXTENDED ADDRESS
MOV @10.,(R1)+ ;SIZE OF DATA BLOCK IN BYTES
MOV @T27BFR,(R1)+ ;ADDRESS OF MESSAGE BUFFER
CLR (R1)+
MOV @20.,(R1)+ ;LENGTH OF MESSAGE BUFFER
CLR (R1)+

```

```

10001 060716 012711 000000      MOV      #0,(R1)                ;SELECT DRIVE ZERO
10003 060722 012702 000030      MOV      #24.,R2              ;NUMBER OF LOCATIONS TO BE CLEARED
10004 060726 012762 177777 055540 64$:  MOV      #177777,T278FR(R2)   ;ALL ONES TO MESSAGE BUFFER
10005 060734 005742              TST      -(R2)                ;NEXT LOCATION
10006 060736 022702 000000      CMP      #0,R2                ;AT END OF LOOP YET
10007 060742 001371              BNE      64$                  ;KEEP GOING UNTIL DONE
10008 060744 000207              RTS      PC                    ;RETURN
10009
10010
10011 060746              T27RT2:
10012 060748              SAVREG
10013 060752 012701 055630      MOV      #T27PK2,R1          ;SAVE THE REGISTERS
10014 060754 012721 100006      MOV      #100006,(R1)+       ;START OF THE PACKET
10015 060762 012721 055660      MOV      #T27BF2,(R1)+      ;WRITE SUBSYSTEM MEM. WITH ACK,
10016 060764 005021              CLR      (R1)+                ;ADDRESS OF DATA BLOCK
10017 060770 012721 000000      MOV      #6.,(R1)+           ;EXTENDED ADDRESS
10018 060774 005021              CLR      (R1)+                ;SIZE OF DATA BLOCK IN BYTES
10019 060776 012701 055660      MOV      #T27BF2,R1          ;POINT TO DATA SEL AREA
10020 061002 005021              CLR      (R1)+
10021 061004 005011              CLR      (R1)
10022 061006 000207              RTS      PC                    ;RETURN
10023 061010              T27RT3:
10024 061012              SAVREG
10025 061014 012701 055650      MOV      #T27PK3,R1          ;SAVE REGISTERS
10026 061020 005021              CLR      (R1)+                ;SET UP POINTER ADDRESS
10027 061022 005021              CLR      (R1)+                ;COMMAND SPACE
10028 061024 005021              CLR      (R1)+                ;ADDRESS OF DATA BLOCK
10029 061026 005011              CLR      (R1)+                ;EXTENDED ADDRESS
10030 061028 000207              RTS      PC                    ;SIZE OF DATA TRANSFER BLOCK
10031 061030              ENDTST
10032 061032 104401              L10066: TRAP      C#ETST
    
```


10433
10434
10435
10436
10437
10438
10439
10440
10441
10442
10443
10444
10445
10446
10447
10448
10449
10450

061034			
061034			
061034	005037	002170	
061040	005037	003100	
061044	012737	005771	002146
061052	005037	003102	
061056	004737	020262	
061062	012700	065251	
061066	004737	017424	
061072	012737	000001	002164
061100			

.SBTTL TEST 4: WRITE/READ TAPE MARK

```

;+
;
; THIS TEST VERIFIES THAT THE WRITE TAPE MARK COMMAND OPERATES
; PROPERLY. IT IS VERIFIED THAT THE TAPE MARK IS WRITTEN ONTO TAPE
; BY CHECKING THAT THE READ AND SPACE RECORDS COMMANDS DETECT THE
; TAPE MARK. IN ADDITION, SINCE WRITE TAPE MARK IS THE FIRST
; SUBCOMMAND UNDER THE FORMAT COMMAND BEING TESTED, IT IS VERIFIED
; THAT THE CLEAR VOLUME CHECK (CVC) BIT OPERATES PROPERLY AND THAT
; FORMAT COMMANDS WITH ILLEGAL MODE CODES ARE REJECTED.
;
; THE TEST CONSISTS OF THE FOLLOWING 3 SUBTESTS
;
; -

```

BTST

```

; CLEAR FATAL ERROR FLAG
; HOLD OFF KT11
; SECONDARY ERROR MESSAGE
; TURN KT11 OFF
; TURN KT11 BACK OFF IF THERE
; ASCII MESSAGE TO IDENTIFY TEST
; DO INITIAL TEST SETUP
; PERFORM 1 ITERATIONS

```

T28LOOP:

10465
10466
10467
10468
10469
10470
10471
10472
10473
10474
10475
10476
10477
10478
10479
10480
10481
10482
10483
10484
10485
10486
10487
10488
10489
10490
10491
10492
10493
10494
10495
10496
10497
10498
10499
10500
10501
10502
10503
10504
10505
10506
10507
10508
10509
10510
10511
10512
10513
10514
10515
10516
10517
10518
10519
10520
10521

;
;
; TEST 4, SUBTEST 1
;
; VERIFIES THAT WRITE TAPE MARK COMMANDS OPERATE
; PROPERLY, AND THAT READ COMMANDS SUBSEQUENTLY ISSUED
; TO DETECT THE WRITTEN TAPE MARKS TERMINATE WITH TAPE
; STATUS ALERT WITH THE TAPE MARK DETECTED (TMK) STATUS
; BIT SET. THE FOLLOWING SEQUENCE IS EXECUTED.
;
; 1. THE CONTROLLER IS INITIALIZED AND TAPE REWOUND.
; THIS SETS THE VOLUME CHECK (VCK) STATUS BIT.
;
; 2. A WRITE TAPE MARK COMMAND WITH CVC=1 IS ISSUED
; AND PROPER TERMINATION AND STATUS IS VERIFIED
; (I.E. VCK=0 AND TMK=1).
;
; 3. SEVERAL MORE WRITE TAPE MARK COMMANDS, THESE WITH
; CVC=0 ARE ISSUED AND PROPER TERMINATION (NORMAL)
; AND STATUS (TMK) VERIFIED.
;
; 4. A READ REVERSE COMMAND IS ISSUED AND PROPER
; TERMINATION (TAPE STATUS ALERT) AND STATUS (TMK)
; VERIFIED. IT IS ALSO VERIFIED THAT NO DATA IS
; TRANSFERRED INTO MEMORY.
;
; 5. A SPACE RECORDS REVERSE COMMAND IS ISSUED AND
; PROPER TERMINATION (TAPE STATUS ALERT) AND STATUS
; (TMK) VERIFIED.
;
; 6. THE TAPE IS REWOUND AND A READ FORWARD COMMAND IS
; ISSUED AND PROPER TERMINATION (TAPE STATUS ALERT)
; AND STATUS (TMK) VERIFIED. IT IS ALSO VERIFIED
; THAT NO DATA IS TRANSFERRED INTO MEMORY.
;
; 7. A SPACE RECORDS REVERSE COMMAND THAT CONTAINS A
; RECORD COUNT GREATER THAN 1 IS ISSUED AND IT IS
; VERIFIED THAT TAPE STATUS ALERT TERMINATION
; OCCURED, TMK=1 AND THAT RBPCR (RESIDUAL
; BYTE/RECORD COUNTER) CONTAINS THE PROPER NONZERO
; VALUE. THIS OPERATION VERIFIES THAT DETECTION OF
; THE TAPE MARK CAUSES THE SPACE RECORDS OPERATION
; TO BE PREMATURELY TERMINATED. THIS SHOULD LEAVE
; THE POSITION JUST BEFORE THE FIRST RECORD ON
; TAPE.
;
; 8. TAPE POSITION IS VERIFIED BY ISSUING ANOTHER
; SPACE RECORDS REVERSE COMMAND AND VERIFYING THAT
; TAPE STATUS ALERT TERMINATION OCCURS, WITH THE
; REVERSE INTO BOT (RIB) STATUS ERROR BIT SET.
;
; 9. A SPACE RECORDS FORWARD COMMAND THAT CONTAINS A
; RECORD COUNT GREATER THAN 1 IS ISSUED AND IT IS
; VERIFIED THAT TAPE STATUS ALERT TERMINATION
; OCCURED, TMK=1, AND THAT RBPCR (RESIDUAL
; BYTE/RECORD COUNTER) CONTAINS THE PROPER NONZERO
; VALUE. THIS OPERATION VERIFIES THAT DETECTION OF

	061264	064331						.WORD	T28RWN
	061266	011710						.WORD	PKTSSR
10567	061270			30\$:	CKLOOP				;LOOP IF SELECTED
	061270	104406						TRAP	C\$CLP1
10568	061272	013701	063236		MOV	T28BFR+6,R1			;PICK UP XSTO
10569	061276	010102			MOV	R1,R2			;SET UP EXPECTED
10570	061300	052702	000002		BIS	#BIT1,R2			;SET BOT BIT IN EXPECTED
10571	061304	020102			CMP	R1,R2			;DOES EXP = REC'D
10572	061306	001406			BEQ	40\$;BR, IF EQUAL (OK)
10573	061310	004737	020116		JSR	PC,FATCHK			;INC AND CHECK FOR MORE THAN 25 ERRORS
10577	061314				ERRHRD	ERRNO,T28BOT,EXPREC			;TAPE NOT AT BOT AFTER REWIND
	061314	104456						TRAP	C\$ERHRD
	061316	000624						.WORD	404
	061320	064207						.WORD	T28BOT
	061322	016360						.WORD	EXPREC
10578	061324			40\$:	CKLOOP				;LOOP IF SELECTED
	061324	104406						TRAP	C\$CLP1
10579	061326	012704	063210		MOV	#T28PACKET,R4			;SUBROUTINE NEEDS PACKET ADDRESS
10580	061332	004737	010342		JSR	PC,WRTCHR			;ISSUE WRITE CHARACTERISTICS
10581	061336	103407			BCS	68\$;BR, IF COMMAND ISSUED OK
10582	061340	004737	020116		JSR	PC,FATCHK			;INC AND CHECK FOR MORE THAN 25 ERRORS
10586	061344	010001			MOV	R0,R1			;SAVE CONTENTS OF ISSR
10587	061346				ERRHRD	ERRNO,WRTMSG,SFMSG			;WRITE CHARACTERISTIC FAILED
	061346	104456						TRAP	C\$ERHRD
	061350	000625						.WORD	405
	061352	004754						.WORD	WRTMSG
	061354	011676						.WORD	SFMSG
10588	061356			68\$:	CKLOOP				;LOOP IF SELECTED
	061356	104406						TRAP	C\$CLP1
10589	061360	012737	140011	063340	MOV	#140011,T28PK3			;WRITE TAPE MARK,ACK,CVC=1 COMMAND
10590	061366	012704	063340		MOV	#T28PK3,R4			;SET UP R4 WITH PACKET ADDRESS
10591	061372	010465	177776		MOV	R4,TSDB(R5)			;ISSUE COMMAND
10592	061376	004737	017134		JSR	PC,WAITF			;WAIT FOR SSR TO SET
10593	061402	016501	000000		MOV	TSSR(R5),R1			;GET TSSR CONTENTS
10594	061406	012702	000200		MOV	#SSR,R2			;SET UP EXPECTED
10595	061412	020102			CMP	R1,R2			;ARE THEY EQUAL
10596	061414	001406			BEQ	70\$;BR, IF OK
10597	061416	004737	020116		JSR	PC,FATCHK			;INC AND CHECK FOR MORE THAN 25 ERRORS
10601	061422				ERRHRD	ERRNO,T28WDC,PKTSSR			;TSSR INCORRECT AFTER WRITE TAPE MARK
	061422	104456						TRAP	C\$ERHRD
	061424	000626						.WORD	406
	061426	064453						.WORD	T28WDC
	061430	011710						.WORD	PKTSSR
10602	061432			70\$:	CKLOOP				;LOOP IF SELECTED
	061432	104406						TRAP	C\$CLP1
10603	061434	013701	063237		MOV	T28BFR+6,R1			;PICK UP XSTO (VCK CHECK)
10604	061440	010102			MOV	R1,R2			;SET UP EXPECTED
10605	061442	042702	000020		BIC	#BIT4,R2			;VCK SHOULD BE 0
10606	061446	020102			CMP	R1,R2			;IS VCK SET CORRECTLY
10607	061450	001406			BEQ	80\$;BR, IF VCK IS CLEAR
10608	061452	004737	020116		JSR	PC,FATCHK			;INC AND CHECK FOR MORE THAN 25 ERRORS
10612	061456				ERRHRD	ERRNO,T28VCK,EXPREC			;VCK WAS NOT CLEAR AFTER CVC=1
	061456	104456						TRAP	C\$ERHRD
	061460	000627						.WORD	407
	061462	064532						.WORD	T28VCK
	061464	016360						.WORD	EXPREC
10613	061466			80\$:	CKLOOP				;LOOP IF SELECTED

10614	061466	104406							TRAP	C#CLP1
10615	061470	013701	063236	MOV	T28BFR+6,R1					
10616	061474	010102		MOV	R1,R2					
10617	061476	052702	100000	JIS	#BIT15,R2					
10618	061502	020102		CMP	R1,R2					
10619	061504	001406		BEQ	90#					
10623	061506	004737	020116	JSR	PC,FATCHK					
	061512			ERRHRD	ERRNO,T28TMK,EXPREC					
	061512	104456								
	061514	000630								
	061516	064605								
	061520	016360								
10624	061522			90#:	CKLOOP					
	061522	104406								
10625	061524	004737	010444	JSR	PC,REWIND					
10626	061530	103411		BCS	130#					
10627	061532	010004		MOV	R0,R4					
10628	061534	016501	000000	MOV	TSSR(R5),R1					
10629	061540	004737	020116	JSR	PC,FATCHK					
10633	061544			ERRHRD	ERRNO,T28RWN,PKTSSR					
	061544	104456								
	061546	000531								
	061550	064331								
	061552	011710								
10634	061554			130#:	CKLOOP					
	061554	104406								
10635	061556	013701	063236	MOV	T28BFR+6,R1					
10636	061562	010102		MOV	R1,R2					
10637	061564	052702	000002	BIS	#BIT1,R2					
10638	061570	020102		CMP	R1,R2					
10639	061572	001406		BEQ	140#					
10640	061574	004737	020116	JSR	PC,FATCHK					
10644	061600			ERRHRD	ERRNO,T28BOT,EXPREC					
	061600	104456								
	061602	000632								
	061604	064207								
	061606	016360								
10645	061610			140#:	CKLOOP					
	061610	104406								
10646	061612	012703	000012							
10647	061616	012737	140011	063340	150#:	MOV	#10.,R3			
10648	061624	012704	063340		MOV	#140011,T28PK3				
10649	061630	010465	177776		MOV	#T28PK3,R4				
10650	061634	004737	017134		MOV	R4,TSD8(R5)				
10651	061640	016501	000000		JSR	PC,WAITF				
10652	061644	012702	000200		MOV	TSSR(R5),R1				
10653	061650	020102			MOV	#SSR,R2				
10654	061652	001406			CMP	R1,R2				
10655	061654	004737	020116		BEQ	165#				
10659	061660				JSR	PC,FATCHK				
	061660	104456			ERRHRD	ERRNO,T28WDC,PKTSSR				
	061662	000633								
	061664	064453								
	061666	011710								
10660	061670			165#:	CKLOOP					
	061670	104406								
10661	061672	013701	063236	MOV	T28BFR+6,R1					

C5

CZIKGA, TK-25, ERT, END, FUNC, #3
 TEST 4: WRITE/READ TAPE MARK

MACRO M1200 20-APR-84 08:13 PAGE 124-4

SEQ 261

10662	061678	010102		MOV	R1,R2		;	SET UP EXPECTED
10663	061700	052702	100000	BIS	#BIT15,R2		;	SET TMR BIT IN EXPECTED
10664	061704	020102		CMP	R1,R2		;	DOES EXP = REC'D
10665	061706	001406		BEQ	180#		;	BR, IF EQUAL (OK)
10666	061710	004737	020116	JSR	PC,FATCHK		;	INC AND CHECK FOR MORE THAN 25 ERRORS
10670	061714			ERRHRD	ERRNO,T28TMK,EXPREC		;	TMK NOT SET AFTER WRT TAPE MARK
	061714	104456						TRAP C#ERHRD
	061716	000634						.WORD 412
	061720	064605						.WORD T28TMK
	061722	016360						.WORD EXPREC
10671	061724			180#:	CKLOOP		;	LOOP IF SELECTED
	061724	104406						TRAP C#CLP1
10672	061726	005303		DEC	R3		;	BUMP COUNTER DOWN
10673	061730	001337		BNE	155#		;	BR, IF LESS THAN 10 TAPE MARKS
10674	061732	012700	177777	MOV	#177777,R0		;	VALUE TO WRITTEN TO MEMORY
10675	061736	004737	020410	JSR	PC,FILLMEM		;	FILL MEM WITH ALL ONES
10676	061742	013737	003072	MOV	FREE,T28WB	063342	;	STARTING READ BUFFER ADDRESS
10677	061750	012737	140401	MOV	#140401,T28PK3	063340	;	READ REVERSE,ACK, COMMAND
10678	061756	012704	063340	MOV	#T28PK3,R4		;	SET UP R4 WITH PACKET ADDRESS
10679	061762	013737	000024	MOV	20.,T28SZ	063346	;	SET UP RECORD SIZE IN PACKET
10680	061770	010465	177776	MOV	R4,T28B(R5)		;	ISSUE COMMAND
10681	061774	004737	017134	JSR	PC,WAITF		;	WAIT FOR SSR TO SET
10682	062000	016501	000000	MOV	T28B(R5),R1		;	GET T28B CONTENTS
10683	062004	012702	100204	MOV	#SSR!SC!BIT2,R2		;	SET UP EXPECTED
10684	062010	020102		CMP	R1,R2		;	ARE THEY EQUAL
10685	062012	001406		BEQ	200#		;	BR, IF OK
10686	062014	004737	020116	JSR	PC,FATCHK		;	INC AND CHECK FOR MORE THAN 25 ERRORS
10690	062020			ERRHRD	ERRNO,T28RDF,PKTSSR		;	T28B INCORRECT AFTER WRITE DATA
	062020	104456						TRAP C#ERHRD
	062022	000635						.WORD 413
	062024	063544						.WORD T28RDF
	062026	011710						.WORD PKTSSR
10691	062030			200#:	CKLOOP		;	LOOP IF SELECTED
	062030	104406						TRAP C#CLP1
10692	062032	013701	063236	MOV	T28BFR+6,R1		;	PICK UP XSTO
10693	062036	010102		MOV	R1,R2		;	SET UP EXPECTED
10694	062040	052702	100000	BIS	#BIT15,R2		;	TMK SHOULD BE SET
10695	062044	020102		CMP	R1,R2		;	IS TMK SET
10696	062046	001406		BEQ	210#		;	BR, IF TMK WAS SET (GOOD)
10697	062050	004737	020116	JSR	PC,FATCHK		;	INC AND CHECK FOR MORE THAN 25 ERRORS
10701	062054			ERRHRD	ERRNO,T28RRM,EXPREC		;	TMK NOT SET AFTER READ REV
	062054	104456						TRAP C#ERHRD
	062056	000636						.WORD 414
	062060	064657						.WORD T28RRM
	062062	016360						.WORD EXPREC
10702	062064			210#:	CKLOOP		;	LOOP IF SELECTED
	062064	104406						TRAP C#CLP1
10703	062066	017701	121000	MOV	#FREE,R1		;	FIRST LOC IN READ BUFFER
10704	062072	012702	177777	MOV	#177777,R2		;	EXPECTED IF NO DATA TRANS.
10705	062076	020102		CMP	R1,R2		;	DO ANY DATA GET TRANSFERRED
10706	062100	001406		BEQ	220#		;	BR, IF NO DATA TRANS (GOOD)
10707	062102	004737	020116	JSR	PC,FATCHK		;	INC AND CHECK FOR MORE THAN 25 ERRORS
10711	062106			ERRHRD	ERRNO,T28DTR,EXPREC		;	DATA TRANSFERRED ON READ TAPE MARK
	062106	104456						TRAP C#ERHRD
	062110	000637						.WORD 415
	062112	065072						.WORD T28DTR
	062114	016360						.WORD EXPREC

10712	062116			220:	CKLOOP		;LOOP IF SELECTED		
	062116	104406						TRAP	C\$CLP1
10713	062120	012737	100410	063340	MOV	#100410,T28PK3	;SPACE REVERSE,ACK, COMMAND		
10714	062126	012737	000001	063342	MOV	#1,T28RB	;NUMBER OF RECORDS TO SPACE BACK		
10715	062134	012704	063340		MOV	#T28PK3,R4	;SET UP R4 WITH PACKET ADDRESS		
10716	062140	010465	177776		MOV	R4,TSDB(R5)	;ISSUE COMMAND		
10717	062144	004737	017134		JSR	PC,WAITF	;WAIT FOR SSR TO SET		
10718	062150	016501	000000		MOV	TSSR(R5),R1	;GET TSSR CONTENTS		
10719	062154	012702	100204		MOV	#SSR!SCIBIT2 R2	;SET UP EXPECTED		
10720	062160	020102			CMP	R1,R2	;ARE THEY EQUAL		
10721	062162	001406			BEQ	222:	;BR, IF OK		
10722	062164	004737	020116		JSR	PC,FATCHK	;INC AND CHECK FOR MORE THAN 25 ERRORS		
10726	062170				ERRHRD	ERRNO,T28RDG,PKTSSR	;TSSR INCORRECT AFTER SPACE C.P.D.		
	062170	104456						TRAP	C\$ERHRD
	062172	000640						.WORD	416
	062174	063625						.WORD	T28RDG
	062176	011710						.WORD	PKTSSR
10727	062200			222:	CKLOOP		;LOOP IF SELECTED		
	062200	104406						TRAP	C\$CLP1
10728	062202	013701	063236		MOV	T28BFR+6,R1	;PICK UP XSTO		
10729	062206	010102			MOV	R1,R2	;SET UP EXPECTED		
10730	062210	052702	100000		BIS	#BIT15,R2	;TMK SHOULD BE SET		
10731	062214	020102			CMP	R1,R2	;IS TMK SET		
10732	062216	001406			BEQ	226:	;BR, IF TMK WAS SET (GOOD)		
10733	062220	004737	020116		JSR	PC,FATCHK	;INC AND CHECK FOR MORE THAN 25 ERRORS		
10737	062224				ERRHRD	ERRNO,T28RRN,EXPREC	;TMK NOT SET AFTER SPACE REV		
	062224	104456						TRAP	C\$ERHRD
	062226	000641						.WORD	417
	062230	064735						.WORD	T28RRN
	062232	016360						.WORD	EXPREC
10738	062234			226:	CKLOOP		;LOOP IF SELECTED		
	062234	104406						TRAP	C\$CLP1
10739	062236	004737	010444		JSR	PC,REWIND	;CALL TAPE REWIND COMMAND		
10740	062242	103411			BCS	230:	;BR, IF NO PROBLEM		
10741	062244	010004			MOV	R0,R4	;SAVE PACKET ADDRESS		
10742	062246	016501	000000		MOV	TSSR(R5),R1	;GET TSSR		
10743	062252	004737	020116		JSR	PC,FATCHK	;INC AND CHECK FOR MORE THAN 25 ERRORS		
10747	062256				ERRHRD	ERRNO,T28RWN,PKTSSR	;REWIND NOT ACCEPTED		
	062256	104456						TRAP	C\$ERHRD
	062260	000642						.WORD	418
	062262	064331						.WORD	T28RWN
	062264	011710						.WORD	PKTSSR
10748	062266			230:	CKLOOP		;LOOP IF SELECTED		
	062266	104406						TRAP	C\$CLP1
10749	062270	013701	063236		MOV	T28BFR+6,R1	;PICK UP XSTO		
10750	062274	010102			MOV	R1,R2	;SET UP EXPECTED		
10751	062276	052702	000002		BIS	#BIT11,R2	;SET BOT BIT IN EXPECTED		
10752	062302	020102			CMP	R1,R2	;DOES EXP = REC'D		
10753	062304	001406			BEQ	240:	;BR, IF EQUAL (OK)		
10754	062306	004737	020116		JSR	PC,FATCHK	;INC AND CHECK FOR MORE THAN 25 ERRORS		
10758	062312				ERRHRD	ERRNO,T28BOT,EXPREC	;TAPE NOT AT BOT AFTER REWIND		
	062312	104456						TRAP	C\$ERHRD
	062314	000643						.WORD	419
	062316	064207						.WORD	T28BOT
	062320	016360						.WORD	EXPREC
10759	062322			240:	CKLOOP		;LOOP IF SELECTED		
	062322	104406						TRAP	C\$CLP1

E5

CZTKGA TK-25 FRT END FUNC #3
TEST 4: WRITE/READ TAPE MARK

MACRO M1200 20-APR-84 08:13 PAGE 124-6

SEQ 263

10760	062324	012700	177777		MOV	#177777,R0	;VALUE TO WRITTEN TO MEMORY
10761	062330	004737	020410		JSR	PC,FILLMEM	;FILL MEM WITH ALL ONES
10762	062334	013737	003072	063342	MOV	FREE,T28RB	;STARTING READ BUFFER ADDRESS
10763	062342	012737	100001	063340	MOV	#100001,T28PK3	;READ FORWARD,ACK, COMMAND
10764	062350	012704	063340		MOV	#T28PK3,R4	;SET UP R4 WITH PACKET ADDRESS
10765	062354	013737	900024	063346	MOV	20.,T28SZ	;SET UP RECORD SIZE IN PACKET
10766	062362	010465	177776		MOV	R4,TSDB(R5)	;ISSUE COMMAND
10767	062366	004737	017134		JSR	PC,WAITF	;WAIT FOR SSR TO SET
10768	062372	016501	000000		MOV	TSSR(R5),R1	;GET TSSR CONTENTS
10769	062376	012702	100204		MOV	#SSR!SC!BIT2,R2	;SET UP EXPECTED
10770	062402	020102			CMP	R1,R2	;ARE THEY EQUAL
10771	062404	001406			BEQ	245#	;BR, IF OK
10772	062406	004737	020116		JSR	PC,FATCHK	;INC AND CHECK FOR MORE THAN 25 ERRORS
10776	062412				ERRHRD	ERRNO,T28WDE,PKTSSR	;TSSR INCORRECT AFTER WRITE DATA
	062412	104456					TRAP C#ERHRD
	062414	000644					.WORD 420
	062416	064116					.WORD T28WDE
	062420	011710					.WORD PKTSSR
10777	062422			245#:	CKLOOP		;LOOP IF SELECTED
	062422	104406					TRAP C#CLP1
10778	062424	013701	063236		MOV	T28BFR+6,R1	;PICK UP XSTO
10779	062430	010102			MOV	R1,R2	;SET UP EXPECTED
10780	062432	052702	100000		BIS	#BIT15,R2	;TMK SHOULD BE SET
10781	062436	020102			CMP	R1,R2	;IS TMK SET
10782	062440	001406			BEQ	247#	;BR, IF TMK WAS SET (GOOD)
10783	062442	004737	020116		JSR	PC,FATCHK	;INC AND CHECK FOR MORE THAN 25 ERRORS
10787	062446				ERRHRD	ERRNO,T28RRP,EXPREC	;TMK NOT SET AFTER READ REV
	062446	104456					TRAP C#ERHRD
	062450	000645					.WORD 421
	062452	065014					.WORD T28RRP
	062454	016360					.WORD EXPREC
10788	062456			247#:	CKLOOP		;LOOP IF SELECTED
	062456	104406					TRAP C#CLP1
10789	062460	017701	120406		MOV	#FREE,R1	;FIRST LOC IN READ BUFFER
10790	062464	012702	177777		MOV	#177777,R2	;EXPECTED IF NO DATA TRANS.
10791	062470	020102			CMP	R1,R2	;DID ANY DATA GET TRANSFERRED
10792	062472	001406			BEQ	250#	;BR, IF NO DATA TRANS (GOOD)
10793	062474	004737	020116		JSR	PC,FATCHK	;INC AND CHECK FOR MORE THAN 25 ERRORS
10797	062500				ERRHRD	ERRNO,T28DTR,EXPREC	;DATA TRANSFERRED ON READ TAPE MARK
	062500	104456					TRAP C#ERHRD
	062502	000646					.WORD 422
	062504	065072					.WORD T28DTR
	062506	016360					.WORD EXPREC
10798	062510			250#:	CKLOOP		;LOOP IF SELECTED
	062510	104406					TRAP C#CLP1
10799	062512	012737	100410	063340	MOV	#100410,T28PK3	;SPACE REVERSE,ACK, COMMAND
10800	062520	012737	000005	063342	MOV	#5,T28RB	;NUMBER OF RECORDS TO SPACE BACK
10801	062526	012704	063340		MOV	#T28PK3,R4	;SET UP R4 WITH PACKET ADDRESS
10802	062532	010465	177776		MOV	R4,TSDB(R5)	;ISSUE COMMAND
10803	062536	004737	017134		JSR	PC,WAITF	;WAIT FOR SSR TO SET
10804	062542	016501	000000		MOV	TSSR(R5),R1	;GET TSSR CONTENTS
10805	062546	012702	100204		MOV	#SSR!SC!BIT2,R2	;SET UP EXPECTED
10806	062552	020102			CMP	R1,R2	;ARE THEY EQUAL
10807	062554	001406			BEQ	260#	;BR, IF OK
10808	062556	004737	020116		JSR	PC,FATCHK	;INC AND CHECK FOR MORE THAN 25 ERRORS
10812	062562				ERRHRD	ERRNO,T28RDG,PKTSSR	;TSSR INCORRECT AFTER SPACE REV CMD.
	062562	104456					TRAP C#ERHRD

H5

CZTKGA TK-25 FRT END FUNC 03
TEST 4: WRITE/READ TAPE MARK

MACRO M1200 20-APR-84 08:13 PAGE 124-9

SEQ 266

10907 063174 000137 061100
10908 063200
10909 063200
 063200 104432
 063202 002252

1634: JMP T28LOOP
 EXIT TST

;EXECUTE AGAIN

;ALL DONE THIS TEST

TRAP C#EXIT
.WORD L10074-

```

10911
10912
10913
10915 063204
10917 063210
10918 063210 100004
10919 063212 063220
10920 063214 000000
10921 063216 000012
10922 063220
10923 063220 063230
10924 063222 000000
10925 063224 000024
10926 063226 000000
10927 063230
10928
10929
10930
10932 063312
10934 063320
10935 063320 100006
10936 063322 063350
10937 063324 000000
10938 063326 000006
10939
10941 063330
10943 063340
10944 063340 100005
10945 063342
10946 063342 003072
10947 063344 000000
10948 063346 000000
10949
10950
10951
10952
10953 063350
10954 063350 010
10955 063351 200
10956 063352 000000
10957 063354 000000
10958
10959
10960
10961
10962
10963 063356
10964 063356 101411
10965 063360 102011
10966 063362 103411
10967 063364 177777
10968 063366 100011
10969 063370 100411
10970 063372 101011
10971 063374 177777
10972
10973

;
; LOCAL STORAGE FOR THIS TEST
;
;
; .BLK 10-<.-TUV2A&7>
T28PACKET:
; .WORD 100004
; .WORD T28DATA
; .WORD 0
; .WORD 10.
; COMMAND PACKET FOR TEST
; WRITE CHARACTERISTICS COMMAND, WITH IE, ACK
; ADDRESS OF CHARACTERISTICS BLOCK
;
; STARTING VALUE OF BLOCK SIZE
; CHARACTERISTICS DATA BLOCK
; ADDRESS OF MESSAGE BUFFER
;
; LENGTH OF MESSAGE BUFFER
; MESSAGE BUFFER
;
; WRITE SUBSYSTEM MEMORY COMMAND PACKET
;
; .BLK 10-<.-TUV2A&7>
T28PK2:
; .WORD 100006
; .WORD T28BF2
; .WORD 0
; .WORD 6.
; WRITE SUB SYS MEM COMMAND, IE AND ACK
; ADDRESS OF SELECT BLOCK DATA
;
; SIZE OF DATA PACKET
;
; .BLK 10-<.-TUV2A&7>
T28PK3:
; .WORD 100005
; REREAD COMMAND, AND ACK
; ADDRESS OF WRITE BUFFER
;
; SIZE OF BUFFER (EXTENT)
;
;
;
;
; .WORD 10
; .WORD 200
; .WORD 0
; .WORD 0
; .BYTE 10
; .BYTE 200
; .WORD 0
; .WORD 0
; BSELO AREA
; BSEL1 AREA
; SEL 2 AREA
; DATA AREA
;
;
; .EVEN
; TAPE MOTION PACKET COMMAND VALUES
;
;
; .WORD 101411
; .WORD 102011
; .WORD 103411
; .WORD 177777
; .WORD 100011
; .WORD 100411
; .WORD 101011
; .WORD 177777
; ILLEGAL MODE BITS TEST DATA
;
; WRITE TAPE MARK COMMAND
; ERASE COMMAND
; WRITE TAPE MARK RETRY
; END OF DATA
;

```

J5

CZTKGA TK-25 FRT END FUNC 03
TEST 4: WRITE/READ TAPE MARK

MACRO M1200 20-APR-84 08:13 PAGE 125-1

SEQ 268

10974 063376 000000
10975 063400 000000
10976 063402 000000
10977
10978

T28CNT: .WORD 0
T28CNU: .WORD 0
T28DLY: .WORD 0
.EVEN

;TAPE TIMER COUNTER STORAGE AREA
;TAPE TIMER COUNTER STORAGE AREA
;DELAY COUNTER

```

10980
10981
10982
10983
10984
10985 063404      124      141      160 T28RIB: .ASCIZ 'Tape Position Not Correct, RIB Should Be Set'
10986 063461      122      145      163 T28PBP: .ASCIZ 'Residual Byte Counter Register (RBPCR) Not Correct'
10987 063544      124      123      123 T28RDF: .ASCIZ 'TSSR Incorrect After READ REVERSE Into TAPE MARK'
10988 063625      124      123      123 T28RDG: .ASCIZ 'TSSR Incorrect After SPACE Command Into TAPE MARK'
10989 063707      124      123      123 T28WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
10990 063764      111      154      154 T28LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XSTO'
10991 064045      127      122      111 T28SSR: .ASCIZ 'WRITE MISCELLANEOUS Command Not Accepted'
10992 064116      124      123      123 T28WDE: .ASCIZ 'TSSR Not Correct After READ DATA Command, Into TAPE MARK'
10993 064207      124      141      150 T28BOT: .ASCIZ 'Tape Not At BOT After REWIND Command'
10994 064254      124      123      123 T28TM: .ASCIZ 'TSSR Not Correct After FORMAT Command Reject'
10995 064331      122      145      167 T28RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
10996 064400      104      162      151 T28OFL: .ASCIZ 'Drive 7 Select Failed To Set "DFL" In TSSR'
10997 064453      124      123      123 T28WDC: .ASCIZ 'TSSR Not Correct After WRITE TAPE MARK Command'
10998 064532      103      126      103 T28VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
10999 064605      124      115      113 T28TMK: .ASCIZ 'TMK Not Set After WRITE TAPE MARK Command'
11000 064657      124      115      113 T28RRM: .ASCIZ 'TMK Not Set After READ REVERSE Into TAPE MARK'
11001 064735      124      115      113 T28RRN: .ASCIZ 'TMK Not Set After SPACE REVERSE Into TAPE MARK'
11002 065014      124      115      113 T28RRP: .ASCIZ 'TMK Not Set After READ FORWARD Into TAPE MARK'
11003 065072      104      141      164 T28DTR: .ASCIZ 'Data Transferred On READ REVERSE Into A TAPE MARK'
11004 065154      104      141      164 T28DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
11005 065251      127      162      151 T28ID: .ASCIZ 'Write/Read Tape Mark'
11006
11007
11008
11009
11010
11011
11012
11013
11014 065276
11015 065276
11016 065302 012701 063210
11017 065306 012721 100004
11018 065312 012721 063220
11019 065316 005021
11020 065320 012721 000012
11021 065324 012721 063230
11022 065330 005021
11023 065332 012721 000024
11024 065336 005021
11025 065340 012711 000000
11026 065344 012702 000030
11027 065350 012762 177777 063230 64$:
11028 065356 005742
11029 065360 020227 000000
11030 065364 001371
11031 065366 000207
11032
11033
11034 065370
11035 065370
11036 065374 012701 063320

;LOCAL TEXT MESSAGES FOR TEST
;
;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
;WRITE SUBSYSTEM MEMORY COMMAND
;
;
T28REST:
        SAVREG
        MOV     #T28PACKET,R1
        MOV     #100004,(R1)+
        MOV     #T28DATA,(R1)+
        CLR     (R1)+
        MOV     #10.,(R1)+
        MOV     #T28BFR,(R1)+
        CLR     (R1)+
        MOV     #20.,(R1)+
        CLR     (R1)+
        MOV     #0,(R1)
        MOV     #24.,R2
        MOV     #177777,T28BFR(R2)
        TST     -(R2)
        CMP     R2,#0
        BNE     64$
        RTS     PC
;SAVE THE REGISTERS
;START OF THE PACKET
;WRITE SUBSYSTEM MEM. WITH ACK,
;ADDRESS OF CHARACTERISTICS DATA BLOCK
;EXTENDED ADDRESS
;SIZE OF DATA BLOCK IN BYTES
;ADDRESS OF MESSAGE BUFFER
;LENGTH OF MESSAGE BUFFER
;SELECT DRIVE ZERO
;NUMBER OF LOCATIONS TO BE CLEARED
;ALL ONES TO MESSAGE BUFFER
;NEXT LOCATION
;CHECK FOR END
;KEEP GOING UNTIL DONE
;RETURN

T28RT2:
        SAVREG
        MOV     #T28PK2,R1
;SAVE THE REGISTERS
;START OF THE PACKET

```

```

11037 065400 012721 100006      MOV      #100006,(R1)+      ;WRITE SUBSYSTEM MEM. WITH ACK,
11038 065404 012721 063350      MOV      #T28BF2,(R1)+    ;ADDRESS OF DATA BLOCK
11039 065410 005021              CLR      (R1)+            ;EXTENDED ADDRESS
11040 065412 012721 000006      MOV      #6,(R1)+        ;SIZE OF DATA BLOCK IN BYTES
11041 065416 005021              CLR      (R1)+
11042 065420 012701 063350      MOV      #T28BF2,R1      ;POINT TO DATA SEL AREA
11043 065424 005021              CLR      (R1)+
11044 065426 005011              CLR      (R1)
11045 065430 000207              RTS      PC              ;RETURN
11046 065432                    T28RT3:
11047 065432                    SAVREG
11048 065436 012701 063340      MOV      #T28PK3,R1      ;GET PACKET ADDRESS
11049 065442 005021              CLR      (R1)+          ;CLEAR COMMAND AREA
11050 065444 005021              CLR      (R1)+          ;CLEAR ADDRESS AREA
11051 065446 005021              CLR      (R1)+          ;CLEAR EXTENDED ADDRESS AREA
11052 065450 005011              CLR      (R1)          ;SIZE OF DATA TRANSFER
11053 065452 000207              RTS      PC              ;RETURN
11054 065454                    ENDTST
      065454
      065454 104401                    L10074: TRAP C$ETST
11060
11065
11071
11072
11073
11074
11075
11076
11077
11078
11079
11080
11081
11082
11083
11084 065456                    .SBTTL  HARDWARE PARAMETER CODING SECTION
      065456 000015                    ;**
      065460                    ; THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
      ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
      ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
      ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
      ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
      ; WITH THE OPERATOR.
      ;**
      BGNHRD
      .WORD L10076-L$HARD/2
L$HARD:
11085
11086 065460                    GPRMA   HPM1,0,0,160000,177776,YES      ;GET TSBA/TSDB REGISTER ADDRESS.
      065460 000031                    .WORD   T$CODE
      065462 065512                    .WORD   HPM1
      065464 160000                    .WORD   T$LLOLIM
      065466 177776                    .WORD   T$HILIM
11087 065470                    GPRMA   HPM2,2,0,0,776,YES              ;GET VECTOR ADDRESS.
      065470 001031                    .WORD   I$CODE
      065472 065541                    .WORD   HPM2
      065474 000000                    .WORD   T$LLOLIM
      065476 000776                    .WORD   T$HILIM
11088 065500                    GPRMD   HPM3,4,0,340,0,7,YES          ;GET INTERRUPT PRIORITY.
      065500 002032                    .WORD   T$CODE
      065502 065565                    .WORD   HPM3
      065504 000340                    .WORD   340
      065506 000000                    .WORD   T$LLOLIM
      065510 000007                    .WORD   T$HILIM
11089 065512                    ENDRD
      .EVEN

```

M5

CZTKGA IK-25 FRT END FUNC #3 MACRO M1200 20-APR-84 08:13 PAGE 126-2
HARDWARE PARAMETER CODING SECT V

SEQ 271

	065512				L10076:		
11090	065512	104	105	126	HPM1:	.ASCIZ	'DEVICE ADDRESS (TSSR) '
11091	065541	111	116	124	HPM2:	.ASCIZ	'INTERRUPT VECTOR '
11092	065565	111	116	124	HPM3:	.ASCIZ	'INTERRUPT PRIORITY '
11093							
11094						.EVEN	

```

11096                                .SBTTL SOFTWARE PARAMETER CODING SECTION
11097
11098                                ;**
11099                                ; THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
11100                                ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
11101                                ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
11102                                ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
11103                                ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
11104                                ; WITH THE OPERATOR.
11105                                ;**
11106 065616                                BGNSFT
11107 065616 000006                                .WORD L10077-L$SOFT/2
11108 065620                                L$SOFT::
11109 065620 000130                                GPRML SPM1,0,-1,YES ;GET RAM DUMP FLAG
11110 065622 065634                                .WORD T$CODE
11111 065624 177777                                .WORD SPM1
11112 065626                                .WORD -1
11113 065626 001130                                GPRML SPM4,2,-1,YES ; GET ITERATION CONTROL.
11114 065626 001130                                .WORD T$CODE
11115 065630 065700                                .WORD SPM4
11116 065632 177777                                .WORD -1
11117 065634                                ; GPRMD SPM6,4,D,7777,0,7777,YES ; GET LOCAL ERROR LIMIT
11118 065634                                ; GPRMD SPM7,6,D,7777,0,7777,YES ; GET GLOBAL ERROR LIMIT
11119                                .EVEN
11120                                L10077:
11121 065634 105 116 101 SPM1: .ASCIZ 'ENABLE CONTROLLER RAM DUMP ON ERROR'
11122 065700 111 116 110 SPM4: .ASCIZ 'INHIBIT ITERATIONS '
11123 065730 120 105 122 SPM6: .ASCIZ 'PER TEST ERROR LIMIT '
11124 065760 120 105 122 SPM7: .ASCIZ 'PER UNIT ERROR LIMIT '
11125                                .EVEN
11126                                .SETTL PATCH AREA
11127                                ;*
11128                                ;DISPATCH TABLE
11129                                ;
11130                                ; *** MOVE TO FRONT OF PROGRAM FOR RELEASE ***
11131                                ;**
11132                                DISPATCH TESTNU
11133 066010                                .WORD 4
11134 066012 000004                                L$DISPATCH::
11135 066012 023650                                .WORD T1
11136 066014 031666                                .WORD T2
11137 066016 051036                                .WORD T3
11138 066020 061034                                .WORD T4
11139                                ;
11140                                ; FINALLY A GENEROUS PATCH AREA.
11141                                ;
11142                                ; AND AN ADJUSTMENT TO ACCOUNT FOR THE "LASTAD BIT7" HACK
11143                                ; DESCRIBED IN "SUPPRG.MEM" (FOR REV C).
11144                                ;
11145                                PATCH::
11146
11147
11148
11149
11150
11151
11152
11153
11154
11155 066022
11156

```


B6

CZTKGA TK-25 FRT END FUNC #3
PATCH AREA

MACRO M1200 20-APR-84 08:13 PAGE 127-1

SEQ 273

11137				.IF	NZ,.6377
11138				. ,1377+1	
11139				.ENDC	
11140	066022			LASTAD	,SET LAST USED ADDRESS.
		066022		.EVEN	
		066024		.WORD T#FREE	
		066026		.WORD T#SIZE	
11141			L#LAST:	.SBTTL	HARD CODED P-TABLE
11142					
11143				DIAGNOSTIC IS PRE-PARAMETERIZED PER THIS TABLE	
11144					
11145	066026			BGNSETUP	1
11146	066026			BGNPTAB	
		066026		.WORD	0
		066030		.WORD	L10102-./2-1
		066032	L10100:	.WORD	172522
11147	066032	172522		.WORD	224
11148	066034	000224		.WORD	PRI05
11149	066036	000240		ENOPTAB	
11150	066040		L10102:	ENDSETUP	
		066040			
11151	066040				
11152					
11153		000001		.END	

T26WSS 050151	T27S2 055662	T28RES 065276	WC.IRW= 000004	XSOVCK= 000020
T27AM3 057177	T27S3 055664	T28RIB 063404	WC.IOT= 000100	XSOWLE= 004000
T27BA 057537	T27TIM 056644	T28RN 063366	WC.IIT= 000040	XSOWLK= 000004
T27BFR 055540	T27TM 057000	T28RRM 064657	WC.I5R= 000020	XS1CON 015257
T27BF2 055660	T27TRL 060133	T28RRN 064735	WF.IED= 000010	XS2CON 015324
T27BOT 056551	T27TSA 060374	T28RRP 065014	WF.IER= 000004	XS3CON 015371
T27BS0 055660	T27VCK 057464	T28RT2 065370	WF.IHI= 000200	XXCOMM 003070 G
T27BS1 055661	T27WB 055652	T28RT3 065432	WF.IRE= 000040	X#ALWA= 000000
T27CNT 055676	T27WDC 057411	T28RWN 064331	WF.IWF= 000020	X#FALS= 000040
T27CNU 055700	T27WDD 057321	T28SSR 064045	WF.IWR= 000100	X#OFFS= 000400
T27CON 055672	T27WDE 056462	T28SZ 063346	WF.I3R= 000002	X#TRUE= 000020
T27DAT 055530	T27WDF 056270	T28S2 063352	WF.I4R= 000001	X1.COR= 020000
T27DLY 055702	T27WDR 055670	T28S3 063354	WRTCHR 010342 G	X1.DLT= 100000
T27DTA 060536	T27WNG 055704	T28TM 064254	WRTERR 005011	X1.MBZ= 017375
T27EOT 056721	T27WRF 060456	T28TMK 064605	WRTMSG 004754	X1.RBP= 000400
T27LON 057701	T27WSS 057612	T28VCK 064532	XFERAS 016624	X1.SPA= 040000
T27L00 051106	T28BFR 063230	T28WB 063342	XNXM 017312	X1.UNC= 000002
T27LOP 057763	T28BF2 063350	T28WDC 064453	XORBFO 007432	X2.BUF= 000100
T27LOQ 056345	T28BOT 064207	T28WDE 064116	XORFOR 007550	X2.EXT= 000200
T27LOR 056220	T28BS0 063350	T28WDF 063707	XSTO = 000006 G	X2.OPM= 100000
T27NEF 060221	T28BS1 063351	T28WDR 063370	XST1 = 000010 G	X2.RCE= 040000
T27OFL 057246	T28CNT 063376	T3 051036 G	XST2 = 000012 G	X2.REV= 000077
T27PAC 055520	T28CNU 063400	T3.1 051106	XST3 = 000014 G	X2.SPA= 035400
T27PBP 060045	T28CON 063372	T3.2 051474	XST4 = 000016 G	X2.UNI= 000007
T27PK2 055630	T28DAT 063220	T3.3 052246	XSOBOT= 000002	X2.WCF= 002000
T27PK3 055650	T28DLY 063402	T3.4 053062	XSOCON 015212	X3.DCK= 000010
T27RB 055652	T28DTA 065154	T3.5 053756	XSOEOT= 000001	X3.MBZ= 000006
T27RDF 055772	T28DTR 065072	T4 061034 G	XSOIE = 000040	X3.MDE= 177400
T27RES 060654	T28IMV 063356	T4.1 061100	XSOILA= 000400	X3.OPI= 000100
T27RN 055666	T28L00 061100	UAM = 000200 G	XSOILC= 001000	X3.REV= 000040
T27RNC 057124	T28L0Q 063764	UNITN 002150 G	XSOLET= 020000	X3.RIB= 000001
T27RRF 056041	T28OFL 064400	UNREC = 000006	XSOMOT= 000200	X3.SPA= 000200
T27RT2 060746	T28PAC 063210	USI 004021	XSJNEF= 002000	X3.TRF= 000020
T27RT3 061010	T28PBP 063461	WAITF 017134 G	XSOONL= 000100	X4.HSP= 100000
T27RWN 057055	T28PK? 063320	WC.IFA= 000200	XSOPED= 000010	X4.MBZ= 017400
T27SC 056136	T28PK3 063340	WC.IFE= 000002	XSORLL= 010000	X4.RCE= 040000
T27SCF 060317	T28RB 063342	WC.IG0= 000001	XSORLS= 040000	X4.TSM= 020000
T27SSR 056426	T28RDF 063544	WC.IRE= 000010	XSOTMK= 100000	X4.WRC= 000377
T27SZ 055656	T28RDG 063625			

. ABS. 066040 000
 000000 001
 ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 29424 WORDS (115 PAGES)
 DYNAMIC MEMORY: 20060 WORDS (77 PAGES)
 ELAPSED TIME: 00:37:17
 CZTKGA.BIC,CZTKGA/-SP=SVC/ML,CZTKGA

TEST 2: REREADSB1
TEST 2: REREADSC1
TEST 2: REREADSD1
TEST 2: REREADSE1
TEST 2: REREADSF1
TEST 2: REREADSG1
TEST 2: REREADSH1
TEST 2: REREADSI1
TEST 2: REREADSJ1
TEST 2: REREADSK1
TEST 2: REREADSL1
TEST 2: REREADSM1
TEST 2: REREADSN1

TEST 2: REREADSB2
TEST 2: REREADSC2
TEST 2: REREADSD2
TEST 2: REREADSE2
TEST 3: WRITE DATAF2
TEST 3: WRITE DATAG2
TEST 3: WRITE DATAH2
TEST 3: WRITE DATAI2
TEST 3: WRITE DATAJ2
TEST 3: WRITE DATAK2
TEST 3: WRITE DATAL2
TEST 3: WRITE DATAM2
TEST 3: WRITE DATAN2

TEST 3: WRITE DATAB3
TEST 3: WRITE DATAC3
TEST 3: WRITE DATAD3
TEST 3: WRITE DATAE3
TEST 3: WRITE DATAF3
TEST 3: WRITE DATAG3
TEST 3: WRITE DATAH3
TEST 3: WRITE DATAI3
TEST 3: WRITE DATAJ3
TEST 3: WRITE DATAK3
TEST 3: WRITE DATAL3
TEST 3: WRITE DATAM3
TEST 3: WRITE DATAN3

TEST 3: WRITE DATAB4
TEST 3: WRITE DATAC4
TEST 3: WRITE DATAD4
TEST 3: WRITE DATAE4
TEST 3: WRITE DATAF4
TEST 3: WRITE DATAG4
TEST 3: WRITE DATAH4
TEST 3: WRITE DATAI4
TEST 3: WRITE DATAJ4
TEST 4: WRITE/READK4
TEST 4: WRITE/READL4
TEST 4: WRITE/READM4
TEST 4: WRITE/READN4

TEST 4: WRITE/READB5
TEST 4: WRITE/READC5
TEST 4: WRITE/READD5
TEST 4: WRITE/READE5
TEST 4: WRITE/READF5
TEST 4: WRITE/READG5
TEST 4: WRITE/READH5
TEST 4: WRITE/READI5
TEST 4: WRITE/READJ5
TEST 4: WRITE/READK5
TEST 4: WRITE/READL5
HARDWARE PARAMETER C....M5
SOFTWARE PARAMETER C....N5

PATCH AREAB6
SYMBOL TABLEC6
SYMBOL TABLED6
SYMBOL TABLEE6
SYMBOL TABLEF6