

.REM_
IDENTIFICATION

PRODUCT ID: AC-T722A-MC
PRODUCT TITLE: CZTSDAO TSU05 DIAG PART 4
DEPARTMENT: COMPUTER SPECIAL SYSTEMS/PPG
DATE: APRIL 26, 1983

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1982,1983 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	POP	UNIQUE'S	MASSBUS
DEC	DECUS	DECTAPE	

TABLE OF CONTENTS

1.0	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.2	SYSTEM REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
1.5	ASSUMPTIONS
2.0	OPERATING INSTRUCTIONS
2.1	COMMANDS
2.2	SWITCHES
2.3	FLAGS
2.4	HARDWARE QUESTIONS
2.5	SOFTWARE QUESTIONS
2.6	EXTENDED P-TABLE DIALOGUE
2.7	QUICK STARTUP PROCEDURE
3.0	ERROR INFORMATION
4.0	PERFORMANCE AND PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
6.0	TEST SUMMARIES
7.0	MAINTENANCE HISTORY

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT

THIS IS A PDP-11 RESIDENT DIAGNOSTIC WHICH CHECKS THE FUNCTIONALITY OF A TSU05 MAGTAPE SUBSYSTEM WHILE CONNECTED TO A PDP-11/23 SYSTEM (Q-BUS). THE PROGRAM PROVIDES ERROR MESSAGES WHICH IDENTIFY FAILING FUNCTIONS THAT AID IN THE REPAIR OF THE DEVICE. THIS DIAGNOSTIC CONSIST OF EIGHT TEST WHICH ARE EXECUTED IN SEQUENCE.

THIS DIAGNOSTIC HAS BEEN WRITTEN FOR USE WITH THE DIAGNOSTIC RUNTIME SERVICES SOFTWARE (SUPERVISOR). THESE SERVICES PROVIDE THE INTERFACE TO THE OPERATOR AND TO THE SOFTWARE ENVIRONMENT. THIS PROGRAM CAN BE USED WITH XXDP+, ACT, APT, SLIDE AND PAPER TAPE. FOR A COMPLETE DESCRIPTION OF THE RUNTIME SERVICES, REFER TO THE XXDP+ USER'S MANUAL. THERE IS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES IN SECTION 2 OF THIS DOCUMENT.

1.2 SYSTEM REQUIREMENTS

PDP-11 PROCESSOR AND MEMORY
CAUTION: DIAGNOSTIC REQUIRES 32K WORDS OF MEMORY
(28K USEABLE AND 4K RESERVED FOR I/O PAGE)
TSU05 MAGTAPE SUBSYSTEM (DRIVE AND CONTROLLER)
CONSOLE TERMINAL
PDP-11 DIAGNOSTIC SUPERVISOR (HSAAA.SYS VERSION 34 OR LATER)
PDP-11 DIAGNOSTIC LOADER/MONITOR (XXDP+)

1.3 RELATED DOCUMENTS AND STANDARDS

DIGITAL EQUIPMENT CORPORATION DOCUMENTS:

1. CHQUS XXDP+ USERS MANUAL; DOCUMENT NUMBER AC-F348E-MC
DATE: 14 JULY 1980.
2. TSU05 TRANSPORT SUBSYSTEM USER'S GUIDE; DOCUMENT NUMBER EK-TSU05-UG-001
DATE: AUGUST 1982
3. TSU05 TRANSPORT SUBSYSTEM TECHNICAL MANUAL; DOCUMENT NUMBER EK-TSU05-TM-001
DATE: AUGUST 1982
4. TSU05 TRANSPORT SUBSYSTEM INSTALLATION MANUAL; DOCUMENT NUMBER EK-TSU05-IN-001
DATE: AUGUST 1982

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

FUNCTIONAL PDP-11 CENTRAL PROCESSOR AND MEMORY
FUNCTIONAL CONSOLE TERMINAL
FUNCTIONAL STANDALONE DIAGNOSTIC SUPERVISOR
FUNCTIONAL DIAGNOSTIC LOADER/MONITOR (XXDP+)

1.5 ASSUMPTIONS

ALL HARDWARE EXCEPT THE HARDWARE UNDER TEST IS ASSUMED TO WORK PROPERLY OR FALSE ERRORS CAN BE REPORTED.
THE TAPE BEING USED ON THE TS05 TRANSPORT IS A KNOWN GOOD REEL OF TAPE.
CZTSAA,CZYSBA AND CZTSCA HAVE SUCESSFULLY RUN.

2.0 OPERATING INSTRUCTIONS

THIS SECTION CONTAINS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES. FOR DETAILED INFORMATION, REFER TO THE XXDP+ USER'S MANUAL (CHQUS).

2.1 COMMANDS

THERE ARE ELEVEN LEGAL COMMANDS FOR THE DIAGNOSTIC RUNTIME SERVICES (SUPERVISOR). THIS SECTION LISTS THE COMMANDS AND GIVES A VERY BRIEF DESCRIPTION OF THEM. THE XXDP+ USER'S MANUAL HAS MORE DETAILS.

COMMAND	EFFECT
START	START THE DIAGNOSTIC FROM AN INITIAL STATE
RESTART	START THE DIAGNOSTIC WITHOUT INITIALIZING
CONTINUE	CONTINUE AT TEST THAT WAS INTERRUPTED (AFTER ↑C)
PROCEED	CONTINUE FROM AN ERROR HALT
EXIT	RETURN TO XXDP+ MONITOR (XXDP+ OPERATION ONLY!)
ADD	ACTIVATE A UNIT FOR TESTING (ALL UNITS ARE CONSIDERED TO BE ACTIVE AT START TIME)
DROP	DEACTIVATE A UNIT
PRINT	PRINT STATISTICAL INFORMATION (IF IMPLEMENTED BY THE DIAGNOSTIC - SECTION 4.0)
DISPLAY	TYPE A LIST OF ALL DFVICE INFORMATION
FLAGS	TYPE THE STATE OF ALL FLAGS (SEE SECTION 2.3)
ZFLAGS	CLEAR ALL FLAGS (SEE SECTION 2.3)

A COMMAND CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. SO YOU MAY, FOR EXAMPLE, TYPE "STA" INSTEAD OF "START".

2.1.1 OPERATOR COMMANDS

THE TS05 DIAGNOSTIC IS A PDP-11 DIAGNOSTIC SUPERVISOR COMPATIBLE PROGRAM. ALL LOADING AND RUNTIME INSTRUCTIONS CAN BE REFERENCED IN THE CHQUS XXDP+ USERS MANUAL, DOCUMENT NUMBER AC-F348E-MC. THE USER ENTRY IS IN QUOTES.

BOOT THE DIAGNOSTIC XXDP MEDIA

```
.R VTSD??
DIAG. RUN-TIME SERVICES REV D. APR 79
CZTSD-B-0
****TS05 LOGIC DIAGNOSTIC****
UNIT IS TS05
>DR
```

2.2 SWITCHES

THERE ARE SEVERAL SWITCHES WHICH ARE USED TO MODIFY SUPERVISOR OPERATION. THESE SWITCHES ARE APPENDED TO THE LEGAL COMMANDS. ALL OF THE LEGAL SWITCHES ARE TABULATED BELOW WITH A BRIEF DESCRIPTION OF EACH. IN THE DESCRIPTIONS BELOW, A DECIMAL NUMBER IS DESIGNATED BY "DDDDD".

SWITCH	EFFECT
/TESTS:LIST	EXECUTE ONLY THOSE TESTS SPECIFIED IN THE LIST. LIST IS A STRING OF TEST NUMBERS, FOR EXAMPLE - /TESTS:1:5:7-10. THIS LIST WILL CAUSE TESTS 1,5,7,8,9,10 TO BE RUN. ALL OTHER TESTS WILL NOT BE RUN.
/PASS:DDDDD	EXECUTE DDDDD PASSES (DDDDD = 1 TO 64000)
/FLAGS:FLGS	SET SPECIFIED FLAGS. FLAGS ARE DESCRIBED IN SECTION 2.3.
/EOP:DDDDD	REPORT END OF PASS MESSAGE AFTER EVERY DDDDD PASSES ONLY. (DDDDD = 1 TO 64000)
/UNITS:LIST	TEST/ADD/DROP ONLY THOSE UNITS SPECIFIED IN THE LIST. LIST EXAMPLE - /UNITS:0:5:10-12 USE UNITS 0,5,10,11,12 (UNIT NUMBERS = 0-63)

EXAMPLE OF SWITCH USAGE:

START/TESTS:1-5/PASS:1000/EOP:100

THE EFFECT OF THIS COMMAND WILL BE: 1) TESTS 1 THROUGH 5 WILL BE EXECUTED, 2) ALL UNITS WILL TESTED 1000 TIMES AND 3) THE END OF PASS MESSAGES WILL BE PRINTED AFTER EACH 100 PASSES ONLY. A SWITCH CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. YOU MAY, FOR EXAMPLE, TYPE "/TES:1-5" INSTEAD OF "/TESTS:1-5".

BELOW IS A TABLE THAT SPECIFIES WHICH SWITCHES CAN BE USED BY EACH COMMAND.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					

2.3 FLAGS

FLAGS ARE USED TO SET UP CERTAIN OPERATIONAL PARAMETERS SUCH AS LOOPING ON ERROR. ALL FLAGS ARE CLEARED AT STARTUP AND REMAIN CLEARED UNTIL EXPLICITLY SET USING THE FLAGS SWITCH. FLAGS

ARE ALSO CLEARED AFTER A START COMMAND UNLESS SET USING THE FLAG SWITCH. THE ZFLAGS COMMAND MAY ALSO BE USED TO CLEAR ALL FLAGS. WITH THE EXCEPTION OF THE START AND ZFLAGS COMMANDS, NO COMMANDS AFFECT THE STATE OF THE FLAGS; THEY REMAIN SET OR CLEARED AS SPECIFIED BY THE LAST FLAG SWITCH.

FLAG	EFFECT
HOE	HALT ON ERROR - CONTROL IS RETURNED TO RUNTIME SERVICES COMMAND MODE
LOE	LOOP ON ERROR
IER*	INHIBIT ALL ERROR REPORTS
IBR*	INHIBIT ALL ERROR REPORTS EXCEPT FIRST LEVEL (FIRST LEVEL CONTAINS ERROR TYPE, NUMBER, PC, TEST AND UNIT)
IXE*	INHIBIT EXTENDED ERROR REPORTS (THOSE CALLED BY PRINTX MACRO'S)
PRI	DIRECT MESSAGES TO LINE PRINTER
PNT	PRINT TEST NUMBER AS TEST EXECUTES
BOE	"BELL" ON ERROR
UAM	UNATTENDED MODE (NO MANUAL INTERVENTION)
ISR	INHIBIT STATISTICAL REPORTS (DOES NOT APPLY TO DIAGNOSTICS WHICH DO NOT SUPPORT STATISTICAL REPORTING)
IDR	INHIBIT PROGRAM DROPPING OF UNITS
ADR	EXECUTE AUTODROP CODE
LOT	LOOP ON TEST

*ERROR MESSAGES ARE DESCRIBED IN SECTION 3.1

SEE THE XXDP* USER'S MANUAL FOR MORE DETAILS ON FLAGS. YOU MAY SPECIFY MORE THAN ONE FLAG WITH THE FLAG SWITCH. FOR EXAMPLE, TO CAUSE THE PROGRAM TO LOOP ON ERROR, INHIBIT ERROR REPORTS AND TYPE A "BELL" ON ERROR, YOU MAY USE THE FOLLOWING STRING:

```
/FLAGS:LOE:IER:BOE
```

2.4 HARDWARE QUESTIONS

WHEN A DIAGNOSTIC IS STARTED, THE RUNTIME SERVICES WILL PROMPT THE USER FOR HARDWARE INFORMATION BY TYPING "CHANGE HW (L) ?" YOU MUST ANSWER "Y" AFTER A START COMMAND UNLESS THE HARDWARE INFORMATION HAS BEEN "PRELOADED" USING THE SETUP UTILITY (SEE CHAPTER 14 OF THE XXDP* USER'S MANUAL). WHEN YOU ANSWER THIS QUESTION WITH A "Y", THE RUNTIME SERVICES WILL ASK FOR THE NUMBER OF UNITS (IN DECIMAL).

AFTER INITIAL STARTING OF THE PROGRAM (START COMMAND TO THE DIAGNOSTIC SUPERVISOR), THE PROGRAM WILL ISSUE THE "CHANGE HW?" QUESTION TO ASK IF THE HARDWARE PARAMETERS ARE TO BE CHANGED (BY THE OPERATOR).

ON A "N" (NO) RESPONSE TO THE "CHANGE HW?" QUESTION, THE DIAGNOSTIC WILL RUN USING THE DEFAULT VALUES FOR ALL QUESTIONS. THE DEFAULT ADDRESS AND VECTOR ARE:

TSBA/TSDB = 172520, VECTOR = 224

ON A "Y" (YES) RESPONSE TO THE QUESTION, THE FOLLOWING QUESTIONS WILL THEN BE ASKED TO ALLOW THE OPERATOR TO SELECT THE UNITS TO BE TESTED. A VALUE, IF PRESENT, LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN IF ONLY A CARRIAGE RETURN IS TYPED AS A RESPONSE. A "(D)" IN A QUESTION INDICATES THAT A DECIMAL NUMBER IS REQUIRED AS A RESPONSE. AN "(O)" INDICATES AN OCTAL NUMBER IS BEING SOLICITED. AN "(L)" INDICATES THAT A LOGICAL RESPONSE IS TO BE MADE: "Y" FOR YES, "N" FOR NO.

Ø UNITS (D) ? <ENTER THE NUMBER OF M7455 CONTROLLERS
PRESENT TO BE TESTED>

UNIT C

DEVICE ADDRESS (O) 172520 ? <ENTER THE ADDRESS OF THE
TSBA/TSDB REGISTER>

VECTOR (O) 224 ? <ENTER ADDRESS OF INTERRUPT
VECTOR>

THE ADDRESS AND VECTOR QUESTIONS WILL BE ASKED FOR EACH OF THE NUMBER OF UNITS (CONTROLLERS) SPECIFIED IN THE "Ø UNITS?" QUESTION. LOGICAL UNIT NUMBERS ARE ASSIGNED IN ORDER, BEGINNING AT 0. UP TO FOUR UNITS CAN BE SELECTED FOR TESTING AS FOLLOWS:
UP TO 4 TSU05 CONTROLLERS PER PDP-11 AND UP TO 2 DRIVES PER CONTROLLER

2.5 SOFTWARE QUESTIONS

AFTER YOU HAVE ANSWERED THE HARDWARE QUESTIONS OR AFTER A RESTART OR CONTINUE COMMAND, THE RUNTIME SERVICES WILL ASK FOR SOFTWARE PARAMETERS. THESE PARAMETERS WILL GOVERN SOME DIAGNOSTIC SPECIFIC OPERATION MODES. YOU WILL BE PROMPTED BY "CHANGE SW (L) ?" IF YOU WISH TO CHANGE ANY PARAMETERS, ANSWER BY TYPING "Y". THE SOFTWARE QUESTIONS AND THE DEFAULT VALUES ARE DESCRIBED IN THE NEXT PARAGRAPH(S).

THE FOLLOWING QUESTIONS ARE ASKED ON A START, RESTART, OR CONTINUE. THEY ALLOW FLEXIBILITY IN THE WAY THE PROGRAM BEHAVES.

CHANGE SW (L) ? <TYPE Y TO CAUSE THE FOLLOWING
QUESTIONS TO BE ASKED>

INHIBIT ITERATIONS (L) N ? <TYPE "Y" TO PREVENT MULTIPLE
ITERATIONS OF CERTAIN TESTS.
THIS CAUSES EACH TEST PASS TO
RUN AS QUICKLY AS POSSIBLE.
ONLY QUICK-RUNNING LOGIC
TESTS USE MULTIPLE
ITERATIONS.>

2.6 EXTENDED P-TABLE DIALOGUE

WHEN YOU ANSWER THE HARDWARE QUESTIONS, YOU ARE BUILDING ENTRIES

IN A TABLE THAT DESCRIBES THE DEVICES UNDER TEST. THE SIMPLEST WAY TO BUILD THIS TABLE IS TO ANSWER ALL QUESTIONS FOR EACH UNIT TO BE TESTED. IF YOU HAVE A MULTIPLEXED DEVICE SUCH AS A MASS STORAGE CONTROLLER WITH SEVERAL DRIVES OR A COMMUNICATION DEVICE WITH SEVERAL LINES, THIS BECOMES TEDIOUS SINCE MOST OF THE ANSWERS ARE REPETITIOUS.

TO ILLUSTRATE A MORE EFFICIENT METHOD, SUPPOSE YOU ARE TESTING A DEVICE, THE XY11. SUPPOSE THIS DEVICE CONSISTS OF A CONTROL MODULE WITH EIGHT UNITS (SUB-DEVICES) ATTACHED TO IT. THESE UNITS ARE DESCRIBED BY THE OCTAL NUMBERS 0 THROUGH 7. THERE IS ONE HARDWARE PARAMETER THAT CAN VARY AMONG UNITS CALLED THE Q-FACTOR. THIS Q-FACTOR MAY BE 0 OR 1. BELOW IS A SIMPLE WAY TO BUILD A TABLE FOR ONE XY11 WITH EIGHT UNITS.

0 UNITS (0) ? 8<CR>

UNIT 1

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 0<CR>

Q-FACTOR (0) 0 ? 1<CR>

UNIT 2

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 1<CR>

Q-FACTOR (0) 1 ? 0<CR>

UNIT 3

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 2<CR>

Q-FACTOR (0) 0 ? <CR>

UNIT 4

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 3<CR>

Q-FACTOR (0) 0 ? <CR>

UNIT 5

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 4<CR>

Q-FACTOR (0) 0 ? <CR>

UNIT 6

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 5<CR>

Q-FACTOR (0) 0 ? <CR>

UNIT 7

CSR ADDRESS (0) ? 160000<CR>

SUB-DEVICE # (0) ? 6<CR>

Q-FACTOR (0) 0 ? 1<CR>

UNIT 8

CSR ADDRESS (0) 160000<CR>

SUB-DEVICE # (0) ? 7<CR>

Q-FACTOR (0) 1 ? <CR>

NOTICE THAT THE DEFAULT VALUE FOR THE Q-FACTOR CHANGES WHEN A NON-DEFAULT RESPONSE IS GIVEN. BE CAREFUL WHEN SPECIFYING MULTIPLE UNITS!

AS YOU CAN SEE FROM THE ABOVE EXAMPLE, THE HARDWARE PARAMETERS DO NOT VARY SIGNIFICANTLY FROM UNIT TO UNIT. THE PROCEDURE SHOWN IS NOT VERY EFFICIENT.

THE RUNTIME SERVICES CAN TAKE MULTIPLE UNIT SPECIFICATIONS HOWEVER. LET'S BUILD THE SAME TABLE USING THE MULTIPLE SPECIFICATION FEATURE.

* UNITS (D) ? 8<CR>

UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0,1<CR>
Q-FACTOR (0) 0 ? 1,0<CR>

UNIT 3
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 2-5<CR>
Q-FACTOR (0) 0 ? 0<CR>

UNIT 7
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 6,7<CR>
Q-FACTOR (0) 0 ? 1<CR>

AS YOU CAN SEE IN THE ABOVE DIALOGUE, THE RUNTIME SERVICES WILL BUILD AS MANY ENTRIES AS IT CAN WITH THE INFORMATION GIVEN IN ANY ONE PASS THROUGH THE QUESTIONS. IN THE FIRST PASS, TWO ENTRIES ARE BUILT SINCE TWO SUB-DEVICES AND Q-FACTORS WERE SPECIFIED. THE SERVICES ASSUME THAT THE CSR ADDRESS IS 160000 FOR BOTH SINCE IT WAS SPECIFIED ONLY ONCE. IN THE SECOND PASS, FOUR ENTRIES WERE BUILT. THIS IS BECAUSE FOUR SUB-DEVICES WERE SPECIFIED. THE "-" CONSTRUCT TELLS THE RUNTIME SERVICES TO INCREMENT THE DATA FROM THE FIRST NUMBER TO THE SECOND. IN THIS CASE, SUB-DEVICES 2, 3, 4 AND 5 WERE SPECIFIED. (IF THE SUB-DEVICE WERE SPECIFIED BY ADDRESSES, THE INCREMENT WOULD BE BY 2 SINCE ADDRESSES MUST BE ON AN EVEN BOUNDARY.) THE CSR ADDRESSES AND Q-FACTORS FOR THE FOUR ENTRIES ARE ASSUMED TO BE 160000 AND 0 RESPECTIVELY SINCE THEY WERE ONLY SPECIFIED ONCE. THE LAST TWO UNITS ARE SPECIFIED IN THE THIRD PASS.

THE WHOLE PROCESS COULD HAVE BEEN ACCOMPLISHED IN ONE PASS AS SHOWN BELOW.

* UNITS (D) ? 8<CR>

UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0-7<CR>
Q-FACTOR (0) 0 ? 0,1,0,...,1,1<CR>

AS YOU CAN SEE FROM THIS EXAMPLE, NULL REPLIES (COMMAS ENCLOSING A NULL FIELD) TELL THE RUNTIME SERVICES TO REPEAT THE LAST REPLY.

2.7 QUICK START-UP PROCEDURE (XXDP+)

TO START-UP THIS PROGRAM:

1. BOOT XXDP+
2. GIVE THE DATE AND ANSWER THE LSI AND 50HZ (IF THERE IS A CLOCK) QUESTIONS
3. TYPE "R NAME", WHERE NAME IS THE NAME OF THE BIN OR BIC FILE FOR THIS PROGRAM
4. TYPE "START"
5. ANSWER THE "CHANGE HW" QUESTION WITH "Y"
6. ANSWER ALL THE HARDWARE QUESTIONS
7. ANSWER THE "CHANGE SW" QUESTION WITH "N"

WHEN YOU FOLLOW THIS PROCEDURE YOU WILL BE USING ONLY THE DEFAULTS FOR FLAGS AND SOFTWARE PARAMETERS. THESE DEFAULTS ARE DESCRIBED IN SECTIONS 2.3 AND 2.5.

3.0 ERROR INFORMATION

3.1 TYPES OF ERROR MESSAGES

THERE ARE THREE LEVELS OF ERROR MESSAGES THAT MAY BE ISSUED BY A DIAGNOSTIC: GENERAL, BASIC AND EXTENDED. GENERAL ERROR MESSAGES ARE ALWAYS PRINTED UNLESS THE "IER" FLAG IS SET (SECTION 2.3). THE GENERAL ERROR MESSAGE IS OF THE FORM:

```
NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX  
ERROR MESSAGE
```

,WHERE; NAME = DIAGNOSTIC NAME
TYPE = ERROR TYPE (SYS FATAL, DEV FATAL, HARD OR SOFT)
NUMBER = ERROR NUMBER
UNIT NUMBER = 0 - N (N IS LAST UNIT IN PTABLE)
TST NUMBER = TEST AND SUBTEST WHERE ERROR OCCURRED
PC:XXXXXX = ADDRESS OF ERROR MESSAGE CALL

BASIC ERROR MESSAGES ARE MESSAGES THAT CONTAIN SOME ADDITIONAL INFORMATION ABOUT THE ERROR. THESE ARE ALWAYS PRINTED UNLESS THE "IER" OR "IBR" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL MESSAGE.

EXTENDED ERROR MESSAGES CONTAIN SUPPLEMENTARY ERROR INFORMATION SUCH AS REGISTER CONTENTS OR GOOD/BAD DATA. THESE ARE ALWAYS PRINTED UNLESS THE "IER", "IBR" OR "IXE" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL ERROR MESSAGE AND ANY ASSOCIATED BASIC ERROR MESSAGES.

3.2 SPECIFIC ERROR MESSAGES

BELOW ARE SAMPLE ERROR MESSAGES. EACH ERROR MESSAGE REPRESENTS DIFFERENT TYPES OF ERRORS DETECTED BY THIS DIAGNOSTIC.

ERROR MESSAGE EXAMPLE 1

THIS ERROR IS INDICATIVE OF AN INCORRECT REGISTER OR STATUS WORD RETURNED TO THE DIAGNOSTIC. THE FIRST PART DEFINES THE TEST FUNCTION AND UNIT THAT FAILED. THE SECOND PART PROVIDES THE REGISTER BIT, AND THEIR MNEMONICS FOR THE INCORRECT REGISTER OR STATUS WORDS. THE THIRD PART IS THE EXPECTED AND RECEIVED DATA.

TST: 016 FIFO EXERCISER TEST
CZTSD HRD ERR 01610 ON UNIT 00 TST 016 SUB 002 PC: 040624
FIFO STATUS (IN WORD 9) INCORRECT AFTER WRITE FIFO

TAPE BUS SIGNALS IN WORD #8: - DESIGNATOR <BIT #>
PARERR<15> IEOT <12> IFMK <9> IRDY<6> IRWD<2>
IRESV2<14> IIDENT<11> IHER <8> IONL<5> IFBY<1>
IRESV1<13> ICER <10> ISPEED<7> ILDP<4> IFPT<0>

TAPE BUS SIGNALS IN WORD #9:
DATMIS<7> ILW<6> OUTFRM<5> INRDY<4>

MESSAGE BUFFER ADDRESS = 047352

MESSAGE BUFFER CONTENTS:

WORD #0	EXPD: 100020	RECV: 100020	XOR: 000000
WORD #1	EXPD: 000012	RECV: 000012	XOR: 000000
WORD #2	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #3	EXPD: 000010	RECV: 000010	XOR: 000000
WORD #4	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #5	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #6	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #7	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #8	EXPD: 070217	RECV: 070217	XOR: 000000
WORD #9	EXPD: 000074	RECV: 000034	XOR: 000040

ERROR MESSAGE EXAMPLE 2

THIS ERROR SHOWS A FATAL FUNCTION ERROR FROM THE TAPE DRIVE, IN THIS INSTANCE A UNRECOVERABLE ERROR OCCURED WHICH INDICATES THAT THE CONTROLLER MAY BE DEFECTIVE.

CZTSD HRD ERR 00159 ON UNIT 00 TST 001 SUB 005 PC: 026202
TSSR NOT CORRECT AFTER SPACE RECORDS COMMAND

TSSR = 100214

TSSR BITS SET: SC,SSR

TERMINATION CLASS CODE = UNRECOVERABLE ERROR

PACKET ADDRESS = 026420

PACKET WORD # = 140010

PACKET WORD # = 000010

PACKET WORD # = 000000

PACKET WORD # = 000024

ERROR MESSAGE EXAMPLE 3

THIS ERROR SHOWS THAT THE MOTION BIT DID NOT GET SET WHILE DOING A REWIND WITH EXTENDED FEATURES MODE ENABLED.

CZTSD HRD ERR 00121 ON UNIT 00 TST 001 SUB 002 PC: 023306
MOT BIT (XST) NOT SET DURING REWIND (EXTENDED FEATURES MODE)
EXPD: 000312 RECV: 000112 XOR: 000200

4.0 PERFORMANCE AND PROGRESS REPORTS

AT THE END OF EACH PASS, THE PASS COUNT IS GIVEN ALONG WITH THE TOTAL NUMBER OF ERRORS REPORTED SINCE THE DIAGNOSTIC WAS STARTED. THE "EOP" SWITCH CAN BE USED TO CONTROL HOW OFTEN THE END OF PASS MESSAGE IS PRINTED. SECTION 2.2 DESCRIBES SWITCHES.

SUCCESSFUL RUN EXAMPLE (PDP-11)

```
DR>STA/FLA:PNT:HOE
UNITS (D) ? 1
UNIT 0
DEVICE ADDRESS (0) 172520 ? <CR>
VECTOR (0) 224 ? <CR>
CHANGE SW (L) ? N<CR>
```

THE ABOVE COMMAND WILL START THE DIAGNOSTIC. THE COMMAND HAS TWO SWITCHES ON WHICH ARE "PRINT EACH TEST NBR AS EXECUTED" AND "HALT ON ERROR".

```
TST: 001 SKIP TAPE MARKS TEST
TST: 002 NO-OP AND INITIALIZE TEST
TST: 003 ERASE AND OPERATION INCOMPLETE TEST
TST: 004 DATA PARITY TEST
TST: 005 TEST OF OPERATIONS AT EOT TEST
TST: 006 EXTENDED-MODE FUNCTIONS TEST
TST: 007 RECORD BUFFERING TEST
TST: 008 FUNCTION TIMING TEST
```

0 ERRORS

NOTE: THE DIAGNOSTIC WILL RUN CONTINUOUSLY UNLESS A PASS NUMBER LIMIT HAS BEEN SPECIFIED WITH THE "/PASS:" SWITCH.

PROGRAM RUN TIMES

THE AVERAGE RUN TIMES OF THE PROGRAM ARE LISTED BELOW. THESE FIGURES ARE TO BE USED AS A GUIDE. THE TIMING WAS DONE ON A PDP-11 PROCESSOR WITH A LA34 CONSOLE.

THE PROGRAM RUNS IN TWO MODES; NO ITERATIONS AND DEFAULT MODE. IN THE NO ITERATIONS MODE, EACH TEST IS RUN ONCE, WITH NO ITERATIONS. IN THE DEFAULT MODE EACH TEST IS REPEATED BY THE NUMBER OF TIMES INDICATED BY THE ITERATION COUNT. NO ITERATIONS MODE IS SELECTED BY ANSWERING THE INHIBIT ITERATIONS QUESTION WITH A "Y" (YES).

TEST NUMBER	N/I SECS.	NUMBER ITER	DEF SECS.
1	1	2	1
2	1	1	0
3	1	1	0
4	1	1	0
5	1	1	0
6	1	1	0
7	1	1	0
8	1	1	0

THE TIMES REQUIRED TO RUN TESTS 1 THROUGH 37 IN ONE COMMAND:

Q.V.	15 SECONDS
DEFAULT	16 SECONDS

5.0 DEVICE INFORMATION TABLES

WHENEVER THE PROGRAM IS STARTED, VIA THE STA(RT) COMMAND, THE SUPERVISOR REQUESTS THE FOLLOWING P-TABLES PARAMETER CHANGES:

CHANGE HW (L) ?

UNITS (D) ? <ENTER THE NUMBER OF M7455 CONTROLLERS
PRESENT TO BE TESTED>

UNIT 0

DEVICE ADDRESS (O) 172520 ? <ENTER THE ADDRESS OF THE
TSBA/TSDB REGISTER>

VECTOR (O) 224 ? <ENTER ADDRESS OF INTERRUPT
VECTOR>

THE ADDRESS AND VECTOR QUESTIONS WILL BE ASKED FOR EACH OF THE NUMBER OF UNITS (CONTROLLERS) SPECIFIED IN THE "# UNITS?" QUESTION. LOGICAL UNIT NUMBERS ARE ASSIGNED IN ORDER, BEGINNING AT 0. UP TO FOUR UNITS CAN BE SELECTED FOR TESTING.

IN ADDITION, ON A START, RESTART OR CONTINUE THE SUPERVISOR REQUESTS CHANGES TO THE SOFTWARE OPERATING PARAMETERS, AS FOLLOWS:

CHANGE SW (L) ?

INHIBIT ITERATIONS (L) N ?

6.0 TEST SUMMARIES

TEST 1: WRITE TAPE MARK RETRY

THIS TEST VERIFIES PROPER OPERATION OF THE WRITE TAPE MARK RETRY COMMAND (SPACE REVERSE, ERASE, WRITE TAPE MARK).

TEST 2: SKIP TAPE MARKS

THIS TEST VERIFIES PROPER OPERATION OF THE SKIP TAPE MARKS FORWARD AND SKIP TAPE MARKS REVERSE COMMANDS. PROPER OPERATION UNDER CONTROL OF ALL COMBINATIONS OF THE ENABLE SKIP TAPE MARKS STOP (ESS) AND ENABLE TAPE MARKS STOP OFF BOT (ENB) BITS SPECIFIED BY THE WRITE CHARACTERISTICS COMMAND.

TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

THIS TEST VERIFIES PROPER OPERATION OF THE NO-OP ("CLEAN TAPE") AND INITIALIZE COMMAND (SPACE REVERSE, ERASE, WRITE DATA)

TEST 4: ERASE AND OPERATION INCOMPLETE

VERIFIES THAT AN ERASE COMMAND ISSUED WHEN THE TAPE IS POSITIONED AT BOT OPERATES PROPERLY AND ACTUALLY ERASES TAPE.

TEST 5: DATA PARITY TEST

THIS TEST VERIFIES THAT THE DATA PARITY CIRCUITRY IN BOTH THE CONTROLLER AND THE TRANSPORT IS OPERATING PROPERLY BY FORCING DATA RECORDS WITH WRONG PARITY TO BE WRITTEN ONTO TAPE AND CHECKING THE RESULTS OBTAINED WHEN THE DATA IS READ.

TEST 6: OPERATIONS AT EOT

THIS TEST VERIFIES PROPER OPERATION OF THE WRITE DATA RETRY COMMAND (SPACE REVERSE, ERASE, WRITE DATA)

TEST 7: EXTENDED MODE FEATURES

THIS TEST VERIFIES THE OPERATION OF COMMANDS ONLY AVAILABLE WHEN THE CONTROLLER IS IN THE EXTENDED FEATURES MODE. THESE COMMANDS ARE:

REWIND WITH IMMEDIATE INTERRUPT

IF THE CONTROLLER IS NOT ALREADY IN EXTENDED FEATURES MODE, IT IS PLACED THERE VIA A WRITE SUBSYSTEM MEMORY COMMAND.

TEST 8: RECORD BUFFERING

THIS TEST VERIFIES THAT RECORD BUFFERING, USED FOR WRITE DATA AND READ NEXT COMMANDS, OPERATES PROPERLY AND IS PROPERLY CONTROLLED BY THE EXTENDED CHARACTERISTICS DATA WORD. IF THE M7455 CONTROLLER MODULE IS NOT ALREADY IN EXTENDED FEATURES MODE (AS CONTROLLED BY THE DIP SWITCH ON THE MODULE), IT IS PLACED INTO THAT MODE BY INVERTING THE SENSE OF THE SWITCH USING THE WRITE SUBSYSTEM MEMORY COMMAND. NOTE THAT RECORD BUFFERING HAS BEEN ENABLED IN PREVIOUS TESTS OF READ AND WRITE AND SO HAS BEEN PARTIALLY TESTED ALREADY. THIS TEST VERIFIES THAT BUFFERING IS ACTUALLY OPERATING.

TEST 9: FUNCTION TIMING

THIS TEST VERIFIES THAT THE TAPE TRANSPORT SEEMS TO BE WRITING RECORDS, GAPS, AND EXTENDED GAPS OF THE PROPER LENGTH. BOTH LOW AND HIGH SPEED MODES ARE TESTED. IT IS ALSO VERIFIED THAT A SKIP TAPE MARKS COMMAND WITH A COUNT OF 6 OR MORE, OPERATE THE TAPE IN HIGH-SPEED MODE. THIS TEST CAN ONLY BE RUN IF A REAL-TIME CLOCK IS AVAILABLE ON THE SYSTEM. THE TEST OPERATES BY TIMING VARIOUS TAPE-MOTION OPERATIONS, USING A NUMBER OF DIFFERENT TEST RECORD LENGTHS.

7.0 MAINTENANCE HISTORY

REVISION A - JUNE 1983

REVISION B - APRIL 1983

- FIXED TWO PROBLEMS, ONE IN TEST 1 AND THE OTHER IN TEST 8.
REF. DOYLE TO GRASKY "TSU05 CZTSDA DIAGNOSTIC PATCH"; 23-DEC-82.

```

1          .TITLE  TSV2 - PROGRAM HEADER
2          .SBTTL  PROGRAM HEADER
3 000000   .PSECT  ABS
4
10         .MCALL  SVC
11 000000   SVC          ; INITIALIZE SUPERVISOR MACROS
12         .ENABLE LC
13         .NLIST  BEX,CND
19         .ENABL  AMA
20         .*+2000
21 002000   002000'     BGNMCD  TSV2
22         TSV2::
23
24         ;++
25         ; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
26         ; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
27         ;--
28
29 002000   POINTER  BGNSW,BGNSFT,BGNAU,BGNDU,BGNRPT
30 002000   HEADER  CZTSD,A,0,655.,0
          L$NAME::      ;DIAGNOSTIC NAME
          .ASCII  /C/
          .ASCII  /Z/
          .ASCII  /T/
          .ASCII  /S/
          .ASCII  /D/
          .BYTE   0
          .BYTE   0
          .BYTE   0
          L$REV::      ;REVISION LEVEL
          .ASCII  /A/
          L$DEFO::    ;0
          .ASCII  /0/
          L$UNIT::    ;NUMBER OF UNITS
          .WORD   0
          L$TIML::    ;LONGEST TEST TIME
          .WORD   655.
          L$HPCP::    ;PTR. TO H.W. QUES.
          .WORD   L$HARD
          L$SPCP::    ;PTR. TO S.W. QUES.
          .WORD   L$SOFT
          L$HPTP::    ;PTR. TO DEF. H.W. PTABLE
          .WORD   L$HW
          L$SPTP::    ;PTR. TO S.W. PTABLE
          .WORD   L$SW
          L$LADP::    ;DIAG. END ADDRESS
          .WORD   L$LAST
          L$STA::    ;RESERVED FOR APT S'ATS
          .WORD   0
          L$CO::      .WORD   0
          L$DTYP::    ;DIAGNOSTIC TYPE
          .WORD   0
          L$APT::     ;APT EXPANSION
          .WORD   0
          L$DTP::     ;PTR. TO DISPATCH TABLE

```


002040	002124'		.WORD	L\$DISPATCH	
002042		L\$PRIO::	.WORD	0	;DIAGNOSTIC RUN PRIORITY
002042	000000		.WORD	0	
002044		L\$ENVI::	.WORD	0	;FLAGS DESCRIBE HOW IT WAS SETUP
002044	000000		.WORD	0	
002046		L\$EXP1::	.WORD	0	;EXPANSION WORD
002046	000000		.WORD	0	
002050		L\$MREV::	.WORD	0	;SVC REV AND EDIT #
002050	003		.BYTE	C\$REVISION	
002051	003		.BYTE	C\$EDIT	
002052		L\$EF::	.WORD	0	;DIAG. EVENT FLAGS
002052	000000		.WORD	0	
002054	000000		.WORD	0	
002056		L\$SPC::	.WORD	0	
002056	000000		.WORD	0	
002060		L\$UEVP::	.WORD	0	; POINTER TO DEVICE TYPE LIST
002060	003374'		.WORD	L\$DVTYP	
002062		L\$REPF::	.WORD	0	;PTR. TO REPORT CODE
002062	022514'		.WORD	L\$RPT	
002064		L\$EXP4::	.WORD	0	
002064	000000		.WORD	0	
002066		L\$EXP5::	.WORD	0	
002066	000000		.WORD	0	
002070		L\$AUT::	.WORD	0	;PTR. TO ADD UNIT CODE
002070	022202'		.WORD	L\$AU	
002072		L\$DUT::	.WORD	0	;PTR. TO DROP UNIT CODE
002072	022300'		.WORD	L\$DU	
002074		L\$LUN::	.WORD	0	;LUN FOR EXERCISERS TO FILL
002074	000000		.WORD	0	
002076		L\$DESP::	.WORD	0	;POINTER TO DIAG. DESCRIPTION
002076	003402'		.WORD	L\$DESC	
002100		L\$LOAD::	.WORD	0	;GENERATE SPECIAL AUTOLOAD EMT
002100	104035		EMT	E\$LOAD	
002102		L\$ETP::	.WORD	0	;POINTER TO ERR_TBL
002102	000000		.WORD	0	
002104		L\$ICP::	.WORD	0	;PTR. TO INIT CODE
002104	021406'		.WORD	L\$INIT	
002106		L\$CCP::	.WORD	0	;PTR. TO CLEAN-UP CODE
002106	022466'		.WORD	L\$CLEAN	
002110		L\$ACP::	.WORD	0	;PTR. TO AUTO CODE
002110	022406'		.WORD	L\$AUTO	
002112		L\$PRT::	.WORD	0	;PTR. TO PROTECT TABLE
002112	021376'		.WORD	L\$PROT	
002114		L\$TEST::	.WORD	0	;TEST NUMBER
002114	000000		.WORD	0	
002116		L\$DLY::	.WORD	0	;DFLAY COUNT
002116	000000		.WORD	0	
002120		L\$HIME::	.WORD	0	;PTR. TO HIGH MEM
002120	000000		.WORD	0	

31
32
33
34
35
36
37
38

.SBTTL DISPATCH TABLE

; THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
; IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.

TSV2 - PROGRAM HEADER MACRO M1113 01-FEB-84 18:55
DISPATCH TABLE

SEQ 018

```

39 002122          DISPATCH 9
   002122 000011  .WORD 9
   002124          I.$DISPATCH::
   002124 023276'  .WORD T1
   002126 032114'  .WORD T2
   002130 041222'  .WORD T3
   002132 046600'  .WORD T4
   002134 052666'  .WORD T5
   002136 055702'  .WORD T6
   002140 063264'  .WORD T7
   002142 073224'  .WORD T8
   002144 101010'  .WORD T9

40
41          .SBTTL  DEFAULT HARDWARE P-TABLE
42
43          ;**
44          ; THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
45          ; THE TEST-DEVICE PARAMETERS.  THE STRUCTURE OF THIS TABLE
46          ; IS IDENTICAL TO THE STRUCTURE OF THE RUN-TIME P-TABLE.
47          ;--
48 002146          BGNHW  DFPTBL          ;DEFAULT HARD-P-TABLE
   002146 000003  .WORD  L10000-L$HW/2'
   002150          L$HW::
   002150          DFPTBL::

49
50 002150 172520  .WORD 172520          ; 1ST (OF 2) REGISTERS.
51 002152 000224  .WORD 224          ; INTERRUPT VECTOR
52 002154 000200  .WORD PRI04          ; INTERRUPT PRIORITY.
53 002156          ENDSW
   002156          L10000:

54
55          .SBTTL  SOFTWARE P-TABLE
56
57          ;**
58          ; THE SOFTWARE P-TABLE CONTAINS THE VALUES OF THE PROGRAM
59          ; PARAMETERS THAT CAN BE CHANGED BY THE OPERATOR.
60          ;--
61 002156          BGNSW  SFPTBL
   002156 000004  .WORD  L10001-L$SW/2
   002160          L$SW::
   002160          SFFPTBL::

62
63 002160 000000  TRANSTST:: .WORD 0          ; ENABLE TEST OF TRANSPORT(S) IF =1
64 002162 000000  NOITS::   .WORD 0          ; INHIBIT ITERATION OPTION.
65          ; ... 0 = ITERATE.
66          ; ... NZ = INHIBIT ITERATE.
67 002164 000017  LERRMAX:: .WORD 15.          ; LOCAL (PER TEST) ERROR LIMIT
68 002166 000310  GERRMAX:: .WORD 200.          ; GLOBAL (PER UNIT) ERROR LIMIT
69 002170          ENDSW
   002170          L10001:

70
71 002170          ENDMOD
72

```



```
          ; PRIORITY LEVEL DEFINITIONS  
          ;  
000340   PRI07== 340  
000300   PRI06== 300  
000240   PRI05== 240  
000200   PRI04== 200  
000140   PRI03== 140  
000100   PRI02== 100  
000040   PRI01== 40  
000000   PRI00== 0
```

```
          ; OPERATOR FLAG BITS  
          ;  
000004   EVL==      4  
000010   LOT==     10  
000020   ADK==     20  
000040   IDU==     40  
000100   ISR==    100  
000200   UAM==    200  
000400   BOE==    400  
001000   PNT==   1000  
002000   PRI==   2000  
004000   IXE==   4000  
010000   IBE==  10000  
020000   IER==  20000  
040000   LOE==  40000  
100000   HOE== 100000
```

34
35 002170

```
          ; DEFINE MEMORY MANAGEMENT REGISTERS  
          ;  
          .SBTTL   KT11  
          .SBTTL   MEMORY MANAGEMENT DEFINITIONS  
          ;*KT11 VECTOR ADDRESS  
000250   MMVEC= 250  
          ;*KT11 STATUS REGISTER ADDRESSES  
177572   SR0= 177572  
177574   SR1= 177574  
177576   SR2= 177576  
172516   SR3= 172516  
          .IF NB  
          ;*USER "I" PAGE DESCRIPTOR REGISTERS  
UIPDR0= 177600  
UIPDR1= 177602  
UIPDR2= 177604  
UIPDR3= 177606  
UIPDR4= 177610  
UIPDR5= 177612  
UIPDR6= 177614  
UIPDR7= 177616  
          .IF NB  
          ;*USER "D" PAGE DESCRIPTOR REGISTERS  
UDPDR0= 177620  
UDPDR1= 177622  
UDPDR2= 177624  
UDPDR3= 177626  
UDPDR4= 177630  
UDPDR5= 177632  
UDPDR6= 177634  
UDPDR7= 177636
```

```
.ENDC
;*USER "I" PAGE ADDRESS REGISTERS
UIPAR0= 177640
UIPAR1= 177642
UIPAR2= 177644
UIPAR3= 177646
UIPAR4= 177650
UIPAR5= 177652
UIPAR6= 177654
UIPAR7= 177656
. IF NB
;*USER "D" PAGE ADDRESS REGISTERS
UDPAR0= 177660
UDPAR1= 177662
UDPAR2= 177664
UDPAR3= 177666
UDPAR4= 177670
UDPAR5= 177672
UDPAR6= 177674
UDPAR7= 177676
.ENDC
.ENDC
. IF NB
;*SUPERVISOR "I" PAGE DESCRIPTOR REGISTERS
SIPDR0= 172200
SIPDR1= 172202
SIPDR2= 172204
SIPDR3= 172206
SIPDR4= 172210
SIPDR5= 172212
SIPDR6= 172214
SIPDR7= 172216
. IF NB
;*SUPERVISOR "D" PAGE DESCRIPTOR REGISTERS
SDPDR0= 172220
SDPDR1= 172222
SDPDR2= 172224
SDPDR3= 172226
SDPDR4= 172230
SDPDR5= 172232
SDPDR6= 172234
SDPDR7= 172236
.ENDC
;*SUPERVISOR "I" PAGE ADDRESS REGISTERS
SIPAR0= 172240
SIPAR1= 172242
SIPAR2= 172244
SIPAR3= 172246
SIPAR4= 172250
SIPAR5= 172252
SIPAR6= 172254
SIPAR7= 172256
. IF NB
;*SUPERVISOR "D" PAGE ADDRESS REGISTERS
SDPAR0= 172260
SDPAR1= 172262
SDPAR2= 172264
```

```

SDPAR3= 172266
SDPAR4= 172270
SDPAR5= 172272
SDPAR6= 172274
SDPAR7= 172276
.ENDC
.ENDC
; *KERNEL "I" PAGE DESCRIPTOR REGISTERS
172300 KIPDR0= 172300
172302 KIPDR1= 172302
172304 KIPDR2= 172304
172306 KIPDR3= 172306
172310 KIPDR4= 172310
172312 KIPDR5= 172312
172314 KIPDR6= 172314
172316 KIPDR7= 172316
; IF NB
; *KERNEL "D" PAGE
DESCRIPTOR REGISTERS
KDPDR0= 172320
KDPDR1= 172322
KDPDR2= 172324
KDPDR3= 172326
KDPDR4= 172330
KDPDR5= 172332
KDPDR6= 172334
KDPDR7= 172336
.ENDC
; *KERNEL "I" PAGE ADDRESS REGISTERS
172340 KIPAR0= 172340
172342 KIPAR1= 172342
172344 KIPAR2= 172344
172 46 KIPAR3= 172346
172350 KIPAR4= 172350
172352 KIPAR5= 172352
172354 KIPAR6= 172354
172356 KIPAR7= 172356
; IF NB
; *KERNEL "D" PAGE ADDRESS REGISTERS
KDPAR0= 172360
KDPAR1= 172362
KDPAR2= 172364
KDPAR3= 172366
KDPAR4= 172370
KDPAR5= 172372
KDPAR6= 172374
KDPAR7= 172376
.ENDC

```

39
40
41
42
43
44
45
46
47

000004

.SDTTL TSU05 REGISTER AND PACKET DEFINITIONS

;
; SOME GENERAL EQUATES.
;

ERRVEC= 4 ; POINTER TO ERROR VECTOR FOR BUS TIME OUT.

```

48      000060      TTIVEC==      60      ; INTERRUPT VECTOR FOR CONSOLE INPUT
49      177560      TTICSR==      177560    ; BUS ADDRESS OF CONSOLE INPUT
50      177562      TTIBFR==      177562    ; CONSOLE INPUT DATA BUFFER
51      177520      BDVPCR==      177520    ; BDV11 PAGE CONTROL REGISTER
52
53      ;+
54      ;BIT DEFINITIONS FOR TSSR REGISTER
55      ;-
56
57      100000      SC=      BIT15      ; SPECIAL CONDITION
58      040000      BiE=      BIT14      ; BUS INTERFACE ERROR
59      020000      SCE=      BIT13      ; SANITY CHECK ERROR
60      010000      RMR=      BIT12      ; MODIFICATION REFUSED
61      004000      NXM=      BIT11      ; NONEXISTANT MEMORY ERROR
62      002000      NBA=      BIT10      ; NEED BUFFER ADDRESS
63      001400      HIADDR= BIT9:BIT8    ; EXTENDED ADDRESS BITS
64      000200      SSR=      BIT7      ; SUB SYSTEM READY
65      000100      OFL=      BIT6      ; OFF LINE BIT
66      000060      FATERR= BIT4:BIT5    ; FATAL TERMINATION ERROR CODES
67      000016      TERCLS= BIT3:BIT2:BIT1 ; TERMINATION CODES
68
69
70      ;+
71      ;
72      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 0
73      ;(XST0)
74      ;
75      ;-
76
77      100000      XSOTMK= BIT15      ; TAPE MARK DETECTED
78      040000      XSORLS= BIT14      ; RECORD LENGTH SHORT
79      020000      XSOLET= BIT13      ; LOGICAL END OF TAPE
80      010000      XSORLL= BIT12      ; RECORD LENGTH LONG
81      004000      XSOWLE= BIT11      ; WRITE LOCK ERROR
82      002000      XSONEF= BIT10      ; NON EXECUTABLE FUNCTION
83      001000      XSOILC= BIT9      ; ILLEGAL COMMAND
84      000400      XSOILA= BIT8      ; ILLEGAL ADDRESS
85      000200      XSOMOT= BIT7      ; TAPE IN MOTION
86      000100      XSOONL= BIT6      ; TRANSPORT ON LINE
87      000040      XSOIE=  BIT5      ; INTERRUPT ENABLE
88      000020      XSOVCK= BIT4      ; VOLUME CHECK BIT
89      000010      XSOPEL= BIT3      ; PHASE ENCODED DRIVE
90      000004      XSOWLK= BIT2      ; WRITE LOCKED
91      000002      XSOBOT= BIT1      ; BEGINNING OF TAPE
92      000001      XSOEOT= BIT0      ; END OF TAPE
93
94
95      ;+
96      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 1
97      ;(XST1)
98      ;-
99      100000      X1.DLT = BIT15      ; DATA LATE
100     040000      X1.SPARE= BIT14      ; NOT USED
101     020000      X1.COR = BIT13      ; CORRECTABLE DATA ERROR
102     017375      X1.MBZ = BIT12+BIT11+BIT10+BIT9+BIT7+BIT6+BIT5+BIT4+BIT3+BIT2+BIT0 ; ALWAYS 0
103     000400      X1.RBP = BIT8      ; READ BUS PARITY ERROR
104     000002      X1.UNC = BIT1      ; UNCORRECTABLE DATA OR HARD ERROR

```

```

105
106
107      ;+
108      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 2
109      ;(XST2)
110      ;-
110      100000      X2.OPM   = BIT15           ;OPERATION IN PROGRESS (TAPE MOVING)
111      040000      X2.RCE   = BIT14           ;RAM CHECKSUM ERROR
112      035400      X2.SPARE = BIT13+BIT12+BIT11+BIT9+BIT8 ;NOT USED BY TSU05 (ALWAYS=0)
113      002000      X2.WCF   = BIT10         ;WRITE CLOCK FAILURE (FIFO NOT EMPTIED BY TRANSPORT)
114      000200      X2.EXTF  = BIT7          ;IF WRITE CHAR CMD THEN = EXTENDED FEATURES ENABLED
115      000100      X2.BUFE  = BIT6          ;IF WRITE CHAR CMD THEN = BUFFERING ENABLED
116      000077      X2.REV   = 000077       ;IF WRITE CHAR CMD THEN = MICROCODE REVISION LEVEL
117      000007      X2.UNIT  = BIT2+BIT1+BIT0 ;IF GET STATUS THEN = CURRENTLY SELECTED UNIT NO.
118
119      ;+
120      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 3
121      ;(XST3)
122      ;-
123      177400      X3.MDE   = 177400       ;MICRO-DIAGNOSTIC ERROR CODE
124      000200      X3.SPARE = BIT7          ;NOT USED BY TSU05
125      000100      X3.OPI   = BIT6          ;OPERATION INCOMPLETE
126      000040      X3.REV   = BIT5          ;REVERSE
127      000020      X3.TRF   = BIT4          ;TRANSPORT RESPONSE FAILURE
128      000010      X3.DCK   = BIT3          ;DENSITY CHECK
129      000006      X3.MBZ   = BIT2+BIT1     ;NOT USED ALWAYS 0
130      000001      X3.RIB   = BIT0         ;REVERSE INTO BOT
131
132      ;+
133      ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 4
134      ;(XST4)
135      ;-
136      100000      X4.HSP   = BIT15         ;HIGH SPEED
137      040000      X4.RCE   = BIT14         ;RETRY COUNT EXCEEDED
138      020000      X4.TSM   = BIT13         ;TRANSPORT SPECIAL MODE
139      017400      X4.MBZ   = BIT12+BIT11+BIT10+BIT9+BIT8 ;NOT USED ALWAYS 0
140      000377      X4.WRC   = 000377       ;WRITE RETRY COUNT FIELD
141
142
143      ;+
144      ;
145      ;TSR TERMINATION CODES (BIT 0-2)
146      ;-
147
148
149      000006      TSREJ = 3+2             ;COMMAND REJECTED
150      000006      UNREC = 6              ;UNRECOVERABLE ERROR
151
152      ;+
153      ;
154      ;DEVICE REGISTER OFFSETS
155      ;-
156
157
158      000000      TSBA = 0
159      000000      TSDB = 0              ;TSDB/TSBA REGISTER
160      000001      TSBAH = 1
161      000001      TSDBH = 1             ;TSDB/TSBA REGISTER HIGH BYTE

```



```

162          000002          TSSR** 2          ;TSSR REGISTER
163          000003          TSSRH** 3         ;TSSR REGISTER HIGH BYTE
164
165          ;+
166          ; TSDB ADDRESS BIT DEFINITIONS
167          ; -
168          000003          A1716  > BIT1+BIT0    ;ADDRESS BITS 17:16 ARE IN 1:0
169
170          ;+
171          ; COMMAND DEFINITIONS
172          ; -
173          000017          P.GETSTAT      = 17    ;GET STATUS
174          000013          P.INIT        = 13    ;INITIALIZE
175          000012          P.CONTROL     = 12    ;CONTROL COMMANDS
176          000011          P.FORMAT      = 11    ;FORMAT
177          000010          P.POSITION    = 10    ;POSITION
178          000006          P.WRYSUB     = 6     ;SUBSYSTEM WRITE
179          000005          P.WRITE       = 5     ;WRITE
180          000004          P.WRTCHAR    = 4     ;WRITE CHARACTERISTICS
181          000001          P.READ        = 1     ;READ
182
183          ;+
184          ; COMMAND PACKET HEADER WORD BIT DEFINITIONS
185          ; -
186          100000          P.ACK        = BIT15   ;BUFFER AVAIL FOR CONTROLLER
187          040000          P.CVC        = BIT14   ;CLEAR VOLUME CHECK
188          020000          P.OPP        = BIT13   ;REVERSE SEQUENCE OF DATA BITS
189          010000          P.SWB        = BIT12   ;SWAP BYTES IN MEMORY
190          007400          P.MODE       = BIT11:BIT10:BIT8 ;EXTENDED COMMAND MODE FIELD
191          000200          P.IE         = BIT7    ;INTERRUPT ENABLE
192          000140          P.FMT       = BIT6:BIT5 ;PACKET HEADER TYPE (ALWAYS=0)
193          000037          P.CMD        = 37     ;MAJOR COMMAND FIELD
194
195          ;+
196          ; CONTROL COMMAND MODE CODES
197          ; -
197          000000          PC.RELEASE   = 0*256. ;RELEASE BUFFER
198          000400          PC.REWIND    = 1*256. ;REWIND
199          001000          PC.NOOP      = 2*256. ;NO-OP
200          002000          PC.IEREW    = 4*256. ;REWIND IMMEDIATE INTERRUPT
201          002400          PC.ERASE     = 5*256. ;SECURITY ERASE
202
203          ;+
204          ; CONTROLLER RAM DEFINITIONS
205          ; -
206          000167          RMCHBEG = 167        ;CHARACTERISTICS IO DATA BEGIN RAM ADDRESS
207          000200          RMCHEND = 200        ;CHARACTERISTICS IO DATA END RAM ADDRESS
208          000201          RMPKTBEGB = 201      ;COMMAND PACKET BEGIN RAM ADDRESS
209          000210          RMPKTEND = 210       ;COMMAND PACKET END RAM ADDRESS
210          000215          RMMSGBEG = 215      ;MESSAGE BUFFER BEGIN RAM ADDRESS
211          000234          RMMSGEND = 234      ;MESSAGE BUFFER END RAM ADDRESS
212
213          ;+
214          ; REGISTER DEFINITIONS IN THE MESSAGE BUFFER
215          ; -
216
217
218          000006          XSTO** 6          ;EXTENDED STATUS REGISTER 0 (WORD 4)

```

```

219      000010      XST1== 8.           ;EXTENDED STATUS REGISTER 1 (WORD 5)
220      000012      XST2== 10.          ;EXTENDED STATUS REGISTER 2 (WORD 6)
221      000014      XST3== 12.          ;EXTENDED STATUS REGISTER 3 (WORD 7)
222      000016      XST4== 14.          ;EXTENDED STATUS REGISTER 4 (WORD 8)
223
224
225      ;+
226      ;
227      ;OFFSETS TO WORD LOCATIONS IN PACKET DEFINITIONS
228      ;
229      ;-
230
231      000002      PKLOW  = 2           ;LOW ORDER CHARACTERISTIC DATA POINTER
232      000004      PKHI   = 4           ;HIGH ORDER CHARACTERISTIC DATA POINTER
233      000006      PKBCNT = 6           ;NUMBER OF BYTES IN DATA PACKET
234
235      000010      EXBCNT=10            ;NUMBER OF BYTES IN EXTENDED DATA PACKET
236
237      ;+
238      ;DATA PACKET OFFSETS FOR WRITE SUBSYSTEM COMMAND
239      ;-
240      000000      BSELO  = 0           ;BYTE 0
241      000001      BSEL1  = 1           ;BYTE 1
242      000002      SEL2   = 2           ;WORD 2
243      000004      SELDATA = 4          ;WORD 3
244
245      ;+
246      ;BSELO SELECT CODES FOR WRITE SUBSYSTEM COMMAND
247      ;-
248      000000      PW.NOP   = 0           ;NO-OP
249      000001      PW.RDRAM = 1           ;READ RAM
250      000002      PW.WTRAM = 2           ;WRITE RAM
251      000003      PW.RFIFO = 3           ;READ FIFO
252      000004      PW.WFIFO = 4           ;WRITE FIFO
253      000005      PW.RDSTAT = 5          ;READ STATUS
254      000006      PW.WCTL  = 6           ;WRITE TAPE CONTROL
255      000007      PW.WFMT  = 7           ;WRITE TAPE FORMAT
256      000010      PW.WMISC = 10          ;WRITE MISCELLANEOUS
257      000011      PW.WNPR  = 11          ;WRITE NPR CONTROL
258      000020      PW.D22   = 20          ;DO MICROTEST 22
259      000021      PW.D11   = 21          ;DO MICROTEST 11
260      000022      PW.D13   = 22          ;DO MICROTEST 13
261      000023      PW.NO1311 = 23         ;DISABLE MICROTEST 11 AND 13
262      000024      PW.RDEXT = 24          ;READ EXT. TAPE STATUS (NOT SUPPORTED BY ALL TRANSPORTS)
263
264      ;+
265      ;BSEL1 CODES FOR WRITE TAPE CONTROL
266      ;-
267      000200      WC.IFAD   = BIT7       ;IFAD - FORMATTER ADDRESS
268      000100      WC.ITAD   = BIT6       ;ITAD0 - TRANSPORT ADDRESS BIT 0
269      000040      WC.ITAD   = BIT5       ;ITAD1 - TRANSPORT ADDRESS BIT 1
270      000020      WC.ISRESV = BIT4       ;IRESV5 - RESERVED #5
271      000010      WC.IREW   = BIT3       ;IREW  - REWIND
272      000004      WC.IRWU   = BIT2       ;IRWU  - REWIND AND UNLOAD
273      000002      WC.IFEN   = BIT1       ;IFEN  - FORMATTER ENABLE
274      000001      WC.IGO    = BIT0       ;IGO
275

```

```

276
277      ; BSEL1 CODES FOR WRITE FORMAT
278      ;
279      000200      WF.IHISP      = BIT7      ; IHISP - HIGH SPEED
280      000100      WF.IWRT      = BIT6      ; IWRT  - WRITE
281      000040      WF.IREV      = BIT5      ; IREV  - REVERSE
282      000020      WF.IWFM      = BIT4      ; IWFM  - WRITE FILE MARK
283      000010      WF.IEDIT     = BIT3      ; IEDIT - EDIT
284      000004      WF.IERASE    = BIT2      ; IERASE - ERASE
285      000002      WF.I3RESV    = BIT1      ; IRESV3 - RESERVED #3
286      000001      WF.I4RESV    = BIT0      ; IRESV4 - RESERVED #4
287
288
289      ;
290      ; BSEL1 CODES FOR WRITE MISCELLANEOUS SUBCOMMAND
291      ;
292      000200      MS.EXT        = BIT7      ; INVERT SENSE OF EXTENDED FEATURES SWITCH
293      000020      MS.RSFIFO     = BIT4      ; RESET FIFO AND INPUT PARITY ERROR
294      000010      MS.RSTAPE     = BIT3      ; RESET TAPE STATUS IN 2 FLIP-FLOPS
295      000006      MS.ATTN       = BIT2:BIT1 ; ATTENTION TRIGGER FIELD
296      000001      MS.RSD        = BIT0      ; RESET TIMER A,B THEN DELAY TIMES IN SEL2
297
298      ;
299      ; MS.ATTN SUBCODES
300      ;
301      000000      MSA.NOP       = 0*2      ; NO-OP (NOTHING TRIGGERED)
302      000002      MSA.VOL       = 1*2      ; SIMULATE ON-LINE/OFF-LINE TRANSITION
303      000004      MSA.NRAM      = 2*2      ; FORCE NON-FATAL RAM ERROR (FORCES ERRCODE 54)
304      000006      MSA.FRAME     = 3*2      ; FORCE FATAL RAM ERROR (CAUSES SCE TO SET)
305
306      ; WRITE SUBSYSTEM WRITE NPR BSEL1 BIT DEFINITIONS
307      ;
308      000200      NP.IR         = BIT7      ; INTERRUPT REQUEST (0-1 TRANSITION)
309      000100      NP.OUT        = BIT6      ; TAPE DATA DIRECTION OUT (0- IN)
310      000040      NP.LOOP       = BIT5      ; ENABLE TRANSPORT LOOPBACK
311      000020      NP.WRP        = BIT4      ; WRITE CORRECT PARITY (SET=0 TO WRITE WRONG)
312
313      ;
314      ; READ STATUS MESSAGE BUFFER BIT DEFINITIONS
315      ;
316      000200      S2.DIM         = BIT7      ; WORD #9 BYTE 2 DATA IN MISS
317      000100      S2.ILW        = BIT6      ; ILW H
318      000040      S2.OUTRDY      = BIT5      ; OUT RDY H
319      000020      S2.INRDY       = BIT4      ; IN RDY H
320      000010      S2.ATIMR      = BIT3      ; TIMER A FLAG H
321      000004      S2.BTIMR      = BIT2      ; TIMER B FLAG H
322      000003      S2.UNDEF       = BIT1:BIT0 ; (UNDEFINED)
323      100000      S1.PARIN       = BIT15     ; WORD #8 BYTE 1 PARIN H
324      040000      S1.I2RESV     = BIT14     ; IRESV2
325      020000      S1.I1RESV     = BIT13     ; IRESV1
326      010000      S1.IEOT       = BIT12     ; IEOT L
327      004000      S1.IIDENT     = BIT11     ; IIDENT H
328      002000      S1.ICER       = BIT10     ; ICER H
329      001000      S1.IFMK       = BIT9      ; IFMK H
330      000400      S1.IHER       = BIT8      ; IHER H
331      000200      S0.ISPEED     = BIT7      ; WORD #8 BYTE 0 ISPEED H
332      000100      S0.IRDY       = BIT6      ; IRDY L
333      000040      S0.IONL       = BIT5      ; IONL L

```

```

333      000020      SO.ILDP      ▫ BIT4      |      ILDP L
334      000010      SO.IDBY      ▫ BIT3      |      IDBY L
335      000004      SO.IRWD      ▫ BIT2      |      IRWD L
336      000002      SO.IFBY      ▫ BIT1      |      IFBY L
337      000001      SO.IFPT      ▫ BIT0      |      IFPT L
338
339      ;+
340      ;UNIBUS MAP DEFINATIONS
341      ;-
342      MMRO= 170200
343
344      .SBTTL SPECIAL MACROS AND OPDEFS.
345
346
347      ;+
348      ;SAVE GENERAL REGS 1 TO 5
349      ;-
350
351      .MACRO SAVREG
352      JSR R5,REGSAV
353      .ENDM
354
355      ;+
356      ; MACRO TO FORCE AN ERROR
357      ;-
358      .MACRO FORCERROR TAG,NOTSSR
359      .NLIST
360      .IF NDF LISTALL, .NLIST
361      .LIST
362      .IF 3 NOTSSR
363      MOV TSSR(R5),R1 ;READ TSSR
364      .ENDC
365      MOV FORCER,FORCER ;IS FORCER SET? (LEAVE C BIT ALONE)
366      BNE TAG ;BR IF YES
367      .NLIST
368      .IF NDF LISTALL, .LIST
369      .LIST
370      .ENDM
371
372      ;+
373      ; MACRO TO FORCE AN EXIT TO AVOID SECTION ITERATIONS
374      ; WILL EXIT TO A LABEL IF FORCER IS NEGATIVE
375      ; SO TO FORCE ERRORS AND EXIT ON 1 ERROR SET
376      ; FORCER TO 17777
377      ; TO FORCE ERRORS AND ITERATIONS SET FORCER TO 1.
378      ;-
379      .MACRO FORCEEXIT TAG
380      .NLIST
381      .IF NDF LISTALL, .NLIST
382      .LIST
383      MOV FORCER,FORCER ;IS FORCER NEGATIVE?
384      BMT TAG ;BR IF YES
385      .NLIST
386      .IF NDF LISTALL, .LIST
387      .LIST
388      .ENDM
389      ;+

```

```

390      ; MACRO TO INCREMENT ERROR COUNTS
391      ;-
392      .MACRO NEXT.ERRNO
393      .NLIST
394      ;;;.IF NDF LISTALL, .NLIST
395      ERRNO=ERRNO+1
396      ;;;.IF NDF LISTALL, .LIST
397      .LIST
398      .ENDM
399
400      ;+
401      ;MACRO TO PERFORM XOR
402      ;-
403
404      .MACRO XOR      A,B
405      MOV      A,-(SP)
406      BIC      B,(SP)
407      BIC      A,B
408      BIS      (SP)+,B
409      .ENDM
410
411      000000      EN=0      ; INITIALIZE ERROR NUMBER
412      .SBTTL FORCER - FORCE ERROR FLAG
413
414      ;
415      ; THE FOLLOWING LOCATIONS MAY BE PATCHED BY THE USER
416      ; TO OBTAIN THE RESULTS DESCRIBED FOR EACH.
417      ;
418
419      002170 000000 FORCER::      0      ; FORCE TYPE ALL HARD ERRORS (THE ONES CALLED -
420      ; - BY THE MACRO "IFERROR"), AN ERROR NEED NOT -
421      ; - EXIST, JUST ASSUME AND TYPE THE MESSAGE.
422
423
424
425      .SBTTL GLOBAL DATA SECTION
426
427      ;++
428      ;THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
429      ;IN MORE THAN ONE TEST.
430      ;--
431
432      ;
433      ;THE FOLLOWING DATA ARE SET FOR EACH UNIT AT INIT TIME.
434      ;SINGLE UNIT DEFAULTS (LISTED) ARE IN THE DEFAULT P-TABLE.
435      ;
436      002172 000000 EPRTSW::      .WORD      0      ;PRINT SWITCH
437      002174 000000 UNITN::      .WORD      0      ;UNIT # UNDER TEST.
438      002176 000000 QVP::      .WORD      0      ;QUICK VERIFY FLAG.
439      002200 000000 CSRADDR::      .WORD      0      ;ADDRESS OF CSR FOR CURRENT DEVICE
440      002202 000224 IVEC::      .WORD      224      ;INTERRUPT VECTOR
441      002204 000200 IPRI::      .WORD      PRI04      ;INTERRUPT PRIORITY.
442      002206 000000 TSTCNT::      .WORD      0      ;NUMBER OF TESTS RUN IN THIS PASS
443      002210 000000 LOOPCN1::      .WORD      0      ;REMAINING ITERATION COUNT FOR TEST
444      002212 000000 DEVCNT::      .WORD      0      ;NUMBER OF DEVICE UNDER TEST
445      002214 000000 FATFLG::      .WORD      0      ;SET IF FATAL ERROR IS DETECTED IN TEST
446      002216 000000 INTRECV::      .WORD      0      ;SET IF TAPE INTERRUPT WAS RECEIVED

```

TSV3 - GLOBAL AREAS
GLOBAL DATA SECTION

MACRO M1113 01-FEB-84 18:55

SEQ 030

```

447 002220 000000 EXTFEA:: .WORD 0 ;EXTENDED FEATURES SOFTWARE SW 0-OFF;1-ON
448 002222 000000 BENBSW:: .WORD 0 ;BUFFER ENABLE SWITCH SW 0-OFF;1-ON
449 002224 000000 EXPD:: .WORD 0 ;EXPECTED RAM DATA FOR PRAMPKT ROUTINE
450 002226 000000 RECV:: .WORD 0 ;RECEIVED RAM DATA FOR PRAMPKT ROUTINE
451 002230 000000 ERRHI:: .WORD 0 ;HIGH ADDRESS MEMORY ERROR
452 002232 000000 ERRLO:: .WORD 0 ;LOW ADDRESS MEMORY ERROR
453 002234 RAMDATA:: .BLKW 16. ;DATA READ FROM RAM PACKET OR MESSAGE BUF AREA
454 002274 000000 RAMSIZ:: .WORD 0 ;RAM DATA SIZE FOR PRAMPKT ROUTINE
455 002276 000000 RCVHIADD:: .WORD 0 ;RECEIVED BUFFER HIGH ADDRESS
456 002300 000000 RCVLOADD:: .WORD 0 ;RECEIVED BUFFER LOW ADDRESS
457 002302 000000 COUNT:: .WORD 0 ;TEST COUNT PATTERN
458 002304 000000 DATA:: .WORD 0 ;TEST DATA
459 002306 000000 TSTFLAG:: .WORD 0 ;TEST FLAG WORD
460 002310 000000 TSTPTR:: .WORD 0 ;TSTBLK POINTER
461 002312 000000 PRMNO:: .WORD 0 ;PRINT ROUTINE TEMP
462 002314 EXPMSG:: .BLKB 100. ;EXPECTED MESSAGE BUFFER DATA
463 002460 RECMG:: .BLKB 100. ;RECEIVED MESSAGE BUFFER DATA
464 002624 TMPBFR:: .BLKB 80. ;TEMPORARY STORAGE FOR PRINT
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482

```

.SBTTL TSTBLK - TEST DATA TABLE

```

;
; THIS TABLE CONTAINS TEST DATA USED IN SEVERAL TESTS
; IN SEQUENCE THE DATA IS:
;
; ALL ZEROS
; ALL ONES
; WALKING ONES
; WALKING ZEROS
; ALTERNATING ONES AND ZEROS
;
;-

```

```

483 002744 TSTBLK:: .WORD 0 ;ALL ZEROS
484 002744 .WORD 177777 ;ALL ONES
485 002746 .WORD BIT0 ;DATA FOR WALKING ONES
486 002750 .WORD BIT1
487 002752 .WORD BIT2
488 002754 .WORD BIT3
489 002756 .WORD BIT4
490 002760 .WORD BIT5
491 002762 .WORD BIT6
492 002764 .WORD BIT7
493 002766 .WORD BIT8
494 002770 .WORD BIT9
495 002772 .WORD BIT10
496 002774 .WORD BIT11
497 002776 .WORD BIT12
498 003000 .WORD BIT13
499 003002 .WORD BIT14
500 003004 .WORD BIT15
501 003006 .WORD +CBIT0 ;DATA FOR WALKING ZEROS
502 003010 .WORD +CBIT1
503 003012 .WORD +CBIT1

```

```

504 003014 177773 .WORD +CBIT2
505 003016 177767 .WORD +CBIT3
506 003020 177757 .WORD +CBIT4
507 003022 177737 .WORD +CBIT5
508 003024 177677 .WORD +CBIT6
509 003026 177577 .WORD +CBIT7
510 003030 177377 .WORD +CBIT8
511 003032 176777 .WORD +CBIT9
512 003034 175777 .WORD +CBIT10
513 003036 173777 .WORD +CBIT11
514 003040 167777 .WORD +CBIT12
515 003042 157777 .WORD +CBIT13
516 003044 157777 .WORD +CBIT14
517 003046 077777 .WORD +CBIT15
518 003050 125252 .WORD 125252 ;ALTERNATING ONES, ZERUS
519 003052 052525 .WORD 052525 ;ALTERNATING ONES, ZERO OPPOSITE FROM ABOVE
520 003054'
521
522
523 .SBTTL GLOBAL ENVIRONMENT STORAGE
524 ;
525 ;STORAGE FOR DEVICE REGISTERS
526 ;
527 003054 000000 100000 000000 DUMMY: 0,100000,0,0 ;DUMMY DEVICE REGISTERS...
528 003064 000000 000000 000000 0,0,0,0,0,0,0,0,0
529 ;...FOR MULTI-UNIT CHECKOUT.
530
531
532 003104 000000 DUFLG:: .WORD 0 ;"DROPPED UNIT" FLAG.
533 ;INHIBITS CODE IN "CLEAN-UP".
534 003106 000000 NODEV:: .WORD 0 ;FLAG TO SAY NO DEVICE.
535
536 003110 000000 TEMP1:: .WORD 0 ;SOME TEMP LOCATIONS.
537 003112 000000 TEMP2:: .WORD 0
538 003114 000000 XXCOMM:: .WORD 0 ;XXDP+ COMM BLOCK POINTER.
539 003116 000000 FREE:: .WORD 0 ;1ST FREE MEMORY ADDRESS...
540 003120 000000 FRESIZ:: .WORD 0 ;...AND SIZE (IN WORDS).
541 003122 000000 FREEHI: .WORD 0 ;LAST WORD IN FREE SPACE
542 003124 000000 KTFLG:: .WORD 0 ;KT11, MEM AVAIL FLAG -
543 ;- .WORD 0 = <24K OR NO KT -
544 ;- NZ = >24K AND KT.
545 003126 000000 KTENABLE:: .WORD 0 ;SET BY TEST ROUTINES TO FLAG >28K UNDER TEST
546 003130 000000 NXMFLG:: .WORD 0 ;SET IF WE CAN TEST CLEARED OTHERWISE
547 003132 000000 NXMLO:: .WORD 0 ;NXM LO ADDRESS BITS
548 003134 000000 NXMHI:: .WORD 0 ;NXM HI ADDRESS BITS FOR DAL'S 16-21
549 003136 000000 T23A:: .WORD 0 ;PROCESSOR TYPE FLAG
550 003140 000000 T23B:: .WORD 0 ;PROCESSOR TYPE FLAG B
551 003142 000000 T3BFLG:: .WORD 0 ;TEST 3B FLAG +0
552 003144 002000 PST32W:: .WORD 2000 ;32W BLOCK ADDRESS FOR 32K START
553 003146 000000 SIFLAG:: .WORD 0 ;
554 003150 000000 BADDAT:: .WORD 0 ;ACTUAL DATA
555 003152 000000 GDDAT:: .WORD 0 ;EXPECTED DATA
556 003154 000000 LOOPFL:: .WORD 0 ;
557 003156 CTAB:: .WORD 0 ;CONFIGURATION TABLES.
558 003156 000000 CTABM:: .WORD 0 ;CONFIG WORK.
559 003160 000000 .WORD 0
560 003162 000000 .WORD 0

```

```

561 003164 000000          .WORD 0
562 003166 177777          .WORD -1          ;END OF MEM TABLE.
563 003170
564
565
566
567
568
569
570
571
572
573 003170
574 003370 000000
575
576 003372 000000
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591 003374
    003374
    003374      124      123      125
592
613
614
615
616 003402
    003402
    003402      052      052      052
618
619
620
621
622
623
624
625 003472 003532' 003535' 003541' TSSRBIT::          .WORD 1$,2$,3$,4$,5$,6$,7$,8$
626 003512 003573' 003577' 003603'          .WORD 9$,10$,11$,12$,13$,14$,15$,16$
627 003532      123      103      000 1$:          .ASCIZ 'SC'
628 003535      102      111      105 2$:          .ASCIZ 'BIE'
629 003541      123      103      105 3$:          .ASCIZ 'SCE'
630 003545      122      115      122 4$:          .ASCIZ 'RMR'
631 003551      116      130      115 5$:          .ASCIZ 'NXM'
632 003555      116      102      101 6$:          .ASCIZ 'NBA'

```

CTABE::
;ERROR STATISTICS TABLE (1 WORD PER UNIT), 64 UNITS MAX:
;
; 0 = UNIT NOT TESTED
; 100000 = UNIT ONLINE, NO ERRORS
; 10XXXX = UNIT ONLINE, ENCOUNTERED XXXX ERRORS
; 160000 = UNIT DROPPED, NON-EXISTENT DEVICE REGISTER
; 160001 = UNIT DROPPED, NOT IDLE AT START
; 14XXXX = UNIT DROPPED, ENCOUNTERED XXXX ERRORS
;
ERTABL: .BLKW 64,
ERTABE: .WORD 0

SKIPT: .WORD 0 ;1=SKIP SUBTEST 0=NO SKIP OF SUBTEST

.SBTTL GLOBAL TEXT MESSAGES

; THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
; MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
; MORE THAN ONE TEST.
;--

; NAMES OF DEVICES SUPPORTED
;--

DEV TYP <TSU05>
L\$DVTYP::
 .ASCIZ /TSU05/
 .EVEN

; TEST DESCRIPTION
;--

DESCRIPT <**** TSU05 DIAG PART 4 - CHECK TRANSPORT IF ERROR ****>
L\$DESC::
 .ASCIZ /**** TSU05 DIAG PART 4 - CHECK TRANSPORT IF ERROR ****/
 .EVEN

; BIT TO ASCII CONVERSION FOR TSSR REGISTER
;--


```

633 003561      102      111      124  7$:      .ASCIZ  'BI19'
634 003566      102      111      124  8$:      .ASCIZ  'BIT8'
635 003573      123      123      122  9$:      .ASCIZ  'SSR'
636 003577      117      106      114 10$:      .ASCIZ  'JFL'
637 003603      102      111      124 11$:      .ASCIZ  'BIT5'
638 003610      102      111      124 12$:      .ASCIZ  'BIT4'
639 003615      102      111      124 13$:      .ASCIZ  'BIT3'
640 003622      102      111      124 14$:      .ASCIZ  'BIT2'
641 003627      102      111      124 15$:      .ASCIZ  'BIT1'
642 003634      102      111      124 16$:      .ASCIZ  'BIT0'
643              .EVEN
644 003642      124      123      123 SFIERR: .ASCIZ  'TSSR ERROR AFTER SOFT INIT'
645 003675      124      123      123 SFHERR: .ASCIZ  'TSSR ERROR AFTER BUS RESET'
646 003730      040      040      116 NXR:    .ASCIZ  / NON-EXISTANT DEVICE REGISTER/
647 003767      045      101      040 NXRX:  .ASCIZ  /#A ADDRESS: #06/
648 004010      045      101      040 TSSX:  .ASCII  /#A TSBA,TSSR EXP'D: #06#A,#06#N/
649 004050      045      101      040      .ASCIZ  /#A TSBA,TSSR REC'D: #06#A,#06/
650 004107      045      116      045 FUSI:  .ASCII  /#N#A/
651 004113      040      040      125 USI:   .ASCIZ  / UNEXPECTED INTERRUPT/
652 004142      040      040      111 NSI:   .ASCIZ  / INTERRUPT EXPECTED, NOT RECEIVED/
653 004205      045      116      045 FNOINTR: .ASCII  /#N#A/
654 004211      040      040      116 NOINTR: .ASCIZ  / NO INTERRUPT WAS GENERATED/
655 004246      040      040      111 IFAULT: .ASCIZ  / INTERRUPT FAULT/
656 004270      045      101      040 INTX:  .ASCIZ  /#A CPU PC: #06#A TSBA: #06/
657 004325      040      040      042 NOINIT: .ASCIZ  / "BUS-INIT" DIDN'T INITIALIZE CONTROLLER/
658 004377      040      040      042 NSINIT: .ASCIZ  / "SOFT-INIT" DIDN'T INITIALIZE THE DPU/
659 004447      040      040      042 BRINIT: .ASCIZ  / "BUS-RESET" DIDN'T INITIALIZE THE DPU/
660
661 004517      000
662 004520      045      116      000 NULCR: .ASCIZ  /#N/
663 004523      045      101      040 EXPGOT: .ASCIZ  /#A EXP'D: #06#A, REC'D: #06/
664 004557      045      116      045 EXPGT2: .ASCIZ  /#N#A EXP'D: #06#A, #06#N#A REC'D: #0#A, #06/
665 004633      045      101      040 DUAD12: .ASCIZ  /#A REG(W) WRITTEN TO: #06#A REG(R) READ; EXP'D: #06#A, REC'D: #06/
666 004735      122      101      115 PKTRAM: .ASCIZ  'RAM Contents Do Not Match Packet Sent'
667 005003      040      040      103 SCME:  .ASCIZ  / CONFIG DOESN'T MATCH MFG. MASTER/
668 005046      127      122      111 WRTMSG: .ASCIZ  'WRITE CHARACTERISTICS Failed'
669 005103      124      123      123 WRTERR: .ASCIZ  'TSSR Incoirrect After WRITE Command, More Bits Set Than SSR'
670 005176      124      123      123 RDERR:  .ASCIZ  'TSSR Incoirrect After READ Command, More Bits Set Than SSR'
671 005270      106      101      124 SCHERR: .ASCIZ  'FATAL ERROR IN SUBTEST - CHECK TAPE,CABLES,TRANSPORT etc.'
672 005362      105      122      122 RETERR: .ASCIZ  'ERROR IN SUBTEST - WRITE DATA RETRY FIVE TIMES FAILED'
673 005450      045      116      045 NOMEM: .ASCIZ  '#N#A ***** NO NXM ADDRESS--CANNOT TEST NXM TIMEOUT. *****#N'
674              .EVEN
675
676              .SBTTL  GLOBAL ERROR REPORT SECTION
677
678
679      ;**
680      ; THE GLOBAL ERROR REPORT SECTION CONTAINS THE PRINTB AND PRINTX
681      ; CALLS THAT ARE USED IN MORE THAN ONE TEST.
682      ; ASCII TEXT STRINGS ARE FOUND IN THE GLOBAL TEXT SECTION.
683      ;--
684 005544      013746  003106'
685 005544      012746  003767'
        005550      012746  000002
        005554

```

```

          BGNMSG  NXREHR          ;NON-EXISTANT DEVICE REGISTER.
NXRERR:  PRINTX  @NXRX,NODEV      ;NDEV = NEXM ADDRESS.
          MOV     NODEV,-(SP)
          MOV     @NXRX,-(SP)
          MOV     @2,-(SP)

```

TSV3 - GLOBAL AREAS MACRO M1113 01-FEB-84 18:55
GLOBAL ERROR REPORT SECTION

SEQ 034

```

005560 010600      MOV      SP,R0
005562 104415      TRAP     C#PNTX
005564 062706 000006  ADD      #6,SP
686 005570 004737 005576' JSR      PC,EXTEND      ; PRINT EXTENSION IF REQUIRED.
687 005574      ENDM3G
005574 104423      L10002: TRAP     C#MSG
688
689
690
691      ; THIS ROUTINE APPENDS A UNIQUE EXTENSION (IF REQUIRED)
692      ; TO ANY OF THE ABOVE ERROR SIGNATURES.
693
694 005576 005727      EXTEND: TST      (PC)+
695 005600 000000      EXTA: 0          ; 0 = NO EXTENSION.
696 005602 001402      BEQ      1$
697 005604 004777 177770 JSR      PC,EXTA      ; APPEND EXTENSION TEXT.
698 005610      1$: PRINTX   #NULCR      ; PRINT A BLANK LINE
005610 012746 004520'   MOV      #NULCR,-(SP)
005614 012746 000001   MOV      #1,-(SP)
005620 010600      MOV      SP,R0
005622 104415      TRAP     C#PNTX
005624 062706 000004  ADD      #4,SP
699 005630 000207      RTS      PC
700
701      .SBTTL  PRITSSR - PRINT TSSR CONTENTS
702
703      ;+
704      ;
705      ; ROUTINE TO DISPLAY THE CONTENTS, AND BIT DEFINITIONS, OF
706      ; THE TSSR REGISTER. THIS ROUTINE IS NORMALLY CALLED ONLY
707      ; BY A MESSAGE PRINTING ROUTINE
708      ;
709      ; INPUTS:
710      ;
711      ; R1      CONTENTS OF TSSR
712      ;
713      ; SUBORDINATE ROUTINES:
714      ;
715      ; CHKAMB  CHECK FOR AMBIGUOUS CONTENTS
716      ;
717      ; -
718
719 005632      PRITSSR: SAVREG      ; SAVE GENERAL REGISTERS
720 005632      MOV      R1,R4      ; SAVE THE TSSR CONTENTS
721 005636 010104      PRINTB   #TSSRFOR,R4 ; PRINT THE CONTENTS OF TSSR
722 005640      MOV      R4,-(SP)
005640 01J446      MOV      #TSSRFOR,-(SP)
005642 012746 006305'   MOV      #2,-(SP)
005646 012746 000002   MOV      SP,R0
005652 010600      TRAP     C#PNTB
005654 104414      ADD      #6,SP
005656 062706 000006  MOV      R4,R0      ; GET TSSR BACK FOR CHKAMB
723 005662 010400      JSR      PC,CHKAMB   ; ARE CONTENTS AMBIGUOUS ?
724 005664 004737 015734'   BCS      5$          ; BRANCH IF NOT
725 005670 103410      PRINTX   #AMBTSSR   ; SHOW CONTENTS ARE AMBIGUOUS
726 005672

```

```

005672 012746 006525'      MOV      #4MBTSSR,-(SP)
005676 012746 000001      MOV      #1,-(SP)
005702 010600      MOV      SP,R0
005704 104415      TRAP     C#PNTX
005706 062706 000004      ADD      #4,SP
727 005712 010403      5$:      MOV      R4,R#      ;CONTENTS OF TSSR
728 005714 042703 001476      BIC      #HIADDR!FATERR!TERCLS,R3      ;CLEAR ALL MULTIPLE BIT FIELDS
729 005720 001434      BEQ      20$      ;NO BITS ARE SET
730 005722 012702 002624'      MOV      #TMPBFR,R2      ;TEMPORARY ASCII BUFFER
731 005726 012701 003472'      MOV      #TSSRBIT,R1      ;ASCII EQUIVALENT OF BITS
732 005732 005703      10$:      TST      R3      ;REMAINING BITS TO CONVERT
733 005734 001413      BEQ      15$      ;BRANCH WHEN ALL ARE DONE
734 005736 000241      CLC      ;CLEAR CARRY FOR SHIFT
735 005740 006103      ROL      R3      ;SHIFT NEXT BIT TO CARRY
736 005742 103006      BCC      13$      ;BRANCH IF BIT NOT SET
737 005744 011100      MOV      (R1),R0      ;POINTER TO BIT DEFINITION
738 005746 112022      11$:      MOVB    (R0)+,(R2)+      ;MOVE ASCII TO BUFFER
739 005750 001376      BNE      11$      ;MOVE ALL BITS
740 005752 112762 000054 177777      MOVB    #'...-1(R2)      ;INSERT A COMMA TO TERMINATE
741 005760 005721      13$:      TST      (R1)+      ;POINT TO NEXT DESCRIPTION
742 005762 000763      BR       10$      ;GET THE REMAINING BITS
743 005764 105042      15$:      CLRB    -(R2)      ;TERMINATE THE LINE
744 005766      PRINTX  #TSSDEF,#TMPBFR      ;PRINT THE BIT DEFINITIONS
005766 012746 002624'      MOV      #TMPBFR,-(SP)
005772 012746 006476'      MOV      #TSSDEF,-(SP)
005776 012746 000002      MOV      #2,-(SP)
006002 010600      MOV      SP,R0
006004 104415      TRAP     C#PNTX
006006 062706 000006      ADD      #6,SP
745
746 006012 010403      20$:      MOV      R4,R3      ;GET THE TSSR CONTENTS
747 006014 042703 177761      BIC      #CTERCLS,R3      ;CLEAR ALL BUT TERMINATION
748 006020 016303 006566'      MOV      TCOCOD(R3),R3      ;GET THE TERMINATION CODE MEANING
749 006024      PRINTX  #TCOASC,R3      ;PRINT THE TERMINATION CODE
006024 010346      MOV      R3,-(SP)
006026 012746 006366'      MOV      #TCOASC,-(SP)
006032 012746 000002      MOV      #2,-(SP)
006036 010600      MOV      SP,R0
006040 104415      TRAP     C#PNTX
006042 062706 000006      ADD      #6,SP
750 006046 010403      MOV      R4,R3      ;TSSR CONTENTS AGAIN
751 006050 042703 177717      BIC      #CFATERR,R3      ;CLEAR ALL BUT FATAL TERMINATION
752 006054 001416      BEQ      25$      ;DON'T PRINT IF ZERO
753 006056 006203      ASR      R3
754 006060 006203      ASR      R3
755 006062 006203      ASR      R3      ;ALINE TERMINATION CODE FOR INDEX
756 006064 016303 007126'      MOV      TFCOD(R3),R3      ;GET THE FATAL TERMINATION CODE
757 006070      PRINTX  #TFCASC,R3      ;PRINT THE FATAL TERMINATION CODE
006070 010346      MOV      R3,-(SP)
006072 012746 006427'      MOV      #TFCASC,-(SP)
006076 012746 000002      MOV      #2,-(SP)
006102 010600      MOV      SP,R0
006104 104415      TRAP     C#PNTX
006106 062706 000006      ADD      #6,SP
758 006112 042704 176377      25$:      BIC      #CHIADDR,R4      ;CLEAR ALL BUT EXTENDED ADDRESS
759 006116 001411      BEQ      30$      ;DON'T PRINT IF ZERO
760 006120      PRINTX  #TEXASC,R4      ;PRINT THE EXTENDED ADDRESS BITS

```

```

006120 010446
006122 012746 006325'
006126 012746 000002
006132 010600
006134 104415
006136 062706 000006
761 006142 013703 002172' 30$:
762 006146
006146 013346
006150 012746 000001
006154 010600
006156 104415
006160 062706 000004
763 006164 000207
764
779 006166 045 116 045 EPRT1: .ASCIZ 'NNA *****CHECK TRANSPORT*****'
780 006225 045 116 045 EPRT2: .ASCIZ 'NNA *****CHECK PARITY SWITCH IN TRANSPORT*****'
782 006305 045 116 045 TSSRFR: .ASCIZ 'NNA TSSR = #06'
783 006325 045 116 045 TEXASC: .ASCIZ 'NNA Extended Address Bits = #06'
784 006366 045 116 045 TCOASC: .ASCIZ 'NNA Termination Class Code = #T'
785 006427 045 116 045 TFCASC: .ASCIZ 'NNA Fatal Termination Class Code = #T'
786 006476 045 116 045 TSSDEF: .ASCIZ 'NNA TSSR Bits Set: #T'
787 006525 045 116 045 AMBTSSR: .ASCIZ 'NNA TSSR Contents Are Ambiguous'
788
789 006566 006606' 006631' 006657' TCOCOD: .EVEN
790 006606 116 157 162 1$: .WORD 1$,2$,3$,4$,5$,6$,7$,8$
791 006631 124 145 162 2$: .ASCIZ 'Normal Termination'
792 006657 124 141 160 3$: .ASCIZ 'Termination Condition'
793 006701 106 165 156 4$: .ASCIZ 'Tape Status Alert'
794 006721 122 145 143 5$: .ASCIZ 'Function Reject'
795 007003 122 145 143 6$: .ASCIZ 'Recoverable Error - Tape Position One Record Down'
796 007052 125 156 162 7$: .ASCIZ 'Recoverable Error - Tape Was Not Moved'
797 007076 106 141 164 8$: .ASCIZ 'Unrecoverable Error'
798
799
800 007126 007136' 007172' 007203' TSFCOD: .ASCIZ 'Fatal Controller Error'
801 007136 111 156 164 1$: .EVEN
802 007172 122 145 163 2$: .ASCIZ 'Internal Diagnostic Failure'
803 007203 102 165 163 3$: .ASCIZ 'Reserved'
804 007247 122 145 163 4$: .ASCIZ 'Bus Interface or Sanity Check Error'
805
806
807
808 .SBTTL PRIPKT - PRINT THE ADDRESS/CONTENTS OF COMMAND PACKET
809
810 ;+
811 ;THIS ROUTINE PRINTS THE ADDRESS AND CONTENTS OF A COMMAND PACKET.
812 ;THIS ROUTINE IS NORMALLY ONLY CALLED FROM A PRINT ROUTINE.
813 ;
814 ;INPUT:
815 ;
816 ; R0 NUMBER OF WORDS IN PACKET
817 ; R3 HIGH ORDER COMMAND PACKET ADDRESS
818 ; R4 ADDRESS OF COMMAND PACKET
819 ;
820 ; NOTE: R3 IS IGNORED IF THE KENABLE FLAG IS CLEAR.
821 ;-

```

TSV3 - GLOBAL AREAS MACRO M1113 01-FEB-84 18:55
 PRIPKT - PRINT THE ADDRESS/CONTENTS OF COMMAND PACKET

SEQ 037

```

822 007260          PRIPKT:
823 007260          SAVREG          ;SAVE THE REGISTERS
824 007264 010005   MCV            R0,R5          ;SAVE NO. OF WORDS IN PACKET
825 007266 005737 003126'  TST            KTENABLE        ;ABOVE 28K UNDER TEST?
826 007272 001001   BNE            10$          ;BR IF YES
827 007274 005003   CLR            R3            ;SET HIGH ORDER ADDRESS TO 0
828 007276 010301 10$:  MOV            R3,R1          ;COPY HIGH ORDER ADDRESS
829 007300 010400   MOV            R4,R0          ;GET LOWER ADDRESS
830 007302 006100   ROL            R0            ;SHIFT BIT 15 INTO C BIT
831 007304 006101   ROL            R1            ;AND INTO HIGH ORDER.
832 007306          PRINTB         #PKTADD,R1,R4  ;PRINT PACKET ADDRESS
      007306 010446   MOV            R4,-(SP)
      007310 010146   MOV            R1,-(SP)
      007312 012746 007444'  MOV            #PKTADD,-(SP)
      007316 012746 000003   MOV            #3,-(SP)
      007322 010600   MOV            SP,R0
      007324 104414   TRAP          C:PNTB
      007326 062706 000010   ADD            #10,SP
833 007332 010300 15$:  MOV            R3,R0          ;GET HIGH ORDER ADDRESS
834 007334 001404   BEQ            20$          ;BR IF NOT ABOVE 28K.
835 007336 010401   MOV            R4,R1          ;GET LOW ORDER ADDRESS
836 007340 004737 017210'  JSR            PC,SETMAP      ;SETUP PAR6 MAPPING FOR 18 BIT ADDRESS
837 007344 010004   MOV            R0,R4          ;GET RETURNED PAR6 ADDRESS BIAS
838 007346 005001 20$:  CLR            R1            ;SAVE WORD NUMBER
839 007350 012402 25$:  MOV            (R4)+,R2        ;GET PACKET CONTENTS
840 007352          PRINTB         #PKTFRM,R1,R2  ;PRINT THE DATA
      007352 010246   MOV            R2,-(SP)
      007354 010146   MOV            R1,-(SP)
      007356 012746 007406'  MOV            #PKTFRM,-(SP)
      007362 012746 000003   MOV            #3,-(SP)
      007366 010600   MOV            SP,R0
      007370 104414   TRAP          C:PNTB
      007372 062706 000010   ADD            #10,SP
841 007376 005201   INC            R1            ;NEXT WORD NUMBER
842 007400 020105   CMP            R1,R5          ;DONE ALL PACKET WORDS?
843 007402 0027E2   BLT            25$          ;LOOP TILL ALL DONE
844 007404 000207   RTS            PC            ;RETURN
845
846 007406          045          116          045  PKTFRM: .ASCIZ  'N#A Packet Word #01#A = #06'
847 007444          045          116          045  PKTADD: .ASCIZ  'N#A Packet Address = #01#05'
848
849
850
851          .SBTTL  PRIBXOR - PRINT EXPD, RECV AND XOR BYTE
852
853          ;*
854          ;
855          ;PRINT EXPECTED DATA, RECEIVED DATA, AND XOR OF THE DATA BYTE
856          ;THIS ROUTINE IS NORMALLY CALLED ONLY FOR PRINT ROUTINES.
857          ;
858          ;INPUTS:
859          ;
860          ;          R1          RECEIVED DATA
861          ;          R2          EXPECTED DATA
862          ;
863          ;OUTPUT:
864          ;

```

```

865      ;      R0      XOR OF EXPECTED/RECEIVED DATA
866      ;
867      ; -
868
869 007502      PRIBXOR::
870 007502      SAVREG      ;SAVE THE REGISTERS
871 007506 010203      MOV      R2,R3      ;EXPECTED DATA
872 007510      XOR      R1,R3      ;FORM THE EXCLUSIVE OR
873 007520 012700 177400      MOV      #C<377>,R0      ;BYTE MASK
874 007524 040001      BIC      R0,R1      ;SAVE LOW BYTE RECV
875 007526 040002      BIC      R0,R2      ;SAVE LOW BYTE EXPD
876 007530 040003      BIC      R0,R3      ;SAVE LOW BYTE XOR
877 007532      PRINTB     #XORBFOR,R2,R1,R3 ;PRINT THE MESSAGE
      007532 010346      MOV      R3,-(SP)
      007534 010146      MOV      R1,-(SP)
      007536 010246      MOV      R2,-(SP)
      007540 012746 007564'      MOV      #XORBFOR,-(SP)
      007544 012746 000004      MOV      #4,-(SP)
      007550 010600      MOV      SP,R0
      007552 104414      TRAP     C#PNTB
      007554 062706 000012      ADD      #12,SP
878 007560 010300      MOV      R3,R0      ;R0 HAS XOR ON RETURN
879 007562 000207      RTS      PC      ;RETURN TO CALLER
880
881 007564      045      116      045 XORBFOR: .ASCIZ 'N#A EXPD: #03#A RECV: #03#A XOR: #03'
882      .EVEN
883
884
885      .SBTTL PRIBXOR - PRINT EXPD, RECV AND XOR
886
887      ;+
888      ;
889      ;PRINT EXPECTED DATA, RECEIVED DATA, AND XOR OF THE TWO
890      ;THIS ROUTINE IS NORMALLY CALLED ONLY FOR PRINT ROUTINES.
891      ;
892      ;INPUTS.
893      ;
894      ;      R1      RECEIVED DATA
895      ;      R2      EXPECTED DATA
896      ;
897      ;OUTPUT.
898      ;
899      ;      R0      XOR OF EXPECTED/RECEIVED DATA
900      ;
901      ; -
902
903 007632      PRIBXOR::
904 007632      SAVREG      ;SAVE THE REGISTERS
905 007636 010203      MOV      R2,R3      ;EXPECTED DATA
906 007640      XOR      R1,R3      ;FORM THE EXCLUSIVE OR
907 007650      PRINTB     #XORBFOR,R2,R1,R3 ;PRINT THE MESSAGE
      007650 010346      MOV      R3,-(SP)
      007652 010146      MOV      R1,-(SP)
      007654 010246      MOV      R2,-(SP)
      007656 012746 007702'      MOV      #XORBFOR,-(SP)
      007662 012746 000004      MOV      #4,-(SP)
      007666 010600      MOV      SP,R0
  
```

```

007670 104414
007672 062706 000012
908 007676 010300
909 007700 000207
910
911 007702 045 116 045 XORFOR: .ASCIZ ' *N*A EXPD: *06*A RECV: *06*A XOR: *06'
912 .EVEN
913
914 .SBTTL PRIEQU - PRINT BIT NUMBERS AS ASCII EQUIVALENT
915
916 ;+
917 ;
918 ;ROUTINE TO CONVERY BIT VALUES TO ASCII AND PRINT THE STRING
919 ;THIS ROUTINE IS NORMALLY CALLED FROM A PRINT ROUTINE
920 ;
921 ;INPUTS:
922 ;
923 ; R0 OCTAL VALUE TO CONVERT
924 ; R1 TABLE OF POINTERS TO ASCII EQUIVALENT
925 ;
926 ;-
927
928 007750 PRIEQU:
929 007750 SAVREG ;SAVE THE REGISTERS
930 007754 000207 RTS PC ;RETURN TO CALLER
931
932
933
934 .SBTTL PRIRAM - PRINT RAM ADDRESS
935
936 ;+
937 ;
938 ;PRINT CONTROLLER RAM ADDRESS.
939 ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
940 ;
941 ;INPUTS:
942 ;
943 ; R4 RAM ADDRESS
944 ;
945 ;-
946 007756 PRIRAM:
947 007756 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
948 007762 PRINTB #RAMFOR,R4 ;PRINT RAM ADDRESS IN ERROR
007762 010446 MOV R4,-(SP)
007764 012746 010006' MCV #RAMFOR,-(SP)
007770 012746 000002 MOV #2,-(SP)
007774 010600 MOV SP,R0
007776 104414 TRAP C$PNTB
010000 062706 000006 ADD #6,SP
949 010004 000207 RTS PC ;RETURN
950
951 010006 045 116 045 RAMFOR: .ASCIZ ' *N*A CONTROLLER RAM ADDRESS * *06'
952 .EVEN
953
954 .SBTTL PRIADD - PRINT MEMORY ERROR ADDRESS
955
956 ;+

```

```

957
958      PRINT MEMORY ADDRESS
959      THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
960
961      IMPLICIT INPUTS
962
963      ERRHI - HIGH ORDER ADDRESS
964      ERRLO - LOW ORDER ADDRESS
965
966
967 010050 PRIADD: SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
968 010050      MOV      ERRHI,R0      ;GET HIGH ADDRESS
969 010054 013700 002230'      MOV      ERRLO,R1      ;GET LOW ADDRESS
970 010060 013701 002232'      MOV      R1,R2          ;COPY LOW ADDRESS
971 010064 010102      ROL      R1          ;SHIFT BIT 15 TO C BIT
972 010066 006101      ROL      R0          ;SHIFT INTO HIGH ORDER
973 010070 006100      PRINTB #PRIA0,R0,R2 ;PRINT MEMORY ADDRESS IN ERROR
974 010072      MOV      R2,-(SP)
          010072 010246      MOV      R0,-(SP)
          010074 010046      MOV      #PRIA0,-(SP)
          010076 012746 010120'  MOV      #3,-(SP)
          010102 012746 000003      MOV      SP,R0
          010106 010600      TRAP    C#PNTB
          010110 104414      ;JD     #10,SP
          010112 062706 000010      RTS      PC          ;RETURN
975 010116 000207
976
977 010120      045      116      045 PRIA0: .ASCIZ 'MWA MEMORY ERROR ADDRESS - #01#05'
978      .EVEN
979
980
981      .SBTTL PRITADD - PRINT MEMORY TEST ADDRESS
982
983      PRINT MEMORY ADDRESS
984      THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
985
986      IMPLICIT INPUTS
987
988      ERRHI - HIGH ORDER ADDRESS
989      ERRLO - LOW ORDER ADDRESS
990
991
992
993 010164 PRITADD: SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
994 010164      MOV      ERRHI,R2      ;GET HIGH ADDRESS
995 010170 013702 002230'      MOV      ERRLO,R1      ;GET LOW ADDRESS
996 010174 013701 002232'      MOV      R1,R2          ;COPY LOW ADDRESS
997      ;ROL      R1          ;SHIFT BIT 15 TO C BIT
998      ;ROL      R0          ;SHIFT INTO HIGH ORDER
999      PRINTB #PRIT0,R1      ;PRINT MEMORY ADDRESS LOW IN ERROR
1000 010200      MOV      R1,-(SP)
          010200 010146      MOV      #PRIT0,-(SP)
          010202 012746 010246'  MOV      #2,-(SP)
          010206 012746 000002      MOV      SP,R0
          010212 010600      TRAP    C#PNTB
          010214 104414      ADD     #6,SP
          010216 062706 000006
    
```



```

1001 010222          PRINTB #PRIT1,R2          ;PRINT MEMORY ADDRESS HIGH IN ERROR
      010222 010246  MOV      R2,-(SP)
      010224 012746 010311' MOV      #PRIT1,-(SP)
      010230 012746 000002 MOV      #2,-(SP)
      010234 010600 MOV      SP,R0
      010236 104414 TRAP    C#PNTB
      010240 062706 000006 ADD      #6,SP
1002 010244 000207  RTS      PC          ;RETURN
1003
1004 010246      045      116      045 PRIT0: .ASCIZ 'NWA MEMORY TEST ADDRESS LOW = #06'
1005 010311      045      116      045 PRIT1: .ASCIZ 'NWA MEMORY TEST ADDRESS HIGH = #06'
1006
1007
1008
1009
1010          .SBTTL SPACE . SPACE RECORDS (FORWARD AND REVERSE) COMMAND
1011
1012
1013 ;ROUTINE TO ISSUE A SPACE RECORDS
1014 ;COMMAND (FORWARD OR REVERSE)
1015
1016 ;INPUT:
1017
1018          R3      NUMBER OF RECORDS TO BE SPACED OVER
1019          BIT15  CONTROLS DIRECTION
1020          BIT15  = 0 IS FORWARD
1021          BIT15  = 1 IS REVERSE
1022          R5      FIRST DEVICE UNIBUS ADDRESS
1023
1024          REQUIRES A WRITE CHARACTERISTICS DONE PREVIOUSLY
1025
1026 ;OUTPUT:
1027
1028          CARRY   SET - SPACE RECORDS COMMAND OK
1029          CLR     SPACE RECORDS FAILED
1030
1031
1032          R0      THE CONTENTS OF R4 IS MOVED TO R0
1033
1034
1035 ;IMPLICIT OUTPUT:
1036
1037          TAPE HAS BEEN MOVED
1038
1039 ;SIDE EFFECTS:
1040
1041
1042
1043
1044 010356          SPACE:: SAVREG          ;SAVE THE GENERAL REGISTERS
1045 010356          MOV      #500.,SDELAY    ;SET UP DELAY
1046 010362 012737 000764 010550' MOV      #140010,80# ;SET UP COMMAND, SPACE FORWARD
1047 010370 012737 140010 010540' TST      R3          ;CHECK FOR DIRECTION
1048 010376 005703 BMI      5#          ;BR, IF REVERSE INDICATED
1049 010400 100403 MOV      R3,90#      ;LOAD UP NUMBER OF RECORDS TO SPACE
1050 010402 010337 010542' BR       10#          ;GO DO COMMAND
1051 010406 000407

```

TSV3 - GLOBAL AREAS MACRO M1113 01-FEB-84 18.55
 SPACE - SPACE RECORDS (FORWARD AND REVERSE) COMMAND

SEQ 042

```

1052 010410 042703 100000      5$: BIC      #BIT15,R3      ;CLEAR DIRECTION BIT
1053 010414 010537 010542'    MOV      R3,90#      ;LOAD UP NUMBER OF RECORDS TO SPACE
1054 010420 052737 000400 010540'  BIS      #BIT8,80#   ;SET REVERSE BIT IN COMMAND PACKET
1055 010426 012704 010540'    10$: MOV      #80#,R4   ;SET UP R4 WITH PACKET ADDRESS
1056 010432 010465 000000      MOV      R4,TSDB(R5) ;SEND OUT COMMAND
1057 010436 004737 016140'    15$: JSR      PC,WAITF ;WAIT FOR SSR
1058 010442 103420      BCS      20#        ;BR, IF SSR IS SET AND OK
1059 010444      DELAY    250      ;DELAY ABOUT .25 SECONDS
      010444 C12727 000250      MOV      #250,(PC)+
      010450 000000      .WORD    0
      010452 013727 002116'    MOV      L#DLY,(PC)+
      010456 000000      .WORD    0
      010460 005367 177772      DEC      -6(PC)
      010464 001375      BNE      .-4
      010466 005367 177756      DEC      -22(PC)
      010472 001367      BNE      .-20
1060 010474 005337 010550'    DEC      SDELAY     ;BUMP DELAY COUNTER DOWN
1061 010500 001356      BNE      15#        ;BR, IF MORE DELAY
1062 010502 000411      BR       60#        ;BR IF TROUBLE CARRY = CLEAR
1063 010504 016501 000002    20$: MOV      TSSR(R5),R1 ;READ TSSR
1064 010510 012702 000200      MOV      #SSR,R2   ;SET UP EXPECTED
1065 010514 020201    25$: CMP      R2,R1   ;ARE THEY OK
1066 010516 001401      BEQ     40#        ;BR, IF EQUAL = OK
1067 010520 000402      BR       60#        ;TROUBLE EXIT
1068 010522 000261    40$: SEC      ;SET CARRY NO TROUBLE
1069 010524 000401      BR       70#        ;EXIT
1070 010526 000241    60$: CLC      ;CARRY CLEAR = ERROR
1071 010530      70$:
1072 010530 010400      MOV      R4,R0     ;PASS PACKET ADDRESS
1073 010532 000207      RTS      PC        ;RETURN
1074
1075
1076
1077
1078 ;PACKET FOR SPACE COMMAND
1079
1081 010534      .BLKB   10-<.-TSV2&7>
1083
1084 ;COMMAND WORD
1085 010540 000000    80$: .WORD
1086 ;NUMBER OF RECORDS TO BE SPACED OVER WORD
1087 010542 000000    90$: .WORD
1088 010544 000000      .WORD
1089 010546 000000      .WORD
1090 010550 000000  SDELAY: .WORD    0      ;DELAY COUNTER
1091      .EVEN
1092
1093
1094      .SBTTL  WRCHR - WRITE CHARACTERISTICS COMMAND
1095
1096
1097
1098 ;ROUTINE TO ISSUE A WRITE CHARACTERISTICS
1099 ;COMMAND SO THAT OTHER COMMANDS WILL BE ACCEPTED
1100
1101 ;INPUT:
1102

```

TSV3 GLOBAL AREAS MACRO M1113 01-FEB-84 18:55
 WRTCHR WRITE CHARACTERISTICS COMMAND

SEQ 043

```

1103      ; R4 ADDRESS OF PACKET FROM TEST
1104      ; R5 FIRST DEVICE UNIBUS ADDRESS
1105      ; REQUIRES A CALL TO SOFINIT BE DONE PREVIOUSLY
1106
1107      ; OUTPUT:
1108
1109      ; RO TSSR CONTENTS
1110      ; CARRY SET - WRITE CHARACTERISTICS COMMAND OK
1111      ; CLR - WRITE CHARACTERISTICS FAILED
1112
1113      ; IMPLICIT OUTPUT:
1114
1115      ; MESSAGE BUFFER AND OTHER BUFFERS ALL SET UP
1116      ; SOFTWARE SWITCHES SET AS FOLLOWS:
1117      ; EXTFEA = EXTENDED FEATURES PRESENT
1118      ; BENBSW = BUFFER ENABLE SWITCH ON OR OFF
1119
1120
1121      ; SIDE EFFECTS:
1122
1123
1124
1125
1126      WRTCHR:
1127      SAVREG
1128      CLR BENBSW ;SAVE THE GENERAL REGISTERS
1129      CLR EXTFEA ;CLEAR BUFFER ENABLE SWITCH
1130      MOV R4,TSDB(R5) ;CLEAR EXTENDED FEATURES SW SWITCH
1131      JSR PC,CHKTSSR ;SEND OUT COMMAND
1132      BCS 20$ ;WAIT FOR SSR
1133      BR 60$ ;BR, IF SSR IS SET AND OK
1134      MOV TSSR(R5),R1 ;BR IF TROUBLE CARRY = CLEAR
1135      MOV #SSR,R2 ;READ TSSR
1136      BIT #OFL,R1 ;SET UP EXPECTED
1137      BEQ 25$ ;WAS OFF LINE SET IN TSSR
1138      BIS #OFL,R2 ;BR, IF NO OFL SET
1139      CMP R2,R1 ;MAKE THEM LOOK ALIKE
1140      BEQ 40$ ;ARE THEY OK
1141      BR 60$ ;BR, IF EQUAL = OK
1142      ADD #8,R4 ;TROUBLE EXIT
1143      MOV (R4),R3 ;POINT TO WRT CHARA DATA PACKET
1144      BIT #X2.EXTF,XST2(R3) ;GET ADDRESS OF MESSAGE BUFFER
1145      BEQ 45$ ;EXTENDED FEATURES BIT SET?
1146      INC EXTFEA ;BR IF NO
1147      ;SET EXTENDED FEATURES SW SWITCH
1148      BIT #X2.BUFE,XST2(R3) ;BUFFER ENABLE SWITCH SET
1149      BEQ 50$ ;BR, IF SWITCH NOT SET
1150      JNC BENBSW ;SET SOFTWARE SWITCH FOR ENABLED
1151
1152      SEC
1153      BR 70$ ;SET CARRY NO TROUBLE
1154      CLC ;EXIT
1155      MOV TSSR(R5),RO ;CARRY CLEAR = ERROR
1156      RTS PC ;RETURN TSSR CONTENTS
1157      ;RETURN
1158
1159      .SBTTL REWIND - POSITION TAPE (REWIND) COMMAND

```

1160
 1161
 1162
 1163
 1164
 1165
 1166
 1167
 1168
 1169
 1170
 1171
 1172
 1173
 1174
 1175
 1176
 1177
 1178
 1179
 1180
 1181
 1182
 1183
 1184
 1185
 1186
 1187 010704
 1188 010704
 1189 010710 012704 011000'
 1190 010714 010465 000000
 1191 010720 012703 000550
 1192 010724 004737 016140'
 1193 010730 103417
 1194 010732
 010732 012727 000572
 010736 000000
 010740 013727 002116'
 010744 000000
 010746 005367 177772
 010752 001375
 010754 005367 177756
 010760 001367
 1195 010762 005303
 1196 010764 001357
 1197 010766 000241
 1198 010770 010400
 1199 010772 000207
 1200
 1201
 1203 010774
 1205 011000
 1206 011000 102010
 1207 011002 000000
 1208
 1209
 1210

```

; THIS ROUTINE WILL REWIND THE SELECTED TAPE.
;
; CAUTION: THE ROUTINE DOES NOT WAIT FOR BOT
; TO ARRIVE. ALSO THE CALLER MUST CHECK FOR
; SSR TO SET IN THE TSSR
;
; CALLING SEQUENCE:
;
; DO A SOFT INIT
; DO A WRITE CHARACTERISTICS
; JSR PC,REWIND
;
; INPUT:
;
; R5 FIRST DEVICE UNIBUS ADDRESS
;
; OUTPUT
;
; R0 THE CONTENTS OF R4 IS PASSED TO R0
;
; REWIND:
; SAVREG ; SAVE R1-R5 UNTIL NEXT RETURN
; MOV @RWPACK,R4 ; GET PACKET ADDRESS
; MOV R4,TSDB(R5) ; SEND PACKET ADDRESS TO EXECUTE
; MOV @360.,R3 ; ENOUGH TIME FOR 2400' REEL TO REWIND
10$: ; JSR PC,WAITF ; WAIT FOR SSR TO SET
; BCS 20$ ; LEAVE WHEN SSR IS SET
; DELAY 250. ; WAIT FOR .25 SECONDS
; MOV @250.,(PC)+
; .WORD 0
; MOV L$DLY,(PC)+
; .WORD 0
; DEC -6(PC)
; BNE .-4
; DEC -22(PC)
; BNE .-20
; DEC R3 ; BUMP COUNTER DOWN
; BNE 10$ ; KEEP GOING
; CLC ; CLEAR CARRY TO SET ERROR
20$: ; MOV R4,R0 ; PASS THE PACKET ADDRESS
; RTS PC ; RETURN
;
; RWPACK:
; .BLKB 10-<.-TSV2&7>
; .WORD 102010 ; POSITION COMMAND (REWIND)
; .WORD 0 ; NOT USED
;
; .SBTTL CKRAM - COMPARE RAM TO I/O PACKET
    
```

TSV8 - GLOBAL AREAS MACRO M1113 01-FEB-84 18:55
 CKRAM - COMPARE RAM TO I/O PACKET

SEQ 045

```

1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239 01'004
1240 011004
1241 011010 012701 002234'
1242 011014 012702 000201
1243 011020 005003
1244 011022 004737 016226'
1245 011026 112765 000000 000000
1246 011034 004737 016226' 10$:
1247 011040 010265 000000
1248 011044 004737 016226'
1249 011050 116511 000000
1250 011054 122124
1251 011056 001401
1252 011060 005203
1253 011062 005202 20$:
1254 011064 020227 000210
1255 011070 003761
1256 011072 005703
1257 011074 001402
1258 011076 000241
1259 011100 000401
1260 011102 000261 30$:
1261 011104 012737 000010 002274' 50$:
1262 011112 000207
1263
1264
1265
1266
1267

;+
;
;ROUTINE TO READ THE FIRST 8 BYTES FROM RAM
;MEMORY AND COMPARE THIS DATA TO A COMMAND PACKET.
;
;INPUT:
;
; R4 ADDRESS OF THE COMMAND PACKET
; R5 FIRST DEVICE UNIBUS ADDRESS
;
;OUTPUT:
;
; CARRY SET - RAM MATCHES PACKET
; CLR - RAM DOES NOT MATCH PACKET
;
;IMPLICIT OUTPUT:
;
; THE TABLE RAMDATA IS FILLED WITH THE
; DATA HELD IN RAM.
; RAMSIZ IS SET TO 8. FOR PRAMPKT ROUTINE
;
;SIDE EFFECTS:
;
; THE SUBSYSTEM IS LEFT IN MAINTENANCE MODE
;
;-

CKRAM::
SAVREG
MOV @RAMDATA,R1 ;SAVE THE GENERAL REGISTERS
MOV @RMPKTBEG,R2 ;ADDRESS TO SAVE THE RAM DATA
CLR R3 ;BYTE ADDRESS OF FIRST RAM DATA
JSR PC,CHKTSSR ;CLEAR THE ERROR FLAG
MOVB #0,TSDB(R5) ;WAIT FOR SSR
JSR PC,CHKTSSR ;SET MAINTENANCE MODE
MOV R2,TSDB(R5) ;WAIT FOR SSR TO SET
JSR PC,CHKTSSR ;SELECT NEXT RAM ADDRESS
MOVB TSBA(R5),(R1) ;WAIT FOR SSR TO SET
CMPB (R1), (R4) ;READ THE RAM DATA
BEQ 20$ ;COMPARE TO EXPECTED
INC R3 ;BRANCH IF OK
INC R2 ;SET ERROR FLAG
CMP R2,@RMPKTEND ;ADDRESS OF NEXT RAM LOCATION
BLE 10$ ;REACHED END YET ?
TST R3 ;BRANCH TILL ALL READ
BEQ 30$ ;WAS AN ERROR FOUND ?
CLC ;BRANCH IF NOT
BR 50$ ;CLEAR CARRY TO SHOW ERROR
SEC ;AND EXIT
MOV @R,RAMSIZ ;SHOW GOOD COMPARE
RTS ;SETUP RAMSIZ FOR PRAMPKT ROUTINE
;RETURN

.SBTTL CKRAM2 - COMPARE RAM TO I/O CHARACTERISTICS DATA
;
;

```

```

1268 ;ROUTINE TO READ THE FIRST 8 OR 10 BYTES FROM RAM
1269 ;MEMORY AND COMPARE THIS DATA TO A CHARACTERISTICS DATA BLOCK.
1270 ;
1271 ;INPUT:
1272 ;
1273 ;       R4       ADDRESS OF THE CHARACTERISTICS DATA
1274 ;       R5       FIRST DEVICE UNIBUS ADDRESS
1275 ;
1276 ;OUTPUT:
1277 ;
1278 ;       CARRY    SET - RAM MATCHES PACKET
1279 ;              CLR - RAM DOES NOT MATCH PACKET
1280 ;
1281 ;IMPLICIT OUTPUT:
1282 ;
1283 ;       THE TABLE RAMDATA IS FILLED WITH THE
1284 ;       DATA HELD IN RAM.
1285 ;       RAMSIZ IS SET TO 8. OR 10. FOR PRAMPKT ROUTINE
1286 ;
1287 ;SIDE EFFECTS:
1288 ;
1289 ;       THE SUBSYSTEM IS LEFT IN MAINTENANCE MODE
1290 ;
1291 ;-
1292 ;
1293 CKRAM2::
1294     SAVREG                ;SAVE THE GENERAL REGISTERS
1295     MOV      @RAMDATA,R1  ;ADDRESS TO SAVE THE RAM DATA
1296     MOV      @RMCHBEG,R2 ;BYTE ADDRESS OF FIRST RAM DATA
1297     CLR      R3          ;CLEAR THE ERROR FLAG
1298     JSR      PC,CHKTSSR  ;WAIT FOR SSR
1299     MOVB     @0,TSDB(R5) ;SET MAINTENANCE MODE
1300     JSR      PC,CHKTSSR  ;WAIT FOR SSR TO SET
1301     MOV      R2,TSDB(R5) ;SELECT NEXT RAM ADDRESS
1302     JSR      PC,CHKTSSR  ;WAIT FOR SSR TO SET
1303     MOVB     TSB(R5),(R1) ;READ THE RAM DATA
1304     CMPB     (R1)+,(R4)+ ;COMPARE TO EXPECTED
1305     BEQ      20$         ;BRANCH IF OK
1306     INC      R3          ;SET ERROR FLAG
1307     INC      R2          ;ADDRESS OF NEXT RAM LOCATION
1308     MOV      @8.,RAMSIZ ;ASSUME EXTFEA NOT SET
1309     TST      EXTFEA      ;IS THE SOFTWARE EXTENDED FEATURES SET
1310     BEQ      25$         ;BR, IF NOT SET
1311     MOV      @10.,RAMSIZ ;SET RAMSIZ FOR EXTEND FEATURES
1312     CMP      R2,@RMCHEND ;AT END OF EXTENDED BUFFER
1313     BLE     10$         ;BR, IF NOT AT END YET
1314     BR      27$         ;AT END BRANCH
1315     CMP      R2,@RMCHEND-2 ;REACHED END YET ?
1316     BLE     10$         ;BRANCH TILL ALL READ
1317     TST      R3          ;WAS AN ERROR FOUND ?
1318     BEQ      30$         ;BRANCH IF NOT
1319     CLC                    ;CLEAR CARRY TO SHOW ERROR
1320     BR      50$         ;AND EXIT
1321     SEC                    ;SHOW GOOD COMPARE
1322     RTS      PC         ;RETURN
1323
1324
1293 011114
1294 011114
1295 011120 012701 002234'
1296 011124 012702 000167
1297 011130 005003
1298 011132 004737 016226'
1299 011136 112765 000000 000000
1300 011144 004737 016226' 10$:
1301 011150 010265 000000
1302 011154 004737 016226'
1303 011160 116511 000000
1304 011164 122124
1305 011166 001401
1306 011170 005203
1307 011172 005202 20$:
1308 011174 012737 000010 002274'
1309 011202 005737 002220'
1310 011206 001407
1311 011210 012737 000012 002274'
1312 011216 020227 000200
1313 011222 003750
1314 011224 000403
1315 011226 020227 000176 25$:
1316 011232 003744
1317 011234 005703 27$:
1318 011236 001402
1319 011240 000241
1320 011242 000401
1321 011244 000261 30$:
1322 011246 000207 50$:
1323
1324
    
```

TSV3 - GLOBAL AREAS MACRO M1113 01-FEB-84 18:55
 CKMSG - COMPARE WRITE CHAR. MESSAGE BUFFERS

SEQ 047

```

1325                                     .SBTTL CKMSG - COMPARE WRITE CHAR. MESSAGE BUFFERS
1326                                     ;+
1327                                     ;
1328                                     ;ROUTINE TO COMPARE A WRITE CHARACTERISTICS EXPD AND RECV
1329                                     ;BUFFER. THE EXPECTED AND RECEIVED BUFFERS ARE STORED FOR
1330                                     ;ERROR PRINT ROUTINES.
1331                                     ;
1332                                     ;INPUT:
1333                                     ;
1334                                     ;      R0      RECV MESSAGE BUFFER HIGH ORDER ADDRESS
1335                                     ;      R1      RECV MESSAGE BUFFER LOW ORDER ADDRESS
1336                                     ;      R2      EXPD MESSAGE BUFFER ADDRESS
1337                                     ;OUTPUT:
1338                                     ;
1339                                     ;      CARRY   SET - MESSAGE BUFFERS MATCH
1340                                     ;      CLR     -MESSAGE BUFFERS DON'T MATCH
1341                                     ;
1342                                     ;IMPLICIT OUTPUT:
1343                                     ;
1344                                     ;      EXPMSG   BUFFER IS SET TO EXPD DATA
1345                                     ;      RECMMSG  BUFFER IS SET TO RECV DATA
1346                                     ;      RCVHIADD SET TO HIGH ORDER ADDRESS OF RECV
1347                                     ;      RCVLOADD SET TO LOW ORDER ADDRESS OF RECV
1348                                     ;
1349                                     ;-
1350 011250 CKMSG:;
1351 011250 SAVREG      ;SAVE R1-R5 UNTIL NEXT RETURN
1352 011254 010037 002276' MOV      R0,RCVHIADD ;SAVE RECV HIGH ADDRESS
1353 011260 010137 002300' MOV      R1,RCVLOAD ;SAVE RECV LOW ADDRESS
1354 011264 005737 003126' TST     KTENABLE    ;TESTING ABOVE 28K?
1355 011270 001403 BEQ      10$        ;BR IF NO
1356 011272 004737 017210' JSR     PC,SETMAP   ;RETURN ADDRESS BIASED TO PAR6 IN R0
1357 011276 010001 MOV      R0,R1      ;GET RETURNED ADDRESS BIASED TO PAR6
1358 011300 005004 10$: CLR     R4          ;WORD IN BUFFER
1359 011302 005003 CLR     R3          ;CLEAR ERROR SEEN FLAG
1360 011304 010205 MOV      R2,R5      ;GET EXPD BUFFER ADDRESS
1361 011306 011264 002314' MOV      (R2),EXPMSG(R4) ;SAVE EXPD FOR ERROR REPORT
1362 011312 011164 002460' MOV      (R1),RECMMSG(R4) ;SAVE RECV FOR ERROR REPORT
1363 011316 022221 CMP      (R2)+,(R1)+ ;EXPD EQUAL RECV?
1364 011320 001401 BEQ      25$        ;BR IF YES
1365 011322 005203 INC     R3          ;SET ERROR SEEN FLAG
1366 011324 062704 000002 25$: ADD    #2,R4        ;POINT TO NEXT WORD ADDRESS
1367 011330 020407 000014 CMP     R4,#14     ;DONE FIRST 7 WORDS?
1368 011334 003764 BLE     15$        ;BR IF NO
1369 011336 032765 000200 000012 BIT     #X2,EXTF,XST2(R5) ;IS EXTENDED FEATURES SET IN EXPD?
1370 011344 001403 BEQ      50$        ;BR IF NO
1371 011346 020427 000016 CMP     R4,#16     ;DONE EXTENDED FEATURES WORD?
1372 011352 003755 BLE     15$        ;BR IF NO
1373 011354 005703 50$: TST     R3          ;ANY ERRORS SEEN?
1374 011356 001402 BEQ      55$        ;BR IF NO
1375 011360 000241 CLC     ;SET FAILURE
1376 011362 000401 BR      60$        ;
1377 011364 000261 55$: SEC     ;SET SUCCESS
1378 011366 000207 60$: RTS     PC          ;RETURN
1379
1380
1381                                     .SBTTL CKMSG2 - COMPARE EXPD RECV MESSAGE BUFFERS

```

```

1362
1387
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408 011370
1409 011370
1410 011374 020327 000144
1411 011400 003412
1412 011402 012703 000144
1413 011406
      011406 012746 011522'
      011412 012746 000001
      011416 010600
      011420 104417
      011422 062706 000004
1414 011426 010037 002276'
1415 011432 010137 002300'
1416 011436 005737 003126'
1417 011442 001403
1418 011444 004737 017210'
1419 011450 0100C1
1420 011452 005004
1421 011454 005005
1422 011456 111264 002314'
1423 011462 111164 002460'
1424 011466 122221
1425 011470 001401
1426 011472 005205
1427 011474 062704 000001
1428 011500 020403
1429 011502 002001
1430 011504 000764
1431 011506 005705
1432 011510 001402
1433 011512 000241
  ;
  ;
  ;ROUTINE TO COMPARE AN EXPECTED AND RECEIVED MESSAGE
  ;BUFFER. THE EXPECTED AND RECEIVED BUFFERS ARE STORED FOR
  ;ERROR PRINT ROUTINES.
  ;
  ;INPUT:
  ;
  ;      R0      RECV MESSAGE BUFFER HIGH ORDER ADDRESS
  ;      R1      RECV MESSAGE BUFFER LOW ORDER ADDRESS
  ;      R2      EXPD MESSAGE BUFFER ADDRESS
  ;      R3      NUMBER OF BYTES TO COMPARE
  ;
  ;OUTPUT:
  ;
  ;      CARRY   SET - MESSAGE BUFFERS MATCH
  ;             CLR - MESSAGE BUFFERS DON'T MATCH
  ;
  ;IMPLICIT OUTPUT:
  ;
  ;      EXPMSG  BUFFER IS SET TO EXPD DATA
  ;      RECVMSG BUFFER IS SET TO RECV DATA
  ;      RCVHIADD SET TO HIGH ORDER ADDRESS OF RECV
  ;      RCVLOADD SET TO LOW ORDER ADDRESS OF RECV
  ;
  ;-
  CKMSG2::
  SAVREG                                ;SAVE R1-R5 UNTIL NEXT RETURN
  CMP  R3, #RECVMSG-EXPMSG, #000        ;R3 IS COUNT ABOVE MAX ALLOWED?
  5$:  BLE  5$                               ;BR IF NO
  MOV  #RECVMSG-EXPMSG, R3, #000
  PRINTF #DEBUGMSG                      ;000
  MOV  #DEBUGMSG, -(SP)
  MOV  #1, -(SP)
  MOV  SP, R0
  TRAP C#PNTF
  ADD  #4, SP
  5$:  MOV  R0, RCVHIADD                    ;SAVE RECV HIGH ADDRESS
  MOV  R1, RCVLOADD                       ;SAVE RECV LOW ADDRESS
  TST  #KTENABLE                          ;TESTING ABOVE 20K?
  BEQ  10$                                ;BR IF NO
  JSR  PC, SETMAP                          ;RETURN ADDRESS BIASED TO PAR6 IN RC
  MOV  R0, R1                              ;GET RETURNED ADDRESS BIASED TO PAR6
  10$: CLR  R4                              ;WORD IN BUFFER
  CLR  R5                                  ;CLEAR ERROR SEEN FLAG
  15$: MOVB (R2), EXPMSG(R4)                ;SAVE EXPD FOR ERROR REPORT
  MOVB (R1), RECVMSG(R4)                  ;SAVE RECV FOR ERROR REPORT
  CMPB (R2)+, (R1)+                        ;EXPD EQUAL RECV?
  BEQ  25$                                ;BR IF YES
  INC  R5                                  ;SET ERROR SEEN FLAG
  25$: ADD  #1, R4                          ;POINT TO NEXT BYTE
  CMP  R4, R3                              ;DONE ALL BYTES?
  BGE  50$                                ;BR IF YES
  BR  15$                                  ;DO NEXT BYTE
  50$: TST  R5                              ;ANY ERRORS SEEN?
  BEQ  55$                                ;BR IF NO
  CLC                                     ;SET FAILURE
  
```


TSV3 - GLOBAL AREAS MACRO M1113 01-FEB-84 18:55
 CKMSG2 - COMPARE EXPD RECV MESSAGE BUFFERS

SEQ 049

```

1434 011514 000401          BR      60$          ;
1435 011516 000261          55$: SEC          ;SET SUCCESS
1436 011520 000207          60$: RTS         PC          ;RETURN
1437
1438 011522      120      122      117 DEBUGMSG: .ASCIZ 'PROGRAM INTERNAL ERROR -CKMSG2 MESSAGE BUFFER EXCEEDED-' ;000
1439 011612      045      116      045 FERCM: .ASCII /NMA ***/
1440 011623      040      040      124 ERCM: .ASCIZ / TSSR ERROR CODE REC'D * /
1441 011656      056      056      056 SIMSG: .ASCIZ /... AFTER DOING SOFT INIT?
1442 011711      124      105      123 TINERR: .ASCIZ /TEST: .../
1443
1444
1445
1446
1447
1448 ;PRINT ROUTINE TO FATAL SOFT INIT ERRORS
1449 ;
1450 ;INPUT:
1451 ;
1452 ; R1      CONTENTS OF TSSR AT ERROR
1453 ;
1454 ;SIDE EFFECTS:
1455 ;
1456 ; EXECUTES DROP UNIT TO CEASE TESTING
1457 ;
1458 ;-
1459
1460 011724          BGNMSG SFIMSG
1461 011724          SFIMSG: ;
1462 011730 004737 005632' JSR PC,PRITSSR ;PRINT CONTENTS OF TSSR REGISTER
1463 011730 004737 017074' JSR PC,CKDROP ;DROP UNIT, IF ALLOWED
1464 011734          ENDMMSG
1465 011734          L10003:
1466 011734 104423    TRAP C$MSG
1467
1468 ;PRINT ROUTINE TO PRINT THE CONTENTS OF
1469 ;TSSR AND A COMMAND PACKET OTHER THAN GET STATUS COMMAND PACKET.
1470 ;
1471 ;INPUTS:
1472 ;
1473 ; R1      TSSR CONTENTS
1474 ; R4      ADDRESS OF COMMAND PACKET
1475 ;-
1476 011736          BGNMSG PKTSSR
1477 011736          PKTSSR: ;
1478 011736 004737 005632' JSR PC,PRITSSR ;PRINT THE CONTENTS OF TSSR REGISTER
1479 011742 012700 000004 MOV #4,R0 ;NO. OF WORDS IN PACKET
1480 011746 004737 007260' JSR PC,PRIPKT ;PRINT THE CONTENTS OF COMMAND PACKET
1481 011752          ENDMMSG
1482 011752          L10004:
1483 011752 104423    TRAP C$MSG
1484
1485 ;PRINT ROUTINE TO PRINT THE CONTENTS OF
1486 ;TSSR AND A GET STATUS COMMAND PACKET.

```

CKMSG2 - COMPARE EXPD RECV MESSAGE BUFFERS

```

1485
1486
1487
1488
1489
1490
1491
1492
1493 011754
      011754
1494 011754 004737 005632'
1495 011760 012700 000002
1496 011764 004737 007260'
1497 011770
      011770
      011770 104423
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507
1508
1509 011772
      011772
1510 011772 004737 005632'
1511 011776
      011776
      011776 104423
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522
1523
1524
1525
1526
1527 012000
      012000
1528 012000 004737 005632'
1529 012004 010200
1530 012006 010301
1531 012010 004737 014132'
1532 012014
      012014
      012014 104423

;
; INPUTS:
;
; R1      TSSR CONTENTS
; R4      ADDRESS OF COMMAND PACKET
;
;
; BGNMSG   PKTGETS
PKTGETS:
; JSR      PC,PRITSSR      ;PRINT THE CONTENTS OF TSSR REGISTER
; MOV      #2,R0           ;NO. OF WORDS IN GET STATUS PACKET
; JSR      PC,PRIPKT       ;PRINT THE CONTENTS OF COMMAND PACKET
; ENDMMSG
L10005:
; TRAP     C$MSG

;+
;PRINT TSSR ERRORS FOR INITIALIZATION TESTS
;
; INPUTS:
;
; R1      TSSR CONTENTS
; R4      ADDRESS OF COMMAND PACKET
;
;
; BGNMSG   SFFMSG
SFFMSG:
; JSR      PC,PRITSSR      ;PRINT CONTENTS OF TSSR REGISTER
; ENDMMSG
L10006:
; TRAP     C$MSG

;SBTTL   PKTMES - PRINT TSSR AND MESSAGE BUFFER
;+
;PRINT ROUTINE TO PRINT THE CONTENTS OF TSSR AND MESSAGE
;BUFFER FOR ERROR REPORTS
;
; INPUTS:
;
; R1      CONTENTS OF TSSR
; R2      LOW ORDER MESSAGE BUFFER
; R3      HIGH ORDER MESSAGE BUFFER ADDRESS
; NOTE: R3 IS IGNORED IF KTENABLE FLAG IS CLEAR
;
; BGNMSG   PKTMES
PKTMES:
; JSR      PC,PRITSSR      ;PRINT CONTENTS OF TSSR
; MOV      R2,R0           ;LOW ORDER ADDRESS
; MOV      R3,R1           ;HIGH ORDER ADDRESS
; JSR      PC,PRMESS       ;PRINT THE MESSAGE BUFFER
; ENDMMSG
L10007:
; TRAP     C$MSG

```

```

1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547 012016
      012016
1548 012016 004737 010164'
1549 012022 016501 000002
1550 012026 004737 005632'
1551 012032
      012032
      012032 104423
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563
1564
1565
1566 012034
      012034
1567 012034 012700 000007
1568 012040 005737 002220'
1569 012044 001402
1570 012046 012700 000010
1571 012052 004737 014442'
1572 012056
      012056
      012056 104423
1573
1574
1575
1576
1577
1578
1579
1580
1581
1582
1583

```

```

      .SBTTL  ADDSSR  - PRINT TEST ADDRESS AND TSSR
;
;PRINT ROUTINE TO PRINT THE CONTENTS OF
;TSSR AND A MEMORY TEST ADDRESS
;
;INPUTS:
;
;      R5      FIRST DEVICE UNIBUS ADDRESS
;      ERRHI   HIGH ORDER MEMORY TEST ADDRESS
;      ERRLO   LOW ORDER MEMORY TEST ADDRESS
;-
      BGNMSG  ADDSSR
ADDSSR:
      JSR     PC,PRITADD      ;PRINT MEMORY TEST ADDRESS
      MOV     TSSR(R5),R1    ;GET CURRENT TSSR
      JSR     PC,PRITSSR     ;PRINT THE CONTENTS OF TSSR REGISTER
      ENDMSG
L10010:
      TRAP   C$MSG

      .SBTTL  MSGEXP - PRINT WRITE CHAR. EXPD-RCV MESSAGE BUFFERS
;
;PRINT ROUTINE TO PRINT WRITE CHARACTERISTIC MESSAGE BUFFER
;
;IMPLICIT INPUTS:
;
;      EXPMSG  - EXPECTED MESSAGE BUFFER
;      RECMSG  - RECEIVED MESSAGE BUFFER
;      RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
;      RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
;-
      BGNMSG  MSGEXP
MSGEXP:
      MOV     #7,R0          ;ASSUME NO EXT FEATURES
      TST     EXTFEA        ;EXT FEATURES SET?
      BEQ     5$            ;BR IF NO
      MOV     #8.,R0       ;EXT FEATURE BUFFER IS 8 WORDS
      JSR     PC,PRMSGEXP   ;PRINT EXPD/RCV MESSAGE BUFFERS
      ENDMSG
5$:
L10011:
      TRAP   C$MSG

      .SBTTL  FIFEXP - PRINT FIFO EXP/RCV DATA
;
;PRINT ROUTINE TO PRINT FIFO EXP/RCV DATA
;
;      R1      - BYT: COUNT
;
;IMPLICIT INPUTS:
;
;      EXPMSG  - EXPECTED MESSAGE BUFFER (CONTAINS FIFO DATA ONLY

```

```

1584      ;      RECMMSG - RECEIVED MESSAGE BUFFER (CONTAINS FIFO DATA ONLY)
1585      ; -
1586 012060      BGNMSG FIFEXP
1587 012060      FIFEXP::
1587 012060 010146      PRINTX #FIF1MSG,R1      ;PRINT BYTES TRANSFERRED
1587 012062 012746 012132      MOV R1,-(SP)
1587 012066 012746 000002      MOV #FIF1MSG,-(SP)
1587 012072 010600      MOV #2,-(SP)
1587 012074 104415      MOV SP,R0
1587 012076 062706 000006      TRAP C$PNTX
1588 012102      ADD #6,SP
1588 012102 012746 012201'      PRINTX #FIF2MSG      ;PRINT HEADER MSG
1588 012106 012746 000001      MOV #FIF2MSG,-(SP)
1588 012112 010600      MOV #1,-(SP)
1588 012114 104415      MOV SP,R0
1588 012116 062706 000004      TRAP C$PNTX
1589 012122 010100      ADD #4,SP
1590 012124 004737 015012'      MOV R1,R0      ;GET BYTE COUNT
1591 012130      JSR PC,PRBYTEXP      ;PRINT FIFO BYTES IN ERROR
1591 012130      ENDMSG
1591 012130 104423      L10012:
1592 012132 045 116 045 FIF1MSG:      TRAP C$MSG
1593 012201 045 116 045 FIF2MSG:      .ASCIZ 'NWA NUMBER OF BYTES TRANSFERRED = D2'
1594      .EVEN
1595      .ASCIZ 'NWA FIFO DATA BYTES IN ERROR:'
1596      .SBTTL MSGSTAT - PRINT STATUS HEADER AND MESSAGE BUFFERS
1597      ;*
1598      ;
1599      ;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RECV
1600      ;
1601      ;
1602      ;IMPLICIT INPUTS:
1603      ;
1604      ;      EXPMSG - EXPECTED MESSAGE BUFFER
1605      ;      RECMMSG - RECEIVED MESSAGE BUFFER
1606      ;      RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
1607      ;      RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
1608      ; -
1609 012240      BGNMSG MSGSTAT
1610 012240      MSGSTAT::
1610 012240 012701 012302'      MOV #STATCOD,R1      ;ASCII ADDRESS TABLE
1611 012244 012100      MOV (R1)+,R0      ;DONE ALL MSG LINES?
1612 012246 001410      BEQ 20$      ;BR IF YES
1613 012250      PRINTX R0      ;PRINT STATUS BIT NAMES
1613 012250 0100'6      MOV R0,-(SP)
1613 012252 012746 000001      MOV #1,-(SP)
1613 012256 010600      MOV SP,R0
1613 012260 104415      TRAP C$PNTX
1613 012262 062706 000004      ADD #4,SP
1614 012266 000766      BR 10$
1615 012270 012700 000012      20$: MOV #10,R0      ;DO ANOTHER MSG LINE
1616 012274 004737 014442'      JSR PC,PRMSGEXP      ;NUMBER OF WORDS IN A READ STATUS BUFFER
1617 012300      ENDMSG      ;PRINT EXPD/RECV MESSAGE BUFFERS
1617 012300      L10^ 5:
1618 012300 104423      TRAP C$MSG
  
```

```

1619 012302 012320' 012362' 012453' STATCOD: .WORD 1#,2#,3#,4#,5#,6#,0
1620 012320 045 116 045 1#:.ASCIZ '#N#A Tape Bus Signals in Word #8:'
1621 012362 045 116 045 2#:.ASCIZ '#N#A PARERR<15> IEOT <12> IFMK <9> IRDY<6> IRWD<2>'
1622 012453 045 116 045 3#:.ASCIZ '#N#A IRESV2<14> IIDENT<11> IHER <8> IONL<5> IFBY<1>'
1623 012544 045 116 045 4#:.ASCIZ '#N#A IRESV1<13> ICER <10> ISPEED<7> ILDP<4> IFPT<0>'
1624 012635 045 116 045 5#:.ASCIZ '#N#A Tape Bus Signals in Word #9:'
1625 012677 045 116 045 6#:.ASCIZ '#N#A DATMIS<7> ILW<6> OUTRDY<5> INRDY<4>'
1626
1627
1628
1629

```

.SBTTL MSGLOOP - PRINT LOOPBACK HEADER AND MESSAGE BUFFERS

```

1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641
1642 012754
012754
1643 012754 012701 013016'
1644 012760 012100
1645 012762 001410
1646 012764
012764 010046
012766 012746 000001
012772 010600
012774 104415
012776 062706 000004
1647 013002 000766
1648 013004 012700 000012
1649 013010 004737 014442'
1650 013014
013014
013014 104423
1651

```

```

;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RCV
;IMPLICIT INPUTS:
;
; EXPMSG - EXPECTED MESSAGE BUFFER
; RECMSG - RECEIVED MESSAGE BUFFER
; RCVHIADD - RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
; RCVLOADD - RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
;
;
; BGNMSG MSGLOOP
MSGLOOP:
10#: MOV #LOOPCOD,R1 ;ASCII ADDRESS TABLE
MOV (R1),R0 ;DONE ALL MSG LINES?
REQ 20# ;BR IF YES
PRINTX R0 ;PRINT STATUS BIT NAMES
MOV R0,-(SP)
MOV #1,-(SP)
MOV SP,R0
TRAP C#PNTX
ADD #4,SP
BR 10# ;DO ANOTHER MSG LINE
20#: MOV #10,,R0 ;NUMBER OF WORDS IN A READ STATUS BUFFER
JSR PC,PRMSGEXP ;PRINT EXPD/RCV MESSAGE BUFFERS
ENDMSG
L1001': TRAP C#MSG

```

```

1652 013016 013036' 013111' 013210' LOOPCOD: .WORD 1#,2#,3#,4#,5#,6#,7#,0
1653 013036 045 116 045 1#:.ASCIZ '#N#A Tape Bus Loopback Signals in Word #8:'
1654 013111 045 116 045 2#:.ASCIZ '#N#A PARERR<15> IRESV2<14> IRESV1<13>'
1655 013210 045 116 045 3#:.ASCIZ '#N#A IHISP->IEOT<12> IWRT->IIDENT<11> IREV->ICER <10>'
1656 013307 045 116 045 4#:.ASCIZ '#N#A IWFM->IFMK<9> IEDIT->IHER <8> IFAD->ISPEED<7>'
1657 013406 045 116 045 5#:.ASCIZ '#N#A ITADO->IRDY<6> ITAD1->IONL <5> IERASE->ILDP <4>'
1658 013505 045 116 045 6#:.ASCIZ '#N#A IREW->IDBY<3> IRWU->IRWD <2> IFEN->IFBY <1>'
1659 013604 045 116 045 7#:.ASCIZ '#N#A IGO->IFPT<0>'
1660
1661
1662
1663
1664
1665
1666
1667

```

.SBTTL MSGSUB - PRINT WRITE SUBSYSTEM MESSAGE BUFFER

```

;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RCV
;

```

```

1668
1669
1670
1671
1672
1673
1674
1675 013632
      013632
1676 013632 012700 000012
1677 013636 004737 014442'
1678 013642
      013642
      013642 104423
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696 013644
      013644
1697 013644 004737 010050'
1698 013650 013701 002224'
1699 013654 013702 002226'
1700 013660 004737 007632'
1701 013664
      013664
      013664 104423
1702
1703
1704
1705
1706
1707
1708
1709
1710
1711
1712
1713
1714
1715
1716
1717
1718
  
```

```

;IMPLICIT INPUTS:
;
;   EXPMSG - EXPECTED MESSAGE BUFFER
;   RECMSG - RECEIVED MESSAGE BUFFER
;   RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
;   RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
;
;
;   DGNMSG MSGSUB
MSGSUB::
;   MOV     #10.,R0      ;SIZE OF WRITE SUBSYSTEM BUFFER
;   JSR     PC,PRMSGEXP  ;PRINT EXPD/RCV MESSAGE BUFFERS
;   ENDMSG
L10015:
;   TRAP    C#MSG

;
;   .SBTTL  MEMADD - PRINT MEMORY ADDRESS DATA ERROR
;
;PRINT ROUTINE TO PRINT MEMORY ADDRESS DATA COMPARE ERROR
;IMPLICIT INPUTS:
;
;   ERRHI - MEMORY ERROR HIGH ORDER ADDRESS
;   ERRLO - MEMORY ERROR LOW ORDER ADDRESS
;   EXP   - EXPECTED DATA
;   RECV  - RECEIVED DATA
;
;
;   BGNMSG MEMADD
MEMADD::
;   JSR     PC,PRIADD    ;PRINT MEMORY ADDRESS IN ERROR
;   MOV     EXPD,R1      ;GET EXPD DATA
;   MOV     RECV,R2      ;GET RECEIVED DATA
;   JSR     PC,PRI XOR   ;PRINT EXPD/RCV
;   ENDMSG
L10016:
;   TRAP    C#MSG

;
;   .SBTTL  PRAMPKT - PRINT RAM AND PACKET DATA
;
;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
;WHEN THE RAM DATA DOES NOT MATCH.
;
;INPUTS:
;
;   R4     POINTER TO COMMAND PACKET
;
;IMPLICIT INPUTS:
;
;   RAMDATA DATA AS READ FROM THE RAM
;   RAMSIZ  NUMBER OF BYTES IN PACKET
;           IF RAMSIZ=0 THEN DEFAULT TO 8.
;
  
```

```

1719 ; IMPLICIT OUTPUTS:
1720 ;
1721 ; RAMSIZ SET TO 0
1722 ;
1723 ;
1724 013666 PRAHPKT:
1725 013666 SAVREG ; SAVE R1-R5 UNTIL NEXT RETURN
1726 013672 012701 002234' MOV #RAMDATA,R1 ; DATA FROM THE RAM
1727 013675 005002 CLR R2 ; INIT BYTE NUMBER
1728 013700 122124 5$: CMPB (R1)+,(R4)+ ; COMPARE EXPECTED, RECEIVED
1729 013702 C01005 BNE 7$ ; BR IF NO MATCH
1730 013704 FORCERROR 7$,NOTSSR
1731 013714 000436 BR 10$ ; 800
1732 013716 116105 177777 7$: MOVB -1(R1),R5 ; GET RECV RAM DATA
1733 013722 116403 177777 MOVB -1(R4),R3 ; GET EXPD PACKET DATA
1734 013726 XOR R5,R3 ; XOR EXPD/RECV
1735 013736 042703 177400 BIC #177400,R3 ; LOW BYTE ONLY
1736 013742 116137 177777 002226' MOVB -1(R1),RECV ; GET RECEIVED RAM DATA
1737 013750 116437 177777 002224' MOVB -1(R4),EXPD ; GET EXPECTED RAM DATA
1738 013756 PRINTB #RAMASC,R2,RECV,EXPD,R3
013756 010346 MOV R3,-(SP)
013760 013746 002224' MOV EXPD,-(SP)
013764 013746 002226' MOV RECV,-(SP)
013770 010246 MOV R2,-(SP)
013772 012746 014046' MOV #RAMASC,-(SP)
013776 012746 000005 MOV #5,-(SP)
014002 010600 MOV SP,R0
014004 104414 TRAP C:PNTB
014006 062706 000014 ADD #14,SP
1739 014012 005202 10$: INC R2 ; UPDATE BYTE COUNT
1740 014014 005737 002274' TST RAMSIZ ; DEFAULT TO 8.?
1741 014020 001404 BEQ 15$ ; BR IF YES
1742 014022 020237 002274' CMP R2,RAMSIZ ; DONE ALL BYTES?
1743 014026 003724 BLE 5$ ; BR IF NO
1744 014030 000403 BR 25$ ;
1745 014032 020227 000010 15$: CMP R2,#8. ; DONE DEFAULT NUMBER OF BYTES?
1746 014036 002720 20$: BLT 5$ ; BR IF NO
1747 014040 005037 002274' 25$: CLR RAMSIZ ; SET DEFAULT RAMSIZ
1748 014044 000207 RTS PC ; RETURN
1749
1750 014046 045 116 045 RAMASC: .ASCIZ '#N#A BYTE: #D2#A RAM: #03#A Packet: #03#A XOR:#03'
1751 .EVEN
1752
1753 ;.SBTTL PRMESS - PRINT CONTENTS OF MESSAGE BUFFER
1754
1755 ;
1756 ; THIS ROUTINE PRINTS THE CONTENTS OF
1757 ; THE 7 OR 8 WORD MESSAGE BUFFER RETURNED BY THE
1758 ; TSV-05.
1759 ;
1760 ; INPUT:
1761 ;
1762 ; R0 LOW ORDER ADDRESS OF MESSAGE BUFFER
1763 ; R1 HIGH ORDER ADDRESS OF MESSAGE BUFFER
1764 ; NOTE: R1 IS IGNORED IF KTENABLE FLAG IS CLEAR
1765 ;
1766 ; THIS ROUTINE IS NORMALLY CALLED FROM A PRINT ROUTINE

```

```

1767 ;
1768 ;
1769 ;
1770 014132 PRMESS: SAVREG ;SAVE THE REGISTERS
1771 014132 MOV R0,R5 ;SAVE LOW ORDER ADDRESS
1772 014136 010005 TST KTENABLE ;ADDRESS ABOVE 28K?
1773 014140 005737 003126' BNE 10$ ;BR IF YES
1774 014144 001001 CLR R1 ;SET HIGH ORDER ADDRESS TO 0
1775 014146 005001 10$: MOV R1,R3 ;SAVE HIGH ORDER ADDRESS
1776 014150 010103 ROL R0 ;SHIFT BIT15 TO C BI
1777 014152 006100 ROL R1 ;SHIFT TO HIGH ORDER FOR PRINTOUT
1778 014154 006101 PRINTX @PROASC,R1,R5 ;PRINT MESSAGE BUFFER ADDRESS
1779 014156 010546 MOV R5,-(SP)
014160 010146 MOV R1,-(SP)
014162 012746 014310' MOV @PROASC,-(SP)
014166 012746 000003 MOV @3,-(SP)
014172 010600 MOV SP,R0
014174 104415 TRAP C:PNTX
014176 062706 000010 ADD @10,SP
1780 014202 PRINTX @PR1ASC ;PRINT HEADER FOR CONTENTS
014202 012746 014355' MOV @PR1ASC,-(SP)
014206 012746 000001 MOV @1,-(SP)
014212 010600 MOV SP,R0
014214 104415 TRAP C:PNTX
014216 062706 000004 ADD @4,SP
1781 014222 005004 CLR R4 ;NUMBER OF THE NEXT WORD
1782 014224 010501 MOV R5,R1 ;COPY LOW ORDER ADDRESS
1783 014226 010300 MOV R3,R0 ;COPY HIGH ORDER ADDRESS
1784 014230 001403 BEQ 20$ ;BR IF NOT ABOVE 28K
1785 014232 004737 017210' JSR PC,SETMAP ;SETUP PAR ADDRESS IN R0
1786 014236 010005 MOV R0,R5 ;GET PAR FORMAT ADDRESS ABOVE 28K
1787 014240 20$: PRINTX @PRASC,R4,(R5)+ ;PRINT THE CONTENTS OF MEMORY BUFFER
014240 012546 MOV (R5)+,-(SP)
014242 010446 MOV R4,-(SP)
014244 012746 014413' MOV @PRASC,-(SP)
014250 012746 000003 MOV @3,-(SP)
014254 010600 MOV SP,R0
014256 104415 TRAP C:PNTX
014260 062706 000010 ADD @10,SP
1788 014264 005204 INC R4 ;NUMBER OF THE NEXT
1789 014266 020427 000007 CMP R4,@7 ;DONE ALL YET ?
1790 014272 003005 BGT 50$ ;BRANCH IF ALL DONE
1791 014274 002761 BLT 20$ ;PRINT FIRST 7 WORDS
1792 014276 032763 000200 000012 BIT @X2,EXTF,XST2(R3);EXTENDED FEATUTES ON ?
1793 014304 001355 BNE 20$ ;PRINT EXTENDED STATUS WORD
1794 014306 000207 50$: RTS PC ;RETURN
1795
1796 014310 045 116 045 PROASC: .ASCIZ 'NNA Message Buffer Address * %01%05'
1797 014355 045 116 045 PR1ASC: .ASCIZ 'NNA Message Buffer Contents:'
1798 014413 045 116 045 PRASC: .ASCIZ 'NNA Word%D1%A: %0'
1799 .EVEN
1800
1801 .SBTTL PRMSGEXP - PRINT EXPD/RECV MESSAGE BUFFERS
1802 ;
1803 ;
1804 ;ROUTINE TO PRINT EXPECTED AND RECEIVED MESSAGE BUFFERS

```



```

1805
1806      ;      RO      - NUMBER OF WORDS IN BUFFER
1807
1808      ;IMPLICIT INPUTS:
1809
1810      ;      EXPMSG  - EXPECTED MESSAGE BUFFER
1811      ;      RECMMSG - RECEIVED MESSAGE BUFFER
1812      ;      RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
1813      ;      RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
1814
1815      PRMSGEXP::
1816      SAVREG      ;SAVE R1-R5 UNTIL NEXT RETURN
1817      MOV        RO,R5      ;SAVE NUMBER OF WORDS
1818      MOV        RCVLOADD,RO ;GET RECV LOW ADDRESS
1819      MOV        RO,R4      ;COPY LOW ADDRESS
1820      MOV        RCVHIADD,R1 ;GET RECV HIGH ADDRESS
1821      ROL        RO
1822      ROL        R1      ;SHIFT BIT15 TO C BIT
1823      PRINTX    @PRMSG0,R1,R4 ;PRINT MESSAGE BUFFER ADDRESS
1824      MOV        R4,-(SP)
1825      MOV        R1,-(SP)
1826      MOV        @PRMSG0,-(SP)
1827      MOV        @3,-(SP)
1828      MOV        SP,RO
1829      TRAP      C@PNTX
1830      ADD        @10,SP
1831      PRINTX    @PRMSG1      ;PRINT HEADER FOR CONTENTS
1832      MOV        @PRMSG1,-(SP)
1833      MOV        @1,-(SP)
1834      MOV        SP,RO
1835      TRAP      C@PNTX
1836      ADD        @4,SP
1837      CLR        R4      ;NUMBER OF THE CURRENT WORD
1838      MOV        @EXPMSG,R1 ;GET EXPD BUFFER ADDRESS
1839      MOV        @RECMMSG,R2 ;GET RECV BUFFER ADDRESS
1840      MOV        (R1),R0 ;GET EXPD
1841      MOV        (R2),R3 ;GET RECV
1842      XOR        RO,R3 ;XOR EXPD/RCV
1843      PRINTX    @PRMSG2,R4,(R1)+,(R2)+,R3
1844      MOV        R3,-(SP)
1845      MOV        (R2)+,-(SP)
1846      MOV        (R1)+,-(SP)
1847      MOV        R4,-(SP)
1848      MOV        @PRMSG2,-(SP)
1849      MOV        @5,-(SP)
1850      MOV        SP,RO
1851      TRAP      C@PNTX
1852      ADD        @14,SP
1853      INC        R4      ;NUMBER OF THE NEXT
1854      CMP        R4,R5 ;DONE ALL YET?
1855      BGE        50$ ;BR IF YES
1856      BR         20$ ;DO ANOTHER
1857      BR         50$ ;RETURN
1858      RTS        PC
1859
1860      20$:
1861      MOV        @PRMSG0,:ASCIZ '##A Message Buffer Address = #01#05'
1862      MOV        @PRMSG1,:ASCIZ '##A Message Buffer Contents:'
1863      MOV        @PRMSG2,:ASCIZ '##A WORD #02#A EXPD: #06#A RECV: #06#A XOR: #06#'
    
```

```

1841 .EVEN
1842
1843 .SBTTL PRBYTEXP - PRINT ERROR BYTES IN EXP/REC MESSAGE BUFFER
1844 ;+
1845 ;
1846 ;ROUTINE TO PRINT ERROR BYTES IN MESSAGE BUFFERS
1847 ; ONLY THE FIRST 8 ERRORS ENCOUNTERED ARE PRINTED DUE TO SCREEN SPACE
1848 ;
1849 ; R0 - NUMBER OF BYTES IN BUFFER
1850 ;
1851 ;IMPLICIT INPUTS:
1852 ;
1853 ; EXPMSG - EXPECTED MESSAGE BUFFER
1854 ; RECMMSG - RECEIVED MESSAGE BUFFER
1855 ;-
1856 015012 PRBYTEXP:;
1857 015012 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
1858 015016 010005 MOV R0,R5 ;SAVE NUMBER OF BYTES
1859 015020 005037 002312' CLR PRMNO ;INIT ERROR COUNT
1860 015024 005004 CLR R4 ;NUMBER OF THE CURRENT BYTE
1861 015026 012701 002314' MOV @EXPMSG,R1 ;GET EXPD BUFFER ADDRESS
1862 015032 012702 002460' MOV @RCMMSG,R2 ;GET RCV BUFFER ADDRESS
1863 015036 111100 20$: MOVB (R1),R0 ;GET EXPD BYTE
1864 015040 042700 177400 BIC @C<377>,R0 ;CLEAR UPPER BYTE
1865 015044 110037 015360' MOVB R0,PRBEXP ;SAVE FOR ERROR REPORT
1866 015050 111203 MOVB (R2),R3 ;GET RCV BYTE
1867 015052 042703 177400 BIC @C<377>,R3 ;CLEAR UPPER BYTE
1868 015056 110337 015362' MOVB R3,PRBREC ;FOR ERROR REPORT
1869 015062 XOR R0,R3 ;XOR EXPD/RCV
1870 015072 122122 CMPB (R1)+,(R2)+ ;EXPD = RCV?
1871 015074 001431 BEQ 30$ ;BR IF YES
1872 015076 005237 002312' INC PRMNO ;UPDATE ERROR COUNT
1873 015102 023727 002312' 000010 CMP PRMNO,#8. ;PRINTED 8?
1874 015110 101023 BHI 30$ ;BR IF YES
1875 015112 27$: PRINTX @PRBMSG,R4,PRBEXP,PRBREC,R3
015112 010346 MOV R3,-(SP)
015114 013746 015362' MOV PRBREC,-(SP)
015120 013746 015360' MOV PRBEXP,-(SP)
015124 010446 MOV R4,-(SP)
015126 012746 015226' MOV @PRBMSG,-(SP)
015132 012746 000005 MOV @5,-(SP)
015136 010600 MOV SP,R0
015140 174415 TRAP C:PNTX
015142 062706 000014 ADD @14,SP
1876 015146 FORCEEXIT 50$ ;000
1877 015156 000404 BR 35$ ;000
1878 015160 30$:
1879 015160 FORCERROR 27$,NOTSSR ;000
1880 015170 35$: ;000
1881 015170 005204 INC R4 ;NUMBER OF THE NEXT
1882 015172 020405 CMP R4,R5 ;DONE ALL YET?
1883 015174 002001 BGE 50$ ;BR IF YES
1884 015176 070717 BR 20$ ;DO ANOTHER
1885 015200 50$: PRINTX @PRBTOT,PRMNO ;PRINT TOTAL ERROR COUNT
015200 013746 002312' MOV PRMNO,-(SP)
015204 012746 015313' MOV @PRBTOT,-(SP)
015210 012746 000002 MOV @2,-(SP)

```

```

015214 010600      MOV      SP,RO
015216 104415      TRAP     C$PNTX
015220 062706 000006  ADD      #6,SP
1885 015224 000207      RTS      PC          ;RETURN
1887
1888 015226      045      116      045  PRBMSG: .ASCIZ  'N#A BYTE #D2#A EXPD: #03#A RECV: #03#A XOR: #03'
1889 015313      045      116      045  PRBTOT: .ASCIZ  'N#A NUMBER OF BYTES IN ERROR = #D2'
1890                      .EVEN
1891 015360 000000      PRBEXP: .WORD   0          ;EXPD
1892 015362 000000      PRBREC: .WORD   0          ;RECV
1893
1894                      .SBTTL  EXPREC - PRINT EXPD/RECV WORD DATA
1895                      ;*
1896                      ;
1897                      ;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
1898                      ;
1899                      ;INPUTS:
1900                      ;
1901                      ;      R1      RECEIVED DATA
1902                      ;      R2      EXPECTED DATA
1903                      ;
1904                      ;-
1905
1906 015364      BGNMSG  EXPREC
015364      EXPREC: ;
1907 015364 004737 007632'  JSR      PC,PRIXOR          ;PRINT THE DATA
1908 015370      ENDMSG
015370      L10017: TRAP     C$MSG
015370 104423
1909
1910
1911
1912
1913                      .SBTTL  EXPBREC - PRINT EXPD/RECV BYTE DATA
1914                      ;*
1915                      ;
1916                      ;PRINT ROUTINE TO DISPLAY BYTE EXPD/RECV DATA
1917                      ;
1918                      ;
1919                      ;INPUTS:
1920                      ;
1921                      ;      R1      RECEIVED DATA BYTE
1922                      ;      R2      EXPECTED DATA BYTE
1923                      ;
1924                      ;-
1925
1926 015372      BGNMSG  EXPBREC
015372      EXPBREC: ;
1927 015372 004737 007502'  JSR      PC,PRIBXOR          ;PRINT THE DATA
1928 015376      ENDMSG
015376      L10020: TRAP     C$MSG
015376 104423
1929
1930
1931
1932
1933                      .SBTTL  RAMERR - PRINT RAM AND PACKET DATA

```

```

1934
1935
1936
1937
1938
1939
1940
1941
1942
1943
1944
1945
1946
1947
1948
1949
1950
1951
1952
1953 015400
      015400
1954 015400 004737 013666'
1955 015404
      015404
      015404 104423
1956
1957
1958
1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980 015406
      015406
1981 015406 004737 010164'
1982 015412 004737 013666'
1983 015416
      015416
      015416 104423
1984
    
```

```

;+
;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
;
;INPUTS:
;
;      R4      POINTER TO COMMAND PACKET
;
;IMPLICIT INPUTS:
;
;      RAMDATA      DATA AS READ FROM THE RAM
;      RAMSIZ       NUMBER OF BYTES IN PACKET
;                  IF RAMSIZ=0 THEN DEFAULT TO 8.
;
;IMPLICIT OUTPUTS:
;
;      RAMSIZ      SET TO 0
;-
;
;      BGNMSG      RAMERR
RAMERR:: JSR      PC,PRAMPKT      ;PRINT RAM/PACKET DATA
          ENDMSG
L10021:  TRAP      C$MSG
;
;      .SBTTL      RAMT/CD - PRINT TEST ADDRESS, RAM AND PACKET DATA
;+
;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
;
;INPUTS:
;
;      R4      POINTER TO COMMAND PACKET
;
;IMPLICIT INPUTS:
;
;      RAMDATA      DATA AS READ FROM THE RAM
;      RAMSIZ       NUMBER OF BYTES IN PACKET
;                  IF RAMSIZ=0 THEN DEFAULT TO 8.
;      ERRHI        HIGH ORDER TEST ADDRESS
;      ERRLO        LOW ORDER TEST ADDRESS
;
;IMPLICIT OUTPUTS:
;
;      RAMSIZ      SET TO 0
;-
;
;      BGNMSG      RAMTADD
RAMTADD:: JSR      PC,PRITADD      ;PRINT TEST ADDRESS
          JSR      PC,PRAMPKT      ;PRINT RAM/PACKET DATA
          ENDMSG
L10022:  TRAP      C$MSG
    
```

1985										
1986										
1987										
1988										
1989										
1990										
1991										
1992										
1993										
1994										
1995										
1996										
1997										
1998	015420									
	015420									
1999	015420	042701	177400							
2000	015424	042702	177400							
2001	015430	004737	007756'							
2002	015434	004737	007632'							
2003	015440									
	015440									
	015440	104423								
2004										
2005										
2006										
2007										
2008										
2009										
2010										
2011										
2012										
2013										
2014										
2015										
2016										
2017	015442									
	015442									
2018	015442									
	015442	012746	015470'							
	015446	012746	000001							
	015452	010600								
	015454	104415								
	015456	062706	000004							
2019	015462	004737	007632'							
2020	015466									
	015466									
	015466	104423								
2021										
2022										
2023	015470	045	116	045	TIMSGO:	.ASCIZ	'#N#A TIMER A STATUS IS IN BIT 3#N#A TIMER B STATUS IS IN BIT 2'			
2024							.EVEN			
2025										
2026										
2027										
2028										
2029										
2030										

```

        .SBTTL  RAMEXP  - PRINT RAM EXPD/RECV DATA
;+
;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
;
;INPUTS:
;
;      R1      RECEIVED DATA
;      R2      EXPECTED DATA
;      R4      CONTROLLER RAM ADDRESS
;-

        BGNMSG  RAMEXP
RAMEXP:  BIC     @C<377>,R1          ;SAVE EXPD RAM DATA BYTE
        BIC     @C<377>,R2          ;SAVE EXPD RAM DATA BYTE
        JSR     PC,PRIRAM          ;PRINT THE RAM ADDRESS
        JSR     PC,PRIXOR          ;PRINT THE DATA
        ENDMSG

L10023:  TRAP    C#MSG

        .SBTTL  TIMEXP  - PRINT TIMER A,B AND EXP/REC
;+
;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
;AND TIMER A,B HEADER MESSAGE
;
;INPUTS:
;
;      R1      RECEIVED DATA
;      R2      EXPECTED DATA
;-

        BGNMSG  TIMEXP
TIMEXP:  PRINTX  @TIMSGO            ;PRINT HEADER
        MOV     @TIMSGO,-(SP)
        MOV     @1,-(SP)
        MOV     SP,R0
        TRAP   C#PNTX
        ADD     @4,SF
        JSR     PC,PRIXOR          ;PRINT THE DATA
        ENDMSG

L10024:  TRAP    C#MSG

        .SBTTL  BADSSR  - PRINT TSSR ERRORS ON DATA TRANSFERS
;+
;

```

```

2031 ;PRINT ROUTINE FOR TSSR ERRORS ON DATA TRANSFERS
2032 ;
2033 ;INPUTS:
2034 ;
2035 ;       R1       CONTENTS OF TSSR
2036 ;       R2       DATA WRITTEN (8 BITS)
2037 ;
2038 ;-
2039
2040          BGNMSG  BADSSR
2041          BADSSR:
015570          MOV     R2,-(SP)           ;SAVE DATA TRANSFERRED
015570          BIC     #177400,R2       ;GET JUST ONE BYTE
2041 015570 010246          PRINTB  #XFERASC,R2
2042 015572 042702 177400          MOV     R2,-(SP)
2043 015576          MOV     #XFERASC,-(SP)
015576 010246          MOV     #2,-(SP)
015600 012746 015630'          MOV     SP,R0
015604 012746 000002          TRAP   C#PNTB
015610 010600          ADD     #6,SP
015612 104414          MOV     (SP),R2           ;RESTORE R2
015614 062706 000006          JSR    PC,PRITSSR       ;DECODE TSSR CONTENTS
2044 015620 012602          ENDMMSG
2045 015622 004737 005632'
2046 015626
015626          L10025:
015626 104423          TRAP   C#MSG
2047 015630 045 116 045 XFERASC: .ASCIZ  'N/A Data Transferred = 03'
2048
2049
2050          .SBTTL  GLOBAL SUBROUTINES SECTION
2051
2052          ;++
2053          ; THE GLOBAL SUBROUTINES SECTION CONTAINS THE SUBROUTINES
2054          ; THAT ARE USED IN MORE THAN ONE TEST.
2055          ;--
2056
2057          .SBTTL  SOFINIT - SOFT INITIALIZE OF CONTROLLER
2058
2059          ;+
2060          ;ROUTINE TO DO A SOFT INITIALIZE OF THE CONTROLLER
2061          ;BY WRITING INTO THE TSSR REGISTER. AFTER THE INIT,
2062          ;THE TSSR REGISTER IS TESTED FOR ERRORS. ANY ERRORS
2063          ;DETECTED SHOULD BE TREATED AS DEVICE FATAL ERRORS.
2064
2065          ;INPUTS:
2066          ;
2067          ;       R5       ADDRESS OF FIRST REGISTER
2068
2069          ;OUTPUTS:
2070          ;
2071          ;       R0       CONTENTS OF TSSR, IF ERROR
2072          ;       CARRY   SET IF INIT WAS OKAY
2073          ;               CLEAR IF FATAL ERROR
2074
2075          ;CALLING SEQUENCE:
2076          ;
2077          ;       MOV     #ADDRESS,R5
2078

```

```

2079      ;      JSR      PC,SOFINIT
2080      ;      BCS      CONTINUE
2081      ;      ERRDF          ;REPORT FATAL ERROR
2082      ;
2083      ;
2084      ;
2085      015664      SOFINIT:;
2086      015664      SAVREG          ; SAVE THE REGISTERS
2087      015670      012765 000000 000002      MOV      #0,TSSR(R5)      ; DO THE INIT.
2088      015676      004737 016140      JSR      PC,WAITF          ; WAIT FOR SSR
2089      015702      016500 000002      MOV      TSSR(R5),R0      ;GET THE TSSR REGISTER
2090      015706      010004      MOV      R0,R4          ;TSSR CONTENTS
2091      015710      042704 176277      BIC      #+C<HIADDR!OFL>,R4
2092      015714      052704 002200      BIS      #SSR!NBA,R4      ;R4 HAS EXPECTED CONTENTS
2093      015720      020400      CMP      R4,R0          ;ONLY EXPECTED BITS SET ?
2094      015722      001402      BEQ      5$          ;BRANCH IF OKAY
2095      015724      000241      CLC          ;CLEAR THE CARRY FOR ERROR
2096      015725      000401      BR      10$          ;GO TO EXIT
2097      015730      000261      5$: SEC          ;SET THE CARRY BIT
2098      015732      000207      10$: RTS      PC          ;RETURN TO CALLER
2099
2100      .SBTTL  CHKAMB - CHECK TSSR FOR AMBIGUITY
2101
2102      ;+
2103      ;
2104      ;THIS ROUTINE TESTS THE CONTENTS OF THE TSSR REGISTER
2105      ;FOR AMBIGUITY
2106      ;
2107      ;INPUT:
2108      ;
2109      ;      RO      CONTENTS OF TSSR
2110      ;
2111      ;OUTPUT:
2112      ;
2113      ;      RO      CONTENTS OF TSSR
2114      ;
2115      ;      CARRY   SET - NO AMBIGUITY
2116      ;              CLR - AMBIGUOUS CONTENTS
2117      ;
2118      ;
2119      ;
2120      015734      CHKAMB:
2121      015734      SAVREG          ;SAVE THE GENERAL REGISTERS
2122      015740      MOV      R0,R4      ;CONTENTS OF TSSR
2123      015742      032700 100000      BIT      #SC,R0          ;IS BIT 15 SET ?
2124      015746      001004      BNE      5$          ;BRANCH IF YES
2125      015750      032700 174077      BIT      #+C<NBA!OFL!SSR!HIADDR>,R0      ;ANY OTHER BITS SET ?
2126      015754      001023      BNE      40$          ;MUST BE AN ERROR
2127      015756      000424      BR      45$          ;RETURN WITH SUCCESS
2128      015760      032700 000200      5$: BIT      #SSR,R0      ;IS READY BIT SET ?
2129      015764      001011      BNE      10$          ;BRANCH IF READY BIT IS SET.
2130      015766      032700 000040      BIT      #BITS,R0      ;IS FATAL ERROR BIT SET ?
2131      015772      001414      BEQ      40$          ;ERROR IF NOT
2132      015774      042704 177761      BIC      #+CTERCLS,R4      ;CLEAR ALL BUT TERMINATION CODE
2133      016000      020427 000016      CMP      R4,#16          ;ALL THREE BITS MUST BE SET
2134      016004      001007      BNE      40$          ;ERROR IF NOT SET
2135      016006      000410      BR      45$          ;OK IF ALL ARE SET

```

TSV3 - GLOBAL AREAS MACRO M1113 01-FEB-84 18:55
 CHKAMB - CHECK TSSR FOR AMBIGUITY

SEQ 064

```

2136 016010 032700 000040      10$: BIT      0BIT5,RO      ;IS FATAL ERROR BIT SET ?
2137 016014 001405              BEQ      45$          ;ERROR IF BIT IS SET WITH SSR
2138 016016 032700 000006              BIT      0BIT2!BIT1,RO ;IS THIS A FUNCTION REJECT
2139 016022 001002              BNE      45$          ;BR, IF TSSR IS OK
2140 016024 000241      40$: CLC              ;AMBIGUOUS CONTENTS
2141 016026 000401              BR       50$
2142 016030 000261      45$: SEC              ;SHOW SUCCESS - NO AMBIGUITY
2143 016032 000207      50$: RTS      PC      ;RETURN TO CALLER
2144
2145              .SBTTL ENAINT,DSBINT - ENABLE/DISABLE INTERRUPTS
2146
2147              ;
2148              ; DEFAULT DISPLAY INTERRUPT HANDLERS.
2149              ; IF DISPLAY TIME-OUT, REPORT DEV FATAL, AND ABORT PASS.
2150              ; OTHERWISE, SAVE DPU REGISTERS AND DISMISS.
2151              ;
2152              ; BIT DEFINITIONS FOR "INTMASK" AND "INTFLAG" BYTES:
2153              ;
2154              ; IOKCKIN=BIT7      ; DON'T CHECK FOR BAD INTERRUPTS -- TEST WILL.
2155              ; IOKSTP=BIT0      ; EXPECT "STOP" INTERRUPT.
2156              ;
2157              ; INTERRUPT MASK -- SAYS EXPECTING INTERRUPTS
2158 016034      000      INTMASK: .BYTE 0
2159              ; INTERRUPT FLAG -- SAYS WE GOT ONE (IF POSITIVE)
2160 016035      000      INTFLAG: .BYTE 0
2161
2162              ; SAVED INTERRUPT VECTOR:
2163 016036      000000      INTVEC: .WORD 0
2164              ; SAVE CPU PC
2165 016040      000000      INTCPC: .WORD 0
2166
2167              ; SUBROUTINE TO ENABLE INTERRUPTS:
2168 016042      010046      ENAINT: MOV      RO,-(SP)      ;SAVE RO
2169 016044      013700      MOV      IVEC,RO      ;GET POINTER TO VECTORS
2170 016050      012720      MOV      0INTR,(RO)+    ;SET UP INTERRUPT VECTOR
2171 016054      012720      MOV      0PRI07,(RO)+
2172 016060      012600      MOV      (SP)+,RO      ;RESTORE RO
2173 016062      011646      MOV      (SP),-(SP)
2174 016064      012766      MOV      0,2(SP)      ;SET CPU TO LEVEL 0
2175 016072      000002      RTI
2176
2177              ; SUBROUTINE TO DISABLE INTERRUPTS (RAISE PRIORITY TO LEVEL 7)
2178 016074      011646      DSBINT: MOV      (SP),-(SP)
2179 016076      012766      MOV      0PRI07,2(SP)
2180 016104      000002      RTI
2181
2182              .SBTTL INTR - INTERRUPT HANDLERS
2183
2184 016106      016106      BGNSRV INTR      ;DEFINE INTERRUPT ENTRY
2185 016106      012737      000001 002216' INTR:: MOV      01,INTRECV    ;SET FLAG TO SHOW INTERRUPT RECEIVED
2186 016114      105037      016035'      CLR      INTFLAG      ;CLEAR FLAG TO SAY WE GOT INTERRUPT
2187 016120      112737      000001 016034'      BIT      0IOKSTP,INTMASK ;EXPECTING STOP INTERRUPT?
2188 016126      001003      BNE      1$          ;BR IF YES
2189 016130      152737      000001 016035'      BIS      0IOKSTP,INTFLAG ;NO. SET THE ERROR FLAG.
2190
2191              ;SAVE REGISTERS, MSG BUFFER, ETC.

```



```

2192 016136          1$:
2193 016136          ENDSRV
      016136          L10026:
      016136 000002    RTI
2194
2195          .SBTTL WAITF - WAIT FOR SUBSYSTEM READY
2196
2197          ;
2198          ; SUBROUTINE TO WAIT FOR THE SUBSYSTEM READY FLAG
2199          ;
2200          ; INPUTS:
2201          ;
2202          ; R5 ADDRESS OF FIRST DEVICE REGISTER
2203          ;
2204          ; OUTPUTS:
2205          ;
2206          ; R0 CONTENTS OF LAST TSSR READ
2207          ; CARRY SET - READY BIT SET
2208          ; CLR - TIMEOUT WAITING FOR READY
2209 016140 000401    WAITF:: BR 1$ ;NOP WHEN SUPER FIXED
2210 016142          BREAK ; DO A SUPVSR BREAK FIRST.
      016142 104422    TRAP C$BRK
2211 016144 012746 011000 1$: MOV #11000,-(SP) ;25-APRIL-83 REV B - 1100 MSEC TIMER
2212 016150 016500 000002 2$: MOV TSSR(R5),R0 ;READ THE TSSR REGISTER
2213 016154 105700    TSTB R0 ;TEST FOR READY BIT SET
2214
2215 016156 100420    BMI 3$ ; EXIT ON STOP FLAG.
2216 016160          DELAY 1 ; WAIT 100 USEC
      016160 012727 000001    MOV #1,(PC)+
      016164 000000    .WORD 0
      016166 013727 002116'    MOV L$DLY,(PC)+
      016172 000000    .WORD 0
      016174 005367 177772    DEC -6(PC)
      016200 001375    BNE .-4
      016202 005367 177756    DEC -22(PC)
      016206 001367    BNE .-20
2217 016210 005316    DEC (SP) ;REDUCE DELAY COUNT
2218 016212 001356    BNE 2$ ;RETRY UNTIL TIMER EXPIRES
2219 016214 000241    CLC ; C = 0, CONTROLLER STILL RUNNING ..
2220 016216 000401    BR 4$ ;...OR HUNG-UP AFTER 300 MSEC.
2221 016220 000261    3$: SEC ; C = 1, CONTROLLER IS STOPPED.
2222 016222 005326    4$: DEC (SP)+ ;RESTORE STACK WITHOUT CHANGING CARRY BIT
2223 016224 000207    RTS PC
2224
2225          .SBTTL CHKTTSSR - CHECK TSSR FOR READY
2226
2227          ;*
2228          ;
2229          ; THIS ROUTINE WAITS FOR READY IN THE TSSR
2230          ; AND TESTS FOR AMBIGUOUS BIT SETTINGS IN TSSR.
2231          ;
2232          ; INPUT:
2233          ;
2234          ; R5 ADDRESS OF CSR REGISTERS
2235          ;
2236          ; OUTPUT:
2237          ;
    
```

```

2238      |      RO      CONTENTS OF TSSR
2239      |      CARRY   SET - OKAY
2240      |           CLR - NOT READY AMBIGUOUS, OR SC SET
2241      |
2242      |
2243      |
2244      |
2244 016226      |      CHKTSR:
2245 016226 004737 016140' |      JSR      PC, WAITF      ;WAIT FOR READY
2246 016232 103014      |      BCC      20$           ;BRANCH IF TIME OUT
2247 016234 004737 015734' |      JSR      PC, CHKAMB     ;TSSR AMBIGUOUS?
2248 016240 103006      |      BCC      10$           ;BR IF YES
2249 016242 032700 100000  |      BIL      @SC, RO       ;SPECIAL CONDITION SET?
2250 016246 001405      |      BEQ      15$           ;BR IF NO
2251 016250 032700 074000  |      BIT      @<SCE!BIE!RMR!NXM>, RO ;ANY ERROR BITS SET?
2252 016254 001402      |      BEQ      15$           ;BR IF NO
2253 016256 000241      | 10$: CLC                  ;SET FAILURE
2254 016260 000401      |      BR       20$           |
2255 016262 000261      | 15$: SEC                  ;SET SUCCESS
2256 016264 000207      | 20$: RTS      PC          ;RETURN TO CALLER
2257
2258      |      .SBITL  NXNM      - CHECK FOR NONEXISTENT MEMORY
2259
2260      |
2261      |      ROUTINE TO TEST FOR A NEXM IN THE RANGE (R1) THRU (R2).
2262      |      ON RETURN, IF "C" = 1, (R1) = NEXM ADDRESS.
2263      |      "C" = 0, ALL ADDRESSES OK.
2264      |
2265      |      CALL:  MOV ADR1, R1
2266      |           MOV ADR2, R2
2267      |           JSR PC, NXM
2268      |           RETURN          ;TEST "C" AND PROCEED.
2269 016266 012737 016322' 000004 |  NXNM:  MOV      @2$, @04      ; SET BUSERR VECTOR.
2270 016274 012737 000200 000006  |      MOV      @PRI04, @06
2271 016302 005003      |      CLR      R3           ;FLAG.
2272 016304 000241      |      CLC                  ;CLEAR THE CARRY FOR NO NXM FOUND
2273 016306 005711      | 1$:  TST      (R1)         ;TEST THE ADDRESS(ES).
2274      |           ;IF ANY TRAP, CONTINUE AT 2$.
2275 016310 020102      |      CMP      R1, R2       ;OTHERWISE, CONTINUE HERE.
2276 016312 001407      |      BEQ      3$           ;BR IF FINISHED (NO NEXM'S).
2277 016314 062701 000002  |      ADD      @2, R1       ;SET NEXT ADDRESS...
2278 016320 000772      |      BR       1$           ;...AND CONTINUE.
2279
2280 016322 005103      | 2$:  COM      R3           ;GOT ONE, SET FLAG...
2281 016324 012716 016332'  |      MOV      @3$, (SP)
2282 016330 000002      |      RTI                  ;...AND DISMISS INTERRUPT...
2283 016332      | 3$:  CLRVEC  @4           ;...AND GIVE BACK THE VECTOR.
2284      |      MOV      @4, RO
2285 016340 005703      |      TRAP     C1CVEC
2286 016342 001401      |      TST      R3           ;DID WE CATCH ONE ??
2287 016344 000261      |      BEQ      .+4         ;NO, "C" = 0, SKIP NEXT.
2288      |      SEC
2289      |      RTS      PC          ;YES, "C" = 1, (R1) = NEXM ADDR.
2290
2291
2292      |      .SBITL  TSTLOOP - CHECK ITERATION COUNT
    
```

```

2293
2294
2295
2296
2297
2298
2299
2300 016350
2301 016350 005737 002162'
2302 016354 001006
2303 016356 005737 002176'
2304 016362 100403
2305 016364 005337 002210'
2306 016370 001002
2307 016372 000241
2308 016374 000401
2309 016376 000261
2310 016400 000207
2311
2312
2313
2314
2315
2316
2317
2318
2319
2320
2321
2322
2323
2324
2325
2326
2327
2328
2329
2330
2331
2332
2333
2334
2335
2336
2337
2338 016402
2339 016402 010046
2340 016404 005037 003146'
2341 016410 005037 016650'
2342 016414 005037 005600'
2343 016420 105037 016034'
2344 016424 013700 002174'
2345 016430 006300
2346 016432 005737 003106'
2347 016436 001430
2348 016440 100010
2349 016442 052760 160000 003170'

```

```

;
; SUBROUTINE TO EXECUTE TEST ITERATIONS.
; EXIT WITH "C" SET IF LOOPS ALLOWED AND LOOP COUNT NON-ZERO.
; LOOP COUNTER IS SET BY "BEGIN.TEST" MACRO.
;
; CALL: LOOPTO ARG
;
TSTLOOP::
    TST     NOITS           ; ITERATIONS INHIBITED?
    BNE     1#             ; YES.
    TST     QVP            ; NO.
    BMI     1#             ; LOOPS DISALLOWED IN QUICK PASS.
    DEC     LOOPCNT        ; BUMP LOOP COUNTER.
    BNE     2#
1#:      CLC                ; LOOP DISALLOWED, OR DONE.
    BR     3#
2#:      SEC                ; LOOP ENABLED.
3#:      RTS     PC

;
; .SBTTL TSTSETUP - PRINT TEST NAME AND INIT ERROR COUNTS
;
; PRINT THE NUMBER AND NAME OF EACH TEST AS WE GO ALONG.
; INCREMENT "TESTK" TO INDICATE THE NUMBER OF TESTS
; IN THE CURRENT RUN SEQUENCE.
; CLEAR THE ERROR COUNTER AND SIGNATURE EXTENSION FLAGS.
;
; INPUT:
;
;     R0     POINTER TO TEST ID ASCIZ STRING
;
; OUTPUT:
;
;     R5     ADDRESS OF FIRST DEVICE REGISTER
;
; IMPLICIT OUTPUTS:
;
;     TSTCNT UPDATED TO COUNT TESTS PERFORMED SINCE START OR RESTART
;
; SIDE EFFECTS:
;
;     INTERRUPT LEVEL IS RAISED TO LEVEL OF
;     THE DEVICE UNDER TEST
;
;
TSTSETUP::
    MOI    RO, -(SP)      ; SAVE THE TEST ID MESSAGE
    CLR    SIFLAG         ; CLEAR "SOFT INIT" FLAG
    CLR    ERRK           ; CLEAR LOCAL ERROR COUNTER.
    CLR    EXTA          ; CLEAR ERROR EXTENSION FLAG.
    CLRB   INTMASK        ; CLEAR INTERRUPT MASK (CHECK ERROR)
    MOV    UNITN, RO      ; GET THE UNIT NUMBER.
    ASL    RO             ; ... AND MAKE IT A WORD OFFSET.
    TST    NODEV          ; DID STARTUP FIND THE DEVICE?
    BEQ    4#             ; BR IF YES
    BPL    3#             ; BR IF NOT IDLE
    BIS    @160000,ERTABL(RO) ; FLAG ERROR IN THE ERROR TABLE

```

TSV3 - GLOBAL AREAS MACRO M1113 01-FEB-84 18:55
 TSTSETUP - PRINT TEST NAME AND INIT ERROR COUNTS

SEQ 063

```

2350 016450          ERRDF 1,NXR,NXRERR ; NO DEVICE HERE -- PRINT IT
      016450 104455 TRAP C#ERDF
      016452 000001 .WORD 1
      016454 003730' .WORD NXR
      016456 005544' .WORD NXRERR
2351 016460 000407 BR 2#
2352 016462 052760 150001 003170' 3#: JIS #160001,ERTABL(RO) ; FLAG ERROR IN THE ERROR TABLE
2353 016470          ERRDF 2,NOINIT ; DEVICE NOT IDLE
      016470 104455 TRAP C#ERDF
      016472 000002 .WORD 2
      016474 004325' .WORD NOINIT
      016476 000000 .WORD 0
2354 016500 012737 177777 003104' 2#: MOV #1,DUFLG ; DROP THE UNIT
2355 016506          DODU UNITN
      016506 013700 002174' MOV UNITN,RO
      016512 104451 TRAP C#DODU
2356 016514          DOCLN
      016514 104444 TRAP C#DOCLN ; ABORT THE PASS
2357 016516 000423 BR 5#
2358
2359 016520          RFLAGS RO ; GET THE OPERATOR FLAGS.
      016520 104421 TRAP C#RFLA
2360 016522 032700 001000 BIT #PNT,RO ; PRINT THE TEST NUMBERS?
2361 016526 001412 BEQ 1# ; BR IF NO
2362 016530 011600 MOV (SP),RO ; GET THE ID MESSAGE
2363 016532          PRINTF #TNAM,RO ; DISPLAY THE TEST ID
      016532 010046 MOV RO,-(SP)
      016534 012746 016576' MOV #TNAM,-(SP)
      016540 012746 000002 MOV #2,-(SP)
      016544 010600 MOV SP,RO
      016546 104417 TRAP C#PNTF
      016550 062706 000006 ADD #6,SP
2364 016554 005237 002206' 1#: INC TSTCNT ; BUMP TEST COUNTER.
2365 016560          SETPRI IPRI ; PRIORITY THAT OF DEVICE
      016560 013700 002204' MOV IPRI,RO
      016564 104441 TRAP C#SPRI
2366 016566 005726 5#: TST (SP)+ ; FIX UP THE STACK
2367 016570 013705 002200' MOV CSRADDR,R5 ; ADDRESS OF TSV REGISTERS ON UNIBUS
2368 016574 000207 RTS PC
2369 016576 045 123 045 TNAM: .ASCIZ '#SWT#A Test'
2370 .EVEN
2371
2372 .SBTTL TSTEND - PRINT ERRORS RECEIVED
2373
2374 ; AT END OF EACH TEST, PRINT THE NUMBER OF ERRORS RECEIVED
2375 ; IF NORMAL ERROR REPORTING IS DISABLED (FLA:IER).
2376
2377 TSTEND: RFLAGS RO
      016612 104421 TRAP C#RFLA
2378 016614 030027 020000 BIT RO,#IER
2379 016620 001412 BEQ 1# ; BR IF "IER" NOT SET.
2380 016622          PRINTF #ESUM,ERRK ; PRINT ERROR COUNT.
      016622 013746 016650' MOV ERK,-(SP)
      016626 012746 016652' MOV #ESUM,-(SP)
      016632 012746 000002 MOV #2,-(SP)
      016634 010600 MOV SP,RO
      016640 104417 TRAP C#PNTF

```

TSV3 - GLOBAL AREAS MACRO M1113 01-FEB-84 18:55
 TSTEND - PRINT ERRORS RECEIVED

SEQ 069

```

2381 016642 062706 000006          ADD    #6,SP
2382 016646 000207          RTS    PC
2383 016650 000000          ERRK:  0                ; LOCAL ERROR COUNT.
2384 016652    045    101    040    ESUM:  .ASCIZ  /#A #D#A ERRORS/
2385 016671    105    122    122    EMAXDU: .ASCIZ  /ERROR LIMIT REACHED -- DROPPING UNIT/
2386                                     .EVEN
2387
2388                                     .SBTTL  INCERK  - INCREMENT LOCAL ERROR COUNT
2389
2390                                     ;+
2391                                     ; ROUTINES TO INCREMENT LOCAL ERROR COUNT AND CHECK FOR LIMIT:
2392 016736 005237 016650' INCERK: INC    ERRK                ; INCREMENT LOCAL ERROR COUNT
2393 016742 010046          MOV    RO,-(SP)            ; SAVE RO
2394 016744 013700 002174' MOV    UNITN,RO           ; GET UNIT NUMBER.
2395 016750 006300          ASL   RO                  ; ... AND MAKE IT A WORD OFFSET.
2396 016752 062700 003170' ADD    #ERTABL,RO         ; RO GETS ADDRESS OF ERROR TABLE ENTRY.
2397 016756 005210          INC   (RO)                ; INCREMENT THE DEVICE ERROR COUNT
2398 016760 032710 007777' BIT    #7777,(RO)        ; DID WE OVERFLOW THE FIELD?
2399 016764 001001          BNE   1$                  ; BR IF NO.
2400 016766 005310          DEC   (RO)                ; YES -- BACK IT UP TO 7777.
2401 016770 012600          1$:  MOV    (SP)+,RO       ; RESTORE RO
2402 016772 000207          RTS    PC                 ; RETURN TO CALLER.
2403
2404 016774 010046          CKEMAX: MOV   RO,-(SP)       ; SAVE RO
2405 016776 013700 002174' MOV   UNITN,RO           ; GET UNIT NUMBER
2406 017002 006300          ASL   RO                  ; ... AND MAKE IT A WORD OFFSET
2407 017004 016000 003170' MOV   ERTABL(RO),RO      ; GET ERROR TABLE ENTRY
2408 017010 042700 170000' BIC   #170000,RO         ; EXTRACT ERROR COUNT FIELD
2409 017014 020037 002166' CMP   RO,GERRMAX         ; IS GLOBAL LIMIT EXCEEDED FOR THIS UNIT?
2410 017020 103004          BHS   1$                  ; BR IF YES
2411 017022 023737 016650' 002164' CMP   ERRK,LERRMAX        ; IS LOCAL LIMIT EXCEEDED FOR THIS TEST?
2412 017030 103417          BLO   2$                  ; BR IF NO
2413 017032          1$:  RFLAGS RO                ; GET OPERATOR FLAGS
2414 017032 104421          TRAP  C#RFLA
2415 017034 032700 000040' BIT   #IDU,RO            ; IS DROPPING INHIBITED?
2416 017040 001013          BNE   2$                  ; BR IF YES.
2417 017042 012737 177777 003104' MOV   #-1,DUFLG         ; NO -- DROP THE UNIT
2418 017050          ERDF  #,EMAXDU
2419 017050 104455          TRAP  C#ERDF
2420 017052 000004          .WORD 4
2421 017054 016671'          .WORD EMAXDU
2422 017056 000000          .WORD 0
2423 017060          DODU  UNITN
2424 017060 013700 002174' MOV   UNITN,RO
2425 017064 104451          TRAP  C#DODU
2426 017066          DOCLN
2427 017066 104444          TRAP  C#DCLN
2428 017070 012600          2$:  MOV   (SP)+,RO         ; RESTORE RO
2429 017072 000207          RTS    PC                 ; RETURN TO CALLER
2430
2431                                     .SBTTL  CKDROP  - CHECK IF UNIT SHOULD BE DROPPED
2432
2433                                     ;+
2434                                     ; CHECK IF UNIT SHOULD BE DROPPED
2435
2436                                     ;-
2437 CKDROP: MOV   RO,-(SP)
2438 FORCERROR 1$,NOTSSR

```

TSV3 - GLOBAL AREAS MACRO M1113 01-FEB-84 18:55
 CKDROP - CHECK IF UNIT SHOULD BE DROPPED

SEQ 070

```

2429 017106          RFLAGS RO
      017106 104421    TRAP   C#RFLA
2430 017110 032700 000040    BIT   #IDU,RO
2431 017114 001010    BNE   1$
2432 017116 011600    MOV   (SP),RO
2433 017120 012737 177777 003104'  MOV   #-1,DUFLG
2434 017126          DODU   UNITN
      017126 013700 002174'  MOV   UNITN,RO
      017132 104451    TRAP   C#DODU
2435 017134          DOCLN          ;ABORT THE PASS
      017134 104444    TRAP   C#DCLN
2436 017136 012600    1$:  MOV   (SP)+,RO
2437 017140 000207    RTS   PC
2438
2439          .SBTTL  CONFIG - DETERMINE CONFIGURATION OF SYSTEM
2440          ;
2441          ; SUBROUTINE - DETERMINE CONFIGURATION OF TSUOS SYSTEM.
2442          ;
2443 017142          CONFIG:
2444 017142 004737 015664'  JSR   PC,SOFINIT
2445 017146 000207          RTS   PC
2446
2447          .SBTTL  KTON,KTOFF - ENABLE/DISABLE MEMORY MANAGEMENT
2448          ;
2449          ; SUBROUTINE - ENABLE MEM MGT.
2450          ;
2451 017150 005737 003124'  KTON:  TST   KTFLG          ; GOT KT?
2452 017154 001403          BEQ   1$          ; NO.
2453 017156 012737 000001 177572  MOV   #1,SRO          ; YES. ENABLE KT11.
2454 017164 000207    1$:  RTS   PC
2455
2456
2457
2458          ;
2459          ; SUBROUTINE - DISABLE MEM MGT.
2460          ;
2461 017166 005737 003124'  KTOFF: TST   KTFLG          ; GOT KT11?
2462 017172 001405          BEQ   1$          ; NO.
2463 017174 000240          NOP
2464 017176 000240          NOP
2465 017200 012737 000000 177572  MOV   #0,SRO          ; DISABLE KT.
2466 017206 000207    1$:  RTS   PC
2467
2468          .SBTTL  SETMAP - SETUP PAR6 MAPPING
2469
2470          ;
2471          ;
2472          ; THIS ROUTINE SETS UP KERNEL PAR6 TP HANDLE
2473          ; AN 22 BIT ADDRESS. THE OFFSET INTO THE PAGE
2474          ; IS RETURNED BIASED TO PAR6.
2475          ;
2476          ; INPUTS:
2477          ;
2478          ;     RO     HIGH ORDER ADDRESS BITS
2479          ;     R1     LOW ORDER ADDRESS BITS
2480          ;
2481          ; OUTPUTS:

```

```

2482      ;
2483      ;      RO      OFFSET INTO BLOCK WITH PAR6 BIAS (I.E. THE ADDRESS)
2484      ;      CARRY   SET IF SUCCESS
2485      ;                      CLR IF ERROR
2486      ;
2487 017210 SETMAP:
2488 017210      SAVREG      ;SAVE R1-R4 UNTIL NEXT RETURN
2489 017214 005737 003124'  TST      KTFLG      ;SYSTEM HAVE ABOVE 28K?
2490 017220 001433          BEQ      10$      ;BR IF NO
2491 017222 010102          MOV      R1,R2      ;SAVE LOW ORDER BITS
2492          000006          .REPT      6
2493          ASR      R0      ;CONVERT WORD ADDRESS TO 32W BLOCKS
2494          ROR      R1      ;MAKE IT DOUBLE PRECISION
2495          .ENDR
2496 017254 042701 000177  BIC      @177,R1      ;ALINE FOR LOWER 4K BOUNDARY
2497 017260 020137 003124'  CMP      R1,KTFLG    ;HIGHER THAN EXISTING MEMORY?
2498 017264 103011          BHS      10$      ;BR IF YES
2499 017266 010137 172354  MOV      R1,@KIPAR6  ;SETUP MAPPING REGISTER PAR6
2500 017272 042702 160000  BIC      @160000,R2  ;SETUP DISPLACEMENT IN PAGE
2501 017276 062702 140000  ADD      @140000,R2  ;ADD IN PAR6 BIAS
2502 017302 010200          MOV      R2,R0      ;RETURN IN R0
2503 017304 000261          SEC          ;SET SUCCESS
2504 017306 000401          BR       15$
2505 017310 000241 10$:   CLC          ;SET FAILURE
2506 017312 000207 15$:   RTS      PC      ;RETURN
2507
2508
2509          .SBTTL  FILLMEM - FILL MEMORY WITH BACKGROUND PATTERN
2510
2511      ;*
2512      ; FILL MEMORY WITH A BACKGROUND PATTERN
2513      ;
2514      ; INPUTS:
2515      ;
2516      ;      RO = BACKGROUND PATTERN
2517      ;      FREE = FIRST LOCATION AVAILABLE TO DIAGNOSTIC
2518      ;      KTFLG = SET TO HIGHEST MEMORY LOCATION IF > 28K.
2519      ;
2520      ; OUTPUTS:
2521      ;
2522      ;      NONE
2523      ;
2524      ;
2525      ; FILLMEM:
2526 017314      SAVREG      ;SAVE R1-R5 UNTIL NEXT RETURN
2527 017320 004737 017166'  JSR      PC,KTOFF   ;DISABLE KT.
2528 017324 010003          MOV      R0,R3      ;COPY TEST PATTERN
2529 017326 013701 003116'  MOV      FREE,R1     ;GET FIRST FREE LOCATION
2530 017332 013702 003120'  MOV      FRESIZ,R2  ;SIZE OF FREE SPACE BELOW 28K.
2531 017336 010321          MOV      R3,(R1)+   ;STORE A BACKGROUND WORD
2532 017340 005302          DEC      R2      ;DONE ALL MEMORY IN FREE SPACE?
2533 017342 003375          BGT      10$      ;BR IF NO
2534 017344 005737 003124'  TST      KTFLG      ; GOT KT?
2535 017350 001502          BEQ      55$      ; NO. GET OUT.
2536 017352 004737 017150'  JSR      PC,KTON    ; YES. ENABLE KT.
2537 017354 005000          CLR      R0      ;HIGH ORDER ADDRESS START
2538 017360 013701 003144'  MOV      PST32W,R1  ;GET >28K START ADDRESS (IN 32W BLOCKS)
2539          000006          .REPT      6
    
```

```

2539          CLC          ;CLEAR C BIT
2540          ROL          R1      ;CONVERT BLOCKS TO WORDS
2541          ROL          R0      ;MAKE IT DOUBLE PRECISION
2542          .ENDR
2543 017430 004737 017210'      JSR          PC,SETMAP      ;SETUP PAR6 MAPPING REGISTER
2544 017434 010320              30$: MOV          R3,(R0)+      ;STORE TEST PATTERN IN >28K ADDRESS
2545 017436 020027 160000      CMP          R0,#160000     ;END OF PAR6 MAPPING AREA?
2546 017442 103774              BLO          30$           ;BR IF NO
2547 017444 162700 020000      SUB          #20000,R0      ;BACKUP INTO PAR6 MAPPING BEGIN
2548 017450 062737 000200 172354 ADD          #200,#KIPAR6   ;POINT TO NEXT 4K BLOCK >28K.
2549 017456 013705 003124'      MOV          KTFLG,R5      ;GET VALUE FROM MEMORY SIZER
2550 017462 042705 170000      BIC          #170000,R5    ;ONLY 18 BITS PASS
2551 017466 023705 172354      CMP          #KIPAR6,R5    ;END OF MEMORY?
2552 017472 001427              BEQ          50$           ;BR IF YES
2553 017474 005737 003136'      TST          T23A         ;PROCESSOR TYPE A
2554 017500 001407              BEQ          35$           ;NO KEEP GOING
2555 017502 013704 177572      MOV          SRO,R4        ;GET SRO CONTENTS
2556 017506 042704 177761      BIC          #177761,R4    ;CLEAR ALL BUT PAGE NUMBER
2557 017512 022704 000016      CMP          #16,R4        ;SEE IF PAGE 7
2558 017516 001415              BEQ          50$           ;EXIT IF THERE
2559 017520 005737 003140'      35$: TST          T23B         ;PROCESSOR TYPE B
2560 017524 001410              BEQ          45$           ;NO KEEP GOING
2561 017526 023727 172354 007600 CMP          #KIPAR6,#7600 ;REACHED 18 BITS?
2562 017534 103001              BHIS         40$           ;YES
2563 017536 000403              BR           45$           ;NO KEEP GOING
2564 017540 012737 000020 172516 40$: MOV          #20,SRO      ;SET MMU RELOCATION
2565 017546 000137 017434'      45$: JMP          30$           ;KEEP GOING ON ETC.
2566 017552 004737 017166'      50$: JSR          PC,KTOFF    ;DISABLE KT.
2567 017556 000207              55$: RTS          PC
  
```

.SBTTL CMPMEM - COMPARE MEMORY TO BACKGROUND PATTERN

```

; *
; COMPARE MEMORY WITH A BACKGROUND PATTERN
; INPUTS:
;
;   RO - BACKGROUND PATTERN
;   FREE - FIRST LOCATION AVAILABLE TO DIAGNOSTIC
;   KTFLG - SET TO HIGHEST MEMORY LOCATION IF > 28K.
;
; OUTPUTS:
;
;   CARRY - SET IF NO ERROR
;   CARRY - CLR IF ERROR
;
; IMPLICIT OUTPUTS:
;
;   ERRHI - ERROR HIGH ADDRESS
;   ERRLO - ERROR LOW ADDRESS
;   EXPD  - EXPECTED DATA
;   REC  - RECEIVED DATA
  
```

```

2590
2591 017560          CMPMEM:
2592 017560          SAVREG
2593 017564 010003      MOV          R0,R3      ;SAVE R1-R5 UNTIL NEXT RETURN
2594 017566 004737 017166' JSR          PC,KTOFF    ;COPY TEST PATTERN
2595 017572 013701 003116' MOV          FREE,R1     ;DISABLE KT.
                          ;GET FIRST FREE LOCATION
  
```


TSV3 - GLOBAL AREAS MACRO M1113 01-FEB-84 18:55
 CMPMEM - COMPARE MEMORY TO BACKGROUND PATTERN

SEQ 073

```

2596 017576 013702 003120'      MOV    FRESIZ,R2      ;SIZE OF FREE SPACE BELOW 28K.
2597 017602 020311      10$:  CMP    R3,(R1)      ;FREE SPACE LOCATION EQUAL TO EXPD?
2598 017602 001411      BEQ    15$           ;BR IF YES
2599 017606 010137 002232'      MOV    R1,ERRLO     ;SAVE ADDRESS IN ERROR
2600 017612 005037 002230'      CLR    ERRHI        ;NO HIGH ADDRESS
2601 017616 010337 002224'      MOV    R3,EXPD      ;SAVE EXPD FOR ERROR REPORT
2602 017622 011137 002226'      MOV    (R1),RECV    ;SAVE RECV FOR ERROR REPORT
2603 017626 000474      BR     50$         ;
2604 017630 005721      15$:  TST    (R1)+        ;POINT TO NEXT ADDRESS
2605 017632 005302      DEC    R2           ;DONE ALL MEMORY IN FREE SPACE?
2606 017634 003362      BGT    10$         ;BR IF NO
2607 017636 005737 003124'      TST    KTFLG        ; GOT KT?
2608 017642 001472      BEQ    55$         ; NO. GET OUT.
2609 017644 004737 017150'      JSR    PC,KTON      ; YES. ENABLE KT.
2610 017650 005000      CLR    R0           ;HIGH ORDER ADDRESS START
2611 017652 013701 003144'      MOV    PST32W,R1    ;GET >28K START ADDRESS (IN 32W BLOCK?)
2612      .REPT    6
2613      ROL    R1        ;CONVERT BLOCKS TO WORDS
2614      ROL    R0        ;MAKE IT DOUBLE PRECISION
2615      .ENDR
2616 017706 042701 000177      BIC    @177,R1      ;ALINE 4K BOUNDARY
2617 017712 010046      MOV    R0,-(SP)     ;SAVE HIGH ORDER
2618 017714 010146      MOV    R1,-(SP)     ;SAVE LOW ORDER
2619 017716 004737 017210'      JSR    PC,SETMAP    ;SETUP PAR6 MAPPING REGISTER
2620 017722 010004      MOV    R0,R4        ;COPY ADDRESS BIASED TO PAR6
2621 017724 012601      MOV    (SP)+,R1     ;RESTORE LOW ORDER IN NON PAR6 FORMAT
2622 017726 012600      MOV    (SP)+,R0     ;RESTORE HIGH ORDER IN NON PAR6 FORMAT
2623 017730 020314      30$:  CMP    R3,(R4)      ;ABOVE 28K LOCATION EQUAL EXPD?
2624 017732 001411      BEQ    32$         ;BR IF YES
2625 017734 010037 002230'      MOV    R0,ERRHI    ;SAVE HIGH ORDER IN ERROR
2626 017740 010137 002232'      MOV    R1,ERRLO    ;SAVE LOW ORDER IN ERROR
2627 017744 010337 002224'      MOV    R3,EXPD     ;SAVE EXPD FOR ERROR REPORT
2628 017750 011437 002226'      MOV    (R4),RECV   ;SAVE RECV FOR ERROR REPORT
2629 017754 000421      BR     50$         ;
2630 017756 062701 000002      32$:  ADD    @2,R1        ;UPDATE NON PAR6 ADDRESS
2631 017762 005500      ADC    R0           ;MAKE IT DOUBLE PRECISION ADD
2632 017764 062704 000002      ADD    @2,R4        ;UPDATE PAR6 FORMAT ADDRESS
2633 017770 020427 160000      CMP    R4,@160000  ;END OF PAR6 MAPPING AREA?
2634 017774 103755      BLO    30$         ;BR IF NO
2635 017776 162704 020000      SUB    @20000,R4    ;BACKUP INTO PAR6 MAPPING BEGIN
2636 020002 062737 000200 172354      ADD    @200,@KIPAR6 ;POINT TO NEXT 4K BLOCK >28K.
2637 020010 023737 172354 003124'      CMP    @KIPAR6,KTFLG ;END OF MEMORY?
2638 020016 101744      BLOS   30$         ;BR IF NO
2639 020020 004737 017166'      50$:  JSR    PC,KTOFF    ;TURN OFF MEMORY MAPPING
2640 020024 000241      CLC                    ;SET FAILURE
2641 020026 000403      BR     60$         ;
2642 020030 004737 017166'      55$:  JSR    PC,KTOFF    ;TURN OFF MEMORY MAPPING
2643 020034 000261      SEC                    ;SET SUCCESS
2644 020036 000207      60$:  RTS    PC
2645
2646      .SBTTL  REGSAV  . SAVE R1-R5 ON STACK
2647      ;+
2648      ;
2649      ;ROUTINE TO
2650      ;SAVE R1 THROUGH R5 ON THE STACK
2651      ;
2652      ;CALLING SEQUENCE:

```

```

2653
2654
2655
2656
2657
2658
2659
2660
2661
2662
2663
2664
2665
2666 020040
2667 020040 010446
2668 020042 010346
2669 020044 010246
2670 020046 010146
2671 020050 010546
2672 020052 016605 000012
2673 020056 004736
2674 020060 012601
2675 020062 012602
2676 020064 012603
2677 020066 012604
2678 020070 012605
2679 020072 000207
2680
2681
2682
2683
2684
2685
2686
2687
2688
2689
2690
2691
2692
2693
2694
2695
2696
2697
2698
2699
2700 020074
2701 020074
2702 020100
    020100 104443
    020102 000406
    020104 020130
    020106 000022
    020110 020132
    020112 000377
    020114 000000

;
; JSR R5,REGSAV
;
; THIS IS A COOROUTINE WHICH TRANSFER CONTROL BACK TO
; THE CALLING ROUTINE. AT THE END OF THE CALLING ROUTINE,
; THE RTS PC RETURNS CONTROL TO THIS ROUTINE TO RESTORE
; REGISTERS.
;
; THIS ROUTINE SHOULD ONLY BE CALLED FROM ROUTINES WHICH ARE
; CALLED VIA A JSR PC INSTRUCTION
;
; -
REGSAV:
    MOV R4,-(SP)
    MOV R3,-(SP)
    MOV R2,-(SP)
    MOV R1,-(SP)
    MOV R5,-(SP)
    MOV 10.(SP),R5
    JSR PC,8(SP)+
    MOV (SP)+,R1
    MOV (SP)+,R2
    MOV (SP)+,R3
    MOV (SP)+,R4
    MOV (SP)+,R5
    RTS PC

.SBTTL GETPAT - GET 8 BIT PATTERN FROM OPERATOR
; *
; ROUTINE TO REQUEST AN 8 BIT DATA PATTERN FROM THE OPERATOR
;
; INPUTS:
;
; NONE.
;
; OUTPUTS:
;
; R0 OCTAL NUMBER FROM THE OPERATOR
;
; CALLING SEQUENCE:
;
; JSR PC,GETPAT
;
; -
GETPAT::
1$: SAVREG ;SAVE THE GENERAL REGISTERS
    GMANID DATASC,PATDAT,0,377,0,377,NO
    TRAP C$GMAN
    BR 10000$
    .WORD PATDAT
    .WORD T$CODE
    .WORD DATASC
    .WORD 377
    .WORD T$LOLIM
    
```

```

020116 000377
020120
2703 020120 10000$; .WORD T$HILIM
020120 103367 020130' BNCOMPLETE 1$ ;RETRY IF ERROR
2704 020122 013700 BCC 1$
2705 020126 0J0207 MOV PATDAT,R0 ;DATA PATTERN FROM OPERATOR
RTS PC ;RETURN TO CALLER
2706
2707
2708 ;*
2709 ;LOCAL DATA AREA
2710 ;-
2711 020130 000000 PATDAT: .WORD 0 ;TEMPORARY STORAGE FOR DATA
2712 020132 105 116 124 DATASC: .ASCIZ 'ENTER DATA PATTERN'
2713 .EVEN
2714
2715 .SBTTL GETSEL - ISSUE MENU AND GET OPERATOR RESPONSE
2716 ;*
2717 ;
2718 ;ROUTINE TO ISSUE A MENU AND GET
2719 ;THE OPERATOR'S RESPONSE.
2720 ;
2721 ;INPUTS:
2722 ;
2723 ; R0 ADDRESS OF ASCIZ STRING OF MENU
2724 ; R1 MAXIMUM ALLOWABLE OPERATOR RESPONSE
2725 ;
2726 ;OUTPUTS:
2727 ;
2728 ; R0 NUMBER OF THE OPERATOR'S SELECTION
2729 ;
2730 ;-
2731
2732 020156 GETSEL::
2733 020156 SAVREG ;SAVE GENERAL REGISTERS
2734 020162 010002 MOV R0,R2 ;SAVE THE MENU ADDRESS
2735 020164 010203 MOV R2,R3 ;START OF MENU STRING
2736 020166 005713 TST (R3) ;END OF ASCII ?
2737 020170 001412 BEQ 3$ ;BRANCH IF ALL LINES DISPLAYED
2738 020172 PRINTF #SELASC,(R3)+ ;DISPLAY THE MENU
020172 012346 MOV (R3)+,-(SP)
020174 012746 020342' MOV #SELASC,-(SP)
020200 012746 000002 MOV #2,-(SP)
020204 010600 MOV SP,R0
020206 104417 TRAP C$PNTF
020210 062706 000006 ADD #6,SP
2739 020214 000764 BR 2$
2740 020216 3$: ;GMANID MENASC,MENRES,D,-1,0,-1,NO
020216 104443 TRAP C$GMAN
020220 000406 BR 10001$
020222 020376' .WORD MENRES
020224 000042 .WORD T$CODE
020226 020347' .WORD MENASC
020230 177777 .WORD -1
020232 000000 .WORD T$LOLIM
020234 177777 .WORD T$HILIM
10001$:
2741 020236 BNCOMPLETE 1$ ;RETRY IF ERROR
  
```

```

020236 103352
2742 020240 013700 020376'
2743 020244 020001
2744 020246 101411
2745 020250
      020250 012746 020274'
      020254 012746 000001
      020260 010600
      020262 104417
      020264 062706 000004
2746 020270 000735
2747 020272 000207
2748 020274 045 116 045 MENERR: .ASCIZ 'MNA *** Menu Selection Too Large ***'
2749 020342 045 116 045 SELASC: .ASCIZ 'MNT'
2750 020347 105 156 164 MENASC: .ASCIZ 'Enter Menu Selection: '
2751
2752 020376 000000
2753
2754
2755
2756
2757
2758
2759
2760
2761
2762
2763
2764
2765
2766
2767
2768
2769
2770
2771
2772
2773
2774
2775
2776 020400
2777 020400
2778 020404 104450
2779 020406 103411
2780 020410
      020410 012746 020434'
      020414 012746 000001
      020420 010600
      020422 104417
      020424 062706 000004
2781 020430 000241
2782 020432 000207
2783
2784 020434 045 116 045 NOMAN: .ASCIZ 'MNA *** Manual Intervention not Allowed - Test Aborted ***'
2785

```

```

      BCC 1$
      MOV MENRES,R0 ;GET THE OPERATOR'S REPLY
      CMP R0,R1 ;COMPARE TO MAXIMUM ALLOWED
      BLOS 5$ ;BRANCH IF OK
      PRINTF @MENERR ;DISPLAY ERROR MESSAGE
      MOV @MENERR,-(SP)
      MOV @1,-(SP)
      MOV SP,R0
      TRAP C$PNTF
      ADD @4,SP
      BR 1$ ;RETRY
      RTS PC ;RETURN TO CALLER
      5$:
      MENERR: .ASCIZ 'MNA *** Menu Selection Too Large ***'
      SELASC: .ASCIZ 'MNT'
      MENASC: .ASCIZ 'Enter Menu Selection: '
      .EVEN
      MENRES: .WORD 0
      .SBTTL CHKMAN - CHECK MANUAL INTERVENTION LEGALITY
      ;*
      ;
      ;ROUTINE TO TEST FOR MANUAL INTERVENTION LEGALITY.
      ;INPUT:
      ;
      ; NONE.
      ;OUTPUT:
      ;
      ; CARRY 0 MANUAL INTERVENTION NOT ALLOWED
      ; 1 MANUAL INTERVENTION IS OK
      ;SIDE EFFECTS:
      ;
      ; A MESSAGE IS DISPLAYED WARNING THAT TEST IS
      ; NOT EXECUTED IF MANUAL INTERVENTION IS NOT
      ; ALLOWED.
      ;-
      CHKMAN:
      SAVREG ;SAVE THE REGISTERS
      MANUAL ;SEE IF MANUAL INTERVENTION OK
      TRAP C$MANI
      BCOMPLETE 1$ ;BRANCH IF ALLOWED
      BCS 1$
      PRINTF @NOMAN ;PRINT THE WARNING MESSAGE
      MOV @NOMAN,-(SP)
      MOV @1,-(SP)
      MOV SP,R0
      TRAP C$PNTF
      ADD @4,SP
      CLC ;CLEAR CARRY FOR ERROR
      RTS PC ;RETURN
      1$:

```

```

2786
2787           .SBTTL ENVIRN - SETUP FREE DIAGNOSTIC SPACE
2788
2789           ; SUBROUTINE TO SET-UP VARIOUS ENVIRONMENTAL PARAMETERS.
2790
2791           ;
2791 020530      ENVIRN: MEMORY R0
2791 020530      104431      TRAP C$MFM
2792 020532      010037      003116'      MOV R0,FREE           ; GET 1ST FREE ADDRESS...
2793 020536      062737      000002      003116'      ADD #2,FREE
2794 020544      011037      003120'      MOV (R0),FRESIZ      ; ...AND WORD COUNT.
2795 020550      162737      000004      003120'      SUB #4,FRESIZ
2796 020556      013702      002012'      MOV L$UNIT,R2           ; GET NUMBER OF UNITS
2797 020562      162737      000007      003120'      10$: SUB #7,FRESIZ      ; TAKE AWAY 7 WORDS PER UNIT
2798 020570      005302
2799 020572      001373      BNE 10$
2800 020574      013700      003116'      MOV FREE,R0           ;GET FIRST FREE ADDRESS
2801 020600      063700      003120'      ADD FRESIZ,R0        ;POINT TO LAST FREE ADDRESS
2802 020604      162700      000002      SUB #2,R0             ;BACKUP 1 WORD
2803 020610      010037      003122'      MOV R0,FREEHI        ;STORE LAST FREE ADDRESS
2804 020614      000207      40$:      RTS PC                 ;RETURN
2805
2806           .SBTTL KTINIT - SETUP KT11 MEMORY MANAGEMENT REGISTERS
2807
2808           ;+
2809           ;
2810           ;ROUTINE TO INIT KT-11
2811           ;
2812           ;-
2813           KTINIT:
2814 020616      005037      003124'      CLR KTFLG           ; INIT >28K MEMORY FLAG
2815 020622      005037      003126'      CLR KTENABLE        ; INIT TEST >28K FLAG
2816 020626      023727      002120'      001577      CMP L$HIME,#1577    ; GOT ENOUGH MEMORY (>28K)?
2817 020634      101453      BLOS 9$              ; NO.
2818 020636      023727      002120'      001777      CMP L$HIME,#1777    ; GOT ENOUGH MEMORY (>32K)?
2819 020644      101447      BLOS 9$              ; NO.
2820 020646      013700      000004      MOV #ERRVEC,R0      ; SAVE OLD ERR VEC PTR.
2821 020652      012737      020744'      000004      MOV #2$,#ERRVEC     ; SET ERR VEC PTR.
2822 020660      005737      177572      TST #SRO            ; GOT KT11?
2823 020664      000240      NOP                ; (TRAP IF NO).
2824 020666      013737      002120'      003124'      MOV L$HIME,KTFLG   ; YES. SET KT FLAG.
2825 020674      042737      000177      003124'      DIC #177,KTFLG
2826 020702      010037      000004      MOV R0,#ERRVEC     ; RESTORE OLD ERR VEC PTR.
2827 020706      005000      CLR R0             ; R0 = AR DATA.
2828 020710      012701      172340      MOV #KIPAR,R1      ; R1 = KI REGS PTR.
2829 020714      012761      077406      177740      1$: MOV #77406,-40(R1) ; SET DESCRIPTOR REG.
2830 020722      010021      MOV R0,(R1)+       ; SET KIPAR REG.
2831 020724      062700      000200      ADD #200,R0        ; BUMP AR DATA BY "4K".
2832 020730      020027      002000      CMP R0,#2000       ; AT "I/O"?
2833 020734      001367      BNE 1$            ; NO.
2834 020736      012741      177600      MOV #177600,-(R1) ; YES. SET KTPAR? FOR I/O.
2835 020742      000410      BR 9$
2836
2837 020744      012716      020760'      2$: MOV #6$,(SP)     ; SET UP RETURN
2838 020750      000002      RTI                ; RTI TO NEXT LOCATION
2839
2840
2841 020752      012716      021006'      3$: MOV #10$,(SP)    ; SET UP RETURN

```

```

2842 020756 000002          RTI          ; RTI TO NEXT LOCATION
2843
2844 020760 010037 000004    6$:  MOV    R0,#ERRVEC    ; RESTORE OLD ERR VEC PTR.
2845
2846 020764          9$:
2847 020764 013700 000004    MOV    @ERRVEC,R0    ; SAVE OLD ERR VEC PTR.
2848 020770 012737 020752' 000004    MOV    #3,@ERRVEC    ; SET ERR VEC PTR.
2849 020776 042737 000001 170200    BIC    @BIT0,@MMRO    ;BE SURE UNIBUS MAP IS OFF
2850 021004 000240          NOP
2851 021006 010037 000004    10$: MOV    R0,@ERRVEC    ; RESET VECTOR BACK TO ERROR POINTER
2852 021012 000207          RTS    PC
2853
2854
2855          ;+
2856          ; SUBROUTINE TO SET EXTENDED FEATURES SWITCH
2857          ;
2858          ; Requires that SOFINIT and WRTCHR have been done previous to call.
2859          ;
2860          ;
2861          ; INPUTS:
2862          ; R5      CURRENT UNIT NUMBER
2863          ; OUTPUTS:
2864          ; The Extended Features Switch is set.
2865          ;
2866          ;-
2867
2868 021014          INVERT::
2869
2870 021014 005737 002220'    TST    EXTFEA        ; IS SWITCH SET?
2871 021020 001020          BNE    1$            ; YES,EXIT STAGE RIGHT!(or the next one outa town!)
2872 021022 012737 100206 021070'    MOV    #100206,CMDPKT ; WRT SUB-SYS MEM CMD
2873 021030 012737 021100' 021072'    MOV    @WSMBK,CMDPKT+2 ; MSG BUF ADDR
2874 021036 012737 000006 021076'    MOV    #6,CMDPKT+6    ; BYTE COUNT
2875 021044 012737 100010 021100'    MOV    #100010,WSMBK  ; INVERT THE SWITCH
2876 021052 012704 021070'    MOV    @CMDPKT,R4    ; SET CMDPKT INTO R4
2877 021056 004737 010552'    JSR    PC,WRTCHR     ; DO IT
2878 021062 000207          1$:  RTS    PC        ; RETURN
2879
2880
2881          ; COMMAND PACKET.
2882
2884 021064          .BLKB 10-<. -TSV2&7>
2886
2887 021070 000000          CMDPKT:: 0           ;1ST WORD IS TSO5 COMMAND.
2888 021072 000000          0           ;2ND WORD IS THE BUFFER LOW ADDRESS.
2889 021074 000000          0           ;3RD WORD IS THE BUFFER HIGH ADDRESS.
2890 021076 000000          0           ;4TH WORD IS THE BYTE/RECORD/FILE COUNT.
2891
2892
2893          ; WRITE SUB-SYSTEM MEMORY CHARACTERISTIC BLOCK.
2894
2895 021100 000000          WSMBK:: 0           ;1ST WORD:: SEL 0
2896 021102 000000          0           ;2ND WORD:: SEL 2
2897 021104 000000          0           ;3RD WORD:: SEL 4
2898          .EVEN
2899
2900          ;+
    
```

```

2901      |          SUBROUTINE TO CHECK WETHER OR NOT WE'LL TEST NXM
2902      |
2903      |
2904      | INPUTS:
2905      | OUTPUTS:
2906      |          The NXMFLG is set if we can test.
2907      |          The NXMLO and NXMHI addresses are setup.
2908      |
2909      |
2910      | MEMCK::
2911      |
2912      |          SAVREG          ;SAVE THE REGISTERS
2913      |          CLR          NXMFLG      ;CLEAR THE FLAG
2914      |          CLR          NXMLO      ;CLEAR THE TEST ADDRESS LO
2915      |          CLR          NXMHI      ;CLEAR THE TEST ADDRESS HI
2916      |          BIT          @170000,L#HIME ;CHECK FOR MORE THAN 18 BITS INDICATED
2917      |
2918      |          BNE          14I        ;FROM THE SUPERVISOR
2919      |          TST          T23B      ;BR, IF MAP BOX ETC.
2920      |          BEQ          1I        ;IS IT A PROCESSOR TYPE B?
2921      |          CMP          L#HIME,@7777 ;NO
2922      |          BLO          2I        ; GREATER THAN 128K
2923      |          JSR          PC,NXMTST ; NO
2924      |          BR          13I       ;SETUP THE ADDRESS
2925      |          TST          T23A      ;SET THE FLAG AND EXIT
2926      |          BEQ          4I        ;IS IT A PROCESSOR TYPE A?
2927      |          CMP          L#HIME,@5777 ;NO
2928      |          BHI          14I       ;GREATER THAN 96K
2929      |          CMP          L#HIME,@3777 ;YES,23A/23B WITH 128K MEMORY
2930      |          BLO          4I        ;GREATER THAN 64K BUT LESS THAN 92K?
2931      |          JSR          PC,NXMTST ;NO, CHECK 24K
2932      |          BR          13I       ;SETUP THE ADDRESS
2933      |          CMP          L#HIME,@1577 ;SET THE FLAG AND EXIT
2934      |          BLO          14I       ;GREATER THAN 24K BUT LESS THAN 64K?
2935      |          JSR          PC,NXMTST ;NO, TELL THEM AND EXIT WITH FLAG CLEAR
2936      |          ADD          @77,NXMHI ;SETUP THE ADDRESS
2937      |          BIT          @177774,NXMHI ;FOOL THE 11/02 & 11/03
2938      |          BNE          15I       ;ANY MORE THAN 18 BITS SET?
2939      |          INC          NXMFLG    ;BR, IF MORE THAN 18 BITS SET
2940      |          BR          15I       ;SET THE FLAG
2941      |          PRINTF      @NOMEM     ;EXIT
2942      |          MOV          @NOMEM,-(SP) ;NOP FOR PRINTOUT
2943      |          MOV          @1,-(SP)   ;TELL THEM & EXIT ***NO PRINT*****
2944      |          MOV          SP,R0
2945      |          TRAP        C#PNTF
2946      |          ADD          @4,SP
2947      |          RTS          PC          ;RETURN
2948      |
2949      |          SUBROUTINE TO SETUP THE NXM ADDRESS FOR TESTING
2950      |
2951      |          OUTPUTS:NXMLO,NXMHI    ;SETUP WITH NXM ADDRESS
2952      |
  
```

C7

TSV3 - GLOBAL AREAS MACRO M1113 01-FEB-84 18:55
KTINIT - SETUP KT11 MEMORY MANAGEMENT REGISTERS

SEG 080

2953	021302	013701	002120'	NXMTST: MOV	L#HIME,R1	;GET TOP OF MEMORY
2954	021306	062701	000200	ADD	#200,R1	;MAKE IT I/O BLOCK OR OTHER NXM
2955	021312	042701	000177	BIC	#177,R1	
2956	021316	010102		MOV	R1,R2	;RESAVE RESULTS
2957		000006		.REPT	6	
2958				ASL	R1	;PUT IN PLACE FOR XFER
2959				.ENDR		
2960	021334	010137	003132'	MOV	R1,NXMLO	;SAVE TEST ADDRESS LOW
2961		000012		.REPT	10.	
2962				ASR	R2	;PUT IN PLACE FOR XFER
2963				.ENDR		
2964	021364	042702	177700	BIC	#177700,R2	;DON'T WANT ILA!
2965	021370	010237	003134'	MOV	R2,NXMHI	;SAVE TEST ADDRESS HIGH
2966	021374	000207		RTS	PC	;RETURN
2967						
2968						
2969						
2970						
2971	021376			ENDMOD		


```

6          .TITLE  TSV4 - MISCELLANEOUS SECTIONS
7
8 021376   BGNMOD  TSV4
9 021376   TSV4::
10
11
12
13
14          .SBTTL  PROTECTION TABLE
15          BGNPROT
16          L$PROT::
17 021376   177777 177777 177777 .WORD  -1, -1, -1, -1      ;NO DEVICE PROTECTION REQUIRED.
18 021376   .ENDPROT
19 021406   .SBYTL  INITIALIZE SECTION
20
21
22          ;++
23          ;THE INITIALIZE SECTION CONTAINS THE CODING THAT IS PERFORMED
24          ;AT THE BEGINNING OF EACH PASS.
25
26          ;
27          ;IF "START" OR "RESTART", SET QUICK-PASS FLAG AND BUS-INIT.
28          ;IF "CONTINUE", NOTHING IS REQUIRED.
29          ;
30          ;--
31          ;
32          ;INSERT TEMPORARY JUMP TO ODT
33          ;-
34 021406   BGNINIT
35 021406   L$INIT::
36 021406   005037 002220' 40$: CLR      EXTFEA
37 021412   005037 003130' CLR      NXMFLG
38 021416   012737 006166' 002172' MOV     @EPT1,EPTSW      ;SET UP PRIMARY MESSAGE FOR REPLACEMENT
39 021424   005037 003146' CLR      SIFLAG      ;CLEAR "SOFT INIT" FLAG
40 021430   005037 003126' CLR      KTENABLE    ;CLEAR TEST ABOVE 28K FLAG
41 021434   005037 002274' CLR      RAMSIZ     ;CLEAR RAM SIZE FOR RAMERR ROUTINE
42 021440   012700 000036 READEF  @EF.CONTINUE
43 021444   104447 MOV     @EF.CONTINUE,R0
44 021446   103023 TRAP   C$REFG
45 021450   023737 002174' 002012' BNCOMplete 1$
46 021456   103070 BCC    1$
47 021460   005737 003106' CMP     UNITN,L$UNIT    ;UNIT IN RANGE?
48 021464   100472 BHIS   4$           ;BR IF NO.
49 021466   013701 002174' TST    DUFFLG        ;DROPPED UNIT?
50 021472   006301 BMI    NXTU         ;BR IF YES
51 021474   005761 003170' MOV     UNITN,R1
52 021500   001516 ASL    R1
53 021502   032761 040000 003170' TST    ERTABL(R1)
54 021510   001060 BEQ    SETU
55 021512   104432 BIT    @BIT14,ERTABL(R1) ;DROPPED?
56 021514   000416 BNE    NXTU
57 021516   012700 000035 EXIT   INIT          ;DO NOTHING IF "CONTINUE".
58 021522   104447 TRAP   C$EXIT
59 021524   021524 .WORD  L10030-.
60 021526   000035 READEF  @EF.NEW
61          MOV     @EF.NEW,R0
62          TRAP   C$REFG
63          BNCOMplete NXTU      ;TAKE NEXT UNIT IF NOT NEW PASS.
64          BCC    NXTU
65          READEF  @EF.START

```

TSV4 - MISCELLANEOUS SECTIONS MACRO M1113 01-FEB-84 18:55
INITIALIZE SECTION

SEQ 082

021526	012700	000040		MOV	DEF,START,RO	
021532	104447			TRAP	C#REFG	
57 021534				BCOMPLETE	2#	
021534	103404			BCS	2#	
58 021536				READEF	DEF.RESTART	
021536	012700	000037		MOV	DEF.RESTART,RO	
021542	104447			TRAP	C#REFG	
59 021544				BNCOMPLETE	31#	
021544	103031			BCC	31#	
60 021546			2#:			;1ST PASS, BUS-INIT...
61 021546				BRESET		;BUS RESET.
021546	104433			TRAP	C#RESET	
62 021550	005037	002206'		CLR	TSTCNT	;NUMBER OF TESTS RUN IN PASS
63 021554	005037	002214'		CLR	FATFLG	;CLEAR FATAL ERROR COUNT
64 021560	005037	003136'		CLR	T23A	;CLEAR PROCSSOR TYPE A FLAG
65 021564	005037	003140'		CLR	T23B	;CLEAR PROCSSOR TYPE B FLAG
66				MOV	#340,-(SP)	
67				MOV	#20#,-(SP)	;RETURN TO DEBUGGER
68				JMP	0.00T	;ENTER THE DEBUGGER
69 021570	005037	003372'		CLR	SKIPT	;CLEAR THE SUBTEST "SKIPPER"
70 021574			20#:			
71 021574	012737	177777	002176'	MOV	#-1,QVP	;...QUICK VERIFY...
72 021602	004737	020530'		JSR	PC,ENVIRN	;SET ENVIRONMENT.
73 021606	004737	020616'		JSR	PC,KTINIT	;INITIALIZE KT MEMORY MANAGEMENT
74 021612	012700	003170'		MOV	ERTABL,RO	
75 021616	005020		30#:	CLR	(RO)+	;CLEAR THE ERROR TABLE
76 021620	020027	003370'		CMP	RO,ERTABE	
77 021624	103774			BLO	30#	
78 021626	000404			BR	4#	
79 021630	005037	002176'	31#:	CLR	QVP	
80 021634	000137	021704'		JMP	PASRPT	;GO REPORT THE STATUS
81						
82 021640			4#:			
83 021640	012737	177777	002174'	NEWPAS:	MOV	#-1,UNITN
84 021646	005037	002212'		CLR	DEV CNT	;INIT UNIT NUMBER...
85 021652			NXTU:	BREAK		;CLEAR COUNT OF DEVICES RUNNING
021652	104422			TRAP	C#BRK	
86 021654	005237	002174'		INC	UNITN	;...AND SET NEXT UNIT NUMBER.
87 021660	023737	002174'	002012'	CMP	UNITN,L#UNIT	
88 021666	103423			BLO	SETU	
89 021670	012737	177777	003104'	MOV	#-1,DUFLG	
90 021676	000401			BR	11#	
91 021700				DOCLN		;ABORT, NO MORE UNITS.
021700	104444			TRAP	C#DCLN	
92 021702	000240		11#:	NOB		
93 021704			PASRPT:			
94 021704	023727	002012'	000001	CMP	L#UNIT,#1	;HOW MANY UNITS SELECTED?
95 021712	101752			BLOS	NEWPAS	;BR IF ONLY 1
96 021714	005737	002212'		TST	DEV CNT	;ARE ANY STILL RUNNING?
97 021720	001747			BEQ	NEWPAS	;BR IF NO
98 021722				RFLAGS	RO	
021722	104421			TRAP	C#RFLA	
99 021724	032700	000100		BIT	#ISR,RO	;SHOULD WE PRINT STATISTICS
100 021730	001343			BNE	NEWPAS	;BR IF NO
101						
102 021732				DORPT		
021732	104424			TRAP	C#DRPT	

TSV4 - MISCELLANEOUS SECTIONS MACRO M1113 01-FEB-84 18:55
INITIALIZE SECTION

SEQ 083

```

103 021734 000741          BR      NEWPAS
104 021736                10$:
105
106 021736                SETU:  GPARD  UNITN,RO      ;GET UNIT N P-TABLE POINTER.
    021736 013700 002174'  MOV      UNITN,RO
    021742 104442          TRAP    C$GPARD
107 021744                BNCOMplete NXTU      ;BR IF UNIT NOT AVAILABLE.
    021744 103342          BCC     NXTU
108 021746 005037 003104'  CLR     DUFLG      ;CLEAR "DROPPED" FLAG.
109 021752 005237 002212'  INC     DEVCNT
110 021756 012001          MOV     (RO)+,R1      ;GET 1ST REGISTER ADDRESS.
111 021760 010137 002200'  MOV     R1,CSRADDR  ;ADDRESS OF REGISTERS OF UNIT UNDER TEST
112
113 021764 012001          MOV     (RO)+,R1      ;GET VECTOR ADDRESS.
114                ;MOV    (RO),R2      ;GET INTERRUPT PRIORITY
115                ;MOV    R2,IPRI     ;SET INTERRUPT PRIORITY.
116 021766 010137 002202'  MOV     R1,IVVEC    ;SET INTERRUPT VECTOR POINTER...
117 021772 012721 016106'  MOV     @INTR,(R1)+  ;...VECTOR...
118 021776 013721 002204'  MOV     IPRI,(R1)+  ;...AND PRIORITY.
119
120 022002                1$:
121                ;      TST    QVP      ;1ST PASS ??
122                ;      BEQ    5$      ;NO, SKIP THE PASS 1 STUFF.
123
124                ;
125                ;1ST PASS, CHECK THAT DEVICE ADDRESSES ARE VALID, AND
126                ;THAT THE DISPLAY STATUS IS PROPERLY INITIALIZED.
127                ;
128 022002 013701 002174'  MOV     UNITN,R1
129 022006 006301          ASL     R1
130 022010 052761 100000 003170'  BIS    @BIT15,ERTABL(R1) ;SAY DEVICE RUNNING
131 022016 005037 005600'  CLR    EXTA      ;CLEAR ERROR EXTENSION FLAG.
132 022022 023727 002012' 000001  CMP    L$UNIT,@1   ;ARE WE TESTING MULTIPLE UNITS?
133 022030 101416          BLOS   10$      ;BR IF NO.
134 022032                RFLAGS  RO      ;YES -- GET OPERATOR FLAGS.
    022032 104421          TRAP    C$RFLA
135 022034 032700 001000'  BIT    @PNT,RO    ;SHOULD WE PRINT UNIT @?
136 022040 001412          BEQ    10$      ;BR IF NOT.
137 022042                PRINTF  @PUNIT,UNITN ;PRINT THE UNIT @
    022042 013746 002174'  MOV     UNITN,-(SP)
    022046 012746 022134'  MOV     @PUNIT,-(SP)
    022052 012746 000002          MOV     @2,-(SP)
    022056 010600          MOV     SP,RO
    022060 104417          TRAP    C$PNTF
    022062 062706 000006          ADD     @6,SP
138 022066                10$:
139 022066 005037 003106'  CLR    NODEV
140 022072 013701 002200'  MOV    CSRADDR,R1 ;ADDRESS OF FIRST REGISTER
141 022076 010102          MOV    R1,R2      ;START OF REGISTERS
142 022100 062702 000002          ADD    @TSSR,R2   ;ADDRESS OF TSSR REGISTER
143 022104 004737 016266'  JSR    PC,XNXM    ;TEST BOTH CONTROLLER REGISTERS...
144 022110 103005          BCC    2$      ;...AND BR IF ALL OK.
145 022112 010137 003106'  MOV    R1,NODEV   ;FLAG DEVICE AS NON-EXISTENT
146 022116 012737 177777 003104'  MOV    @-1,DUFLG  ;DROP THIS UNIT.
147 022124                2$:
148                ;
149                ;FINALLY, SET CPU PRIORITY AND WE'RE DONE.

```

TSV4 - MISCELLANEOUS SECTIONS MACRO M1113 01-FEB-84 18:55
INITIALIZE SECTION

SEQ 084

```

150
151 022124          5$:  SETPRI  #PRI00          ;ENABLE INTERRUPTS.
    022124 012700 000000
    022130 104441
152 022132          L10030:
    022132
    022132 104411          TRAP  C$INIT
153
154 022134          045      116      045  PUNIT:  .ASCIZ  /#N#A***** TESTING UNIT #D#A *****/
155          .EVEN
156
157          .SBTTL  ADD AND DROP UNITS SECTIONS
158
159          ;**
160          ; THE ADD-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
161          ; TO BE (A) ADDED TO THE TEST LIST FOR THE FIRST TIME,
162          ; OR (B) RE-INSERTED IF IT HAD BEEN PREVIOUSLY DROPPED.
163          ;--
164 022202          BGNUA
    022202
165 022202 010001          L$AU:;
166 022204 006301          MOV      RO,R1          ; GET UNIT TO BE ADDED (RO)
167 022206 052761 100000 003170'  ASL      R1          ; MAKE IT A WORD INDEX
168 022214 042761 040000 003170'  BIS      #100000,ERTABL(R1) ; SET THE "ACTIVE" BIT
169 022222          BIC      #40000,ERTABL(R1) ; CLEAR THE "DROPPED" BIT
    022222 010046          PRINTF  #1$,RO
    022224 012746 022250'  MOV      RO,-(SP)
    022230 012746 000002  MOV      #1,-(SP)
    022234 010600          MOV      #2,-(SP)
    022236 104417          MOV      SP,RO
    022240 062706 000006  TRAP    C$PNTF
170 022244          ADD      #6,SP
    022244 000167          EXIT    AU
    022246 000026          .WORD   J$JMP
171 022250          .WORD   L10031-2-
    045      116      045  1$:  .ASCIZ  /#N#A UNIT #D#A ADDED/
172          .EVEN
173
174 022276          ENDAU          ; UNUSED.
    022276
    022276 104452          L10031:
          TRAP    C$AU
175
176          ;**
177          ; THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
178          ; TO BE REMOVED FROM THE TEST LIST.
179          ;
180          ; SUPVSR DOES THE "DROPPING". THIS IS JUST TO TELL THE MAN.
181          ; "DROPPED" UNITS ARE RE-SELECTED ON OPERATOR "STA" OR "ADD"
182          ; COMMAND, OTHERWISE REMAIN INACTIVE. THE "DISPLAY" COMMAND
183          ; WILL PRINT ALL DROPPED UNITS, AND THE P-TABLES OF THOSE
184          ; WHICH ARE STILL ACTIVE.
185          ; UPON ENTRY, RO CONTAINS THE UNIT TO BE DROPPED.
186 022300          BGNDU
    022300
187 022300 012737 177777 003104'  L$DU:;
188 022306 010001          MOV      #-1,DUFLG
189 022310 006301          MOV      RO,R1
190 022312 052761 140000 003170'  ASL      R1
          BIS      #140000,ERTABL(R1) ; SAY DROPPED

```

```

191 022320 000240 000240 000240      240,240,240      ; ??????????
192 022326                                PRINTF #1$,R0
      022326 010046                        MOV RO,-(SP)
      022330 012746 022354'                MOV #1,-(SP)
      022334 012746 000002                MOV #2,-(SP)
      022340 010600                        MOV SP,R0
      022342 104417                        TRAP C$PNTF
      022344 062706 000006                ADD #6,SP
193 022350                                EXIT DU
      022350 000167                        .WORD J$JMP
      022352 000030                        .WORD L10032-2-
194 022354 045 116 045 1$:              .ASCIZ /%N%A UNIT %DWA DROPPED/
195 .EVEN
196 022404                                ENDDU
      022404                                L10032:
      022404 104453                        TRAP C$DU
197 .***
198 ; AUTO-DROP CODE SECTION.
199 ;--
200 022406                                BGNAUTO
      022406                                L$AUTO::
201 022406 013705 002200'                MOV CSRADDR,R5 ;POINT TO DEVICE REGISTER
202 022412 012703 000550                MOV #360.,R3 ;ENOUGH TIME FOR 2400' REEL TO REWIND
203 022416 004737 016140'                JSR PC,WAITF ;WAIT FOR SSR TO SET
204 022422 103420                        BCS 20$ ;LEAVE WHEN SSR IS SET
205 022424                                DELAY 250. ;WAIT FOR .25 SECONDS
      022424 012727 000372                MOV #250.,(PC)+
      022430 000000                        .WORD 0
      022432 013727 002116'                MOV L$DLY,(PC)+
      022436 000000                        .WORD 0
      022440 005367 177772                DEC -6(PC)
      022444 001375                        BNE -.4
      022446 005367 177756                DEC -22(PC)
      022452 001367                        BNE -.20
206 022454 005303                        DEC R3 ;BUMP COUNTER DOWN
207 022456 001357                        BNE 10$ ;KEEP GOING
208 022460 004737 017074'                JSR PC,CKDROP ;TRY AND DROP UNIT
209 022464
210 022464                                20$:
      022464                                ENDAUTO ; UNUSED.
      022464 104461                        L10033:
      022464                                TRAP C$AUTO
211 .SBTTL CLEAN-UP AND REPORT CODING SECTIONS
212
213
214 .***
215 ; THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS
216 ; EXECUTED AT THE END OF EACH PASS (OR SUB-PASS).
217 ; USE TO RETURN DEVICE UNDER TEST TO A NEUTRAL STATE.
218 ;--
219 022466                                BGNCLN
      022466                                L$CLEAN::
220 022466 013705 002200'                MOV CSRADDR,R5 ;POINT TO DEVICE REGISTER
221 022472 005737 003104'                TST DUFLG ;"DROPPED" FLAG IS SET ON...
222 022476 100405                        BMI 1$ ;...AND GROSS CONTROLLER FAULT...
223 . ;...DON'T TRY TO XCT CLEANUP CODE.
224
225 022500 012765 000000 000002                MOV #0,TSSR(R5) ;DO SOFT INIT

```

226	022506	004737	016140'		JSR	PC, WAITF	
227	022512			1\$:			
228	022512			2\$:	ENDCLN		
	022512			L10034:			
	022512	104412			TRAP	C\$CLEAN	
229				;	++		
230				;	THE REPORT CODING SECTION CONTAINS THE		
231				;	"PRINTS" CALLS THAT GENERATE STATISTICAL REPORTS.		
232				;	--		
233	022514				BGNRPT		
	022514			L\$RPT::			
234	022514				PRINTS	#DEVSUM	
	022514	012746	022756'		MOV	#DEVSUM, -(SP)	
	022520	012746	000001		MOV	#1, -(SP)	
	022524	010600			MOV	SP, R0	
	022526	104416			TRAP	C\$PNTS	
	022530	062706	000004		ADD	#4, SP	
235	022534	010246			MOV	R2, -(SP)	
236	022536	010346			MOV	R3, -(SP)	
237	022540	010446			MOV	R4, -(SP)	
238	022542	012704	003170'		MOV	#ERTABL, R4	; GET START OF ERROR TABLE.
239	022546	005003			CLR	R3	; CLEAR UNIT NUMBER
240	022550	011402		1\$:	MOV	(R4), R2	; GET ERROR TABLE ENTRY & TEST IT.
241	022552	001467			BEQ	4\$; ZERO IF UNIT NOT RUN
242	022554	100066			BPL	4\$	
243	022556	032702	040000		BIT	#BIT14, R2	; WAS UNIT DROPPED?
244	022562	001015			BNE	2\$; BR IF YES
245	022564	042702	170000		BIC	#1C7777, R2	; GET ERROR COUNT FIELD
246	022570				PRINTS	#DEVONL, R3, R2	; PRINT
	022570	010246			MOV	R2, -(SP)	
	022572	010346			MOV	R3, -(SP)	
	022574	012746	023013'		MOV	#DEVONL, -(SP)	
	022600	012746	000003		MOV	#3, -(SP)	
	022604	010600			MOV	SP, R0	
	022606	104416			TRAP	C\$PNTS	
	022610	062706	000010		ADD	#10, SP	
247	022614	000446			BR	4\$	
248	022616	020227	160000	2\$:	CMP	R2, #160000	; WAS UNIT NON-EXISTENT?
249	022622	001012			BNE	3\$; BR IF NO
250	022624				PRINTS	#DEVNXR, R3	
	022624	010346			MOV	R3, -(SP)	
	022626	012746	023063'		MOV	#DEVNXR, -(SP)	
	022632	012746	000002		MOV	#2, -(SP)	
	022636	010600			MOV	SP, R0	
	022640	104416			TRAP	C\$PNTS	
	022642	062706	000006		ADD	#6, SP	
251	022646	000431			BR	4\$	
252	022650	020227	160001	3\$:	CMP	R2, #160001	; WAS UNIT NOT READY AT STARTUP?
253	022654	001012			BNE	30\$; BR IF NO.
254	022656				PRINTS	#DEVNRD, R3	
	022656	010346			MOV	R3, -(SP)	
	022660	012746	023145'		MOV	#DEVNRD, -(SP)	
	022664	012746	000002		MOV	#2, -(SP)	
	022670	010600			MOV	SP, R0	
	022672	104416			TRAP	C\$PNTS	
	022674	062706	000006		ADD	#6, SP	
255	022700	000414			BR	4\$	

J7

TSV4 - MISCELLANEOUS SECTIONS MACRO M1113 01-FEB-84 18:55
CLEAN-UP AND REPORT CODING SECTIONS

SEQ 087

```

256 022702 042702 170000      30$: BIC      #C7777,R2
257 022706      PRINTS  #DEVDR0,R3,R2
      022706 010246      MOV      R2,-(SP)
      022710 010346      MOV      R3,-(SP)
      022712 012746 023226'  MOV      #DEVDR0,-(SP)
      022716 012746 000003  MOV      #3,-(SP)
      022722 010600      MOV      SP,R0
      022724 104416      TRAP     C#PNTS
      022726 062706 000010  ADD      #10,SP
258 022732 062704 000002      4$: ADD      #2,R4
259 022736 005203      INC      R3
260 022740 020427 003370'  CMP      R4,#ERTABE
261 022744 103701      BLO     1#
262 022746 012604      MOV      (SP)+,R4
263 022750 012603      MOV      (SP)+,R3
264 022752 012602      MOV      (SP)+,R2
265 022754      ENDRPT      ; UNUSED.
      022754      L10035:
      022754 104425      TRAP     C#RPT
266
267
268 022756      045      116      045  DEVSUM: .ASCIZ /#N#ADEVICE STATUS SUMMARY:#N/
269 023013      045      101      040  DEVONL: .ASCIZ /#A UNIT #D3#A ONLINE, ERRORS = #D#N/
270 023063      045      101      040  DEVNXR: .ASCIZ /#A UNIT #D3#A DROPPED, NON-EXISTENT REGISTER#N/
271 023145      045      101      040  DEVNRD: .ASCIZ /#A UNIT #D3#A DROPPED, NOT READY AT STARTUP#N/
272 023226      045      101      040  DEVDR0: .ASCIZ /#A UNIT #D3#A DROPPED, ERRORS = #D#N/
273      .EVEN
274
275 023276      ENDMOD
276
277
278

```


167	023760	004737	031726'		JSR	PC,T29REST		;SET COMMAND PACKET		
168	023764	004737	032020'		JSR	PC,T29RT2		;SET UP OTHER COMMAND PACKET		
169	023770	004737	032062'		JSR	PC,T29RT3		;SET UP OTHER COMMAND PACKET		
170	023774	004737	015664'		JSR	PC,SOFINIT		;DO INITIALIZE ON CONTROLLER		
171	024000	103407			RCS	20\$;BR IF INIT WAS OK		
172	024002	005237	002214'		INC	FATFLG		;ERROR COUNT		
176	024006	010001			MOV	R0,R1		;CONTENTS OF TSSR REGISTER		
177	024010				ERRDF	ERRNO,SFIERR,SFIMSG		;FATAL ERROR TSSR WAS NOT OK		
	024010	104455						TRAP	C\$ERDF	
	024012	000154						.WORD	108	
	024014	003642'						.WORD	SFIERR	
	024016	011724'						.WORD	SFIMSG	
178	024020	013737	002174'	026110'	20\$:	MOV	UNITN,T29DSW		;SET UP UNIT NUMBER	
179										
180	024026	012704	026070'		MOV	#T29PACKET,R4		;SUBROUTINE NEEDS PACKET ADDRESS		
181	024032	004737	010552'		JSR	PC,WRTCHR		;ISSUE WRITE CHARACTERISTICS		
182	024036	103407			BCS	25\$;BR, IF COMMAND ISSUED OK		
183	024040	005237	002214'		INC	FATFLG		;ERROR COUNT		
187	024044	010001			MOV	R0,R1		;SAVE CONTENTS OF TSSR		
188	024046				ERRHRD	ERRNO,WRMSG,SFIMSG		;WRITE CHARACTERISTIC FAILED		
	024046	104456						TRAP	C\$ERHRD	
	024050	000155						.WORD	109	
	024052	005046'						.WORD	WRMSG	
	024054	011724'						.WORD	SFIMSG	
189	024056				25\$:	CKLOOP		;LOOP IF SELECTED		
	024056	104406						TRAP	C\$CLP1	
190	024060	004737	010704'		26\$:	JSR	PC,REWIND		;CALL TAPE REWIND COMMAND	
191	024064	016501	000002		MOV	TSSR(R5),R1		;GET TSSR		
192	024070	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED TSSR		
193	024074	103407			RCS	30\$;BR, IF NO PROBLEM		
194	024076	010004			MOV	R0,R4		;PACKET ADDRESS SET UP		
195	024100	005237	002214'		INC	FATFLG		;ERROR COUNT		
199	024104				ERRHRD	ERRNO,T29RWN,PKTSSR		;REWIND NOT ACCEPTED		
	024104	104456						TRAP	C\$ERHRD	
	024106	000156						.WORD	110	
	024110	030065'						.WORD	T29RWN	
	024112	011736'						.WORD	PKTSSR	
200	024114				30\$:	CKLOOP		;LOOP IF SELECTED		
	024114	104406						TRAP	C\$CLP1	
201	024116	013701	026120'		MOV	T29BFR+6,R1		;PICK UP XSTO		
202	024122	010102			MOV	R1,R2		;SET UP EXPECTED		
203	024124	052702	000002		BIS	#BIT1,R2		;SET BIT IN EXPECTED		
204	024130	020102			CMP	R1,R2		;DOES EXP = REC'D		
205	024132	001406			BEQ	40\$;BR, IF EQUAL (OK)		
206	024134	005237	002214'		INC	FATFLG		;ERROR COUNT		
210	024140				ERRHRD	ERRNO,T29BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND		
	024140	104456						TRAP	C\$ERHRD	
	024142	000157						.WORD	111	
	024144	027556'						.WORD	T29BOT	
	024146	015364'						.WORD	EXPREC	
211	024150	012737	000001	026222'	40\$:	MOV	#1,T29RB		;NUMBER OF RECORDS TO SPACE OVER	
212	024156	012737	000400	026226'		MOV	#256,,T29SZ		;SET UP RECORD SIZE	
213	024164	012737	140005	026220'		MOV	#140005,T29PK3		;WRITE FORWARD,CVC=1,ACK COMMAND	
214	024172	012704	026220'		MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS		
215	024176	010465	000000		MOV	R4,TSDR(R5)		;ISSUE COMMAND		
216	024202	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET		
217	024206	016501	000002'		MOV	TSSR(R5),R1		;GET TSSR CONTENTS		

218	024212	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED	
219	024216	020102			CMP	R1,R2		;ARE THEY EQUAL	
220	024220	001420			BEQ	75:		;BR, IF OK	
221	024222	013703	026120'		MOV	T29BFR+6,R3		;PICK UP XT50	
222	024226	032703	000004		BIT	#4,R3		;IS UNIT WRITE-LOCKED?	
223	024232	001405			BEQ	41:		;NO,PROCEED WITH NORMAL ERROR	
224	024234				ERRDF	ERRNO,T29WLK,SFIMSG		;TAPE IS WRITE LOCKED	
	024234	104455						TRAP	C#ERDF
	024236	000157						.WORD	111
	024240	027424'						.WORD	T29WLK
	024242	011724'						.WORD	SFIMSG
225	024244				DOCLN			;DROP IT	
	024244	104444						TRAP	C#DOCLN
226	024246	005237	002214'	41:	INC	FATFLG		;ERROR COUNT	
230	024252				ERRHRD	ERRNO,T29WRT,PKTSSR		;TSSR INCORRECT AFTER WRITE DATA	
	024252	104456						TRAP	C#ERRHRD
	024254	000160						.WORD	112
	024256	027511'						.WORD	T29WRT
	024260	011736'						.WORD	PKTSSR
231	024262			75:	CKL.OOP			;LOOP IF SELECTED	
	024262	104406						TRAP	C#CLP1
232	024264	012737	000001 026222'		MOV	#1,T29RB		;NUMBER OF RECORDS TO SPACE OVER	
233	024272	012737	140410 026220'		MOV	#140410,T29PK3		;SET UP COMMAND IN APCKET	;SET
UP	SPACE REVERSE								
234	024300	012704	026220'		MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS	
235	024304	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND	
236	024310	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET	
237	024314	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS	
238	024320	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED	
239	024324	020102			CMP	R1,R2		;ARE THEY EQUAL	
240	024328	001406			BEQ	175:		;BR, IF OK	
241	024330	005237	002214'		INC	FATFLG		;ERROR COUNT	
245	024334				ERRHRD	ERRNO,T29WDE,PKTSSR		;TSSR INCORRECT AFTER READ DATA	
	024334	104456						TRAP	C#ERRHRD
	024336	000161						.WORD	113
	024340	027342'						.WORD	T29WDE
	024342	011736'						.WORD	PKTSSR
246	024344			175:	CKLOOP			;LOOP IF SELECTED	
	024344	104406						TRAP	C#CLP1
247	024346	013737	003116' 026222'		MOV	FREE,T29RB		;ADDRESS OF BUFFER	
248	024354	012737	141011 026220'		MOV	#141011,T29PK3		;WRITE TAPE MARK RETRY,ACK,CVC=1 COMD.	
249	024362	012704	026220'		MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS	
250	024366	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND	
251	024372	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET	
252	024376	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS	
253	024402	012702	100204		MOV	#SSR!SC!BIT2,R2		;SET UP EXPECTED	
254	024406	020102			CMP	R1,R2		;ARE THEY EQUAL	
255	024410	001406			BEQ	180:		;BR, IF OK	
256	024412	005237	002214'		INC	FATFLG		;ERROR COUNT	
260	024416				ERRHRD	ERRNO,T29WDE,PKTSSR		;TSSR INCORRECT AFTER READ DATA	
	024416	104455						TRAP	C#ERRHRD
	024420	000162						.WORD	114
	024422	027342'						.WORD	T29WDE
	024424	011736'						.WORD	PKTSSR
261	024426			180:	CKLOOP			;LOOP IF SELECTED	
	024426	104406						TRAP	C#CLP1
262	024430	013701	026126'		MOV	T29BFR+14,R1		;GET XT53 STATUS WORD	
263	024434	010102			MOV	R1,R2		;SET UP EXPECTED	

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 1: WRITE TAPE MARK RETRY

SEQ 097

```

447 025432 052702 000002      BIS      #BIT1,R2      ;SET BOT BIT IN EXPECTED
448 025436 020102      CMP      R1,R2      ;DOES EXP = REC'D
449 025440 001406      BEQ      40$      ;BR, IF EQUAL (OK)
450 025442 005237 002214'      INC      FATFLG      ;ERROR COUNT
454 025446      ERRHRD  ERRNO,T29BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      025446 104456      TRAP      C$ERHRD
      025450 000177      .WORD     127
      025452 027556'      .WORD     T29BOT
      025454 015364'      .WORD     EXPREC
455 025456      40$:  CKLOOP      ;LOOP IF SELECTED
      025456 104406      TRAP      C$CLP1
456 025460 012737 140011 026220'      MOV      #140011,T29PK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
457 025466 012704 026220'      MOV      #T29PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
458 025472 010465 000000      MOV      R4,TSDB(R5)      ;ISSUE COMMAND
459 025476 004737 016140'      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
460 025502 016501 000002      MOV      TSSR(R5),R1      ;GET TSSR CONTENTS
461 025506 012702 000200      MOV      #SSR,R2      ;SET UP EXPECTED
462 025512 020102      CMP      R1,R2      ;ARE THEY EQUAL
463 025514 001406      BEQ      70$      ;BR, IF OK
464 025516 005237 002214'      INC      FATFLG      ;ERROR COUNT
468 025522      ERRHRD  ERRNO,T29WDC,PKTSSR ;TSSR INCORRECT AFTER WRITE TAPE MARK
      025522 104456      TRAP      C$ERHRD
      025524 000200      .WORD     128
      025526 030457'      .WORD     T29WDC
      025530 011736'      .WORD     PKTSSR
469 025532      70$:  CKLOOP      ;LOOP IF SELECTED
      025532 104406      TRAP      C$CLP1
470 025534 012703 000012      150$:  MOV      #10,R3      ;NUMBER OF RECORDS TO WRITE TM
471 025540 012737 000001 026222'      MOV      #1,T29RB      ;SET UP PACKET
472 025546 012737 141011 026220'      MOV      #141011,T29PK3 ;WRITE TAPE MARK RETRY,ACK,CVC=1 COMMAND
473 025554 012704 026220'      MOV      #T29PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
474 025560 010465 000000      155$:  MOV      R4,TSDB(R5)      ;ISSUE COMMAND
475 025564 004737 016140'      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
476 025570 016501 000002      MOV      TSSR(R5),R1      ;PICK UP TSSR
477 025574 012702 000200      MOV      #SSR,R2      ;SET UP EXPECTED (SSR ONLY)
478 025600 020102      CMP      R1,R2      ;WAS STATUS GOOD
479 025602 001406      BEQ      165$      ;BR, IF TERMINATION WAS GOOD
480 025604 005237 002214'      INC      FATFLG      ;ERROR COUNT
484 025610      ERRHRD  ERRNO,T29WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
      025610 104456      TRAP      C$ERHRD
      025612 000201      .WORD     129
      025614 030457'      .WORD     T29WDC
      025616 011736'      .WORD     PKTSSR
485 025620      165$:  CKLOOP      ;LOOP IF SELECTED
      025620 104406      TRAP      C$CLP1
486 025622 005303      DEC      R3      ;BUMP COUNTER DOWN
487 025624 001355      BNE      155$      ;BR, IF LESS THAN 10 TAPE MARKS
488 025626 012737 140410 026220'      MOV      #140410,T29PK3 ;SPACE REVERSE,ACK,CVC=1, COMMAND
489 025634 012737 000001 026222'      MOV      #1,T29RB      ;NUMBER OF RECORDS TO SPACE BACK
490 025642 012704 026220'      MOV      #T29PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
491 025646 010465 000000      MOV      R4,TSDB(R5)      ;ISSUE COMMAND
492 025652 004737 016140'      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
493 025656 016501 000002      MOV      TSSR(R5),R1      ;GET TSSR CONTENTS
494 025662 012702 100204      MOV      #SSR,SC!BIT2,R2 ;SET UP EXPECTED
495 025666 020102      CMP      R1,R2      ;ARE THEY EQUAL
496 025670 001406      BEQ      222$      ;BR, IF OK
497 025672 005237 002214'      INC      FATFLG      ;ERROR COUNT

```


TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 1: WRITE TAPE MARK RETRY

SEQ 099

544					
545				; LOCAL STORAGE FOR THIS TEST	
546				;	
548	026064		.BLKB	10-<.-TSV2&7>	
550	026070		T29PACKET:		; COMMAND PACKET FOR TEST
551	026070	014004	.WORD	14004	; WRITE CHARACTERISTICS COMMAND, WITH CVC=1, ACK
552	026072	126100	.WORD	T29DATA	; ADDRESS OF CHARACTERISTICS BLOCK
553	026074	000000	.WORD	0	
554	026076	000012	.WORD	10.	; STARTING VALUE OF BLOCK SIZE
555	026100		T29DATA:		; CHARACTERISTICS DATA BLOCK
556	026100	026112	.WORD	T29BFR	; ADDRESS OF MESSAGE BUFFER
557	026102	000000	.WORD	0	
558	026104	000024	.WORD	20.	; LENGTH OF MESSAGE BUFFER
559	026106	000000	.WORD	0	
560	026110	000000	T29DSW:	.WORD 0	; SELECT DRIVE 0
561	026112		T29BFR:	.BLKW 25.	; MESSAGE BUFFER
562					
563				; WRITE SUBSYSTEM MEMORY COMMAND PACKET	
564				;	
566	026174		.BLKB	10-<.-TSV2&7>	
568	026200		T29PK2:		
569	026200	100006	.WORD	100006	; WRITE SUB SYS MEM COMMAND, AND ACK
570	026202	026230	.WORD	T29BF2	; ADDRESS OF SELECT BLOCK DATA
571	026204	000000	.WORD	0	
572	026206	000006	.WORD	6.	; SIZE OF DATA PACKET
573					
575	026210		.BLKB	10-<.-TSV2&7>	
577	026220		T29PK3:		
578	026220	140005	.WORD	140005	; WRITE TAPE MARK RETRY COMMAND, CVC=1 AND ACK
579	026222		T29RB:		
580	026222	003116	T29WB:	.WORD FREE	; ADDRESS OF WRITE BUFFER
581	026224	000000	.WORD	0	
582	026226	000000	T29SZ:	.WORD 0	; SIZE OF BUFFER (EXTENT)
583			.EVEN		
584					
585					
586					
587	026230		T29BF2:		
588	026230	010	T29BS0:	.BYTE 10	; BSELO AREA
589	026231	200	T29BS1:	.BYTE 200	; BSEL1 AREA
590	026232	000000	T29S2:	.WORD 0	; SEL 2 AREA
591	026234	000000	T29S3:	.WORD 0	; DATA AREA
592					
593					
594			.EVEN		
595				; TAPE MOTION PACKET COMMAND VALUES	
596					
597	026236	140001	T29RN:	.WORD 140001	; READ DATA
598	026240	140401	T29WR:	.WORD 140401	; READ DATA REVERSE
599	026242	141001	T29CON:	.WORD 141001	; READ PREVIOUS OPP=0
600	026244	161001	.WORD	161001	; READ PREVIOUS OPP=1
601	026246	141401	.WORD	141401	; WRITE TAPE MARK RETRY NEXT OPP=0
602	026250	161401	.WORD	161401	; WRITE TAPE MARK RETRY NEXT OPP=1
603	026252	177777	.WORD	177777	; END OF DATA
604					
605					
606	026254	000000	T29CNT:	.WORD 0	; TAPE RECORD COUNTER STORAGE AREA

```

607
608 026256 000000          T29RSZ: .WORD    0          ;RECORD STORAGE SIZE AREA
609 026260 000000          T29DLY: .WORD          ;DELAY COUNTER STORAGE AREA
610
611
612
613          ;*
614          ;LOCAL TEXT MESSAGES FOR TEST
615          ;-
616
617 026262      104      162      151  T29OFL: .ASCIZ  'Drive is OFFLINE'
618 026303      124      141      160  T29WNG: .ASCIZ  'Tape Position Incorrect After WRITE TAPE MARK RETRY Previous (OPP=1)'
619 026410      127      122      111  T29NEF: .ASCIZ  'WRITE TAPE MARK RETRY, At BOT, Failed To Set NEF (XST0)'
620 026500      124      123      123  T29RDF: .ASCIZ  'TSSR Incorrect After READ DATA Command'
621 026547      127      122      111  T29RRF: .ASCIZ  'WRITE TAPE MARK RETRY Previous (Space Reverse, Read Forward) Command Failed'

622 026663      127      122      111  T29RRG: .ASCIZ  'WRITE TAPE MARK RETRY Previous (Read Forward, Space Reverse) Command Failed'

623 026777      120      117      123  T29SC:  .ASCIZ  'POSITION (Space Command) Failed, TSSR Not Correct'
624 027061      122      111      102  T29LOR: .ASCIZ  'RIB NOT SET AFTER READ REVERSE INTO BOT'
625 027131      124      123      123  T29WDF: .ASCIZ  'TSSR Not Correct After Illegal Mode Bits Set'
626 027206      111      154      154  T29LOQ: .ASCIZ  'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
627 027267      127      122      111  T29SSR: .ASCIZ  'WRITE TAPE MARK RETRY COMMAND Not Accepted'
628 027342      124      123      123  T29WDE: .ASCIZ  'TSSR Not Correct After SPACE REVERSE DATA Command'
629 027424      052      052      052  T29WLK: .ASCIZ  '*****TAPE IS WRITE-LOCKED AND WILL CAUSE ERRORS*****'
630 027511      124      123      123  T29WRT: .ASCIZ  'TSSR Not Correct After WRITE Command'
631 027556      124      141      160  T29BOT: .ASCIZ  'Tape Not At BOT After REWIND Command'
632 027623      104      141      164  T29DIA: .ASCIZ  'Data Written To Tape Not Equal To Data Read From Tape'
633 027711      127      122      111  T29EOT: .ASCIZ  'WRITE TAPE MARK RETRY DATA OVER EOT GAVE NO TAPE STATUS ALERT'
634 030007      124      123      123  T29TM:  .ASCIZ  'TSSR Not Correct After SPACE REVERSE Into BOT'
635 030065      122      145      167  T29RWN: .ASCIZ  'Rewind (POSITION) Command Not Accepted'
636 030134      122      101      115  T29RNC: .ASCIZ  'RAM Error, Correct Data Pattern Not In Ram'
637 030207      124      123      123  T29AMS: .ASCIZ  'TSSR Init, Failed After WRITE TAPE MARK RETRY COMMAND'
638 030275      104      162      151  T29OF7: .ASCIZ  'Drive 7 Select Failed To Set "OFL" In TSSR'
639 030350      124      123      123  T29WUD: .ASCIZ  'TSSR Not Correct After WRITE TAPE MARK RETRY DATA Command, SWB Bit Set'
640 030457      124      123      123  T29WDC: .ASCIZ  'TSSR Not Correct After WRITE TAPE MARK RETRY DATA Command'
641 030551      103      126      103  T29VCK: .ASCIZ  'CVC Set, Didn't Reset VCK In Message Buffer'
642 030624      124      123      102  T29BA:  .ASCIZ  'TSBA Not Correct After WRITE TAPE MARK RETRY DATA Command'
643 030716      127      122      111  T29WSS: .ASCIZ  'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
644 031005      122      145      141  T29LON: .ASCIZ  'Reading Long Record Failed To Set RLL Bit In XST0'
645 031067      122      145      141  T29LOP: .ASCIZ  'Reading Long Record Failed To Set RLS Bit In XST0'
646 031151      122      145      163  T29PBP: .ASCIZ  'Residual Byte Count Incorrect After Short Record Read'
647 031237      122      145      141  T29TRL: .ASCIZ  'Reading Long Record Failed To Give Tape Status Alert'
648 031325      104      141      164  T29NEQ: .ASCIZ  'Data WRITE TAPE MARK RETRY From Tape Not Correct, After SWB=1'
649 031423      124      123      123  T29RDG: .ASCIZ  'TSSR Incorrect After READ REVERSE Into Tape Mark'
650 031504      127      122      111  T29RIB: .ASCIZ  'WRITE TAPE MARK RETRY At First Record, Failed To Set RIB (XST3)'
651 031604      124      115      113  T29RRN: .ASCIZ  'TMK (XST0) Failed To Set After READ REVERSE Into Tape Mark'
652 031677      127      162      151  TST29TD: .ASCIZ  'Write Tape Mark Retry'
653          .EVEN
654          ;*
655          ;
656          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
657          ;WRITE SUBSYSTEM MEMORY COMMAND
658          ;
659          ;-
660
661 031726          T29REST:
662 031726          SAVREG          ;SAVE THE REGISTERS
663 031732      012701  026070'  MOV          @T29PACKET,R1          ;START OF THE PACKET
  
```

```

664 031736 012721 140004      MOV      #140004,(R1)+      ;WRITE SUBSYSTEM MEM. WITH ACK, CVC=1
665 031742 012721 026100'    MOV      #T29DATA,(R1)+   ;ADDRESS OF CHARAISTICS DATA BLOCK
666 031746 005021             CLR      (R1)+            ;EXTENDED ADDRESS
667 031750 012721 000012      MOV      #10.,(R1)+       ;SIZE OF DATA BLOCK IN BYTES
668 031754 012721 026112'    MOV      #T29BFR,(R1)+   ;ADDRESS OF MESSAGE BUFFER
669 031760 005021             CLR      (R1)+            ;
670 031762 012721 000024      MOV      #20.,(R1)+       ;LENGTH OF MESSAGE BUFFER
671 031766 005021             CLR      (R1)+            ;
672 031770 012711 000000      MOV      #0,(R1)         ;SELECT DRIVE ZERO (0)
673 031774 012702 000030      MOV      #24.,R2         ;NUMBER OF LOCATIONS TO BE CLEARED
674 032000 012762 177777 026112' 64$: MOV      #177777,T29BFR(R2) ;ALL UNES TO MESSAGE DUFFER
675 032006 005742             TSI      -(R2)           ;NEXT LOCATION
676 032010 020227 000000      CMP      R2,#0          ;CHECK FOR END OF LOOP
677 032014 001371             BNE     64$             ;KEEP GOING UNTIL DONE
678 032016 000207             RTS      PC              ;RETURN
679
680

```

```

681 032020             T29RT2:
682 032020             SAVREG      ;SAVE THE REGISTERS
683 032024 012701 026200'    MOV      #T29PK2,R1      ;START OF THE PACKET
684 032030 012721 140006      MOV      #140006,(R1)+   ;WRITE SUBSYSTEM MEM. WITH ACK,CVC=1.
685 032034 012721 026230'    MOV      #T29BF2,(R1)+   ;ADDRESS OF DATA BLOCK
686 032040 005021             CLR      (R1)+            ;EXTENDED ADDRESS
687 032042 012721 000006      MOV      #6.,(R1)+       ;SIZE OF DATA BLOCK IN BYTES
688 032046 005021             CLR      (R1)+            ;
689 032050 012701 026230'    MOV      #T29BF2,R1      ;POINT TO DATA SEL AREA
690 032054 005021             CLR      (R1)+            ;
691 032056 005011             CLR      (R1)+            ;
692 032060 000207             RTS      PC              ;RETURN
693

```

```

694 032062             T29RT3:
695 032066 012701 026220'    SAVREG      ;SAVE THE REGISTERS
696 032072 012721 000000      MOV      #T29PK3,R1      ;START OF THE PACKET
697 032076 012721 000000      MOV      #0,(R1)+       ;WRITE SUBSYSTEM MEM. WITH ACK,
698 032102 005021             MOV      #0,(R1)+       ;ADDRESS OF DATA BLOCK
699 032104 012711 000000      CLR      (R1)+            ;EXTENDED ADDRESS
700 032110 000207             MOV      #0,(R1)         ;SIZE OF DATA BLOCK IN BYTES
701 032112             RTS      PC              ;RETURN
032112             L10036:
032112 104401             TRAP      C$ETST

```

702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718

```

.SBTTL TEST 2: SKIP TAPE MARKS
;
; THIS TEST VERIFIES PROPER OPERATION OF THE SKIP TAPE MARKS
; FORWARD AND SKIP TAPE MARKS REVERSE COMMANDS. PROPER OPERATION
; UNDER CONTROL OF ALL COMBINATIONS OF THE ENABLE SKIP TAPE MARKS
; STOP (ESS) AND ENABLE TAPE MARKS STOP OFF BOT (ENB) BITS SPECIFIED
; BY THE WRITE CHARACTERISTICS COMMAND. THE TEST CONSISTS OF THE
; FOLLOWING SUBTESTS (FOR EACH SUBTEST, THE TAPE IS FIRST WRITTEN
; WITH AN APPROPRIATE SERIES OF DATA RECORDS AND/OR TAPE MARKS
; AND/OR DOUBLE TAPE MARKS.
;
; THE TEST CONSISTS OF THE FOLLOWING 11 SUBTESTS
;

```



```

769 032231 005237 002214'          INC    FATFLG          ;ERROR COUNT
773 032240 010001                   MOV    R0,R1          ;CONTENTS OF TSSR REGISTER
774 032242                   ERRDF  ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
                                104455                   TRAP    C$ERDF
                                032244 000311                   .WORD  201
                                032246 003642'                   .WORD  SFIERR
                                032250 011724'                   .WORD  SFIMSG
775 032252                   20$:
776 032252 013737 002174' 036300'  MOV    UNITN,T30DSW    ;SET UP UNIT NUMBER
777 032260 012704 036260'         MOV    #T30PACKET,R4   ;SUBROUTINE NEEDS PACKET ADDRESS
778
779 ;*****
780 ;
781 ;ISSUE WRITE CHARACTERISTICS COMMAND
782 ;
783 ;*****
784
785 032264 004737 010552'          JSR    PC,WRTCHR       ;ISSUE WRITE CHARACTERISTICS
786 032270 103407                   BCS    23$            ;BR, IF COMMAND ISSUED OK
787 032272 005237 002214'          INC    FATFLG          ;ERROR COUNT
791 032276 010001                   MOV    R0,R1          ;SAVE CONTENTS OF TSSR
792 032300                   ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
                                104456                   TRAP    C$ERHRD
                                032302 000312                   .WORD  202
                                032304 005046'                   .WORD  WRTMSG
                                032306 011724'                   .WORD  SFIMSG
793 032310                   23$:  CKLOOP          ;LOOP IF SELECTED
                                104406                   TRAP    C$CLP1
794
795 ;*****
796 ;
797 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR IO SET
798 ;
799 ;*****
800
801 032312 004737 010704'          JSR    PC,REWIND       ;CALL TAPE REWIND COMMAND
802 032316 103411                   BCS    30$            ;BR, IF NO PROBLEM
803 032320 010004                   MOV    R0,R4          ;GET PACKET ADDRESS
804 032322 016501 000002         MOV    TSSR(R5),R1     ;GET STATUS REGISTER
805 032326 005237 002214'          INC    FATFLG          ;ERROR COUNT
809 032332                   ERRHRD ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
                                104456                   TRAP    C$ERHRD
                                032334 000313                   .WORD  203
                                032336 040030'                   .WORD  T30RWN
                                032340 011736'                   .WORD  PKTSSR
810 032342                   30$:  CKLOOP          ;LOOP IF SELECTED
                                104406                   TRAP    C$CLP1
811
812 ;*****
813 ;
814 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
815 ;
816 ;*****
817
818 032344 013701 036310'         MOV    T30BFR+6,R1     ;PICK UP XSTO
819 032350 010102                   MOV    R1,R2          ;SET UP EXPECTED
820 032352 052702 000002         BIS    #BIT1,R2       ;SET BOT BIT IN EXPECTED

```

```

821 032356 020102          CMP      R1,R2          ;DOES EXP = REC'D
822 032360 001406          BEQ      40$           ;BR, IF EQUAL (OK)
823 032362 005237 002214'  INC      FATFLG        ;ERROR COUNT
827 032366          EPRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER RE, IND
      032366 104456          TRAP    C$ERHRD
      032370 000314          .WORD  204
      032372 037631'       .WORD  T30BOT
      032374 015364'       .WORD  EXPREC
828 032376          40$:  CKLOOP          ;LOOP IF SELECTED
      032376 104406          TRAP    C$CLP1
829 032400 012737 000001 036444'  MOV      #1.,T30FCN    ;SET "FILE" COUNTER AT 1 DECIMAL
830 032406 012703 000001          64$:  MOV      #1,R3    ;ONE RECORD PER "FILE"
831 032412 013737 003116' 036412'  65$:  MOV      FREE,T30WB ;SET UP PACKETS'S WRITE BUFFER
832 032420 012737 003720 036416'  MOV      #2000.,T30SZ ;SET RECORD SIZE AT 2000 BYTES
833
834 ;*****
835 ;
836 ;WRITE DATA,ACK,CVC=1 COMMAND
837 ;
838 ;*****
839
840 032426 012737 140005 036410'  MOV      #140005,T30PK3 ;WRITE [ TA,ACK,CVC=1 COMMAND
841 032434 012704 036410'  MOV      #T30PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
842 032440 013702 036444'  MOV      T30FCN,R2    ;GET FILE COUNTER
843 032444 000302          SWAB    R2            ;MOVE TO UPPER BYTE
844 032446 010301          MOV     R3,R1         ;GET RECORD COUNTER
845 032450 060201          ADD     R2,R1         ;FILE COUNTER IN UPPER, RECORD # LOW
846 032452 010177 150440          MOV     R1,#FREE     ;MOV TO OUT PUT BUFFER
847 032456 010465 000000          MOV     R4,TSD8(R5)  ;ISSUE COMMAND
848 032462 004737 016140'  JSR     PC,WAITF      ;WAIT FOR SSR TO SET
849 032466 016501 000002          MOV     TSSR(R5),R1  ;GET TSSR CONTENTS
850 032472 012702 000200          MOV     #SSR,R2     ;SET UP EXPECTED
851 032476 020102          CMP     R1,R2        ;ARE THEY EQUAL
852 032500 001406          BEQ     70$          ;BR, IF OK
853 032502 005237 002214'  INC     FATFLG        ;ERROR COUNT
857  32506          EPRHRD  ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      032506 104456          TRAP    C$ERHRD
      032510 000315          .WORD  205
      032512 036760'       .WORD  T30WDD
      032514 011736'       .WORD  PKTSSR
858 032516          70$:  CKLOOP          ;LOOP IF SELECTED
      032516 104406          TRAP    C$CLP1
859 032520 005203          INC     R3            ;COUNT THE RECORD COUNTER DOWN
860 032522 020327 000021          CMP     R3,#21      ;AT 20 YET
861 032526 001331          BNE    65$          ;BR, IF NOT AT 20 RECORDS WRITTEN
862
863 ;*****
864 ;
865 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
866 ;
867 ;*****
868
869 032530 012737 141011 036410'  MOV      #141011,T30PK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
870 032536 012704 036410'  MOV      #T30PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
871 032542 010465 000000          MOV     R4,TSD8(R5)  ;ISSUE COMMAND
872 032546 004737 016140'  JSR     PC,WAITF      ;WAIT FOR SSR TO SET
873 032552 016501 000002          MOV     TSSR(R5),R1  ;PICK UP TSSR

```


TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-74 18:55
 TEST 2: SKIP TAPE MARKS

SEQ 105

874	032556	012702	000200		MOV	#SSR,R2		!SET UP EXPECTED (SSR ONLY)
875	032562	020102			CMP	R1,R2		!WAS STATUS GOOD
876	032564	001406			BEQ	160!		!BR, IF TERMINATION WAS GOOD
877	032566	005237	002214'		INC	FATFLG		!ERROR COUNT
881	032572				ERRHRD	ERRNO,T3OWDC,PKTSSR		!TSSR NOT CORRECT AFTER WRT TAPE M.
	032572	104456					TRAP	C!ERHRD
	032574	000316					.WORD	206
	032576	040152'					.WORD	T3OWDC
	032600	011736'					.WORD	PKTSSR
882	032602			160!:	CKLOOP			!LOOP IF SELECTED
	032602	104406					TRAP	C!CLP1
883	032601	005237	036444'		INC	T3OFCN		!COUNT THE "FILE" COUNTER DOWN
884	032610	023727	036444'	000006	CMP	T3OFCN,#6		!WRITE 5 FILE TO TAPE
885	032616	001273			BNE	64!		!BR, IF NOT AT 5 FILES WRITTEN
886								
887								
888								
889								
890								
891								
892								
893	032620	012737	141011	036410'	MOV	#141011,T3OPK3		!WRITE TAPE MARK,ACK,CVC=1 COMMAND
894	032626	012704	036410'		MOV	#T3OPK3,R4		!SET UP R4 WITH PACKET ADDRESS
895	032632	010465	000000		MOV	R4,TSD8(R5)		!ISSUE COMMAND
896	032636	004737	016140'		JSR	PC,WAITF		!WAIT FOR SSR TO SET
897	032642	016501	000002		MOV	TSSR(R5),R1		!PICK UP TSSR
898	032646	012702	000200		MOV	#SSR,R2		!SET UP EXPECTED (SSR ONLY)
899	032652	020102			CMP	R1,R2		!WAS STATUS GOOD
900	032654	001406			BEQ	165!		!BR, IF TERMINATION WAS GOOD
901	032656	005237	002214'		INC	FATFLG		!ERROR COUNT
905	032662				ERRHRD	ERRNO,T3OWDC,PKTSSR		!TSSR NOT CORRECT AFTER WRT TAPE M.
	032662	104456					TRAP	C!ERHRD
	032664	000317					.WORD	207
	032666	040152'					.WORD	T3OWDC
	032670	011736'					.WORD	PKTSSR
906	032672			165!:	CKLOOP			!LOOP IF SELECTED
	032672	104406					TRAP	C!CLP1
907								
908								
909								
910								
911								
912								
913								
914	032674	004737	010704'		JSR	PC,REWIND		!CALL TAPE REWIND COMMAND
915	032700	103411			BCS	170!		!BR, IF NO PROBLEM
916	032702	010004			MOV	RO,R4		!GET PACKET ADDRESS
917	032704	016501	000002		MOV	TSSR(R5),R1		!GET STATUS REGISTER
918	032710	005237	002214'		INC	FATFLG		!ERROR COUNT
922	032714				ERRHRD	ERRNO,T3ORWN,PKTSSR		!REWIND NOT ACCEPTED
	032714	104456					TRAP	C!ERHRD
	032716	000320					.WORD	208
	032720	040030'					.WORD	T3ORWN
	032722	011736'					.WORD	PKTSSR
923	032724			170!:	CKLOOP			!LOOP IF SELECTED
	032724	104406					TRAP	C!CLP1
924								

SET

```

925
926
927
928
929
930
931 032726 013701 036310'
932 032732 010102
933 032734 052702 000002
934 032740 020102
935 032742 001406
936 032744 005237 002214'
940 032750
    032750 104456
    032752 000321
    032754 037631'
    032756 015364'
941 032760
    032760 104406
942 032762 012703 036426'
943 032766 013737 002174' 036300'
944 032774 011337 036276'
945 033000 012704 036260'
946
947
948
949
950
951
952
953 033004 004737 010552'
954 033010 103407
955 033012 005237 002214'
959 033016 010001
960 033020
    033020 104456
    033022 000322
    033024 005046'
    033026 011724'
961 033030
    033030 104406
962
963
964
965
966
967
968
969 033032 012737 141010 036410'
970 033040 012737 000001 036412'
971 033046 012704 036410'
972 033052 010465 000000
973 033056 012737 176750 036446'
974 033064 004737 016140'
975 033070 016501 000002
976 033074 032701 000200
977 033100 001017

```

```

;*****
;
;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
;
;*****
      MOV     T30BFR+6,R1      ;PICK UP XSTO
      MOV     R1,R2           ;SET UP EXPECTED
      BIS     @BIT1,R2        ;SET BOT BIT IN EXPECTED
      CMP     R1,R2           ;DOES EXP = REC'D
      BEQ     180$           ;BR, IF EQUAL (OK)
      INC     FATFLG          ;ERROR COUNT
      ERRHRD ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP   C$ERHRD
                                .WORD  209
                                .WORD  T30BOT
                                .WORD  EXPREC
180$:  CKLOOP                ;LOOP IF SELECTED
                                TRAP   C$CLP1
      MOV     @T30IMV,R3      ;SET UP POINTER TO COMMAND TABLE
      MOV     UNITN,T30DSW    ;SET UP UNIT NUMBER
182$:  MOV     (R3),T30ETM    ;GET NEXT COMMAND
      MOV     @T30PACKET,R4   ;SUBROUTINE NEEDS PACKET ADDRESS
;*****
;
;ISSUE WRITE CHARACTERISTICS COMMAND
;
;*****
      JSR     PC,WRTCHR       ;ISSUE WRITE CHARACTERISTICS
      BCS     188$           ;BR, IF COMMAND ISSUED OK
      INC     FATFLG          ;ERROR COUNT
      MOV     RO,R1          ;SAVE CONTENTS OF TSSR
      ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
                                TRAP   C$ERHRD
                                .WORD  210
                                .WORD  WRTMSG
                                .WORD  SFIMSG
188$:  CKLOOP                ;LOOP IF SELECTED
                                TRAP   C$CLP1
;*****
;
;SKIP TAPE MARK,ACK,CVC=1 COMMAND
;
;*****
      MOV     @141010,T30PK3  ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
      MOV     @1,T30RB        ;SET UP NUMBER TO SKIP
      MOV     @T30PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
189$:  MOV     R4,T30DB(R5)    ;ISSUE COMMAND
      MOV     @65000.,T30DLY  ;SET UP DELAY COUNTER
190$:  JSR     PC,WAITF        ;WAIT FOR SSR TO SET
      MOV     TSSR(R5),R1     ;PICK UP TSSR
      BIT     @SSR,R1         ;IS SSR SET YET
      BNE     191$           ;BR, IF SSR IS SET

```

```

978 033102          DELAY 250          ;CALL DELAY ROUTINE
    033102 012727 000250          MOV      #250,(PC)+
    033106 000000          .WORD 0
    033110 013727 002116'        MOV      L$DLY,(PC)+
    033114 000000          .WORD 0
    033116 005367 177772          DEC      -6(PC)
    033122 001375          BNE     .-4
    033124 005367 177756          DEC      -22(PC)
    033130 001367          BNE     .-20
979 033132 005337 036446'        DEC      T30DLY          ;BUMP DELAY ROUTINE
980 033136 001352          BNE     190$          ;BR, IF MORE DELAY TO GO
981 033140 012702 000200          191$: MOV      #SSR,R2          ;SET UP EXPECTED (SSR ONLY)
982 033144 000102          CMP      R1,R2          ;WAS STATUS GOOD
983 033146 001406          BEQ     192$          ;BR, IF TERMINATION WAS GOOD
984 033150 005237 002214'        INC      FATFLG          ;ERROR COUNT
988 033154          ERRHRD ERRNO,T30SKM,PKTSSR ;TSSR NOT CORRECT AFTER
    033154 104456          TRAP   C$ERHRD          SKIP TAPE M.
    033156 000323          .WORD 211
    033160 036704'        .WORD T30SKM
    033162 011736'        .WORD PKTSSR
989 033164          192$: CKLOOP          ;LOOP IF SELECTED
    033164 104406          TRAP   C$CLP1
990
991
992
993
994
995
996
997 033166 013701 036310'        MOV      T30BFR+6,R1          ;PICK UP XSTO
998 033172 010102          MOV      R1,R2          ;SET UP EXPECTED
999 033174 052702 100000          BIS      #BIT15,R2          ;SET TMK BIT IN EXPECTED
1000 033200 020102          CMP      R1,R2          ;DOES EXP = REC'D
1001 033202 001406          BEQ     195$          ;BR, IF EQUAL (OK)
1002 033204 005237 002214'        INC      FATFLG          ;ERROR COUNT
1006 033210          ERRHRD ERRNO,T30TMK,EXPREC ;TMK NOT SET AFTER WRT TAPE MARK
    033210 104456          TRAP   C$ERHRD
    033212 000324          .WORD 212
    033214 040304'        .WORD T30TMK
    033216 015364'        .WORD EXPREC
1007 033220          195$: CKLOOP          ;LOOP IF SELECTED
    033220 104406          TRAP   C$CLP1
1008 033222 012700 177777          MOV      #177777,R0          ;VALUE TO WRITTEN TO MEMORY
1009 033226 004737 017314'        JSR     PC,FILLMEM          ;FILL MEM WITH ALL ONES
1010 033232 013737 003116' 036412' MOV      FREE,T30RB          ;STARTING READ BUFFER ADDRESS
1011
1012
1013
1014
1015
1016
1017
1018 033240 012737 140001 036410' MOV      #140001,T30PK3          ;READ FORWARD,ACK,CVC=1 COMMAND
1019 033246 012704 036410'        MOV      #T30PK3,R4          ;SET UP R4 WITH PACKET ADDRESS
1020 033252 012737 003720 036416' MOV      #2000.,T30SZ          ;SET UP RECORD SIZE IN PACKET
1021 033260 010465 000000          MOV      R4,T30DB(R5)          ;ISSUE COMMAND
1022 033264 004737 016140'        JSR     PC,WAITF          ;WAIT FOR SSR TO SET

```


TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
TEST 2: SKIP TAPE MARKS

SEQ 109

```

1072 ;
1073 ;GET EXTENDED STATUS REGISTER ZERO (XST0) FROM MESSAGE BUFFER
1074 ;
1075 ;*****
1076 ;
1077 033440 013701 036310'      MOV     T30BFR+6,R1      ;PICK UP XST0
1078 033444 010102              MOV     R1,R2           ;SET UP EXPECTED
1079 033446 052702 000002      BIS     @BIT1,R2        ;SET BOT BIT IN EXPECTED
1080 033452 020102              CMP     R1,R2           ;DOES EXP = REC'D
1081 033454 001406              BEQ     240$            ;BR, IF EQUAL (OK)
1082 033456 005237 002214'      INC     FATFLG          ;ERROR COUNT
1086 033462              ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP     C$ERHRD
                                .WORD    217
                                .WORD    T30BOT
                                .WORD    EXPREC
1087 033472 240$: CKLOOP           ;LOOP IF SELECTED      TRAP     C$CLP1
                                .WORD    CKLOOP
1088 033474 104406              TST     (R3)+          ;POINT TO NEXT POSITION
1089 033476 011301              MOV     (R3),R1        ;GET NEXT COMMAND ETC.
1090 033500 020127 177777      CMP     R1,#177777     ;END OF TABLE MARKER
1091 033504 001402              BEQ     330$            ;BR, IF AT END OF TABLE
1092 033506 000137 032774'      JMP     182$            ;JUMP TO MORE COMMANDS TO DO
1093 033512 330$: CKLOOP           ;LOOP IF SELECTED      TRAP     C$CLP1
                                .WORD    CKLOOP
1094 033514 104406              ENDSUB                ;<<<<<<<<<<<<<<< END SUBTEST >>>>>>>>>>>>>>>>>>
                                L10044:
                                TRAP     C$ESUB
1095 033516 104403              CMP     FATFLG,#15.    ;IS ERROR COUNT AT 25
1096 033524 023727 002214' 000017 BLO     999$            ;BR, IF LESS THAN 25
1097 033526 004737 017074'      JSR     PC,CKDROP     ;TRY TO DROP THE UNIT
1098 033532 999$:
1099 ;
1100 ;
1101 ;
1102 ;TEST 2, SUBTEST 2
1103 ;
1104 ;VERIFIES THAT SKIP TAPE MARKS COMMANDS WITH A TAPE
1105 ;MARK COUNT GREATER THAN 1 OPERATE PROPERLY. COUNTS
1106 ;OF 2,3,8,64,256, AND 512 ARE TESTED. THE
1107 ;TESTING SEQUENCE IS SIMILAR TO THAT USED IN SUBTEST 1.
1108 ;
1109 ;
1110 ;
1111 ;
1112 ;
1113 033532 104402              BGNSUB                ;>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>
                                .WORD    BGNSUB
                                TRAP     C$BSUB
1114 033534 004737 041042'      JSR     PC,T30REST     ;SET COMMAND PACKET
1115 033540 005037 036444'      CLR     T30FCN        ;CLEAR FILE COUNTER
1116 033544 0047.7 041134'      JSR     PC,T30RT2     ;SET UP OTHER COMMAND PACKET
1117 033550 004737 041176'      JSR     PC,T30RT3     ;SET UP OTHER COMMAND PACKET
1118 033554 012737 176750 036446' MOV     #65000.,T30DLY ;SET UP DELAY COUNTER
1119 033562 004737 015664'      JSR     PC,SOFINIT    ;DO INITIALIZE ON CONTROLLER
1120 033566 103426              BCS     20$            ;BR IF INIT WAS OK
1121 033570 20$: DELAY 250          ;DELAY ROUTINE CALL

```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 2: SKIP TAPE MARKS

SEQ 110

```

033570 012727 000250                                MOV     #250,(PC)+
033574 000000                                .WORD  0
033576 013727 002116'                            MOV     L$DLY,(PC)+
033602 000000                                .WORD  0
033604 005367 177772                            DEC     -6(PC)
033610 001375                                BNE    .-4
033612 005367 177756                            DEC     -22(PC)
033616 001367                                BNE    .-20
1122 033620 005337 036446'                        DEC     T30DLY                ;BUMP COUNTER
1123 033624 001356                                BNE    10$                    ;BR, IF MORE COUNTING TO DO
1124 033626 005237 002214'                        INC     FATFLG                ;ERROR COUNT
1128 033632 010001                                MOV     R0,R1                 ;CONTENTS OF TSSR REGISTER
1129 033634                                ERRDF  ERRNO,SFIERR,SFIMSG    ;FATAL ERROR TSSR WAS NOT OK
                                TRAP   C$ERDF
                                .WORD  218
                                .WORD  SFIERR
                                .WORD  SFIMSG
033634 104455
033636 000332
033640 003642'
033642 011724'
1130 033644
1131 033644 013737 002174' 036300' 20$:        MOV     UNITN,T30DSW          ;SET UP UNIT NUMBER
1132 033652 012704 036260'                        MOV     #T30PACKET,R4        ;SUBROUTINE NEEDS PACKET ADDRESS
1133
1134 ;*****
1135 ;
1136 ;ISSUE WRITE CHARACTERISTICS COMMAND
1137 ;
1138 ;*****
1139
1140 033656 004737 010552'                        JSR     PC,WRTCHR             ;ISSUE WRITE CHARACTERISTICS
1141 033662 103407                                BCS    23$                    ;BR, IF COMMAND ISSUED OK
1142 033664 005237 002214'                        INC     FATFLG                ;ERROR COUNT
1146 033670 010001                                MOV     R0,R1                 ;SAVE CONTENTS OF TSSR
1147 033672                                ERRHRD ERRNO,WRTMSG,SFIMSG    ;WRITE CHARACTERISTIC FAILED
                                TRAP   C$ERHRD
                                .WORD  219
                                .WORD  WRTMSG
                                .WORD  SFIMSG
033672 104456
033674 000333
033676 005046'
033700 011724'
1148 033702                                23$:    CKLOOP                ;LOOP IF SELECTED
033702 104406                                TRAP   C$CLP1
1149
1150 ;*****
1151 ;
1152 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
1153 ;
1154 ;*****
1155
1156 033704 004737 010704'                        JSR     PC,REWIND             ;CALL TAPE REWIND COMMAND
1157 033710 103411                                BCS    30$                    ;BR, IF NO PROBLEM
1158 033712 010004                                MOV     R0,R4                 ;GET PACKET ADDRESS
1159 033714 016501 000002                        MOV     TSSR(R5),R1           ;GET STATUS REGISTER
1160 033720 005237 002214'                        INC     FATFLG                ;ERROR COUNT
1164 033724                                ERRHRD ERRNO,T30RWN,PKTSSR    ;REWIND NOT ACCEPTED
                                TRAP   C$ERHRD
                                .WORD  220
                                .WORD  T30RWN
                                .WORD  PKTSSR
033724 104456
033726 000334
033730 040030'
033732 011736'
1165 033734                                30$:    CKLOOP                ;LOOP IF SELECTED
033734 104406                                TRAP   C$CLP1
    
```

```

1166
1167
1168
1169
1170
1171
1172
1173 033736 013701 036310'
1174 033742 010102
1175 033744 052702 000602
1176 033750 020102
1177 033752 001406
1178 033754 005237 002214'
1182 033760
      033760 104456
      033762 000335
      033764 037631'
      033766 015364'
1183 033770
      033770 104406
1184 033772 012737 000001 036444'
1195 034000 012703 000001
1186 034004 013737 003116' 036412'
1187 034012 012737 000024 036416'
1188
1189
1190
1191
1192
1193
1194
1195 034020 012737 140005 036410'
1196 034026 012704 036410'
1197 034032 013702 036444'
1198 034036 000302
1199 034040 010301
1200 034042 060201
1201 034044 010177 147046
1202 034050 010465 000000
1203 034054 004737 016140'
1204 034060 016501 000002
1205 034064 012702 000200
1206 034070 020102
1207 034072 001406
1208 034074 005237 002214'
1212 034100
      034100 104456
      034102 000336
      034104 036760'
      034106 011736'
1213 034110
      034110 104406
1214 034112 005203
1215 034114 020327 000021
1216 034120 001331
1217
1218

```

```

;*****
;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
;*****
      MOV     T30BFR+6,R1      ;PICK UP XSTO
      MOV     R1,R2           ;SET UP EXPECTED
      BIS     @BIT1,R2        ;SET BOT BIT IN EXPECTED
      CMP     R1,R2           ;DOES EXP = REC'D
      BEQ     40$             ;BR. IF EQUAL (OK)
      INC     FATFLG          ;ERROR COUNT
      ERRHRD ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP   C$ERHRD
                                .WORD  221
                                .WORD  T30BOT
                                .WORD  EXPREC
40$:   CKLOOP                ;LOOP IF SELECTED
                                TRAP   C$CLP1
      MOV     @1.,T30FCN      ;SET "FILE" COUNTER AT 1 DECIMAL
64$:   MOV     @1,R3          ;ONE RECORD PER "FILE"
65$:   MOV     FREE,T30WB     ;SET UP PACKETS'S WRITE BUFFER
      MOV     @20.,T30SZ      ;SET RECORD SIZE AT 2000 BYTES
;*****
;WRITE DATA,ACK,CVC=1 COMMAND
;*****
      MOV     @140005,T30PK3  ;WRITE DATA,ACK,CVC=1 COMMAND
      MOV     @T30PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
      MOV     T30FCN,R2       ;GET FILE COUNTER
      SWAB    R2              ;MOVE TO UPPER BYTE
      MOV     R3,R1           ;GET RECORD COUNTER
      ADD     R2,R1           ;FILE COUNTER IN UPPER, RECORD @ LOW
      MOV     R1,@FREE        ;MOV TO OUT PUT BUFFER
      MOV     R4,@TSDB(R5)    ;ISSUE COMMAND
      JSR     PC,WAITF        ;WAIT FOR SSR TO SET
      MOV     TSSR(R5),R1     ;GET TSSR CONTENTS
      MOV     @SSR,R2         ;SET UP EXPECTED
      CMP     R1,R2           ;ARE THEY EQUAL
      BEQ     70$             ;BR. IF OK
      INC     FATFLG          ;ERROR COUNT
      ERRHRD ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP   C$ERHRD
                                .WORD  222
                                .WORD  T30WDD
                                .WORD  PKTSSR
70$:   CKLOOP                ;LOOP IF SELECTED
                                TRAP   C$CLP1
      INC     R3              ;COUNT THE RECORD COUNTER DOWN
      CMP     R3,@21          ;AT 20 YET
      BNE    65$             ;BR. IF NOT AT 20 RECORDS WRITTEN
;*****

```

```

1219
1220 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
1221 ;
1222 ;*****
1223
1224 034122 012737 141011 036410' MOV #141011,T30PK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
1225 034130 012704 036410' MOV #T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
1226 034134 010465 000000 MOV R4,TSDB(R5) ;ISSUE COMMAND
1227 034140 004737 016140' JSR PC,WAITF ;WAIT FOR SSR TO SET
1228 034144 016501 000002 MOV TSSR(R5),R1 ;PICK UP TSSR
1229 034150 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED (SSR ONLY)
1230 034154 020102 CMP R1,R2 ;WAS STATUS GOOD
1231 034156 001406 BEQ 160$ ;BR, IF TERMINATION WAS GOOD
1232 034160 005237 002214' INC FATFLG ;ERROR COUNT
1236 034164 ERRHRD ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP C$ERHRD
                                .WORD 223
                                .WORD T30WDC
                                .WORD PKTSSR
                                TRAP C$CLP1
                                .WORD 104456
                                .WORD 000337
                                .WORD 040152'
                                .WORD 011736'
1237 034174 160$: CKLOOP ;LOOP IF SELECTED
                                TRAP C$CLP1
                                .WORD 104406
1238 034176 005237 036444' INC #30FCN ;COUNT THE "FILE" COUNTER DOWN
1239 034202 023727 036444' 000031 CMP T30FCN,#25. ;WRITE 25 FILES TO TAPE
1240 034210 001273 BNE 64$ ;BR, IF NOT AT 25 FILES WRITTEN
1241
1242 ;*****
1243 ;
1244 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
1245 ;
1246 ;*****
1247
1248 034212 012737 141011 036410' MOV #141011,T30PK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
1249 034220 012704 036410' MOV #T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
1250 034224 010465 000000 MOV R4,TSDB(R5) ;ISSUE COMMAND
1251 034230 004737 016140' JSR PC,WAITF ;WAIT FOR SSR TO SET
1252 034234 016501 000002 MOV TSSR(R5),R1 ;PICK UP TSSR
1253 034240 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED (SSR ONLY)
1254 034244 020102 CMP R1,R2 ;WAS STATUS GOOD
1255 034246 001406 BEQ 165$ ;BR, IF TERMINATION WAS GOOD
1256 034250 005237 002214' INC FATFLG ;ERROR COUNT
1260 034254 ERRHRD ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP C$ERHRD
                                .WORD 224
                                .WORD T30WDC
                                .WORD PKTSSR
                                TRAP C$CLP1
                                .WORD 104456
                                .WORD 000340
                                .WORD 040152'
                                .WORD 011736'
1261 034264 165$: CKLOOP ;LOOP IF SELECTED
                                TRAP C$CLP1
                                .WORD 104406
1262
1263 ;*****
1264 ;
1265 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
1266 ;
1267 ;*****
1268
1269 034266 004737 010704' JSR PC,REWIND ;CALL TAPE REWIND COMMAND
1270 034272 103411 BCS 170$ ;BR, IF NO PROBLEM
1271 034274 010004 MOV R0,R4 ;GET PACKET ADDRESS
    
```


TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
TEST 2: SKIP TAPE MARKS

SEQ 113

```

1272 034276 016501 000002      MOV      TSSR(R5),R1      ;GET STATUS REGISTER
1273 034302 005237 002214'    INC      FATFLG          ;ERROR COUNT
1277 034306      ERRHRD  ERRNO,T3ORWN,PKTSSR ;REWIND NOT ACCEPTED
      034306 104456      TRAP    C$ERHRD
      034310 000341      .WORD  225
      034312 040030'    .WORD  T3ORWN
      034314 011736'    .WORD  PKTSSR
1278 034316      170$:  CKLOOP          ;LOOP IF SELECTED      TRAP    C$CLP1
      034316 104406
1279
1280      ;*****
1281      ;
1282      ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
1283      ;
1284      ;*****
1285
1286 034320 013701 036310'    MOV      T3OBF+6,R1     ;PICK UP XSTO
1287 034324 010102      MOV      R1,R2          ;SET UP EXPECTED
1288 034326 052702 000002    BIS      #BIT1,R2       ;SET BOT BIT IN EXPECTED
1289 034332 020102      CMP      R1,R2          ;DOES EXP = REC'D
1290 034334 001406      BEQ     180$            ;BR, IF EQUAL (OK)
1291 034336 005237 002214'    INC      FATFLG          ;ERROR COUNT
1295 034342      ERRHRD  ERRNO,T3OBOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      034342 104456      TRAP    C$ERHRD
      034344 000342      .WORD  226
      034346 037631'    .WORD  T3OBOT
      034350 015364'    .WORD  EXPREC
1296 034352      180$:  CKLOOP          ;LOOP IF SELECTED      TRAP    C$CLP1
      034352 104406
1297 034354 012737 000002 036444'  MOV      #2,T3OFCN      ;SET TO NUMBER OF SKIP "FILES"
1298 034362 012703 036426'  MOV      #T3OIMV,R3     ;SET UP POINTER TO COMMAND TABLE
1299 034366 013737 002174' 036300'  MOV      UNITN,T3ODSW   ;SET UP UNIT NUMBER
1300 034374 011337 036276' 182$:  MOV      (R3),T3OETM ;GET NEXT COMMAND
1301 034400 012704 036260'  MOV      #T3OPACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
1302
1303      ;*****
1304      ;
1305      ;ISSUE WRITE CHARACTERISTICS COMMAND
1306      ;
1307      ;*****
1308
1309 034404 004737 010552'    JSR      PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
1310 034410 103407      BCS     188$            ;BR, IF COMMAND ISSUED OK
1311 034412 005237 002214'    INC      FATFLG          ;ERROR COUNT
1315 034416 010001      MOV      R0,R1          ;SAVE CONTENTS OF TSSR
1316 034420      ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
      034420 104456      TRAP    C$ERHRD
      034422 000343      .WORD  227
      034424 005046'    .WORD  WRTMSG
      034426 011724'    .WORD  SFIMSG
1317 034430      188$:  CKLOOP          ;LOOP IF SELECTED      TRAP    C$CLP1
      034430 104406
1318
1319      ;*****
1320      ;
1321      ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
1322      ;

```

```

1323 ;*****
1324
1325 034432 012737 141010 036410'      MOV      #141010,T30PK3      ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
1326 034440 013737 036444' 036412'      MOV      T30FCN,T30RB      ;SET UP NUMBER TO SKIP
1327 034446 012704 036410'      MOV      #T30PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
1328 034452 010465 000000      189$:   MOV      R4,TSD8(R5)      ;ISSUE COMMAND
1329 034456 012737 176750 036446'      MOV      #65000.,T30DLY     ;SET UP DELAY COUNTER
1330 034464 004737 016140'      190$:   JSR      PC,WAITF          ;WAIT FOR SSR TO SET
1331 034470 016501 000002      MOV      TSSR(R5),R1       ;PICK UP TSSR
1332 034474 032701 000200      BIT      #SSR,R1           ;IS SSR SET YET
1333 034500 001017      BNE      191$              ;BR, IF SSR IS SET
1334 034502      DELAY      250            ;CALL DELAY ROUTINE
      MOV      #250,(PC)+
      .WORD      0
      MOV      L$DLY,(PC)+
      .WORD      0
      DEC      -6(PC)
      BNE      .-4
      DEC      -22(PC)
      BNE      .-20
1335 034532 005337 036446'      DEC      T30DLY            ;BUMP DELAY ROUTINE
1336 034536 001352      BNE      190$              ;BR, IF MORE DELAY TO GO
1337 034540 012702 000200      191$:   MOV      #SSR,P2          ;SET UP EXPECTED (SSR ONLY)
1338 034544 020102      CMP      R1,R2              ;WAS STATUS GOOD
1339 034546 001406      BEQ      192$              ;BR, IF TERMINATION WAS GOOD
1340 034550 005237 002214'      INC      FATFLG             ;ERROR COUNT
1344 034554      ERRHRD   ERRNO,T30SKM,PKTSSR ;TSSR NOT CORRECT AFTER SKIP TAPE M.
      TRAP    C$ERHRD
      .WORD   228
      .WORD   T30SKM
      .WORD   PKTSSR
1345 034564      192$:   CKLOOP              ;LOOP IF SELECTED
      TRAP    C$CLP1
1346
1347 ;*****
1348 ;
1349 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
1350 ;
1351 ;*****
1352
1353 034566 013701 036310'      MOV      T30BFR+6,R1       ;PICK UP XSTO
1354 034572 010102      MOV      R1,R2              ;SET UP EXPECTED
1355 034574 052702 100000      BIS      #BIT15,R2         ;SET TMK BIT IN EXPECTED
1356 034600 020102      CMP      R1,R2              ;DOES EXP = REC'D
1357 034602 001406      BEQ      195$              ;BR, IF EQUAL (OK)
1358 034604 005237 002214'      INC      FATFLG             ;ERROR COUNT
1362 034610      ERRHRD   ERRNO,T30TMK,EXPREC ;TMK NOT SET AFTER WRT TAPE MARK
      TRAP    C$ERHRD
      .WORD   229
      .WORD   T30TMK
      .WORD   EXPREC
1363 034620      195$:   CKLOOP              ;LOOP IF SELECTED
      TRAP    C$CLP1
1364 034622 012700 177777      MOV      #177777,R0        ;VALUE TO WRITTEN TO MEMORY
1365 034626 004737 017314'      JSR      PC,FILLMEM         ;FILL MEM WITH ALL ONES
1366 034632 013737 003116 036412'      MOV      FREE,T30RB        ;STARTING READ BUFFER ADDRESS
1367

```

```

1368 ;*****
1369 ;
1370 ;READ FORWARD,ACK,CVC=1 COMMAND
1371 ;
1372 ;*****
1373
1374 034640 012737 140001 036410'      MOV      0140001,T30PK3      ;READ FORWARD,ACK,CVC=1 COMMAND
1375 034646 012704 036410'      MOV      0T30PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
1376 034652 012737 000024 036416'      MOV      020.,T30SZ        ;SET UP RECORD SIZE IN PACKET
1377 034660 010465 000000          MOV      R4,T30DB(R5)      ;ISSUE COMMAND
1378 034664 004737 016140          JSR      PC,WAITF          ;WAIT FOR SSR TO SET
1379 034670 016501 000002          MOV      T30SR(R5),R1     ;GET T30SR CONTENTS
1380 034674 012702 000200          MOV      0SSR,R2         ;SET UP EXPECTED
1381 034700 020102          CMP      R1,R2           ;ARE THEY EQUAL
1382 034702 001406          BEQ      200$           ;BR. IF OK
1383 034704 005237 002214'      INC      FATFLG          ;ERROR COUNT
1387 034710          ERRHRD  ERRNO,T30RDF,PKTSSR ;T30SR INCORRECT AFTER WRITE DATA
                                TRAP      C$ERRHRD
                                .WORD    230
                                .WORD    T30RDF
                                .WORD    PKTSSR
                                TRAP      C$CLP1
                                .WORD    200$
                                CKLOOP
                                ;LOOP IF SELECTED
1388 034720          200$:
                                034720 104406          ;FIRST LOC IN READ BUFFER
1389 034722 017701 146170          MOV      0FREE,R1        ;EXPECTED IF NO DATA TRANS.
1390 034726 012702 177777          MOV      0177777,R2      ;DID ANY DATA GET TRANSFERRED
1391 034732 020102          CMP      R1,R2           ;BR. IF NO DATA TRANS (GOOD)
1392 034734 001006          BNE      220$           ;ERROR COUNT
1393 034736 005237 002214'      INC      FATFLG          ;DATA TRANSFERRED ON READ TAPE MARK
1397 034742          ERRHRD  ERRNO,T30DTR,EXPREC ;
                                TRAP      C$ERRHRD
                                .WORD    231
                                .WORD    T30DTR
                                .WORD    EXPREC
                                TRAP      C$CLP1
                                .WORD    220$
                                CKLOOP
                                ;LOOP IF SELECTED
1398 034752          220$:
                                034752 104406          ;GET NUMBER OF SKIPS
1399 034754 013702 036444'      MOV      T30FCN,R2       ;SET TO CORRECT FILE VALUE
1400 034760 005202          INC      R2              ;SWAP BYTE HALVES
1401 034762 000502          SWAB    R2              ;SET FOR RECORD #1
1402 034764 052702 000001          BIS      0BIT0,R2        ;GET INFO FROM BUFFER
1403 034770 017701 146122          MOV      0FREE,R1        ;ARE THEY EQUAL
1404 034774 020201          CMP      R2,R1           ;BR. IF EQUAL (OK)
1405 034776 001406          BEQ      228$           ;ERROR COUNT
1406 035000 005237 002214'      INC      FATFLG          ;RECORD POSITION WAS NOT CORRECT
1410 035004          ERRHRD  ERRNO,T30PTB,EXPREC ;
                                TRAP      C$ERRHRD
                                .WORD    232
                                .WORD    T30PTB
                                .WORD    EXPREC
                                TRAP      C$CLP1
                                .WORD    228$
                                CKLOOP
                                ;LOOP IF SELECTED
1411 035014          228$:
                                035014 104406          ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
1412 ;*****
1413 ;
1414 ;
1415 ;
1416 ;
1417 ;*****
1418 ;

```

```

1419 035016 004737 010704'          JSR    PC,REWIND          ;CALL TAPE REWIND COMMAND
1420 035022 103411                 BCS    230$              ;BR, IF NO PROBLEM
1421 035024 010004                 MOV    R0,R4            ;SAVE PACKET ADDRESS
1422 035026 016501 000002         MOV    TSSR(R5),R1      ;GET TSSR STATUS
1423 035032 005237 002214'         INC    FATFLG           ;ERROR COUNT
1427 035036                 ERRHRD  ERRNO,T3ORWN,PKTSSR ;REWIND NOT ACCEPTED
                                035036 104456                 TRAP   C$ERHRD
                                035040 000351                 .WORD 233
                                035042 040030'                .WORD T3ORWN
                                035044 011736'                .WORD PKTSSR
1428 035046                 230$: CKLOOP            ;LOOP IF SELECTED
                                035046 104406                 TRAP   C$CLP1
1429
1430
1431
1432
1433
1434
1435
                                ;*****
                                ; GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
                                ;*****
1436 035050 013701 036310'         MOV    T30BFR+6,R1     ;PICK UP XSTO
1437 035054 010102                 MOV    R1,R2           ;SET UP EXPECTED
1438 035056 052702 000002         BIS    #BIT1,R2        ;SET BOT BIT IN EXPECTED
1439 035062 020102                 CMP    R1,R2           ;DOES EXP = REC'D
1440 035064 001406                 BEQ    240$            ;BR, IF EQUAL (OK)
1441 035066 005237 002214'         INC    FATFLG           ;ERROR COUNT
1445 035072                 ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                035072 104456                 TRAP   C$ERHRD
                                035074 000352                 .WORD 234
                                035076 037631'                .WORD T30BOT
                                035100 015364'                .WORD EXPREC
1446 035102                 240$: CKLOOP            ;LOOP IF SELECTED
                                035102 104406                 TRAP   C$CLP1
1447 035104 005723                 TST    (R3)+           ;POINT TO NEXT POSITION
1448 035106 011301                 MOV    (R3),R1         ;GET NEXT COMMAND ETC.
1449 035110 020127 177777         CMP    R1,#177777     ;END OF TABLE MARKER
1450 035114 001410                 BEQ    330$            ;BR, IF AT END OF TABLE
1451 035116 013701 036444'         MOV    T30FCN,R1      ;GET NUMBER OF SKIPS
1452 035122 000241                 CLC                    ;CLEAR THE CARRY BIT
1453 035124 006101                 ROL    R1              ;PUSH OVER ONE POSITION
1454 035126 010137 036444'         MOV    R1,T30FCN      ;PUT BACK IN COUNTER
1455 035132 000137 034374'         JMP    182$            ;JUMP TO MORE COMMANDS TO DO
1456 035136                 330$: CKLOOP            ;LOOP IF SELECTED
                                035136 104406                 TRAP   C$CLP1
1457 035140                 ENDSUB                ;<<<<<<<<<<<<< END SUBTEST >>>>>>>>>>>>>
                                035140                 L10045:
                                035140 104403                 TRAP   C$ESUB
1458 035142 023727 002214' 000017  CMP    FATFLG,#15     ;IS ERROR COUNT AT 25
1459 035150 103402                 BLO    999$            ;BR, IF LESS THAN 25
1460 035152 004737 017074'         JSR    PC,CKDROP      ;TRY TO DROP THE UNIT
1461 035156
0999$:
1462
1463
1464
1465
1466
1467
1468
                                ;TEST 2, SUBTEST 3
                                ;
                                ; VERIFIES THAT A SKIP TAPE MARKS REVERSE COMMAND
                                ; ISSUED WHILE THE TAPE IS POSITIONED AT BOT CAUSES

```



```

1513
1514
1515
1516
1517
1518
1519
1520 035330 004737 010704'      JSR      PC,REWIND          ;CALL TAPE REWIND COMMAND
1521 035334 103411              BCS      300                ;BR, IF NO PROBLEM
1522 035336 010004              MOV      R0,R4              ;GET PACKET ADDRESS
1523 035340 016501 000002      MOV      TSSR(R5),R1        ;GET STATUS REGISTER
1524 035344 005237 002214'      INC      FATFLG             ;ERROR COUNT
1528 035350              ERRHRD  ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
      035350 104456              TRAP    C1ERHPD
      035352 000355              .WORD  237
      035354 040030'          .WORD  T30RWN
      035356 011736'          .WORD  PKTSSR
1529 035360              300:   CKLOOP              ;LOOP IF SELECTED
      035360 104406              TRAP    C1CLP1
1530
1531
1532
1533
1534
1535
1536
1537 035362 013701 036310'      MOV      T30BFR+6,R1        ;PICK UP XSTO
1538 035366 010102              MOV      R1,R2              ;SET UP EXPECTED
1539 035370 052702 000002      BIS      #BIT1,R2           ;SET BOT BIT IN EXPECTED
1540 035374 020102              CMP      R1,R2              ;DOES EXP = REC'D
1541 035376 001406              BEQ      400                ;BR, IF EQUAL (OK)
1542 035400 005237 002214'      INC      FATFLG             ;ERROR COUNT
1546 035404              ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      035404 104456              TRAP    C1ERHRD
      035406 000356              .WORD  238
      035410 037631'          .WORD  T30BOT
      035412 015364'          .WORD  EXPREC
1547 035414              400:   CKLOOP              ;LOOP IF SELECTED
      035414 104406              TRAP    C1CLP1
1548 035416 012737 000001 036412'  MOV      #1,T30WB          ;SET 0 OF TM TO SKIP
1549
1550
1551
1552
1553
1554
1555
1556 035424 012737 141410 036410'  MOV      #141410,T30PK3     ;SKIP TAPE MARK REVERSE,ACK,CVC=1 CMD
1557 035432 012704 036410'      MOV      #T30PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
1558 035436 010465 000000      MOV      R4,T30B(R5)       ;ISSUE COMMAND
1559 035442 004737 016140'      JSR      PC,WAITF          ;WAIT FOR SSR TO SET
1560 035446 016501 000002      MOV      TSSR(R5),R1        ;GET TSSR CONTENTS
1561 035452 012702 100206      MOV      #SSR!SC!BIT1!BIT2,R2 ;SET UP EXPECTED
1562 035456 020102              CMP      R1,R2              ;ARE THEY EQUAL
1563 035460 001406              BEQ      700                ;BR, IF OK
1564 035462 005237 002214'      INC      FATFLG             ;ERROR COUNT
1568 035466              ERRHRD  ERRNO,T30IBT,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA

```


D10

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 2: SKIP TAPE MARKS

SEQ 120

```

1615 035574 012737 176750 036446'      MOV      #65000.,T3ODLY      ;SET UP DELAY COUNTER
1616 035602 004737 015664'      10$:    JSF      PC,SOFINIT      ;DO INITIALIZE ON CONTROLLER
1617 035606 103426                    BCS      20$              ;BR IF INIT WAS OK
1618 035610                    DELAY    250              ;DELAY ROUTINE CALL
      035610 012727 000250                    MOV      #250,(PC)+
      035614 000000                    .WORD   0
      035616 013727 002116'      MOV      L$DLY,(PC)+
      035622 000000                    .WORD   0
      035624 005367 177772                    DEC      -6(PC)
      035630 001375                    BNE     .-4
      035632 005367 177756                    DEC      -22(PC)
      035636 001367                    BNE     .-20
1619 035640 005337 036446'      DEC      T3ODLY          ;BUMP COUNTER
1620 035644 001356                    BNE     10$              ;BR, IF MORE COUNTING TO DO
1621 035646 005337 002214'      INC      FATFLG          ;ERROR COUNT
1625 035652 010001                    MOV      R0,R1           ;CONTENTS OF TSSR REGISTER
1626 035654                    ERRDF   ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
      035654 104455                    TRAP    C$ERDF
      035656 000361                    .WORD   241
      035660 003642'                    .WORD   SFIERR
      035662 011724'                    .WORD   SFIMSG
1627 035664                    20$:
1628 035664 013737 002174' 036300'  MOV      UNITN,T3ODSW      ;SET UP UNIT NUMBER
1629 035672 012704 036260'      MOV      @T3OPACKET,R4    ;SUBROUTINE NEEDS PACKET ADDRESS
1630
1631 ;*****
1632 ;
1633 ;ISSUE WRITE CHARACTERISTICS COMMAND
1634 ;
1635 ;*****
1636
1637 035676 004737 010552'      JSR      PC,WRTCHR        ;ISSUE WRITE CHARACTERISTICS
1638 035702 103407                    BCS      23$              ;BR, IF COMMAND ISSUED OK
1639 035704 005237 002214'      INC      FATFLG          ;ERROR COUNT
1643 035710 010001                    MOV      R0,R1           ;SAVE CONTENTS OF TSSR
1644 035712                    ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
      035712 104456                    TRAP    C$ERHRD
      035714 000362                    .WORD   242
      035716 005046'                    .WORD   WRTMSG
      035720 011724'                    .WORD   SFIMSG
1645 035722                    23$:    CKLOOP            ;LOOP IF SELECTED
      035722 104406                    TRAP    C$CLP1
1646
1647 ;*****
1648 ;
1649 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
1650 ;
1651 ;*****
1652
1653 035724 004737 010704'      JSR      PC,REWIND        ;CALL TAPE REWIND COMMAND
1654 035730 103411                    BCS      30$              ;BR, IF NO PROBLEM
1655 035732 010004                    MOV      R0,R4           ;GET PACKET ADDRESS
1656 035734 016501 000002      MOV      TSSR(R5),R1     ;GET STATUS REGISTER
1657 035740 005237 002214'      INC      FATFLG          ;ERROR COUNT
1661 035744                    ERRHRD  ERRNO,T3ORWN,PKTSSR ;REWIND NOT ACCEPTED
      035744 104456                    TRAP    C$ERHRD
      035746 000363                    .WORD   243
  
```


E10

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
TEST 2: SKIP TAPE MARKS

SEQ 121

```

035750 040030'
035752 011736'
1662 035754 104406      30$:   CKLOOP                    ;LOOP IF SELECTED
                                .WORD   T30RWN
                                .WORD   PKTSSR
                                TRAP    C$CLP1
1663
1664
1665 ;*****
1666 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
1667 ;
1668 ;*****
1669
1670 035756 013701 036310'      MOV     T30BFR+6,R1          ;PICK UP XSTO
1671 035762 010102              MOV     R1,R2              ;SET UP EXPECTED
1672 035764 052702 000002      BIS     @BIT1,R2          ;SET BOT BIT IN EXPECTED
1673 035770 020102              CMP     R1,R2              ;DOES EXP = REC'D
1674 035772 001406              BEQ    40$                ;BR, IF EQUAL (OK)
1675 035774 005237 002214'      INC     FATFLG             ;ERROR COUNT
1679 036000              ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP    C$ERHRD
                                .WORD   244
                                .WORD   T30BOT
                                .WORD   EXPREC
036000 104456
036002 000364
036004 037631'
036006 015364'
1680 036010 104406      40$:   CKLOOP                    ;LOOP IF SELECTED
                                TRAP    C$CLP1
1681 036012 013737 002116' 036412'      MOV     FREE,T30WB        ;SET UP GOOD WRITE BUFFER
1682 036020 012737 000400 036416'      MOV     @256.,T30SZ      ;SET UP SIZE
1683
1684 ;*****
1685 ;
1686 ;WRITE DATA,ACK,CVC=1 COMMAND
1687 ;
1688 ;*****
1689
1690 036026 012737 140005 036410'      MOV     @140005,T30PK3   ;WRITE DATA,ACK,CVC=1 COMMAND
1691 036034 012704 036410'      MOV     @T30PK3,R4       ;SET UP R4 WITH PACKET ADDRESS
1692 036040 010465 000000      MOV     R4,T30DB(R5)     ;ISSUE COMMAND
1693 036044 004737 016140'      JSR     PC,WAITF         ;WAIT FOR SSR TO SET
1694 036050 016501 000002      MOV     TSSR(R5),R1      ;GET TSSR CONTENTS
1695 036054 012702 000200      MOV     @SSR,R2          ;SET UP EXPECTED
1696 036060 020102              CMP     R1,R2            ;ARE THEY EQUAL
1697 036062 001406              BEQ    70$                ;BR, IF OK
1698 036064 005237 002214'      INC     FATFLG             ;ERROR COUNT
1702 036070              ERRHRD  ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP    C$ERHRD
                                .WORD   245
                                .WORD   T30WDD
                                .WORD   PKTSSR
036070 104456
036072 000365
036074 036760'
036076 011736'
1703 036100 104406      70$:   CKLOOP                    ;LOOP IF SELECTED
                                TRAP    C$CLP1
1704
1705 ;*****
1706 ;
1707 ;SKIP TAPE MARK REVERSE,ACK,CVC=1 COMMAND
1708 ;
1709 ;*****
1710
1711 036102 012737 000001 036412'      MOV     @1,T30WB         ;# OF TM TO SKIP

```

F10

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
TEST 2: SKIP TAPE MARKS

SEQ 122

```

1712 036110 012737 141410 036410'          MOV      #141410,T30PK3          ;SKIP TAPE MARK REVERSE,ACK,CVC=1 CMD
1713 036116 012704 036410'          MOV      #T30PK3,R4             ;SET UP R4 WITH PACKET ADDRESS
1714 036122 010465 000000          MOV      R4,TSDB(R5)           ;ISSUE COMMAND
1715 036126 004737 016140'          JSR      PC,WAITF              ;WAIT FOR SSR TO SET
1716 036132 016501 000002          MOV      TSSR(R5),R1           ;PICK UP TSSR
1717 036136 012702 100204          MOV      #SSR!BIT2!SC,R2       ;SET UP EXPECTED (SSR AND SC ONLY)
1718 036142 020102          CMP      R1,R2                 ;WAS STATUS GOOD
1719 036144 001406          BEQ      160$                  ;BR, IF TERMINATION WAS GOOD
1720 036146 005237 002214'          INC      FATFLG                 ;ERROR COUNT
1724 036152          ERRHRD  ERRNO,T30IBU,PKTSSR    ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                   TRAP      C$ERHRD
                                   .WORD    246
                                   .WORD    T30IBU
                                   .WORD    PKTSSR
1725 036162          160$:  CKLOOP                ;LOOP IF SELECTED
                                   TRAP      C$CLP1
                                   .WORD    104406
1726
1727
1728          ;*****
1729          ;GET EXTENDED STATUS REGISTER ZERO (XST3) FROM MESSAGE BUFFER
1730
1731          ;*****
1732
1733 036164 013701 036316'          MOV      T308FR+14,R1          ;PICK UP XST3
1734 036170 010102          MOV      R1,R2                 ;SET UP EXPECTED
1735 036172 052702 000001          BIS      #BIT0,R2              ;SET RIB BIT IN EXPECTED
1736 036176 020102          CMP      R1,R2                 ;DOES EXP = REC'D
1737 036200 001406          BEQ      170$                  ;BR, IF EQUAL (OK)
1738 036202 005237 002214'          INC      FATFLG                 ;ERROR COUNT
1742 036206          ERRHRD  ERRNO,T30RIB,EXPREC    ;TAPE NOT AT RIB
                                   TRAP      C$ERHRD
                                   .WORD    247
                                   .WORD    T30RIB
                                   .WORD    EXPREC
1743 036216          170$:  CKLOOP                ;LOOP IF SELECTED
                                   TRAP      C$CLP1
                                   .WORD    104406
1744 036220          ENDSUB                    ;<<<<<<<<<< END SUBTEST >>>>>>>>
                                   L10047:
                                   TRAP      C$ESUB
1745 036222 023727 002214' 000017    CMP      FATFLG,#15.           ;IS ERROR COUNT AT 25
1746 036230 103402          BLO      999$                   ;BR, IF LESS THAN 25
1747 036232 004737 017074'          JSR      PC,CKDROP             ;TRY TO DROP THE UNIT
1748 036236          999$:
1749
1750          ;SUBTEST END
1751
1752
1753 036236 004737 016350'          JSR      PC,TSTLOOP            ;DO WE NEED TO ITERATE TEST
1754 036242 103002          BCC      400$                   ;BR, IF NO LOOP REQUIRED
1755 036244 000137 032140'          JMP      T30LOOP               ;EXECUTE AGAIN
1756 036250          400$:  EXIT                   ;ALL DONE THIS TEST
                                   TRAP      C$EXIT
                                   .WORD    L10043..
1757
1758
1759          ;*
1760          ;LOCAL STORAGE FOR THIS TEST
          ;

```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M113 01-FEB-84 18:55
 TEST 2: SKIP TAPE MARKS

SEQ 123

1762	036254		.BLKB	10-<.TSV2&7>	
1764	036260		T3OPACKET:		;COMMAND PACKET FOR TEST
1765	036260	100004	.WORD	100004	;WRITE CHARACTERISTICS COMMAND, WITH , ACK
1766	036262	036270	.WORD	T30DATA	;ADDRESS OF CHARACTERISTICS BLOCK
1767	036264	000000	.WORD	0	
1768	036266	000012	.WORD	10.	;STARTING VALUE OF BLOCK SIZE
1769	036270		T30DATA:		;CHARACTERISTICS DATA BLOCK
1770	036270	036302	.WORD	T30BFR	;ADDRESS OF MESSAGE BUFFER
1771	036272	000000	.WORD	0	
1772	036274	000024	.WORD	20.	;LENGTH OF MESSAGE BUFFER
1773	036276	000000	T30ETM:	.WORD 0	;SKIP TAPE MARK CONTROL
1774	036300	000000	T30DSW:	.WORD 0	;SELECT DRIVE 0
1775	036302		T30BFR:	.BLKW 25.	;MESSAGE BUFFER
1776					
1777					
1778					
1780	036364		.BLKB	10-<.-TSV2&7>	
1782	036370		T30PK2:		
1783	036370	100006	.WORD	100006	;WRITE SUB SYS MEM COMMAND, AND ACK
1784	036372	036420	.WORD	T30BF2	;ADDRESS OF SELECT BLOCK DATA
1785	036374	000000	.WORD	0	
1786	036376	000006	.WORD	6.	;SIZE OF DATA PACKET
1787					
1789	036400		.BLKB	10-<.-TSV2&7>	
1791	036410		T30PK3:		
1792	036410	100205	.WORD	100205	;REREAD COMMAND, IE AND ACK
1793	036412		T30RB:		
1794	036412	003116	T30WB:	.WORD FREE	;ADDRESS OF WRITE BUFFER
1795	036414	000000	.WORD	0	
1796	036416	000000	T30SZ:	.WORD 0	;SIZE OF BUFFER (EXTENT)
1797			.EVEN		
1798					
1799					
1800					
1801	036420		T30BF2:		
1802	036420	010	T30BS0:	.BYTE 10	;BSEL0 AREA
1803	036421	200	T30BS1:	.BYTE 200	;BSEL1 AREA
1804	036422	000000	T30S2:	.WORD 0	;SEL 2 AREA
1805	036424	000000	T30S3:	.WORD 0	;DATA AREA
1806					
1807					
1808					
1809			.EVEN		
1810			;TAPE MOTION PACKET COMMAND VALUES		
1811	036426		T30IMV:		
1812	036426		T30RN:		
1813	036426	000000	.WORD	000000	;NEITHER EWB NOR ESS
1814	036430	000100	.WORD	000100	;EWB SET
1815	036432	000200	.WORD	000200	;ESS SET
1816	036434	000300	.WORD	000300	;BOTH EWB AND ESS SET
1817	036436	177777	.WORD	177777	;END OF DATA
1818					
1819					
1820	036440	000000	T30CNT:	.WORD 0	;TAPE TIMER COUNTER STORAGE AREA
1821	036442	000000	T30CNU:	.WORD 0	;TAPE TIMER COUNTER STORAGE AREA
1822	036444	000000	T30FCN:	.WORD 0	;FILE NUMBER COUNTER
1823	036446	000000	T30DLY:	.WORD 0	;DELAY COUNTER STORAGE

```

1824
1825
1826
1827
1828
1829
1830
1831 036450      124      123      123  T30IBU: .ASCIZ 'TSSR Incorrect After SKIP TAPE MARK REVERSE Into BOT'
1832 036535      122      111      102  T30RIB: .ASCIZ 'RIB Bit (XST3) Failed To Set After Reverse Into BOT'
1833 036621      124      123      123  T30IBT: .ASCIZ 'TSSR Incorrect After SKIP TAPE MARK REVERSE At BOT'
1834 036704      124      123      123  T30SKM: .ASCIZ 'TSSR Incorrect After SKIP TAPE MARK Command'
1835 036760      124      123      123  T30WDD: .ASCIZ 'TSSR Not Correct After WRITE DATA Command'
1836 037032      124      141      160  T30PTB: .ASCIZ 'Tape Not Positioned On Correct Record After READ REVERSE'
1837 037123      124      141      160  T30TPB: .ASCIZ 'Tape Not Positioned On Second File First Record'
1838 037203      124      123      123  T30RDF: .ASCIZ 'TSSR Incorrect After READ FORWARD Into "File"'
1839 037261      124      123      123  T30RDG: .ASCIZ 'TSSR Incorrect After SPACE Command Into TAPE MARK'
1840 037343      124      123      123  T30WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
1841 037A20      111      154      154  T30LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
1842 037501      127      122      111  T30SSR: .ASCIZ 'WRITE MISCELLANEOUS Command Not Accepted'
1843 037552      124      123      123  T30WDE: .ASCIZ 'TSSR Not Correct After SKIP TAPE MARKS, At BOT'
1844 037631      124      141      160  T30BOT: .ASCIZ 'Tape Not At BOT After REWIND Command'
1845 037676      124      123      123  T30TM: .ASCIZ 'TSSR Not Correct After SPACE FORWARD Command'
1846 037753      124      123      123  T30TM2: .ASCIZ 'TSSR Not Correct After SPACE REVERSE Command'
1347 040030      122      145      167  T30RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
1348 040077      104      162      151  T30OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
1849 040152      124      123      123  T30WDC: .ASCIZ 'TSSR Not Correct After WRITE TAPE MARK Command'
1850 040231      103      126      103  T30VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
1851 040304      124      115      113  T30TMK: .ASCIZ 'TMK Not Set After WRITE TAPE MARK (RETRY) Command'
1852 040366      123      113      111  T30NEF: .ASCIZ 'SKIP TAPE MARKS, At BOT, Failed To Set NEF Bit'
1853 040445      124      115      113  T30RRM: .ASCIZ 'TMK Not Set After READ REVERSE Into TAPE MARK'
1854 040523      124      115      113  T30RRN: .ASCIZ 'TMK Not Set After SPACE REVERSE Into TAPE MARK'
1855 040602      124      115      113  T30RRP: .ASCIZ 'TMK Not Set After READ FORWARD Into TAPE MARK'
1856 040660      116      117      040  T30DTR: .ASCIZ 'NO Data Transferred On READ FORWARD'
1857 040724      104      141      164  T30DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
1858 041021      123      153      151  TST30ID: .ASCIZ 'Skip Tape Marks'
1859
1860
1861
1862
1863
1864
1865
1866
1867 041042
1868 041042
1869 041046      012701  036260'
1870 041052      012721  100004
1871 041056      012721  036270'
1872 041062      005021
1873 041064      012721  000012
1874 041070      012721  036302'
1875 041074      005021
1876 041076      012721  000024
1877 041102      005021
1878 041104      012711  000000
1879 041110      012702  000030
1880 041114      012762  177777  036302' 64$:

```

```

;+
;LOCAL TEXT MESSAGES FOR TEST
;-

;+
;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
;WRITE SUBSYSTEM MEMORY COMMAND
;-

T30REST:
    SAVREG
    MOV     @T30PACKET,R1
    MOV     @100004,(R1)+
    MOV     @T30DATA,(R1)+
    CLR     (R1)+
    MOV     @10.,(R1)+
    MOV     @T30BFR,(R1)+
    CLR     (R1)+
    MOV     @20.,(R1)+
    CLR     (R1)+
    MOV     @0,(R1)
    MOV     @24.,R2
    MOV     @177777,T30BFR(R2)
;SAVE THE REGISTERS
;START OF THE PACKET
;WRITE SUBSYSTEM MEM. WITH ACK.
;ADDRESS OF CHARAISTICS DATA BLOCK
;EXTENDED ADDRESS
;SIZE OF DATA BLOCK IN BYTES
;ADDRESS OF MESSAGE BUFFER
;LENGTH OF MESSAGE BUFFER
;SELECT DRIVE ZERO
;NUMBER OF LOCATIONS TO BE CLEARED
;ALL ONES TO MESSAGE BUFFER

```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 2: SKIP TAPE MARKS

SEQ 125

```

1881 041122 005742          TST      -(R2)          ;NEXT LOCATION
1882 041124 022702 000000    CMP      #0.,R2        ;CHECK R2 FOR DONE
1883 041130 001371          BNE     64$           ;KEEP GOING UNTIL DONE
1884 041132 000207          RTS      PC           ;RETURN
1885
1886
1887 041134          T3ORT2:
1888 041134          SAVREG          ;SAVE THE REGISTERS
1889 041140 012701 036370'    MOV      #T30PK2,R1   ;START OF THE PACKET
1890 041144 012721 100006    MOV      #100006,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK,
1891 041150 012721 036420'    MOV      #T30BF2,(R1)+ ;ADDRESS OF DATA BLOCK
1892 041154 005021          CLR      (R1)+        ;EXTENDED ADDRESS
1893 041156 012721 000006    MOV      #6.,(R1)+    ;SIZE OF DATA BLOCK IN BYTES
1894 041162 005021          CLR      (R1)+
1895 041164 012701 036420'    MOV      #T30BF2,R1   ;POINT TO DATA SEL AREA
1896 041170 005021          CLR      (R1)+
1897 041172 005011          CLR      (R1)
1898 041174 000207          RTS      PC           ;RETURN
1899 041176          T3ORT3:
1900 041176          SAVREG          ;SAVE REGISTERS
1901 041202 012701 036410'    MOV      #T30PK3,R1   ;SET UP POINTER ADDRESS
1902 041206 005021          CLR      (R1)+        ;COMMAND SPACE
1903 041210 005021          CLR      (R1)+        ;ADDRESS OF DATA BLOCK
1904 041212 005021          CLR      (R1)+        ;EXTENDED ADDRESS
1905 041214 005011          CLR      (R1)         ;SIZE OF DATA TRANSFER BLOCK
1906 041216 000207          RTS      PC           ;RETURN
1907 041220
1908 041220 104401          L10043:          TRAP      C$ETST
1909
1910          .SBTTL TEST 3: NO-UP ("CLEAN TAPE") AND INITIALIZE
1911          ;+
1912          ;THIS TEST VERIFIES PROPER OPERATION OF THE NO-OP ("CLEAN TAPE") AND INITIALIZE
1913          ;COMMAND (SPACE REVERSE, ERASE, WRITE DATA)
1914          ;
1915          ;
1916          ;THE TEST CONSISTS OF THE FOLLOWING 2 SUBTESTS
1917          ;
1918          ;
1919          ;
1920          ;-
1921 041222          BGNTST
1922 041222          MOV      #EPRT1,EPRTSW ;PRIMARY ERROR MESSAGE
1927 041230          MOV      #TST31ID,R0  ;ASCII MESSAGE TO IDENTIFY TEST
1928 041234          JSR      PC,ISTSETUP ;DO INITIAL TEST SETUP
1929 041240          MOV      #5,LOOPCNT  ;PERFORM 5 ITERATIONS
1930 041246          CLR      T31CNT     ;CLEAR TAPE RECORD COUNTER
1931          ;
1932          ;-
1933
1934 041252          T31LOOP:
1935          ;+
1936          ;
1937          ;
1938          ;TEST 3, SUBTEST 1

```

```

1939
1940
1941
1942
1943
1944
1945
1946
1947
1948
1949
1950
1951
1952
1953
1954
1955
1956
1957 041252          ;
      041252          ;
      041252 104402   ;
1958 041254 004737 046420' JSR    PC,T31REST      ;SET COMMAND PACKET
1959 041260 004737 046512' JSR    PC,T31RT2      ;SET UP OTHER COMMAND PACKET
1960 041264 004737 046554' JSR    PC,T31RT3      ;SET UP OTHER COMMAND PACKET
1961 041270 012737 176750 043152' MOV    #65000.,T31DLY ;SET UP DELAY COUNTER
1962 041276 004737 015664' 10$: JSR    PC,SOFINIT    ;DO INITIALIZE ON CONTROLLER
1963 041302 103426      BCS    20$          ;BR IF INIT WAS OK
1964 041304          DELAY 250          ;DELAY ABOUT .25 SEC
      041304 012727 000250          MOV    #250,(PC)+
      041310 000000          .WORD 0
      041312 013727 002116'          MOV    L$DLY,(PC)+
      041316 000000          .WORD 0
      041320 005367 177772          DEC    -6(PC)
      041324 001375          BNE    -4
      041326 005367 177756          DEC    -22(PC)
      041332 001367          BNE    -20
1965 041334 005337 043152' DEC    T31DLY      ;BUMP COUNTER
1966 041340 001356      BNE    10$          ;BR, IF COUNTER NOT DONE
1967 041342 005237 002214' INC    FATFLG      ;ERROR COUNT
1971 041346 010001      MOV    R0,R1      ;CONTENTS OF TSSR REGISTER
1972 041350          ERRDF ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
      041350 104455          TRAP    C$ERDF
      041352 000455          .WORD 301
      041354 003642'          .WORD SFIERR
      041356 011724'          .WORD SFIMSG
1973 041360 013737 002174' 043010' 20$: MOV    UNITN,T31DSW ;SET UP UNIT NUMBER IN PACKET
1974 041366 012704 042770' MOV    #T31PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
1975 041372 004737 010552' JSR    PC,WRTCHR    ;ISSUE WRITE CHARACTERISTICS
1976 041376 103407      BCS    23$          ;BR, IF COMMAND ISSUED OK
1977 041400 005237 002214' INC    FATFLG      ;ERROR COUNT
1981 041404 010001      MOV    R0,R1      ;SAVE CONTENTS OF TSSR
1982 041406          ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
      041406 104456          TRAP    C$ERHRD
      041410 000456          .WORD 302
      041412 005046'          .WORD WRTMSG
      041414 011724'          .WORD SFIMSG
1983 041416          23$: CKLOOP          ;LOOP IF SELECTED
    
```

VERIFIES THAT THE NO-OP COMMAND (CORRESPONDS TO THE CLEAN TAPE COMMAND) TERMINATES PROPERLY (NORMAL TERMINATION), STORES PROPER STATUS IN THE MESSAGE BUFFER (LIKE THE GET STATUS COMMAND), AND INDEED DOES NOT MOVE TAPE. THE TAPE IS FIRST REWOUND AND WRITTEN WITH SEQUENCED TEST RECORDS. IT IS THEN REWOUND AGAIN AND THE NO-OP COMMAND IS ISSUED. IT IS VERIFIED THAT THE TAPE IS STILL AT BOT AND THAT PROPER STATUS IS STORED. THE FIRST RECORD ON TAPE IS READ AND VERIFIED (TO CHECK TAPE POSITION AND VERIFY THAT DATA WAS NOT CHANGED), THEN THE NO-OP COMMAND IS ISSUED AGAIN AND STATUS AND POSITION VERIFIED.

Line	Address	Label	Op	Op	Op	Op	Op	Op	Op	Op	Op	Op
											TRAP	C\$CLP1
1984	041416	104406										
1985	041420	004737	010704'	JSR	PC,REWIND							
1986	041424	103407		BCS	30\$							
1987	041426	010004		MOV	R0,R4							
1991	041430	005237	002214'	INC	FATFLG							
1991	041434			ERRHRD	ERRNO,T31RWN,PKTSSR							
	041434	104456									TRAP	C\$ERHRD
	041436	000457									.WORD	303
	041440	044504'									.WORD	T31RWN
	041442	011736'									.WORD	PKTSSR
1992	041444			30\$:	CKLOOP							
	041444	104406										
1993	041446	013701	043020'	MOV	T31BFR+6,R1						TRAP	C\$CLP1
1994	041452	010102		MOV	R1,R2							
1995	041454	052702	000002	BIS	#BIT1,R2							
1996	041460	020102		CMP	R1,R2							
1997	041462	001406		BEQ	40\$							
1998	041464	005237	002214'	INC	FATFLG							
2002	041470			ERRHRD	ERRNO,T31BOT,EXPREC							
	041470	104456									TRAP	C\$ERHRD
	041472	000460									.WORD	304
	041474	044155'									.WORD	T31BOT
	041476	015364'									.WORD	EXPREC
2003	041500			40\$:	CKLOOP							
	041500	104406										
2004	041502	013737	003116' 043122'	MOV	FREE,T31WB						TRAP	C\$CLP1
2005	041510	012737	140005 043120'	MOV	#140005,T31PK3							
2006	041516	012704	043120'	MOV	#T31PK3,R4							
2007	041522	012700	000144	MOV	#100.,R0							
2008	041526	004737	017314'	JSR	PC,FILLMEM							
2009	041532	012737	000144 043126'	MOV	#100.,T31SZ							
2010	041540	010465	000000	MOV	R4,TSD8(R5)							
2011	041544	004737	016140'	JSR	PC,WAITF							
2012	041550	016501	000002	MOV	TSSR(R5),R1							
2013	041554	012702	000200	MOV	#SSR,R2							
2014	041560	020102		CMP	R1,R2							
2015	041562	001406		BEQ	80\$							
2016	041564	005237	002214'	INC	FATFLG							
2020	041570			ERRHRD	ERRNO,T31WDC,PKTSSR							
	041570	104456										
	041572	000461									TRAP	C\$ERHRD
	041574	045040'									.WORD	305
	041576	011736'									.WORD	T31WDC
2021	041600			80\$:	CKLOOP							
	041600	104406										
2022	041602	004737	010704'	JSR	PC,REWIND						TRAP	C\$CLP1
2023	041606	103407		BCS	230\$							
2024	041610	010001		MOV	R0,R1							
2025	041612	005237	002214'	INC	FATFLG							
2029	041616			ERRHRD	ERRNO,T31RWN,EXPREC							
	041616	104456										
	041620	000462									TRAP	C\$ERHRD
	041622	044504'									.WORD	306
	041624	015364'									.WORD	T31RWN
2030	041626			230\$:	CKLOOP							
	041626	104406										
2031	041630	013701	043020'	MOV	T31BFR+6,R1						TRAP	C\$CLP1

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

SEQ 128

2032	041634	010102			MOV	R1,R2		;SET UP EXPECTED		
2033	041636	052702	000002		BIS	*BIT1,R2		;SET BOT BIT IN EXPECTED		
2034	041642	020102			CMP	R1,R2		;DOES EXP = REC'D		
2035	041644	001406			BEQ	240\$;BR, IF EQUAL (OK)		
2036	041646	005237	002214'		INC	FATFLG		;ERROR COUNT		
2040	041652				ERRHRD	ERRNO,T31BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND		
	041652	104456						TRAP	C\$ERHRD	
	041654	000463						.WORD	307	
	041656	044155'						.WORD	T31BOT	
	041660	015364'						.WORD	EXPREC	
2041	041662			240\$:	CKLOOP			;LOOP IF SELECTED		
	041662	104406						TRAP	C\$CLP1	
2042	041664	012737	041012	043120'	265\$:	MOV	*041012,T31PK3	;NO-OP,CVC=1 COMMAND		
2043	041672	012704	043120'		MOV	*T31PK3,R4		;SET UP R4 WITH PACKET ADDRESS		
2044	041676	010337	043126'		MOV	R3,T31SZ		;SET UP RECORD SIZE IN PACKET		
2045	041702	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND		
2046	041706	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET		
2047	041712	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS		
2048	041716	012702	000200		MOV	*SSR,R2		;SET UP EXPECTED		
2049	041722	020102			CMP	R1,R2		;ARE THEY EQUAL		
2050	041724	001406			BEQ	280\$;BR, IF OK		
2051	041726	005237	002214'		INC	FATFLG		;ERROR COUNT		
2055	041732				ERRHRD	ERRNO,T31RDF,PKTSSR		;TSSR INCORRECT AFTER READ DATA		
	041732	104456						TRAP	C\$ERHRD	
	041734	000464						.WORD	308	
	041736	043353'						.WORD	T31RDF	
	041740	011736'						.WORD	PKTSSR	
2056	041742			280\$:	CKLOOP			;LOOP IF SELECTED		
	041742	104406						TRAP	C\$CLP1	
2057	041744	013701	043020'		MOV	T31BFR+6,R1		;PICK UP XSTO		
2058	041750	010102			MOV	R1,R2		;SET UP EXPECTED		
2059	041752	052702	000002		BIS	*BIT1,R2		;SET BOT BIT IN EXPECTED		
2060	041756	020102			CMP	R1,R2		;DOES EXP = REC'D		
2061	041760	001406			BEQ	285\$;BR, IF EQUAL (OK)		
2062	041762	005237	002214'		INC	FATFLG		;ERROR COUNT		
2066	041766				ERRHRD	ERRNO,T31BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND		
	041766	104456						TRAP	C\$ERHRD	
	041770	000465						.WORD	309	
	041772	044155'						.WORD	T31BOT	
	041774	015364'						.WORD	EXPREC	
2067	041776			285\$:	CKLOOP			;LOOP IF SELECTED		
	041776	104406						TRAP	C\$CLP1	
2068	042000	012737	140001	043120'	MOV	*140001,T31PK3		;READ,ACK,CVC=1 COMMAND		
2069	042006	012704	043120'		MOV	*T31PK3,R4		;SET UP R4 WITH PACKET ADDRESS		
2070	042012	012737	000144	043126'	MOV	*100.,T31SZ		;SET UP RECORD SIZE IN PACKET		
2071	042020	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND		
2072	042024	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET		
2073	042030	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS		
2074	042034	012702	000200		MOV	*SSR,R2		;SET UP EXPECTED		
2075	042040	020102			CMP	R1,R2		;ARE THEY EQUAL		
2076	042042	001406			BEQ	290\$;BR, IF OK		
2077	042044	005237	002214'		INC	FATFLG		;ERROR COUNT		
2081	042050				ERRHRD	ERRNO,T31RDE,PKTSSR		;TSSR INCORRECT AFTER READ DATA		
	042050	104456						TRAP	C\$ERHRD	
	042052	000466						.WORD	310	
	042054	043154'						.WORD	T31RDE	
	042056	011736'						.WORD	PKTSSR	

	042222	000471							.WORD	313
	042224	005046'							.WORD	WRTMSG
	042226	011724'							.WORD	SFIMSG
2134	042230		23\$:	CKLOOP				;LOOP IF SELECTED		
	042230	104406							TRAP	C\$CLP1
2135	042232	004737	010704'	JSR	PC,REWIND			;CALL TAPE REWIND COMMAND		
2136	042236	103407		BCS	30\$;BR, IF NO PROBLEM		
2137	042240	010004		MOV	R0,R4			;SET UP REWIND PACKET ADDRESS		
2138	042242	005237	002214'	INC	FATFLG			;ERROR COUNT		
2142	042246			ERRHRD	ERRNO,T31RWN,PKTSSR			;REWIND NOT ACCEPTED		
	042246	104456							TRAP	C\$ERHRD
	042250	000472							.WORD	314
	042252	044504'							.WORD	T31RWN
	042254	011736'							.WORD	PKTSSR
2143	042256		30\$:	CKLOOP				;LOOP IF SELECTED		
	042256	104406							TRAP	C\$CLP1
2144	042260	013701	043020'	MOV	T31BFR+6,R1			;PICK UP XSTO		
2145	042264	010102		MOV	R1,R2			;SET UP EXPECTED		
2146	042266	052702	000002	BIS	#B11,R2			;SET BOT BIT IN EXPECTED		
2147	042272	020102		CMP	R1,R2			;DOES EXP = REC'D		
2148	042274	001406		BEQ	40\$;BR, IF EQUAL (OK)		
2149	042276	005237	002214'	INC	FATFLG			;ERROR COUNT		
2153	042302			ERRHRD	ERRNO,T31BOT,EXPREC			;TAPE NOT AT BOT AFTER REWIND		
	042302	104456							TRAP	C\$ERHRD
	042304	000473							.WORD	315
	042306	044155'							.WORD	T31BOT
	042310	015364'							.WORD	EXPREC
2154	042312		40\$:	CKLOOP				;LOOP IF SELECTED		
	042312	104406							TRAP	C\$CLP1
2155	042314	013737	003116'	MOV	FREE,T31WB	043122'		;STARTING WRITE BUFFER ADDRESS		
2156	042322	012737	140005	MOV	#140005,T31PK3	043120'	65\$:	;WRITE DATA,CVC=1,ACK COMMAND		
2157	042330	012704	043120'	MOV	#T31PK3,R4			;SET UP R4 WITH PACKET ADDRESS		
2158	042334	012700	000144	MOV	#100.,R0			;SET PATTERN IN CORRECT REGISTER		
2159	042340	004737	017314'	JSR	PC,FILLMEM			;FILL MEMORY WITH RECORD SIZE		
2160	042344	012737	000144	MOV	#100.,T31SZ	043126'		;SET UP RECORD SIZE IN PACKET		
2161	042352	010465	000000	MOV	R4,TSDB(R5)			;ISSUE COMMAND		
2162	042356	004737	016140'	JSR	PC,WAITF			;WAIT FOR SSR TO SET		
2163	042362	016501	000002	MOV	TSSR(R5),R1			;GET TSSR CONTENTS		
2164	042366	012702	000200	MOV	#SSR,R2			;SET UP EXPECTED		
2165	042372	020102		CMP	R1,R2			;ARE THEY EQUAL		
2166	042374	001406		BEQ	80\$;BR, IF OK		
2167	042376	005237	002214'	INC	FATFLG			;ERROR COUNT		
2171	042402			ERRHRD	ERRNO,T31WDC,PKTSSR			;TSSR INCORRECT AFTER WRITE DATA		
	042402	104456							TRAP	C\$ERHRD
	042404	000474							.WORD	316
	042406	045040'							.WORD	T31WDC
	042410	011736'							.WORD	PKTSSR
2172	042412		80\$:	CKLOOP				;LOOP IF SELECTED		
	042412	104406							TRAP	C\$CLP1
2173	042414	004737	010704'	JSR	PC,REWIND			;CALL TAPE REWIND COMMAND		
2174	042420	103407		BCS	230\$;BR, IF NO PROBLEM		
2175	042422	010001		MOV	R0,R1			;SAVE TSSR		
2176	042424	005237	002214'	INC	FATFLG			;ERROR COUNT		
2180	042430			ERRHRD	ERRNO,T31RWN,EXPREC			;REWIND NOT ACCEPTED		
	042430	104456							TRAP	C\$ERHRD
	042432	000475							.WORD	317
	042434	044504'							.WORD	T31RWN

Line	Address	Label	Code	Op	Opnd	Comment	Trap	Word	Exp
2181	042436	015364'	230#:	CKLOOP		;LOOP IF SELECTED		.WORD	EXPREC
	042440	104406					TRAP		C#CLP1
2182	042442	013701	043020'	MOV	T31BFR+6,R1	;PICK UP XSTO			
2183	042446	010102		MOV	R1,R2	;SET UP EXPECTED			
2184	042450	052702	000002	BIS	#BIT1,R2	;SET BOT BIT IN EXPECTED			
2185	042454	020102		CMP	R1,R2	;DOES EXP = REC'D			
2186	042456	001406		BEQ	240#	;BR, IF EQUAL (OK)			
2187	042460	005237	002214'	INC	FATFLG	;ERROR COUNT			
2191	042464			ERRHRD	ERRNO,T31BOT,EXPREC	;TAPE NOT AT BOT AFTER REWIND			
	042464	104456					TRAP		C#ERHRD
	042466	000476						.WORD	316
	042470	044155'						.WORD	T31BOT
	042472	015364'						.WORD	EXPREC
2192	042474		240#:	CKLOOP		;LOOP IF SELECTED			
	042474	104406					TRAP		C#CLP1
2193	042476	012737	041012	043120'	265#:	MOV	#041012,T31PK3		
2194	042504	012704	043120'	MOV	#T31PK3,R4	;INITIALIZE,CVC=1 COMMAND			
2195	042510	010337	043126'	MOV	R3,T31S2	;SET UP R4 WITH PACKET ADDRESS			
2196	042514	010465	000000	MOV	R4,TSDB(R5)	;SET UP RECORD SIZE IN PACKET			
2197	042520	004737	016140'	JSR	PC,WAITF	;ISSUE COMMAND			
2198	042524	016501	000002	MOV	TSSR(R5),R1	;WAIT FOR SSR TO SET			
2199	042530	012702	000200	MOV	#SSR,R2	;GET TSSR CONTENTS			
2200	042534	020102		CMP	R1,R2	;SET UP EXPECTED			
2201	042536	001406		BEQ	280#	;ARE THEY EQUAL			
2202	042540	005237	002214'	INC	FATFLG	;BR, IF OK			
2206	042544			ERRHRD	ERRNO,T31RDF,PKTSSR	;ERROR COUNT			
	042544	104456				;TSSR INCORRECT AFTER READ DATA			
	042546	000477					TRAP		C#ERHRD
	042550	043353'						.WORD	319
	042552	011736'						.WORD	T31RDF
								.WORD	PKTSSR
2207	042554		280#:	CKLOOP		;LOOP IF SELECTED			
	042554	104406					TRAP		C#CLP1
2208	042556	013701	043020'	MOV	T31BFR+6,R1	;PICK UP XSTO			
2209	042562	010102		MOV	R1,R2	;SET UP EXPECTED			
2210	042564	052702	000002	BIS	#BIT1,R2	;SET BOT BIT IN EXPECTED			
2211	042570	020102		CMP	R1,R2	;DOES EXP = REC'D			
2212	042572	001406		BEQ	285#	;BR, IF EQUAL (OK)			
2213	042574	005237	002214'	INC	FATFLG	;ERROR COUNT			
2217	042600			ERRHRD	ERRNO,T31BOT,EXPREC	;TAPE NOT AT BOT AFTER REWIND			
	042600	104456					TRAP		C#ERHRD
	042602	000500						.WORD	320
	042604	044155'						.WORD	T31BOT
	042606	015364'						.WORD	EXPREC
2218	042610		285#:	CKLOOP		;LOOP IF SELECTED			
	042610	104406					TRAP		C#CLP1
2219	042612	012737	140001	043120'	MOV	#140001,T31PK3			
2220	042620	012704	043120'	MOV	#T31PK3,R4	;READ,ACK,CVC=1 COMMAND			
2221	042624	012737	000144	043126'	MOV	#100.,T31S2	;SET UP R4 WITH PACKET ADDRESS		
2222	042632	010465	000000	MOV	R4,TSDB(R5)	;SET UP RECORD SIZE IN PACKET			
2223	042636	004737	016140'	JSR	PC,WAITF	;ISSUE COMMAND			
2224	042642	016501	000002	MOV	TSSR(R5),R1	;WAIT FOR SSR TO SET			
2225	042646	012702	000200	MOV	#SSR,R2	;GET TSSR CONTENTS			
2226	042652	020102		CMP	R1,R2	;SET UP EXPECTED			
2227	042654	001406		BEQ	290#	;ARE THEY EQUAL			
2228	042656	005237	002214'	INC	FATFLG	;BR, IF OK			
2232	042662			ERRHRD	ERRNO,T31RDE,PKTSSR	;ERROR COUNT			
						;TSSR INCORRECT AFTER READ DATA			

TEST 1: HARDWARE TEST 1.8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

SEQ 133

```

2284 043104 000000          .WORD 0
2285 043106 000006          .WORD 6.          ;SIZE OF DATA PACKET
2286
2288 043110                .BLKB 10-<. -TSV2E7>
2290 043120                T31PK3:
2291 043120 100005          .WORD 100005      ;REREAD COMMAND, AND ACK
2292 043122                T31RB:
2293 043122 003116'        T31WB: .WORD FREE   ;ADDRESS OF WRITE BUFFER
2294 043124 000000          .WORD 0
2295 043126 000000          T31SZ: .WORD 0     ;SIZE OF BUFFER (EXTENT)
2296                      .EVEN
2297                      ;
2298                      ;
2299                      ;
2300 043130                T31BF2:
2301 043130          010    T31BS0: .BYTE 10   ;BSELO AREA
2302 043131          200    T31BS1: .BYTE 200  ;BSEL1 AREA
2303 043132 000000          T31S2: .WORD 0     ;SEL 2 AREA
2304 043134 000000          T31S3: .WORD 0     ;DATA AREA
2305                      ;
2306                      ;
2307                      .EVEN
2308                      ;TAPE MOTION PACKET COMMAND VALUES
2309
2310 043136 100205          T31RN: .WORD 100205 ;REREAD DATA (NEXT)
2311 043140 100605          T31WR: .WORD 100605 ;REREAD DATA RETRY
2312 043142 102205          T31CON: .WORD 102205 ;WRITE CONTINUOUS
2313 043144 177777          .WORD 177777 ;END OF DATA
2314
2315                      ;
2316 043146 000000          T31CNT: .WORD 0     ;TAPE TIMER COUNTER STORAGE AREA
2317 043150 000000          T31CNU: .WORD 0     ;TAPE TIMER COUNTER STORAGE AREA
2318 043152 000000          T31DLY: .WORD 0     ;DELAY COUNTER
2319
2320
2321                      ;
2322                      ;LOCAL TEXT MESSAGES FOR TEST
2323                      ;
2324
2325
2326
2327 043154          124      123      123 T31RDE: .ASCIZ 'TSSR Not Correct After READ Command'
2328 043220          124      141      160 T31WNH: .ASCIZ 'Tape Position Incorrect After INITIALIZE Command'
2329 043301          124      141      160 T31WNG: .ASCIZ 'Tape Position Incorrect After NOP Command'
2330 043353          124      123      123 T31RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
2331 043422          122      105      122 T31RRF: .ASCIZ 'REREAD Previous (Space Reverse, Read Forward) Command Failed'
2332 043517          120      117      123 T31SC: .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
2333 043601          122      111      102 T31LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'
2334 043651          124      123      123 T31WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
2335 043726          111      154      154 T31LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
2336 044007          122      105      122 T31SSR: .ASCIZ 'REREAD COMMAND Not Accepted'
2337 044043          124      123      123 T31WDE: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE Command, At BOT'
2338 044155          124      141      160 T31BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
2339 044250          116      117      055 T31TIM: .ASCIZ 'NO-OP ("CLEAN TAPE") AND INITIALIZE'S Erase Tape Not Long Enough'
2340 044350          122      105      122 T31EOT: .ASCIZ 'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
2341 044427          124      123      123 T31TM: .ASCIZ 'TSSR Not Correct After REREAD COMMAND Reject'
2342 044504          122      145      167 T31RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'

```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

SEQ 134

```

2343 044553      122      101      115  T31RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
2344 044626      124      123      123  T31AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
2345 044675      104      162      151  T31OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
2346 044750      124      123      123  T31WDD: .ASCIZ 'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
2347 045040      124      123      123  T31WDC: .ASCIZ 'TSSR Not Correct After REREAD DATA Command'
2348 045113      103      126      103  T31VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
2349 045166      124      123      102  T31BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
2350 045241      127      122      111  T31WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
2351 045330      122      145      141  T31LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XSTO'
2352 045412      122      145      141  T31LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XSTO'
2353 045474      122      145      163  T31PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
2354 045562      122      145      141  T31TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
2355 045650      116      117      055  T31NEF: .ASCIZ 'NO-OP ("CLEAN TAPE") AND INITIALIZE, At First Record, Failed To Set RIB Bit
X
2356 045771      124      123      123  T31SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
2357 046046      124      123      123  T31TSA: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE, Into BOT'
2358 046153      124      123      123  T31WRF: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE Command'
2359 046256      104      141      164  T31DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
2360 046353      116      117      055  TST31ID: .ASCIZ 'NO-OP ("Clean Tape") And INITIALIZE'
2361                                     .EVEN
2362                                     ;+
2363                                     ;
2364                                     ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
2365                                     ;WRITE SUBSYSTEM MEMORY COMMAND
2366                                     ;
2367                                     ;-
2368
2369 046420      T31REST:
2370 046420      SAVREG
2371 046424      012701  042770'  MOV      #T31PACKET,R1      ;SAVE THE REGISTERS
2372 046430      012721  100004  MOV      #100004,(R1)+      ;START OF THE PACKET
2373 046434      012721  043000'  MOV      #T31DATA,(R1)+    ;WRITE SUBSYSTEM MEM. WITH ACK,
2374 046440      005021  CLR      (R1)+              ;ADDRESS OF CHARAISTICS DATA BLOCK
2375 046442      012721  C00012  MOV      #10.,(R1)+        ;EXTENDED ADDRESS
2376 046446      012721  043012'  MOV      #T31BFR,(R1)+     ;SIZE OF DATA BLOCK IN BYTES
2377 046452      005021  CLR      (R1)+              ;ADDRESS OF MESSAGE BUFFER
2378 046454      012721  000024  MOV      #20.,(R1)+        ;LENGTH OF MESSAGE BUFFER
2379 046460      005021  CLR      (R1)+
2380 046462      012711  000000  MOV      #0,(R1)           ;SELECT DRIVE ZERO
2381 046466      012702  000030  MOV      #24.,R2          ;NUMBER OF LOCATIONS TO BE CLEARED
2382 046472      012762  177777  043012'  64$:  MOV      #177777,T31BFR(R2) ;ALL ONES TO MESSAGE BUFFER
2383 046500      005742  TST      -(R2)             ;NEXT LOCATION
2384 046502      022702  000000  CMP      #0,R2            ;AT END OF LOOP YET
2385 046506      001371  BNE      64$              ;KEEP GOING UNTIL DONE
2386 046510      000207  RTS      PC                ;RETURN
2387
2388
2389 046512      T31RT2:
2390 046512      SAVREG
2391 046516      012701  043100'  MOV      #T31PK2,R1        ;SAVE THE REGISTERS
2392 046522      012721  100006  MOV      #100006,(R1)+     ;START OF THE PACKET
2393 046526      012721  043130'  MOV      #T31BF2,(R1)+    ;WRITE SUBSYSTEM MEM. WITH ACK,
2394 046532      005021  CLR      (R1)+              ;ADDRESS OF DATA BLOCK
2395 046534      012721  000006  MOV      #6.,(R1)+         ;EXTENDED ADDRESS
2396 046540      005021  CLR      (R1)+              ;SIZE OF DATA BLOCK IN BYTES
2397 046542      012701  043130'  MOV      #T31BF2,R1        ;POINT TO DATA SEL AREA
2398 046546      005021  CLR      (R1)+
2399 046550      005011  CLR      (R1)

```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

SEQ 135

```

2400 046552 000207          RTS      PC          ;RETURN
2401 046554          T31RT3:          ;SAVE REGISTERS
2402 046554          SAVREG          ;SET UP POINTER ADDRESS
2403 046560 012701 043120'  MOV     #T31PK3,R1  ;COMMAND SPACE
2404 046564 005021          CLR     (R1)+        ;ADDRESS OF DATA BLOCK
2405 046566 005021          CLR     (R1)+        ;EXTENDED ADDRESS
2406 046570 005021          CLR     (R1)+        ;SIZE OF DATA TRANSFER BLOCK
2407 046572 005011          CLR     (R1)         ;RETURN
2408 046574 000207          RTS      PC
2409 046576          ENDTST
                                L10050:
                                TRAP     C$ETST
046576 104401
    
```

.SBTTL TEST 4: Erase And Operation Incomplete

VERIFIES THAT AN ERASE COMMAND ISSUED WHEN THE TAPE IS
 POSITIONED AT BOT OPERATES PROPERLY AND ACTUALLY ERASES TAPE.
 THE FOLLOWING TEST SEQUENCE IS PERFORMED:

1. THE TAPE IS FIRST REWOUND, SEVERAL TEST RECORDS ARE WRITTEN, AND THE TAPE IS REWOUND AGAIN.
2. AN ERASE COMMAND IS ISSUED, WHICH SHOULD ERASE A NUMBER OF THE TEST RECORDS.
3. NORMAL TERMINATION IS VERIFIED AND STATUS IS CHECKED (BOT SHOULD BE 0).
4. A READ REVERSE COMMAND IS ISSUED. IT IS VERIFIED THAT THE COMMAND TERMINATES WITH TAPE STATUS ALERT, THAT THE REVERSE INTO BOT (RIB) STATUS BIT IS SET, AND THAT NO DATA IS TRANSFERRED. THIS DEMONSTRATES THAT NO DATA WAS ENCOUNTERED IN THE AREA ERASED BY THE ERASE COMMAND.

THE TEST CONSISTS OF THE FOLLOWING 3 SUBTESTS

```

2446 046600          BGNTST
                                T4::
2447 046600 012737 006166' 002172'  MOV     #EPRT1,EPRTSW ;PRIMARY ERROR MESSAGE
2452 046606 012700 052460'          MOV     #TST32ID,R0  ;ASCII MESSAGE TO IDENTIFY TEST
2453 046612 004737 016402'          JSR     PC,TSTSETUP  ;DO INITIAL TEST SETUP
2454 046616 012737 000005 002210'  MOV     #5,L00PLNT  ;PERFORM 5 ITERATIONS
2455 046624 005037 051330'          CLR     T32CNT      ;CLEAR TAPE RECORD COUNTER
2456
2457
    
```


TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
TEST 4: ERASE AND OPERATION INCOMPLETE

2502	047002	103411		BCS	26\$;	BR, IF NO PROBLEM		
2503	047004	010004		MOV	R0,R4			;	SET UP REWIND PACKET ADDRESS		
2504	047006	016501	000002	MOV	TSSR(R5),R1			;	GET TSSR CONTENTS		
2505	047012	005237	002214'	INC	FATFLG			;	ERROR COUNT		
2509	047016			ERRHRD	ERRNO,T32RWN,PKTSSR			;	REWIND NOT ACCEPTED		
	047016	104456						TRAP		C\$ERHRD	
	047020	000623						.WORD		403	
	047022	051520'						.WORD		T32RWN	
	047024	011736'						.WORD		PKTSSR	
2510	047026				26\$: CKLOOP			;	LOOP IF SELECTED		
	047026	104406						TRAP		C\$CLP1	
2511	047030	012703	000400	MOV	#256.,R3			;	STARTING RECORD SIZE		
2512	047034	013737	003116'	MOV	FREE,T32WB		051272'	;	STARTING WRITE BUFFER ADDRESS		
2513	047042	012737	140005	MOV	#140005,T32PK3		051270'	;	WRITE DATA,CVC=1,ACK COMMAND		
2514	047050	012704	051270'	MOV	#T32PK3,R4			;	SET UP R4 WITH PACKET ADDRESS		
2515	047054	010337	051276'	MOV	R3,T32SZ			;	SET UP RECORD SIZE IN PACKET		
2516	047060	010465	000000	MOV	R4,TSDB(R5)		27\$:	;	ISSUE COMMAND		
2517	047064	004737	016140'	JSR	PC,WAITF			;	WAIT FOR SSR TO SET		
2518	047070	016501	000002	MOV	TSSR(R5),R1			;	GET TSSR CONTENTS		
2519	047074	012702	000200	MOV	#SSR,R2			;	SET UP EXPECTED		
2520	047100	020102		CMP	R1,R2			;	ARE THEY EQUAL		
2521	047102	001406		BEQ	28\$;	BR, IF OK		
2522	047104	005237	002214'	INC	FATFLG			;	ERROR COUNT		
2526	047110			ERRHRD	ERRNO,T32WDC,PKTSSR			;	TSSR INCORRECT AFTER WRITE DATA		
	047110	104456						TRAP		C\$ERHRD	
	047112	000624						.WORD		404	
	047114	052356'						.WORD		T32WDC	
	047116	011736'						.WORD		PKTSSR	
2527	047120				28\$: CKLOOP			;	LOOP IF SELECTED		
	047120	104406						TRAP		C\$CLP1	
2528	047122	005723		TST	(R3)+			;	BUMP RECORD COUNTER		
2529	047124	020327	001002	CMP	R3,#514.			;	AT MAX SIZE YET		
2530	047130	001351		BNE	27\$;	BR, IF NOT AT END OF LOOP		
2531	047132	004737	010704'	JSR	PC,REWIND			;	CALL TAPE REWIND COMMAND		
2532	047136	103411		BCS	30\$;	BR, IF NO PROBLEM		
2533	047140	016501	000002	MOV	TSSR(R5),R1			;	GET TSSR CONTENTS		
2534	047144	010004		MOV	R0,R4			;	SET UP REWIND PACKET ADDRESS		
2535	047146	005237	002214'	INC	FATFLG			;	ERROR COUNT		
2539	047152			ERRHRD	ERRNO,T32RWN,PKTSSR			;	REWIND NOT ACCEPTED		
	047152	104456						TRAP		C\$ERHRD	
	047154	000625						.WORD		405	
	047156	051520'						.WORD		T32RWN	
	047160	011736'						.WORD		PKTSSR	
2540	047162				30\$: CKLOOP			;	LOOP IF SELECTED		
	047162	104406						TRAP		C\$CLP1	
2541	047164	013701	051170'	MOV	T32BFR+6,R1			;	PICK UP XSTO		
2542	047170	010102		MOV	R1,R2			;	SET UP EXPECTED		
2543	047172	052702	000002	BIS	#BIT1,R2			;	SET BOT BIT IN EXPECTED		
2544	047176	020102		CMP	R1,R2			;	DOES EXP = REC'D		
2545	047200	001406		BEQ	40\$;	BR, IF EQUAL (OK)		
2546	047202	005237	002214'	INC	FATFLG			;	ERROR COUNT		
2550	047206			ERRHRD	ERRNO,T32BOE,EXPREC			;	TAPE AT BOT AFTER ERASE		
	047206	104456						TRAP		C\$ERHRD	
	047210	000626						.WORD		406	
	047212	052206'						.WORD		T32BOE	
	047214	015364'						.WORD		EXPREC	
2551	047216				40\$: CKLOOP			;	LOOP IF SELECTED		

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 4: ERASE AND OPERATION INCOMPLETE

SEQ 138

```

047216 104406
2552 047220 012737 140411 051270'    MOV    #140411,T32PK3    ;ERASE TAPE,CVC=1,ACK COMMAND
2553 047226 012704 051270'    MOV    #T32PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
2554 047232 010465 000000    MOV    R4,TSDB(R5)     ;ISSUE COMMAND
2555 047236 004737 016140'    JSR    PC,WAITF        ;WAIT FOR SSR TO SET
2556 047242 016501 000002    MOV    TSSR(R5),R1    ;GET TSSR CONTENTS
2557 047246 012702 000200    MOV    #SSR,R2        ;SET UP EXPECTED
2558 047252 020102           CMP    R1,R2          ;ARE THEY EQUAL
2559 047254 001406           BEQ    50$            ;BR, IF OK
2560 047256 005237 002214'    INC    FATFLG         ;ERROR COUNT
2564 047262           ERRHRD ERRNO,T32ERA,PKTSSR ;TSSR INCORRECT AFTER ERASE DATA
    047262 104456           TRAP  C$ERHRD
    047264 000627           .WORD 407
    047266 051636'           .WORD T32ERA
    047270 011736'           .WORD PKTSSR
2565 047272           50$: CKLOOP            ;LOOP IF SELECTED
    047272 104406           TRAP  C$CLP1
2566 047274 013701 051170'    MOV    T32BFR+6,R1    ;PICK UP XST0
2567 047300 010102           MOV    R1,R2          ;SET UP EXPECTED
2568 047302 042702 000002    BIC    #BIT1,R2       ;SET BOT BIT IN EXPECTED
2569 047306 020102           CMP    R1,R2          ;DOES EXP = REC'D
2570 047310 001406           BEQ    55$            ;BR, IF EQUAL (OK)
2571 047312 005237 002214'    INC    FATFLG         ;ERROR COUNT
2575 047316           ERRHRD ERRNO,T32BOE,EXPREC ;TAPE NOT AT BOT AFTER REWIND
    047316 104456           TRAP  C$ERHRD
    047320 000630           .WORD 408
    047322 052206'           .WORD T32BOE
    047324 015364'           .WORD EXPREC
2576 047326           55$: CKLOOP            ;LOOP IF SELECTED
    047326 104406           TRAP  C$CLP1
2577 047330 013737 003116' 051272'    MOV    FREE,T32RB     ;ADDRESS OF BUFFER
2578 047336 012737 140401 051270'    MOV    #140401,T32PK3 ;READ REVERSE,ACK,CVC=1 COMMAND
2579 047344 012737 000400 051276'    MOV    #256,T32SZ     ;SET UP THE SIZE OF RECORD
2580 047352 012704 051270'    MOV    #T32PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
2581 047356 010465 000000    MOV    R4,TSDB(R5)   ;ISSUE COMMAND
2582 047362 004737 016140'    JSR    PC,WAITF      ;WAIT FOR SSR TO SET
2583 047366 016501 000002    MOV    TSSR(R5),R1  ;GET TSSR CONTENTS
2584 047372 012702 100204    MOV    #SSR!SC!BIT2,R2 ;SET UP EXPECTED TAPE STATUS ALERT
2585 047376 020102           CMP    R1,R2          ;ARE THEY EQUAL
2586 047400 001406           BEQ    180$          ;BR, IF OK
2587 047402 005237 002214'    INC    FATFLG         ;ERROR COUNT
2591 047406           ERRHRD ERRNO,T32TSA,PKTSSR ;TSSR INCORRECT AFTER READ DATA
    047406 104456           TRAP  C$ERHRD
    047410 000631           .WORD 409
    047412 052131'           .WORD T32TSA
    047414 011736'           .WORD PKTSSR
2592 047416           180$: CKLOOP           ;LOOP IF SELECTED
    047416 104406           TRAP  C$CLP1
2593 047420 013701 051176'    MOV    T32BFR+14,R1  ;GET XST3 STATUS WORD
2594 047424 010102           MOV    R1,R2          ;SET UP EXPECTED
2595 047426 052702 000001    BIS    #BIT0,R2       ;SET THE RIB BIT
2596 047432 020102           CMP    R1,R2          ;ARE THEY EQUAL
2597 047434 001406           BEQ    190$          ;BR, IF EQUAL (GOOD)
2598 047436 005237 002214'    INC    FATFLG         ;ERROR COUNT
2602 047442           ERRHRD ERRNO,T32RIB,EXPREC ;RIB SHOULD BE SET
    047442 104456           TRAP  C$ERHRD
    047444 000632           .WORD 410
  
```


047524	000633							.WORD	411
047526	003642'							.WORD	SFIERR
047530	011724'							.WORD	SFIMSG
2656	047532	013737	002174'	051160'	20\$:	MOV	UNITN,T32DSW		;SET UP UNIT NUMBER IN PACKET
2657	047540	012704	051140'			MOV	#T32PACKET,R4		;SUBROUTINE NEEDS PACKET ADDRESS
2658	047544	004737	010552'			JSR	PC,WRTCHR		;ISSUE WRITE CHARACTERISTICS
2659	047550	103407				BCS	23\$;BR, IF COMMAND ISSUED OK
2660	047552	005237	002214'			INC	FATFLG		;ERROR COUNT
2664	047556	^10C01				MOV	RO,R1		;SAVE CONTENTS OF TSSR
2665	047560					ERRHRD	ERRNO,WRTMSG,SFIMSG		;WRITE CHARACTERISTICSC FAILED
	047560	104456						TRAP	C\$ERHRD
	047562	000634						.WORD	412
	047564	005046'						.WORD	WRTMSG
	047566	011724'						.WORD	SFIMSG
2666	047570				23\$:	CKLOOP			;LOOP IF SELECTED
	047570	104406						TRAP	C\$CLP1
2667	047572	004737	010704'			JSR	PC,REWIND		;CALL TAPE REWIND COMMAND
2668	047576	103407				BCS	30\$;BR, IF NO PROBLEM
2669	047600	010004				MOV	RO,R4		;SET UP REWIND PACKET ADDRESS
2670	047602	005237	002214'			INC	FATFLG		;ERROR COUNT
2674	047606					ERRHRD	ERRNO,T32RWN,PKTSSR		;REWIND NOT ACCEPTED
	047606	104456						TRAP	C\$ERHRD
	047610	000635						.WORD	413
	047612	051520'						.WORD	T32RWN
	047614	011736'						.WORD	PKTSSR
2675	047616				30\$:	CKLOOP			;LOOP IF SELECTED
	047616	104406						TRAP	C\$CLP1
2676	047620	013701	051170'			MOV	T32BFR+6,R1		;PICK UP XSTO
2677	047624	010102				MOV	R1,R2		;SET UP EXPECTED
2678	047626	052702	000002			BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED
2679	047632	020102				CMP	R1,R2		;DOES EXP = REC'D
2680	047634	001406				BEQ	40\$;BR, IF EQUAL (OK)
2681	047636	005237	002214'			INC	FATFLG		;ERROR COUNT
2685	047642					ERRHRD	ERRNO,T32BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND
	047642	104456						TRAP	C\$ERHRD
	047644	000636						.WORD	414
	047646	051336'						.WORD	T32BOT
	047650	015364'						.WORD	EXPREC
2686	047652				40\$:	CKLOOP			;LOOP IF SELECTED
	047652	104406						TRAP	C\$CLP1
2687	047654	012703	000144			MOV	#100.,R3		;STARTING RECORD SIZE
2688	047660	010300				MOV	R3,RO		;SET UP MEMORY FILL
2689	047662	004737	017314'			JSR	PC,FILLMEM		;CALL MEMORY FILLER
2690	047666	013737	003116'	051272'		MOV	FREE,T32WB		;STARTING WRITE BUFFER ADDRESS
2691	047674	012737	140005	051270'	65\$:	MOV	#140005,T32PK3		;WRITE DATA,CVC=1,ACK COMMAND
2692	047702	012704	051270'			MOV	#T32PK3,R4		;SET UP R4 WITH PACKET ADDRESS
2693	047706	010300				MOV	R3,RO		;SET PATTERN IN CORRECT REGISTER
2694	047710	004737	017314'			JSR	PC,FILLMEM		;FILL MEMORY WITH RECORD SIZE
2695	047714	010337	051276'			MOV	R3,T32SZ		;SET UP RECORD SIZE IN PACKET
2696	047720	010465	000000			MOV	R4,T32DB(R5)		;ISSUE COMMAND
2697	047724	004737	016140'			JSR	PC,WAITF		;WAIT FOR SSR TO SET
2698	047730	016501	000002			MOV	TSSR(R5),R1		;GET TSSR CONTENTS
2699	047734	012702	000200			MOV	#SSR,R2		;SET UP EXPECTED
2700	047740	020102				CMP	R1,R2		;ARE THEY EQUAL
2701	047742	001406				BEQ	80\$;BR, IF OK
2702	047744	005237	002214'			INC	FATFLG		;ERROR COUNT
2706	047750					ERRHRU	ERRNO,T32WDC,PKTSSR		;TSSR INCORRECT AFTER WRITE DATA

	047750	104456							TRAP	C\$ERHRD
	047752	000637							.WORD	415
	047754	052356'							.WORD	T32WDC
	047756	011736'							.WORD	PKTSSR
2707	047760			80\$:	CKLOOP					;LOOP IF SELECTED
	047760	104406							TRAP	C\$CLP1
2708	047762	005723			TST	(R3)+				;BUMP RECORD SIZE COUNTER
2709	047764	020327	000156		CMP	R3,#110.				;AT 160 SIZE YET
2710	047770	001341			BNE	65)				;BR, IF MORE RECORDS TO WRITE
2711	047772	004737	010704'		JSR	PC,REWIND				;CALL TAPE REWIND COMMAND
2712	047776	103407			BCS	230\$;BR, IF NO PROBLEM
2713	050070	010001			MOV	R0,R1				;SAVE TSSR
2714	050002	005237	002214'		INC	FATFLG				;ERROR COUNT
2718	050006				ERRHRD	ERRNO,T32RWN,EXPREC				;REWIND NOT ACCEPTED
	050006	104456							TRAP	C\$ERHRD
	050010	000640							.WORD	416
	050012	051520'							.WORD	T32RWN
	050014	015364'							.WORD	EXPREC
2719	050016				230\$:	CKLOOP				;LOOP IF SELECTED
	050016	104406							TRAP	C\$CLP1
2720	050020	013701	051170'		MOV	T32BFR+6,R1				;PICK UP XSTO
2721	050024	010102			MOV	R1,R2				;SET UP EXPECTED
2722	050026	052702	000002		BIS	#BIT1,R2				;SET BOT BIT IN EXPECTED
2723	050032	020102			CMP	R1,R2				;DOES EXP = REC'D
2724	050034	001406			BEQ	240\$;BR, IF EQUAL (OK)
2725	050036	005237	002214'		INC	FATFLG				;ERROR COUNT
2729	050042				ERRHRD	ERRNO,T32BOT,EXPREC				;TAPE NOT AT BOT AFTER REWIND
	050042	104456							TRAP	C\$ERHRD
	050044	000641							.WORD	417
	050046	051336'							.WORD	T32BOT
	050050	015364'							.WORD	EXPREC
2730	050052				240\$:	CKLOOP				;LOOP IF SELECTED
	050052	104406							TRAP	C\$CLP1
2731	050054	012703	000001		MOV	#1,R3				;SET UP FOR SPACE COMMAND
2732	050060	004737	010356'		JSR	PC,SPACE				;ISSUE SPACE COMMAND 1 FORWARD
2733	050064	012737	140411	051270'	265\$:	MOV	#140411,T32PK3			;ERASE DATA,ACK COMMAND
2734	050072	012704	051270'		MOV	#T32PK3,R4				;SET UP R4 WITH PACKET ADDRESS
2735	050076	010465	000000		MOV	R4,TSDB(R5)				;ISSUE COMMAND
2736	050102	004737	016140'		JSR	PC,WAITF				;WAIT FOR SSR TO SET
2737	050106	016501	000002		MOV	TSSR(R5),R1				;GET TSSR CONTENTS
2738	050112	012702	000200		MOV	#SSR,R2				;SET UP EXPECTED
2739	050116	020102			CMP	R1,R2				;ARE THEY EQUAL
2740	050120	001406			BEQ	280\$;BR, IF OK
2741	050122	005237	002214'		INC	FATFLG				;ERROR COUNT
2745	050126				ERRHRD	ERRNO,T32ERA,PKTSSR				;TSSR INCORRECT AFTER READ DATA
	050126	104456							TRAP	C\$ERHRD
	050130	000642							.WORD	418
	050132	051636'							.WORD	T32ERA
	050134	011736'							.WORD	PKTSSR
2746	050136				280\$:	CKLOOP				;LOOP IF SELECTED
	050136	104406							TRAP	C\$CLP1
2747	050140	013737	003116'	051272'	MOV	FREE,T32RB				;ADDRESS OF BUFFER
2748	050146	012737	140401	051270'	MOV	#140401,T32PK3				;READ REVERSE,ACK,CVC-1 COMMAND
2749	050154	012737	000144	051276'	MOV	#100.,T32SZ				;SET UP THE SIZE OF RECORD
2750	050162	012704	051270'		MOV	#T32PK3,R4				;SET UP R4 WITH PACKET ADDRESS
2751	050166	010465	000000		MOV	R4,TSDB(R5)				;ISSUE COMMAND
2752	050172	004737	016140'		JSR	PC,WAITF				;WAIT FOR SSR TO SET

```

2753 050176 016501 000002          MOV   TSSR(R5),R1          ;GET TSSR CONTENTS
2754 050202 012702 000200          MOV   *SSR,R2            ;SET UP EXPECTED TAPE STATUS ALERT
2755 050206 020102                   CMP   R1,R2              ;ARE THEY EQUAL
2756 050210 001406                   BEQ   290$                ;BR, IF OK
2757 050212 005237 002214'         INC   FATFLG              ;ERROR COUNT
2761 050216                       ERRHRD ERRNO,T32TSA,PKTSSR ;TSSR INCORRECT AFTER READ DATA
                                 TRAP   C$ERHRD
                                 .WORD  419
                                 .WORD  T32TSA
                                 .WORD  PKTSSR
        050216 104456
        050220 000643
        050222 052131'
        050224 011736'
2762 050226                       290$: CKLOOP              ;LOOP IF SELECTED
                                 TRAP   C$CLP1
        050226 104406
2763 050230 017701 132662          MOV   *FREE,R1           ;GET DATA READ
2764 050234 012702 000144          MOV   *100.,R2           ;SHOULD BE 100
2765 050240 020102                   CMP   R1,R2              ;CHECK 'EM OUT
2766 050242 001406                   BEQ   300$                ;BR, IF OK
2767 050244 005237 002214'         INC   FATFLG              ;ERROR COUNT
2771 050250                       ERRHRD ERRNO,T32ECF,EXPREC ;ERASE COMMAND DIDN'T WORK
                                 TRAP   C$ERHRD
                                 .WORD  420
                                 .WORD  T32ECF
                                 .WORD  EXPREC
        050250 104456
        050252 000644
        050254 052275'
        050256 015364'
2772 050260                       300$: CKLOOP              ;LOOP IF SELECTED
                                 TRAP   C$CLP1
        050260 104406
2773 050262                       330$:
2774 050262                   ENDSUB                  ;>>>>>>>>>>>>>>> END SUBTEST >>>>>>>>>>>>>>>
                                 L10055:
        050262 104403
2775 050264 023727 002214' 000017   CMP   FATFLG,*15,        ;IS ERROR COUNT AT 25
2776 050272 103402                   BLO  999$                ;BR, IF LESS THAN 25
2777 050274 004737 017074'         JSR   PC,CKDROP          ;TRY TO DROP THE UNIT
2778 050300                       999$:
2779
2780
2781
2782
2783
2784
2785
2786
2787
2788
2789
2790
2791
2792
2793
2794
2795
2796
2797
2798
2799
2800
2801
2802
2803

```

;+
;TEST 4, SUBTEST 3
;
; VERIFIES THAT AN ERASE COMMAND ENCOUNTERING THE EOT MARKER, OR
; EXECUTED BEYOND THE EOT MARKER, CAUSES TAPE STATUS ALERT
; TERMINATION WITH THE EOT STATUS BIT SET. ALSO VERIFIES THAT THE
; OTHER TAPE MOTION COMMANDS EXECUTED WHEN THE TAPE IS BLANK
; RESULT IN UNRECOVERABLE ERROR TERMINATION AND OPERATION
; INCOMPLETE STATUS. THE FOLLOWING TEST SEQUENCE IS EXECUTED:
;
; 1. THE TAPE IS REWOUND.
;
; 2. ERASE COMMANDS ARE REPEATEDLY ISSUED UNTIL EOT STATUS
; IS SEEN. AN ERROR IS REPORTED IF ANY TERMINATION OTHER
; THAN NORMAL (WITH EOT=0) OR TAPE STATUS ALERT (WITH
; EOT=1) IS ENCOUNTERED. IF THE CONTROLLER OR TRANSPORT
; DOES NOT DETECT THE EOT, THE TRANSPORT WILL FAULT.
; THIS IS REPORTED AS A FATAL ERROR AND THE TEST IS
; ABORTED.
;
; 3. AN ADDITIONAL ERASE COMMAND IS ISSUED AND IT IS
; VERIFIED THAT TAPE STATUS ALERT TERMINATION RESULTS,
; WITH EOT=1.

B12

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST A: ERASE AND OPERATION INCOMPLETE

SEQ 144

2848	050462	016501	000002			MOV	TSSR(R5),R1	;GET TSSR CONTENTS		
2849	050466	010004				MOV	R0,R4	;GET PACKET ADDRESS		
2850	050470	005237	002214'			INC	FATFLG	;ERROR COUNT		
2854	050474					ERRHRD	ERRNO,T32RWN,PKTSSR	;REWIND NOT ACCEPTED		
	050474	104456							TRAP	C1ERHRD
	050476	000647							.WORD	423
	050500	051520'							.WORD	T32RWN
	050502	011736'							.WORD	PKTSSR
2855	050504			301:		CKLOOP		;LOOP IF SELECTED		
	050504	104406							TRAP	C1CLP1
2856	050506	013701	051170'			MOV	T32BFR+6,R1	;PICK UP XSTO		
2857	050512	010102				MOV	R1,R2	;SET UP EXPECTED		
2858	050514	052702	000002			BIS	#BIT1,R2	;SET BOT BIT IN EXPECTED		
2859	050520	020102				CMP	R1,R2	;DOES EXP = REC'D		
2860	050522	001406				BEQ	401	;BR, IF EQUAL (OK)		
2861	050524	005237	002214'			INC	FATFLG	;ERROR COUNT		
2865	050530					ERRHRD	ERRNO,T32BOT,EXPREC	;TAPE NOT AT BOT AFTER REWIND		
	050530	104456							TRAP	C1ERHRD
	050532	000650							.WORD	424
	050534	051336'							.WORD	T32BOT
	050536	015364'							.WORD	EXPREC
2866	050540			401:		CKLOOP		;LOOP IF SELECTED		
	050540	104406							TRAP	C1CLP1
2867	050542	012737	140411 051270'	651:		MOV	#140411,T32PK3	;ERASE DATA,CVC=1,ACK COMMAND		
2868	050550	012704	051270'			MOV	#T32PK3,R4	;SET UP R4 WITH PACKET ADDRESS		
2869	050554	010337	051276'			MOV	R3,T32SZ	;SET UP RECORD SIZE IN PACKET		
2870	050560	010465	000000			MOV	R4,TSD08(R5)	;ISSUE COMMAND		
2871	050564	001737	016140'			JSR	PC,WAIF	;WAIT FOR SSR TO SET		
2872	050570	016501	000002			MOV	TSSR(R5),R1	;GET TSSR CONTENTS		
2873	050574	012702	000200			MOV	#SSR,R2	;SET UP EXPECTED		
2874	050600	020102				CMP	R1,R2	;ARE THEY EQUAL		
2875	050602	001757				BEQ	651	;BR, IF OK		
2876	050604	032701	000004			BIT	#BIT2,R1	;CHECK FOR TAP STATUS ALERT		
2877	050610	001006				BNE	801	;BR, IF TAP STATUS ALERT SET		
2878	050612	005237	002214'			INC	FATFLG	;ERROR COUNT		
2882	050616					ERRHRD	ERRNO,T32WDC,PKTSSR	;TSSR INCORREC AFTER WRITE DATA		
	050616	104456							TRAP	C1ERHRD
	050620	000651							.WORD	425
	050622	052356'							.WORD	T32WDC
	050624	011736'							.WORD	PKTSSR
2883	050626			801:		CKLOOP		;LOOP IF SELECTED		
	050626	104406							TRAP	C1CLP1
2884	050630	013701	051170'			MOV	T32BFR+6,R1	;PICK UP XSTO		
2885	050634	010102				MOV	R1,R2	;SET UP EXPECTED		
2886	050636	052702	000001			BIS	#BIT0,R2	;SET EOT BIT IN EXPECTED		
2887	050642	020102				CMP	R1,R2	;DOES EXP = REC'D		
2888	050644	001406				BEQ	2401	;BR, IF EQUAL (OK)		
2889	050646	005237	002214'			INC	FATFLG	;ERROR COUNT		
2893	050652					ERRHRD	ERRNO,T32EOT,EXPREC	;TAPE NOT AT EOT AFTER ERASE COMMANDS		
	050652	104456							TRAP	C1ERHRD
	050654	000652							.WORD	426
	050656	051431'							.WORD	T32EOT
	050660	015364'							.WORD	EXPREC
2894	050662			2401:		CKLOOP		;LOOP IF SELECTED		
	050662	104406							TRAP	C1CLP1
2895	050664	012703	051300'			MOV	#T32CMD,R3	;STARTING RECORD SIZE		
2896	050670	013737	003116' 051270'			MOV	FREE,T32RB	;STARTING READ BUFFER ADDRESS		


```

2897 050676 011337 051270' 2654: MOV (R3),T32PK3 ;READ DATA,ACK COMMAND
2898 050702 012734 051270' MOV #T32PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
2899 050706 012700 177777 MOV #177777,R0 ;SET PATTERN IN CORRECT REGISTER
2900 050712 004737 017314' JSR PC,FILL MEM ;FILL MEMORY WITH ALL ONES
2901 050716 012737 060144 051276' MOV #100.,T32SZ ;SET UP RECORD SIZE IN PACKET
2902 050724 010465 000000 MOV R4,TSD8(R5) ;ISSUE COMMAND
2903 050730 012737 000062 051334' MOV #50.,T32DLY ;SET UP DELAY COUNTER
2904 050736 004737 016140' 2704: JSR PC,WAITF ;WAIT FOR SSR TO SET
2905 050742 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
2906 050746 012702 100214 MOV #SSR!SCIBIT2!BIT3,R2 ;SET UP EXPECTED
2907 050752 020102 CMP R1,R2 ;ARE THEY EQUAL
2908 050754 001425 BEQ 2804 ;BR, IF OK
2909 050756 DELAY 250 ;DELAY FOR SSR TO BE SET
      050756 012727 000250 MOV #250,(PC)+
      050762 000000 .WORD 0
      050764 013727 002116' MOV L#DLY,(PC)+
      050770 000000 .WORD 0
      050772 005367 177772 DEC -6(PC)
      050776 001375 BNE -.4
      051000 005367 177756 DEC -22(PC)
      051004 001367 BNE -.20
2910 051006 005337 051334' DEC T32DLY ;COUNT DELAY ROUTINE DOWN
2911 051012 001351 BNE 2704 ;BR, IF DELAY HAS NOT ENDED
2912 051014 005237 002214' INC FATFLG ;ERROR COUNT
2916 051020 ERRHRD ERRNO,T32ECF,PKTSSR ;TSSR INCORRECT AFTER READ DATA
      051020 104456 TRAP C#ERHRD
      051022 000653 .WORD 427
      051024 052275' .WORD T32ECF
      051026 011736' .WORD PKTSSR
2917 051030 2804: CKLOOP ;LOOP IF SELECTED
      051030 104406 TRAP C#CLP1
2918 051032 013701 051176' MOV T328FR+14,R1 ;PICK UP XST3
2919 051036 010102 MOV R1,R2 ;SET UP EXPECTED
2920 051040 052702 000100 BIS #BIT6,R2 ;SET OPI BIT IN EXPECTED
2921 051044 020102 CMP R1,R2 ;IS OPI BIT SET
2922 051046 001406 BEQ 2904 ;BR, IF BIT IS SET
2923 051050 005237 002214' INC FATFLG ;ERROR COUNT
2927 051054 ERRHRD ERRNO,T32OPI,EXPREC ;OPI BIT NOT SET
      051054 104456 TRAP C#ERHRD
      051056 000654 .WORD 428
      051060 052424' .WORD T32OPI
      051062 015364' .WORD EXPREC
2928 051064 2904: CKLOOP ;LOOP IF SELECTED
      051064 104406 TRAP C#CLP1
2929 051066 005723 TST (R3)+ ;BUMP COMMAND POINTER
2930 051070 021327 177777 CMP (R3),#177777 ;AT END OF TABLE YET
2931 051074 001300 BNE 2654 ;BR, KEEP TRYING COMMANDS
2932 051076 ENDSUB ;????????????????? END SUBTEST ??????????????????
      051076 104403 L10056:
2933 051100 023727 002214' 000017 CMP FATFLG,#15, TRAP C#ESUB
2934 051106 103402 BLO 9994 ;IS ERROR COUNT AT 25
2935 051110 004737 017074' JSR PC,CKDROP ;BR, IF LESS THAN 25
2936 051114 9994: ;TRY TO DROP THE UNIT
2937
2938
2939

```

TEST 1: HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 4: ERASE AND OPERATION INCOMPLETE

SEQ 146

```

2940
2941 051114 004737 016350'      JSR    PC,TSTLOOP      ;DO WE NEED TO ITERATE TEST
2942 051120 103002                BCC    1634            ;BR, IF NO LOOP REQUIRED
2943 051122 000137 046630'      JMP    T32LOOP        ;EXECUTE AGAIN
2944 051126                1634:  EXIT    TST      ;ALL DONE THIS TEST
      051126 104432                TRAP   C$EXIT
      051130 001534                .WORD  L10053-
2945
2946
2947      ; LOCAL STORAGE FOR THIS TEST
2948      ;
2950 051132                .BLKB  10-<.-TSV2&7>
2952 051140      T32PACKET:      .WORD  100004      ;COMMAND PACKET FOR TEST
2953 051140 100004                .WORD  T32DATA    ;WRITE CHARACTERISTICS COMMAND, WITH , ACK
2954 051142 051150'                .WORD  0           ;ADDRESS OF CHARACTERISTICS BLOCK
2955 051144 000000                .WORD  0
2956 051146 000012                .WORD  10.        ;STARTING VALUE OF BLOCK SIZE
2957 051150      T32DATA:      .WORD  T32BFR     ;CHARACTERISTICS DATA BLOCK
2958 051150 051162'                .WORD  0           ;ADDRESS OF MESSAGE BUFFER
2959 051152 000000                .WORD  0
2960 051154 000024                .WORD  20.        ;LENGTH OF MESSAGE BUFFER
2961 051156 000000                .WORD  0
2962 051160 000000      T32DSW: .WORD  0     ;SELECT DRIVE 0
2963 051162      T32BFR: .BLKW  25.  ;MESSAGE BUFFER
2964
2965      ; WRITE SUBSYSTEM MEMORY COMMAND PACKET
2966      ;
2968 051244                .BLKB  10-<.-TSV2&7>
2970 051250      T32PK2:      .WORD  100006      ;WRITE SUB SYS MEM COMMAND, AND ACK
2971 051250 100006                .WORD  0           ;ADDRESS OF SELECT BLOCK DATA
2972 051252 000000                .WORD  0
2973 051254 000000                .WORD  0
2974 051256 000006                .WORD  6.         ;SIZE OF DATA PACKET
2975
2977 051260                .BLKB  10-<.-TSV2&7>
2979 051270      T32PK3:      .WORD  100005      ;REREAD COMMAND, AND ACK
2980 051270 100005                .WORD  0           ;ADDRESS OF WRITE BUFFER
2981 051272                .WORD  0
2982 051272 003116'      T32WB: .WORD  0     ;SIZE OF BUFFER (EXTENT)
2983 051274 000000                .WORD  0
2984 051276 000000      T32SZ: .WORD  0
2985
2986      .EVEN
2987
2988
2989
2990
2991      .EVEN
2992      ; TAPE MOTION PACKET COMMAND VALUES
2993
2994 051300      T32CMD:      .WORD  140410      ;SPACE RECORDS REVERSE
2995 051300 140410                .WORD  141410      ;SKIP TAPE MARKS REVERSE
2996 051302 141410                .WORD  140401      ;READ REVERSE
2997 051304 140401                .WORD  141001      ;REREAD PREVIOUS (OPP=0)
2998 051306 141001                .WORD  161401      ;REREAD NEXT (OPP=1)
2999 051310 161401                .WORD  161001      ;REREAD PREVIOUS (OPP=1)
3000 051312 161001                .WORD  161001

```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 4: ERASE AND OPERATION INCOMPLETE

SEQ 147

```

3001 051314 141401          .WORD 141401          ;REREAD NEXT (OPP=0)
3002 051316 140001          .WORD 140001          ;READ NEXT
3003 051320 141410          .WORD 141410          ;SKIP TAPE MARKS REVERSE
3004 051322 141010          .WORD 141010          ;SKIP RECORDS FORWARD
3005 051324 141005          .WORD 141005          ;WRITE DATA RETRY
3006 051326 177777          .WORD 177777          ;END OF DATA
3007
3008
3009 051330 000000          T32CNT: .WORD 0        ;TAPE TIMER COUNTER STORAGE AREA
3010 051332 000000          T32CNU: .WORD 0        ;TAPE TIMER COUNTER STORAGE AREA
3011 051334 000000          T32DLY: .WORD 0        ;DELAY COUNTER
3012
3013
3014
3015          ;*
3016          ;LOCAL TEXT MESSAGES FOR TEST
3017          ;-
3018
3019 051336      124      141      160  T32BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
3020 051431      124      141      160  T32EOT: .ASCIZ 'Tape Status Alert During Erase To EOT, But EOT Not Set'
3021 051520      122      145      167  T32RWN: .ASCIZ 'Rewind (POSITI(N) Command Not Accepted'
3022 051567      124      123      123  T32AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
3023 051636      124      123      123  T32ERA: .ASCIZ 'TSSR Not Correct After ERASE Command'
3024 051703      124      123      102  T32BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
3025 051756      122      105      101  T32RIB: .ASCIZ 'READ REVERSE, After ERASE From BOT, Failed To Set RIB In XST3'
3026 052054      124      123      123  T32SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
3027 052131      124      123      123  T32TSA: .ASCIZ 'TSSR Not Correct After READ REVERSE Into BOT'
3028 052206      102      117      124  T32BOE: .ASCIZ 'BOT (XST0) Still Set After Erase From Tape's BOT Marker'
3029 052275      105      122      101  T32ECF: .ASCIZ 'ERASE Failed To Clear Tape (Erase) Tape Properly'
3030
3031 052356      124      123      123  T32WDC: .ASCIZ 'TSSR Not Correct After ERASE Command'
3032 052423      117      120      111  T32OPI: .ASCIZ 'OPI Bit (XST3) Failed To Set'
3033 052460      105      152      141  T32ID:  .ASCIZ 'Erase And Operation Incomplete'
3034
3035          .EVEN
3036
3037          ;*
3038          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
3039          ;WRITE SUBSYSTEM MEMORY COMMAND
3040          ;-
3041
3042 052520          T32REST:
3043 052520          SAVREG
3044 052524 012701 051140'      MOV      #T32PACKET,R1          ;SAVE THE REGISTERS
3045 052530 012721 100004'      MOV      #100004,(R1)+         ;START OF THE PACKET
3046 052534 012721 051150'      MOV      #T32DATA,(R1)+       ;WRITE SUBSYSTEM MEM. WITH ACK,
3047 052540 005021          CLR      (R1)+                 ;ADDRESS OF CHARAISTICS DATA BLOCK
3048 052542 012721 000012'      MOV      #10.,(R1)+          ;EXTENDED ADDRESS
3049 052546 012721 051162'      MOV      #T32BFR,(R1)+       ;SIZE OF DATA BLOCK IN BYTES
3050 052552 005021          CLR      (R1)+                 ;ADDRESS OF MESSAGE BUFFER
3051 052554 012721 000024'      MOV      #20.,(R1)+          ;LENGTH OF MESSAGE BUFFER
3052 052560 005021          CLR      (R1)+
3053 052562 012711 000000'      MOV      #0,(R1)             ;SELECT DRIVE ZERO
3054 052566 012702 000030'      MOV      #24.,R2             ;NUMBER OF LOCATIONS TO BE CLEARED
3055 052572 012762 177777 051162' 64: MOV      #177777,T32BFR(R2)    ;ALL ONES TO MESSAGE BUFFER
3056 052600 005742          TST      -(R2)                 ;NEXT LOCATION
3057 052602 022702 000000'      CMP      #0,R2               ;AT END OF LOOP YET

```

```

3058 052606 001371          BNE      64$          ;KEEP GOING UNTIL DONE
3059 052610 000207          RTS      PC          ;RETURN
3060
3061
3062 052612          T32RT2:
3063 052612          SAVREG          ;SAVE THE REGISTERS
3064 052616 012701 051250'  MOV     @T32PK2,R1    ;START OF THE PACKET
3065 052622 012721 100006  MOV     @100006,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK,
3066 052626 005021          CLR     (R1)+        ;ADDRESS OF DATA BLOCK
3067 052630 005021          CLR     (R1)+        ;EXTENDED ADDRESS
3068 052632 012721 000006  MOV     @6.,(R1)+    ;SIZE OF DATA BLOCK IN BYTES
3069 052636 005021          CLR     (R1)+
3070 052640 000207          RTS      PC          ;RETURN
3071 052642          T32RT3:
3072 052642          SAVREG          ;SAVE REGISTERS
3073 052646 012701 051270'  MOV     @T32PK3,R1    ;SET UP POINTER ADDRESS
3074 052652 005021          CLR     (R1)+        ;COMMAND SPACE
3075 052654 005021          CLR     (R1)+        ;ADDRESS OF DATA BLOCK
3076 052656 005021          CLR     (R1)+        ;EXTENDED ADDRESS
3077 052660 005011          CLR     (R1)        ;SIZE OF DATA TRANSFER BLOCK
3078 052662 000207          RTS      PC          ;RETURN
3079 052664          ENDTST
          L10053:
          TRAP      C$ETST
          052664 104401
    
```

3080
 3081
 3082
 3083
 3084
 3085
 3086
 3087
 3088
 3089
 3090
 3091
 3092
 3093
 3094
 3095
 3096
 3097
 3098
 3099
 3100
 3101
 3102
 3103
 3104
 3105
 3106
 3107
 3108
 3109
 3110
 3111
 3112

.SBTTL TEST 5: DATA PARITY TEST

```

;
;
;
;
;
;
;TEST 5 -- Data Parity Test
;
;This test verifies that the data parity circuitry in both the controller and the
;transport is operating properly by forcing data records with wrong parity to be
;written onto tape and checking the results obtained when the data is read. The
;following test sequence is performed:
;
; 1. A Write Characteristics command is issued and the resulting status is
;    examined to determine the states of the Extended Features and Buffering
;    Enable switches on the controller module. If buffering is disabled, no
;    further actions need be taken in this step and the program proceeds to
;    the next step. If buffering is enabled, it is disabled via the Buffer
;    Control field in the extended characteristics data word supplied by a
;    Write Characteristics command. (The module must be in Extended mode,
;    so if it is not already, a Write Subsystem Memory command is issued to
;    change the logical sense of the Extended Features switch.)
;
; 2. The Write Subsystem Memory command is used to set the Force Wrong
;    Parity control flip-flop.
;
; 3. The tape is rewound.
;
; 4. A Write Data command is issued to write a data record containing all
;    0's. It is verified that this command results in Recoverable Error
    
```


TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 5: DATA PARITY TEST

SEQ 150

3170	052760	004737	055656'		JSR	PC,T33RT3		;SET UP OTHER COMMAND PACKET	
3171	052764	012737	176750'	054562'	MOV	#65000.,T33DLY		;SET UP DELAY COUNTER	
3172	052772	004737	015664'		JSR	PC,SOFINIT		;DO INITIALIZE ON CONTROLLER	
3173	052776	103426			BCS	20\$;BR IF INIT WAS OK	
3174	053000				DELAY	250		;DELAY ABOUT .25 SEC	
	053000	012727	000250					MOV	#250,(PC)+
	053004	000000						.WORD	0
	053006	013727	002116'					MOV	L\$DLY,(PC)+
	053012	000000						.WORD	0
	053014	005367	177772					DEC	-6(PC)
	053020	001375						BNE	.-4
	053022	005367	177756					DEC	-22(PC)
	053026	001367						BNE	.-20
3175	053030	005337	054562'		DEC	T33DLY		;BUMP COUNTER	
3176	053034	001356			BNE	10\$;BR, IF COUNTER NOT DONE	
3177	053036	005237	002214'		INC	FATFLG		;ERROR COUNT	
3181	053042	010001			MOV	RO,R1		;CONTENTS OF TSSR REGISTER	
3182	053044				ERRDF	ERRNO,SFIERR,SFIMSG		;FATAL ERROR TSSR WAS NOT OK	
	053044	104455						TRAP	C\$ERDF
	053046	000765						.WORD	501
	053050	003642'						.WORD	SFIERR
	053052	011724'						.WORD	SFIMSG
3183	053054	013737	002174'	054420'	20\$:	MOV	UNITN,T33DSW		;SET UP UNIT NUMBER
3184									
3185	053062	012704	054400'		MOV	#T33PACKET,R4		;SUBROUTINE NEEDS PACKET ADDRESS	
3186	053066	004737	010552'		JSR	PC,WRTCHR		;ISSUE WRITE CHARACTERISTICS	
3187	053072	103407			BCS	23\$;BR, IF COMMAND ISSUED OK	
3188	053074	005237	002214'		INC	FATFLG		;ERROR COUNT	
3192	053100	010001			MOV	RO,R1		;SAVE CONTENTS OF TSSR	
3193	053102				ERRHRD	ERRNO,WRTMSG,SFIMSG		;WRITE CHARACTERISTIC FAILED	
	053102	104456						TRAP	C\$ERHRD
	053104	000766						.WORD	502
	053106	005046'						.WORD	WRTMSG
	053110	011724'						.WORD	SFIMSG
3194	053112				23\$:	CKLOOP		;LOOP IF SELECTED	
	053112	104406						TRAP	C\$CLP1
3195	053114	004737	010704'		JSR	PC,REWIND		;CALL TAPE REWIND COMMAND	
3196	053120	103411			BCS	30\$;BR, IF NO PROBLEM	
3197	053122	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS	
3198	053126	010004			MOV	RO,R4		;GET PACKET ADDRESS	
3199	053130	005237	002214'		INC	FATFLG		;ERROR COUNT	
3203	053134				ERRHRD	ERRNO,T33RWN,PKTSSR		;REWIND NOT ACCEPTED	
	053134	104456						TRAP	C\$ERHRD
	053136	000767						.WORD	503
	053140	055260'						.WORD	T33RWN
	053142	011736'						.WORD	PKTSSR
3204	053144				30\$:	CKLOOP		;LOOP IF SELECTED	
	053144	104406						TRAP	C\$CLP1
3205	053146	013701	054430'		MOV	T33BFR+6,R1		;PICK UP XSTO	
3206	053152	010102			MOV	R1,R2		;SET UP EXPECTED	
3207	053154	052702	000002		RIS	#BIT1,R2		;SET BOT BIT IN EXPECTED	
3208	053160	020102			CMP	R1,R2		;DOES EXP = REC'D	
3209	053162	001406			BEQ	40\$;BR, IF EQUAL (OK)	
3210	053164	005237	002214'		INC	FATFLG		;ERROR COUNT	
3214	053170				ERRHRD	ERRNO,T33BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND	
	053170	104456						TRAP	C\$ERHRD
	053172	000770						.WORD	504

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 5: DATA PARITY TEST

SEQ 151

```

053174 055165'
053176 015364'
3215 053200 40$: CKLOOP ;LOOP IF SELECTED .WORD T33BOT
053200 104406 TRAP C$CLP1 .WORD EXPREC

3216
3217 053202 005737 002220' 42$: TST EXTFEA ;CHECK FOR EXTENDED FEATURES SW SWITCH
3218 053206 001025 BNE 55$ ;BR IF SWITCH IS ON
3219 053210 112737 000200 054541' MOVB #200,T33BS1 ;WRITE MISCELLANEOUS CONT/READ STATUS
3220 053216 112737 000010 054540' MOVB #10,T33BS0 ;FUNC. SEL. BIT (TURN ON EXTFEA SWITCH)
3221 053224 012704 054510' MOV #T33PK2,R4 ;WRITE SUBSYS MEM PACKET
3222 053230 010465 000000 MOV R4,TSDB(R5) ;ISSUE COMMAND
3223 053234 004737 016226' JSR PC,CHKTSSR ;WAIT FOR SSR
3224 053240 103407 BCS 50$ ;BR, IF NO ERROR
3225 053242 010001 MOV R0,R1 ;ERROR, SAVE TSSR
3226 053244 005237 002214' INC FATFLG ;ERROR COUNT
3230 053250 ERRHRD ERRNO,T33SSR,PKTSSR ;TSSR NOT CORRECT AFTER WRT. MISCELLANEOUS
053250 104456 TRAP C$ERHRD
053252 000771 .WORD 505
053254 055101' .WORD T33SSR
053256 011736' .WORD PKTSSR

3231 053260 50$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
053260 104406 TRAP C$CLP1

3232 053262 005737 002222' 55$: TST BEMBSW ;CHECK FOR BUFFER ENABLED
3233 053266 001426 BEQ 70$ ;BR, IF BUFFERING NOT ENABLED
3234 053270 013737 002174' 054420' MOV UNITN,T33DSW ;SET UP UNIT NUMBER
3235 053276 042737 000020 054420' BIC #BIT4,T33DSW ;BUFFER DISABLE
3236 053304 052737 000010 054420' BIS #BIT3,T33DSW ;BUFFER DISABLE SEND 01 TO BITS 4 AND 3
3237 053312 012704 054400' MOV #T33PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
3238 053316 004737 010552' JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
3239 053322 103407 BCS 60$ ;BR, IF COMMAND ISSUED OK
3240 053324 005237 002214' INC FATFLG ;ERROR COUNT
3244 053330 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
3245 053332 ERRHRD ERRNO,WRTMSG,SFMSG ;WRITE CHARACTERISTIC FAILED
053332 104456 TRAP C$ERHRD
053334 000772 .WORD 506
053336 005046' .WORD WRTMSG
053340 011724' .WORD SFMSG

3246 053342 60$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
053342 104406 TRAP C$CLP1

3247 053344 70$:
3248 053344 112737 000100 054541' MOVB #100,T33BS1 ;WRITE MISCELLANEOUS CONT/READ STATUS
3249 053352 112737 000011 054540' MOVB #11,T33BS0 ;FUNC. SEL. BIT (SET WRONG PARITY)
3250 053360 012704 054510' MOV #T33PK2,R4 ;WRITE SUBSYS MEM PACKET
3251 053364 010465 000000 MOV R4,TSDB(R5) ;ISSUE COMMAND
3252 053370 004737 016226' JSR PC,CHKTSSR ;WAIT FOR SSR
3253 053374 103407 BCS 80$ ;BR, IF NO ERROR
3254 053376 010001 MOV R0,R1 ;ERROR, SAVE TSSR
3255 053400 005237 002214' INC FATFLG ;ERROR COUNT
3259 053404 ERRHRD ERRNO,T33SSR,PKTSSR ;TSSR NOT CORRECT AFTER WRT. MISCELLANEOUS
053404 104456 TRAP C$ERHRD
053406 000773 .WORD 507
053410 055101' .WORD T33SSR
053412 011736' .WORD PKTSSR

3260 053414 80$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
053414 104406 TRAP C$CLP1

3261 053416 012703 000026 MOV #22.,R3 ;NUMBER OF RECORDS TO BE WRITTEN
3262 053422 013737 003116' 054532' MOV FREE,T33WB ;STARTING WRITE BUFFER ADDRESS

```

3263	053430	005037	054560'		CLR	T33CNU		;MAKE SURE ITS CLEAR
3264	053434	012737	140005	054530' 110\$:	MOV	#140005,T33PK3		;WRITE DATA,ACK,CVC=1 COMMAND
3265	053442	012704	054530'		MOV	#T33PK3,R4		;SET UP R4 WITH PACKET ADDRESS
3266	053446	012737	000024	054536'	MOV	#20.,T33SZ		;SET UP RECORD SIZE IN PACKET
3267	053454	013777	054560'	127434	MOV	T33CNU,#FREE		;MEMORY FILLED WITH DATA IN RECORD
3268	053462	005237	054560'		INC	T33CNU		;READY FOR NEXT RECORD
3269	053466	010465	000000		MOV	R4,T33DB(R5)		;ISSUE COMMAND
3270	053472	004737	016140'		JSR	FC,WAITF		;WAIT FOR SSR TO SET
3271	053476	016501	000002		MOV	T33R(R5),R1		;GET T33R CONTENTS
3272	053502	012702	100210		MOV	#SSR!SC!BIT3,R2		;SET UP EXPECTED
3273	053506	020102			CMP	R1,R2		;ARE THEY EQUAL
3274	053510	001406			BEQ	120\$;BR, IF OK
3275	053512	005237	002214'		INC	FATFLG		;ERROR COUNT
3279	053516				ERRHRD	ERRNO,T33WPW,PKTSSR		;T33R INCORRECT AFTER WRITE DATA
	053516	104456					TRAP	C\$ERHRD
	053520	000774					.WORD	508
	053522	054642'					.WORD	T33WPW
	053524	011736'					.WORD	PKTSSR
3280	053526			120\$:	CKLOOP			;LOOP IF SELECTED
	053526	104406					TRAP	C\$CLP1
3281	053530	013701	054432'		MOV	T33BFR+10,R1		;PICK UP XST1
3282	053534	010102			MOV	R1,R2		;SET UP EXPECTED
3283	053536	052702	000002		BIS	#BIT1,R2		;SET UNC BIT IN EXPECTED
3284	053542	020102			CMP	R1,R2		;DOES EXP = REC'D
3285	053544	001406			BEQ	130\$;BR, IF EQUAL (OK)
3286	053546	005237	002214'		INC	FATFLG		;ERROR COUNT
3290	053552				ERRHRD	ERRNO,T33UNC,EXPREC		;TAPE NOT AT BOT AFTER REWIND
	053552	104456					TRAP	C\$ERHRD
	053554	000775					.WORD	509
	053556	054722'					.WORD	T33UNC
	053560	015364'					.WORD	EXPREC
3291	053562			130\$:	CKLOOP			;LOOP IF SELECTED
	053562	104406					TRAP	C\$CLP1
3292	053564	005303			DEC	R3		;DEC RECORD COUNTER
3293	053566	001322			BNE	110\$;BR, IF MORE RECORDS TO WRITE
3294	053570	004737	010704'		JSR	PC,REWIND		;CALL TAPE REWIND COMMAND
3295	053574	103411			BCS	140\$;BR, IF NO PROBLEM
3296	053576	016501	000002		MOV	'SSR(R5),R1		;GET T33R CONTENTS
3297	053602	010004			MOV	R0,R4		;GET PACKET ADDRESS
3298	053604	005237	002214'		INC	FATFLG		;ERROR COUNT
3302	053610				ERRHRD	ERRNO,T33RWN,PKTSSR		;REWIND NOT ACCEPTED
	053610	104456					TRAP	C\$ERHRD
	053612	000776					.WORD	510
	053614	055260'					.WORD	T33RWN
	053616	011736'					.WORD	PKTSSR
3303	053620			140\$:	CKLOOP			;LOOP IF SELECTED
	053620	104406					TRAP	C\$CLP1
3304	053622	013701	054430'		MOV	T33BFR+6,R1		;PICK UP XST0
3305	053626	010102			MOV	R1,R2		;SET UP EXPECTED
3306	053630	052702	000002		BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED
3307	053634	020102			CMP	R1,R2		;DOES EXP = REC'D
3308	053636	001406			BEQ	150\$;BR, IF EQUAL (OK)
3309	053640	005237	002214'		INC	FATFLG		;ERROR COUNT
3313	053644				ERRHRD	ERRNO,T33BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND
	053644	104456					TRAP	C\$ERHRD
	053646	000777					.WORD	511
	053650	055165'					.WORD	T33BOT

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 5: DATA PARITY TEST

SEQ 153

```

3314 053652 015364'          150$: CKLOOP          ;LOOP IF SELECTED          .WORD  EXPREC
      053654 104406          TRAP          C$CLP1
3315 053656 005037 054560'      CLR          T33CNU          ;CLEAR DATA VALUE IN RECORD
3316 053662 012703 000024      MOV          #20.,R3          ;RECORD SIZE
3317 053666 013737 003116' 054532' 155$: MOV          FREE,T33RB          ;STARTING WRITE BUFFER ADDRESS
3318 053674 012737 140001 054530' MOV          #140001,T33PK3      ;READ DATA,CVC=1,ACK COMMAND
3319 053702 012704 054530'      MOV          #T33PK3,R4          ;SET UP R4 WITH PACKET ADDRESS
3320 053706 012737 000024 054536' MOV          #20.,T33SZ          ;SET UP RECORD SIZE IN PACKET
3321 053714 010465 000000      MOV          R4,TSDB(R5)        ;ISSUE COMMAND
3322 053720 004737 016140'      JSR          PC,WAITF          ;WAIT FOR SSR TO SET
3323 053724 016501 000002      MOV          TSSR(R5),R1        ;GET TSSR CONTENTS
3324 053730 012702 100210      MOV          #SSR!SC!BIT3,R2    ;SET UP EXPECTED
3325 053734 020102              CMP          R1,R2              ;ARE THEY EQUAL
3326 053736 001406              BEQ          160$              ;BR. IF OK
3327 053740 005237 002214'      INC          FATFLG            ;ERROR COUNT
3331 053744              ERRHRD          ERRNO,T33WDC,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      053744 104456          TRAP          C$ERHRD
      053746 001000          .WORD          512
      053750 055327'        .WORD          T33WDC
      053752 011736'        .WORD          PKTSSR
3332 053754          160$: CKLOOP          ;LOOP IF SELECTED          TRAP          C$CLP1
      053754 104406          ;PICK UP XST1
3333 053756 013701 054432'      MOV          T33BFR+10,R1      ;SET UP EXPECTED
3334 053762 010102              MOV          R1,R2              ;SET UNC BIT IN EXPECTED
3335 053764 052702 000002      BIS          #BIT1,R2          ;DOES EXP = REC'D
3336 053770 020102              CMP          R1,R2              ;BR. IF EQUAL (OK)
3337 053772 001406              BEQ          170$              ;ERROR COUNT
3338 053774 005237 002214'      INC          FATFLG
3342 054000              ERRHRD          ERRNO,T33UND,EXPREC ;UNC BIT NOT SET AFTER READ CMD.
      054000 104456          TRAP          C$ERHRD
      054002 001001          .WORD          513
      054004 055012'        .WORD          T33UND
      054006 015364'        .WORD          EXPREC
3343 054010          170$: CKLOOP          ;LOOP IF SELECTED          TRAP          C$CLP1
      054010 104406          ;PICK UP XST1
3344 054012 013701 054432'      MOV          T33BFR+10,R1      ;SET UP EXPECTED
3345 054016 010102              MOV          R1,R2              ;SET RBP BIT IN EXPECTED
3346 054020 052702 000400      BIS          #BIT8,R2          ;DOES EXP = REC'D
3347 054024 020102              CMP          R1,R2              ;BR. IF EQUAL (OK)
3348 054026 001406              BEQ          180$              ;ERROR COUNT
3349 054030 005237 002214'      INC          FATFLG
3353 054034              ERRHRD          ERRNO,T33RBP,EXPREC ;READ BUS PARITY ERROR BIT NOT SET
      054034 104456          TRAP          C$ERHRD
      054036 001002          .WORD          514
      054040 054564'        .WORD          T33RBP
      054042 015364'        .WORD          EXPREC
3354 054044          180$: CKLOOP          ;LOOP IF SELECTED          TRAP          C$CLP1
      054044 104406          ;GET DATA READ
3355 054046 017701 127044      MOV          @FREE,R1          ;GET PATTERN
3356 054052 013702 054560'      MOV          T33CNU,R2
3357 054056 020102              CMP          R1,R2              ;ARE THEY EQUAL
3358 054060 001406              BEQ          182$              ;BR. IF OK
3359 054062 005237 002214'      INC          FATFLG            ;ERROR COUNT
3363 054066              ERRHRD          ERRNO,T33DTA,EXPREC ;DATA NOT CORRECT
      054066 104456          TRAP          C$ERHRD
      054070 001003          .WORD          515

```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 5: DATA PARITY TEST

SEQ 154

	054072	055410'							.WORD	T33DTA
	054074	015364'							.WORD	EXPREC
3364	054076		182\$:	CKLOOP						; LOOP IF SELECTED
	054076	104406							TRAP	C\$CLP1
3365	054100	013737	003116'	054532'	MOV	FREE, T33WB				; STARTING WRITE BUFFER ADDRESS
3366	054106	012737	140401	054530'	195\$:	MOV	#140401, T33PK3			; READ REVERSE DATA RETRY, ACK COMMAND
3367	054114	012704	054530'		MOV	#T33PK3, R4				; SET UP R4 WITH PACKET ADDRESS
3368	054120	012737	000024	054536'	MOV	#20, T33SZ				; SET UP RECORD SIZE IN PACKET
3369	054126	010465	000000		MOV	R4, TSDB(R5)				; ISSUE COMMAND
3370	054132	004737	016140'		JSR	PC, WAITF				; WAIT FOR SSR TO SET
3371	054136	016501	000002		MOV	TSSR(R5), R1				; GET TSSR CONTENTS
3372	054142	012702	100210		MOV	#SSR!BIT3, R2				; SET UP EXPECTED
3373	054146	020102			CMP	R1, R2				; ARE THEY EQUAL
3374	054150	001406			BEQ	190\$; BR, IF OK
3375	054152	005237	002214'		INC	FATFLG				; ERROR COUNT
3379	054156				ERRHRD	ERRNO, T33WDC, PKTSSR				; TSSR INCORRECT AFTER WRITE DATA
	054156	104456							TRAP	C\$ERHRD
	054160	001004							.WORD	516
	054162	055327'							.WORD	T33WDC
	054164	011736'							.WORD	PKTSSR
3387	054166		190\$:	CKLOOP						; LOOP IF SELECTED
	054166	104406							TRAP	C\$CLP1
3381	054170	013701	054432'		MOV	T33BFR+10, R1				; PICK UP XST1
3382	054174	010102			MOV	R1, R2				; SET UP EXPECTED
3383	054176	052702	000002		BIS	#BIT1, R2				; SET UNC BIT IN EXPECTED
3384	054202	020102			CMP	R1, R2				; DOES EXP = REC'D
3385	054204	001406			BEQ	200\$; BR, IF EQUAL (OK)
3386	054206	005237	002214'		INC	FATFLG				; ERROR COUNT
3390	054212				ERRHRD	ERRNO, T33UND, EXPREC				; TAPE NOT AT BOT AFTER REWIND
	054212	104456							TRAP	C\$ERHRD
	054214	001005							.WORD	517
	054216	055012'							.WORD	T33UND
	054220	015364'							.WORD	EXPREC
3391	054222		200\$:	CKLOOP						; LOOP IF SELECTED
	054222	104406							TRAP	C\$CLP1
3392	054224	013701	054432'		MOV	T33BFR+10, R1				; PICK UP XST0
3393	054230	010102			MOV	R1, R2				; SET UP EXPECTED
3394	054232	052702	000400		BIS	#BIT8, R2				; SET RBP BIT IN EXPECTED
3395	054236	020102			CMP	R1, R2				; DOES EXP = REC'D
3396	054240	001406			BEQ	210\$; BR, IF EQUAL (OK)
3397	054242	005237	002214'		INC	FATFLG				; ERROR COUNT
3401	054246				ERRHRD	ERRNO, T33RBP, EXPREC				; READ BUS PARITY ERROR BIT NOT SET
	054246	104456							TRAP	C\$ERHRD
	054250	001006							.WORD	518
	054252	054564'							.WORD	T33RBP
	054254	015364'							.WORD	EXPREC
3402	054256		210\$:	CKLOOP						; LOOP IF SELECTED
	054256	104406							TRAP	C\$CLP1
3403	054260	017701	126632		MOV	#FREE, R1				; GET DATA READ
3404	054264	013702	054560'		MOV	T33CNU, R2				; GET PATTERN
3405	054270	020102			CMP	R1, R2				; ARE THEY EQUAL
3406	054272	001406			BEQ	215\$; BR, IF OK
3407	054274	005237	002214'		INC	FATFLG				; ERROR COUNT
3411	054300				ERRHRD	ERRNO, T33DTA, EXPREC				; DATA NOT CORRECT
	054300	104456							TRAP	C\$ERHRD
	054302	001007							.WORD	519
	054304	055410'							.WORD	T33DTA


```

3469 054530 100005          .WORD 100005          ;REREAD COMMAND, AND ACK
3470 054532          T33RB:          ;
3471 054532 003116'      T33WB: .WORD FREE          ;ADDRESS OF WRITE BUFFER
3472 054534 000000          .WORD 0
3473 054536 000000      T33SZ: .WORD 0          ;SIZE OF BUFFER (EXTENT)
3474          .EVEN
3475          ;
3476          ;
3477          ;
3478 054540          T33BF2:          ;
3479 054540          T33BS0: .BYTE 10          ;BSELO AREA
3480 054541          T33BS1: .BYTE 200        ;BSEL1 AREA
3481 054542 000000      T33S2: .WORD 0          ;SEL 2 AREA
3482 054544 000000      T33S3: .WORD 0          ;DATA AREA
3483          ;
3484          ;
3485          .EVEN
3486          ;TAPE MOTION PACKET COMMAND VALUES
3487          ;
3488 054546 100205      T33RN: .WORD 100205      ;REREAD DATA (NEXT)
3489 054550 100605      T33WDR: .WORD 100605     ;REREAD DATA RETRY
3490 054552 102205      T33CON: .WORD 102205     ;WRITE CONTINOUS
3491 054554 177777          .WORD 177777          ;END OF DATA
3492          ;
3493          ;
3494 054556 000000      T33CNT: .WORD 0          ;TAPE TIMER COUNTER STORAGE AREA
3495 054560 000000      T33CNU: .WORD 0          ;TAPE TIMER COUNTER STORAGE AREA
3496 054562 000000      T33DLY: .WORD 0          ;DELAY COUNTER
3497          ;
3498          ;
3499          ;+
3500          ;LOCAL TEXT MESSAGES FOR TEST
3501          ;-
3502          ;
3503          ;
3504 054564          122      145      141  T33RBP: .ASCIZ 'Read Bus Parity Bit Not Set (XST1), Should Be'
3505 054642          124      123      123  T33WPW: .ASCIZ 'TSSR Incorrect After Wrong Parity Write Command'
3506 054722          125      116      103  T33UNC: .ASCIZ 'UNC Bit (XST1) Not Set After Wrong Parity WRITE Command'
3507 055012          125      116      103  T33UND: .ASCIZ 'UNC Bit (XST1) Not Set After Wrong Parity READ Command'
3508 055101          127      122      111  T33SSR: .ASCIZ 'WRITE MISCELLANEOUS CONT/READ COMMAND Not Accepted'
3509 055165          124      141      160  T33BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
3510 055260          122      145      167  T33RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
3511 055327          124      123      123  T33WDC: .ASCIZ 'TSSR Not Correct After READ Wrong Parity Command'
3512 055410          104      141      164  T33DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
3513 055505          104      141      164  T33ID:  .ASCIZ 'Data Parity'
3514          .EVEN
3515          ;+
3516          ;
3517          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
3518          ;WRITE SUBSYSTEM MEMORY COMMAND
3519          ;
3520          ;-
3521          ;
3522 055522          T33REST:          ;
3523 055522          SAVREG          ;SAVE THE REGISTERS
3524 055526 012701 054400'  MOV #T33PACKET,R1      ;START OF THE PACKET
3525 055532 012721 100004'  MOV #100004,(R1)+      ;WRITE SUBSYSTEM MEM, WITH ACK,

```

```

3526 055536 012721 054410'      MOV      @T33DATA,(R1)+      ;ADDRESS OF CHARAISTICS DATA BLOCK
3527 055541 005021              CLR      (R1)+              ;EXTENDED ADDRESS
3528 055541 012721 000012      MOV      @10.,(R1)+         ;SIZE OF DATA BLOCK IN BYTES
3529 055550 012721 054422'      MOV      @T33BFR,(R1)+     ;ADDRESS OF MESSAGE BUFFER
3530 055554 005021              CLR      (R1)+              ;
3531 055556 012721 000024      MOV      @20.,(R1)+         ;LENGTH OF MESSAGE BUFIER
3532 055562 005021              CLR      (R1)+              ;
3533 055564 012711 000000      MOV      @0,(R1)           ;SELECT DRIVE ZERO
3534 055570 012702 000030      MOV      @24.,R2           ;NUMBER OF LOCATIONS TO BE CLEARED
3535 055574 012762 177777 0544.2' 641: MOV      @177777,T33BFR(R2) ;ALL ONES TO MESSAGE BUFFER
3536 055602 005742              TST      -(R2)              ;NEXT LOCATION
3537 055604 022702 000000      CMP      @0,R2             ;AT END OF LOOP YET
3538 055610 001371              BNE      611                ;KEEP GOING UNTIL DONE
3539 055612 000207              RTS      PC                  ;RETURN
3540
3541

```

```

3542 055614              T33RT2:
3543 055614              SAVREG      ;SAVE THE REGISTERS
3544 055620 012701 054510'      MOV      @T33PK2,R1        ;START OF THE PACKET
3545 055624 012721 100006      MOV      @100006,(R1)+     ;WRITE SUBSYSTEM MEM. WITH ACK,
3546 055630 012721 054540'      MOV      @T33BF2,(R1)+     ;ADDRESS OF DATA BLOCK
3547 055634 005021              CLR      (R1)+              ;EXTENDED ADDRESS
3548 055636 012721 000006      MOV      @6.,(R1)+         ;SIZE OF DATA BLOCK IN BYTES
3549 055642 005021              CLR      (R1)+              ;
3550 055644 012701 054540'      MOV      @T33BF2,R1        ;POINT TO DATA SEL AREA
3551 055650 005011              CLR      (R1)+              ;
3552 055652 005011              CLR      (R1)+              ;
3553 055654 000207              RTS      PC                  ;RETURN
3554 055656

```

```

3555 055656              T33RT3:
3556 055662 012701 054530'      SAVREG      ;SAVE REGISTERS
3557 055666 005021              MOV      @T33PK3,R1        ;SET UP POINTER ADDRESS
3558 055670 005021              CLR      (R1)+              ;COMMAND SPACE
3559 055672 005021              CLR      (R1)+              ;ADDRESS OF DATA BLOCK
3560 055674 005011              CLR      (R1)+              ;EXTENDED ADDRESS
3561 055676 000207              CLR      (R1)+              ;SIZE OF DATA TRANSFER BLOCK
3562 055700              RTS      PC                  ;RETURN
3563 055700              ENDTST
3564 055700 104401              L10057: TRAP      C#TST

```

```

3565              .STTL TEST 6: OPERATIONS AT EOT
3566              ;
3567              ; THIS TEST VERIFIES PROPER OPERATION OF THE WRITE DATA RETRY
3568              ; COMMAND (SPACE REVERSE, ERASE, WRITE DATA)
3569              ;
3570              ; THE TEST CONSISTS OF THE FOLLOWING 1 SUBTEST
3571              ;
3572              ;
3573              ;
3574              ;
3575              ;
3576 055702              BGNTST
3577 055702 012737 006166' 002172'      MOV      @EPR1,EPR1SW      ;PRIMARY ERROR MESSAGE
3578 055710 012700 063057'      MOV      @TST3#ID,R0       ;ASCII MESSAGE TO IDENTIFY TEST
3579 055714 004737 016402'      JSR      PC,TSTSETUP       ;DO INITIAL TEST SETUP

```

```

3584 055720 012737 000005 002210'
3585 055726 005037 060542'
3586
3587
3588
3589
3590
3591
3592
3593
3594
3595
3596
3597
3598
3599
3600
3601
3602
3603
3604
3605
3606
3607
3608
3609
3610
3611
3612
3613
3614
3615
3616
3617
3618
3619
3620
3621
3622
3623
3624
3625
3626
3627
3628
3629
3630
3631
3632
3633
3634
3635
3636
3637
3638
3639
3640

```

```

MOV 05, LOOPCNT
CLR T34CNT

```

```

;PERFORM 5 ITERATIONS
;CLEAR TAPE RECORD COUNTER

```

```

TEST 6, SUBTEST 1

```

THIS TEST VERIFIES THAT THE EOT STATUS IS HANDLED PROPERLY BY THE VARIOUS TAPE MOTION COMMANDS. THE FOLLOWING TEST SEQUENCE IS PERFORMED:

1. THE TAPE IS REWOUND.
2. WRITE DATA COMMANDS ARE REPEATEDLY ISSUED UNTIL TAPE STATUS ALERT TERMINATION IS SEEN WITH EOT=1. ERRORS OTHER THAN OCCASIONAL CORRECTABLE OR UNCORRECTABLE DATA ERRORS CAUSE A FATAL ERROR REPORT. RECORDS WITH DATA ERRORS ARE RETRIED, SO THE TAPE ENDS UP WITH GOOD DATA.
3. ANOTHER WRITE DATA COMMAND IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1.
4. A WRITE TAPE MARK COMMAND IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1.
5. A SKIP TAPE MARKS REVERSE COMMAND IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1 AND TMK=1.
6. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 1, IS ISSUED, AND IT IS CHECKED THAT TAPE STATUS ALERT TERMINATION OCCURS, WITH EOT=1 AND TMK=1.
7. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 1, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
8. A SPACE RECORDS FORWARD COMMAND, WITH A RECORD COUNT OF 1, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
9. A READ REVERSE COMMAND IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
10. A READ FORWARD COMMAND IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
11. A SPACE RECORDS REVERSE COMMAND, WITH A RECORD COUNT OF 3, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=0.
12. A SPACE RECORDS FORWARD COMMAND, WITH A RECORD COUNT OF 3, IS ISSUED, AND IT IS CHECKED THAT NORMAL TERMINATION OCCURS, WITH EOT=1.
13. A SKIP FILE MARKS REVERSE COMMAND IS ISSUED, WHICH SHOULD SKIP ALL THE WAY TO BOT, AND IT IS CHECKED THAT

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 6: OPERATIONS AT EOT

SEQ 160

```

3691 056040 010001          MOV      RO,R1          ;CONTENTS OF TSSR REGISTER
3692 056042          ERRDF   ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
                                TRAP      C$ERDF
                                .WORD    601
                                .WORD    SFIERR
                                .WORD    SFIMSG
3693 056052          20$:   CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
3694 056054 013737 002174' 060420'  MOV      UNITN,T34DSW    ;SET UP DRIVE NUMBER
3695 056062 052737 000040 060420'  BIS      @BITS,T34DSW    ;TURN ON HIGH SPEED TO SAVE TIME
3696 056070 012704 060400'          MOV      @T34PACKET,R4   ;SUBROUTINE NEEDS PACKET ADDRESS
3697 056074 004737 010552'          JSR      PC,WRTCHR       ;ISSUE WRITE CHARACTERISTICS
3698 056100 103407          BCS     30$              ;BR, IF COMMAND ISSUED OK
3699 056102 005237 002214'          INC      FATFLG         ;ERROR COUNT
3703 056106 010001          MOV      RO,R1          ;SAVE CONTENTS OF TSSR
3704 056110          ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
                                TRAP      C$ERHRD
                                .WORD    602
                                .WORD    WRTMSG
                                .WORD    SFIMSG
3705 056120          30$:   CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
3706 056122 004737 010704'          JSR      PC,REWIND       ;REWIND CALL
3707 056126 103411          BCS     35$              ;BR, IF TSSR IS OK (GOOD)
3708 056130 016501 000002          MOV      TSSR(R5),R1    ;GET TSSR
3709 056134 010004          MOV      RO,R4          ;SET UP PACKET
3710 056136 005237 002214'          INC      FATFLG         ;ERROR COUNT
3714 056142          ERRHRD  ERRNO,T34RWN,PKTSSR ;TSSR IS INCORRECT AFTER REWIND
                                TRAP      C$ERHRD
                                .WORD    603
                                .WORD    T34RWN
                                .WORD    PKTSSR
3715 056152          35$:   CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
3716 056154 012737 140005 060530'  MOV      @140005,T34PK3  ;WRITE DATA, ACK, CVC-1
3717 056162 012703 176750          MOV      @65000,R3      ;SET MAX NUMBER OF WRITES
3718 056166 013737 003116' 060532'  MOV      FREE,T34WB     ;SET UP WRITE BUFFER ADDRESS
3719 056174 012737 006654 060536'  MOV      @3500,T34SZ    ;SET UP BUFFER SIZE (4K BYTES)
3720 056202 012704 060530'          MOV      @T34PK3,R4     ;R4 = POINTER TO PACKET
3721 056206 010465 000000          MOV      R4,TSDB(R5)    ;ISSUE COMMAND
3722 056212 004737 016140'          JSR      PC,WAITF       ;WAIT FOR SSR TO SET
3723 056216 016501 000002          MOV      TSSR(R5),R1    ;GET TSSR CONTENTS
3724 056222 012702 000200          MOV      @SSR,R2       ;SET UP EXPECTED
3725 056226 020102          CMP      R1,R2          ;ARE THEY EQUAL
3726 056230 001010          BNE     50$              ;BR, IT MIGHT BE END OF TAPE
3727 056232 005303          DEC      R3             ;DEC RECORD COUNTER
3728 056234 001364          BNE     40$              ;BR, IF MORE TO GO
3729 056235 005237 002214'          INC      FATFLG         ;ERROR COUNT
3733 056242          ERRDF   ERRNO,T34ET,PKTSSR ;EOT NOT FOUND (USE SHORTER TAPE?)
                                TRAP      C$ERDF
                                .WORD    604
                                .WORD    T34ET
                                .WORD    PKTSSR
3734 056252 032701 000004          50$:   BIT      @BIT2,R1  ;CHECK FOR TAPE STATUS ALERT
3735 056256 001001          BNE     60$              ;BR, IF SET
3736 056260 000752          BR      40$              ;KEEP GOING
3737 056262 013701 060430'          60$:   MOV      T34BFR+6,R1 ;PICK UP XSTO

```


3738	056266	010102			MOV	R1,R2		;SET UP EXPECTED
3739	056270	052702	000001		BIS	#BIT0,R2		;SET THE EOT BIT ON IN EXPECTED
3740	056274	020102			CMP	R1,R2		;WAS THE BIT ON
3741	056276	001402			BEQ	80\$;BR, IF EOT WAS FOUND
3742	056300	000137	056206'		JMP	40\$;KEEP LOOKING
3743	056304			80\$:	CKLOOP			;LOOP IF SELECTED
	056304	104406						TRAP C\$CLP1
3744	056306	012737	140005	060530'	MOV	#140005,T34PK3		;WRITE DATA, ACK, CVC=1
3745	056314	013737	003116'	060532'	MOV	#REE,T34WB		;SET UP WRITE BUFFER ADDRESS
3746	056322	012737	006654	060536'	MOV	#3500.,T34SZ		;SET UP BUFFER SIZE (4K BYTES)
3747	056330	012704	060530'		MOV	#T34PK3,R4		;R4 = POINTER TO PACKET
3748	056334	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND
3749	056340	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET
3750	056344	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
3751	056350	012702	100204		MOV	#SC!SSR!BIT2,R2		;SET UP EXPECTED
3752	056354	020102			CMP	R1,R2		;ARE THEY EQUAL
3753	056356	001406			BEQ	90\$;BR, IF THEY ARE OK
3754	056360	005237	002214'		INC	FATFLG		;ERROR COUNT
3758	056364				ERRHRD	ERRNO,T34ET2,PKTSSR		;WRITE TAPE AT EOT FAILED TO SET TSA
	056364	104456						TRAP C\$ERHRD
	056366	001135						.WORD 605
	056370	061237'						.WORD T34ET2
	056372	011736'						.WORD PKTSSR
3759	056374			90\$:	CKLOOP			;LOOP IF SELECTED
	056374	104406						TRAP C\$CLP1
3760	056376	013701	060430'		MOV	T34BFR+6,R1		;PICK UP XSTO
3761	056402	010102			MOV	R1,R2		;SET UP EXPECTED
3762	056404	052702	000001		BIS	#BIT0,R2		;SET THE EOT BIT ON IN EXPECTED
3763	056410	020102			CMP	R1,R2		;WAS THE BIT ON
3764	056412	001406			BEQ	100\$;BR, IF EOT WAS FOUND
3765	056414	005237	002214'		INC	FATFLG		;ERROR COUNT
3769	056420				ERRHRD	ERRNO,T34ETN,EXPREC		;EOT BIT (XSTO) NOT SET
	056420	104456						TRAP C\$ERHRD
	056422	001136						.WORD 606
	056424	061321'						.WORD T34ETN
	056426	015364'						.WORD EXPREC
3770	056430			100\$:	CKLOOP			;LOOP IF SELECTED
	056430	104406						TRAP C\$CLP1
3771	056432	012737	140011	060530'	MOV	#140011,T34PK3		;WRITE TAPE MARK, ACK, CVC=1 COMMAND
3772	056440	012704	060530'		MOV	#T34PK3,R4		;R4 = POINTER TO PACKET
3773	056444	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND
3774	056450	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET
3775	056454	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
3776	056460	012702	100204		MOV	#SC!SSR!BIT2,R2		;SET UP EXPECTED
3777	056464	020102			CMP	R1,R2		;ARE THEY EQUAL
3778	056466	001406			BEQ	110\$;BR, IF STATUS IS GOOD (OK)
3779	056470	005237	002214'		INC	FATFLG		;ERROR COUNT
3783	056474				ERRHRD	ERRNO,T34WTM,PKTSSR		;EOT NOT FOUND (USE SHORTER TAPE?)
	056474	104456						TRAP C\$ERHRD
	056476	001137						.WORD 607
	056500	061150'						.WORD T34WTM
	056502	011736'						.WORD PKTSSR
3784	056504			110\$:	CKLOOP			;LOOP IF SELECTED
	056504	104406						TRAP C\$CLP1
3785	056506	013701	060430'		MOV	T34BFR+6,R1		;PICK UP XSTO
3786	056512	010102			MOV	R1,R2		;SET UP EXPECTED
3787	056514	052702	000001		BIS	#BIT0,R2		;SET THE EOT BIT ON IN EXPECTED

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 6: OPERATIONS AT EOT

SEQ 162

3788	056520	020102				CMP	R1,R2		; WAS THE BIT ON		
3789	056522	001406				BEQ	120\$; BR, IF EOT WAS FOUND		
3790	056524	005237	002214'			INC	FATFLG		; ERROR COUNT		
3794	056530					ERRHRD	ERRNO,T34ETO,EXPREC		; EOT BIT (XSTO) NOT SET		
	056530	104456								TRAP	C\$ERHRD
	056532	001140								.WORD	608
	056534	060652'								.WORD	T34ETO
	056536	015364'								.WORD	EXPREC
3795	056540				120\$:	CKLOOP			; LOOP IF SELECTED		
	056540	104406								TRAP	C\$CLP1
3796	056542	012737	141410	060530'		MOV	#141410,T34PK3		; SKIP TAPE MARK REVERSE ACK,CVC=1 COMMAND		
3797	056550	012737	000001	060532'		MOV	#1,T34WB		; SET NUMBER (1) OF TMS TO SKIP		
3798	056556	012704	060530'			MOV	#T34PK3,R4		; R4 = POINTER TO PACKET		
3799	056562	010465	000000			MOV	R4,TSDB(R5)		; ISSUE COMMAND		
3800	056566	004737	016140'			JSR	PC,WAITF		; WAIT FOR SSR TO SET		
3801	056572	016501	000002			MOV	TSSR(R5),R1		; GET TSSR CONTENTS		
3802	056576	012702	000200			MOV	#SSR,R2		; SET UP EXPECTED		
3803	056602	020102				CMP	R1,R2		; ARE THEY EQUAL		
3804	056604	001406				BEQ	130\$; BR, IF STATUS IS GOOD (OK)		
3805	056606	005237	002214'			INC	FATFLG		; ERROR COUNT		
3809	056612					ERRHRD	ERRNO,T34STM,PKTSSR		; SKIP TAPE MARK REV. DIDN'T SET TSA		
	056612	104456								TRAP	C\$ERHRD
	056614	001141								.WORD	609
	056616	061550'								.WORD	T34STM
	056620	011736'								.WORD	PKTSSR
3810	056622				130\$:	CKLOOP			; LOOP IF SELECTED		
	056622	104406								TRAP	C\$CLP1
3811	056624	013701	060430'			MOV	T34BFR+6,R1		; PICK UP XSTO		
3812	056630	010102				MOV	R1,R2		; SET UP EXPECTED		
3813	056632	052702	000001			BIS	#BIT0,R2		; SET THE EOT BIT ON IN EXPECTED		
3814	056636	020102				CMP	R1,R2		; WAS THE BIT ON		
3815	056640	001406				BEQ	140\$; BR, IF EOT WAS FOUND		
3816	056642	005237	002214'			INC	FATFLG		; ERROR COUNT		
3820	056646					ERRHRD	ERRNO,T34ETN,EXPREC		; EOT BIT (XSTO) NOT SET		
	056646	104456								TRAP	C\$ERHRD
	056650	001142								.WORD	610
	056652	061321'								.WORD	T34ETN
	056654	015364'								.WORD	EXPREC
3821	056656				140\$:	CKLOOP			; LOOP IF SELECTED		
	056656	104406								TRAP	C\$CLP1
3822	056660	013701	060430'			MOV	T34BFR+6,R1		; PICK UP XSTO		
3823	056664	010102				MOV	R1,R2		; SET UP EXPECTED		
3824	056666	052702	100000			BIS	#BIT15,R2		; SET THE TMK BIT ON IN EXPECTED		
3825	056672	020102				CMP	R1,R2		; WAS THE BIT ON		
3826	056674	001406				BEQ	150\$; BR, IF TMK WAS FOUND		
3827	056676	005237	002214'			INC	FATFLG		; ERROR COUNT		
3831	056702					ERRHRD	ERRNO,T34TMK,EXPREC		; EOT BIT (XSTO) NOT SET		
	056702	104456								TRAP	C\$ERHRD
	056704	001143								.WORD	611
	056706	061633'								.WORD	T34TMK
	056710	015364'								.WORD	EXPREC
3832	056712				150\$:	CKLOOP			; LOOP IF SELECTED		
	056712	104406								TRAP	C\$CLP1
3833	056714	012737	140410	060530'		MOV	#140410,T34PK3		; SPACE RECORDS REVERSE, ACK, CVC=1 CMD		
3834	056722	012737	000001	060532'		MOV	#1,T34WB		; SPACE ONE RECORD REVERSE		
3835	056730	012704	060530'			MOV	#T34PK3,R4		; R4 = POINTER TO PACKET		
3836	056734	010465	000000			MOV	R4,TSDB(R5)		; ISSUE COMMAND		

3837	056740	004737	016140'		JSR	PC, WAITF		;WAIT FOR SSR TO SET	
3838	056744	016501	000302		MOV	TSSR(R5), R1		;GET TSSR CONTENTS	
3839	056750	012702	100204		MOV	*SC:SSR:BIT2, R2		;SET UP EXPECTED	
3840	056754	020102			CMP	R1, R2		;ARE THEY EQUAL	
3841	056756	001006			BNE	160\$;BR, IT MIGHT BE END OF TAPE	
3842	056760	005237	002214'		INC	FATFLG		;ERROR COUNT	
3846	056764				ERRHRD	ERRNO, T34POS, PKTSSR		;EOT NOT FOUND (USE SHORTER TAPE?)	
	056764	104456						TRAP	C\$ERHRD
	056766	001144						.WORD	612
	056770	060564'						.WORD	T34POS
	056772	011736'						.WORD	PKTSSR
3847	056774			160\$:	CKLOOP			;LOOP IF SELECTED	
	056774	104406						TRAP	C\$CLP1
3848	056776	013701	060430'		MOV	T34BFR+6, R1		;PICK UP XSTO	
3849	057002	010102			MOV	R1, R2		;SET UP EXPECTED	
3850	057004	052702	000001		BIS	*BIT0, R2		;SET THE EOT BIT ON IN EXPECTED	
3851	057010	020102			CMP	R1, R2		;WAS THE BIT ON	
3852	057012	001406			BEQ	163\$;BR, IF EOT WAS FOUND	
3853	057014	005237	002214'		INC	FATFLG		;ERROR COUNT	
3857	057020				ERRHRD	ERRNO, T34ETN, EXPREC		;EOT BIT (XSTO) NOT SET	
	057020	104456						TRAP	C\$ERHRD
	057022	001145						.WORD	613
	057024	061321'						.WORD	T34ETN
	057026	015364'						.WORD	EXPREC
3858	057030			163\$:	CKLOOP			;LOOP IF SELECTED	
	057030	104406						TRAP	C\$CLP1
3859	057032	013701	060430'		MOV	T34BFR+6, R1		;PICK UP XSTO	
3860	057036	010102			MOV	R1, R2		;SET UP EXPECTED	
3861	057040	042702	100000		BIC	*BIT15, R2		;CLEAR THE TMK BIT ON IN EXPECTED	
3862	057044	020102			CMP	R1, R2		;WAS THE BIT ON	
3863	057046	001406			BEQ	165\$;BR, IF TMK WAS FOUND	
3864	057050	005237	002214'		INC	FATFLG		;ERROR COUNT	
3868	057054				ERRHRD	ERRNO, T34TMK, EXPREC		;EOT BIT (XSTO) NOT SET	
	057054	104456						TRAP	C\$ERHRD
	057056	001146						.WORD	614
	057060	061633'						.WORD	T34TMK
	057062	015364'						.WORD	EXPREC
3869	057064			165\$:	CKLOOP			;LOOP IF SELECTED	
	057064	104406						TRAP	C\$CLP1
3870	057066	012737	140410	060530'	MOV	*140410, T34PK3		;SPACE RECORDS REVERSE, ACK, CVC=1 CMD	
3871	057074	012737	000001	060532'	MOV	*1, T34WB		;SPACE ONE RECORD REVERSE	
3872	057102	012704	060530'		MOV	*T34PK3, R4		;R4 = POINTER TO PACKET	
3873	057106	010465	000000		MOV	R4, TSDB(R5)		;ISSUE COMMAND	
3874	057112	004737	016140'		JSR	PC, WAITF		;WAIT FOR SSR TO SET	
3875	057116	016501	000002		MOV	TSSR(R5), R1		;GET TSSR CONTENTS	
3876	057122	012702	000200		MOV	*SSR, R2		;SET UP EXPECTED	
3877	057126	020102			CMP	R1, R2		;ARE THEY EQUAL	
3878	057130	001406			BEQ	167\$;BR, IT MIGHT BE END OF TAPE	
3879	057132	005237	002214'		INC	FATFLG		;ERROR COUNT	
3883	057136				ERRHRD	ERRNO, T34POS, PKTSSR		;EOT NOT FOUND (USE SHORTER TAPE?)	
	057136	104456						TRAP	C\$ERHRD
	057140	001147						.WORD	615
	057142	060564'						.WORD	T34POS
	057144	011736'						.WORD	PKTSSR
3884	057146			167\$:	CKLOOP			;LOOP IF SELECTED	
	057146	104406						TRAP	C\$CLP1
3885	057150	013701	060430'		MOV	T34BFR+6, R1		;PICK UP XSTO	

3936	057414	004737	016140'		JSR	PC, WAITF		;WAIT FOR SSR TO SET
3937	057420	016501	000002		MOV	TSSR(R5), R1		;GET TSSR CONTENTS
3938	057424	012702	000200		MOV	*SSR, R2		;SET UP EXPECTED
3939	057430	020102			CMP	R1, R2		;ARE THEY EQUAL
3940	057432	001406			BEQ	210\$;BR, IT MIGHT BE END OF TAPE
3941	057434	005237	002214'		INC	FATFLG		;ERROR COUNT
3945	057440				ERRHRD	ERRNO, T34RRE, PKTSSR		;EOT NOT FOUND (USE SHORTER TAPE?)
	057440	104456						TRAP C\$ERHRD
	057442	001153						.WORD 619
	057444	060736'						.WORD T34RRE
	057446	011736'						.WORD PKTSSR
3946	057450			210\$:	CKLOOP			;LOOP IF SELECTED
	057450	104406						TRAP C\$CLP1
3947	057452	012737	140001	060530'	MOV	*140001, T34PK3		;READ DATA, ACK, CVC=1
3948	057460	013737	003116'	060532'	MOV	FREE, T34RB		;SET UP WRITE BUFFER ADDRESS
3949	057466	012737	006654	060536'	MOV	*3500., T34SZ		;SET UP BUFFER SIZE (4K BYTES)
3950	057474	012704	060530'		MOV	*T34PK3, R4		;R4 = POINTER TO PACKET
3951	057500	010465	000000		MOV	R4, TSDB(R5)		;ISSUE COMMAND
3952	057504	004737	016140'		JSR	PC, WAITF		;WAIT FOR SSR TO SET
3953	057510	016501	000002		MOV	TSSR(R5), R1		;GET TSSR CONTENTS
3954	057514	012702	000200		MOV	*SSR, R2		;SET UP EXPECTED
3955	057520	020102			CMP	R1, R2		;ARE THEY EQUAL
3956	057522	001406			BEQ	230\$;BR, IT MIGHT BE END OF TAPE
3957	057524	005237	002214'		INC	FATFLG		;ERROR COUNT
3961	057530				ERRHRD	ERRNO, T34RRE, PKTSSR		;EOT NOT FOUND (USE SHORTER TAPE?)
	057530	104456						TRAP C\$ERHRD
	057532	001154						.WORD 620
	057534	060736'						.WORD T34RRE
	057536	011736'						.WORD PKTSSR
3962	057540			230\$:	CKLOOP			;LOOP IF SELECTED
	057540	104406						TRAP C\$CLP1
3963	057542	012737	140001	060530'	MOV	*140001, T34PK3		;READ DATA, ACK, CVC=1
3964	057550	013737	003116'	060532'	MOV	FREE, T34RB		;SET UP WRITE BUFFER ADDRESS
3965	057556	012737	006654	060536'	MOV	*3500., T34SZ		;SET UP BUFFER SIZE (4K BYTES)
3966	057564	012704	060530'		MOV	*T34PK3, R4		;R4 = POINTER TO PACKET
3967	057570	010465	000000		MOV	R4, TSDB(R5)		;ISSUE COMMAND
3968	057574	004737	016140'		JSR	PC, WAITF		;WAIT FOR SSR TO SET
3969	057600	016501	000002		MOV	TSSR(R5), R1		;GET TSSR CONTENTS
3970	057604	012702	000200		MOV	*SSR, R2		;SET UP EXPECTED
3971	057610	020102			CMP	R1, R2		;ARE THEY EQUAL
3972	057612	001406			BEQ	235\$;BR, IT MIGHT BE END OF TAPE
3973	057614	005237	002214'		INC	FATFLG		;ERROR COUNT
3977	057620				ERRHRD	ERRNO, T34RRE, PKTSSR		;EOT NOT FOUND (USE SHORTER TAPE?)
	057620	104456						TRAP C\$ERHRD
	057622	001155						.WORD 621
	057624	060736'						.WORD T34RRE
	057626	011736'						.WORD PKTSSR
3978	057630			235\$:	CKLOOP			;LOOP IF SELECTED
	057630	104406						TRAP C\$CLP1
3979	057632	013701	060430'		MOV	T34FR+6, R1		;PICK UP XSTO
3980	057636	010102			MOV	R1, R2		;SET UP EXPECTED
3981	057640	052702	000001		BIS	*BIT0, R2		;SET THE EOT BIT ON IN EXPECTED
3982	057644	020102			CMP	R1, R2		;WAS THE BIT ON
3983	057646	001406			BEQ	240\$;BR, IF EOT WAS FOUND
3984	057650	005237	002214'		INC	FATFLG		;ERROR COUNT
3988	057654				ERRHRD	ERRNO, T34ETZ, EXPREC		;EOT BIT (XSTO) NOT SET
	057654	104456						TRAP C\$ERHRD

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 6: OPERATIONS AT EOT

SEQ 166

	057656	001156							.WORD	622
	057660	061472'							.WORD	T34ETZ
	057662	015364'							.WORD	EXPREC
3989	057664		240\$:	CKLOOP						;LOOP IF SELECTED
	057664	104406								TRAP C\$CLP1
3990	057666	012737	140410	060530'	MOV	0140410,T34PK3				;SPACE RECORDS REVERSE, ACK, CVC=1 CMD.
3991	057674	012737	000005	060532'	MOV	05,T34RB				;NUMBER OF RECORDS TO SPACE
3992	057702	012704	060530'		MOV	0T34PK3,R4				;R4 = POINTER TO PACKET
3993	057706	010465	000000		MOV	R4,TSDB(R5)				;ISSUE COMMAND
3994	057712	004737	016140'		JSR	PC,WAITF				;WAIT FOR SSR TO SET
3995	057716	016501	000002		MOV	TSSR(R5),R1				;GET TSSR CONTENTS
3996	057722	012702	000200		MOV	0SSR,R2				;SET UP EXPECTED
3997	057726	020102			CMP	R1,R2				;ARE THEY EQUAL
3998	057730	001406			BEQ	250\$;BR, IT MIGHT BE END OF TAPE
3999	057732	005237	002214'		INC	FATFLG				;ERROR COUNT
4003	057736				ERRHRD	ERRNO,T34POS,PKTSSR				;POSITION COMMAND DIDN'T WORK
	057736	104456								TRAP C\$ERHRD
	057740	001157							.WORD	623
	057742	060564'							.WORD	T34POS
	057744	011736'							.WORD	PKTSSR
4004	057746		250\$:	CKLOOP						;LOOP IF SELECTED
	057746	104406								TRAP C\$CLP1
4005	057750	013701	060430'		MOV	T34BFR+6,R1				;PICK UP XSTO
4006	057754	010102			MOV	R1,R2				;SET UP EXPECTED
4007	057756	042702	000001		BIC	0BIT0,R2				;CLEAR THE EOT BIT ON IN EXPECTED
4008	057762	020102			CMP	R1,R2				;WAS THE BIT ON
4009	057764	001406			BEQ	260\$;BR, IF EOT WAS FOUND
4010	057766	005237	002214'		TNC	FATFLG				;ERROR COUNT
4014	057772				ERRHRD	ERRNO,T34ETC,EXPREC				;EOT BIT (XSTO) NOT CLEAR
	057772	104456								TRAP C\$ERHRD
	057774	001160							.WORD	624
	057776	061027'							.WORD	T34ETC
	060000	015364'							.WORD	EXPREC
4015	060002		260\$:	CKLOOP						;LOOP IF SELECTED
	060002	104406								TRAP C\$CLP1
4016	060004	012737	140010	060530'	MOV	0140010,T34PK3				;SPACE RECORDS FORWARD, ACK, CVC=1 CMD.
4017	060012	012737	000005	060532'	MOV	05,T34RB				;NUMBER OF RECORDS TO SPACE
4018	060020	012704	060530'		MOV	0T34PK3,R4				;R4 = POINTER TO PACKET
4019	060024	010465	000000		MOV	R4,TSDB(R5)				;ISSUE COMMAND
4020	060030	004737	016140'		JSR	PC,WAITF				;WAIT FOR SSR TO SET
4021	060034	016501	000002		MOV	TSSR(R5),R1				;GET TSSR CONTENTS
4022	060040	012702	000200		MOV	0SSR,R2				;SET UP EXPECTED
4023	060044	020102			CMP	R1,R2				;ARE THEY EQUAL
4024	060046	001406			BEQ	270\$;BR, IT MIGHT BE END OF TAPE
4025	060050	005237	002214'		INC	FATFLG				;ERROR COUNT
4029	060054				ERRHRD	ERRNO,T34ET,PKTSSR				;TSSR NOT CORRECT
	060054	104456								TRAP C\$ERHRD
	060056	001161							.WORD	625
	060060	061766'							.WORD	T34ET
	060062	011736'							.WORD	PKTSSR
4030	060064		270\$:	CKLOOP						;LOOP IF SELECTED
	060064	104406								TRAP C\$CLP1
4031	060066	013701	060430'		MOV	T34BFR+6,R1				;PICK UP XSTO
4032	060072	010102			MOV	R1,R2				;SET UP EXPECTED
4033	060074	052702	000001		BIS	0BIT0,R2				;SET THE EOT BIT ON IN EXPECTED
4034	060100	020102			CMP	R1,R2				;WAS THE BIT ON
4035	060102	001400			BEQ	280\$;BR, IF EOT WAS FOUND

4036	060104			280\$:	CKL OOP		; LOOP IF SELECTED	
	060104	104406					TRAP	C\$CLP1
4037	060106	012737	141410	060530'	MOV	#141410,T34PK3	; SKIP FILE MARKS REVERSE,ACK,CVC=1 COMMAND	
4038	060114	012737	000003	060532'	MOV	#3,T34RB	; NUMBER OF FILE MARKS	
4039	060122	012704	060530'		MOV	#T34PK3,R4	; R4 = POINTER TO PACKET	
4040	060126	010465	000000		MOV	R4,TSDB(R5)	; ISSUE COMMAND	
4041	060132	012737	176750	060544'	MOV	#65000.,T34DLY	; SET UP DELAY COUNTER	
4042	060140	004737	016140'	285\$:	JSR	PC,WAITF	; WAIT FOR SSR TO SET	
4043	060144	016501	000002		MOV	TSSR(R5),R1	; GET TSSR CONTENTS	
4044	060150	032701	000200		BIT	#SSR,R1	; CHECK FOR SSR SET	
4045	060154	001017			BNE	286\$; BR, WHEN SSR IS SET	
4046	060156				DELAY	250	; WAIT ABOUT .25 SECONDS	
	060156	012727	000250				MCV	#250,(PC)+
	060162	000000					.WORD	0
	060164	013727	002116'				MOV	L\$DLY,(PC)+
	060170	000000					.WORD	0
	060172	005367	177772				DEC	-6(PC)
	060176	001375					BNE	-4
	060200	005367	177756				DEC	-22(PC)
	060204	001367					BNE	-20
4047	060206	005337	060544'		DEC	T34DLY	; BUMP COUNTER	
4048	060212	001352			BNE	285\$; BR, IF MORE TO COUNT	
4049	060214	012702	000200	286\$:	MOV	#SSR,R2	; SET UP EXPECTED	
4050	060220	020102			CMP	R1,R2	; ARE THEY EQUAL	
4051	060222	001007			BNE	290\$; BR, IT MIGHT BE END OF TAPE	
4052	060224	005303			DEC	R3	; DEC RECORD COUNTER	
4053	060226	005237	002214'		INC	FATFLG	; ERROR COUNT	
4057	060232				ERRHRD	ERRNO,T34ET,PKTSSR	; EOT NOT FOUND (USE SHORTER TAPE?)	
	060232	104456					TRAP	C\$ERHRD
	060234	001162					.WORD	626
	060236	061766'					.WORD	T34ET
	060240	011736'					.WORD	PKTSSR
4058	060242	032701	000004	290\$:	BIT	#BIT2,R1	; CHECK FOR TAPE STATUS ALERT	
4059	060246	013701	060430'		MOV	T34BFR+6,R1	; PICK UP XSTO	
4060	060252	010102			MOV	R1,R2	; SET UP EXPECTED	
4061	060254	042702	000001		BIC	#BIT0,R2	; CLEAR THE EOT BIT IN EXPECTED	
4062	060260	020102			CMP	R1,R2	; WAS THE BIT ON	
4063	060262	001406			BEQ	300\$; BR, IF EOT WAS FOUND	
4064	060264	005237	002214'		INC	FATFLG	; ERROR COUNT	
4068	060270				ERRHRD	ERRNO,T34ETC,EXPREC	; EOT BIT (XSTO) NOT CLEAR	
	060270	104456					TRAP	C\$ERHRD
	060272	001163					.WORD	627
	060274	061027'					.WORD	T34ETC
	060276	015364'					.WORD	EXPREC
4069	060300			300\$:	CKLOOP		; LOOP IF SELECTED	
	060300	104406					TRAP	C\$CLP1
4070	060302	013701	060430'		MOV	T34BFR+6,R1	; PICK UP XSTO	
4071	060306	010102			MOV	R1,R2	; SET UP EXPECTED	
4072	060310	052702	000002		BIS	#BIT1,R2	; SET THE BOT BIT ON IN EXPECTED	
4073	060314	020102			CMP	R1,R2	; WAS THE BIT ON	
4074	060316	001406			BEQ	320\$; BR, IF BOT WAS FOUND	
4075	060320	005237	002214'		INC	FATFLG	; ERROR COUNT	
4079	060324				ERRHRD	ERRNO,T34BOT,EXPREC	; EOT BIT (XSTO) NOT CLEAR	
	060324	104456					TRAP	C\$ERHRD
	060326	001164					.WORD	628
	060330	061104'					.WORD	T34BOT
	060332	015364'					.WORD	EXPREC

```

4080 060334      320$:   CKLOOP      ;LOOP IF SELECTED
      060334      104406          TRAP      C$CLP1
4081 060336      600$:
4082 060336      ENDSUB          ;>>>>>>>>>> END SUBTEST >>>>>>>>>>
      060336          L10062:
4083 060340      104403          TRAP      C$ESUB
      023727      002214' 000017    CMP      FATFLG,#15.      ;IS ERROR COUNT AT 25
4084 060346      103402          BLO      999$           ;BR, IF LESS THAN 25
4085 060350      004737      017074' JSR      PC,CKDROP     ;TRY TO DROP THE UNIT
4086 060354      999$:
4087 060354      004737      016350' JSR      PC,TSTLOOP
4088 060360      103002          BCC      163$
4089 060362      000137      055732' JMP      T34LOOP
4090 060366      163$:   EXIT      TST
      060366      104432          TRAP      C$EXIT
      060370      002672          .WORD    L10061-.

4091
4092
4093
4094
4096 060372          .BLKB    10-<.-TSV2&7>
4098 060400      T34PACKET:
4099 060400      100004          .WORD    100004      ;COMMAND PACKET FOR TEST
4100 060402      060410'        .WORD    T34DATA    ;WRITE CHARACTERISTICS COMMAND, WITH ACK
4101 060404      000000          .WORD    0           ;ADDRESS OF CHARACTERISTICS BLOCK
4102 060406      000010          .WORD    8.         ;STARTING VALUE OF BLOCK SIZE
4103 060410      T34DATA:
4104 060410      060422'        .WORD    T34BFR     ;CHARACTERISTICS DATA BLOCK
4105 060412      000000          .WORD    0           ;ADDRESS OF MESSAGE BUFFER
4106 060414      000012          .WORD    10.        ;LENGTH OF MESSAGE BUFFER
4107 060416      000000          .WORD    0
4108 060420      000000          T34DSW: .WORD    0   ;SELECT DRIVE 0
4109 060422      T34BFR: .BLKW  25. ;MESSAGE BUFFER
4110
4111
4112
4114 060504          .BLKB    10-<.-TSV2&7>
4116 060510      T34PK2:
4117 060510      100006          .WORD    100006    ;WRITE SUB SYS MEM COMMAND, AND ACK
4118 060512      060546'        .WORD    T34BF2     ;ADDRESS OF SELECT BLOCK DATA
4119 060514      000000          .WORD    0
4120 060516      000006          .WORD    6.         ;SIZE OF DATA PACKET
4121
4123 060520          .BLKB    10-<.-TSV2&7>
4125 060530      T34PK3:
4126 060530      100005          .WORD    100005    ;WRITE COMMAND, AND ACK
4127 060532      T34RB:
4128 060532      000000          T34WB: .WORD    0   ;ADDRESS OF WRITE/READ BUFFER
4129 060534      000000          .WORD    0
4130 060536      000000          T34SZ: .WORD    0   ;SIZE OF BUFFER (EXTENT)
4131
4132
4133 060540      000000          T34RSZ: .WORD    0  ;LARGEST TAPE RECORD IN BYTES
4134 060542      000000          T34CNT: .WORD    0  ;TAPE RECORD COUNTER
4135 060544      000000          T34DLY: .WORD    0  ;DELAY COUNTER
4136
4137

```



```

4138 060546          T34BF2:
4139 060546          T34BS0: .BYTE 10          ;BSELO AREA
4140 060547          T34BS1: .BYTE 200        ;BSEL1 AREA
4141 060550 000000   T34S2:  .WORD 0          ;SEL 2 AREA
4142 060552 000000   T34S3:  .WORD 0          ;DATA AREA
4143
4144
4145
4146
4147
4148 060554 100005   T34WD:  .WORD 100005     ;WRITE DATA (NEXT)
4149 060556 100405   T34WDR: .WORD 100405     ;WRITE DATA RETRY
4150 060560 102005   T34CON: .WORD 102005     ;WRITE CONTINOUS
4151 060562 177777   .WORD 177777            ;END OF DATA
4152
4153
4154
4155
4156
4157
4158
4159 060564          T34POS: .ASCIZ 'TSSR Incorrect After Position (SPACE RECORDS) Command'
4160 060562          T34ETO:  .ASCIZ 'WRITE TAPE MARK At EOT Failed To Set EOT Bit (XSTO)'
4161 060736          T34RRE: .ASCIZ 'READ Command At EOT Didn't Give Normal Termination (TSSR)'
4162 061027          T34ETC: .ASCIZ 'Unable To Clear EOT Indication, (XSTO) Bit 0'
4163 061104          T34BOT: .ASCIZ 'REWIND Failed To Set BOT (XSTO) Bit'
4164 061150          T34WTM: .ASCIZ 'WRITE TAPE MARK At EOT Failed To Set Tape Status Alert'
4165 061237          T34ET2: .ASCIZ 'WRITE DATA At EOT Failed To Set Tape Status Alert'
4166 061321          T34ETN: .ASCIZ 'WRITE DATA At EOT Failed To Set EOT Bit (XSTO)'
4167 061400          T34ETS: .ASCIZ 'SPACE RECORDS FORWARD At EOT Failed To Set EOT Bit (XSTO)'
4168 061472          T34ETZ: .ASCIZ 'READ DATA At EOT Failed To Set EOT Bit (XSTO)'
4169 061550          T34STM: .ASCIZ 'TSSR Incorrect After SKIP TAPE MARK REVERSE At EOT'
4170 061633          T34TMK: .ASCIZ 'POSITION Command At EOT Onto Tape Mark Failed To Set TMK (XSTO)'
4171 061733          T34SSR: .ASCIZ 'WRITE Command Not Accepted'
4172 061766          T34ET:  .ASCIZ 'EOT Not Found In 65000 3.5K Writes, (Use Shorter Tape)'
4173 062055          T34EOT: .ASCIZ 'WRITE DATA OVER EOT GAVE NO TAPE STATUS ALERT'
4174 062133          T34TM:  .ASCIZ 'TSSR Not Correct After WRITE Command Reject'
4175 062207          T34RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
4176 062256          T34RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
4177 062331          T34AM3: .ASCIZ 'TSSR Init. Failed After WRITE Command'
4178 062377          T34OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
4179 062452          T34WDD: .ASCIZ 'TSSR Not Correct After WRITE DATA Command, SWB Bit Set'
4180 062541          T34WDC: .ASCIZ 'TSSR Not Correct After WRITE DATA Command, Check For Tape Offline'
4181 062643          T34VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
4182 062716          T34BA:  .ASCIZ 'TSBA Not Correct After WRITE DATA Command'
4183 062770          T34WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
4184 063057          TST34ID: .ASCIZ 'Operations At EOT'
4185
4186
4187
4188
4189
4190
4191
4192
4193 063102          T34REST:
4194 063102          SAVREG          ;SAVE THE REGISTERS

```

```

4195 063106 012701 060400'      MOV      #T34PACKET,R1      ;START OF THE PACKET
4196 063112 012721 100004      MOV      #100004,(R1)      ;WRITE SUBSYSTEM MEM. WITH ACK
4197 063116 012721 060410'      MOV      #T34DATA,(R1)    ;ADDRESS OF CHARAISTICS DATA BLOCK
4198 063122 005021              CLR      (R1)              ;EXTENDED ADDRESS
4199 063124 012721 000012      MOV      #10,(R1)         ;SIZE OF DATA BLOCK IN BYTES
4200 063130 012721 060422'      MOV      #T34BFR,(R1)    ;ADDRESS OF MESSAGE BUFFER
4201 063134 005021              CLR      (R1)              ;
4202 063136 012721 000024      MOV      #20,(R1)        ;LENGTH OF MESSAGE BUFFER
4203 063142 005021              CLR      (R1)              ;
4204 063144 012711 000000      MOV      #0,(R1)         ;SELECT DRIVE ZERO
4205 063150 012702 000030      MOV      #24,R2           ;NUMBER OF LOCATIONS TO BE CLEARED
4206 063154 012762 177777 060422' 64:  MOV      #177777,T34BFR(R2) ;ALL ONES TO MESSAGE BUFFER
4207 063162 005742              TST      (R2)              ;BUMP DOWN TO NEXT LOCATION
4208 063164 020227 000000      CMP      R2,#0           ;R2 AT ZERO YET
4209 063170 001371              BNE      64:              ;KEEP GOING UNTIL DONE
4210 063172 000207              RTS      PC                ;RETURN
4211
4212

```

```

4213 063174
4214 063174
4215 063200 012701 060510'      SAVREG
4216 063204 012721 100006      MOV      #T34PK2,R1      ;SAVE THE REGISTERS
4217 063210 012721 060546'      MOV      #100006,(R1)    ;START OF THE PACKET
4218 063214 005021              MOV      #T34BF2,(R1)    ;WRITE SUBSYSTEM MEM. WITH ACK
4219 063216 012721 000006      CLR      (R1)            ;ADDRESS OF DATA BLOCK
4220 063222 012701 060546'      MOV      #6,(R1)         ;EXTENDED ADDRESS
4221 063226 005021              MOV      #T34BF2,R1      ;SIZE OF DATA BLOCK IN BYTES
4222 063230 005021              CLR      (R1)            ;POINT TO DATA SEL AREA
4223 063232 005011              CLR      (R1)            ;
4224 063234 000207              CLR      (R1)            ;
4225 063236
4226 063236
4227 063242 012701 060530'      SAVREG
4228 063246 012721 100005      MOV      #T34PK3,R1      ;SAVE THE REGISTERS
4229 063252 005021              MOV      #100005,(R1)    ;START OF THE PACKET
4230 063254 005021              CLR      (R1)            ;WRITE TAPE. WITH ACK
4231 063256 005011              CLR      (R1)            ;ADDRESS OF DATA BLOCK
4232 063260 000207              CLR      (R1)            ;EXTENDED ADDRESS
4233 063262
4234 063262 104401              RTS      PC                ;SIZE OF DATA BLOCK
4235
4236
4237
4238
4239
4240
4241
4242
4243
4244
4245
4246
4247
4248
4249

```

T34RT2:

T34RT3:

L1006: TRAP C1E1ST

.SBT'L TEST 7: EXTENDED MODE FEATURES

THIS TEST VERIFIES THE OPERATION OF COMMANDS ONLY AVAILABLE WHEN THE CONTROLLER IS IN THE EXTENDED FEATURES MODE. THESE COMMANDS ARE:

REWIND WITH IMMEDIATE INTERRUPT

IF THE CONTROLLER IS NOT ALREADY IN EXTENDED FEATURES MODE, IT IS PLACED THERE VIA A WRITE SUBSYSTEM MEMORY COMMAND.

THE TEST CONSISTS OF THE FOLLOWING 7 SUBTESTS


```

063430 011724' .WORD SFIMSG
4300 063432 013737 002174' 067260' 20: MOV UNITN,T35DSW ;SET UP DRIVE NUMBER
4301 063440 012704 067240' MOV @T35PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
4302 063444 004737 010552' JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
4303 063450 103407 BCS 25: ;BR, IF COMMAND ISSUED OK
4304 063452 005237 002214' INC FATFLG ;ERROR COUNT
4308 063456 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
4309 063460 ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
063460 104456 TRAP C1ERRHRD
063462 001276 .WORD 702
063464 005046' .WORD WRTMSG
063466 011724' .WORD SFIMSG
4310 063470 25: CKLOOP ;LOOP IF SELECTED
063470 104406 TRAP C1CLP1
4311 063472 004737 010704' JSR PC,REWIND ;CALL TAPE REWIND COMMAND
4312 063476 103411 BCS 30: ;BR, IF NO PROBLEM
4313 063500 010004 MOV R0,R4 ;SET UP REWIND PACKET ADDRESS
4314 063502 016501 000002' MOV TSSR(R5),R1 ;GET TSSR FOR PRINTOUT
4315 063506 005237 002214' INC FATFLG ;ERROR COUNT
4319 063512 ERRHRD ERRNO,T35RWN,PKTSSR ;REWIND NOT ACCEPTED
063512 104456 TRAP C1ERRHRD
063514 001277 .WORD 703
063516 070524' .WORD T35RWN
063520 011736' .WORD PKTSSR
4320 063522 30: CKLOOP ;LOOP IF SELECTED
063522 104406 TRAP C1CLP1
4321 063524 013701 067270' MOV T35BOT+6,R1 ;PICK UP XSTO
4322 063530 010102 MOV R1,R2 ;SET UP EXPECTED
4323 063532 052702 000002' BIS @BIT1,R2 ;SET BOT BIT IN EXPECTED
4324 063536 020102 CMP R1,R2 ;DOES EXP = REC'D
4325 063540 001406 BEQ 40: ;BR, IF EQUAL (OK)
4326 063542 005237 002214' INC FATFLG ;ERROR COUNT
4330 063546 ERRHRD ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
063546 104456 TRAP C1ERRHRD
063550 001300 .WORD 704
063552 070220' .WORD T35BOT
063554 015364' .WORD EXPREC
4331 063556 40: CKLOOP ;LOOP IF SELECTED
063556 104406 TRAP C1CLP1
4332 063560 012703 000024 MOV @20,R3 ;NUMBER OF RECORDS
4333 063564 012737 000400 067376' MOV @256,T35SZ ;SET UP RECORD SIZE
4334 063572 013737 003116' 067372' MOV FREE,T35WB ;ADDRESS OF WRITE BUFFER
4335
4336 ;*****
4337 ;
4338 ;WRITE DATA,ACK,CVC-1 COMMAND
4339 ;
4340 ;*****
4341
4342 063600 012737 140005 067370' MOV @140005,T35PK3 ;WRITE DATA,ACK,CVC-1 COMMAND
4343 063606 012704 067370' MOV @T35PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4344 063612 010465 000000 50: MOV R4,TSD8(R5) ;ISSUE COMMAND
4345 063616 004737 016140' JSR PC,WAITF ;WAIT FOR SSR TO SET
4346 063622 016501 000002' MOV TSSR(R5),R1 ;GET TSSR CONTENTS
4347 063626 012702 000200 MOV @SSR,R2 ;SET UP EXPECTED
4348 063632 020102 CMP R1,R2 ;ARE THEY EQUAL
4349 063634 001406 BEQ 60: ;BR, IF OK

```

```

4350 063636 005237 002214'      INC      FATFLG      ;ERROR COUNT
4354 063642      ERRSOFT ERRNO,T35WDE,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      063642 104457      TRAP      C$ERSOFT
      063644 001301      .WORD      705
      063646 070146'      .WORD      T35WDE
      063650 011736'      .WORD      PKTSSR
4355 063652      60$:  CKLOOP      ;LOOP IF SELECTED      TRAP      C$CLP1
      063652 104406
4356 063654 005303      DEC      R3      ;BUMP RECORD COUNTER
4357 063656 001355      BNE      50$      ;BR, IF MORE RRECORDS TO COUNT
4358
4359      ;*****
4360      ;
4361      ;WAIT FOR TAPE TO STOP ALL MOTION
4362      ;
4363      ;*****
4364
4365 063660 012737 000012 067422'  MOV      @10,,T35DLY      ;SET UP DELAY COUNTER
4366 063666      70$:  DELAY      250      ;WAIT ABOUT .25 SEC
      063666 012727 000250      MOV      @250,(PC)+
      063672 000000      .WORD      0
      063674 013727 002116'      MOV      L$DLY,(PC)+
      063700 000000      .WORD      0
      063702 005367 177772      DEC      -6(PC)
      063706 001375      BNE      -4
      063710 005367 177756      DEC      -22(PC)
      063714 001367      BNE      -20
4367 063716 005337 067422'      DEC      T35DLY      ;BUMP COUNTER DOWN
4368 063722 001361      BNE      70$      ;BR, IF MORE TO DELAY
4369 063724 005737 002220'      TST      EXTFEA      ;CHECK FOR EXTENDED FEATURES SW SWITCH
4370 063730 001042      BNE      110$      ;BR IF SWITCH IS ON
4371 063732 112737 000200 067401'  MOVB     @200,T_5B51      ;WRITE MISCELLANEOUS CONT/READ STATUS
4372 063740 112737 000010 067400'  MOVB     @10,T35B50
4373 063746 012704 067350'      MOV      @T35PK2,R4      ;FUNCTION SELECTION BIT (TURN ON EXTFEA HW SWITCH)
4374 063752 010465 000000      MOV      R4,T35B(R5)      ;WRITE SUBSYS MEM PACKET
4375 063756 004737 016226'      MOV      PC,CHKTSSR      ;ISSUE COMMAND
4376 063762 103407      BCS      90$      ;WAIT FOR SSR
4377 063764 010001      MOV      R0,R1      ;BR, IF NO ERROR
4378 063766 005237 002214'      INC      FATFLG      ;ERROR, SAVE TSSR
4382 063772 104456      ERRHRD  ERRNO,T35SSR,PKTSSR ;TSSR NOT CORRECT AFTER WRT. MISCELLANEOUS
      063774 001302      TRAP      C$ERHRD
      063776 072302'      .WORD      706
      064000 011736'      .WORD      T35SSR
      .WORD      PKTSSR
4383 064002      90$:  CKLOOP      ;LOOP IF SELECTED      TRAP      C$CLP1
      064002 104406
4384 064004 012704 067240'      MOV      @T35PACKET,R4      ;SUBROUTINE NEEDS PACKET ADDRESS
4385 064010 004737 010552'      JSR      PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
4386 064014 103407      BCS      100$      ;BR, IF COMMAND ISSUED OK
4387 064016 005237 002214'      INC      FATFLG      ;ERROR COUNT
4391 064022 010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
4392 064024      ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
      064024 104456      TRAP      C$ERHRD
      064026 001303      .WORD      707
      064030 005046'      .WORD      WRTMSG
      064032 011724'      .WORD      SFIMSG
4393 064034      100$: CKLOOP      ;SCOPE LOOP

```

```

4394 064034 104406
4394 064036 012737 176750 067422' 110$: MOV      #65000.,T35DLY      ;SET UP DELAY COUNTER
4395 064044 005037 067416'          CLR      T35CNT          ;DELAY COUNTER
4396
4397          ;*****
4398          ;
4399          ;REWIND IMED. INTERRUPT,ACK,CVC=1,IE=0 COMMAND
4400          ;
4401          ;*****
4402
4403 064050 012737 142012 067370'          MOV      #142012,T35PK3      ;REWIND IMED. INTERRUPT,ACK,CVC=1,IE=0 COMMAND
4404 064056 012704 067370'          MOV      #T35P<3,R4        ;SET UP R4 WITH PACKET ADDRESS
4405 064062 010465 000000          MOV      R4,T35DB(R5)      ;ISSUE COMMAND
4406 064066 016501 000002          MOV      T35R(R5),R1      ;GET T35R CONTENTS
4407 064072 032701 000200          BIT      #SSR,R1          ;CHECK FOR SSR SET
4408 064076 001021          BNE     130$              ;BR, WHEN SSR IS SET
4409 064100 005237 067416'          INC      T35CNT          ;BUMP THE CYCLE COUNTER
4410 064104          DELAY   1                ;DELAY TO KEEP COUNTER DOWN
         064104 012727 000001          MOV      #1,(PC)+
         064110 000000          .WORD   0
         064112 013727 002116'          MOV      L$DLY,(PC)+
         064116 000000          .WORD   0
         064120 005367 177772          DEC     -6(PC)
         064124 001375          BNE     -4
         064126 005367 177756          DEC     -22(PC)
         064132 001367          BNE     -20
4411 064134 005337 067422'          DEC     T35DLY            ;DROP DEAD TIMER BUMP DOWN
4412 064140 001352          BNE     120$              ;BR, IF MORE TIME TO GO
4413 064142 012702 000200          130$: MOV      #SSR,R2      ;SET UP EXPECTED
4414 064146 020102          CMP     R1,R2            ;ARE THEY EQUAL
4415 064150 001406          BEQ     140$              ;BR, IF OK
4416 064152 005237 002214'          INC     FATFLG           ;ERROR COUNT
4420 064156          ERRHRD  ERRNO,T35RWE,PKTSSR ;T35R INCORRECT AFTER WRITE DATA
         064156 104456          TRAP   C$ERRHRD
         064160 001304          .WORD   708
         064162 072650'          .WORD   T35RWE
         064164 011736'          .WORD   PKTSSR
4421 064166          140$: CKLOOP           ;LOOP IF SELECTED
         064166 104406          TRAP   C$CLP1
4422 064170 005737 002216'          TST     INTRECV          ;CHECK FOR INTERRUPTS
4423 064174 001410          BEQ     150$              ;BR, IF NO INTERRUPTS DETECTED
4424 064176 016501 000002          MOV     T35R(R5),R1      ;GET T35R STATUS FOR PRINTOUT
4425 064202 005237 002214'          INC     FATFLG           ;ERROR COUNT
4429 064206          ERRHRD  ERRNO,T35INT,PKTSSR ;INTERRUPT RECEIVED (BAD)
         064206 104456          TRAP   C$ERRHRD
         064210 001305          .WORD   709
         064212 072461'          .WORD   T35INT
         064214 011736'          .WORD   PKTSSR
4430 064216          150$: CKLOOP           ;LOOP IF SELECTED
         064216 104406          TRAP   C$CLP1
4431
4432          ;*****
4433          ;
4434          ;NOW CHECK FOR THE MOTION BITS SET
4435          ;
4436          ;*****
4437

```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 7: EXTENDED MODE FEATURES

SEQ 175

4438	064220	013701	067270'	MOV	T35BFR+6,R1	;PICK UP XST0		
4439	064224	010102		MOV	R1,R2	;SET UP EXPECTED		
4440	064226	052702	000200	BIS	#BIT7,R2	;SET MOT BIT IN EXPECTED		
4441	064232	020102		CMP	R1,R2	;DOES EXP = REC'D		
4442	064234	001406		BEQ	160\$;BR, IF EQUAL (OK)		
4443	064236	005237	002214'	INC	FATFLG	;ERROR COUNT		
4447	064242			ERRHRD	ERRNO,T35MOT,EXPREC	;TAPE NOT AT BOT AFTER REWIND		
	064242	104456				TRAP	C\$ERHRD	
	064244	001306				.WORD	710	
	064246	072363'				.WORD	T35MOT	
	064250	015364'				.WORD	EXPREC	
4448	064252			160\$:	CKLOOP	;LOOP IF SELECTED		
	064252	104406				TRAP	C\$CLP1	
4449	064254	013701	067274'	MOV	T35BFR+12,R1	;PICK UP XST2		
4450	064260	010102		MOV	R1,R2	;SET UP EXPECTED		
4451	064262	052702	100000	BIS	#BIT15,R2	;SET OPM BIT IN EXPECTED		
4452	064266	020102		CMP	R1,R2	;DOES EXP = REC'D		
4453	064270	001406		REQ	170\$;BR, IF EQUAL (OK)		
4454	064272	005237	002214'	INC	FATFLG	;ERROR COUNT		
4458	064276			ERRHRD	ERRNO,T35OPM,EXPREC	;OPM BIT NOT SET		
	064276	104456				TRAP	C\$ERHRD	
	064300	001307				.WORD	711	
	064302	072552'				.WORD	T35OPM	
	064304	015364'				.WORD	EXPREC	
4459	064306			170\$:	CKLOOP	;LOOP IF SELECTED		
	064306	104406				TRAP	C\$CLP1	
4460	064310	012737	000027 067422'	MOV	#23,,T35DLY	;SET UP DELAY COUNTER		
4461	064316			175\$:	DELAY 250	;START DELAY		
	064316	012727	000250			MOV	#250,(PC)+	
	064322	000000				.WORD	0	
	064324	013727	002116'			MOV	L\$DLY,(PC)+	
	064330	000000				.WORD	0	
	064332	005367	177772			DEC	-6(PC)	
	064336	001375				BNE	.-4	
	064340	005367	177756			DEC	-22(PC)	
	064344	001367				BNE	.-20	
4462	064346	005337	067422'	DEC	T35DLY	;BUMP DELAY COUNTER		
4463	064352	001361		BNE	175\$;BR, IF MORE DELAY		
4464	064354			ENDSUB				
	064354						L10064:	
	064354	104403				TRAP	C\$ESUB	
4465	064356	023727	002214' 000017	CMP	FATFLG,#15,	;IS ERROR COUNT AT 25		
4466	064364	103402		BLO	999\$;BR, IF LESS THAN 25		
4467	064366	004737	017074'	JSR	PC,CKDROP	;TRY TO DROP THE UNIT		
4468	064372			999\$:				
4469								
4470								
4471								
4472								
4473								
4474								
4475								
4476								
4477								
4478								
4479								
4480								

TEST 7: SUBTEST 2

WITH THE INTERRUPT ENABLE (IE) BIT SET (1), CAUSES ALMOST IMMEDIATE TERMINATION AND AN INTERRUPT. STATUS IN THE MESSAGE BUFFER IS CHECKED TO VERIFY IF THE MOTION (MOT) AND OPERATION IN PROGRESS (OPM) STATUS BITS ARE BOTH SET.

```

4481 ;
4482 ;
4483 ;
4484 ;
4485 ;
4486 064372          ; BGNSUB                  ; >>>>>>>>>>>>>>>> BEGIN SUBTEST >>>>>>>>>>>>
      064372          ;                          ; T7.2:
      064372 104402          ; TRAP          C$BSUB
4487 064374          ; SETPRI @PRI00        ; ENABLE INTERRUPTS.
      064374 012700 000000          ; MOV          @PRI00,R0
      064400 104441          ; TRAP          C$SPRI
4488 064402 004737 073044'         ; JSR          PC,T35REST      ; SET COMMAND PACKET
4489 064406 005037 002216'         ; CLR          INTRECV        ; CLEAR INTERRUPT RECEIVED FLAG
4490 064412 004737 073136'         ; JSR          PC,T35RT2      ; SET UP OTHER COMMAND PACKET
4491 064416 004737 073200'         ; JSR          PC,T35RT3      ; SET UP OTHER COMMAND PACKET
4492 064422 012737 176750 067422'   ; MOV          @5000.,T35DLY  ; SET UP DELAY COUNTER
4493 064430 005037 067416'         ; CLR          T35CNT        ; CLEAR COUNTER
4494 064434 004737 015664'         ; JSR          PC,SOFINIT     ; DO INITIALIZE ON CONTROLLER
4495 064440 103426          ; BCS         20$           ; BR IF INIT WAS OK
4496 064442          ; DELAY        250         ; DELAY ABOUT .25 SEC
      064442 012727 000250          ; MOV          @250,(PC)+
      064446 000000          ; .WORD        0
      064450 013727 002116'         ; MOV          L$DLY,(PC)+
      064454 000000          ; .WORD        0
      064456 005367 177772          ; DEC          -6(PC)
      064462 001375          ; BNE          -4
      064464 005367 177756          ; DEC          -22(PC)
      064470 001367          ; BNE          -20
4497 064472 005337 067422'         ; DEC          T35DLY        ; BUMP COUNTER
4498 064476 001356          ; BNE          10$           ; BR, IF COUNTER NOT DONE
4499 064500 005237 002214'         ; INC          FATFLG        ; ERROR COUNT
4503 064504 010001          ; MOV          R0,R1         ; CONTENTS OF TSSR REGISTER
4504 064506          ; ERRDF        ERRNO,SFIERR,SFIMSG ; FATAL ERROR TSSR WAS NOT OK
      064506 104455          ; TRAP          C$ERDF
      064510 001310          ; .WORD        712
      064512 003642'         ; .WORD        SFIERR
      064514 011724'         ; .WORD        SFIMSG
4505 064516 013737 002174' 067260' 20$ ; MOV          UNITN,T35DSW   ; SET UP DRIVE NUMBER
4506 064524 012704 067240'         ; MOV          @T35PACKET,R4 ; SUBROUTINE NEEDS PACKET ADDRESS
4507 064530 004737 010552'         ; JSR          PC,WRTCHR     ; ISSUE WRITE CHARACTERISTICS
4508 064534 103407          ; BCS         25$           ; BR, IF COMMAND ISSUED OK
4509 064536 005237 002214'         ; INC          FATFLG        ; ERROR COUNT
4513 064542 010001          ; MOV          R0,R1         ; SAVE CONTENTS OF TSSR
4514 064544          ; ERRHRD       ERRNO,WRTMSG,SFIMSG ; WRITE CHARACTERISTICS FAILED
      064544 104456          ; TRAP          C$ERHRD
      064546 001311          ; .WORD        713
      064550 005046'         ; .WORD        WRTMSG
      064552 011724'         ; .WORD        SFIMSG
4515 064554          ; CKLOOP              ; LOOP IF SELECTED
      064554 104406          ; TRAP          C$CLP1
4516 064556 004737 010704'         ; JSR          PC,REWIND     ; CALL TAPE REWIND COMMAND
4517 064562 103411          ; BCS         30$           ; BR, IF NO PROBLEM
4518 064564 010004          ; MOV          R0,R4         ; SET UP REWIND PACKET ADDRESS
4519 064566 016501 000002          ; MOV          TSSR(R5),R1   ; GET TSSR CONTENTS
4520 064572 005237 002214'         ; INC          FATFLG        ; ERROR COUNT
4524 064576          ; ERRHRD       ERRNO,T35RWN,PKTSSR ; REWIND NOT ACCEPTED
      064576 104456          ; TRAP          C$ERHRD
    
```



```

064600 001312                                .WORD 714
064602 070524'                               .WORD T35RWN
064604 011736'                               .WORD PKTSSR
4525 064606 30$: CKLOOP                       ;LOOP IF SELECTED
064606 104406                                TRAP C$CLP1
4526 064610 013701 067270'                   MOV T35BFR+6,R1 ;PICK UP XSTC
4527 064614 010102                             MOV R1,R2 ;SET UP EXPECTED
4528 064616 052702 000002                     BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
4529 064622 020102                             CMP R1,R2 ;DOES EXP = REC'D
4530 064624 001406                             BEQ 40$ ;BR, IF EQUAL (OK)
4531 064626 005237 002214'                   INC FATFLG ;ERROR COUNT
4535 064632 ERRHRD ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
064632 104456                                TRAP C$ERHRD
064634 001313                                .WORD 715
064636 070220'                               .WORD T35BOT
064640 015364'                               .WORD EXPREC
4536 064642 40$: CKLOOP                       ;LOOP IF SELECTED
064642 104406                                TRAP C$CLP1
4537 064644 012703 000024                     MOV #20.,R3 ;NUMBER OF RECORDS
4538 064650 012737 000400 067376'           MOV #256.,T35SZ ;SET UP RECORD SIZE
4539 064656 013737 003116' 067372'         MOV FREE,T35WB ;ADDRESS OF WRITE BUFFER
4540
4541 ;*****
4542 ;
4543 ;WRITE DATA,ACK,CVC=1 COMMAND
4544 ;
4545 ;*****
4546
4547 064664 012737 140005 067370'           MOV #140005,T35PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
4548 064672 012704 067370'                   MOV #T35PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4549 064676 010465 000000 50$: MOV R4,T50B(R5) ;ISSUE COMMAND
4550 064702 004737 016140'                   JSR PC,WAITF ;WAIT FOR SSR TO SET
4551 064706 016501 000002                     MOV TSSR(R5),R1 ;GET TSSR CONTENTS
4552 064712 012702 000200                     MOV #SSR,R2 ;SET UP EXPECTED
4553 064716 020102                             CMP R1,R2 ;ARE THEY EQUAL
4554 064720 001406                             BEQ 60$ ;BR, IF OK
4555 064722 005237 002214'                   INC FATFLG ;ERROR COUNT
4559 064726 ERRHRD ERRNO,T35WDE,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
064726 104456                                TRAP C$ERHRD
064730 001314                                .WORD 716
064732 070146'                               .WORD T35WDE
064734 011736'                               .WORD PKTSSR
4560 064736 60$: CKLOOP                       ;LOOP IF SELECTED
064736 104406                                TRAP C$CLP1
4561
4562 ;*****
4563 ;
4564 ;WAIT FOR TAPE TO STOP ALL MOTION
4565 ;
4566 ;*****
4567
4568 064740 012737 000012 067422'           MOV #10.,T35DLY ;SET UP DELAY COUNTER
4569 064746 012727 000250 70$: DELAY 250 ;WAIT ABOUT .25 SEC
064746 012727 000250
064752 000000
064754 013727 002116'
064760 000000
MOV #250,(PC),
.WORD 0
MOV L$DLY,(PC),
.WORD 0
    
```

```

064762 005367 177772          DEC      -6(PC)
064766 001375          BNE      -4
064770 005367 177756          DEC     -22(PC)
064774 001367          BNE      -20
4570 064776 005337 067422'    DEC      T35DLY      ;BUMP COUNTER DOWN
4571 065002 001361          BNE      70$        ;BR, IF MORE TO DELAY
4572 065004 005737 002220'    TST      EXTFEA     ;CHECK FOR EXTENDED FEATURES SW SWITCH
4573 065010 001042          BNE      110$       ;BR IF SWITCH IS ON
4574 065012 112737 000200 067401'  MOVB     #200,T35BS1 ;WRITE MISCELLANEOUS CONT/READ STATUS
4575 065020 112737 000010 067400'  MOVB     #10,T35BS0 ;FUNCTION SELECTION BIT (TURN ON EXTFEA HW SWITCH)
4576 065026 012704 067350'    MOV      #T35PK2,R4 ;WRITE SUBSYS MEM PACKET
4577 065032 010465 000000          MOV      R4,TSDB(R5) ;ISSUE COMMAND
4578 065036 004737 016226'    JSR      PC,CHKTSSR ;WAIT FOR SSR
4579 065042 103407          BCS     90$        ;BR, IF NO ERROR
4580 065044 010001          MOV      R0,R1     ;ERROR, SAVE TSSR
4581 065046 005237 002214'    INC      FATFLG    ;ERROR COUNT
4585 065052          ERRHRD  ERRNO,T35SSR,PKTSSR ;TSSR NOT CORRECT AFTER WRT. MISCELLANEOUS
065052 104456          TRAP    C$ERHRD
065054 001315          .WORD  717
065056 072302'        .WORD  T35SSR
065060 011736'        .WORD  PKTSSR
4586 065062          90$:   CKLOOP      ;LOOP IF SELECTED
065062 104406          TRAP    C$CLP1
4587 065064 012704 067240'    MOV      #T35PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
4588 065070 004737 010552'    JSR      PC,WRTCHR  ;ISSUE WRITE CHARACTERISTICS
4589 065074 103407          BCS     100$       ;BR, IF COMMAND ISSUED OK
4590 065076 005237 002214'    INC      FATFLG    ;ERROR COUNT
4594 065102 010001          MOV      R0,R1     ;SAVE CONTENTS OF TSSR
4595 065104          ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
065104 104456          TRAP    C$ERHRD
065106 001316          .WORD  718
065110 005046'        .WORD  WRTMSG
065112 011724'        .WORD  SFIMSG
4596 065114          100$: CKLOOP      ;SCOPE LOOP
065114 104406          TRAP    C$CLP1
4597 065116 012737 176750 067422' 110$:  MOV      #065000.,T35DLY ;SET UP DELAY COUNTER
4598 065124 005037 067416'    CLR      T35CNT    ;DELAY COUNTER
4600          ;*****
4601          ;
4602          ;REWIND IMMEDIATE,ACK,CVC=1,IE=1 COMMAND
4603          ;
4604          ;*****
4605          ;*****
4606 065130 012737 142212 067370'    MOV      #142212,T35PK3 ;REWIND IMMEDIATE,ACK,CVC=1,IE=1 COMMAND
4607 065136 012704 067370'    MOV      #T35PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4608 065142 010465 000000          MOV      R4,TSDB(R5) ;ISSUE COMMAND
4609 065146 016501 000002          120$: MOV      TSSR(R5),R1 ;GET TSSR CONTENTS
4610 065152 032701 000200          BIT      #SSR,R1   ;CHECK FOR SSR SET
4611 065156 001021          BNE     130$       ;BR, WHEN SSR IS SET
4612 065160 005237 067416'    INC      T35CNT    ;BUMP THE CYCLE COUNTER
4613 065164          DELAY   1        ;DELAY TO KEEP COUNTER DOWN
065164 012727 000001          MOV      #1,(PC).
065170 000000          .WORD  0
065172 013727 002116'    MOV      L$DLY,(PC).
065176 000000          .WORD  0
065200 005367 177772          DEC     -6(PC)

```

```

065204 001375
065206 005367 177756
065212 001367
4614 065214 005337 067422'
4615 065220 001352
4616 065222 012702 000200
4617 065226 020102
4618 065230 001406
4619 065232 005237 002214'
4623 065236
065236 104456
065240 001317
065242 072650'
065244 011736'
4624 065246
065246 104406
4625 065250 005737 002216'
4626 065254 001010
4627 065256 016501 000002
4628 065262 005237 002214'
4632 065266
065266 104456
065270 001320
065272 072736'
065274 011736'
4633 065276
065276 104406
4634
4635
4636
4637
4638
4639
4640
4641 065300 013701 067270'
4642 065304 010102
4643 065306 052702 000200
4644 065312 020102
4645 065314 001406
4646 065316 005237 002214'
4650 065322
065322 104456
065324 001321
065326 072363'
065330 015364'
4651 065332
065332 104406
4652 065334 013701 067274'
4653 065340 010102
4654 065342 052702 100000
4655 065346 020102
4656 065350 001406
4657 065352 005237 002214'
4661 065356
065356 104456
065360 001322
065362 072552'

;*****
;
;NOW CHECK FOR THE MOTION BITS SET
;
;*****

MOV T35BFR+6,R1 ;PICK UP XST0
MOV R1,R2 ;SET UP EXPECTED
BIS #BIT7,R2 ;SET MOT BIT IN EXPECTED
CMP R1,R2 ;DOES EXP = REC'D
BEQ 160$ ;BR, IF EQUAL (OK)
INC FATFLG ;ERROR COUNT
ERRHRD ERRNO,T35MOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
TRAP C$ERHRD
WORD 721
WORD T35MOT
WORD EXPREC

160$: CKLOOP ;LOOP IF SELECTED
TRAP C$CLP1

MOV T35BFR+12,R1 ;PICK UP XST2
MOV R1,R2 ;SET UP EXPECTED
BIS #BIT15,R2 ;SET OPM BIT IN EXPECTED
CMP R1,R2 ;DOES EXP = REC'D
BEQ 170$ ;BR, IF EQUAL (OK)
INC FATFLG ;ERROR COUNT
ERRHRD ERRNO,T35OPM,EXPREC ;OPM BIT NOT SET
TRAP C$ERHRD
WORD 722
WORD T35OPM

BNE -4
DEC -22(PC)
BNE -20

```

4662	065364	015364'		170\$:	CKLOOP		;LOOP IF SELECTED	.WORD	EXPREC
	065366	104406						TRAP	C\$CLP1
4663	065370	012737	000027	067422'	MOV	#23.,T35DLY	;SET UP DELAY COUNTER		
4664	065376			175\$:	DELAY	250	;START DELAY		
	065376	012727	000250					MOV	#250,(PC)+
	065402	000000						.WORD	0
	065404	013727	002116'					MOV	L\$DLY,(PC)+
	065410	000000						.WORD	0
	065412	005367	177772					DEC	-6(PC)
	065416	001375						BNE	.-4
	065420	005367	177756					DEC	-22(PC)
	065424	001367						BNE	.-20
4665	065426	005337	067422'		DEC	T35DLY	;BUMP DELAY COUNTER		
4666	065432	001361			BNE	175\$;BR, IF MORE DELAY		
4667	065434				ENDSUB				
	065434							L10065:	
4668	065436	104403						TRAP	C\$ESUB
4668	065436	023727	002214'	000017	CMP	FATFLG,#15.	;IS ERROR COUNT AT 25		
4669	065444	103402			BLO	999\$;BR, IF LESS THAN 25		
4670	065446	004737	017074'		JSR	PC,CKDROP	;TRY TO DROP THE UNIT		
4671	065452			999\$:					
4672									
4673									
4674									
4675									
4676									
4677									
4678									
4679									
4680									
4681									
4682									
4683									
4684									
4685									
4686									
4687									
4688									
4689									
4690									
4691									
4692									
4693	065452				BGNSUB		; >>>>>>>>>> BEGIN SUBTEST >>>>>>>>>>>>>		
	065452						T7.3:		
4694	065452	104402						TRAP	C\$BSUB
4694	065454	004737	073044'		JSR	PC,T35REST	;SET COMMAND PACKET		
4695	065460	004737	073136'		JSR	PC,T35RT2	;SET UP OTHER COMMAND PACKET		
4696	065464	004737	073200'		JSR	PC,T35RT3	;SET UP OTHER COMMAND PACKET		
4697	065470	004737	015664'		JSR	PC,SOFINIT	;DO INITIALIZE ON CONTROLLER		
4698	065474	103407			BCS	20\$;BR IF INIT WAS OK		
4699	065476	005237	002214'		INC	FATFLG	;ERROR COUNT		
4703	065502	010001			MOV	R0,R1	;CONTENTS OF TSSR REGISTER		
4704	065504				ERRDF	ERRNO,SFIERR,SFIMSG	;FATAL ERROR TSSR WAS NOT OK		
	065504	104455						TRAP	C\$ERDF
	065506	001323						.WORD	723
	065510	003642'						.WORD	SFIERR

TEST 7, SUBTEST 3

VERIFIES THAT THE NON-TAPE-MOTION COMMAND GET STATUS, ISSUED IMMEDIATELY AFTER TERMINATION OF A REWIND WITH IMMEDIATE INTERRUPT COMMAND, TERMINATES PROPERLY AND PROVIDES PROPER STATUS. FIRST, A NUMBER OF DATA RECORDS ARE WRITTEN FROM BOT. THEN THE REWIND WITH IMMEDIATE INTERRUPT COMMAND IS ISSUED AND TERMINATION VERIFIED. THEN THE GET STATUS COMMAND IS ISSUED. THE GET STATUS SHOULD TERMINATE ALMOST IMMEDIATELY AND SHOW MOT=1 AND OPM=1 IN THE MESSAGE BUFFER. AFTER A DELAY LONG ENOUGH TO ALLOW THE REWIND TO COMPLETE AND THE TAPE COME TO REST, GET STATUS IS AGAIN ISSUED AND THE STATUS CHECKED; BOTH MOT AND OPM SHOULD BE CLEAR.

```

4705 065512 011724' 002174' 067260' 20$: MOV UNITN,T35DSW ;SET UP UNIT NUMBER IN PACKET .WORD SFIMSG
4706 065522 012704 067240' MOV #T35PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
4707 065526 004737 010552' JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
4708 065532 103407 BCS 23$ ;BR, IF COMMAND ISSUED OK
4709 065534 005237 002214' INC FATFLG ;ERROR COUNT
4713 065540 010001 MCV R0,R1 ;SAVE CONTENTS OF TSSR
4714 065542 ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
      065542 104456 TRAP C$ERHRD
      065544 001324 .WORD 724
      065546 005046' .WORD WRTMSG
      065550 011724' .WORD SFIMSG
4715 065552 23$: CKLOOP ;LOOP IF SELECTED
      065552 104406 TRAP C$CLP1
4716 065554 004737 010704' JSR PC,REWIND ;CALL TAPE REWIND COMMAND
4717 065560 103411 BCS 30$ ;BR, IF NO PROBLEM
4718 065562 010004 MOV R0,R4 ;SET UP REWIND PACKET ADDRESS
4719 065564 016501 000002 MOV TSSR(R5),R1 ;GET CONTENTS FOR CALL
4720 065570 005237 002214' INC FATFLG ;ERROR COUNT
4724 065574 ERRHRD ERRNO,T35RWN,PKTSSR ;REWIND NOT ACCEPTED
      065574 104456 TRAP C$ERHRD
      065576 001325 .WORD 725
      065600 070524' .WORD T35RWN
      065602 011736' .WORD PKTSSR
4725 065604 30$: CKLOOP ;LOOP IF SELECTED
      065604 104406 TRAP C$CLP1
4726 065606 013701 067270' MOV T35BFR+6,R1 ;PICK UP XSTO
4727 065612 010102 MOV R1,R2 ;SET UP EXPECTED
4728 065614 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
4729 065620 020102 CMP R1,R2 ;DOES EXP = REC'D
4730 065622 001406 BEQ 40$ ;BR, IF EQUAL (OK)
4731 065624 005237 002214' INC FATFLG ;ERROR COUNT
4735 065630 ERRHRD ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      065630 104456 TRAP C$ERHRD
      065632 001326 .WORD 726
      065634 070220' .WORD T35BOT
      065636 015364' .WORD EXPREC
4736 065640 40$: CKLOOP ;LOOP IF SELECTED
      065640 104406 TRAP C$CLP1
4737 065642 012703 000024 MOV #20.,R3 ;STARTING RECORD SIZE
4738 065646 013737 003116' 067372' MOV FREE,T35WB ;STARTING WRITE BUFFER ADDRESS
4739
4740 ;*****
4741 ;
4742 ;WRITE DATA,CVC=1,ACK COMMAND
4743 ;
4744 ;*****
4745
4746 065654 012737 140005 067370' 65$: MOV #140005,T35PK3 ;WRITE DATA,CVC=1,ACK COMMAND
4747 065662 012704 067370' MOV #T35PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4748 065666 010300 MOV R3,R0 ;SET PATTERN IN CORRECT REGISTER
4749 065670 004737 017314' JSR PC,FILLMEM ;FILL MEMORY WITH RECORD SIZE
4750 065674 010337 067376' MOV R3,T35SZ ;SET UP RECORD SIZE IN PACKET
4751 065700 010465 000000 MOV R4,T35DB(R5) ;ISSUE COMMAND
4752 065704 004737 016140' JSR PC,WAITF ;WAIT FOR SSR TO SET
4753 065710 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
4754 065714 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
    
```

```

4755 065720 020102          CMP      R1,R2          ;ARE THEY EQUAL
4756 065722 001406          BEQ      80$           ;BR, IF OK
4757 065724 005237 002214'  INC      FATFLG        ;ERROR COUNT
4761 065730          ERRHRD  ERRNO,T35WDC,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP      C$ERHRD
                                .WORD    727
                                .WORD    T35WDC
                                .WORD    PKTSSR
                                TRAP      C$CLP1
                                .WORD    104456
                                .WORD    001327
                                .WORD    071060'
                                .WORD    011736'
4762 065740          80$:   CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD    104406
4763
4764          ;*****
4765          ;
4766          ;WRITE DATA RETRY,CVC=1,ACK COMMAND
4767          ;
4768          ;*****
4769
4770 065742 012737 141005 067370'  MOV      :141005,T35PK3 ;WRITE DATA RETRY,CVC=1,ACK COMMAND
4771 065750 010465 000000          MOV      R4,;SDB(R5)    ;ISSUE COMMAND
4772 065754 004737 016140'  JSR      PC,WAITF      ;WAIT FOR SSR TO SET
4773 065760 016501 000002          MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
4774 065764 012702 000200          MOV      *SSR,R2       ;SET UP EXPECTED
4775 065770 020102          CMP      R1,R2         ;ARE THEY EQUAL
4776 065772 001406          BEQ      90$           ;BR, IF OK
4777 065774 005237 002214'  INC      FATFLG        ;ERROR COUNT
4781 066000          ERRHRD  ERRNO,T35WRF,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA RETRY
                                TRAP      C$ERHRD
                                .WORD    728
                                .WORD    T35WRF
                                .WORD    PKTSSR
                                TRAP      C$CLP1
                                .WORD    104456
                                .WORD    001330
                                .WORD    072125'
                                .WORD    011736'
4782 066010          90$:   CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD    104406
4783 066012 005723          TST      (R3)+         ;BUMP RECORD SIZE COUNTER
4784 066014 020327 000052          CMP      R3,#42       ;AT 42 SIZE YET
4785 066020 001315          BNE      65$           ;BR, IF MORE RECORDS TO WRITE
4786 066022 004737 010704'  JSR      PC,REWIND     ;CALL TAPE REWIND COMMAND
4787 066026 103411          BCS     230$          ;BR, IF NO PROBLEM
4788 066030 010001          MOV      R0,R1        ;SAVE TSSR
4789 066032 016501 000002          MOV      TSSR(R5),R1  ;GET TSSR CONTENTS
4790 066036 005237 002214'  INC      FATFLG        ;ERROR COUNT
4794 066042          ERRHRD  ERRNO,T35RWN,EXPREC ;REWIND NOT ACCEPTED
                                TRAP      C$ERHRD
                                .WORD    729
                                .WORD    T35RWN
                                .WORD    EXPREC
                                TRAP      C$CLP1
                                .WORD    104456
                                .WORD    001331
                                .WORD    070524'
                                .WORD    015364'
4795 066052          230$:  CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD    104406
4796 066054 013701 067270'  MOV      T35BFR+6,R1   ;PICK UP XSTO
4797 066060 010102          MOV      R1,R2        ;SET UP EXPECTED
4798 066062 052702 000002          BIS     *BIT1,R2      ;SET BOT BIT IN EXPECTED
4799 066066 020102          CMP      R1,R2        ;DOES EXP = REC'D
4800 066070 001406          BEQ     240$          ;BR, IF EQUAL (OK)
4801 066072 005237 002214'  INC      FATFLG        ;ERROR COUNT
4805 066076          ERRHRD  ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C$ERHRD
                                .WORD    730
                                .WORD    T35BOT
                                .WORD    104456
                                .WORD    001332
                                .WORD    070220'
    
```

B15

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
TEST 7: EXTENDED MODE FEATURES

SEQ 183

```

066104 015364'
4806 066106 2401: CKLOOP ;LOOP IF SELECTED .WORD EXPREC
      066106 104406 ; TRAP C1CLP1
4807 066110 012703 000024 MOV #20,R3 ;STARTING RECORD SIZE
4808 066114 013737 003116' 067372' MOV FREE,T35RB ;STARTING READ BUFFER ADDRESS
4809
4810 ;*****
4811 ;
4812 ;READ DATA,ACK COMMAND
4813 ;
4814 ;*****
4815
4816 066122 012737 100601 067370' 2651: MOV #100001,T35PK3 ;READ DATA,ACK COMMAND
4817 066130 012704 067370' MOV #T35PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4818 066134 012700 177777 MOV #177777,R0 ;SET PATTERN IN CORRECT REGISTER
4819 066140 004737 017314' JSR PC,FILLMEM ;FILL MEMORY WITH RECORD SIZE
4820 066144 010337 067376' MOV R3,T35SZ ;SET UP RECORD SIZE IN PACKET
4821 066150 010465 000000 MOV R4,T35DB(R5) ;ISSUE COMMAND
4822 066154 004737 016140' JSR PC,WAITF ;WAIT FOR SSR TO SET
4823 066160 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
4824 066164 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED
4825 066170 020102 CMP R1,R2 ;ARE THEY EQUAL
4826 066172 001406 BEQ 2801 ;BR, IF OK
4827 066174 005237 002214' INC FATFLG ;ERROR COUNT
4831 066200 ERRHRD ERRNO,T35RDF,PKTSSR ;TSSR INCORRECT AFTER READ DATA
      066200 104456 TRAP C1ERHRD
      066202 001333 .WORD 731
      066204 067512' .WORD T35RDF
      066206 011736' .WORD PKTSSR
4832 066210 2801: CKLOOP ;LOOP IF SELECTED .WORD EXPREC
      066210 104406 ; TRAP C1CLP1
4833 066212 013702 003116' MOV FREE,R2 ;GET BUFFER ADDRESS
4834 066216 010304 MOV R3,R4 ;GET RECORD SIZE
4835 066220 162704 000024 SUB #20,R4 ;POINT BACK TO 1ST RECORD
4836 066224 060204 2851: ADD R2,R4 ;POINT TO 1ST LOC IN BUFFER
4837 066226 021403 CMP (R4),R3 ;DATA WRITTEN - READ
4838 066230 001410 BEQ 2901 ;BR, IF DATA OK (GOOD)
4839 066232 011401 MOV (R4),R1 ;PICK UP BAD DATA
4840 066234 010302 MOV R3,R2 ;SET UP EXPECTED
4841 066236 005237 002214' INC FATFLG ;ERROR COUNT
4845 066242 ERRHRD ERRNO,T35DTA,EXPREC ;DATA IN BUFFER NOT CORRECT
      066242 104456 TRAP C1ERHRD
      066244 001334 .WORD 732
      066246 072205' .WORD T35DTA
      066250 015364' .WORD EXPREC
4846 066252 2901: CKLOOP ;LOOP IF SELECTED .WORD EXPREC
      066252 104406 ; TRAP C1CLP1
4847 066254 005724 TST (R4), ;BUMP TO NEXT ADDRESS
1848 066256 160204 SUB R2,R4 ;BACK TO RECORD SIZE
4849 066260 020403 CMP R4,R3 ;AT END OF RECORD YET
4850 066262 001360 BNE 2851 ;BR, IF MORE DATA TO CHECK
4851 066264 005725 TST (R5), ;BUMP RECORD SIZE
4852 066266 020327 000050 CMP R3,#40, ;DONE YET
4853 066272 001313 DNE 2651 ;BR, IF NOT DONE YET (MORE READS)
4854 066274 3001: CKLOOP ;LOOP IF SELECTED .WORD EXPREC
      066274 104406 ; TRAP C1CLP1
4855 066276 3301:

```

```

4856 066276          ENDSUB          ;>>>>>>>>>>>>>>> END SUBTEST >>>>>>>>>>>>>>>
      066276          ;>>>>>>>>>>>>>>> L10066;
      066276 104403          TRAP      C1ESUB
4857 066300 023727 002214' 000017    CMP      FATFLG,015,          ;IS ERROR COUNT AT 25
4858 066306 103402          BLO      999$              ;BR. IF LESS THAN 25
4859 066310 004737 017074'          JSR      PC,CKDROP          ;TRY TO DROP THE UNIT
4860 066314          999$;
4861
4862
4863
4864          ;
4865          ;TEST 7, SUBTEST 4
4866          ;
4867          ;   VERIFIES THAT A TAPE-MOTION COMMAND (READ, WRITE, POSITION),
4868          ;   ISSUED IMMEDIATELY AFTER TERMINATION OF A REWIND WITH
4869          ;   IMMEDIATE INTERRUPT COMMAND, IS "QUEUED" BY THE CONTROLLER AND
4870          ;   THEN EXECUTES PROPERLY.
4871          ;
4872          ;
4873          ;
4874 066314          BGNSUB          ;>>>>>>>>>>>>>>> BEGIN SUBTEST >>>>>>>>>>>>>>>
      066314          ;>>>>>>>>>>>>>>> T7.4;
      066314 104402          TRAP      C1BSUB
4875 066316 004737 075044'          JSR      PC,T35REST          ;SET COMMAND PACKET
4876 066322 004737 073136'          JSR      PC,T35RT2          ;SET UP OTHER COMMAND PACKET
4877 066326 004737 073200'          JSR      PC,T35RT3          ;SET UP OTHER COMMAND PACKET
4878 066332 012737 176750' 067422'  MOV      #65000.,T35DLY      ;SET UP DELAY COUNTER
4879 066340 004737 015164'          JSR      PC,SOFINIT          ;DO INITIALIZE ON CONTROLLER
4880 066344 103426          BCS      20$              ;BR IF INIT WAS OK
4881 066346          DELAY      250          ;DELAY ABOUT .25 SEC
      066346 012727 000250          MOV      #250,(PC);
      066352 000000          .WORD      0
      066354 013727 002116'          MOV      L#DLY,(PC);
      066360 000000          .WORD      0
      066362 005367 177772          DEC      -6(PC)
      066366 001375          BNE      -4
      066370 005367 177756          DEC      -22(PC)
      066374 001367          BNE      -20
4882 066376 005337 067422'          DEC      T35DLY          ;BUMP COUNTER
4883 066402 001356          BNE      10$              ;BR. IF COUNTER NOT DONE
4884 066404 005237 002214'          INC      FATFLG          ;ERROR COUNT
4888 066410 010001          MOV      R0,R1          ;CONTENTS OF TSSR REGISTER
4889 066412          ERRDF      ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
      066412 104455          TRAP      C1ERDF
      066414 001335          .WORD      733
      066416 003642'          .WORD      SFIERR
      066420 011724'          .WORD      SFIMSG
4890 066422 013737 002174' 067260' 20$; MOV      UNITN,T35DSW          ;SET UP UNIT (DRIVE) NUMBER
4891 066430 012704 067240'          MOV      #T35PACKET,R4      ;SUBROUTINE NEEDS PACKET ADDRESS
4892 066434 004737 010552'          JSR      PC,WRTCHR          ;ISSUE WRITE CHARACTERISTICS
4893 066440 103407          BCS      23$              ;BR. IF COMMAND ISSUED OK
4894 066442 005237 002214'          INC      FATFLG          ;ERROR COUNT
4898 066446 010001          MOV      R0,R1          ;SAVE CONTENTS OF TSSR
4899 066450          ERRHRD      ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
      066450 104456          TRAP      C1ERHRD
      066452 001336          .WORD      734
      066454 005046'          .WORD      WRTMSG

```



```

4900 066456 011724'          23:  CKLOOP          ;LOOP IF SELECTED          .WORD  SFIMSG
      066460 104406          ;CALL TAPE REWIND COMMAND TRAP  C$CLP1
4901 066462 004737 010704    JSR    PC,REWIND
4902 066466 103411          BCS    30:
4903 066470 016501 000002    MOV    TSSR(R5),R1      ;GET TSSR CONTENTS
4904 066474 010004          MOV    R0,R4            ;GET PACKET ADDRESS
4905 066476 005237 002214'    INC    FATFLG          ;ERROR COUNT
4909 066502          ERRHRD  ERRNO,T35RWN,PKTSSR ;REWIND NOT ACCEPTED
      066502 104456          TRAP  C$ERHRD
      066504 001337          .WORD 735
      066506 070524'        .WORD T35RWN
      066510 011736'        .WORD PKTSSR
4910 066512          30:  CKLOOP          ;LOOP IF SELECTED          TRAP  C$CLP1
      066512 104406          ;PICK UP XSTO
4911 066514 013701 067270'    MOV    T35BFR+6,R1     ;SET UP EXPECTED
4912 066520 010102          MOV    R1,R2           ;SET BOT BIT IN EXPECTED
4913 066522 052702 000002    BIS    0BIT1,R2       ;DOES EXP = REC'D
4914 066526 020102          CMP    R1,R2           ;BR, IF EQUAL (OK)
4915 066530 001406          BEQ    40:
4916 066532 005237 002214'    INC    FATFLG          ;ERROR COUNT
4920 066536          ERRHRD  ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      066536 104456          TRAP  C$ERHRD
      066540 001340          .WORD 736
      066542 070220'        .WORD T35BOT
      066544 015364'        .WORD EXPREC
4921 066546          40:  CKLOOP          ;LOOP IF SELECTED          TRAP  C$CLP1
      066546 104406          ;STARTING RECORD SIZE
4922 066550 012703 000024    MOV    020.,R3        ;STARTING WRITE BUFFER ADDRESS
4923 066554 013737 003116' 067372'  MOV    FREE,T35WB
4924
4925          ;*****
4926          ;WRITE DATA,CVC=1,ACK COMMAND
4927          ;
4928          ;*****
4929
4930
4931 066562 012737 140005 067370' 65:  MOV    0140005,T35PK3  ;WRITE DATA,CVC=1,ACK COMMAND
4932 066570 012704 067370'    MOV    0T35PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
4933 066574 010300          MOV    R3,R0          ;SET PATTERN IN CORRECT REGISTER
4934 066576 004737 017314'    JSR    PC,FILLMEM     ;FILL MEMORY WITH RECORD SIZE
4935 066602 010337 067376'    MOV    R3,T35SZ      ;GET UP RECORD SIZE IN PACKET
4936 066606 010465 000000          MOV    R4,T35DB(R5)   ;ISSUE COMMAND
4937 066612 004737 016140'    JSR    PC,WAITF       ;WAIT FOR SSR TO SET
4938 066616 016501 000002    MOV    TSSR(R5),R1    ;GET TSSR CONTENTS
4939 066622 012702 000200          MOV    0SSR,R2       ;SET UP EXPECTED
4940 066626 020102          CMP    R1,R2          ;ARE THEY EQUAL
4941 066630 001406          BEQ    80:
4942 066632 005237 002214'    INC    FATFLG          ;ERROR COUNT
4946 066636          ERRHRD  ERRNO,T35WDC,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      066636 104456          TRAP  C$ERHRD
      066640 001341          .WORD 737
      066642 071060'        .WORD T35WDC
      066644 011736'        .WORD PKTSSR
4947 066646          80:  CKLOOP          ;LOOP IF SELECTED          TRAP  C$CLP1
      066646 104406
4948
    
```

```

4949
4950
4951
4952
4953
4954
4955 066650 012737 111005 067370'      MOV      0111005,T35PK3      ;WRITE DATA RETRY,ACK,SWB=1 COMMAND
4956 066656 010465 000000                MOV      R4,TSDB(R5)        ;ISSUE COMMAND
4957 066662 004737 016140'      JSR      PC,WAITF           ;WAIT FOR SSR TO SET
4958 066666 016501 000002                MOV      TSSR(R5),R1       ;GET TSSR CONTENTS
4959 066672 012702 000200                MOV      0SSR,R2          ;SET UP EXPECTED
4960 066676 020102                CMP      R1,R2             ;ARE THEY EQUAL
4961 066700 001406                BEQ      90$              ;BR, IF OK
4962 066702 005237 002214'      INC      FATFLG           ;ERROR COUNT
4966 066706                ERRHRD  ERRNO,T35WRF,EXPREC ;TSSR INCORRECT AFTER WRITE DATA RETRY
                                TRAP      C$ERHRD
                                .WORD    738
                                .WORD    T35WRF
                                .WORD    EXPREC
4967 066716                90$:  CKLOOP              ;LOOP IF SELECTED
                                TRAP      C$CLP1
4968 066720                TST      (R3),            ;BUMP RECORD SIZE COUNTER
4969 066722 020327 000052                CMP      R3,042.         ;AT 42 SIZE YET
4970 066726 001315                BNE      65$              ;BR, IF MORE RECORDS TO WRITE
4971 066730 004737 010704'      JSR      PC,REWIND        ;CALL TAPE REWIND COMMAND
4972 066734 103411                BCS      230$            ;BR, IF NO PROBLEM
4973 066736 016501 000002                MOV      TSSR(R5),R1     ;GET TSSR CONTENTS
4974 066742 010004                MOV      R0,R4           ;GET PACKET ADDRESS
4975 066744 005237 002214'      INC      FATFLG           ;ERROR COUNT
4979 066750                ERRHRD  ERRNO,T35RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP      C$ERHRD
                                .WORD    739
                                .WORD    T35RWN
                                .WORD    PKTSSR
4980 066760                230$: CKLOOP              ;LOOP IF SELECTED
                                TRAP      C$CLP1
4981 066762 013701 067270'      MOV      T35BFR+6,R1     ;PICK UP XSTO
4982 066766 010102                MOV      R1,R2           ;SET UP EXPECTED
4983 066770 052702 000002                BIS      0BIT1,R2        ;SET BOT BIT IN EXPECTED
4984 066774 020102                CMP      R1,R2           ;DOES EXP = REC'D
4985 066776 001406                BEQ      240$            ;BR, IF EQUAL (OK)
4986 067000 005237 002214'      INC      FATFLG           ;ERROR COUNT
4990 067004                ERRHRD  ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C$ERHRD
                                .WORD    740
                                .WORD    T35BOT
                                .WORD    EXPREC
4991 067014                240$: CKLOOP              ;LOOP IF SELECTED
                                TRAP      C$CLP1
4992 067016 012703 000024                MOV      020.,R3         ;STARTING RECORD SIZE
4993 067022 013737 003116' 067372'      MOV      FREE,T35RB      ;STARTING READ BUFFER ADDRESS
4994
4995
4996
4997
4998
4999

```

```

5000
5001 067030 012737 100001 067370' 265$: MOV      #100001,T35PK3      ;READ DATA,ACK COMMAND
5002 067036 012704 067370'     MOV      #T35PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
5003 067042 010337 067376'     MOV      R3,T35SZ       ;SET UP RECORD SIZE IN PACKET
5004 067046 010465 000000     MOV      R4,T35DB(R5)   ;ISSUE COMMAND
5005 067052 004737 016140'     JSR      PC,WAITF       ;WAIT FOR SSR TO SET
5006 067056 016501 000002     MOV      T35SR(R5),R1  ;GET T35SR CONTENTS
5007 067062 012702 000200     MOV      #SSR,R2      ;SET UP EXPECTED
5008 067066 020102           CMP      R1,R2         ;ARE THEY EQUAL
5009 067070 001406           BEQ      250$         ;BR, IF OK
5010 067072 005237 002214'     INC      FATFLG        ;ERROR COUNT
5014 067076           ERRHRD   ERRNO,T35RDF,PKTSSR ;T35SR INCORRECT AFTER READ DATA
                                TRAP      C1ERHRD
                                .WORD    741
                                .WORD    T35RDF
                                .WORD    PKTSSR
5015 067106           280$:   CKLOOP           ;LOOP IF SELECTED
                                TRAP      C1CLP1
5016 067110 013702 003116'     MOV      FREE,R2       ;GET BUFFER ADDRESS
5017 067114 010304           MOV      R3,R4         ;GET RECORD SIZE
5018 067116 162704 000024     SUB      #20.,R4       ;POINT BACK TO 1ST RECORD
5019 067122 060204           285$:   ADD      R2,R4       ;POINT TO 1ST LOC IN BUFFER
5020 067124 000303           SWAB    R3             ;SWAP BYTES SWB=1 ETC.
5021 067126 021403           CMP      (R4),R3       ;DATA WRITTEN = READ
5022 067130 001410           BEQ      290$         ;BR, IF DATA OK (GOOD)
5023 067132 011401           MOV      (R4),R1       ;PICK UP BAD DATA
5024 067134 010302           MOV      R3,R2         ;SET UP EXPECTED
5025 067136 005237 002214'     INC      FATFLG        ;ERROR COUNT
5029 067142           ERRHRD   ERRNO,T35DTA,EXPREC ;DATA IN BUFFER NOT CORRECT
                                TRAP      C1ERHRD
                                .WORD    742
                                .WORD    T35DTA
                                .WORD    EXPREC
5030 067152           290$:   CKLOOP           ;LOOP IF SELECTED
                                TRAP      C1CLP1
5031 067154 005724           TST      (R4).         ;BUMP TO NEXT ADDRESS
5032 067156 160204           SUB      R2,R4         ;BACK TO RECORD SIZE
5033 067160 000303           SWAB    R3             ;PUT R3 BACK INTO SHAPE
5034 067162 020403           CMP      R4,R3         ;AT END OF RECORD YET
5035 067164 001356           BNE     285$         ;BR, IF MORE DATA TO CHECK
5036 067166 005723           TST      (R3).         ;BUMP RECORD SIZE
5037 067170 020327 000050     CMP      R3,#40.       ;DONE YET
5038 067174 001315           BNE     265$         ;BR, IF NOT DONE YET (MORE READS)
5039 067176           300$:   CKLOOP           ;LOOP IF SELECTED
                                TRAP      C1CLP1
5040 067200           104406  ENDSUB           ;>>>>>>>>>> END SUBTEST >>>>>>>>>
                                L10067;
5041 067202 023727 002214' 000017     CMP      FATFLG,#15.   ;IS ERROR COUNT AT 25
5042 067210 103402           BLO     999$         ;BR, IF LESS THAN 25
5043 067212 004737 017074'     JSR      PC,CKDROP     ;TRY TO DROP THE UNIT
5044 067216           999$:   ;
5045           ;
5046           ;
5047           ;
5048 067216 004737 016350'     JSR      PC,TSTLOOP   ;DO WE NEED TO ITERATE TEST
5049 067222 103002           BCC     163$         ;BR, IF NO LOOP REQUIRED
    
```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 7: EXTENDED MODE FEATURES

SEQ 188

```

5050 067224 000137 063314'          JMP      T35LOUP
5051 067230          1534:  EXIT      TST
      067230 104432
      067232 003770
5052
5053
5054          ; LOCAL STORAGE FOR THIS TEST
5055
5057 067234          ;
5059 067240          T35PACKET: .BLKB 10-<.-TSV2&7>
5060 067240 100004          .WORD 100004
5061 067242 067250'        .WORD T35DATA
5062 067244 000000          .WORD 0
5063 067246 000012          .WORD 10.
5064 067250          T35DATA:
5065 067250 067262'        .WORD T35BFR
5066 067252 000000          .WORD 0
5067 067254 000024          .WORD 20.
5068 067256 000000          .WORD 0
5069 067260 000000          T35DSW: .WORD 0
5070 067262          T35BFR: .BLKW 25.
5071
5072          ; WRITE SUBSYSTEM MEMGRY COMMAND PACKET
5073
5075 067344          ;
5077 067350          T35PK2: .BLKB 10-<.-TSV2&7>
5078 067350 100006          .WORD 100006
5079 067352 067400'        .WORD T35BF2
5080 067354 000000          .WORD 0
5081 067356 000006          .WORD 6.
5082
5084 067360          ;
5086 067370          T35PK3: .BLKB 10-<.-TSV2&7>
5087 067370 100005          .WORD 100005
5088 067372          T35RB:
5089 067372 003116'        T35WB: .WORD FREE
5090 067374 000000          .WORD 0
5091 067376 000000          T35SZ: .WORD 0
5092
5093          ;
5094          ;
5095          ;
5096 067400          T35BF2:
5097 067400 010          T35BS0: .BYTE 10
5098 067401 200          T35BS1: .BYTE 200
5099 067402 000000          T35S2: .WORD 0
5100 067404 000000          T35S3: .WORD 0
5101
5102          ;
5103          ;
5104          ;
5105          ;
5106 067406 100205          ;
5107 067410 100605          .EVEN
5108 067412 102205          ; TAPE MOTION PACKET COMMAND VALUES
5109 067414 177777          T35RN: .WORD 100205
5110
      .WORD 100605
      .WORD 102205
      .WORD 177777
; EXECUTE AGAIN
; ALL DONE THIS TEST
TRAP      C:EXIT
.WORD     L10063-.
; COMMAND PACKET FOR TEST
; WRITE CHARACTERISTICS COMMAND, WITH , ACK
; ADDRESS OF CHARACTERISTICS BLOCK
; STARTING VALUE OF BLOCK SIZE
; CHARACTERISTICS DATA BLOCK
; ADDRESS OF MESSAGE BUFFER
; LENGTH OF MESSAGE BUFFER
; SELECT DRIVE 0
; MESSAGE BUFFER
; WRITE SUB SYS MEM COMMAND, AND ACK
; ADDRESS OF SELECT BLOCK DATA
; SIZE OF DATA PACKET
; REREAD COMMAND, AND ACK
; ADDRESS OF WRITE BUFFER
; SIZE OF BUFFER (EXTENT)
; BSELO AREA
; BSEL1 AREA
; SFL 2 AREA
; DATA AREA
; REREAD DATA (NEXT)
; REREAD DATA RETRY
; WRITE CONTINUOUS
; END OF DATA

```

```

5111
5112 067416 000000      T35CNT: .WORD 0      ;TAPE TIMER COUNTER STORAGE AREA
5113 067420 000000      T35CNU: .WORD 0      ;TAPE TIMER COUNTER STORAGE AREA
5114 067422 000000      T35DLY: .WORD 0      ;DELAY COUNTER
5115
5116
5117
5118      ;
5119      ; LOCAL TEXT MESSAGES FOR TEST
5120      ;
5121
5122 067424      124      141      160      T35WNG: .ASCIZ 'Tape Position Incorrect After REREAD Previous (OPP=1)'
5123 067512      124      123      123      T35RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
5124 067561      122      105      122      T35RRF: .ASCIZ 'REREAD Previous (Space Reverse, Read Forward) Command Failed'
5125 067656      120      117      123      T35SC: .ASCIZ 'POSITION (Space Command) failed, TSSR Not Correct'
5126 067740      122      111      102      T35LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'
5127 070010      124      123      123      T35WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
5128 070065      111      154      154      T35LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XSTO'
5129 070146      124      123      123      T35WDE: .ASCIZ 'TSSR Not Correct After WRITE DATA Command'
5130 070220      124      141      160      T35BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XSTO)'
5131 070313      127      122      111      T35TIM: .ASCIZ 'WRITE DATA RETRY'S Erase Tape Not Long Enough'
5132 070370      122      105      122      T35EOT: .ASCIZ 'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
5133 070447      124      123      123      T35TM: .ASCIZ 'TSSR Not Correct After REREAD COMMAND Reject'
5134 070524      122      145      167      T35RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
5135 070573      122      101      115      T35RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
5136 070646      124      123      123      T35AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
5137 070715      104      162      151      T35OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
5138 070770      124      123      123      T35WDD: .ASCIZ 'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
5139 071060      124      123      123      T35WDC: .ASCIZ 'TSSR Not Correct After REREAD DATA Command'
5140 071133      103      126      103      T35VCK: .ASCIZ 'CVC Sec, Didn't Reset VCK In Message Buffer'
5141 071206      124      123      102      T35BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
5142 071261      127      122      111      T35WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
5143 071350      122      145      141      T35LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XSTO'
5144 071432      122      145      141      T35LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XSTO'
5145 071514      122      145      163      T35PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
5146 071602      122      145      141      T35TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
5147 071670      127      122      111      T35NEF: .ASCIZ 'WRITE DATA RETRY, At First Record, Failed To Set RIB Bit XST3'
5148 071766      124      123      123      T35SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
5149 072043      124      123      123      T35TSA: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY, Into BOT'
5150 072125      124      123      123      T35WRF: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY Command'
5151 072205      104      141      164      T35DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
5152 072302      124      123      123      T35SSR: .ASCIZ 'TSSR Incorrect After WRITE MISCELLANEOUS Command'
5153 072363      115      117      124      T35MOT: .ASCIZ 'MOT Bit (XST0) Not Set During Rewind (Extended Features Mode)'
5154 072461      111      156      154      T35INT: .ASCIZ 'Interrupt Received After REWIND Command (IE Bit Not Set)'
5155 072552      117      120      115      T35OPM: .ASCIZ 'OPM Bit (XST2) Not Set During Rewind (Extended Features Mode)'
5156 072650      124      123      123      T35RWE: .ASCIZ 'TSSR Incorrect After Extended Features REWIND Command'
5157 072736      116      157      040      T35NIN: .ASCIZ 'No Interrupt Detected After REWIND IMMEDIATE'
5158 073013      105      170      164      TST35ID: .ASCIZ 'Extended Mode Functions'
5159
5160
5161
5162      ;
5163      ; ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
5164      ; WRITE SUBSYSTEM MEMORY COMMAND
5165
5166
5167 073044      T35REST:

```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 7: EXTENDED MODE FEATURES

SEQ 190

```

5168 073044 SAVREG ;SAVE THE REGISTERS
5169 073050 012701 067240' MOV #T35PACKET,R1 ;START OF THE PACKET
5170 073054 012721 100004 MOV #100004,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK,
5171 073060 012721 067250' MOV #T35DATA,(R1)+ ;ADDRESS OF CHARACTERISTICS DATA BLOCK
5172 073064 005021 CLR (R1)+ ;EXTENDED ADDRESS
5173 073066 012721 000012 MOV #10,(R1)+ ;SIZE OF DATA BLOCK IN BYTES
5174 073072 012721 067262' MOV #T35BFR,(R1)+ ;ADDRESS OF MESSAGE BUFFER
5175 073076 005021 CLR (R1)+ ;
5176 073100 012721 000024 MOV #20,(R1)+ ;LENGTH OF MESSAGE BUFFER
5177 073104 005021 CLR (R1)+ ;
5178 073106 012711 000000 MOV #0,(R1) ;SELECT DRIVE ZERO
5179 073112 012702 000030 MOV #24,R2 ;NUMBER OF LOCATIONS TO BE CLEARED
5180 073116 012762 177777 067262' 64$; MOV #177777,T35BFR(R2) ;ALL ONES TO MESSAGE BUFFER
5181 073124 005742 TST -(R2) ;NEXT LOCATION
5182 073126 022702 000000 C/P #0,R2 ;AT END OF LOOP YET
5183 073132 001371 BNE 64$ ;KEEP GOING UNTIL DONE
5184 073134 000207 RTS PC ;RETURN
5185
5186
5187 073136 T35RT2: SAVREG ;SAVE THE REGISTERS
5188 073136 MOV #T35PK2,R1 ;START OF THE PACKET
5189 073142 012701 067350' MOV #100006,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK,
5190 073146 012721 100006 MOV #T35BF2,(R1)+ ;ADDRESS OF DATA BLOCK
5191 073152 012721 067400' CLR (R1)+ ;EXTENDED ADDRESS
5192 073156 005021 MOV #6,(R1)+ ;SIZE OF DATA BLOCK IN BYTES
5193 073160 012721 000006 CLR (R1)+ ;
5194 073164 005021 MOV #T35BF2,R1 ;POINT TO DATA SEL AREA
5195 073166 012701 067400' CLR (R1)+ ;
5196 073172 005021 CLR (R1) ;
5197 073174 005011 RTS PC ;RETURN
5198 073176 000207
5199 073200 T35RT3: SAVREG ;SAVE REGISTERS
5200 073200 MOV #T35PK3,R1 ;SET UP POINTER ADDRESS
5201 073204 012701 067370' CLR (R1)+ ;COMMAND SPACE
5202 073210 005021 CLR (R1)+ ;ADDRESS OF DATA BLOCK
5203 073212 005021 CLR (R1)+ ;EXTENDED ADDRESS
5204 073214 005021 CLR (R1) ;SIZE OF DATA TRANSFER BLOCK
5205 073216 005011 RTS PC ;RETURN
5206 073220 000207
5207 073222 ENDTST
5208 073222 104401 L10063: TRAP C$ETST
5209
5210 .SBTTL TEST 8: RECORD BUFFERING
5211
5212
5213
5214
5215
5216
5217
5218
5219
5220
5221
5222

```

THIS TEST VERIFIES THAT RECORD BUFFERING, USED FOR WRITE DATA AND READ NEXT COMMANDS, OPERATES PROPERLY AND IS PROPERLY CONTROLLED BY THE EXTENDED CHARACTERISTICS DATA WORD. IF THE M7455 CONTROLLER MODULE IS NOT ALREADY IN EXTENDED FEATURES MODE (AS CONTROLLED BY THE DIP SWITCH ON THE MODULE), IT IS PLACED INTO THAT MODE BY INVERTING THE SENSE OF THE SWITCH USING THE WRITE SUBSYSTEM MEMORY COMMAND. NOTE THAT RECORD BUFFERING HAS BEEN ENABLED IN PREVIOUS TESTS OF READ AND WRITE AND SO HAS BEEN PARTIALLY TESTED ALREADY. THIS TEST VERIFIES THAT BUFFERING IS ACTUALLY OPERATING. THE FOLLOWING SUBTESTS ARE PERFORMED:

5223
5224
5225
5226
5227
5228
5229
5230
5231
5232
5233
5234
5235
5236
5237
5238
5239
5240
5241
5242
5243
5244
5245
5246
5247
5248
5249
5250
5251
5252
5253
5254
5255
5256
5257
5258
5259
5260
5261
5262
5263
5264
5265
5266
5267
5268
5273
5274
5275
5276
5277
5278
5279
5280
5281
5262

073224
073224
073224 012737 006166' 002172'
073232 004737 017166'
073236 012700 100607'
073242 004737 016402'
073246 012737 000005 002210'
073254 005037 075616'

VERIFIES THAT NORMAL BUFFERING ON WRITE DATA COMMANDS OPERATES PROPERLY AT LOW TAPE SPEED. THE FOLLOWING SEQUENCE IS PERFORMED:

1. THE TAPE IS REWOUND.
2. BUFFERING IS DISABLED AND LOW TAPE SPEED IS SELECTED (VIA WRITE CHARACTERISTICS COMMAND).
3. AN INITIAL RECORD IS WRITTEN ONTO THE TAPE IN ORDER TO MOVE THE TAPE OFF BOT.
4. THE PROGRAM DELAYS FOR A TIME SUFFICIENT TO ALLOW THE TAPE TO REPOSITION AND COME TO REST.
5. A WRITE DATA COMMAND, WITH A BYTE COUNT LESS THAN 3.5K, IS ISSUED, AND THE PROGRAM COUNTS, IN A WAIT LOOP, THE TIME IT TAKES TO RECEIVE COMMAND TERMINATION. THIS SHOULD BE A RELATIVELY LONG TIME SINCE BUFFERING IS DISABLED.
6. BUFFERING IS ENABLED.
7. THE WRITE DATA COMMAND IS AGAIN ISSUED, WITH THE SAME BYTE COUNT AS THAT USED PREVIOUSLY. THE TIME TO COMPLETION IS AGAIN MEASURED.
8. THE COMPLETION TIMES MEASURED FOR THE NON-BUFFERED AND BUFFERED CASES ARE COMPARED. IT IS VERIFIED THAT THE TIME MEASURED FOR THE NON-BUFFERED CASE IS MUCH LARGER THAN THAT MEASURED FOR THE BUFFERED CASE.
9. THE PREVIOUS STEPS, EXCEPT FOR REWINDING AND WRITING A RECORD OFF BOT, ARE REPEATED FOR VARIOUS BYTE COUNTS IN THE RANGE 20 THROUGH 3.5K.

THE TEST CONSISTS OF THE FOLLOWING 2 SUBTESTS

```
BGNTST
MOV    0EPRT1,EPRTSW      ;PRIMARY ERROR MESSAGE
JSR    PC,KTOFF           ;TURN OFF KT11
MOV    0TST36ID,R0        ;ASCII MESSAGE TO IDENTIFY TEST
JSR    PC,TSTSETUP        ;DO INITIAL TEST SETUP
MOV    05,LOOPCNT         ;PERFORM 5 ITERATIONS
CLR    T36CNT             ;CLEAR TAPE RECORD COUNTER
```

TEST 8, SUBTEST 1

VERIFIES THAT A WRITE DATA RETRY COMMAND ISSUED WHILE

5327	073454	011736'			30\$:	CKLOOP				.WORD	PKTSSR
	073456	104406								TRAP	C\$CLP1
5328	073460	013701	075470'			MOV	T36BFR*6,R1				
5329	073464	010102				MOV	R1,R2				
5330	073466	052702	000002			BIS	#BIT1,R2				
5331	073472	020102				CMP	R1,R2				
5332	073474	001406				BEQ	40\$				
5333	073476	005237	002214'			INC	FATFLG				
5337	073502					ERRHRD	ERRNO,T36BOT,EXPREC				
	073502	104456									
	073504	001444									
	073506	076525'									
	073510	015364'									
5338	073512				40\$:	CKLOOP					
	073512	104406									
5339	073514	013737	002174'	075460'		MOV	UNITN,T36DSW				
5340	073522	052737	000030	075460'		BIS	#BIT3!BIT4,T36DSW				
5341	073530	012704	075440'			MOV	#T36PACKET,R4				
5342	073534	004737	010552'			JSR	PC,WRTCHR				
5343	073540	103407				BCS	50\$				
5344	073542	005237	002214'			INC	FATFLG				
5348	073546	010001				MOV	R0,R1				
5349	073550					ERRHRD	ERRNO,WRTMSG,SFMSG				
	073550	104456									
	073552	001445									
	073554	005046'									
	073556	011724'									
5350	073560				50\$:	CKLOOP					
	073560	104406									
5351	073562	012737	003720	075576'		MOV	#2000.,T36SZ				
5352	073570	013737	003116'	075572'		MOV	FREE,T36WB				
5353	073576	012737	140005	075570'		MOV	#140005,T36PK3				
5354	073604	012704	075570'			MOV	#T36PK3,R4				
5355	073610	010465	000000			MOV	R4,TSDB(R5)				
5356	073614	004737	016140'			JSR	PC,WAITF				
5357	073620	016501	000002			MOV	TSSR(R5),R1				
5358	073624	012702	000200			MOV	#SSR,R2				
5359	073630	020102				CMP	R1,R2				
5360	073632	001406				BEQ	60\$				
5361	073634	005237	002214'			INC	FATFLG				
5365	073640					ERRHRD	ERRNO,WRTERR,PKTSSR				
	073640	104456									
	073642	001446									
	073644	005103'									
	073646	011736'									
5366	073650				60\$:	CKLOOP					
	073650	104406									
5367	073652	012737	000005	075522'		MOV	#05.,T36DLY				
5368	073660				70\$:	DELAY	1				
	073660	012727	000001								
	073664	000000									
	073666	013727	002116'								
	073672	000000									
	073674	005367	177772								
	073700	001375									
	073702	005367	177756								

```

5369 073706 001367          DEC      T36DLY          ;BUMP COUNTER DOWN          BNE      .-20
5370 073710 005337 075622'   BNE      70$          ;BR, IF MORE DELAY TO GO
5371 073716 012737 006642 075576' MOV     $3490.,T36SZ  ;SET SIZE OF TRANSFER
5372 073724 012737 140005 075570' MOV     $140005,T36PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
5373 073732 012704 075570'   MOV     $T36PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
5374 073736 005037 075616'   CLR     T36CNT        ;CLEAR COUNTER
5375 073742 012737 001750 075622' MOV     $1000.,T36DLY  ;SET DROP DEAD COUNTER VALUE
5376 073750 010465 000000       MOV     R4,TSDB(R5)   ;ISSUE COMMAND
5377 073754 016501 000002 80$:   MOV     TSSR(R5),R1  ;GET TSSR CONTENTS
5378 073760 032701 000200       BIT     $SSR,R1      ;CHECK FOR SSR SET
5379 073764 001021          BNE     90$          ;BR, IF SSR IS SET
5380 073766 005237 075616'   INC     T36CNT       ;BUMP CYCLE COUNTER
5381 073772          DELAY    1          ;CUT NUMBER OF LOOPS DOWN
                                MOV     $1,(PC)+
                                .WORD    0
                                MOV     L$DLY,(PC)+
                                .WORD    0
                                DEC     -6(PC)
                                BNE     .-4
                                DEC     -22(PC)
                                BNE     .-20
073772 012727 000001          DEC     T36DLY          ;BUMP DROP DEAD COUNTER
073776 000000          BNE     80$          ;BR, IF THERE IS STILL TIME
074000 013727 002116'   MOV     $SSR,R2     ;SET UP EXPECTED
074004 000000          CMP     R1,R2        ;ARE THEY EQUAL
074006 005367 177772       BEQ     100$         ;BR, IF OK
074012 001375          INC     FATFLG        ;ERROR COUNT
074014 005367 177756       ERRHRD  ERRNO,T36WDE,PKTSSR ;TSSR INCORRECT AFTER READ DATA
                                TRAP    C$ERRHD
                                .WORD    807
                                .WORD    T36WDE
                                .WORD    PKTSSR
074020 001367          CKLOOP
5382 074022 005337 075622'   100$:  MOV     UNITN,T36DSW  ;LOOP IF SELECTED
5383 074026 001352          BIS     $BIT3,T36DSW TRAP    C$CLP1
5384 074030 012702 000200 90$:   ;SET UP DRIVE NUMBER
5385 074034 020102          MOV     $25-APR-83 REV B - TURN OFF BUFFERING
5386 074036 001406          ;TURN OFF BUFFERING CAPABILITY
5387 074040 005237 002214'   MOV     $T36PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
5391 074044          JSR     PC,WRTCHR    ;ISSUE WRITE CHARACTERISTICS
                                BCS     110$         ;BR, IF COMMAND ISSUED OK
                                INC     FATFLG        ;ERROR COUNT
                                MOV     R0,R1        ;SAVE CONTENTS OF TSSR
                                ERRHRD  ERRNO,WRTMSG,SFMSG ;WRITE CHARACTERISTICS FAILED
                                TRAP    C$ERRHD
                                .WORD    808
                                .WORD    WRTMSG
                                .WORD    SFMSG
074044 104456          CKLOOP
074046 001447          110$:  MOV     $3490.,T36SZ  ;LOOP IF SELECTED
074050 076453'          MOV     $140005,T36PK3 ;SET SIZE OF TRANSFER
074052 011736'          MOV     $T36PK3,R4    ;WRITE DATA,ACK,CVC=1 COMMAND
5392 074054          CLR     T36CNU       ;SET UP R4 WITH PACKET ADDRESS
074054 104406          MOV     $1000.,T36DLY ;CLEAR COUNTER
5393 074056 013737 002174' 075460' MOV     $1000.,T36DLY ;SET DROP DEAD COUNTER VALUE
5394 074064 052737 000010 075460' MOV     R4,TSDB(R5)  ;ISSUE COMMAND
5395          BCS     110$         ;BR, IF COMMAND ISSUED OK
5396 074072 012704 075440'   MOV     $T36PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
5397 074076 004737 010552'   JSR     PC,WRTCHR    ;ISSUE WRITE CHARACTERISTICS
5398 074102 103407          BCS     110$         ;BR, IF COMMAND ISSUED OK
5399 074104 005237 002214'   INC     FATFLG        ;ERROR COUNT
5403 074110 010001          MOV     R0,R1        ;SAVE CONTENTS OF TSSR
5404 074112          ERRHRD  ERRNO,WRTMSG,SFMSG ;WRITE CHARACTERISTICS FAILED
                                TRAP    C$ERRHD
                                .WORD    808
                                .WORD    WRTMSG
                                .WORD    SFMSG
074112 104456          CKLOOP
074114 001450          110$:  MOV     $3490.,T36SZ  ;LOOP IF SELECTED
074116 005046'          MOV     $140005,T36PK3 ;SET SIZE OF TRANSFER
074120 011724'          MOV     $T36PK3,R4    ;WRITE DATA,ACK,CVC=1 COMMAND
5405 074122          CLR     T36CNT       ;SET UP R4 WITH PACKET ADDRESS
074122 104406          MOV     $1000.,T36DLY ;CLEAR COUNTER
5406 074124 012737 006642 075576' MOV     $1000.,T36DLY ;SET DROP DEAD COUNTER VALUE
5407 074132 012737 140005 075570' MOV     R4,TSDB(R5)  ;ISSUE COMMAND
5408 074140 012704 075570'   BCS     110$         ;BR, IF COMMAND ISSUED OK
5409 074144 005037 075620'   INC     FATFLG        ;ERROR COUNT
5410 074150 012737 001750 075622' MOV     R0,R1        ;SAVE CONTENTS OF TSSR
5411 074156 010465 000000       ERRHRD  ERRNO,WRTMSG,SFMSG ;WRITE CHARACTERISTICS FAILED
5412 074162 016501 000002 120$:  MOV     $3490.,T36SZ  ;LOOP IF SELECTED
                                MOV     $140005,T36PK3 ;SET SIZE OF TRANSFER
                                MOV     $T36PK3,R4    ;WRITE DATA,ACK,CVC=1 COMMAND
                                CLR     T36CNT       ;SET UP R4 WITH PACKET ADDRESS
                                MOV     $1000.,T36DLY ;CLEAR COUNTER
                                MOV     $1000.,T36DLY ;SET DROP DEAD COUNTER VALUE
                                MOV     R4,TSDB(R5)  ;ISSUE COMMAND
                                BCS     110$         ;BR, IF COMMAND ISSUED OK
                                MOV     $1000.,T36DLY ;SET DROP DEAD COUNTER VALUE
                                MOV     R4,TSDB(R5)  ;ISSUE COMMAND
                                BCS     110$         ;BR, IF COMMAND ISSUED OK
```

```

5413 074166 032701 000200          BIT      #SSR,R1          ;CHECK FOR SSR SET
5414 074172 001021          BNE      130$           ;BR, IF SSR IS SET
5415 074174 005237 075620'       INC      T36CNU        ;BUMP CYCLE COUNTER
5416 074200          DELAY    1              ;CUT NUMBER OF LOOPS DOWN
           074200 012727 000001          MOV      #1,(PC)+
           074204 000000          .WORD   0
           074206 013727 002116'       MOV      L$DLY,(PC)+
           074212 000000          .WORD   0
           074214 005367 177772          DEC      -6(PC)
           074220 001375          BNE      .-4
           074222 005367 177756          DEC      -22(PC)
           074226 001367          BNE      .-20
5417 074230 005337 075622'       DEC      T36DLY        ;BUMP DROP DEAD COUNTER
5418 074234 001352          BNE      120$           ;BR, IF THERE IS STILL TIME
5419 074236 012702 000200          130$:  MOV      #SSR,R2        ;SET UP EXPECTED
5420 074242 020102          CMP      R1,R2        ;ARE THEY EQUAL
5421 074244 001406          BEQ      140$           ;BR, IF OK
5422 074246 005237 002214'       INC      FATFLG        ;ERROR COUNT
5426 074252          ERRHRD  ERRNO,WRTErr,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
           074252 104456          TRAP    C$ERHRD
           074254 001451          .WORD   809
           074256 005103'       .WORD   WRTErr
           074260 011736'       .WORD   PKTSSR
5427 074262          140$:  CKLOOP          ;LOOP IF SELECTED
           074262 104406          TRAP    C$CLP1
5428 074264 013701 075616'       MOV      T36CNT,R1    ;GET FIRST COUNTER
5429 074270 013702 075620'       MOV      T36CNU,R2    ;GET SECOND COUNTER
5430 074274 020102          CMP      R1,R2        ;25-APR-83 REV B - COMPARE EM
5431 074276 003406          BLE      300$           ;BR, IF VALUES ARE CORRECT (OK)
5432 074300 005237 002214'       INC      FATFLG        ;ERROR COUNT
5436 074304          ERRHRD  ERRNO,T36NAS,EXPREC ;TAPE NOT AT CORRECT SPEED
           074304 104456          TRAP    C$ERHRD
           074306 001452          .WORD   810
           074310 075624'       .WORD   T36NAS
           074312 015364'       .WORD   EXPREC
5437 074314          300$:  CKLOOP          ;LOOP IF SELECTED
           074314 104406          TRAP    C$CLP1
5438 074316          ENDSUB
           074316          L10071:  TRAP    C$ESUB
           074316 104403          ;IS ERROR COUNT AT 25
5439 074320 023727 002214' 000017  CMP      FATFLG,#15.   ;BR, IF LESS THAN 25
5440 074326 103402          BLO      999$           ;TRY TO DROP THE UNIT
5441 074330 004737 017074'       JSR      PC,CKDROP
5442 074334          999$:
5443
5444          ;*
5445          ;
5446          ;TEST 8, SUBTEST 2
5447          ;
5448          ;
5449          ;
5450          ;
5451          ;
5452          ;
5453          ;
5454          ;
5455          ;

```

THIS TEST VERIFIES THAT RECORD BUFFERING, USED FOR WRITE DATA AND READ NEXT COMMANDS, OPERATES PROPERLY AND IS PROPERLY CONTROLLED BY THE EXTENDED CHARACTERISTICS DATA WORD. IF THE M7455 CONTROLLER MODULE IS NOT ALREADY IN EXTENDED FEATURES MODE (AS CONTROLLED BY THE DIP SWITCH ON THE MODULE), IT IS PLACED INTO THAT MODE BY INVERTING THE SENSE OF THE SWITCH USING THE WRITE SUBSYSTEM MEMORY COMMAND. NOTE THAT RECORD BUFFERING HAS

Address	OpCode	Operand 1	Operand 2	Operand 3	Operand 4	Comment	Trap	Trap Value
074404	000000						.WORD	0
074406	005367	177772					DEC	-6(PC)
074412	001375						BNE	.-4
074414	005367	177756					DEC	-22(PC)
074420	001367						BNE	.-20
5508	074422	005337	075622'			DEC T36DLY		
5509	074426	001356				BNE 10'		
5510	074430	005237	002214'			INC FATFLG		
5514	074434	010001				MOV RO,R1		
5515	074436					ERRDF ERRNO,SFIERR,SFIMSG		
074436	104455						TRAP	C#ERDF
074440	001453						.WORD	811
074442	003642'						.WORD	SFIERR
074444	011724'						.WORD	SFIMSG
5516	074446	013737	002174'	075460'	20#:	MOV UNITN,T36DSW		
5517	074454	052737	000040'	075460'		BIS #BIT5,T36DSW		
5518	074462	012704	075440'			MOV #T36PACKET,R4		
5519	074466	004737	010552'			JSR PC,WRTCHR		
5520	074472	103407				BCS 25#		
5521	074474	005237	002214'			INC FATFLG		
5525	074500	010001				MOV RO,R1		
5526	074502					ERRHRD ERRNO,WRTMSG,SFIMSG		
074502	104453						TRAP	C#ERHRD
074504	001454						.WORD	812
074506	005046'						.WORD	WRTMSG
074510	011724'						.WORD	SFIMSG
5527	074512				25#:	CKLOOP		
074512	104406						TRAP	C#CLP1
5528	074514	004737	010704'			JSR PC,REWIND		
5529	074520	103407				BCS 30#		
5530	074522	010004				MOV RO,R4		
5531	074524	005237	002214'			INC FATFLG		
5535	074530					ERPHRD ERRNO,T36RWN,PKTSSR		
074530	104456						TRAP	C#ERHRD
074532	001455						.WORD	813
074534	077031'						.WORD	T36RWN
074536	011736'						.WORD	PKTSSR
5536	074540				30#:	CKLOOP		
074540	104406						TRAP	C#CLP1
5537	074542	013701	075470'			MOV T36BFR+6,R1		
5538	074546	010102				MOV R1,R2		
5539	074550	052702	000002			BIS #BIT1,R2		
5540	074554	020102				CMP R1,R2		
5541	074556	001406				REQ 40#		
5542	074560	005237	002214'			INC FATFLG		
5546	074564					ERRHRD ERRNO,T36BOT,EXPREC		
074564	104456						TRAP	C#ERHRD
074566	001455						.WORD	814
074570	076525'						.WORD	T36BOT
074572	015364'						.WORD	EXPREC
5547	074574				40#:	CKLOOP		
074574	104406						TRAP	C#CLP1
5549	074576	013737	002174'	075460'		MOV UNITN,T36DSW		
5549	074604	052737	000030'	075460'		BIS #BIT3:BIT4,T36DSW		
5550	074612	012704	075440'			MOV #T36PACKET,R4		
5551	074616	004737	010552'			JSR PC,WRTCHR		
5552	074622	103407				BCS 50#		


```

075102 001367
5591 075104 005337 075622' DEC T36DLY ;BUMP DROP DEAD COUNTER BNE .-20
5592 075110 001352 BNE 80 ;BR, IF THERE IS STILL TIME
5593 075112 012702 000200 90 ; MOV #SSR,R2 ;SET UP EXPECTED
5594 075116 020102 CMP R1,R2 ;ARE THEY EQUAL
5595 075120 001406 BEQ 100 ;BR, IF OK
5596 075122 005237 002214' INC FATFLG ;ERROR COUNT
5600 075126 ERRHRD ERRNO,T36WDE,PKTSSR ;TSSR INCORRECT AFTER READ DATA
075126 104456 TRAP C$ERHRD
075130 001461 .WORD 817
075132 076453' .WORD T36WDE
075134 011736' .WORD PKTSSR
5601 075136 100 ; CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
075136 104406 TRAP C$CLP1
5602 075140 013737 002174' 075460' MOV UNITN,T36DSW ;SET UP DRIVE NUMBER
5603 075146 052737 000010 075460' BIS #BIT3,T36DSW ;25-APR-83 REV B - TURN OFF BUFFERING
5604 075154 012704 075440' MOV #T36PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
5605 075160 004737 010552' JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
5606 075164 103407 BCS 110 ;BR, IF COMMAND ISSUED OK
5607 075166 005237 002214' INC FATFLG ;ERROR COUNT
5611 075172 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
5612 075174 ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
075174 104456 TRAP C$ERHRD
075176 001462 .WORD 818
075200 005046' .WORD WRTMSG
075202 011724' .WORD SFIMSG
5613 075204 110 ; CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
075204 104406 TRAP C$CLP1
5614 075206 012737 006642 075576' MOV #3490.,T36SZ ;SET SIZE OF TRANSFER
5615 075214 012737 140005 075570' MOV #140005,T36PK3 ;WRITE DATA,ACK,LVC-1 COMMAND
5616 075222 012704 075570' MOV #T36PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
5617 075226 005037 075620' CLR T36CNU ;CLEAR COUNTER
5618 075232 012737 001750 075622' MOV #1000.,T36DLY ;SET DROP DEAD COUNTER VALUE
5619 075240 010465 000000 MOV R4,TSD8(R5) ;ISSUE COMMAND
5620 075244 016501 000002 120 ; MOV TSSR(R5),R1 ;GET TSSR CONTENTS
5621 075250 032701 000200 BIT #SSR,R1 ;CHECK FOR SSR SET
5622 075254 001021 BNE 130 ;BR, IF SSR IS SET
5623 075256 005237 075620' INC T36CNU ;BUMP CYCLE COUNTER
5624 075262 DELAY 1 ;CUT NUMBER OF LOOPS DOWN
075262 012727 000001 MOV #1.(PC),
075266 000000 .WORD 0
075270 013727 002116' MOV L$DLY,(PC),
075274 000000 .WORD 0
075276 005367 177772 DEC -6(PC)
075302 001375 BNE .-4
075304 005367 177756 DEC -22(PC)
075310 001367 BNE .-20
5625 075312 005337 075622' DEC T36DLY ;BUMP DROP DEAD COUNTER
5626 075316 001352 BNE 120 ;BR, IF THERE IS STILL TIME
5627 075320 012702 000200 130 ; MOV #SSR,R2 ;SET UP EXPECTED
5628 075324 020102 CMP R1,R2 ;ARE THEY EQUAL
5629 075326 001406 BEQ 140 ;BR, IF OK
5630 075330 005237 002214' INC FATFLG ;ERROR COUNT
5634 075334 ERRHRD ERRNO,WRTERR,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
075334 104456 TRAP C$ERHRD
075336 001463 .WORD 819
075340 005103' .WORD WRTERR

```

TEST 1 HARDWARE TEST 1 8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 8: RECORD BUFFERING

SEQ 200

5635	075342	011736'								
	075344		140\$:	CKLOOP					.WORD	PKTSSR
	075344	104406							TRAP	C\$CLP1
5636	075346	013701	075616'	MOV	T36CNT,R1					
5637	075352	013702	075620'	MOV	T36CNU,R2					
5638	075356	020102		CMP	R1,R2					
5639	075360	003406		BLE	300\$					
5640	075362	005237	002214'	INC	FATFLG					
5644	075366			ERRHRD	ERRNO,T36NAS,EXPREC					
	075366	104456								
	075370	001464								
	075372	075624'								
	075374	015364'								
5645	075376		300\$:	CKLOOP						
	075376	104406								
5646	075400			ENDSUB						
	075400									
	075400	104403								
5647	075402	023727	002214'	000017	CMP	FATFLG,015.				
5648	075410	103402			BLO	999\$				
5649	075412	004737	017074'		JSR	PC,CKUROP				
5650	075416									
5651			999\$:							
5652			:							
5653			:							
5654			:							
5655	075416	004737	016350'		JSR	PC,TSTLOOP				
5656	075422	103702			BCC	163\$				
5657	075424	000137	073260'		JMP	T36LOOP				
5658	075430									
5659	075430		163\$:	EXIT	TST					
	075430	104432								
	075432	003354								
5660										
5661										
5662										
5663										
5665	075434				.BLKB	10<<,-TSV2&7>				
5667	075440			T36PACKET:						
5668	075440	100004			.WORD	100004				
5669	075442	075450'			.WORD	T36DATA				
5670	075444	000000			.WORD	0				
5671	075446	000012			.WORD	10.				
5672	075450			T36DATA:						
5673	075450	075462'			.WORD	T36BFR				
5674	075452	000000			.WORD	0				
5675	075454	000024			.WORD	20.				
5676	075456	000000			.WORD	0				
5677	075460	000000		T36DSW:	.WORD	0				
5678	075462			T36BFR:	.BLKW	25.				
5679										
5680										
5681										
5683	075544				.BLKB	10<<,-TSV2&7>				
5685	075550			T36PK2:						
5686	075550	100006			.WORD	100006				
5687	075552	075600'			.WORD	T36BF2				

```

;LOOP IF SELECTED
;GET FIRST COUNTER
;GET SECOND COUNTER
;25-APR-83 REV B - COMPARE EM
;BR, IF VALUES ARE CORRECT (OK)
;ERROR COUNT
;TAPE NOT AT CORRECT SPEED
;DO WE NEED TO ITERATE TEST
;BR, IF NO LOOP REQUIRED
;EXECUTE AGAIN
;ALL DONE THIS TEST
;IS ERROR COUNT AT 25
;BR, IF LESS THAN 25
;TRY TO DROP THE UNIT
;COMMAND PACKET FOR TEST
;WRITE CHARACTERISTICS COMMAND, WITH , ACK
;ADDRESS OF CHARACTERISTICS BLOCK
;STARTING VALUE OF BLOCK SIZE
;CHARACTERISTICS DATA BLOCK
;ADDRESS OF MESSAGE BUFFER
;LENGTH OF MESSAGE BUFFER
;SELECT DRIVE 0
;MESSAGE BUFFER
;WRITE SUB SYS MEM COMMAND, AND ACK
;ADDRESS OF SELECT BLOCK DATA
  
```


TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 01-FEB-84 18:55
 TEST 8: RECORD BUFFERING

SEQ 201

5688	075554	000000			.WORD	0	
5689	075556	000006			.WORD	6.	;SIZE OF DATA PACKET
5690							
5692	075560				.BLKB	10-<.TSV2&7>	
5694	075570			T36PK3:			
5695	075570	100005			.WORD	100005	;REREAD COMMAND, AND ACK
5696	075572			T36RB:			
5697	075572	003116'		T36WB:	.WORD	FREE	;ADDRESS OF WRITE BUFFER
5698	075574	000000			.WORD	0	
5699	075576	000000		T36SZ:	.WORD	0	;SIZE OF BUFFER (EXTENT)
5700					.EVEN		
5701							
5702							
5703							
5704	075600			T36BF2:			
5705	075600	010		T36BS0:	.BYTE	10	;BSEL0 AREA
5706	075601	200		T36BS1:	.BYTE	200	;BSEL1 AREA
5707	075602	000000		T36S2:	.WORD	0	;SEL 2 AREA
5708	075604	000000		T36S3:	.WORD	0	;DATA AREA
5709							
5710							
5711					.EVEN		
5712							;TAPE MOTION PACKET COMMAND VALUES
5713							
5714	075606	100205		T36RN:	.WORD	100205	;REREAD DATA (NEXT)
5715	075610	100605		T36WR:	.WORD	100605	;REREAD DATA RETRY
5716	075612	102205		T36CON:	.WORD	102205	;WRITE CONTINUOUS
5717	075614	177777			.WORD	177777	;END OF DATA
5718							
5719							
5720	075616	000000		T36CNT:	.WORD	0	;TAPE TIMER COUNTER STORAGE AREA
5721	075620	000000		T36CNU:	.WORD	0	;TAPE TIMER COUNTER STORAGE AREA
5722	075622	000000		T36DLY:	.WORD	0	;DELAY COUNTER
5723							
5724							
5725							
5726							
5727							;LOCAL TEXT MESSAGES FOR TEST
5728							
5729							
5730	075624	111	155	160	T36NAS:	.ASCIZ	'Improper Tape Controller Buffering Speed'
5731	075675	124	141	160	T36WNG:	.ASCIZ	'Tape Position Incorrect After REREAD Previous (OPP-1)'
5732	075763	124	123	123	T36ROF:	.ASCIZ	'TSSR Incorrect After READ DATA Command'
5733	076032	122	105	122	T36RRF:	.ASCIZ	'REREAD Previous (Space Reverse, Read Forward) Command Failed'
5734	076127	120	117	123	T36SC:	.ASCIZ	'POSITION (Space Command) Failed, TSSR Not Correct'
5735	076211	122	111	102	T36LOR:	.ASCIZ	'RIB NOT SET AFTER READ REVERSE INTO BOT'
5736	076261	124	123	123	T36WDF:	.ASCIZ	'TSSR Not Correct After Illegal Mode Bits Set'
5737	076336	111	154	154	T36LOQ:	.ASCIZ	'Illegal Mode Bits, Failed To Set ILC Bit in XSTO'
5738	076417	122	105	122	T36SSR:	.ASCIZ	'REREAD COMMAND Not Accepted'
5739	076453	124	123	123	T36WDE:	.ASCIZ	'TSSR Not Correct After WRITE DATA Command'
5740	076525	124	141	160	T36BOT:	.ASCIZ	'Tape Not At BOT After REWIND Command (BOT Not Set In XSTO)'
5741	076620	127	122	111	T36TIM:	.ASCIZ	'WRITE DATA RETRY'S Erase Tape Not Long Enough'
5742	076675	122	105	122	T36EOT:	.ASCIZ	'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
5743	076754	124	123	123	T36TM:	.ASCIZ	'TSSR Not Correct After REREAD COMMAND Reject'
5744	077031	122	145	167	T36RWN:	.ASCIZ	'Rewind (POSITION) Command Not Accepted'
5745	077100	122	101	115	T36RNC:	.ASCIZ	'RAM Error, Correct Data Pattern Not In Ram'
5746	077153	124	123	123	T36AM3:	.ASCIZ	'TSSR Init. Failed After REREAD COMMAND'

5747	077222	104	162	151	T36OFL:	.ASCIZ	'Drive 7 Select Failed To Set "OFL" In TSSR'
5748	077275	124	123	123	T36WDN:	.ASCIZ	'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
5749	077365	124	123	123	T36WDC:	.ASCIZ	'TSSR Not Correct After REREAD DATA Command'
5750	077440	103	126	103	T36VCK:	.ASCIZ	'CVC Set, Didn't Reset VCK In Message Buffer'
5751	077513	124	123	102	T36BA:	.ASCIZ	'TSBA Not Correct After REREAD DATA Command'
5752	077566	127	122	111	T36WSS:	.ASCIZ	'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
5753	077655	122	145	141	T36LON:	.ASCIZ	'Reading Long Record Failed To Set RLL Bit In XST0'
5754	077737	122	145	141	T36LOP:	.ASCIZ	'Reading Long Record Failed To Set RLS Bit In XST0'
5755	100021	122	145	163	T36PBP:	.ASCIZ	'Residual Byte Count Incorrect After Short Record Read'
5756	100107	122	145	141	T36TRL:	.ASCIZ	'Reading Long Record Failed To Give Tape Status Alert'
5757	100175	127	122	111	T36NEF:	.ASCIZ	'WRITE DATA RETRY, At First Record, Failed To Set RIB Bit XST3'
5758	100273	124	123	123	T36SCF:	.ASCIZ	'TSSR Not Correct After SPACE RECORDS Command'
5759	100350	124	123	123	T36TSA:	.ASCIZ	'TSSR Not Correct After WRITE DATA RETRY, Into BOT'
5760	100432	124	123	123	T36WRF:	.ASCIZ	'TSSR Not Correct After WRITE DATA RETR Command'
5761	100512	104	141	164	T36DTA:	.ASCIZ	'Data Compare Error, Data Read From Tape Not Equal To Written'
5762	100607	122	145	143	TST36ID:	.ASCIZ	'Record Buffering'
5763						.EVEN	
5764							
5765							
5766							
5767							
5768							
5769							
5770							
5771	100630				T36REST:		
5772	100630				SAVREG		SAVE THE REGISTERS
5773	100634	012701	075440'		MOV	@T36PACKET,R1	START OF THE PACKET
5774	100640	012721	100004		MOV	@100004,(R1)+	WRITE SUBSYSTEM MEM. WITH ACK,
5775	100644	012721	075450'		MOV	@T36DATA,(R1)+	ADDRESS OF CHARACTERISTICS DATA BLOCK
5776	100650	005021			CLR	(R1)+	EXTENDED ADDRESS
5777	100652	012721	000012		MOV	@10,(R1)+	SIZE OF DATA BLOCK IN BYTES
5778	100656	012721	075462'		MOV	@T36BFR,(R1)+	ADDRESS OF MESSAGE BUFFER
5779	100662	005021			CLR	(R1)+	
5780	100664	012721	000024		MOV	@20,(R1)+	LENGTH OF MESSAGE BUFFER
5781	100670	005021			CLR	(R1)+	
5782	100672	012711	000000		MOV	@0,(R1)	SELECT DRIVE ZERO
5783	100676	012702	000030		MOV	@24,R2	NUMBER OF LOCATIONS TO BE CLEARED
5784	100702	012762	177777	075462'	MOV	@177777,T36BFR(R2)	ALL ONES TO MESSAGE BUFFER
5785	100710	005742			TST	-(R2)	NEXT LOCATION
5786	100712	022702	000000		CMP	@0,R2	AT END OF LOOP YET
5787	100716	001371			BNE	64\$	KEEP GOING UNTIL DONE
5788	100720	000207			RTS	PC	RETURN
5789							
5790							
5791	100722				T36RT2:		
5792	100722				SAVREG		SAVE THE REGISTERS
5793	100726	012701	075550'		MOV	@T36PK2,R1	START OF THE PACKET
5794	100732	012721	100006		MOV	@100006,(R1)+	WRITE SUBSYSTEM MEM. WITH ACK,
5795	100736	012721	075600'		MOV	@T36BF2,(R1)+	ADDRESS OF DATA BLOCK
5796	100742	005021			CLR	(R1)+	EXTENDED ADDRESS
5797	100744	012721	000006		MOV	@6,(R1)+	SIZE OF DATA BLOCK IN BYTES
5798	100750	005021			CLR	(R1)+	
5799	100752	012701	075600'		MOV	@T36BF2,R1	POINT TO DATA SEL AREA
5800	100756	005021			CLR	(R1)+	
5801	100760	005011			CLR	(R1)	
5802	100762	000207			RTS	PC	RETURN
5803	100764				T36RT3:		

Line	Address	Hex	Hex	Label	Code	Comment	Trap	Value
5860	101112			DELAY	250	;DELAY ABOUT .25 SEC		
	101112	012727	000250				MOV	0250,(PC)+
	101116	000000					.WORD	0
	101120	013727	002116'				MOV	L\$DLY,(PC)+
	101124	000000					.WORD	0
	101126	005367	177772				DEC	-6(PC)
	101132	001375					BNE	-.4
	101134	005367	177756				DEC	-22(PC)
	101140	001367					BNE	.-20
5861	101142	005337	102312'	DEC	T37DLY	;BUMP COUNTER		
5862	101146	001356		BNE	10\$;BR, IF COUNTER NOT DONE		
5863	101150	005237	002214'	INC	FATFLG	;ERROR COUNT		
5867	101154	010001		MOV	RO,R1	;CONTENTS OF TSSR REGISTER		
5868	101156			ERRDF	ERRNO,SFIERR,SFIMSG	;FATAL ERROR TSSR WAS NOT OK		
	101156	104455					TRAP	C\$ERDF
	101160	001605					.WORD	901
	101162	003642'					.WORD	SFIERR
	101164	011724'					.WORD	SFIMSG
5869	101166	013737	002174' 102150' 20\$:	MOV	UNITN,T37DSW	;SET UP UNIT NUMBER		
5870								
5871	101174	012704	102130'	MOV	0137PACKET,R4	;SUBROUTINE NEEDS PACKET ADDRESS		
5872	101200	004737	010552'	JSR	PC,WRTCHR	;ISSUE WRITE CHARACTERISTICS		
5873	101204	103407		BCS	23\$;BR, IF COMMAND ISSUED OK		
5874	101206	005237	002214'	TNC	FATFLG	;ERROR COUNT		
5878	101212	010001		MOV	RO,R1	;SAVE CONTENTS OF TSSR		
5879	101214			ERRHRD	ERRNO,WRTMSG,SFIMSG	;WRITE CHARACTERISTICS FAILED		
	101214	104456					TRAP	C\$ERHRD
	101216	001606					.WORD	902
	101220	005046'					.WORD	WRTMSG
	101222	011724'					.WORD	SFIMSG
5890	101224			23\$:	CKLOOP	;LOOP IF SELECTED		
	101224	104406					TRAP	C\$CLP1
5881	101226	004737	010704'	JSR	PC,REWIND	;CALL TAPE REWIND COMMAND		
5882	101232	103411		BCS	30\$;BR, IF NO PROBLEM		
5883	101234	016501	000002	MOV	TSSR(R5),R1	;GET TSSR CONTENTS		
5884	101240	010004		MOV	RO,R4	;GET PACKET ADDRESS		
5885	101242	005237	002214'	INC	FATFLG	;ERROR COUNT		
5889	101246			ERRHRD	ERRNO,T37RWN,PKTSSR	;REWIND NOT ACCEPTED		
	101246	104456					TRAP	C\$ERHRD
	101250	001607					.WORD	903
	101252	103465'					.WORD	T37RWN
	101254	011736'					.WORD	PKTSSR
5890	101256			30\$:	CKLOOP	;LOOP IF SELECTED		
	101256	104406					TRAP	C\$CLP1
5891	101260	013701	102160'	MOV	T37BFR+6,R1	;PICK UP XSTO		
5892	101264	010102		MOV	R1,R2	;SET UP EXPECTED		
5893	101266	052702	000002	BIS	0BIT1,R2	;SET BOT BIT IN EXPECTED		
5894	101272	020102		CMP	R1,R2	;DOES EXP = REC'D		
5895	101274	001406		BEQ	40\$;BR, IF EQUAL (OK)		
5896	101276	005237	002214'	INC	FATFLG	;ERROR COUNT		
5900	101302			ERRHRD	ERRNO,T37BOT,EXPREC	;TAPE NOT AT BOT AFTER REWIND		
	101302	104456					TRAP	C\$ERHRD
	101304	001610					.WORD	904
	101306	103161'					.WORD	T37BOT
	101310	015364'					.WORD	EXPREC
5901	101312			40\$:	CKLOOP	;LOOP IF SELECTED		
	101312	104406					TRAP	C\$CLP1

5902	101314	012703	000144		MOV	#100.,R3		;NUMBER OF RECORDS TO BE WRITTEN
5903	101320	013737	003116'	102262'	MOV	FREE,T37WB		;STARTING WRITE BUFFER ADDRESS
5904	101326	012737	140005	102260' 65\$:	MOV	#140005,T37PK3		;WRITE DATA,ACK,CVC=1 COMMAND
5905	101334	012704	102260'		MOV	#T37PK3,R4		;SET UP R4 WITH PACKET ADDRESS
5906	101340	012737	001130	102266'	MOV	#600.,T37SZ		;SET UP RECORD SIZE IN PACKET
5907	101346	010465	0C0000		MOV	R4,TSDB(R5)		;ISSUE COMMAND
5908	101352	004737	016140'		JSR	PC,WAITF		;WAIT FOR SSR TO SET
5909	101356	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
5910	101362	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED
5911	101366	020102			CMP	R1,R2		;ARE THEY EQUAL
5912	101370	001406			BEQ	70\$;BR, IF OK
5913	101372	005237	002214'		INC	FATFLG		;ERROR COUNT
5917	101376				ERRHRD	ERRNO,T37WDC,PKTSSR		;TSSR INCORRECT AFTER WRITE DATA
	101376	104456					TRAP	C\$ERHRD
	101400	001611					.WORD	905
	101402	104021'					.WORD	T37WDC
	101404	011736'					.WORD	PKTSSR
5918	101406			70\$:	CKLOOP			;LOOP IF SELECTED
	101406	104406					TRAP	C\$CLP1
5919	101410	005303			DEC	R3		;DEC RECORD COUNTER
5920	101412	001345			BNE	65\$;BR, IF MORE RECORDS TO WRITE
5921	101414	004737	010704'		JSR	PC,REWIND		;CALL TAPE REWIND COMMAND
5922	101420	103411			BCS	130\$;BR, IF NO PROBLEM
5923	101422	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
5924	101426	010004			MOV	R0,R4		;GET PACKET ADDRESS
5925	101430	005237	002214'		INC	FATFLG		;ERROR COUNT
5929	101434				ERRHRD	ERRNO,T37RWN,PKTSSR		;REWIND NOT ACCEPTED
	101434	104456					TRAP	C\$ERHRD
	101436	001612					.WORD	906
	101440	103465'					.WORD	T37RWN
	101442	011736'					.WORD	PKTSSR
5930	101444			130\$:	CKLOOP			;LOOP IF SELECTED
	101444	104406					TRAP	C\$CLP1
5931	101446	013701	102160'		MOV	T37BFR+6,R1		;PICK UP XSTO
5932	101452	010102			MOV	R1,R2		;SET UP EXPECTED
5933	101454	052702	000002		BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED
5934	101460	020102			CMP	R1,R2		;DOES EXP = REC'D
5935	101462	001406			BEQ	140\$;BR, IF EQUAL (OK)
5936	101464	005237	002214'		INC	FATFLG		;ERROR COUNT
5940	101470				ERRHRD	ERRNO,T37BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND
	101470	104456					TRAP	C\$ERHRD
	101472	001613					.WORD	907
	101474	103161'					.WORD	T37BOT
	101476	015364'					.WORD	EXPREC
5941	101500			140\$:	CKLOOP			;LOOP IF SELECTED
	101500	104406					TRAP	C\$CLP1
5942	101502	012704	102260'		MOV	#T37PK3,R4		;SET UP PACKET ADDRESS
5943	101506	012737	000037	102262'	MOV	#31.,T37RB		;SET UP RECORDS TO SPACE OVER
5944	101514	012737	140010	102260'	MOV	#140010,T37PK3		;ACK,CVC=1,SPACE FORWARD COMMAND
5945	101522	010465	000000	150\$:	MOV	R4,TSDB(R5)		;ISSUE COMMAND
5946	101526	005237	102306'	152\$:	INC	T37CNT		;BUMP TIMER
5947	101532				DELAY	1		;DELAY ABOUT 100US
	101532	012727	000001				MOV	#1,(PC)+
	101536	000000					.WORD	0
	101540	013727	002116'				MOV	L\$DLY,(PC)+
	101544	000000					.WORD	0
	101546	005367	177772				DEC	-6(PC)

PC	Address	Next PC	Label	Op	Op2	Op3	Comment	Op4	Op5
101552	001375								
101554	005367	177756						JNE	.-4
101560	001367							DEC	-22(PC)
5948	101562	016501	000002	MOV	TSSR(R5),R1			BNE	.-20
5949	101566	032701	000200	BIT	*SSR,R1				
5950	101572	001755		BEQ	152\$				
5951	101574	012702	000200	MOV	*SSR,R2				
5952	101600	020201		CMP	R2,R1				
5953	101602	001406		BEQ	160\$				
5954	101604	005237	002214'	INC	FATFLG				
5958	101610			ERRHRD	ERRNO,T37SCF,PKTSSR				
	101610	104456							
	101612	001614						TRAP	C\$ERHRD
	101614	104727'						.WORD	908
	101616	011736'						.WORD	T37SCF
5959	101620							.WORD	PKTSSR
	101620	104406	160\$:	CKLOOP					
5960	101622	004737	010704'						
5961	101626	103411		JSR	PC,REWIND			TRAP	C\$CLF1
5962	101630	010004		BCS	170\$				
5963	101632	016501	000002	MOV	R0,R4				
5964	101636	005237	002214'	MOV	TSSR(R5),R1				
5968	101642			INC	FATFLG				
	101642	104456		ERRHRD	ERRNO,T37RWN,PKTSSR				
	101644	001615							
	101646	103465'						TRAP	C\$ERHRD
	101650	011736'						.WORD	909
5969	101652							.WORD	T37RWN
	101652	104406	170\$:	CKLOOP				.WORD	PKTSSR
5970	101654	013701	102160'						
5971	101660	010102		MOV	T37BFR+6,R1			TRAP	C\$CLP1
5972	101662	052702	000002	MOV	R1,R2				
5973	101666	020102		BIS	*BIT1,R2				
5974	101670	001406		CMP	R1,R2				
5975	101672	005237	002214'	BEQ	175\$				
5979	101676			INC	FATFLG				
	101676	104456		ERRHRD	ERRNO,T37BOT,EXPREC				
	101700	001616							
	101702	103161'						TRAP	C\$ERHRD
	101704	015364'						.WORD	910
5980	101706							.WORD	T37BOT
	101706	104406	175\$:	CKLOOP				.WORD	EXPREC
5981	101710	012704	102260'						
5982	101714	012737	000121 102262'	MOV	*T37PK3,R4			TRAP	C\$CLP1
5983	101722	012737	140010 102260'	MOV	*81.,T37RB				
5984	101730	010465	000000	MOV	*140010,T37PK3				
5985	101734	005237	102310'	MOV	R4,T37DB(R5)				
5986	101740			INC	T37CNU				
	101740	012727	000001	DELAY	1				
	101744	000000							
	101746	013727	002116'					MOV	*1,(PC)+
	101752	000000						.WORD	0
	101754	005367	177772					MOV	L\$DLY,(PC)+
	101760	001375						.WORD	0
	101762	005367	177756					DEC	-6(PC)
	101766	001367						BNE	.-4
5987	101770	016501	000002	MOV	TSSR(R5),R1			DEC	-22(PC)
								BNE	.-20

....B1	MSGSTAT - PRINT STAT....B5	TEST 2: SKIP TAPE M....B9	TEST 5: DATA PARITY....B13
....C1	MSGSUB - PRINT WRITE....C5	TEST 2: SKIP TAPE M....C9	TEST 6: OPERATIONSC13
....D1	PRAMPKT - PRINT RAMD5	TEST 2: SKIP TAPE M....D9	TEST 6: OPERATIONSD13
....E1	PRMESS - PRINT CNT....E5	TEST 2: SKIP TAPE M....E9	TEST 3: OPERATIONSE13
....F1	PRMSGEXP - PRINT EXP....F5	TEST 2: SKIP TAPE M....F9	TEST 6: OPERATIONSF13
....G1	PRMSGEXP - PRINT EXP....G5	TEST 2: SKIP TAPE M....G9	TEST 6: OPERATIONSG13
....H1	PRBYTEXP - PRINT ERR....H5	TEST 2: SKIP TAPE M....H9	TEST 6: OPERATIONSH13
....I1	RAMERR - PRINT RAMI5	TEST 2: SKIP TAPE M....I9	TEST 6: OPERATIONSI13
....J1	RAMTADD - PRINT TEST....J5	TEST 2: SKIP TAPE M....J9	TEST 6: OPERATIONSJ13
....K1	BADSSR - PRINT TSSRK5	TEST 2: SKIP TAPE M....K9	TEST 6: OPERATIONSK13
....L1	SOFINIT - SOFT INITI....L5	TEST 2: SKIP TAPE M....L9	TEST 6: OPERATIONSL13
....M1	CHKAMB - CHECK TSSR....M5	TEST 2: SKIP TAPE M....M9	TEST 6: OPERATIONSM13
....N1	INTR - INTERRUPTN5	TEST 2: SKIP TAPE M....N9	TEST 6: OPERATIONSN13
....B2	CHKTSSR - CHECK TSSR....B6	TEST 2: SKIP TAPE M....B10	TEST 6: OPERATIONSB14
....C2	TSTLOOP - CHECK ITER....C6	TEST 2: SKIP TAPE M....C10	TEST 7: EXTENDED MO....C14
....D2	TSTSETUP - PRINT TES....D6	TEST 2: SKIP TAPE M....D10	TEST 7: EXTENDED MO....D14
PROGRAM HEADER	TSTEND - PRINT ERRO....E6	TEST 2: SKIP TAPE M....E10	TEST 7: EXTENDED MO....E14
DISPATCH TABLE	CKDROP - CHECK IF U....F6	TEST 2: SKIP TAPE M....F10	TEST 7: EXTENDED MO....F14
SOFTWARE P-TABLE	SETMAP - SETUP PAR6....G6	TEST 2: SKIP TAPE M....G10	TEST 7: EXTENDED MO....G14
GLOBAL EQUATES SECTI....H2	FILLMEM - FILL MEMOR....H6	TEST 2: SKIP TAPE M....H10	TEST 7: EXTENDED MO....H14
MEMORY MANAGEMENT DE....I2	CMPMEM - COMPARE ME....I6	TEST 2: SKIP TAPE M....I10	TEST 7: EXTENDED MO....I14
MEMORY MANAGEMENT DE....J2	REGSAV - SAVE R1-R5....J6	TEST 3: NO-OP ("CLE....J10	TEST 7: EXTENDED MO....J14
TSU05 REGISTER AND P....K2	GETPAT - GET 8 BITK6	TEST 3: NO-OP ("CLE....K10	TEST 7: EXTENDED MO....K14
TSU05 REGISTER AND P....L2	GETSEL - ISSUE MENU....L6	TEST 3: NO-OP ("CLE....L10	TEST 7: EXTENDED MO....L14
TSU05 REGISTER AND P....M2	CHKMAN - CHECK MANU....M6	TEST 3: NO-OP ("CLE....M10	TEST 7: EXTENDED MO....M14
TSU05 REGISTER AND P....N2	KTINIT - SETUP KT11....N6	TEST 3: NO-OP ("CLE....N10	TEST 7: EXTENDED MO....N14
TSU05 REGISTER AND P....B3	KTINIT - SETUP KT11....B7	TEST 3: NO-OP ("CLE....B11	TEST 7: EXTENDED MO....B15
TSU05 REGISTER AND P....C3	KTINIT - SETUP KT11....C7	TEST 3: NO-OP ("CLE....C11	TEST 7: EXTENDED MO....C15
SPECIAL MACROS AND O....D3	KTINIT - SETUP KT11....D7	TEST 3: NO-OP ("CLE....D11	TEST 7: EXTENDED MO....D15
GLOBAL DATA SECTIONE3	INITIALIZE SECTIONE7	TEST 3: NO-OP ("CLE....E11	TEST 7: EXTENDED MO....E15
TSTBLK - TEST DATAF3	INITIALIZE SECTIONF7	TEST 3: NO-OP ("CLE....F11	TEST 7: EXTENDED MO....F15
GLOBAL ENVIRONMENT S....G3	INITIALIZE SECTIONG7	TEST 4: ERASE AND O....G11	TEST 7: EXTENDED MO....G15
GLOBAL TEXT MESSAGES....H3	ADD AND DROP UNITS S....H7	TEST 4: ERASE AND O....H11	TEST 7: EXTENDED MO....H15
GLOBAL ERROR REPORTI3	CLEAN-UP AND REPORTI7	TEST 4: ERASE AND O....I11	TEST 7: EXTENDED MO....I15
PRITSSR - PRINT TSSR....J3	CLEAN-UP AND REPORTJ7	TEST 4: ERASE AND O....J11	TEST 8: RECORD BUFF....J15
PRITSSR - PRINT TSSR....K3	CLEAN-UP AND REPORTK7	TEST 4: ERASE AND O....K11	TEST 8: RECORD BUFF....K15
PRIPKT - PRINT THEL3	TEST 1: WRITE TAPEL7	TEST 4: ERASE AND O....L11	TEST 8: RECORD BUFF....L15
PRIBXOR - PRINT EXPD....M3	TEST 1: WRITE TAPEM7	TEST 4: ERASE AND O....M11	TEST 8: RECORD BUFF....M15
PRIXOR - PRINT EXPD....N3	TEST 1: WRITE TAPEN7	TEST 4: ERASE AND O....N11	TEST 8: RECORD BUFF....N15
PRIAAD - PRINT MEMO....B4	TEST 1: WRITE TAPEB8	TEST 4: ERASE AND O....B12	TEST 8: RECORD BUFF....B16
PRITADD - PRINT MEMO....C4	TEST 1: WRITE TAPEC8	TEST 4: ERASE AND O....C12	TEST 8: RECORD BUFF....C16
SPACE - SPACE RECO....D4	TEST 1: WRITE TAPED8	TEST 4: ERASE AND O....D12	TEST 8: RECORD BUFF....D16
WRCHR - WRITE CHAR....E4	TEST 1: WRITE TAPEE8	TEST 4: ERASE AND O....E12	TEST 8: RECORD BUFF....E16
REWIND - POSITION T....F4	TEST 1: WRITE TAPEF8	TEST 4: ERASE AND O....F12	TEST 8: RECORD BUFF....F16
CKRAM - COMPARE RA....G4	TEST 1: WRITE TAPEG8	TEST 5: DATA PARITY....G12	TEST 8: RECORD BUFF....G16
CKRAM2 - COMPARE RA....H4	TEST 1: WRITE TAPEH8	TEST 5: DATA PARITY....H12	TEST 8: RECORD BUFF....H16
CKMSG - COMPARE WR....I4	TEST 1: WRITE TAPEI8	TEST 5: DATA PARITY....I12	TEST 3: RECORD BUFF....I16
CKMSG2 - COMPARE EX....J4	TEST 1: WRITE TAPEJ8	TEST 5: DATA PARITY....J12	TEST 9: FUNCTION TI....J16
CKMSG2 - COMPARE EX....K4	TEST 1: WRITE TAPEK8	TEST 5: DATA PARITY....K12	TEST 9: FUNCTION TI....K16
....L4	TEST 2: SKIP TAPE M....L8	TEST 5: DATA PARITY....L12	TEST 9: FUNCTION TI....L16
PRIMES - PRINT TSSR....M4	TEST 2: SKIP TAPE M....M8	TEST 5: DATA PARITY....M12	TEST 9: FUNCTION TI....M16
FIFEXP - PRINT FIFO....N4	TEST 2: SKIP TAPE M....N8	TEST 5: DATA PARITY....N12	

6039	102144	000024				.WORD	20.		;LENGTH OF MESSAGE BUFFER
6040	102146	000000				.WORD	0		
6041	102150	000000			T37DSW:	.WORD	0		;SELECT DRIVE 0
6042	102152				T37BFR:	.BLKW	25.		;MESSAGE BUFFER
6043									
6044									
6045									
6047	102234								
6049	102240				T37PK2:	.BLKB	10-<.-TSV2&7>		
6050	102240	100006				.WORD	100006		;WRITE SUB SYS MEM COMMAND, AND ACK
6051	102242	102270				.WORD	T37BF2		;ADDRESS OF SELECT BLOCK DATA
6052	102244	000000				.WORD	0		
6053	102246	000006				.WORD	6.		;SIZE OF DATA PACKET
6054									
6056	102250					.BLKB	10-<.-TSV2&7>		
6058	102260				T37PK3:				
6059	102260	100005				.WORD	100005		;REREAD COMMAND, AND ACK
6060	102262				T37RB:				
6061	102262	003116			T37WB:	.WORD	FREE		;ADDRESS OF WRITE BUFFER
6062	102264	000000				.WORD	0		
6063	102266	000000			T37SZ:	.WORD	0		;SIZE OF BUFFER (EXTENT)
6064						.EVEN			
6065									
6066									
6067									
6068	102270				T37BF2:				
6069	102270	010			T37BS0:	.BYTE	10		;BSEL0 AREA
6070	102271	200			T37BS1:	.BYTE	200		;BSEL1 AREA
6071	102272	000000			T37S2:	.WORD	0		;SEL 2 AREA
6072	102274	000000			T37S3:	.WORD	0		;DATA AREA
6073									
6074									
6075						.EVEN			
6076									
6077									
6078	102276	100205			T37RN:	.WORD	100205		;REREAD DATA (NEXT)
6079	102300	100605			T37WR:	.WORD	100605		;REREAD DATA RETRY
6080	102302	102205			T37CON:	.WORD	102205		;WRITE CONTINUOUS
6081	102304	177777				.WORD	177777		;END OF DATA
6082									
6083									
6084	102306	000000			T37CNT:	.WORD	0		;TAPE TIMER COUNTER STORAGE AREA
6085	102310	000000			T37CNU:	.WORD	0		;TAPE TIMER COUNTER STORAGE AREA
6086	102312	000000			T37DLY:	.WORD	0		;DELAY COUNTER
6087									
6088									
6089									
6090									
6091									
6092									
6093	102314	124	141	160	T37WNG:	.ASCIZ			'Tape Position Incorrect After REREAD Previous (OPP=1)'
6094	102402	124	123	123	T37RDF:	.ASCIZ			'TSSR Incorrect After READ DATA Command'
6095	102451	122	105	122	T37RRF:	.ASCIZ			'REREAD Previous (Space Reverse, Read Forward) Command Failed'
6096	102546	120	117	123	T37SC:	.ASCIZ			'POSITION (Space Command) Failed, TSSR Not Correct'
6097	102630	122	111	102	T37LOR:	.ASCIZ			'RIB NOT SET AFTER READ REVERSE INTO ROT'
6098	102700	124	123	123	T37WDF:	.ASCIZ			'TSSR Not Correct After Illegal Mode Bits Set'
6099	102755	111	154	154	T37LQ:	.ASCIZ			'Illegal Mode Bits, Failed To Set ILC Bit In XSTO'

6100	103036	122	105	122	T37SSR:	.ASCIZ	'REREAD COMMAND Not Accepted'
6101	103072	124	123	123	T37WDE:	.ASCIZ	'TSSR Not Correct After WRITE DATA RETRY Command, At BOT'
6102	103161	124	141	160	T37BOT:	.ASCIZ	'Tape Not At BOT After REWIND Command (BOT Not Set In XSTO)'
6103	103254	127	122	111	T37TIM:	.ASCIZ	'WRITE DATA RETRY'S Erase Tape Not Long Enough'
6104	103331	122	105	122	T37EOT:	.ASCIZ	'REREAD DATA OVER EOF GAVE NO TAPE STATUS ALERT'
6105	103410	124	123	123	T37TM:	.ASCIZ	'TSSR Not Correct After REREAD COMMAND Reject'
6106	103465	122	145	167	T37RWN:	.ASCIZ	'Rewind (POSITION) Command Not Accepted'
6107	103534	122	101	115	T37RNC:	.ASCIZ	'RAM Error, Correct Data Pattern Not In Ram'
6108	103607	124	123	123	T37AM3:	.ASCIZ	'TSSR Init. Failed After REREAD COMMAND'
6109	103656	104	162	151	T37OFL:	.ASCIZ	'Drive 7 Select Failed To Set "CFL" In TSSR'
6110	103731	124	123	123	T37WDD:	.ASCIZ	'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
6111	104021	124	123	123	T37WDC:	.ASCIZ	'TSSR Not Correct After REREAD DATA Command'
6112	104074	103	126	103	T37VCK:	.ASCIZ	'CVC Set, Didn't Reset VCK In Message Buffer'
6113	104147	124	123	102	T378A:	.ASCIZ	'TSBA Not Correct After REREAD DATA Command'
6114	104222	127	122	111	T37WSS:	.ASCIZ	'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
6115	104311	122	145	141	T37LON:	.ASCIZ	'Reading Long Record Failed To Set RLI Bit In XSTO'
6116	104373	122	145	141	T37LOP:	.ASCIZ	'Reading Long Record Failed To Set RLS Bit In XSTO'
6117	104455	122	145	163	T37PBP:	.ASCIZ	'Residual Byte Count Incorrect After Short Record Read'
6118	104543	122	145	141	T37TRL:	.ASCIZ	'Reading Long Record Failed To Give Tape Status Alert'
6119	104631	127	122	111	T37NEF:	.ASCIZ	'WRITE DATA RETRY, At First Record, Failed To Set RIB Bit XST3'
6120	104727	124	123	123	T37SCF:	.ASCIZ	'TSSR Not Correct After SPACE RECORDS Command'
6121	105004	124	123	123	T37TSA:	.ASCIZ	'TSSR Not Correct After WRITE DATA RETRY, Into BOT'
6122	105066	124	123	123	T37WRF:	.ASCIZ	'TSSR Not Correct After WRITE DATA RETRY Command'
6123	105146	104	141	164	T37DTA:	.ASCIZ	'Data Compare Error, Data Read From Tape Not Equal To Written'
6124	105243	106	165	156	T37ID:	.ASCIZ	'Function Timing'
6125						.EVEN	
6126							
6127							
6128							
6129							
6130							
6131							
6132							
6133	105264				T37REST:		
6134	105264				SAVREG		'SAVE THE REGISTERS
6135	105270	012701	102130'		MOV	@T37PACKET,R1	'START OF THE PACKET
6136	105274	012721	100004		MOV	@100004,(R1),	'WRITE SUBSYSTEM MEM. WITH ACK,
6137	105300	012721	102140'		MOV	@T37DATA,(R1),	'ADDRESS OF CHARAISTICS DATA BLOCK
6138	105304	005021			CLR	(R1),	'EXTENDED ADDRESS
6139	105306	012721	000012		MOV	@10.,(R1),	'SIZE OF DATA BLOCK IN BYTES
6140	105312	012721	102152'		MOV	@T37BFR,(R1),	'ADDRESS OF MESSAGE BUFFER
6141	105316	005021			CLR	(R1),	
6142	105320	012721	000024		MOV	@20.,(R1),	'LENGTH OF MESSAGE BUFFER
6143	105324	005021			CLR	(R1),	
6144	105326	012711	000000		MOV	@0,(R1)	'SELECT DRIVE ZERO
6145	105332	012702	000030		MOV	@24.,R2	'NUMBER OF LOCATIONS TO BE CLEARED
6146	105336	012762	177777	102152'	MOV	@177777,T37BFR(R2)	'ALL ONES TO MESSAGE BUFFER
6147	105344	005742			TST	-(R2)	'NEXT LOCATION
6148	105346	022702	000000		CMF	@0,R2	'AT END OF LOOP YET
6149	105352	001371			BNE	64\$	'KEEP GOING UNTIL DONE
6150	105354	000207			RTS	PC	'RETURN
6151							
6152							
6153	105356				T37R12:		
6154	105356				SAVREG		'SAVE THE REGISTERS
6155	105362	012701	102240'		MOV	@T37PK2,R1	'START OF THE PACKET
6156	105366	012721	100006		MOV	@100006,(R1),	'WRITE SUBSYSTEM MEM. WITH ACK,

6157	105372	012721	102270'	MOV	0T37BF2,(R1),				
6158	105376	005021		CLR	(R1),				
6159	105400	012721	000006	MOV	06,(R1),				
6160	105404	005021		CLR	(R1),				
6161	105406	012701	102270'	MOV	0T37BF2,R1				
6162	105412	005021		CLR	(R1),				
6163	105414	005011		CLR	(R1)				
6164	105416	000207		RTS	PC				
6165	105420								
6166	105420			T37RT3:					
6167	105424	012701	102260'	SAVREG					
6168	105430	005021		MOV	0T37PK3,R1				
6169	105432	005021		CLR	(R1),				
6170	105434	005021		CLR	(R1),				
6171	105436	005011		CLR	(R1),				
6172	105440	000207		CLR	(R1)				
6173	105442			RTS	PC				
	105442			ENDTST					
	105442	104401							
6174	105444			ENDMOD					

L1.0073: TRAP C\$ETST

```

1          .TITLE  TSV6 - PARAMETER CODING
7
12
18
19 105444      BGNMOD  TSV6
105444      TSV6::
20
21
22          .SBTTL  HARDWARE PARAMETER CODING SECTION
23
24          ;**
25          ; THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
26          ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
27          ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
28          ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
29          ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
30          ; WITH THE OPERATOR.
31          ;--
32 105444      BGNHRD
105444      000010      .WORD  L10075-L$HARD/2
105446      L$HARD::
33
34 105446      GPRMA   HPM1,0,0,160010,177776,YES      ;GET TSBA/TSDB REGISTER ADDRESS.
105446      000031      .WORD  T$CODE
105450      105466      .WORD  HPM1
105452      160010      .WORD  T$LLOLIM
105454      177776      .WORD  T$HILIM
35 105456      GPRMA   HPM2,2,0,0,776,YES      ;GET VECTOR ADDRESS.
105456      001031      .WORD  T$CODE
105460      105522      .WORD  HPM2
105462      000000      .WORD  T$LLOLIM
105464      000776      .WORD  T$HILIM
36          ;GPRMD  HPM3,4,0,340,0,7,YES      ;GET INTERRUPT PRIORITY.
37 105466      ENDRD
105466      .EVEN
38 105466      104      105      126  HPM1:  .ASCIZ  'DEVICE ADDRESS (TSBA/TSDB) '
39 105522      111      116      124  HPM2:  .ASCIZ  'INTERRUPT VECTOR '
40 105546      111      116      124  HPM3:  .ASCIZ  'INTERRUPT PRIORITY '
41          .EVEN
42
43          .SBTTL  SOFTWARE PARAMETER CODING SECTION
44
45          ;**
46          ; THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
47          ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
48          ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
49          ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
50          ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
51          ; WITH THE OPERATOR.
52          ;--
53 105576      BGNSFT
105576      000003      .WORD  L10076-L$SOFT/2
105600      L$SOFT::
54          ; GPRML   SPM1,0,-1,YES      ; GET TRANSPORT TEST FLAG.
55 105600      GPRML   SPM4,2,-1,YES      ; GET ITERATION CONTROL.
105600      001130      .WORD  T$CODE

```

```

105602 105636' .WORD SPM4
105604 177777 .WORD -1
56 ; GPRMD SPM6,4,D,7777,0,7777,YES ; GET LOCAL ERROR LIMIT
57 ; GPRMD SPM7,6,D,7777,0,7777,YES ; GET GLOBAL ERROR LIMIT
58 105606 ENDSFT
.EVEN
105606 L10076:
59
60
61 105606 105 116 101 SPM1: .ASCIZ 'ENABLE TRANSPORT TESTS '
62 105636 111 116 110 SPM4: .ASCIZ 'INHIBIT ITERATIONS '
63 ; SPM6: .ASCIZ 'PER TEST ERROR LIMIT '
64 ; SPM7: .ASCIZ 'PER UNIT ERROR LIMIT '
65 .SBTTL PATCH AREA
66
67 ;
68 ; FINALLY A GENEROUS PATCH AREA.
69 ;
70 ; AND AN ADJUSTMENT TO ACCOUNT FOR THE "LASTAD BIT7" HACK
71 ; DESCRIBED IN "SUPPRG.MEM" (FOR REV C).
72 ;
73
74 105666 PATCH::
75
76 ; .BLKW 32.
77 105666 .BLKW 1.
78
79 ; .IF NZ,,&377
80 ; .!377+1
81 ; .ENDC
82 105670 LASTAD ;SET LAST USED ADDRESS.
.EVEN
105670 000000 .WORD 0
105672 000000 .WORD 0
105674
83 105674 L$LAST:: ENMOD
84 .SBTTL HARD CODED P TABLE
85
86 ;
87 ;
88 105674 BGNSETUP 1
89 105674 BGNPTAB
105674 000000 .WORD 0
105676 000003 .WORD L10101-,,/2-1
105700
90 105700 172522 L10077: .WORD 172522
91 105702 000224 .WORD 224
92 105704 000240 .WORD PRI05
93 105706 ENDP TAB
105706 L10101:
94 105706 ENDS ETUP
95
96 000001 .END
    
```

ADDSSR	012016RG	002	C\$AU	000052	DEVDR0	023226R	002	FRESIZ	003120RG	002	INTFLA	016035R	002
ADR	000020 G		C\$AUTO	000061	DEVNRD	023145R	002	FUSI	004107R	002	INTMAS	016034R	002
AMBTSS	006525R	002	C\$BRK	000022	DEVNXR	023067R	002	F\$AU	000015		INTR	016106RG	002
ASSEMB	000010		C\$BSEG	000004	DEVOML	023011R	002	F\$AUTO	000020		INTREC	002216RG	002
A1716	000003		C\$BSUB	000002	DEVSUM	022756R	002	F\$BGN	000040		INTVEC	016036R	002
BADDAT	003150RG	002	C\$CEFG	000045	DFPTBL	002150RG	002	F\$CLEA	000007		INTX	004270R	002
BADSSR	015570RG	002	C\$CLCK	000062	DIAGMC	000000		F\$DU	000016		INVERT	021014RG	002
BDVPCR	177520 G		C\$CLEA	000012	DICED	000001		F\$END	000041		IOKCKI	000200	
BENBSW	002222RG	002	C\$CLOS	000035	DSBINT	016074R	002	F\$HARD	000004		IOKSTP	000001	
BIE	040000		C\$CLP1	000006	DUAD12	004633R	002	F\$HW	000013		IPRI	002204RG	002
BIT0	000001 G		C\$CVEC	000036	DUFLG	003104RG	002	F\$INIT	000006		ISR	000100 G	
BIT00	000001 G		C\$DCLN	000044	DUMMY	003054R	002	F\$JMP	000050		IVEC	002202PG	002
BIT01	000002 G		C\$DODU	000051	EF.CON	000036 G		F\$MOD	000000		IXE	004000 G	
BIT02	000004 G		C\$GRPT	000024	EF.NEW	000035 G		F\$MSG	000011		I\$AU	000041	
BIT03	000010 G		C\$DU	000053	EF.PWR	000034 G		F\$PROT	000021		I\$AUTO	000041	
BIT04	000020 G		C\$EDIT	000003	EF.RES	000037 G		F\$PWR	000017		I\$CLN	000041	
BIT05	000040 G		C\$ERDF	000055	EF.STA	000040 G		F\$RPT	000012		I\$DU	000041	
BIT06	000100 G		C\$ERHR	000056	EMAXDU	016671R	002	F\$SEG	000003		I\$HRD	000041	
BIT07	000200 G		C\$ERRO	000060	EN	000000		F\$SOFT	000005		I\$INIT	000041	
BIT08	000400 G		C\$ERSF	000054	ENAINI	016042R	002	F\$SRV	000010		I\$MOD	000041	
BIT09	001000 G		C\$ERSO	000057	ENVIRN	020530R	002	F\$SUB	000002		I\$MSG	000041	
BIT1	000002 G		C\$ESCA	000010	EPRTSW	002172RG	002	F\$SW	000014		I\$PROT	000040	
BIT10	002000 G		C\$ESG	000005	EPRT1	006166R	002	F\$TEST	000001		I\$PTAB	000041	
BIT11	004000 G		C\$ESUB	000003	EPRT2	006225R	002	GDDAT	003152RG	002	I\$PWR	000041	
BIT12	010000 G		C\$ETST	000001	ERCM	011623R	002	GERRM	002166RG	002	I\$RPT	000041	
BIT13	020000 G		C\$EXIT	000032	ERRHI	002230RG	002	GETPA	020074RG	002	I\$SEG	000041	
BIT14	040000 G		C\$GETB	000026	ERRK	016650R	002	GETSE	020156RG	002	I\$SETU	000041	
BIT15	100000 G		C\$GETW	000027	ERRLO	002232RG	002	G\$CNTD	000200		I\$SFT	000041	
BIT2	000004 G		C\$GMAN	000043	ERRNO	001620		G\$DELM	000372		I\$SRV	000041	
BIT3	000010 G		C\$GPHR	000042	ERRVEC	000004 G		G\$DISP	000003		I\$SUB	000041	
BIT4	000020 G		C\$GPLO	000030	EPTABE	003370R	002	G\$EXCP	000400		I\$TSY	000041	
BIT5	000040 G		C\$GPRI	000040	EITABL	003170R	002	G\$HILI	000002		J\$JMP	000167	
BIT6	000100 G		C\$INIT	000011	ESUM	016652R	002	G\$LOLI	000001		KIPAR0	172340	
BIT7	000200 G		C\$INLP	000020	EVL	000004 G		G\$NO	000000		KIPAR1	172342	
BIT8	000400 G		C\$MANI	000050	EXBCNT	000010		G\$OFFS	000400		KIPAR2	172344	
BIT9	001000 G		C\$MEM	000031	EXPBRE	015372RG	002	G\$OFST	000376		KIPAR3	172346	
BOE	000400 G		C\$MSG	000023	EXPD	002224RG	002	G\$PRMA	000001		KIPAR4	172350	
BRINIT	004447R	002	C\$OPEN	000034	EXPGET	004523R	002	G\$PRMD	000002		KIPAR5	172352	
BSELO	000000		C\$PNTB	000014	EXPGET	004557R	002	G\$PRML	000000		KIPAR6	172354	
BSEL1	000001		C\$PNTF	000017	EXPMMSG	002314RG	002	G\$RADA	000140		KIPAR7	172356	
CHKAMB	015734R	002	C\$PNTS	000016	EXPREC	015364RG	002	G\$RADB	000000		KIPDR0	172300	
CHKMAN	020400RG	002	C\$PNTX	000015	EXTA	005600R	002	G\$RADD	000040		KIPDR1	172302	
CHKTSS	016226R	002	C\$QIO	000377	EXTEND	005576R	002	G\$RADL	000120		KIPDR2	172304	
CKDROP	017074R	002	C\$RDBU	000007	EXTFEA	002220RG	002	G\$RADO	000020		KIPDR3	172306	
CKEMAX	016774R	002	C\$REFG	000047	E\$END	002100		G\$XFER	000004		KIPDR4	172310	
CKMSG	011250RG	002	C\$RESE	000033	E\$LOAD	000035		G\$YES	000010		KIPDR5	172312	
CKMSG2	011370RG	002	C\$REVI	000003	FATERR	000060		HIADDR	001400		KIPDR6	172314	
CKRAM	011004RG	002	C\$RFLA	000021	FATFLG	002214RG	002	HOE	100000 G		KIPDR7	172316	
CKRAM2	011114RG	002	C\$RPT	000025	FERCM	011612R	002	HPM1	105466R	002	KTENAB	003126RG	002
CMDPKT	021070RG	002	C\$SEFG	000046	FIFEXP	012060RG	002	HPM2	105522R	002	KTFLG	003124RG	002
CMPMEM	017560R	002	C\$SPRI	000041	FIF1MS	012132R	002	HPM3	105546R	002	KTINIT	020616R	002
CONFIG	017142R	002	C\$SVEC	000037	FIF2MS	012201R	002	IBE	010000 G	002	KTOFF	017166R	002
COUNT	002302RG	002	C\$TPRI	000013	FILLME	017314R	002	IDU	000040 G		KTON	017150R	002
CSRADD	002200RG	002	DATA	002304RG	FNOINT	004205R	002	IER	020000 G		LEHRMA	002154RG	002
CTAB	003156RG	002	DATASC	020132R	FORCER	002170RG	002	IFAUT	004246R	002	LISTAL	000001	
CTABE	003170RG	002	DEBUGM	011522R	FREE	003116RG	002	INCERK	016736R	002	LOE	040000 G	
CTABM	003156RG	002	DEVcnt	002212RG	FREEHI	003122R	002	INTCPC	016040R	002	LOPCN	002210RG	002

L00PCO	013016R	002	L10001	002170R	002	L10073	105442R	002	O#DU	000001	PRIASC	014355R	002
L00PFL	003154RG	002	L10002	005574R	002	L10074	102072R	002	O#ERRT	000000	PST32W	003144RG	002
LOT	000010 G		L10003	011734R	002	L10075	105466R	002	O#GNSW	000001	PUNIT	022134R	002
L\$ACP	002110RG	002	L10004	011752R	002	L10076	105606R	002	O#POIN	000001	PW.D11	000021	
L\$APT	002036RG	002	L10005	011770R	002	L10077	105700R	002	O#SETU	000000	PW.D13	000022	
L\$AU	022202RG	002	L10006	011776R	002	L10101	105706R	002	PASRPT	021704R	PW.D22	000020	
L\$AUT	002070RG	002	L10007	012014R	002	MEMADD	013644RG	002	PATCH	105666RG	PW.NOP	000000	
L\$AUTO	022406RG	002	L10010	012032R	002	MEMCK	021106RG	002	PATDAT	020150R	PW.NO1	000023	
L\$CCP	002106RG	002	L10011	012056R	002	MEMASC	020347R	002	PC.ERA	002400	PW.RDE	000024	
L\$CLEA	022466RG	002	L10012	012130R	002	MEMARR	020274R	002	PC.IER	002000	PW.RDR	000001	
L\$CO	002032RG	002	L10013	012300R	002	MEMRES	020376R	002	PC.NOO	001000	PW.RDS	000005	
L\$DEPO	002011RG	002	L10014	013014R	002	MMRO	0170200	002	PC.REL	000000	PW.RFI	000003	
L\$DESC	003402RG	002	L10015	013642R	002	MMVEC	0000250	002	PC.REW	000400	PW.WCT	000006	
L\$DESP	002076RG	002	L10016	013664R	002	MSA.FR	000006	002	PKBCNT	000006	PW.WFI	000004	
L\$DEVP	002060RG	002	L10017	015370R	002	MSA.NO	000000	002	PKHI	000004	PW.WFM	000007	
L\$DISP	002124RG	002	L10020	015376R	002	MSA.NR	000004	002	PKLOW	000002	PW.WPI	000010	
L\$DLY	002116RG	002	L10021	015404R	002	MSA.VO	000002	002	PKTADD	007444R	PW.WPK	000011	
L\$DTP	002040RG	002	L10022	015416R	002	MSGEXP	012034RG	002	PKTFRM	007406R	PW.WTR	000002	
L\$DTYP	002034RG	002	L10023	015440R	002	MSGLOU	012754RG	002	PKTGET	011754RG	P.ACK	000000	
L\$DU	022300RG	002	L10024	015466R	002	MSGSTA	012240RG	002	PKTMES	012000RG	P.CMD	000037	
L\$DUT	002072RG	002	L10025	015626R	002	MSGSUB	013632RG	002	PKTRAM	004735RG	P.CONT	000012	
L\$DVTY	003374RG	002	L10026	016136R	002	MS.ATT	000006	002	PKTSSR	011736RG	P.CVC	040000	
L\$EF	002052RG	002	L10030	022132R	002	MS.EXT	000200	002	PNT	001000 G	P.FMT	000140	
L\$ENVI	002044RG	002	L10031	022276R	002	MS.RSD	000001	002	PRAMF	013666R	P.FORM	000011	
L\$ETP	002102RG	002	L10032	022404R	002	MS.WSF	000020	002	PRASC	014413R	P.GETS	000017	
L\$EXP1	002046RG	002	L10033	022464R	002	MS.RST	000010	002	PRBEXP	015360R	P.IE	000200	
L\$EXP4	002064RG	002	L10034	022512R	002	NBA	002000	002	PRDMSG	015226R	P.INIT	000013	
L\$EXP5	002066RG	002	L10035	022754R	002	NEWPAS	021640R	002	PRBREC	015362R	P.MODE	007400	
L\$HARD	105446RG	002	L10036	032112R	002	NODEV	003106RG	002	PRBTOT	015313R	P.OPP	020000	
L\$HIME	002120RG	002	L10037	023740R	002	NOINIT	004325R	002	PRBYTE	015012RG	P.POSI	000010	
L\$HPCP	002016RG	002	L10040	024462R	002	NOINTR	004211R	002	PRI	002000 G	P.READ	000001	
L\$HPTP	002022RG	002	L10041	025206R	002	NOITS	002162RG	002	PRIADD	010050R	P.SWB	010000	
L\$HW	002150RG	002	L10042	026030R	002	NOMAN	020434R	002	PRIAO	010120R	P.WRIT	000005	
L\$ICP	002104RG	002	L10043	041220R	002	NOMEM	005450R	002	PRI BX0	007502RG	P.WRTC	000004	
L\$INIT	021406RG	002	L10044	033514R	002	NP.IR	000200	002	PRIEQU	007750R	P.WRTS	000006	
L\$LADP	002026RG	002	L10045	035140R	002	NP.LCO	000040	002	PRIPKT	007260RG	QVP	002176RG	002
L\$LAST	105674RG	002	L10046	035534R	002	NP.OUT	000100	002	PRIRAM	007756R	RAMASC	014046R	002
L\$LOAD	002100RG	002	L10047	036220R	002	NP.WRP	000020	002	PRITAD	010164R	RAMDAT	002234RG	002
L\$LUN	002074RG	002	L10050	046576R	002	NSI	004142R	002	PRITSS	005632R	RAMERR	015400RG	002
L\$MREV	002030RG	002	L10051	042112R	002	NSINIT	004377R	002	PRITO	010246R	RAMEXP	015420RG	002
L\$NAME	002000RG	002	L10052	042724R	002	NUL	004517R	002	PRIT1	010311R	RAMFOR	010006R	002
L\$PRIO	002042RG	002	L10053	052664R	002	NULCR	004520R	002	PRI XOR	007632RG	RAMSIZ	002274RG	002
L\$PROT	021376RG	002	L10054	047452R	002	NXM	004000	002	PRI00	000000 G	RAMTAD	015406RG	002
L\$PRT	002112RG	002	L10055	050262R	002	NXMFLG	003130RG	002	PRI01	000040 G	RCVHIA	002276RG	002
L\$REPP	002062RG	002	L10056	051076R	002	NXMHI	003134RG	002	PRI02	000100 G	RCVLOA	002300RG	002
L\$REV	002010RG	002	L10057	055700R	002	NXML0	003132RG	002	PRI03	000140 G	RDERR	005175R	002
L\$RPT	022514RG	002	L10060	054342R	002	NXMTST	021302R	002	PRI04	000200 G	RECMG	002460RG	002
L\$SOFT	105600RG	002	L10061	063262R	002	NXR	003730R	002	PRI05	000240 G	RECV	002226RG	002
L\$SPC	002056RG	002	L10062	060336R	002	NXRERR	005544RG	002	PRI06	000300 G	REGSAV	020040R	002
L\$SPCP	002020RG	002	L10063	073222R	002	NXR	003767R	002	PRI07	000340 G	RE TERR	007362R	002
L\$STYP	002024RG	002	L10064	064354R	002	NXTU	021652R	002	PRMESS	014132R	REWIND	010004RG	002
L\$STA	002030RG	002	L10065	065434R	002	OFL	000100	002	PRMNO	002312RG	RMCHBE	000167	
L\$SW	002160RG	002	L10066	066276R	002	ONEFIL	000000	002	PRMSG	014442RG	RMCHEN	000200	
L\$TEST	002114RG	002	L10067	067200R	002	O#APTS	000000	002	PRMSG0	014622R	RMMSGB	000215	
L\$TIML	002014RG	002	L10070	101006R	002	O#AU	000001	002	PRMSG1	014667R	RMMSGG	000234	
L\$UNIT	002012RG	002	L10071	074316R	002	O#BGNR	000001	002	PRMSG2	014725R	RMPKTB	000201	
L10000	002156R	002	L10072	075400R	002	O#BGNS	000001	002	PROASC	014310R	RMPKTE	000210	

RMR = 010000	S2.OUT = 000040	T\$FLAG = 000040	T29BA 030624R	002 T29WSS 030716R	002
RWFACT = 011000R	002 S2.UND = 000003	T\$FREE = 105706R	002 T29BFR 026112R	002 T3 041222RG	002
SC = 100000	TBLEND = 003054RG	002 T\$GMAN = 000000	T29BF2 026230R	002 T3BFLG 003142RG	002
SCE = 020000	TCOASC 006366R	002 T\$HILI = 000776	T29BOT 027556R	002 T3.1 041252R	002
SCHERR 005270R	002 TCOCOD 006566R	002 T\$LAST = 000001	T29BS0 026230R	002 T3.2 042130R	002
SCME 005003R	002 TEMP1 003110RG	002 T\$LOLI = 000000	T29BS1 026231R	002 T30BFR 036302R	002
SDELAY 010550R	002 TEMP2 003112RG	002 T\$LSYM = 010000	T29CNT 026254R	002 T30BF2 036420R	002
SELASC 020342R	002 YERCLS = 000016	T\$LTNO = 000011	T29CON 026242R	002 T30BOT 037631R	002
SELDAT = 000004	TESTNO = 000011	T\$NEST = 177777	T29DAT 026100R	002 T30BS0 036420R	002
SEL2 = 000002	TEXASC 006325R	002 T\$NSC = 000000	T29DLY 026260R	002 T30BS1 036421R	002
SETMAP 017210R	002 TFCASC 006427R	002 T\$NS1 = 000005	T29DSW 026110R	002 T30CNT 036440R	002
SETU 021736R	002 TIMEXP 015442RG	002 T\$NS2 = 000002	T29DTA 027623R	002 T30CNU 036442R	002
SFFMSG 011772RG	002 TIMSGO 015470R	002 T\$PCNT = 000000	T29EOT 027711R	002 T30DAT 036270R	002
SFHERR 003675R	002 TINERR 011711R	002 T\$PTAB = 010100	T29LON 031005R	002 T30DLY 036446R	002
SFIERR 003642R	002 TMPBFR 002624RG	002 T\$PTHV = 000001	T29LOO 023326R	002 T30DSW 036300R	002
SFIMSG 011724RG	002 TNAM 016576R	002 T\$PTNU = 000001	T29LOP 031067R	002 T30DTA 040724R	002
SFPTBL 002160RG	002 TRINST 002160RG	002 T\$SAVL = 177777	T29LOQ 027206R	002 T30DTR 040660R	002
SIFLAG 003146RG	002 TSBA = 000000 G	T\$SEGL = 177777	T29LOF 027061R	002 T30ETM 036276R	002
SIMSG 011656R	002 TSBAH = 000001 G	T\$SIZE = 000005	T29NEF 026410R	002 T30FCN 036444R	002
SKIP1 003372R	002 TSDB = 000000 G	T\$SUBN = 000001	T29NEQ 031325R	002 T30IBT 036621R	002
SOFINI 015664RG	002 TSDBH = 000001 G	T\$TAGL = 177777	T29OFL 026262R	002 T30IBU 036450R	002
SPACE 010356RG	002 TSFCOD 007126R	002 T\$TAGN = 010102	T29OF7 030275R	002 T30IMV 036426R	002
SPM1 105606R	002 TSREJ = 000006	T\$TEMP = 000000	T29PAC 026070R	002 T30LOO 032140R	002
SPM4 105636R	002 TSSDEF 006476R	002 T\$TEST = 000011	T29PBP 031151R	002 T30LOQ 037420R	002
SR0 = 177572	TSSR = 000002 G	T\$TSTM = 177777	T29PK2 026200R	002 T30NEF 040366R	002
SR1 = 177574	TSSRBI 003472RG	002 T\$TSTS = 000001	T29PK3 026220R	002 T30OFL 040077R	002
SR2 = 177576	TSSRFO 006305R	002 T\$TJ = 010031	T29RB 026222R	002 T30PAC 036260R	002
SR3 = 172516	TSSRH = 000003 G	T\$TAUT = 010033	T29RDF 026500R	002 T30PK2 036370R	002
SSR = 000200	TSSX 004010R	002 T\$TCLE = 010034	T29RDG 031423R	002 T30PK3 036410R	002
STATCO 012302R	002 TSTBLK 002744RG	002 T\$TDAT = 010101	T29RES 031726R	002 T30PI3 037032R	002
SVCGBL = 000000	TSTCNT 002206RG	002 T\$TDU = 010032	T29RIB 031504R	002 T30RB 036412R	002
SVCINS = 000000	TSTEND 016612R	002 T\$THAR = 010075	T29RN 026236R	002 T30RDF 037203R	002
SVCSUB = 000001	TSTFLA 002306RG	002 T\$THW = 010000	T29RNC 030134R	002 T30RDG 037261R	002
SVCTAG = 000000	TSTLOO 016350RG	002 T\$TINI = 010030	T29RRF 026547R	002 T30RES 041042R	002
SVCTST = 000001	TSTPTR 002310RG	002 T\$TMSG = 010025	T29RRG 026663R	002 T30RIB 036535R	002
S\$LSYM = 010000	TSTSET 016402RG	002 T\$TPC = 000001	T29RRN 031604R	002 T30RN 036426R	002
SO.IDB = 000010	TST29I 031677R	002 T\$TPRO = 010027	T29RSZ 026256R	002 T30RRM 040445R	002
SO.IFB = 000002	TST30I 041021R	002 T\$TPTA = 010100	T29RT2 032020R	002 T30RRN 040523R	002
SO.IFP = 000001	TST31I 046353R	002 T\$TRPT = 010035	T29RT3 032062R	002 T30RRP 040602R	002
SO.ILD = 000020	TST32I 052460R	002 T\$TSOF = 010076	T29RWN 030065R	002 T30RT2 041134R	002
SO.IDN = 000040	TST33I 055505R	002 T\$TSRV = 010026	T29SC 026777R	002 T30RT3 041176R	002
SO.IRD = 000100	TST34I 063057R	002 T\$TSJB = 010074	T29SSR 027267R	002 T30RWN 040030R	002
SO.IRW = 000004	TST35I 073013R	002 T\$TSW = 010001	T29SZ 026226R	002 T30SKM 036704R	002
SO.ISP = 000200	TST36I 100607R	002 T\$TTES = 010073	T29S2 026232R	002 T30SSR 037501R	002
S1.ICE = 002000	TST37I 105243R	002 T1 023276RG	002 T29S3 026234R	002 T30SZ 036416R	002
S1.IEO = 010000	TSV2 002000RG	002 T1.1 023326R	002 T29TM 030007R	002 T30S2 036422R	002
S1.IFM = 001000	TSV3 002170RG	002 T1.2 023756R	002 T29TRL 031237R	002 T30S3 036424R	002
S1.IHE = 000400	TSV4 021376RG	002 T1.3 024500R	002 T29VCK 030551R	002 T30TM 037676R	002
S1.IID = 004000	TSV6 105444RG	002 T1.4 025224R	002 T29WB 026222R	002 T30TMK 040304R	002
S1.IIR = 020000	TSV7B 023276RG	002 T2 032114RG	002 T29WDC 030457R	002 T30TM2 037753R	002
S1.I2R = 040000	TTIBFR = 177562 G	T2.1 032140R	002 T29WDD 030354R	002 T30TPB 037123R	002
S1.PAR = 100000	TTICSH = 177560 G	T2.2 033532R	002 T29WDE 027342R	002 T30VCK 040231R	002
S2.ATI = 000010	TTIVEC = 000060 G	T2.3 035156R	002 T29WDF 027131R	002 T30WB 036412R	002
S2.BTI = 000004	T\$ARGC = 000003	T2.4 035552R	002 T29WDR 026240R	002 T30WDC 040152R	002
S2.DIM = 000200	T\$CODE = 001130	T23A 003136RG	002 T29WLK 027424R	002 T30WDD 036760R	002
S2.ILW = 000100	T\$EPRN = 001620	T23B 003140RG	002 T29WNG 026303R	002 T30WDE 037552R	002
S2.INR = 000020	T\$EXCP = 000000	T29AM3 030207R	002 T29WRT 027511R	002 T30WDF 037343R	002

T31AM3	044626R	002	T32AM3	051567R	002	T33UNC	054722R	002	T35BFR	067262R	002	T35WSS	071261R	002
T31BA	045166R	002	T32BA	051703R	002	T33UND	055012R	002	T35BF2	067400R	002	T36AM3	077153R	002
T31BFR	043012R	002	T32BFR	051162R	002	T33WB	054532R	002	T35BOT	070220R	002	T36BA	077513R	002
T31BF2	043130R	002	T32BOE	052206R	002	T33WDC	055327R	002	T35BS0	067400R	002	T36BFR	075462R	002
T31BOT	044155R	002	T32BOT	051336R	002	T33WDR	054550R	002	T35BS1	067401R	002	T36BF2	075600R	002
T31BS0	043130R	002	T32CMD	051307R	002	T33WPW	054642R	002	T35CNT	067416R	002	T36BOT	076525R	002
T31BS1	043131R	002	T32CNT	051330R	002	T34AM3	062331R	002	T35CNU	067420R	002	T36BS0	075600R	002
T31CNT	043146R	002	T32CNU	051332R	002	T34BA	062716R	002	T35CON	067412R	002	T36BS1	075601R	002
T31CNU	043150R	002	T32DAT	051150R	002	T34BFR	060422R	002	T35DAT	067250R	002	T36CNT	075616R	002
T31CON	043142R	002	T32DLY	051334R	002	T34BF2	060546R	002	T35DLY	067422R	002	T36CNU	075620R	002
T31DAT	043000R	002	T32DSW	051160R	002	T34BOT	061104R	002	T35DSW	067260R	002	T36CON	075612R	002
T31DLY	043152R	002	T32ECF	052275R	002	T34BS0	060546R	002	T35DTA	072205R	002	T36DAT	075430R	002
T31DSW	043010R	002	T32EOT	051431R	002	T34BS1	060547R	002	T35EOT	070370R	002	T36DLY	075622R	002
T31DTA	046256R	002	T32EWA	051636R	002	T34CNT	060542R	002	T35INT	072461R	002	T36DSW	075460R	002
T31EOT	044350R	002	T32LOO	046630R	002	T34CON	060560R	002	T35LON	071350R	002	T36DTA	100512R	002
T31LON	045330R	002	T32OPI	052423R	002	T34DAT	060410R	002	T35LOO	063314R	002	T36EOT	076675R	002
T31LOO	041252R	002	T32PAC	051140R	002	T34DLY	060544R	002	T35LOP	071432R	002	T36LON	077655R	002
T31LOF	045412R	002	T32PK2	051250R	002	T34DSW	060420R	002	T35LOQ	070065R	002	T36LOO	073260R	002
T31LOQ	043726R	002	T32PK3	051270R	002	T34EOT	062055R	002	T35LOR	067740R	002	T36LOP	077737R	002
T31LOR	043601R	002	T32RB	051272R	002	T34ET	061766R	002	T35MOT	072363R	002	T36LOQ	076336R	002
T31NEF	045650R	002	T32RES	052520R	002	T34ETC	061027R	002	T35NEF	071670R	002	T36LOR	076211R	002
T31OFL	044675R	002	T32RIB	051756R	002	T34ETN	061321R	002	T35NIN	072736R	002	T36NAS	075624R	002
T31PAC	042770R	002	T32RT2	052612R	002	T34EIO	060652R	002	T35OFL	070715R	002	T36NEF	100175R	002
T31PBP	045474R	002	T32RT3	052612R	002	T34ETS	061400R	002	T35OPM	072552R	002	T36OFL	077222R	002
T31PK2	043100R	002	T32RWN	051520R	002	T34ETZ	061472R	002	T35PAC	067240R	002	T36PAC	075440R	002
T31PK3	043120R	002	T32SCF	052054R	002	T34ET2	061237R	002	T35PBP	071514R	002	T36PBP	100021R	002
T31RB	043122R	002	T32SZ	051276R	002	T34L00	055732R	002	T35PK2	067350R	002	T36PK2	075550R	002
T31RDE	043154R	002	T32TSA	052131R	002	T34OFL	062377R	002	T35PK3	067370R	002	T36PK3	075570R	002
T31RDF	043353R	002	T32WB	051272R	002	T34PAC	060400R	002	T35RB	067372R	002	T36RE	075572R	002
T31RES	046420R	002	T32WDC	052356R	002	T34PK2	060510R	002	T35RDF	067512R	002	T36RDF	075763R	002
T31RN	043136R	002	T33BFR	054422R	002	T34PK3	060530R	002	T35RES	073044R	002	T36RES	100630R	002
T31RNC	044553R	002	T33BF2	054540R	002	T34POS	060564R	002	T35RN	067400R	002	T36RN	075606R	002
T31RRF	043422R	002	T33BOT	055165R	002	T34RB	060532R	002	T35RNC	070573R	002	T36RNC	077100R	002
T31RT2	046512R	002	T33BS0	054540R	002	T34RES	063102R	002	T35RRF	067561R	002	T36RRF	076332R	002
T31RT3	046554R	002	T33BS1	054541R	002	T34RNC	062256R	002	T35RT2	073136R	002	T36RT2	100722R	002
T31RWN	044504R	002	T33CNT	054556R	002	T34RRE	060736R	002	T35RT3	073200R	002	T36RT3	100764R	002
T31SC	043517R	002	T33CNU	054560R	002	T34RSZ	060540R	002	T35RWE	072650R	002	T36RWN	077031R	002
T31SCF	045771R	002	T33CON	054552R	002	T34RT2	063174R	002	T35RWN	070524R	002	T36SC	076127R	002
T31SSR	044007R	002	T33DAT	054410R	002	T34RT3	063236R	002	T35SC	067656R	002	T36SCF	100273R	002
T31SZ	043126R	002	T33DLY	054562R	002	T34RWN	062207R	002	T35SCF	071766R	002	T36SSR	076417R	002
T31S2	043132R	002	T33DSW	054420R	002	T34SSR	061733R	002	T35SSR	072302R	002	T36SZ	075576R	002
T31S3	043134R	002	T33DTA	055410R	002	T34STM	061550R	002	T35SZ	067376R	002	T36S2	075602R	002
T31TIM	044250R	002	T33L00	052716R	002	T34SZ	060536R	002	T35S2	067402R	002	T36S3	075604R	002
T31TM	044427R	002	T33PAC	054400R	002	T34S2	060550R	002	T35S3	067404R	002	T36TIM	076620R	002
T31TRL	045562R	002	T33PK2	054510R	002	T34S3	060552R	002	T35TIM	070313R	002	T36TM	076754R	002
T31TSA	046046R	002	T33PK3	054530R	002	T34TM	062133R	002	T35TM	070447R	002	T36TRL	100107R	002
T31VCK	045113R	002	T33RB	054532R	002	T34TMK	061633R	002	T35TRL	071602R	002	T36TSA	100350R	002
T31WB	043122R	002	T33RBP	054564R	002	T34VCK	062643R	002	T35TSA	072043R	002	T36VCK	077440R	002
T31WDC	045040R	002	T33RES	055522R	002	T34WB	060532R	002	T35VCK	071133R	002	T36WB	075572R	002
T31WDD	044750R	002	T33RN	054546R	002	T34WD	060554R	002	T35WB	067372R	002	T36WDC	077365R	002
T31WDE	044043R	002	T33RT2	055614R	002	T34WDC	062541R	002	T35WDC	071060R	002	T36WDD	077275R	002
T31WDF	043651R	002	T33RT3	055656R	002	T34WDD	062452R	002	T35WDD	070770R	002	T36WDE	076453R	002
T31WDR	043140R	002	T33RWN	055260R	002	T34WDR	060556R	002	T35WDE	070146R	002	T36WD	076261R	002
T31WNG	043301R	002	T33SSR	055101R	002	T34WSS	062770R	002	T35WDF	070010R	002	T36WDR	075610R	002
T31WNH	043220R	002	T33SZ	054536R	002	T34WTM	061150R	002	T35WDR	067410R	002	T36WNG	075675R	002
T31WRF	046153R	002	T33S2	054542R	002	T35AM3	070646R	002	T35WNG	067424R	002	T36WRF	100432R	002
T31WSS	045241R	002	T33S3	054544R	002	T35BA	071206R	002	T35WRF	072125R	002	T36WSS	077566R	002

T37AM3	103607R	002	T37RRF	102451R	002	T6.1	055732R	002	WF.I4R	000001	X#ALWA	000000	
T37BA	104147R	002	T37RT2	105356R	002	T7	063264RG	002	WRTCHR	010552RG	002	X#FALS	000040
T37BFR	102152R	002	T37RT3	105420R	002	T7.1	063314R	002	WRTERR	005103R	002	X#OFFS	000400
T37BF2	102270R	002	T37RWN	103465R	002	T7.2	064372R	002	WRTMSG	005046R	002	X#TRUE	000020
T37BOT	103161R	002	T37SC	102546R	002	T7.3	065452R	002	WSMBK	021100RG	002	X1.COR	020000
T37BS0	102270R	002	T37SCF	104727R	002	T7.4	066314R	002	XFERAS	015630R	002	X1.DLT	100000
T37BS1	102271R	002	T37SSR	103036R	002	T8	073224RG	002	XNXM	016266R	002	X1.MBZ	017375
T37CNT	102306R	002	T37SZ	102266R	002	T8.1	073260R	002	XORBFO	007564R	002	X1.RBP	000400
T37CNU	102310R	002	T37S2	102272R	002	T8.2	074334R	002	XORFOR	007702R	002	X1.SPA	040000
T37CON	102302R	002	T37S3	102274R	002	T9	101010RG	002	XST0	000006 G		X1.UNC	000002
T37DAT	102140R	002	T37T1M	103254R	002	T9.1	101044R	002	XST1	000010 G		X2.BUF	000100
T37DLY	102312R	002	T37TM	103410R	002	UAM	000200 G		XST2	000012 G		X2.EXT	000200
T37DSW	102150R	002	T37TRL	104513R	002	UNITN	002174RG	002	XST3	000014 G		X2.OPM	100000
T37DTA	105146R	002	T37TSA	105004R	002	UNREC	000006		XST4	000016 G		X2.RCE	040000
T37EOT	103331R	002	T37VCK	104074R	002	USI	004113R	002	XSOBOT	000002		X2.REV	000077
T37LON	104311R	002	T37WB	102262R	002	WAITF	016140RG	002	XSOEOT	000001		X2.SPA	035400
T37LOO	101044R	002	T37WDC	104021R	002	WC.IFA	000200		XSOIE	000040		X2.UNI	000007
T37LOP	104373R	002	T37WDD	103731R	002	WC.IFE	000002		XSOILA	000400		X2.WCF	002000
T37LOQ	102355R	002	T37WDE	103072R	002	WC.IGU	000001		XSOILC	001000		X3.DCK	000010
T37LUH	102630R	002	T37WDF	102700R	002	WC.IRE	000010		XSOLET	020000		X3.MBZ	000006
T37NEF	104631R	002	T37WDR	102300R	002	WC.TRW	000004		XSOMOT	000200		X3.MDE	177400
T37OFL	103656R	002	T37WNG	102314R	002	WC.IOT	000100		XSONEF	002000		X3.OPI	000100
T37PAC	102130R	002	T37WRF	105066R	002	WC.IIT	000040		XSNL	000100		X3.REV	000040
T37PBP	104455R	002	T37WSS	104222R	002	WC.ISR	000020		XSPED	000010		X3.RIB	000001
T37PK2	102240R	002	T4	046600RG	002	WF.IED	000010		XSORLL	010000		X3.SPA	000200
T37PK3	102260R	002	T4.1	046630R	002	WF.IER	000004		XSORLS	040000		X3.TRF	000020
T37RB	102262R	002	T4.2	047470R	002	WF.IHI	000200		XSOTMK	100000		X4.HSP	100000
T37RDF	102402R	002	T4.3	050300R	002	WF.IRE	000040		XSOVCK	000020		X4.MBZ	017400
T37RES	105264R	002	T5	052666RG	002	WF.IWF	000020		XSOWLE	004000		X4.RCE	040000
T37RN	102276P	002	T5.1	052716P	002	WF.IWF	000100		XSOWLK	000004		X4.TSM	020000
T37RNC	103534R	002	T6	055702RG	002	WF.I3R	000002		XXCOMM	003114RG	002	X4.WRC	000377

. ABS. 000000 000
000000 001
ABS 105706 002
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 30363 WORDS (119 PAGES)
DYNAMIC MEMORY: 20614 WORDS (79 PAGES)
ELAPSED TIME: 00:39:35
CZTSDA,CZTSDA,SEQ/-SP=SVC/ML,TSV1D,TSV22D,TSV58,TSV4,TSV7B,TSV6

TEST 9: FUNCTION TI....B1
TEST 9: FUNCTION TI....C1
TEST 9: FUNCTION TI....D1
TEST 9: FUNCTION TI....E1
SOFTWARE PARAMETER C....F1
SYMBOL TABLEG1
SYMBOL TABLEH1
SYMBOL TABLEI1
SYMBOL TABLEJ1
SYMBOL TABLEK1