

.REM.
IDENTIFICATION

PRODUCT CODE: AC-T099B-MC
PRODUCT TITLE: CVTSDBO TSV05 CONTROLLER LOGIC TEST 4
AUTHOR: DICK MITCHELL
DEPARTMENT: COMPUTER SPECIAL SYSTEMS/PPG
DATE: APRIL 26, 1983

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1982,1983 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL
DEC

POP
DECUS

UNIBUS
DECTAPE

MASSBUS

TABLE OF CONTENTS

1.0	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.2	SYSTEM REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
1.5	ASSUMPTIONS
2.0	OPERATING INSTRUCTIONS
2.1	COMMANDS
2.2	SWITCHES
2.3	FLAGS
2.4	HARDWARE QUESTIONS
2.5	SOFTWARE QUESTIONS
2.6	EXTENDED P-TABLE DIALOGUE
2.7	QUICK STARTUP PROCEDURE
3.0	ERROR INFORMATION
4.0	PERFORMANCE AND PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
6.0	TEST SUMMARIES
7.0	MAINTENANCE HISTORY

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT

THIS IS A PDP-11/23 RESIDENT DIAGNOSTIC WHICH CHECKS THE FUNCTIONALITY OF A TSV05 MAGTAPE SUBSYSTEM WHILE CONNECTED TO A PDP-11/23 SYSTEM (Q-BUS). THE PROGRAM PROVIDES ERROR MESSAGES WHICH IDENTIFY FAILING FUNCTIONS THAT AID IN THE REPAIR OF THE DEVICE. THIS DIAGNOSTIC CONSIST OF EIGHT TEST WHICH ARE EXECUTED IN SEQUENCE.

THIS DIAGNOSTIC HAS BEEN WRITTEN FOR USE WITH THE DIAGNOSTIC RUNTIME SERVICES SOFTWARE (SUPERVISOR). THESE SERVICES PROVIDE THE INTERFACE TO THE OPERATOR AND TO THE SOFTWARE ENVIRONMENT. THIS PROGRAM CAN BE USED WITH XXDP+, ACT, APT, SLIDE AND PAPER TAPE. FOR A COMPLETE DESCRIPTION OF THE RUNTIME SERVICES, REFER TO THE XXDP+ USER'S MANUAL. THERE IS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES IN SECTION 2 OF THIS DOCUMENT.

1.2 SYSTEM REQUIREMENTS

PDP-11/23 PROCESSOR AND MEMORY
CAUTION:DIAGNOSTIC REQUIRES 32K WORDS OF MEMORY
(28K USEABLE AND 4K RESERVED FOR I/O PAGE)
TSV05 MAGTAPE SUBSYSTEM (DRIVE AND CONTROLLER)
CONSOLE TERMINAL
PDP-11 DIAGNOSTIC SUPERVISOR (MSAAA.SYS VERSION 34 OR LATER)
PDP-11 DIAGNOSTIC LOADER/MONITOR (XXDP+)

1.3 RELATED DOCUMENTS AND STANDARDS

DIGITAL EQUIPMENT CORPORATION DOCUMENTS:

1. CHQUS XXDP+ USERS MANUAL; DOCUMENT NUMBER AC-F348E-MC
DATE: 14 JULY 1980.
2. TSV05 TRANSPORT SUBSYSTEM USER'S GUIDE; DOCUMENT NUMBER EK-TSV05-UG-001
DATE: AUGUST 1982
3. TSV05 TRANSPORT SUBSYSTEM TECHNICAL MANUAL; DOCUMENT NUMBER EK-TSV05-TM-001
DATE: AUGUST 1982
4. TSV05 TRANSPORT SUBSYSTEM INSTALLATION MANUAL; DOCUMENT NUMBER EK-TSV05-IN-001
DATE: AUGUST 1982

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

FUNCTIONAL PDP-11/23 CENTRAL PROCESSOR AND MEMORY
FUNCTIONAL CONSOLE TERMINAL
FUNCTIONAL STANDALONE DIAGNOSTIC SUPERVISOR
FUNCTIONAL DIAGNOSTIC LOADER/MONITOR (XXDP+)

1.5 ASSUMPTIONS

ALL HARDWARE EXCEPT THE HARDWARE UNDER TEST IS ASSUMED TO WORK PROPERLY OR FALSE ERRORS CAN BE REPORTED.
THE TAPE BEING USED ON THE TSO5 TRANSPORT IS A KNOWN GOOD REEL OF TAPE.
CVTSAA, CVTSBA AND CVTSCA HAVE SUCCESSFULLY RUN.

2.0 OPERATING INSTRUCTIONS

THIS SECTION CONTAINS A BRIEF DESCRIPTION OF THE RUNTIME SERVICES. FOR DETAILED INFORMATION, REFER TO THE XXDP+ USER'S MANUAL (CHQUS).

2.1 COMMANDS

THERE ARE ELEVEN LEGAL COMMANDS FOR THE DIAGNOSTIC RUNTIME SERVICES (SUPERVISOR). THIS SECTION LISTS THE COMMANDS AND GIVES A VERY BRIEF DESCRIPTION OF THEM. THE XXDP+ USER'S MANUAL HAS MORE DETAILS.

COMMAND	EFFECT
START	START THE DIAGNOSTIC FROM AN INITIAL STATE
RESTART	START THE DIAGNOSTIC WITHOUT INITIALIZING
CONTINUE	CONTINUE AT TEST THAT WAS INTERRUPTED (AFTER +C)
PROCEED	CONTINUE FROM AN ERROR HALT
EXIT	RETURN TO XXDP+ MONITOR (XXDP+ OPERATION ONLY!)
ADD	ACTIVATE A UNIT FOR TESTING (ALL UNITS ARE CONSIDERED TO BE ACTIVE AT START TIME)
DROP	DEACTIVATE A UNIT
PRINT	PRINT STATISTICAL INFORMATION (IF IMPLEMENTED BY THE DIAGNOSTIC - SECTION 4.0)
DISPLAY	TYPE A LIST OF ALL DEVICE INFORMATION
FLAGS	TYPE THE STATE OF ALL FLAGS (SEE SECTION 2.3)
ZFLAGS	CLEAR ALL FLAGS (SEE SECTION 2.3)

A COMMAND CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. SO YOU MAY, FOR EXAMPLE, TYPE "STA" INSTEAD OF "START".

2.1.1 OPERATOR COMMANDS

THE TSV05 DIAGNOSTIC IS A PDP-11/23 DIAGNOSTIC SUPERVISOR COMPATIBLE PROGRAM. ALL LOADING AND RUNTIME INSTRUCTIONS CAN BE REFERENCED IN THE CHQUS XXDP+ USER'S MANUAL, DOCUMENT NUMBER AC-F348E-MC. THE USER ENTRY IS IN QUOTES.

BOOT THE DIAGNOSTIC XXDP MEDIA

```
.R VTSO??
DIAG. RUN-TIME SERVICES REV D. APR 79
CVTSD-B-0
****TSV05 LOGIC DIAGNOSTIC****
UNIT IS TSV05
>DR
```

2.2 SWITCHES

THERE ARE SEVERAL SWITCHES WHICH ARE USED TO MODIFY SUPERVISOR OPERATION. THESE SWITCHES ARE APPENDED TO THE LEGAL COMMANDS. ALL OF THE LEGAL SWITCHES ARE TABULATED BELOW WITH A BRIEF DESCRIPTION OF EACH. IN THE DESCRIPTIONS BELOW, A DECIMAL NUMBER IS DESIGNATED BY "DDDDD".

SWITCH	EFFECT
/TESTS:LIST	EXECUTE ONLY THOSE TESTS SPECIFIED IN THE LIST. LIST IS A STRING OF TEST NUMBERS, FOR EXAMPLE - /TESTS:1:5:7-10. THIS LIST WILL CAUSE TESTS 1,5,7,8,9,10 TO BE RUN. ALL OTHER TESTS WILL NOT BE RUN.
/PASS:DDDDD	EXECUTE DDDDD PASSES (DDDDD = 1 TO 64000)
/FLAGS:FLGS	SET SPECIFIED FLAGS. FLAGS ARE DESCRIBED IN SECTION 2.3.
/EOP:DDDDD	REPORT END OF PASS MESSAGE AFTER EVERY DDDDD PASSES ONLY. (DDDDD = 1 TO 64000)
/UNITS:LIST	TEST/ADD/DROP ONLY THOSE UNITS SPECIFIED IN THE LIST. LIST EXAMPLE - /UNITS:0:5:10:12 USE UNITS 0,5,10,11,12 (UNIT NUMBERS = 0-63)

EXAMPLE OF SWITCH USAGE:

START/TESTS:1-5/PASS:1000/EOP:100

THE EFFECT OF THIS COMMAND WILL BE: 1) TESTS 1 THROUGH 5 WILL BE EXECUTED, 2) ALL UNITS WILL TESTED 1000 TIMES AND 3) THE END OF PASS MESSAGES WILL BE PRINTED AFTER EACH 100 PASSES ONLY. A SWITCH CAN BE RECOGNIZED BY THE FIRST THREE CHARACTERS. YOU MAY, FOR EXAMPLE, TYPE "/TES:1-5" INSTEAD OF "/TESTS:1-5".

BELOW IS A TABLE THAT SPECIFIES WHICH SWITCHES CAN BE USED BY EACH COMMAND.

	TESTS	PASS	FLAGS	EOP	UNITS
START	X	X	X	X	X
RESTART	X	X	X	X	X
CONTINUE		X	X	X	
PROCEED			X		
DROP					X
ADD					X
PRINT					
DISPLAY					X
FLAGS					
ZFLAGS					
EXIT					

2.3 FLAGS

FLAGS ARE USED TO SET UP CERTAIN OPERATIONAL PARAMETERS SUCH AS LOOPING ON ERROR. ALL FLAGS ARE CLEARED AT STARTUP AND REMAIN CLEARED UNTIL EXPLICITLY SET USING THE FLAGS SWITCH. FLAGS

ARE ALSO CLEARED AFTER A START COMMAND UNLESS SET USING THE FLAG SWITCH. THE ZFLAGS COMMAND MAY ALSO BE USED TO CLEAR ALL FLAGS. WITH THE EXCEPTION OF THE START AND ZFLAGS COMMANDS, NO COMMANDS AFFECT THE STATE OF THE FLAGS; THEY REMAIN SET OR CLEARED AS SPECIFIED BY THE LAST FLAG SWITCH.

FLAG	EFFECT
HOE	HALT ON ERROR - CONTROL IS RETURNED TO RUNTIME SERVICES COMMAND MODE
LOE	LOOP ON ERROR
IER*	INHIBIT ALL ERROR REPORTS
IBR*	INHIBIT ALL ERROR REPORTS EXCEPT FIRST LEVEL (FIRST LEVEL CONTAINS ERROR TYPE, NUMBER, PC, TEST AND UNIT)
IXE*	INHIBIT EXTENDED ERROR REPORTS (THOSE CALLED BY PRINTX MACRO'S)
PRI	DIRECT MESSAGES TO LINE PRINTER
PNT	PRINT TEST NUMBER AS TEST EXECUTES
BOE	"BELL" ON ERROR
UAM	UNATTENDED MODE (NO MANUAL INTERVENTION)
ISR	INHIBIT STATISTICAL REPORTS (DOES NOT APPLY TO DIAGNOSTICS WHICH DO NOT SUPPORT STATISTICAL REPORTING)
IDR	INHIBIT PROGRAM DROPPING OF UNITS
ADR	EXECUTE AUTODROP CODE
LOT	LOOP ON TEST

*ERROR MESSAGES ARE DESCRIBED IN SECTION 3.1

SEE THE XXDP* USER'S MANUAL FOR MORE DETAILS ON FLAGS. YOU MAY SPECIFY MORE THAN ONE FLAG WITH THE FLAG SWITCH. FOR EXAMPLE, TO CAUSE THE PROGRAM TO LOOP ON ERROR, INHIBIT ERROR REPORTS AND TYPE A "BELL" ON ERROR, YOU MAY USE THE FOLLOWING STRING:

```
/FLAGS:LOE:IER:BOE
```

2.4 HARDWARE QUESTIONS

WHEN A DIAGNOSTIC IS STARTED, THE RUNTIME SERVICES WILL PROMPT THE USER FOR HARDWARE INFORMATION BY TYPING "CHANGE HW (L) ?" YOU MUST ANSWER "Y" AFTER A START COMMAND UNLESS THE HARDWARE INFORMATION HAS BEEN "PRELOADED" USING THE SETUP UTILITY (SEE CHAPTER 14 OF THE XXDP* USER'S MANUAL). WHEN YOU ANSWER THIS QUESTION WITH A "Y", THE RUNTIME SERVICES WILL ASK FOR THE NUMBER OF UNITS (IN DECIMAL).

AFTER INITIAL STARTING OF THE PROGRAM (START COMMAND TO THE DIAGNOSTIC SUPERVISOR), THE PROGRAM WILL ISSUE THE "CHANGE HW?" QUESTION TO ASK IF THE HARDWARE PARAMETERS ARE TO BE CHANGED (BY THE OPERATOR).

ON A "N" (NO) RESPONSE TO THE "CHANGE HW?" QUESTION, THE DIAGNOSTIC WILL RUN USING THE DEFAULT VALUES FOR ALL QUESTIONS. THE DEFAULT ADDRESS AND VECTOR ARE:

TSBA/TSDB = 172520, VECTOR = 224

ON A "Y" (YES) RESPONSE TO THE QUESTION, THE FOLLOWING QUESTIONS WILL THEN BE ASKED TO ALLOW THE OPERATOR TO SELECT THE UNITS TO BE TESTED. A VALUE, IF PRESENT, LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN IF ONLY A CARRIAGE RETURN IS TYPED AS A RESPONSE. A "(D)" IN A QUESTION INDICATES THAT A DECIMAL NUMBER IS REQUIRED AS A RESPONSE. AN "(O)" INDICATES AN OCTAL NUMBER IS BEING SOLICITED. AN "(L)" INDICATES THAT A LOGICAL RESPONSE IS TO BE MADE: "Y" FOR YES, "N" FOR NO.

UNITS (D) ? <ENTER THE NUMBER OF M7196 CONTROLLERS
PRESENT TO BE TESTED>

UNIT 0

DEVICE ADDRESS (O) 172520 ? <ENTER THE ADDRESS OF THE
TSBA/TSDB REGISTER>

VECTOR (O) 224 ? <ENTER ADDRESS OF INTERRUPT
VECTOR>

THE ADDRESS AND VECTOR QUESTIONS WILL BE ASKED FOR EACH OF THE NUMBER OF UNITS (CONTROLLERS) SPECIFIED IN THE "# UNITS?" QUESTION. LOGICAL UNIT NUMBERS ARE ASSIGNED IN ORDER, BEGINNING AT 0. UP TO FOUR UNITS CAN BE SELECTED FOR TESTING AS FOLLOWS:
UP TO 4 TSV05 CONTROLLERS PER 11/23 AND UP TO 2 DRIVES PER CONTROLLER

2.5 SOFTWARE QUESTIONS

AFTER YOU HAVE ANSWERED THE HARDWARE QUESTIONS OR AFTER A RESTART OR CONTINUE COMMAND, THE RUNTIME SERVICES WILL ASK FOR SOFTWARE PARAMETERS. THESE PARAMETERS WILL GOVERN SOME DIAGNOSTIC SPECIFIC OPERATION MODES. YOU WILL BE PROMPTED BY "CHANGE SW (L) ?" IF YOU WISH TO CHANGE ANY PARAMETERS, ANSWER BY TYPING "Y". THE SOFTWARE QUESTIONS AND THE DEFAULT VALUES ARE DESCRIBED IN THE NEXT PARAGRAPH(S).

THE FOLLOWING QUESTIONS ARE ASKED ON A START, RESTART, OR CONTINUE. THEY ALLOW FLEXIBILITY IN THE WAY THE PROGRAM BEHAVES.

CHANGE SW (L) ? <TYPE Y TO CAUSE THE FOLLOWING
QUESTIONS TO BE ASKED>

INHIBIT ITERATIONS (L) N ? <TYPE "Y" TO PREVENT MULTIPLE
ITERATIONS OF CERTAIN TESTS.
THIS CAUSES EACH TEST PASS TO
RUN AS QUICKLY AS POSSIBLE.
ONLY QUICK-RUNNING LOGIC
TESTS USE MULTIPLE
ITERATIONS.>

2.6 EXTENDED P TABLE DIALOGUE

WHEN YOU ANSWER THE HARDWARE QUESTIONS, YOU ARE BUILDING ENTRIES

IN A TABLE THAT DESCRIBES THE DEVICES UNDER TEST. THE SIMPLEST WAY TO BUILD THIS TABLE IS TO ANSWER ALL QUESTIONS FOR EACH UNIT TO BE TESTED. IF YOU HAVE A MULTIPLEXED DEVICE SUCH AS A MASS STORAGE CONTROLLER WITH SEVERAL DRIVES OR A COMMUNICATION DEVICE WITH SEVERAL LINES, THIS BECOMES TEDIOUS SINCE MOST OF THE ANSWERS ARE REPETITIOUS.

TO ILLUSTRATE A MORE EFFICIENT METHOD, SUPPOSE YOU ARE TESTING A DEVICE, THE XY11. SUPPOSE THIS DEVICE CONSISTS OF A CONTROL MODULE WITH EIGHT UNITS (SUB-DEVICES) ATTACHED TO IT. THESE UNITS ARE DESCRIBED BY THE OCTAL NUMBERS 0 THROUGH 7. THERE IS ONE HARDWARE PARAMETER THAT CAN VARY AMONG UNITS CALLED THE Q FACTOR. THIS Q-FACTOR MAY BE 0 OR 1. BELOW IS A SIMPLE WAY TO BUILD A TABLE FOR ONE XY11 WITH EIGHT UNITS.

♦ UNITS (0) ? 8<CR>

UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0<CR>
Q-FACTOR (0) 0 ? 1<CR>

UNIT 2
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 1<CR>
Q-FACTOR (0) 1 ? 0<CR>

UNIT 3
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 2<CR>
Q-FACTOR (0) 0 ? <CR>

UNIT 4
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 3<CR>
Q-FACTOR (0) 0 ? <CR>

UNIT 5
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 4<CR>
Q-FACTOR (0) 0 ? <CR>

UNIT 6
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 5<CR>
Q-FACTOR (0) 0 ? <CR>

UNIT 7
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 6<CR>
Q-FACTOR (0) 0 ? 1<CR>

UNIT 8
CSR ADDRESS (0) 160000<CR>
SUB-DEVICE # (0) ? 7<CR>
Q-FACTOR (0) 1 ? <CR>

NOTICE THAT THE DEFAULT VALUE FOR THE Q-FACTOR CHANGES WHEN A NON-DEFAULT RESPONSE IS GIVEN. BE CAREFUL WHEN SPECIFYING MULTIPLE UNITS!

AS YOU CAN SEE FROM THE ABOVE EXAMPLE, THE HARDWARE PARAMETERS DO NOT VARY SIGNIFICANTLY FROM UNIT TO UNIT. THE PROCEDURE SHOWN IS NOT VERY EFFICIENT.

THE RUNTIME SERVICES CAN TAKE MULTIPLE UNIT SPECIFICATIONS HOWEVER. LET'S BUILD THE SAME TABLE USING THE MULTIPLE SPECIFICATION FEATURE.

```
* UNITS (0) ? 8<CR>
```

```
UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0,1<CR>
Q-FACTOR (0) 0 ? 1,0<CR>
```

```
UNIT 3
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 2-5<CR>
Q-FACTOR (0) 0 ? 0<CR>
```

```
UNIT 7
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 6,7<CR>
Q-FACTOR (0) 0 ? 1<CR>
```

AS YOU CAN SEE IN THE ABOVE DIALOGUE, THE RUNTIME SERVICES WILL BUILD AS MANY ENTRIES AS IT CAN WITH THE INFORMATION GIVEN IN ANY ONE PASS THROUGH THE QUESTIONS. IN THE FIRST PASS, TWO ENTRIES ARE BUILT SINCE TWO SUB-DEVICES AND Q-FACTORS WERE SPECIFIED. THE SERVICES ASSUME THAT THE CSR ADDRESS IS 160000 FOR BOTH SINCE IT WAS SPECIFIED ONLY ONCE. IN THE SECOND PASS, FOUR ENTRIES WERE BUILT. THIS IS BECAUSE FOUR SUB-DEVICES WERE SPECIFIED. THE "-" CONSTRUCT TELLS THE RUNTIME SERVICES TO INCREMENT THE DATA FROM THE FIRST NUMBER TO THE SECOND. IN THIS CASE, SUB-DEVICES 2, 3, 4 AND 5 WERE SPECIFIED. (IF THE SUB-DEVICE WERE SPECIFIED BY ADDRESSES, THE INCREMENT WOULD BE BY 2 SINCE ADDRESSES MUST BE ON AN EVEN BOUNDARY.) THE CSR ADDRESSES AND Q-FACTORS FOR THE FOUR ENTRIES ARE ASSUMED TO BE 160000 AND 0 RESPECTIVELY SINCE THEY WERE ONLY SPECIFIED ONCE. THE LAST TWO UNITS ARE SPECIFIED IN THE THIRD PASS.

THE WHOLE PROCESS COULD HAVE BEEN ACCOMPLISHED IN ONE PASS AS SHOWN BELOW.

```
* UNITS (0) ? 8<CR>
```

```
UNIT 1
CSR ADDRESS (0) ? 160000<CR>
SUB-DEVICE # (0) ? 0-7<CR>
Q-FACTOR (0) 0 ? 0,1,0,...,1,1<CR>
```

AS YOU CAN SEE FROM THIS EXAMPLE, NULL REPLIES (COMMAS ENCLOSING A NULL FIELD) TELL THE RUNTIME SERVICES TO REPEAT THE LAST REPLY.

2.7 QUICK START-UP PROCEDURE (XXDP*)

TO START-UP THIS PROGRAM:

1. BOOT XXDP*
2. GIVE THE DATE AND ANSWER THE LSI AND 50HZ (IF THERE IS A CLOCK) QUESTIONS
3. TYPE "R NAME", WHERE NAME IS THE NAME OF THE BIN OR BIC FILE FOR THIS PROGRAM
4. TYPE "START"
5. ANSWER THE "CHANGE HW" QUESTION WITH "Y"
6. ANSWER ALL THE HARDWARE QUESTIONS
7. ANSWER THE "CHANGE SW" QUESTION WITH "N"

WHEN YOU FOLLOW THIS PROCEDURE YOU WILL BE USING ONLY THE DEFAULTS FOR FLAGS AND SOFTWARE PARAMETERS. THESE DEFAULTS ARE DESCRIBED IN SECTIONS 2.3 AND 2.5.

3.0 ERROR INFORMATION

3.1 TYPES OF ERROR MESSAGES

THERE ARE THREE LEVELS OF ERROR MESSAGES THAT MAY BE ISSUED BY A DIAGNOSTIC: GENERAL, BASIC AND EXTENDED. GENERAL ERROR MESSAGES ARE ALWAYS PRINTED UNLESS THE "IER" FLAG IS SET (SECTION 2.3). THE GENERAL ERROR MESSAGE IS OF THE FORM:

```
NAME TYPE NUMBER ON UNIT NUMBER TST NUMBER PC:XXXXXX
ERROR MESSAGE
```

WHERE: NAME = DIAGNOSTIC NAME
 TYPE = ERROR TYPE (SYS FATAL, DEV FATAL, HARD OR SOFT)
 NUMBER = ERROR NUMBER
 UNIT NUMBER = 0 - N (N IS LAST UNIT IN PTABLE)
 TST NUMBER = TEST AND SUBTEST WHERE ERROR OCCURRED
 PC:XXXXXX = ADDRESS OF ERROR MESSAGE CALL

BASIC ERROR MESSAGES ARE MESSAGES THAT CONTAIN SOME ADDITIONAL INFORMATION ABOUT THE ERROR. THESE ARE ALWAYS PRINTED UNLESS THE "IER" OR "IBR" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL MESSAGE.

EXTENDED ERROR MESSAGES CONTAIN SUPPLEMENTARY ERROR INFORMATION SUCH AS REGISTER CONTENTS OR GOOD/BAD DATA. THESE ARE ALWAYS PRINTED UNLESS THE "IER", "IBR" OR "IXE" FLAGS ARE SET (SECTION 2.3). THESE MESSAGES ARE PRINTED AFTER THE ASSOCIATED GENERAL ERROR MESSAGE AND ANY ASSOCIATED BASIC ERROR MESSAGES.

3.2 SPECIFIC ERROR MESSAGES

BELOW ARE SAMPLE ERROR MESSAGES. EACH ERROR MESSAGE REPRESENTS DIFFERENT TYPES OF ERRORS DETECTED BY THIS DIAGNOSTIC.

ERROR MESSAGE EXAMPLE 1

THIS ERROR IS INDICATIVE OF AN INCORRECT REGISTER OR STATUS WORD RETURNED TO THE DIAGNOSTIC. THE FIRST PART DEFINES THE TEST FUNCTION AND UNIT THAT FAILED. THE SECOND PART PROVIDES THE REGISTER BITS AND THEIR MNEMONICS FOR THE INCORRECT REGISTER OR STATUS WORDS. THE THIRD PART IS THE EXPECTED AND RECEIVED DATA.

TST: 016 FIFO EXERCISER TEST
CVTSD HRD ERR 01610 ON UNIT 00 TST 016 SUB 002 PC: 040624
FIFO STATUS (IN WORD 9) INCORRECT AFTER WRITE FIFO

TAPE BUS SIGNALS IN WORD #8: - DESIGNATOR <BIT #>
PARERR<15> IEOT <12> IFMK <9> IRDY<6> IRWD<2>
IRESV2<14> IIDENT<11> IHER <8> IONL<5> IFBY<1>
IRESV1<13> ICER <10> ISPEED<7> ILDP<4> IFPT<0>

TAPE BUS SIGNALS IN WORD #9:
DATMIS<7> ILW<6> OUTRDY<5> INRDY<4>

MESSAGE BUFFER ADDRESS = 047352

MESSAGE BUFFER CONTENTS:

WORD #0	EXPD: 100020	RECV: 100020	XOR: 000000
WORD #1	EXPD: 000012	RECV: 000012	XOR: 000000
WORD #2	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #3	EXPD: 000010	RECV: 000010	XOR: 000000
WORD #4	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #5	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #6	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #7	EXPD: 000000	RECV: 000000	XOR: 000000
WORD #8	EXPD: 070217	RECV: 070217	XOR: 000000
WORD #9	EXPD: 000074	RECV: 000034	XOR: 000040

ERROR MESSAGE EXAMPLE 2

THIS ERROR SHOWS A FATAL FUNCTION ERROR FROM THE TAPE DRIVE, IN THIS INSTANCE A UNRECOVERABLE ERROR OCCURED WHICH INDICATES THAT THE CONTROLLER MAY BE DEFECTIVE.

CVTSD HRD ERR 00159 ON UNIT 00 TST 001 SUB 005 PC: 026202
TSSR NOT CORRECT AFTER SPACE RECORDS COMMAND

TSSR = 100214

TSSR BITS SET: SC, SSR

TERMINATION CLASS CODE = UNRECOVERABLE ERROR

PACKET ADDRESS = 026420

PACKET WORD # = 140010

PACKET WORD # = 000010

PACKET WORD # = 000000

PACKET WORD # = 000024

ERROR MESSAGE EXAMPLE 3

THIS ERROR SHOWS THAT THE MOTION BIT DID NOT GET SET WHILE DOING A REWIND WITH EXTENDED FEATURES MODE ENABLED.

CVTSD HRD EPR 00121 ON UNIT 00 TST 001 SUB 002 PC: 023306
MOT BIT (XSTO) NOT SET DURING REWIND (EXTENDED FEATURES MODE)
EXPD: 000312 RECV: 000112 XOR: 000200

4.0 PERFORMANCE AND PROGRESS REPORTS

AT THE END OF EACH PASS, THE PASS COUNT IS GIVEN ALONG WITH THE TOTAL NUMBER OF ERRORS REPORTED SINCE THE DIAGNOSTIC WAS STARTED. THE "EOP" SWITCH CAN BE USED TO CONTROL HOW OFTEN THE END OF PASS MESSAGE IS PRINTED. SECTION 2.2 DESCRIBES SWITCHES.

SUCCESSFUL RUN EXAMPLE (PDP-11/23)

```
DR>STA/FLA:PNT:HOE
```

```
UNITS (0) ? 1
```

```
UNIT 0
```

```
DEVICE ADDRESS (0) 172520 ? <CR>
```

```
VECTOR (0) 224 ? <CR>
```

```
CHANGE SW (L) ? N<CR>
```

THE ABOVE COMMAND WILL START THE DIAGNOSTIC. THE COMMAND HAS TWO SWITCHES ON WHICH ARE "PRINT EACH TEST NBR AS EXECUTED" AND "HALT ON ERROR".

```
TST: 001 SKIP TAPE MARKS TEST  
TST: 002 NO-OP AND INITIALIZE TEST  
TST: 003 ERASE AND OPERATION INCOMPLETE TEST  
TST: 004 DATA PARITY TEST  
TST: 005 TEST OF OPERATIONS AT EOT TEST  
TST: 006 EXTENDED-MODE FUNCTIONS TEST  
TST: 007 RECORD BUFFERING TEST  
TST: 008 FUNCTION TIMING TEST
```

0 ERRORS

NOTE: THE DIAGNOSTIC WILL RUN CONTINUOUSLY UNLESS A PASS NUMBER LIMIT HAS BEEN SPECIFIED WITH THE "/PASS:" SWITCH.

PROGRAM RUN TIMES

THE AVERAGE RUN TIMES OF THE PROGRAM ARE LISTED BELOW. THESE FIGURES ARE TO BE USED AS A GUIDE. THE TIMING WAS DONE ON A PDP-11/23 PROCESSOR WITH A LA34 CONSOLE.

THE PROGRAM RUNS IN TWO MODES. NO ITERATIONS AND DEFAULT MODE. IN THE NO ITERATIONS MODE, EACH TEST IS RUN ONCE, WITH NO ITERATIONS. IN THE DEFAULT MODE EACH TEST IS REPEATED BY THE NUMBER OF TIMES INDICATED BY THE ITERATION COUNT. NO ITERATIONS MODE IS SELECTED BY ANSWERING THE INHIBIT ITERATIONS QUESTION WITH A "Y" (YES).

TEST NUMBER	N/I SECS.	NUMBER ITER	DEF SECS.
1	1	2	1
2	1	1	0
3	1	1	0
4	1	1	0
5	1	1	0
6	1	1	0
7	1	1	0
8	1	1	0

THE TIMES REQUIRED TO RUN TESTS 1 THROUGH 37 IN ONE COMMAND:

Q.V.	15 SECONDS
DEFAULT	16 SECONDS

5.0 DEVICE INFORMATION TABLES

WHENEVER THE PROGRAM IS STARTED, VIA THE STA(RT) COMMAND, THE SUPERVISOR REQUESTS THE FOLLOWING P-TABLES PARAMETER CHANGES:

CHANGE HW (L) ?

UNITS (D) ? <ENTER THE NUMBER OF M7196 CONTROLLERS
PRESENT TO BE TESTED>

UNIT 0

DEVICE ADDRESS (O) 172520 ? <ENTER THE ADDRESS OF THE
TSBA/TSDB REGISTER>

VECTOR (O) 224 ? <ENTER ADDRESS OF INTERRUPT
VECTOR>

THE ADDRESS AND VECTOR QUESTIONS WILL BE ASKED FOR EACH OF THE NUMBER OF UNITS (CONTROLLERS) SPECIFIED IN THE "# UNITS?" QUESTION. LOGICAL UNIT NUMBERS ARE ASSIGNED IN ORDER, BEGINNING AT 0. UP TO FOUR UNITS CAN BE SELECTED FOR TESTING.

IN ADDITION, ON A STA.T, RESTART OR CONTINUE THE SUPERVISOR REQUESTS CHANGES TO THE SOFTWARE OPERATING PARAMETERS, AS FOLLOWS:

CHANGE SW (L) ?

INHIBIT ITERATIONS (L) N ?

6.0 TEST SUMMARIES

TEST 1: WRITE TAPE MARK RETRY

THIS TEST VERIFIES PROPER OPERATION OF THE WRITE TAPE MARK RETRY COMMAND (SPACE REVERSE, ERASE, WRITE TAPE MARK).

TEST 2: SKIP TAPE MARKS

THIS TEST VERIFIES PROPER OPERATION OF THE SKIP TAPE MARKS FORWARD AND SKIP TAPE MARKS REVERSE COMMANDS. PROPER OPERATION UNDER CONTROL OF ALL COMBINATIONS OF THE ENABLE SKIP TAPE MARKS STOP (ESS) AND ENABLE TAPE MARKS STOP OFF BOT (ENB) BITS SPECIFIED BY THE WRITE CHARACTERISTICS COMMAND.

TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

THIS TEST VERIFIES PROPER OPERATION OF THE NO-OP ("CLEAN TAPE") AND INITIALIZE COMMAND (SPACE REVERSE, ERASE, WRITE DATA)

TEST 4: ERASE AND OPERATION INCOMPLETE

VERIFIES THAT AN ERASE COMMAND ISSUED WHEN THE TAPE IS POSITIONED AT BOT OPERATES PROPERLY AND ACTUALLY ERASES TAPE.

TEST 5: DATA PARTTY TEST

THIS TEST VERIFIES THAT THE DATA PARITY CIRCUITRY IN BOTH THE CONTROLLER AND THE TRANSPORT IS OPERATING PROPERLY BY FORCING DATA RECORDS WITH WRONG PARITY TO BE WRITTEN ONTO TAPE AND CHECKING THE RESULTS OBTAINED WHEN THE DATA IS READ.

TEST 6: OPERATIONS AT EOF

THIS TEST VERIFIES PROPER OPERATION OF THE WRITE DATA RETRY COMMAND (SPACE REVERSE, ERASE, WRITE DATA)

TEST 7: EXTENDED MODE FEATURES

THIS TEST VERIFIES THE OPERATION OF COMMANDS ONLY AVAILABLE WHEN THE CONTROLLER IS IN THE EXTENDED FEATURES MODE. THESE COMMANDS ARE:

REWIND WITH IMMEDIATE INTERRUPT

IF THE CONTROLLER IS NOT ALREADY IN EXTENDED FEATURES MODE, IT IS PLACED THERE VIA A WRITE SUBSYSTEM MEMORY COMMAND.

TEST 8: RECORD BUFFERING

THIS TEST VERIFIES THAT RECORD BUFFERING, USED FOR WRITE DATA AND READ NEXT COMMANDS, OPERATES PROPERLY AND IS PROPERLY CONTROLLED BY THE EXTENDED CHARACTERISTICS DATA WORD. IF THE M7196 CONTROLLER MODULE IS NOT ALREADY IN EXTENDED FEATURES MODE (AS CONTROLLED BY THE DIP SWITCH ON THE MODULE), IT IS PLACED INTO THAT MODE BY INVERTING THE SENSE OF THE SWITCH USING THE WRITE SUBSYSTEM MEMORY COMMAND. NOTE THAT RECORD BUFFERING HAS BEEN ENABLED IN PREVIOUS TESTS OF READ AND WRITE AND SO HAS BEEN PARTIALLY TESTED ALREADY. THIS TEST VERIFIES THAT BUFFERING IS ACTUALLY OPERATING.

TEST 9: FUNCTION TIMING

THIS TEST VERIFIES THAT THE TAPE TRANSPORT SEEMS TO BE WRITING RECORDS, GAPS, AND EXTENDED GAPS OF THE PROPER LENGTH. BOTH LOW AND HIGH SPEED MODES ARE TESTED. IT IS ALSO VERIFIED THAT A SKIP TAPE MARKS COMMAND WITH A COUNT OF 6 OR MORE, OPERATE THE TAPE IN HIGH-SPEED MODE. THIS TEST CAN ONLY BE RUN IF A REAL-TIME CLOCK IS AVAILABLE ON THE SYSTEM. THE TEST OPERATES BY TIMING VARIOUS TAPE-MOTION OPERATIONS, USING A NUMBER OF DIFFERENT TEST RECORD LENGTHS.

7.0 MAINTENANCE HISTORY

REVISION A - MARCH 1982

REVISION B - APRIL 1983

- FIXED TWO PROBLEMS, ONE IN TEST 1 AND THE OTHER IN TEST 8.
REF. DOYLE TO GRASKY "TSV05 CVTSDA DIAGNOSTIC PATCH"; 23-DEC-82.

```

2          .TITLE  TSV2 - PROGRAM HEADER
3          .SBTTL  PROGRAM HEADER
4
10         .MCALL  SVC
11 000000 SVC          ; INITIALIZE SUPERVISOR MACROS
12         .ENABLE LC
13         .NLIST  BEX,CND
19 000000 .ENABL  ABS,AMA
20         .*2000
21 002000 BGNMOD  TSV2
22         TSV2::
23         ;**
24         ; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
25         ; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
26         ;--
27
28 002000          POINTER BGNSW,BGNSFT,BGNAU,BGNDU,BGNRPT
29 002000          HEADER  CVTSD,B,0,655.,0
          L$NAME::          ;DIAGNOSTIC NAME
          .ASCII /C/
          .ASCII /V/
          .ASCII /T/
          .ASCII /S/
          .ASCII /D/
          .BYTE  0
          .BYTE  0
          .BYTE  0
          L$REV::          ;REVISION LEVEL
          .ASCII /B/
          L$DEPO::          ;0
          .ASCII /O/
          L$UNIT::          ;NUMBER OF UNITS
          .WORD  0
          L$TIML::          ;LONGEST TEST TIME
          .WORD  655.
          L$HPCP::          ;POINTER TO H.W. QUES.
          .WORD  L$HARD
          L$SPCP::          ;POINTER TO S.W. QUES.
          .WORD  L$SOFT
          L$MPTP::          ;PTR. TO DEF. H.W. PTABLE
          .WORD  L$HW
          L$SPTP::          ;PTR. TO S.W. PTABLE
          .WORD  L$SW
          L$LADP::          ;DIAG. END ADDRESS
          .WORD  L$LAST
          L$STA::          ;RESERVED FOR APT STATS
          .WORD  0
          L$CO::          .WORD  0
          L$DTYP::          ;DIAGNOSTIC TYPE
          .WORD  0
          L$APT::          ;APT EXPANSION
          .WORD  0
          L$DTP::          ;PTR. TO DISPATCH TABLE
          .WORD  L$DISPATCH
          L$PRIQ::          ;DIAGNOSTIC RUN PRIORITY

```


TSV2 - PROGRAM HEADER MACRO M1113 06-FEB-84 18:04

SEQ 017

```

PROGRAM HEADER
002042 000000
002044 000000
002046 000000
002050 000000
002050 003
002051 003
002052
002052 000000
002054 000000
002056
002056 000000
002060
002060 003374
002062
002062 022744
002064
002064 000000
002066
002066 000000
002070
002070 022432
002072
002072 022530
002074
002074 000000
002076
002076 003402
002100
002100 104035
002102
002102 000000
002104
002104 021636
002106
002106 022716
002110
002110 022636
002112
002112 021626
002114
002114 000000
002116
002116 000000
002120
002120 000000

L$ENVI:: .WORD 0 ;FLAGS DESCRIBE HOW IT WAS SETUP
L$EXP1:: .WORD 0 ;EXPANSION WORD
L$MREV:: .WORD 0 ;SVC REV AND EDIT *
          .BYTE C$REVISION
          .BYTE C$EDIT
L$EF:: .WORD 0 ;DIAG. EVENT FLAGS
L$SPC:: .WORD 0
L$DEVP:: .WORD 0 ; POINTER TO DEVICE TYPE LIST
L$REPP:: .WORD L$DVTYP ;PTR. TO REPORT CODE
L$EXP4:: .WORD L$RPT
L$EXP5:: .WORD 0
L$AUT:: .WORD 0 ;PTR. TO ADD UNIT CODE
L$DUT:: .WORD L$AU ;PTR. TO DROP UNIT CODE
L$LUN:: .WORD L$DU ;LUN FOR EXERCISERS TO FILL
L$DESP:: .WORD 0 ;POINTER TO DIAG. DESCRIPTION
L$LOAD:: .WORD L$DESC ;GENERATE SPECIAL AUTOLOAD EMT
          EMT E$LOAD
L$ETP:: .WORD 0 ;POINTER TO EARTBL
L$ICP:: .WORD 0 ;PTR. TO INIT CODE
L$CCP:: .WORD L$INIT ;PTR. TO CLEAN-UP CODE
L$ACP:: .WORD L$CLEAN ;PTR. TO AUTO CODE
L$PRT:: .WORD L$AUTO ;PTR. TO PROTECT TABLE
L$TEST:: .WORD L$PROT ;TEST NUMBER
L$DLY:: .WORD 0 ;DELAY COUNT
L$HIME:: .WORD 0 ;PTR. TO HIGH MEM

```

31
32
33
34
35
36
37
38
39

.SBTTL DISPATCH TABLE

!++
; THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
; IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.
!--

002122
002122 000011
002124
002124 023526
002126 032334
002130 041432
002132 046770
002134 053046
002136 056042
002140 063414
002142 073344
002144 101120

DISPATCH 9
.WORD 9
L\$DISPATCH::
.WORD T1
.WORD T2
.WORD T3
.WORD T4
.WORD T5
.WORD T6
.WORD T7
.WORD T8
.WORD T9

TSV2 PROGRAM HEADER MACRO M1113 06-FEB-84 18:04
 DEFAULT HARDWARE P-TABLE

SEQ 019

```

41          .SBTTL  DEFAULT HARDWARE P-TABLE
42
43          ;++
44          ; THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
45          ; THE TEST-DEVICE PARAMETERS.  THE STRUCTURE OF THIS TABLE
46          ; IS IDENTICAL TO THE STRUCTURE OF THE RUN-TIME P-TABLE.
47          ;--
48 002146          BGNHW  DFPTBL          ;DEFAULT HARD-P-TABLE
      002146 000003          .WORD  L10000-L$HW/2
      002150          L$HW::
      002150          DFPTBL::
49
50 002150 172520          .WORD  172520          ; 1ST (OF 2) REGISTERS.
51 002152 000224          .WORD  224           ; INTERRUPT VECTOR
52 002154 000200          .WORD  PRI04         ; INTERRUPT PRIORITY.
53 002156          ENDDW
      002156          L10000:

```

```

55          .SBTTL  SOFTWARE P-TABLE
56
57          ;**
58          ; THE SOFTWARE P-TABLE CONTAINS THE VALUES OF THE PROGRAM
59          ; PARAMETERS THAT CAN BE CHANGED BY THE OPERATOR.
60          ;**
61 002156          BGNSW  SFPTBL
002156          .WORD  L10001-L$SW/2
002160          000004
002160
002160
62
63 002160          000000          TRANSTST::          .WORD  0          ; ENABLE TEST OF TRANSPORT(S) IF =1
64 002162          000000          NOITS::          .WORD  0          ; INHIBIT ITERATION OPTION.
65          ; ... 0 = ITERATE.
66          ; ...NZ = INHIBIT ITERATE.
67 002164          000017          LERRMAX::          .WORD  15.          ; LOCAL (PER TEST) ERROR LIMIT
68 002166          000310          GERRMAX::          .WORD  200.          ; GLOBAL (PER UNIT) ERROR LIMIT
69 002170          ENDSW
002170          L10001;
70
71 002170          ENDMOD

```

TSV3 - GLOBAL AREAS
SOFTWARE P-TABLE

MACRO M1113 06-FEB-84 18:04

SEQ 021

7
8
13
19
20 002170
002170
21
22
23
24
25
26
27
28
32 002170

.TITLE TSV3 - GLOBAL AREAS
.SBTTL GLOBAL EQUATES SECTION

BGNMOD TSV3
TSV3::

.SBTTL GLOBAL EQUATES SECTION

; THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
; ARE USED IN MORE THAN ONE TEST.

EQUALS ; GET STANDARD EQUATES.

; BIT DEFINITIONS

100000	BIT15	100000
040000	BIT14	40000
020000	BIT13	20000
010000	BIT12	10000
004000	BIT11	4000
002000	BIT10	2000
001000	BIT09	1000
000400	BIT08	400
000200	BIT07	200
000100	BIT06	100
000040	BIT05	40
000020	BIT04	20
000010	BIT03	10
000004	BIT02	4
000002	BIT01	2
000001	BIT00	1
001000	BIT9	BIT09
000400	BIT8	BIT08
000200	BIT7	BIT07
000100	BIT6	BIT06
000040	BIT5	BIT05
000020	BIT4	BIT04
000010	BIT3	BIT03
000004	BIT2	BIT02
000002	BIT1	BIT01
000001	BIT0	BIT00

; EVENT FLAG DEFINITIONS
; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION

000040	EF.START	32.	; START COMMAND WAS ISSUED
000037	EF.RESTART	31.	; RESTART COMMAND WAS ISSUED
000036	EF.CONTINUE	30.	; CONTINUE COMMAND WAS ISSUED
000035	EF.NEW	29.	; A NEW PASS HAS BEEN STARTED
000034	EF.PWR	28.	; A POWER-FAIL/POWER-UP OCCURRED

; PRIORITY LEVEL DEFINITIONS

```
000340      ;
000300      PRI07== 340
000240      PRI06== 300
000200      PRI05== 240
000140      PRI04== 200
000100      PRI03== 140
000040      PRI02== 100
000000      PRI01== 40
           PRI00== 0
```

```
           ;
           ;OPERATOR FLAG BITS
           ;
000004      EVL==      4
000010      LOT==     10
000020      ADR==     20
000040      IDU==     40
000100      ISR==    100
000200      UAM==    200
000400      BOE==    400
001000      PNT==   1000
002000      PRI==   2000
004000      IXE==   4000
010000      IBE==  10000
020000      IER==  20000
040000      LOE==  40000
100000      HOE== 100000
```

33
34 002170

```
           ;
           ;KT11 MEMORY MANAGEMENT DEFINITIONS      ;DEFINE MEMORY MANAGEMENT REGISTERS
           ;*KT11 VECTOR ADDRESS
000250      MMVEC= 250
           ;*KT11 STATUS REGISTER ADDRESSES
177572      SR0=   177572
177574      SR1=   177574
177576      SR2=   177576
172516      SR3=   172516
           .IF NB
           ;*USER "I" PAGE DESCRIPTOR REGISTERS
UIPDR0= 177600
UIPDR1= 177602
UIPDR2= 177604
UIPDR3= 177606
UIPDR4= 177610
UIPDR5= 177612
UIPDR6= 177614
UIPDR7= 177616
           .IF NB
           ;*USER "D" PAGE DESCRIPTOR REGISTERS
UDPDR0= 177620
UDPDR1= 177622
UDPDR2= 177624
UDPDR3= 177626
UDPDR4= 177630
UDPDR5= 177632
UDPDR6= 177634
UDPDR7= 177636
           .ENDC
```

```
;*USER "I" PAGE ADDRESS REGISTERS
UIPAR0= 177640
UIPAR1= 177642
UIPAR2= 177644
UIPAR3= 177646
UIPAR4= 177650
UIPAR5= 177652
UIPAR6= 177654
UIPAR7= 177656
. IF NB
;*USER "D" PAGE ADDRESS REGISTERS
UDPAR0= 177660
UDPAR1= 177662
UDPAR2= 177664
UDPAR3= 177666
UDPAR4= 177670
UDPAR5= 177672
UDPAR6= 177674
UDPAR7= 177676
. ENDC
. ENDC
. IF NB
;*SUPERVISOR "I" PAGE DESCRIPTOR REGISTERS
SIPDR0= 172200
SIPDR1= 172202
SIPDR2= 172204
SIPDR3= 172206
SIPDR4= 172210
SIPDR5= 172212
SIPDR6= 172214
SIPDR7= 172216
. IF NB
;*SUPERVISOR "D" PAGE DESCRIPTOR REGISTERS
SDPDR0= 172220
SDPDR1= 172222
SDPDR2= 172224
SDPDR3= 172226
SDPDR4= 172230
SDPDR5= 172232
SDPDR6= 172234
SDPDR7= 172236
. ENDC
;*SUPERVISOR "I" PAGE ADDRESS REGISTERS
SIPAR0= 172240
SIPAR1= 172242
SIPAR2= 172244
SIPAR3= 172246
SIPAR4= 172250
SIPAR5= 172252
SIPAR6= 172254
SIPAR7= 172256
. IF NB
;*SUPERVISOR "D" PAGE ADDRESS REGISTERS
SDPAR0= 172260
SDPAR1= 172262
SDPAR2= 172264
SDPAR3= 172266
```

```
SDPAR4 = 172270
SDPAR5 = 172272
SDPAR6 = 172274
SDPAR7 = 172276
.ENDC
.ENDC
;*KERNEL "I" PAGE DESCRIPTOR REGISTERS
172300 KIPDR0 = 172300
172302 KIPDR1 = 172302
172304 KIPDR2 = 172304
172306 KIPDR3 = 172306
172310 KIPDR4 = 172310
172312 KIPDR5 = 172312
172314 KIPDR6 = 172314
172316 KIPDR7 = 172316
      .IF NB
;*KERNEL "D" PAGE
      DESCRIPTOR REGISTERS
KOPDR0 = 172320
KOPDR1 = 172322
KOPDR2 = 172324
KOPDR3 = 172326
KOPDR4 = 172330
KOPDR5 = 172332
KOPDR6 = 172334
KOPDR7 = 172336
      .ENDC
;*KERNEL "I" PAGE ADDRESS REGISTERS
172340 KIPAR0 = 172340
172342 KIPAR1 = 172342
172344 KIPAR2 = 172344
172346 KIPAR3 = 172346
172350 KIPAR4 = 172350
172352 KIPAR5 = 172352
172354 KIPAR6 = 172354
172356 KIPAR7 = 172356
      .IF NB
;*KERNEL "D" PAGE ADDRESS REGISTERS
KOPAR0 = 172360
KOPAR1 = 172362
KOPAR2 = 172364
KOPAR3 = 172366
KOPAR4 = 172370
KOPAR5 = 172372
KOPAR6 = 172374
KOPAR7 = 172376
      .ENDC
```



```

39          .SBTTL  TSV05 REGISTER AND PACKET DEFINITIONS
40
41          ;
42          ; SOME GENERAL EQUATES.
43          ;
44
45          000004  ERRVEC==      4          ; POINTER TO ERROR VECTOR FOR BUS TIME OUT.
46          000060  TTIVEC==     60          ; INTERRUPT VECTOR FOR CONSOLE INPUT
47          177560  TTICSR==    177560       ; BUS ADDRESS OF CONSOLE INPUT
48          177562  TTIBFR==    177562       ; CONSOLE INPUT DATA BUFFER
49          177520  BDVPCR==    177520       ; BDV11 PAGE CONTROL REGISTER
50
51          ;+
52          ;BIT DEFINITIONS FOR TSSR REGISTER
53          ;-
54
55          100000  SC=          BIT15       ;SPECIAL CONDITION
56          040000  BIE=        BIT14       ;BUS INTERFACE ERROR
57          020000  SCE=        BIT13       ;SANITY CHECK ERROR
58          010000  RMR=        BIT12       ;MODIFICATION REFUSED
59          004000  NXM=        BIT11       ;NONEXISTANT MEMORY ERROR
60          002000  NBA=        BIT10       ;NEED BUFFER ADDRESS
61          001400  HIADDR=     BIT9!BIT8   ;EXTENDED ADDRESS BITS
62          000200  SSR=        BIT7        ;SUB SYSTEM READY
63          000100  OFL=        BIT6        ;OFF LINE BIT
64          000060  FATERR=     BIT4!BIT5   ;FATAL TERMINATION ERROR CODES
65          000016  TERCLS=     BIT3!BIT2!BIT1 ;TERMINATION CODES
66
67          ;+
68          ;
69          ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 0
70          ;(XST0)
71          ;
72          ;-
73
74          100000  XSOTMK=     BIT15       ;TAPE MARK DETECTED
75          040000  XSORLS=     BIT14       ;RECORD LENGTH SHORT
76          020000  XSOLET=     BIT13       ;LOGICAL END OF TAPE
77          010000  XSORLL=     BIT12       ;RECORD LENGTH LONG
78          004000  XSOWLE=     BIT11       ;WRITE LOCK ERROR
79          002000  XSONEF=     BIT10       ;NON EXECUTABLE FUNCTION
80          001000  XSOILC=     BIT9        ;ILLEGAL COMMAND
81          000400  XSOILA=     BIT8        ;ILLEGAL ADDRESS
82          000200  XSOMOT=     BIT7        ;TAPE IN MOTION
83          000100  XSOONL=     BIT6        ;TRANSPORT ON LINE
84          000040  XSOIE=      BIT5        ;INTERRUPT ENABLE
85          000020  XSOVCK=     BIT4        ;VOLUME CHECK BIT
86          000010  XSOPED=     BIT3        ;PHASE ENCODED DRIVE
87          000004  XSOWLK=     BIT2        ;WRITE LOCKED
88          000002  XSOBOT=     BIT1        ;BEGINNING OF TAPE
89          000001  XSOEOT=     BIT0        ;END OF TAPE
90
91          ;+
92          ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 1
93          ;(XST1)
94          ;
95          100000  X1.DLT =     BIT15       ;DATA LATE

```

```

96          040000      X1.SPARE= BIT14          ;NOT USED
97          020000      X1.COR  = BIT13          ;CORRECTABLE DATA ERROR
98          017375      X1.MBZ  = BIT12+BIT11+BIT10+BIT9+BIT7+BIT6+BIT5+BIT4+BIT3+BIT2+BIT0 ;ALWAYS 0
99          000400      X1.RBP  = BIT8          ;READ BUS PARITY ERROR
100         000002      X1.UNC  = BIT1          ;UNCORRECTABLE DATA OR HARD ERROR
101
102          ;+
103          ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 2
104          ;(XST2)
105          ;-
106          100000      X2.OPM  = BIT15          ;OPERATION IN PROGRESS (TAPE MOVING)
107          040000      X2.RCE  = BIT14          ;RAM CHECKSUM ERROR
108          035400      X2.SPARE= BIT13+BIT12+BIT11+BIT9+BIT8      ;NOT USED BY TSV05 (ALWAYS=0)
109          002000      X2.WCF  = BIT10          ;WRITE CLOCK FAILURE (FIFO NOT EMPTIED BY TRANSPORT)
110          000200      X2.EXTF = BIT7          ;IF WRITE CHAR CMD THEN = EXTENDED FEATURES ENABLED
111          000100      X2.BUFE = BIT6          ;IF WRITE CHAR CMD THEN = BUFFERING ENABLED
112          000077      X2.REV  = 000077        ;IF WRITE CHAR CMD THEN = MICROCODE REVISION LEVEL
113          000007      X2.UNIT = BIT2+BIT1+BIT0 ;IF GET STATUS THEN = CURRENTLY SELECTED UNIT NO.
114
115          ;+
116          ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 3
117          ;(XST3)
118          ;-
119          177400      X3.MDE  = 177400        ;MICRO-DIAGNOSTIC ERROR CODE
120          000200      X3.SPARE= BIT7          ;NOT USED BY TSV05
121          000100      X3.OPI  = BIT6          ;OPERATION INCOMPLETE
122          000040      X3.REV  = BIT5          ;REVERSE
123          000020      X3.TRF  = BIT4          ;TRANSPORT RESPONSE FAILURE
124          000010      X3.DCK  = BIT3          ;DENSITY CHECK
125          000006      X3.MBZ  =BIT2+BIT1      ;NOT USED ALWAYS 0
126          000001      X3.RIB  = BIT0          ;REVERSE INTO BOT
127
128          ;+
129          ;BIT DEFINITIONS FOR EXTENDED STATUS REGISTER 4
130          ;(XST4)
131          ;-
132          100000      X4.HSP  = BIT15          ;HIGH SPEED
133          040000      X4.RCE  = BIT14          ;RETRY COUNT EXCEEDED
134          020000      X4.TSM  = BIT13          ;TRANSPORT SPECIAL MODE
135          017400      X4.MBZ  = BIT12+BIT11+BIT10+BIT9+BIT6      ;NOT USED ALWAYS 0
136          000377      X4.WRC  = 000377        ;WRITE RETRY COUNT FIELD
137
138          ;+
139          ;
140          ;TSSR TERMINATION CODES (BIT 0-2)
141          ;
142          ;-
143
144          000006      TSREJ= 3+2          ;COMMAND REJECTED
145          000006      UNREC= 6          ;UNRECOVERABLE ERROR
146
147          ;+
148          ;
149          ;DEVICE REGISTER OFFSETS
150          ;
151          ;-
152

```

```

153      000000      TSBA== 0
154      000000      TSDB== 0      ;TSDB/TSBA REGISTER
155      000001      TSBAH== 1
156      000001      TSDBH== 1      ;TSDB/TSBA REGISTER HIGH BYTE
157      000002      TSSR== 2      ;TSSR REGISTER
158      000003      TSSRH== 3      ;TSSR REGISTER HIGH BYTE
159
160      ;*
161      ; TSDB ADDRESS BIT DEFINITIONS
162      ;-
163      000003      A1716  = BIT1:BIT0      ;ADDRESS BITS 17:16 ARE IN 1:0
164
165      ;*
166      ; COMMAND DEFINITIONS
167      ;-
168      000017      P.GETSTAT      = 17      ;GET STATUS
169      000013      P.INIT          = 13      ;INITIALIZE
170      000012      P.CONTROL      = 12      ;CONTROL COMMANDS
171      000011      P.FORMAT       = 11      ;FORMAT
172      000010      P.POSITION     = 10      ;POSITION
173      000006      P.WRTSUB       = 6       ;SUBSYSTEM WRITE
174      000005      P.WRITE        = 5       ;WRITE
175      000004      P.WRTCHAR      = 4       ;WRITE CHARACTERISTICS
176      000001      P.READ         = 1       ;READ
177
178      ;*
179      ; COMMAND PACKET HEADER WORD BIT DEFINITIONS
180      ;-
181      100000      P.ACK          = BIT15      ;BUFFER AVAIL FOR CONTROLLER
182      040000      P.CVC          = BIT14      ;CLEAR VOLUME CHECK
183      020000      P.OPP          = BIT13      ;REVERSE SEQUENCE OF DATA BITS
184      010000      P.SWB         = BIT12      ;SWAP BYTES IN MEMORY
185      007400      P.MODE         = BIT11:BIT10:BIT9:BIT8 ;EXTENDED COMMAND MODE FIELD
186      000200      P.IE          = BIT7       ;INTERRUPT ENABLE
187      000140      P.FMT         = BIT6:BIT5   ;PACKET HEADER TYPE (ALWAYS=0)
188      000037      P.CMD         = 37        ;MAJOR COMMAND FIELD
189
190      ;*
191      ; CONTROL COMMAND MODE CODES
192      ;-
192      000000      PC.RELEASE     = 0*256.    ;RELEASE BUFFER
193      00C400      PC.REWIND      = 1*256.    ;REWIND
194      001C00      PC.NOOP        = 2*256.    ;NO-OP
195      002000      PC.IEREW       = 4*256.    ;REWIND IMMEDIATE INTERRUPT
196      002400      PC.ERASE       = 5*256.    ;SECURITY ERASE
197
198      ;*
199      ; CONTROLLER RAM DEFINITIONS
200      ;-
201      000167      RMCHBEG = 167      ;CHARACTERISTICS IO DATA BEGIN RAM ADDRESS
202      000200      RMCHEND = 200      ;CHARACTERISTICS IO DATA END RAM ADDRESS
203      000201      RMPKTBEG = 201     ;COMMAND PACKET BEGIN RAM ADDRESS
204      000210      RMPKTEND = 210     ;COMMAND PACKET END RAM ADDRESS
205      000215      RMMSEGBEG = 215    ;MESSAGE BUFFER BEGIN RAM ADDRESS
206      000234      RMMSEGEN = 234    ;MESSAGE BUFFER END RAM ADDRESS
207
208      ;*
209      ; REGISTER DEFINITIONS IN THE MESSAGE BUFFER

```

```

210 |
211 |
212 |
213 | 000006 XST0== 6 ;EXTENDED STATUS REGISTER 0 (WORD 4)
214 | 000010 XST1== 8. ;EXTENDED STATUS REGISTER 1 (WORD 5)
215 | 000012 XST2== 10. ;EXTENDED STATUS REGISTER 2 (WORD 6)
216 | 000014 XST3== 12. ;EXTENDED STATUS REGISTER 3 (WORD 7)
217 | 000016 XST4== 14. ;EXTENDED STATUS REGISTER 4 (WORD 8)
218 |
219 |
220 |
221 | ;OFFSETS TO WORD LOCATIONS IN PACKET DEFINITIONS
222 |
223 |
224 |
225 | 000002 PKLOW = 2 ;LOW ORDER CHARACTERISTIC DATA POINTER
226 | 000004 PKHI = 4 ;HIGH ORDER CHARACTERISTIC DATA POINTER
227 | 000006 PKBCNT = 6 ;NUMBER OF BYTES IN DATA PACKET
228 |
229 | 000010 EXBCNT=10 ;NUMBER OF BYTES IN EXTENDED DATA PACKET
230 |
231 |
232 | ;DATA PACKET OFFSETS FOR WRITE SUBSYSTEM COMMAND
233 |
234 | 000000 BSELO = 0 ;BYTE 0
235 | 000001 BSEL1 = 1 ;BYTE 1
236 | 000002 SEL2 = 2 ;WORD 2
237 | 000004 SELDATA = 4 ;WORD 3
238 |
239 |
240 | ;BSELO SELECT CODES FOR WRITE SUBSYSTEM COMMAND
241 |
242 | 000000 PW.NOP = 0 ;NO-OP
243 | 000001 PW.RDRAM = 1 ;READ RAM
244 | 000002 PW.WTRAM = 2 ;WRITE RAM
245 | 000003 PW.RFIFO = 3 ;READ FIFO
246 | 000004 PW.WFIFO = 4 ;WRITE FIFO
247 | 000005 PW.RDSTAT = 5 ;READ STATUS
248 | 000006 PW.WCTL = 6 ;WRITE TAPE CONTROL
249 | 000007 PW.WFMT = 7 ;WRITE TAPE FORMAT
250 | 000010 PW.WMISC = 10 ;WRITE MISCELLANEOUS
251 | 000011 PW.WNPR = 11 ;WRITE NPR CONTROL
252 | 000020 PW.D22 = 20 ;DO MICROTEST 22
253 | 000021 PW.D11 = 21 ;DO MICROTEST 11
254 | 000022 PW.D13 = 22 ;DO MICROTEST 13
255 | 000023 PW.NO1311 = 23 ;DISABLE MICROTEST 11 AND 13
256 | 000024 PW.RDEXT = 24 ;READ EXT. TAPE STATUS (NOT SUPPORTED BY ALL TRANSPORTS)
257 |
258 |
259 | ;BSEL1 CODES FOR WRITE TAPE CONTROL
260 |
261 | 000200 WC.IFAD = BIT7 ;IFAD - FORMATTER ADDRESS
262 | 000100 WC.IOTAD = BIT6 ;ITAD0 - TRANSPORT ADDRESS BIT 0
263 | 000040 WC.I1TAD = BIT5 ;ITAD1 - TRANSPORT ADDRESS BIT 1
264 | 000020 WC.ISRESV = BIT4 ;IRESV5 - RESERVED #5
265 | 000010 WC.IREW = BIT3 ;IREW - REWIND
266 | 000004 WC.IRWU = BIT2 ;IRWU - REWIND AND UNLOAD

```

```

267          000002      WC.IFEN      * BIT11      ;IFEN   - FORMATTER ENABLE
268          000001      WC.IGO       * BIT0       ;GO     -
269
270          ;+
271          ;BSEL1 CODES FOR WRITE FORMAT
272          ;-
273          000200      WF.IHISP     * BIT7       ;IHISP  - HIGH SPEED
274          000100      WF.IWRT     * BIT6       ;IWRT   - WRITE
275          000040      WF.IREV     * BIT5       ;IREV   - REVERSE
276          000020      WF.IWFM     * BIT4       ;IWFM   - WRITE FILE MARK
277          000010      WF.IEDIT    * BIT3       ;IEDIT  - EDIT
278          000004      WF.IERASE    * BIT2       ;IERASE - ERASE
279          000002      WF.I3RESV   * BIT1       ;IRESV3 - RESERVED #3
280          000001      WF.I4RESV   * BIT0       ;IRESV4 - RESERVED #4
281
282          ;+
283          ;BSEL1 CODES FOR WRITE MISCELLANEOUS SUBCOMMAND
284          ;-
285          000200      MS.EXT       * BIT7       ;INVERT SENSE OF EXTENDED FEATURES SWITCH
286          000020      MS.RSFIFO    * BIT4       ;RESET FIFO AND INPUT PARITY ERRORR
287          000010      MS.RSTAPE    * BIT3       ;RESET TAPE STATUS IN 2 FLIP-FLOPS
288          000006      MS.ATTN     * BIT2:BIT1 ;ATTENTION TRIGGER FIELD
289          000001      MS.RSD      * BIT0       ;RESET TIMER A,B THEN DELAY TIMES IN SEL2
290
291          ;+
292          ; MS.ATTN SUBCODES
293          ;-
294          000000      MSA.NGP     * 0*2       ;NO-OP (NOTHING TRIGGERED)
295          000002      MSA.VOL     * 1*2       ;SIMULATE ON-LINE/OFF-LINE TRANSITION
296          000004      MSA.NRAM    * 2*2       ;FORCE NON-FATAL RAM ERROR (FORCES ERRCODE 54)
297          000006      MSA.FRAME   * 3*2       ;FORCE FATAL RAM ERROR (CAUSES SCE TO SET)
298
299          ;+
300          ; WRITE SUBSYSTEM WRITE NPR BSEL1 BIT DEFINITIONS
301          ;-
302          000200      NP.IR       * BIT7       ;INTERRUPT REQUEST (0-1 TRANSITION)
303          000100      NP.OUT     * BIT6       ;TAPE DATA DIRECTION OUT (0= IN)
304          000040      NP.LOOP    * BIT5       ;ENABLE TRANSPORT LOOPBACK
305          000020      NP.WRP     * BIT4       ;WRITE CORRECT PARITY (SET=0 TO WRITE WRONG)
306
307          ;+
308          ; READ STATUS MESSAGE BUFFER BIT DEFINITIONS
309          ;-
310          000200      S2.DIM      * BIT7       ;WORD #9 BYTE 2 DATA IN MISS
311          000100      S2.ILW     * BIT6       ; ILW H
312          000040      S2.OUTRDY   * BIT5       ; OUT RDY H
313          000020      S2.INRDY   * BIT4       ; IN RDY H
314          000010      S2.ATIMR   * BIT3       ; TIMER A FLAG H
315          000004      S2.BTIMR   * BIT2       ; TIMER B FLAG H
316          000003      S2.UNDEF   * BIT1:BIT0 ;(UNDEFINED)
317          100000      S1.PARIN    * BIT15      ;WORD #8 BYTE 1 PARIN H
318          040000      S1.I2RESV  * BIT14      ; IRESV2
319          020000      S1.I1RESV  * BIT13      ; IRESV1
320          010000      S1.IEOT    * BIT12      ; IEOT L
321          004000      S1.IIDENT  * BIT11      ; IIDENT H
322          002000      S1.ICER    * BIT10      ; ICER H
323          001000      S1.IFMK    * BIT9       ; IFMK H
324          000400      S1.IHER    * BIT8       ; IHER H
325          000200      S0.ISPEED  * BIT7       ;WORD #8 BYTE 0 ISPEED H

```

```

324      000100      SO.IRDY      ▫ BIT6      ;      IRDY L
325      000040      SO.IONL      ▫ BIT5      ;      IONL L
326      000020      SO.ILOP      ▫ BIT4      ;      ILOP L
327      000010      SO.IDBY      ▫ BIT3      ;      IDBY L
328      000004      SO.IRWD      ▫ BIT2      ;      IRWD L
329      000002      SO.IFBI      ▫ BIT1      ;      IFBI L
330      000001      SO.IFPT      ▫ BIT0      ;      IFPT L
331                                     .SBTTL  SPECIAL MACROS AND OPDEFS.
332
333      ;*
334      ;SAVE GENERAL REGS 1 TO 5
335      ;-
336
337      .MACRO  SAVREG
338      JSR    R5,REGSAV
339      .ENDM
340
341      ;*
342      ; MACRO TO FORCE AN ERROR
343      ;-
344      .MACRO  FORCERROR      TAG,NOTSSR
345      .NLIST
346      .IIF NDF LISTALL, .NLIST
347      .LIST
348      .IF B NOTSSR
349      MOV    TSSR(R5),R1      ;READ TSSR
350      .ENDC
351      MOV    FORCER,FORCER    ;IS FORCER SET? (LEAVE C BIT ALONE)
352      BNE   TAG              ;BR IF YES
353      .NLIST
354      .IIF NDF LISTALL, .LIST
355      .LIST
356      .ENDM
357
358      ;*
359      ; MACRO TO FORCE AN EXIT TO AVOID SECTION ITERATIONS
360      ; WILL EXIT TO A LABEL IF FORCER IS NEGATIVE
361      ; SO TO FORCE ERRORS AND EXIT ON 1 ERROR SET
362      ; FORCER TO 177777
363      ; TO FORCE ERRORS AND ITERATIONS SET FORCER TO 1.
364      ;-
365      .MACRO  FORCEEXIT      TAG
366      .NLIST
367      .IIF NDF LISTALL, .NLIST
368      .LIST
369      MOV    FORCER,FORCER    ;IS FORCER NEGATIVE?
370      BMI   TAG              ;BR IF YES
371      .NLIST
372      .IIF NDF LISTALL, .LIST
373      .LIST
374      .ENDM
375      ;*
376      ; MACRO TO INCREMENT ERROR COUNTS
377      ;-
378      .MACRO  NEXT.ERRNO
379      .NLIST
380      ;;;.IIF NDF LISTALL, .NLIST

```

```

381          ERRNO=ERRNO+1
382      :;;.IF NDF LISTALL, .LIST
383      .LIST
384      .ENDM
385
386      :+
387      ;MACRO TO PERFORM XOR
388      :-
389
390          .MACRO XOR      A,B
391          MOV      A,-(SP)
392          BIC      B,(SP)
393          BIC      A,B
394          BIS      (SP)+,B
395          .ENDM
396
397          000000          EN=0          ; INITIALIZE ERROR NUMBER
398          .SBITL FORCER - FORCE ERROR FLAG
399
400      ;
401      ; THE FOLLOWING LOCATIONS MAY BE PATCHED BY THE USER
402      ; TO OBTAIN THE RESULTS DESCRIBED FOR EACH.
403      ;
404
405      002170 000000 FORCER::      0          ; FORCE TYPE ALL HARD ERRORS (THE ONES CALLED -
406      ; - BY THE MACRO "IFERROR"). AN ERROR NEED NOT -
407      ; - EXIST, JUST ASSUME AND TYPE THE MESSAGE.
408          .SBTTL GLOBAL DATA SECTION
409
410      :++
411      ;THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
412      ;IN MORE THAN ONE TEST.
413      ;--
414
415      ;
416      ;THE FOLLOWING DATA ARE SET FOR EACH UNIT AT INIT TIME.
417      ;SINGLE UNIT DEFAULTS (LISTED) ARE IN THE DEFAULT P-TABLE.
418      ;
419      002172 000000 EPRTSW::      .WORD      0          ;PRINT SWITCH
420      002174 000000 UNITN::      .WORD      0          ;UNIT # UNDER TEST.
421      002176 000000 QVP::      .WORD      0          ;QUICK VERIFY FLAG.
422      002200 000000 CSRADDR:: .WORD      0          ;ADDRESS OF CSR FOR CURRENT DEVICE
423      002202 000224 IVEC::      .WORD      224         ;INTERRUPT VECTOR
424      002204 000200 IPRI::      .WORD      PRI04        ;INTERRUPT PRIORITY.
425      002206 000000 TSTCNT:: .WORD      0          ;NUMBER OF TESTS RUN IN THIS PASS
426      002210 000000 LOOPCNT:: .WORD      0          ;REMAINING ITERATION COUNT FOR TEST
427      002212 000000 DEVCNT:: .WORD      0          ;NUMBER OF DEVICE UNDER TEST
428      002214 000000 FATFLG:: .WORD      0          ;SET IF FATAL ERROR IS DETECTED IN TEST
429      002216 000000 INTRECV:: .WORD      0          ;SET IF TAPE INTERRUPT WAS RECEIVED
430      002220 000000 EXTFEA:: .WORD      0          ;EXTENDED FEATURES SOFTWARE SW 0=OFF;1=ON
431      002222 000000 BENBSW:: .WORD      0          ;BUFFER ENABLE SWITCH SW 0=OFF;1=ON
432      002224 000000 EXPD::      .WORD      0          ;EXPECTED RAM DATA FOR PRAMPKT ROUTINE
433      002226 000000 RECV::      .WORD      0          ;RECEIVED RAM DATA FOR PRAMPKT ROUTINE
434      002230 000000 ERRHI::      .WORD      0          ;HIGH ADDRESS MEMORY ERROR
435      002232 000000 ERRLO::      .WORD      0          ;LOW ADDRESS MEMORY ERROR
436      002234          RAMDATA:: .BLKW      16.         ;DATA READ FROM RAM PACKET OR MESSAGE BUF AREA
437      002274 000000 RAMSIZ::      .WORD      0          ;RAM DATA SIZE FOR PRAMPKT ROUTINE

```

TSV3 - GLOBAL AREAS
GLOBAL DATA SECTION

MACRO M1113 06-FEB-84 18:04

SEQ 032

```

438 002276 000000 RCVHIADD:: .WORD 0 ;RECEIVED BUFFER HIGH ADDRESS
439 002300 000000 RCVLOADD:: .WORD 0 ;RECEIVED BUFFER LOW ADDRESS
440 002302 000000 COUNT:: .WORD 0 ;TEST COUNT PATTERN
441 002304 000000 DATA:: .WORD 0 ;TEST DATA
442 002306 000000 TSTFLAG:: .WORD 0 ;TEST FLAG WORD
443 002310 000000 TSTPTR:: .WORD 0 ;TSTBLK POINTER
444 002312 000000 PRMNO:: .WORD 0 ;PRINT ROUTINE TEMP
445 002314 EXPMSG:: .BLKB 100. ;EXPECTED MESSAGE BUFFER DATA
446 002460 RECMMSG:: .BLKB 100. ;RECEIVED MESSAGE BUFFER DATA
447 002624 TMPBFR:: .BLKB 80. ;TEMPORARY STORAGE FOR PRINT
448 .SBTTL TSTBLK - TEST DATA TABLE
449
450
451 ;*
452 ;THIS TABLE CONTAINS TEST DATA USED IN SEVERAL TESTS
453 ;
454 ;IN SEQUENCE THE DATA IS:
455 ;
456 ; ALL ZEROS
457 ; ALL ONES
458 ; WALKING ONES
459 ; WALKING ZEROS
460 ; ALTERNATING ONES AND ZEROS
461 ;
462 ;-
463
464 002744 TSTBLK::
465 002744 000000 .WORD 0 ;ALL ZEROS
466 002746 177777 .WORD 177777 ;ALL ONES
467 002750 000001 .WORD BIT0 ;DATA FOR WALKING ONES
468 002752 000002 .WORD BIT1
469 002754 000004 .WORD BIT2
470 002756 000010 .WORD BIT3
471 002760 000020 .WORD BIT4
472 002762 000040 .WORD BIT5
473 002764 000100 .WORD BIT6
474 002766 000200 .WORD BIT7
475 002770 000400 .WORD BIT8
476 002772 001000 .WORD BIT9
477 002774 002000 .WORD BIT10
478 002776 004000 .WORD BIT11
479 003000 010000 .WORD BIT12
480 003002 020000 .WORD BIT13
481 003004 040000 .WORD BIT14
482 003006 100000 .WORD BIT15
483 003010 177776 .WORD +CBIT0 ;DATA FOR WALKING ZEROS
484 003012 177775 .WORD +CBIT1
485 003014 177773 .WORD +CBIT2
486 003016 177767 .WORD +CBIT3
487 003020 177757 .WORD +CBIT4
488 003022 177737 .WORD +CBIT5
489 003024 177677 .WORD +CBIT6
490 003026 177577 .WORD +CBIT7
491 003030 177377 .WORD +CBIT8
492 003032 176777 .WORD +CBIT9
493 003034 175777 .WORD +CBIT10
494 003036 173777 .WORD +CBIT11

```



```

495 003040 167777          .WORD    †CBIT12
496 003042 157777          .WORD    †CBIT13
497 003044 137777          .WORD    †CBIT14
498 003046 077777          .WORD    †CBIT15
499 003050 125252          .WORD    125252          ;ALTERNATING ONES, ZEROS
500 003052 052525          .WORD    052525          ;ALTERNATING ONES, ZERO OPPOSITE FROM ABOVE
501          003054          TBLEND==.
502          .SBTTL  GLOBAL ENVIRONMENT STORAGE
503          ;
504          ;STORAGE FOR DEVICE REGISTERS
505          ;
506 003054 000000 100000 000000 DUMMY: 0,100000,0,0      ;DUMMY DEVICE REGISTERS...
507 003064 000000 000000 000000      0,0,0,0,0,0,0,0,0
508          ;...FOR MULTI-UNIT CHECKOUT.
509
510 003104 000000          DUFLG::      .WORD    0          ;"DROPPED UNIT" FLAG.
511          ;INHIBITS CODE IN "CLEAN-UP".
512 003106 000000          NODEV::      .WORD    0          ;FLAG TO SAY NO DEVICE.
513
514 003110 000000          TEMP1::      .WORD    0          ;SOME TEMP LOCATIONS.
515 003112 000000          TEMP2::      .WORD    0
516 003114 000000          XXCGMM::      .WORD    0          ;XXDP+ COMM BLOCK POINTER.
517 003116 000000          FREE::      .WORD    0          ;1ST FREE MEMORY ADDRESS...
518 003120 000000          FRESIZ::      .WORD    0          ;...AND SIZE (IN WORDS).
519 003122 000000          FREEHI: .WORD    0          ;LAST WORD IN FREE SPACE
520 003124 000000          KTFLG::      .WORD    0          ;KT11, MEM AVAIL FLAG -
521          ;- .WORD    0 = <24K OR NO KT -
522          ;- NZ = >24K AND KT.
523 003126 000000          KTENABLE:: .WORD    0          ;SET BY TEST ROUTINES TO FLAG >28K UNDER TEST
524 003130 000000          NXMFLG::      .WORD    0          ;SET IF WE CAN TEST CLEARED OTHERWISE
525 003132 000000          NXML0::      .WORD    0          ;NXM LO ADDRESS BITS
526 003134 000000          NXMHI::      .WORD    0          ;NXM HI ADDRESS BITS FOR DAL'S 16-21
527 003136 000000          T23A::      .WORD    0          ;11/23A FLAG
528 003140 000000          T23B::      .WORD    0          ;11/23B FLAG
529 003142 000000          T3BFLG::      .WORD    0          ;TEST 3B FLAG †0
530 003144 002000          PST32W::      .WORD    2000        ;32W BLOCK ADDRESS FOR 32K START
531 003146 000000          SIFLAG::      .WORD    0
532 003150 000000          BADDAT::      .WORD    0          ;ACTUAL DATA
533 003152 000000          GDDAT::      .WORD    0          ;EXPECTED DATA
534 003154 000000          LOOPFL::      .WORD    0
535 003156          CTAB::          ;CONFIGURATION TABLES.
536 003156 000000          CTABM::      .WORD    0          ;CONFIG WORK.
537 003160          .WORD    0
538 003162          .WORD    0
539 003164          .WORD    0
540 003166 177777          .WORD    -1          ;END OF MEM TABLE.
541 003170          CTABE::
542          ;ERROR STATISTICS TABLE (1 WORD PER UNIT), 64 UNITS MAX:
543          ;
544          ; 0          = UNIT NOT TESTED
545          ; 100000    = UNIT ONLINE, NO ERRORS
546          ; 10XXXX    = UNIT ONLINE, ENCOUNTERED XXXX ERRORS
547          ; 160000    = UNIT DROPPED, NON-EXISTENT DEVICE REGISTER
548          ; 160001    = UNIT DROPPED, NOT IDLE AT START
549          ; 14XXXX    = UNIT DROPPED, ENCOUNTERED XXXX ERRORS
550          ;
551 003170          ERTABL:      .BLKW    64.
    
```

TSV3 - GLOBAL AREAS MACRO M1113 06-FEB-84 18:04
GLOBAL ENVIRONMENT STORAGE

SEQ 034

552 003370 000000
553
554 003372 000000

ERTABE: .WORD 0
SKIPT: .WORD 0

;1=SKIP SUBTEST 0=NO SKIP OF SUBTEST

```

556 .SBTTL GLOBAL TEXT MESSAGES
557 ;
558 ; THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
559 ; MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
560 ; MORE THAN ONE TEST.
561 ;
562 ;
563 ;
564 ; NAMES OF DLVICES SUPPORTED
565 ;
566 ;
567 003374 DEVTYP <TSV05>
003374 L$DVTYP::
003374 124 123 126 .ASCIZ /TSV05/
.EVEN

568 ;
569 ;
590 ; TEST DESCRIPTION
591 ;
592 003402 DESCRIPT <**** TSV05 LOGIC DIAGNOSTIC - CHECK TRANSPORT IF ERROR ****>
003402 L$DESC::
003402 052 052 052 .ASCIZ /**** TSV05 LOGIC DIAGNOSTIC - CHECK TRANSPORT IF ERROR ****/
.EVEN

594 ;
595 ;
596 ; BIT TO ASCII CONVERSION FOR TSSR REGISTER
597 ;
598 ;
599 003476 003536 003541 003545 TSSRBIT:: .WORD 1$,2$,3$,4$,5$,6$,7$,8$
600 003516 003577 003603 003607 .WORD 9$,10$,11$,12$,13$,14$,15$,16$
601 003536 123 103 000 1$: .ASCIZ 'SC'
602 003541 102 111 105 2$: .ASCIZ 'BIE'
603 003545 123 103 105 3$: .ASCIZ 'SCE'
604 003551 122 115 122 4$: .ASCIZ 'RMR'
605 003555 116 130 115 5$: .ASCIZ 'NXM'
606 003561 116 102 101 6$: .ASCIZ 'NBA'
607 003565 102 111 124 7$: .ASCIZ 'BIT9'
608 003572 102 111 124 8$: .ASCIZ 'BIT8'
609 003577 123 123 122 9$: .ASCIZ 'SSR'
610 003603 117 106 114 10$: .ASCIZ 'OFL'
611 003607 102 111 124 11$: .ASCIZ 'BIT5'
612 003614 102 111 124 12$: .ASCIZ 'BIT4'
613 003621 102 111 124 13$: .ASCIZ 'BIT3'
614 003626 102 111 124 14$: .ASCIZ 'BIT2'
615 003633 102 111 124 15$: .ASCIZ 'BIT1'
616 003640 102 111 124 16$: .ASCIZ 'BIT0'
617 .EVEN
618 003646 124 123 123 SFIERR: .ASCIZ 'TSSR ERROR AFTER SOFT INIT'
619 003701 124 123 123 SFHERR: .ASCIZ 'TSSR ERROR AFTER BUS RESET'
620 003734 040 040 116 NXR: .ASCIZ / NON-EXISTANT DEVICE REGISTER/
621 003773 045 101 040 NXR: .ASCIZ /#A ADDRESS: #06/
622 004014 045 101 040 TSSX: .ASCII /#A TSBA,TSSR EXP'D: #06#A,#06#N/
623 004054 045 101 040 TSSX: .ASCII /#A TSBA,TSSR REC'D: #06#A,#06#N/
624 004113 045 116 045 FUSI: .ASCII /#N#A/
625 004117 040 040 125 USI: .ASCIZ / UNEXPECTED INTERRUPT/
626 004146 040 040 111 NSI: .ASCIZ / INTERRUPT EXPECTED, NOT RECEIVED/
627 004211 045 116 045 FNOINTR: .ASCII /#N#A/

```

```

628 004215      040      040      116 NOINTR: .ASCIZ / NO INTERRUPT WAS GENERATED/
629 004252      040      040      111 IFAULT: .ASCIZ / INTERRUPT FAULT/
630 004274      045      101      040 INTX: .ASCIZ /*A CPU PC: #06#A TSBA: #06/
631 004331      040      040      042 NOINIT: .ASCIZ / "BUS-INIT" DIDN'T INITIALIZE CONTROLLER/
632 004403      040      040      042 NSINIT: .ASCIZ / "SOFT-INIT" DIDN'T INITIALIZE THE DPU/
633 004453      040      040      042 BRINIT: .ASCIZ / "BUS-RESET" DIDN'T INITIALIZE THE DPU/
634
635 004523      000              NUL: .ASCIZ //
636 004524      045      116      000 NULCR: .ASCIZ /*N/
637 004527      045      101      040 EXPGOT: .ASCIZ /*A EXP'D: #06#A, REC'D: #06/
638 004563      045      116      045 EXPGT2: .ASCIZ /*N#A EXP'D: #06#A, #06#N#A REC'D: #0#A, #06/
639 004637      045      101      040 DUAD12: .ASCIZ /*A REG(W) WRITTEN TO: #06#A REG(R) READ; EXP'D: #06#A, REC'D: #06/
640 004741      122      101      115 PKTRAM: .ASCIZ 'RAM Contents Do Not Match Packet Sent'
641 005007      040      040      103 SCME: .ASCIZ / CONFIG DOESN'T MATCH MFG. MASTER/
642 005052      127      122      111 WRTMSG: .ASCIZ 'WRITE CHARACTERISTICS Failed'
643 005107      124      123      123 WRTERR: .ASCIZ 'TSSR Incorrect After WRITE Command, More Bits Set Than SSR'
644 005202      124      123      123 RDERR: .ASCIZ 'RSSR Incorrect After READ Command, More Bits Set Than SSR'
645 005274      106      101      124 SCHERR: .ASCIZ 'FATAL ERROR IN SUBTEST - CHECK TAPE,CABLES,TRANSPORT etc.'
646 005366      105      122      122 RETERR: .ASCIZ 'ERROR IN SUBTEST - WRITE DATA RETRY FIVE TIMES FAILED'
647 005454      045      116      045 NOMEM: .ASCIZ /*N#A ***** NO NXM ADDRESS--CANNOT TEST NXM TIMEOUT. *****N'
648 005550      045      116      045 M8186: .ASCIZ /*N#A ***** 11/23A SYSTEM *****N'
649 005641      045      116      045 M8189: .ASCIZ /*N#A ***** 11/23B SYSTEM *****N'
650
651
652
653
654
655
656
657
658
659 005732
005732
660 005732
005732 013746 003106
005736 012746 003773
005742 012746 000002
005746 010600
005750 104415
005752 062706 000006
661 005756 004737 005764
662 005762
005762
005762 104423
663
664
665
666
667
668 005764 005727
669 005766 000000
670 005770 001402
671 005772 004777 177770
672 005776
005776 012746 004524
006007 012746 000001
006006 010600

```

```

;+
; THE GLOBAL ERROR REPORT SECTION CONTAINS THE PRINTB AND PRINTX
; CALLS THAT ARE USED IN MORE THAN ONE TEST.
; ASCII TEXT STRINGS ARE FOUND IN THE GLOBAL TEXT SECTION.
;--

```

```

NXRERR: BGNMSG NXRERR ;NON-EXISTANT DEVICE REGISTER.
PRINTX #NXRX,NODEV ;NODEV = NEXM ADDRESS.
MOV NCDEV,-(SP)
MOV #NXRX,-(SP)
MOV #2,-(SP)
MOV SP,RO
TRAP C#PNTX
ADD #6,SP
JSR PC,EXTEND ; PRINT EXTENSION IF REQUIRED.
ENDMSG
L10002: TRAP C#MSG

```

```

;
; THIS ROUTINE APPENDS A UNIQUE EXTENSION (IF REQUIRED)
; TO ANY OF THE ABOVE ERROR SIGNATURES.
;

```

```

EXTEND: IST (PC)+
EXTA: 0 ; 0 - NO EXTENSION.
BEQ 1$
JSR PC,@EXTA ; APPEND EXTENSION TEXT.
1$: PRINTX @NULCR ; PRINT A BLANK LINE
MOV @NULCR,-(SP)
MOV #1,-(SP)
MOV SP,RO

```

L3

TSV3 - GLOBAL AREAS MACRO M1113 06-FEB-84 18:04
GLOBAL ERROR REPORT SECTION

SEQ 037

006010	104415		TRAP	C:PNTX
006012	062706	000004	ADD	04,SP
673 006016	000207		RTS	PC

```

675          .SBTTL  PRITSSR - PRINT TSSR CONTENTS
676
677          ;+
678          ;
679          ;ROUTINE TO DISPLAY THE CONTENTS, AND BIT DEFINITIONS, OF
680          ;THE TSSR REGISTER. THIS ROUTINE IS NORMALLY CALLED ONLY
681          ;BY A MESSAGE PRINTING ROUTINE
682          ;
683          ;INPUTS:
684          ;
685          ;       R1      CONTENTS OF TSSR
686          ;
687          ;SUBORDINATE ROUTINES:
688          ;
689          ;       CHKAMB  CHECK FOR AMBIGUOUS CONTENTS
690          ;
691          ;-
692
693 006020    PRITSSR:
694 006020    SAVREG          ;SAVE GENERAL REGISTERS
695 006024    010104    MOV     R1,R4          ;SAVE THE TSSR CONTENTS
696 006026    010446    PRINTB   #TSSRFOR,R4    ;PRINT THE CONTENTS OF TSSR
        006026    010446    MOV     R4,-(SP)
        006030    012746    006473    MOV     #TSSRFOR,-(SP)
        006034    012746    000002    MOV     #2,-(SP)
        006040    010600    MOV     SP,R0
        006042    104414    TRAP    C#PNTB
        006044    062706    000006    ADD     #6,SP
697 006050    010400    MOV     R4,R0          ;GET TSSR BACK FOR CHKAMB
698 006052    004737    016124    JSR    PC,CHKAMB     ;ARE CONTENTS AMBIGUOUS ?
699 006056    103410    BCS    5$           ;BRANCH IF NOT
700 006060    PRINTX   #AMBTSSR    ;SHOW CONTENTS ARE AMBIGUOUS
        006060    012746    006713    MOV     #AMBTSSR,-(SP)
        006064    012746    000001    MOV     #1,-(SP)
        006070    010600    MOV     SP,R0
        006072    104415    TRAP    C#PNTX
        006074    062706    000004    ADD     #4,SP
701 006100    010403    5$:    MOV     R4,R3          ;CONTENTS OF TSSR
702 006102    042703    001476    BIC    #HIADDR!FATERP!TERCLS,R3    ;CLEAR ALL MULTIPLE BIT FIELDS
703 006106    001434    BEQ    20$           ;NO BITS ARE SET
704 006110    012702    002624    MOV     #TMPBFR,R2    ;TEMPORARY ASCII BUFFER
705 006114    012701    003476    MOV     #TSSRBIT,R1  ;ASCII EQUIVALENT OF BITS
706 006120    005703    10$:    TST    R3           ;REMAINING BITS TO CONVERT
707 006122    001413    BEQ    15$           ;BRANCH WHEN ALL ARE DONE
708 006124    000241    CLC                    ;CLEAR CARRY FOR SHIFT
709 006126    006103    ROL    R4           ;SHIFT NEXT BIT TO CARRY
710 006130    103006    BCC    13$           ;BRANCH IF BIT NOT SET
711 006132    011100    MOV     (R1),R0      ;POINTER TO BIT DEFINITION
712 006134    112022    11$:    MOVB   (R0)+,(R2)+   ;MOVE ASCII TO BUFFER
713 006136    001376    BNE    11$           ;MOVE ALL BITS
714 006140    112762    000054    177777    MOVB   #' ,'-1(R2)   ;INSERT A COMMA TO TERMINATE
715 006146    005721    13$:    TST    (R1)+        ;POINT TO NEXT DESCRIPTION
716 006150    000763    CB      10$         ;GET THE REMAINING BITS
717 006152    105042    15$:    CB      -(R2)       ;TERMINATE THE LINE
718 006154    PRINTX   #SSDEF,#TMPBFR    ;PRINT THE BIT DEFINITIONS
        006154    012746    002624    MOV     #TMPBFR,-(SP)
        006160    012746    006664    MOV     #SSDEF,-(SP)
    
```

```

006164 012746 000002      MOV     #2,-(SP)
006170 010600      MOV     SP,R0
006172 104415      TRAP   C$PNTX
006174 062706 000006      ADD     #6,SP
719
720 006200 010403      20$:   MOV     R4,R3          ;GET THE TSSR CONTENTS
721 006202 042703 177761      BIC     #+CTERCLS,R3   ;CLEAR ALL BUT TERMINATION
722 006206 016303 006754      MOV     TCOCOD(R3),R3  ;GET THE TERMINATION CODE MEANING
723 006212      PRINTX #TCOASC,R3      ;PRINT THE TERMINATION CODE
      006212 010346      MOV     R3,-(SP)
      006214 012746 006554      MOV     #TCCASC,-(SP)
      006220 012746 000002      MOV     #2,-(SP)
      006224 010600      MOV     SP,R0
      006226 104415      TRAP   C$PNTX
      006230 062706 000006      ADD     #6,SP
724 006234 010403      MOV     R4,R3          ;TSSR CONTENTS AGAIN
725 006236 042703 177767      BIC     #+CFATERR,R3  ;CLEAR ALL BUT FATAL TERMINATION
726 006242 001416      BEQ    25$            ;DON'T PRINT IF ZERO
727 006244 006203      ASR    R3
728 006246 006203      ASR    R3
729 006250 006203      ASR    R3          ;ALINE TERMINATION CODE FOR INDEX
730 006252 016303 007314      MOV     TSFCOD(R3),R3 ;GET THE FATAL TERMINATION CODE
731 006256      PRINTX #TFCASC,R3    ;PRINT THE FATAL TERMINATION CODE
      006256 010346      MOV     R3,-(SP)
      006260 012746 006615      MOV     #TFCASC,-(SP)
      006264 012746 000002      MOV     #2,-(SP)
      006270 010600      MOV     SP,R0
      006272 104415      TRAP   C$PNTX
      006274 062706 000006      ADD     #6,SP
732 006300 042704 176377      25$:   BIC     #+CHIADDR,R4  ;CLEAR ALL BUT EXTENDED ADDRESS
733 006304 001411      BEQ    30$            ;DON'T PRINT IF ZERO
734 006306      PRINTX #TEXASC,R4    ;PRINT THE EXTENDED ADDRESS BITS
      006306 010446      MOV     R4,-(SP)
      006310 012746 006513      MOV     #TEXASC,-(SP)
      006314 012746 000002      MOV     #2,-(SP)
      006320 010600      MOV     SP,R0
      006322 104415      TRAP   C$PNTX
      006324 062706 000006      ADD     #6,SP
735 006330 013703 002172      30$:   MOV     EPRTSW,R3      ;PRINT MESSAGE BUFFER ADDRESS
736 006334      PRINTX R3            ;PRINT PROPER MESSAGE
      006334 010346      MOV     R3,-(SP)
      006336 012746 000001      MOV     #1,-(SP)
      006342 010600      MOV     SP,R0
      006344 104415      TRAP   C$PNTX
      006346 062706 000004      ADD     #4,SP
737 006352 000207      RTS     PC            ;RETURN TO CALLER
738
753 006354      045      116      045  EPRT1: .ASCIZ '###A *****CHECK TRANSPORT*****'
754 006413      045      116      045  EPRT2: .ASCIZ '###A *****CHECK PARITY SWITCH IN TRANSPORT*****'
756 006473      045      116      045  TSSRFOR: .ASCIZ '###A TSSR = #06'
757 006513      045      116      045  TEXASC: .ASCIZ '###A Extended Address Bits = #06'
758 006554      045      116      045  TCOASC: .ASCIZ '###A Termination Class Code = #T'
759 006615      045      116      045  TFCASC: .ASCIZ '###A Fatal Termination Class Code = #T'
760 006664      045      116      045  TSSDEF: .ASCIZ '###A TSSR Bits Set: #T'
761 006713      045      116      045  AMBTSSR: .ASCIZ '###A TSSR Contents Are Ambiguous'
762
763 006754 006774 007017 007045  TCOCOD: .WORD 1$,2$,3$,4$,5$,6$,7$,8$
    
```

```

764 006774      116      157      162 1#: .ASCIZ 'Normal Termination'
765 007017      124      145      162 2#: .ASCIZ 'Termination Condition'
766 007045      124      141      160 3#: .ASCIZ 'Tape Status Alert'
767 007067      106      165      156 4#: .ASCIZ 'Function Reject'
768 007107      122      145      143 5#: .ASCIZ 'Recoverable Error - Tape Position One Record Down'
769 007171      122      145      143 6#: .ASCIZ 'Recoverable Error - Tape Was Not Moved'
770 007240      125      156      162 7#: .ASCIZ 'Unrecoverable Error'
771 007264      106      141      164 8#: .ASCIZ 'Fatal Controller Error'
772              .EVEN
773
774 007314      007324 007360 007371 TSFCOD: .WORD 1#,2#,3#,4#
775 007324      111      156      164 1#: .ASCIZ 'Internal Diagnostic Failure'
776 007360      122      145      163 2#: .ASCIZ 'Reserved'
777 007371      102      165      163 3#: .ASCIZ 'Bus Interface or Sanity Check Error'
778 007435      122      145      163 4#: .ASCIZ 'Reserved'
779              .EVEN
780              .SBTTL PRIPKT - PRINT THE ADDRESS/CONTENTS OF COMMAND PACKET
781
782
783              ;
784              ; THIS ROUTINE PRINTS THE ADDRESS AND CONTENTS OF A COMMAND PACKET.
785              ; THIS ROUTINE IS NORMALLY ONLY CALLED FROM A PRINT ROUTINE.
786              ;
787              ; INPUT:
788              ;
789              ; R0      NUMBER OF WORDS IN PACKET
790              ; R3      HIGH ORDER COMMAND PACKET ADDRESS
791              ; R4      ADDRESS OF COMMAND PACKET
792              ;
793              ; NOTE:  R3 IS IGNORED IF THE KTENABLE FLAG IS CLEAR.
794              ;
795 PRIPKT::
796 007446              SAVREG              ;SAVE THE REGISTERS
797 007446              MOV      R0,R5              ;SAVE NO. OF WORDS IN PACKET
798 007452      010005              TST      KTENABLE              ;ABOVE 28K UNDER TEST?
799 007454      005737      003126              BNE      10#              ;BR IF YES
800 007460      001001              CLR      R3              ;SET HIGH ORDER ADDRESS TO 0
801 007462      005003              10#:  MOV      R3,R1              ;COPY HIGH ORDER ADDRESS
802 007464      010301              MOV      R4,R0              ;GET LOWER ADDRESS
803 007466      010400              ROL      R0              ;SHIFT BIT 15 INTO C BIT
804 007470      006100              ROL      R1              ;AND INTO HIGH ORDER.
805 007472      006101              PRINTB   @PKTADD,R1,R4              ;PRINT PACKET ADDRESS
806 007474              MOV      R4,-(SP)
807 007476      010446              MOV      R1,-(SP)
808 007500      012746      007632              MOV      @PKTADD,-(SP)
809 007504      012746      000003              MOV      @3,-(SP)
810 007510      010600              MOV      SP,R0
811 007512      104414              TRAP    C#PNTB
812 007514      062706      000010              ADD      @10,SP
813 007520      010300              15#:  MOV      R3,R0              ;GET HIGH ORDER ADDRESS
814 007522      001404              BEQ     20#              ;BR IF NOT ABOVE 28K.
815 007524      010401              MOV      R4,R1              ;GET LOW ORDER ADDRESS
816 007526      004737      017376              JSR     PC,SETMAP              ;SETUP PAR6 MAPPING FOR 18 BIT ADDRESS
817 007532      010004              MOV      R0,R4              ;GET RETURNED PAR6 ADDRESS BIAS
818 007534      005001              20#:  CLR      R1              ;SAVE WORD NUMBER
819 007536      012402              25#:  MOV      (R4)+,R2              ;GET PACKET CONTENTS
820 007540              PRINTB   @PKTFRM,R1,R2              ;PRINT THE DATA

```


TSV3 - GLOBAL AREAS MACRO M1113 06-FEB-84 18:04
 PRIPKT - PRINT THE ADDRESS/CONTENTS OF COMMAND PACKET

SEQ 041

```

007540 010246      MOV      R2,-(SP)
007542 010146      MOV      R1,-(SP)
007544 012746 007574  MOV      @PKTFRM,-(SP)
007550 012746 000003  MOV      @3,-(SP)
007554 010600      MOV      SP,R0
007556 104414      TRAP    C#PNTB
007560 062706 000010  ADD      @10,SP
814 007564 005201      INC      R1          ;NEXT WORD NUMBER
815 007566 020105      CMP      R1,R5      ;DONE ALL PACKET WORDS?
816 007570 002762      BLT     25#         ;LOOP TILL ALL DONE
817 007572 000207      RTS     PC          ;RETURN
818
819 007574      045      116      045  PKTFRM: .ASCIZ  '##NA Packet Word @#D1#A = #06'
820 007632      045      116      045  PKTADD: .ASCIZ  '##NA Packet Address = #01#05'
821
822          .EVEN
823          .SBTTL  PRIBXOR - PRINT EXPD, RECV AND XOR BYTE
824
825          ;
826          ;PRINT EXPECTED DATA, RECEIVED DATA, AND XOR OF THE DATA BYTE
827          ;THIS ROUTINE IS NORMALLY CALLED ONLY FOR PRINT ROUTINES.
828          ;
829          ;INPUTS:
830          ;
831          ;      R1      RECEIVED DATA
832          ;      R2      EXPECTED DATA
833          ;
834          ;OUTPUT:
835          ;
836          ;      R0      XOR OF EXPECTED/RECEIVED DATA
837          ;
838          ;-
839
840 007670          PRIBXOR:
841 007670          SAVREG          ;SAVE THE REGISTERS
842 007674 010203      MOV      R2,R3      ;EXPECTED DATA
843 007676          XOR      R1,R3      ;FORM THE EXCLUSIVE OR
844 007706 012700 177400  MOV      @C<377>,R0 ;BYTE MASK
845 007712 040001      BIC     R0,R1      ;SAVE LOW BYTE RECV
846 007714 040002      BIC     R0,R2      ;SAVE LOW BYTE EXPD
847 007716 040003      BIC     R0,R3      ;SAVE LOW BYTE XOR
848 007720          PRINTB @XORBFOR,R2,R1,R3 ;PRINT THE MESSAGE
      MOV      R3,-(SP)
      MOV      R1,-(SP)
      MOV      R2,-(SP)
      MOV      @XORBFOR,-(SP)
      MOV      @4,-(SP)
      MOV      SP,R0
      TRAP    C#PNTB
      ADD      @12,SP
849 007746 010300      MOV      R3,R0      ;R0 HAS XOR ON RETURN
850 007750 000207      RTS     PC          ;RETURN TO CALLER
851
852 007752      045      116      045  XORBFOR: .ASCIZ  '##NA EXPD: #03#A RECV: #03#A XOR: #03'
853          .EVEN
854          .SBTTL  PRIBXOR - PRINT EXPD, RECV AND XOR
855

```

```

856
857
858 ; PRINT EXPECTED DATA, RECEIVED DATA, AND XOR OF THE TWO
859 ; THIS ROUTINE IS NORMALLY CALLED ONLY FOR PRINT ROUTINES.
860
861 ; INPUTS:
862
863 ; R1 RECEIVED DATA
864 ; R2 EXPECTED DATA
865
866 ; OUTPUT:
867
868 ; R0 XOR OF EXPECTED/RECEIVED DATA
869
870 ; -
871
872 010020 PRIXOR:
873 010020 SAVREG ;SAVE THE REGISTERS
874 010024 010203 MOV R2,R3 ;EXPECTED DATA
875 010026 XOR R1,R3 ;FORM THE EXCLUSIVE OR
875 010036 PRINTB XORFOR,R2,R1,R3 ;PRINT THE MESSAGE
      010036 010346 MOV R3,-(SP)
      010040 010146 MOV R1,-(SP)
      010042 010246 MOV R2,-(SP)
      010044 012746 010070 MOV XORFOR,-(SP)
      010050 012746 000004 MOV #4,-(SP)
      010054 010600 MOV SP,R0
      010056 104414 TRAP C#PNTB
      010060 062706 000012 ADD #12,SP
877 010064 010300 MOV R3,R0 ;R0 HAS XOR ON RETURN
878 010066 000207 RTS PC ;RETURN TO CALLER
879
880 010070 045 116 045 XORFOR: .ASCIZ '#N#A EXPD: #06#A RECV: #06#A XOR: #06#
881 .EVEN
882 .SBTTL FRIEQU - PRINT BIT NUMBERS AS ASCII EQUIVALENT
883
884
885
886 ; ROUTINE TO CONVERT BIT VALUES TO ASCII AND PRINT THE STRING
887 ; THIS ROUTINE IS NORMALLY CALLED FROM A PRINT ROUTINE.
888
889 ; INPUTS:
890
891 ; R0 OCTAL VALUE TO CONVERT
892 ; R1 TABLE OF POINTERS TO ASCII EQUIVALENT
893
894 ; -
895
896 010136 PRIEQU:
897 010136 SAVREG ;SAVE THE REGISTERS
898 010142 000207 RTS PC ;RETURN TO CALLER
899
900 .SBTTL PRIRAM - PRINT RAM ADDRESS
901
902
903 ; PRINT CONTROLLER RAM ADDRESS.
904 ; THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.

```

TSV3 - GLOBAL AREAS MACRO M1113 06-FEB-84 18:04
 PRIRAM - PRINT RAM ADDRESS

SEQ 043

```

905
906
907
908
909
910
911 010144
912 010144
913 010150
    010150 010446
    010152 012746 010174
    010156 012746 000002
    010162 010600
    010164 104414
    010166 062706 000006
914 010172 000207
915
916 010174 045 116 045 RAMFOR: .ASCIZ 'NWA CONTROLLER RAM ADDRESS = #06'
917 .EVEN
918
919 .SBTTL PRIADD - PRINT MEMORY ERROR ADDRESS
920
921
922 ;PRINT MEMORY ADDRESS
923 ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.
924
925 ; IMPLICIT INPUTS
926
927 ; ERRHI - HIGH ORDER ADDRESS
928 ; ERRLO - LOW ORDER ADDRESS
929
930
931 010236
932 010236
933 010242 013700 002230
934 010246 013701 002232
935 010252 010102
936 010254 006101
937 010256 006100
938 010260
    010260 010246
    010262 010046
    010264 012746 010306
    010270 012746 000003
    010274 010600
    010276 104414
    010300 062706 000010
939 010304 000207
940
941 010306 045 116 045 PRIA0: .ASCIZ 'NWA MEMORY ERROR ADDRESS = #01#05'
942 .EVEN
943
944 .SBTTL PRITADD - PRINT MEMORY TEST ADDRESS
945
946
947 ;PRINT MEMORY ADDRESS
948 ;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.

; INPUTS:
; R4 RAM ADDRESS

PRIRAM:
  SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
  PRINTB @RAMFOR,R4 ;PRINT RAM ADDRESS IN ERROR
  MOV R4,-(SP)
  MOV @RAMFOR,-(SP)
  MOV @2,-(SP)
  MOV SP,R0
  TRAP C:PNTB
  ADD @6,SP
  RTS PC ;RETURN

RAMFOR: .ASCIZ 'NWA CONTROLLER RAM ADDRESS = #06'
.EVEN
.SBTTL PRIADD - PRINT MEMORY ERROR ADDRESS

;PRINT MEMORY ADDRESS
;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.

; IMPLICIT INPUTS
; ERRHI - HIGH ORDER ADDRESS
; ERRLO - LOW ORDER ADDRESS

PRIADD:
  SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
  MOV ERRHI,R0 ;GET HIGH ADDRESS
  MOV ERRLO,R1 ;GET LOW ADDRESS
  MOV R1,R2 ;COPY LOW ADDRESS
  ROL R1 ;SHIFT BIT 15 TO C BIT
  ROL R0 ;SHIFT INTO HIGH ORDER
  PRINTB @PRIA0,R0,R2 ;PRINT MEMORY ADDRESS IN ERROR
  MOV R2,-(SP)
  MOV R0,-(SP)
  MOV @PRIA0,-(SP)
  MOV @3,-(SP)
  MOV SP,R0
  TRAP C:PNTB
  ADD @10,SP
  RTS PC ;RETURN

PRIA0: .ASCIZ 'NWA MEMORY ERROR ADDRESS = #01#05'
.EVEN
.SBTTL PRITADD - PRINT MEMORY TEST ADDRESS

;PRINT MEMORY ADDRESS
;THIS ROUTINE IS NORMALLY CALLED ONLY FROM PRINT ROUTINES.

```

TSV3 - GLOBAL AREAS MACRO M1113 06-FEB-84 18:04
 PRITADD - PRINT MEMORY TEST ADDRESS

SEQ 044

```

949
950      ; IMPLICIT INPUTS
951
952      ; ERRHI   - HIGH ORDER ADDRESS
953      ; ERRLO   - LOW ORDER ADDRESS
954
955      ;
956 010352 PRITADD:
957 010352 SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
958 010356 013702 002230 MOV ERRHI,R2      ;GET HIGH ADDRESS
959 010362 013701 002232 MOV ERRLO,R1      ;GET LOW ADDRESS
960      ;MOV     R1,R2      ;COPY LOW ADDRESS
961      ;ROL     R1          ;SHIFT BIT 15 TO C BIT
962      ;ROL     R0          ;SHIFT INTO HIGH ORDER
963 010366 PRINTB #PRIT0,R1 ;PRINT MEMORY ADDRESS LOW IN ERROR
    010366 010146 MOV R1,-(SP)
    010370 012746 010434 MOV #PRIT0,-(SP)
    010374 012746 000002 MOV #2,-(SP)
    010400 010600 MOV SP,R0
    010402 104414 TRAP C#PNTB
    010404 062706 000006 ADD #6,SP
964 010410 PRINTB #PRIT1,R2 ;PRINT MEMORY ADDRESS HIGH IN ERROR
    010410 010246 MOV R2,-(SP)
    010412 012746 010477 MOV #PRIT1,-(SP)
    010416 012746 000002 MOV #2,-(SP)
    010422 010600 MOV SP,R0
    010424 104414 TRAP C#PNTB
    010426 062706 000006 ADD #6,SP
965 010432 000207 RTS PC          ;RETURN
966
967 010434 045 116 045 PRIT0: .ASCIZ 'NMA MEMORY TEST ADDRESS LOW = #06'
968 010477 045 116 045 PRIT1: .ASCIZ 'NMA MEMORY TEST ADDRESS HIGH = #06'
969      .EVEN
970      .SBTTL SPACE - SPACE RECORDS (FORWARD AND REVERSE) COMMAND
971
972      ; *
973      ;
974      ;ROUTINE TO ISSUE A SPACE RECORDS
975      ;COMMAND (FORWARD OR REVERSE)
976      ;
977      ;INPUT:
978      ;
979      ; R3 NUMBER OF RECORDS TO BE SPACED OVER
980      ; BIT15 CONTROLS DIRECTION
981      ; BIT15 = 0 IS FORWARD
982      ; BIT15 = 1 IS REVERSE
983      ; R5 FIRST DEVICE UNIBUS ADDRESS
984      ;
985      ; REQUIRES A WRITE CHARACTERISTICS DONE PREVIOUSLY
986      ;
987      ;OUTPUT:
988      ;
989      ; CARRY SET - SPACE RECORDS COMMAND OK
990      ; CLR - SPACE RECORDS FAILED
991      ;
992      ;
993      ; R0 THE CONTENTS OF R4 IS MOVED TO R0

```

TSSB - GLOBAL AREAS MACRO M1113 06-FEB-84 18:04
 SPACE - SPACE RECORDS (FORWARD AND REVERSE) COMMAND

SEQ 045

```

994
995
996      ;IMPLICIT OUTPUT:
997
998      ;      TAPE HAS BEEN MOVED
999
1000     ;SIDE EFFECTS:
1001
1002
1003     ;-
1004
1005     SPACE::
1006     010544      SAVREG      ;SAVE THE GENERAL REGISTERS
1007     010550 012737 000764 010740      MOV      #500.,SDELAY ;SET UP DELAY
1008     010556 012737 140010 010730      MOV      #140010,80$ ;SET UP COMMAND, SPACE FORWARD
1009     010564 005703                TST      R3      ;CHECK FOR DIRECTION
1010     010566 100403                BMI      5$      ;BR, IF REVERSE INDICATED
1011     010570 010337 010732      MOV      R3,90$ ;LOAD UP NUMBER OF RECORDS TO SPACE
1012     010574 000407                BR       10$     ;GO DO COMMAND
1013     010576 042703 100000      5$:    BIC      #BIT15,R3 ;CLEAR DIRECTION BIT
1014     010602 010337 010732      MOV      R3,90$ ;LOAD UP NUMBER OF RECORDS TO SPACE
1015     010606 052737 000400 010730      BIS      #BIT8,80$ ;SET REVERSE BIT IN COMMAND PACKET
1016     010614 012704 010730      10$:   MOV      #80$,R4 ;SET UP R4 WITH PACKET ADDRESS
1017     010620 010465 000000      MOV      R4,TSSB(R5) ;SEND OUT COMMAND
1018     010624 004737 016330      15$:   JSR      PC,WAITF ;WAIT FOR SSR
1019     010630 103420                BCS     20$     ;BR, IF SSR IS SET AND OK
1020     010632                DELAY    250    ;DELAY ABOUT .25 SECONDS
1021     010632 012727 000250      MOV      #250,(PC)+
1022     010636 000000                .WORD   0
1023     010640 013727 002116      MOV      L#DLY,(PC)+
1024     010644 000000                .WORD   0
1025     010646 005367 177772      DEC      -6(PC)
1026     010652 001375                BNE     -.4
1027     010654 005367 177756      DEC      -22(PC)
1028     010660 001367                BNE     .-20
1029     010662 005337 010740      DEC      SDELAY ;BUMP DELAY COUNTER DOWN
1030     010666 001356                BNE     15$     ;BR, IF MORE DELAY
1031     010670 000411                BR      60$     ;BR IF TROUBLE CARRY = CLEAR
1032     010672 016501 000002      20$:   MOV      TSSR(R5),R1 ;READ TSSR
1033     010676 012702 000200      MOV      #SSR,R2 ;SET UP EXPECTED
1034     010702 020201      25$:   CMP      R2,R1 ;ARE THEY OK
1035     010704 001401                BEQ     40$     ;BR, IF EQUAL = OK
1036     010706 000402                BR      60$     ;TROUBLE EXIT
1037     010710 000261      40$:   SEC                ;SET CARRY NO TROUBLE
1038     010712 000401                BR      70$     ;EXIT
1039     010714 000241      60$:   CLC                ;CARRY CLEAR = ERROR
1040     010716 010400                MOV      R4,R0 ;PASS PACKET ADDRESS
1041     010720 000207                RTS      PC     ;RETURN

```

TSM3 - GLOBAL AREAS MACRO M1113 06-FEB-84 18:04
 SPACL - SPACE RECORDS (FORWARD AND REVERSE) COMMAND

SEQ 046

```

1036 ;
1037 ;
1038 ;
1039 ; PACKET FOR SPACE COMMAND
1040 ;
1042 010730 .=<. +10>&177770
1044 ;
1045 ; COMMAND WORD
1046 010730 000000 80$: .WORD
1047 ; NUMBER OF RECORDS TO BE SPACED OVER WORD
1048 010732 000000 90$: .WORD
1049 010734 000000 .WORD
1050 010736 000000 .WORD
1051 010740 000000 SDELAY: .WORD 0 ; DELAY COUNTER
1052 .EVEN
1053 .SBTTL WRTCHR - WRITE CHARACTERISTICS COMMAND
1054 ;
1055 ;+
1056 ;
1057 ; ROUTINE TO ISSUE A WRITE CHARACTERISTICS
1058 ; COMMAND SO THAT OTHER COMMANDS WILL BE ACCEPTED
1059 ;
1060 ; INPUT:
1061 ;
1062 ; R4 ADDRESS OF PACKET FROM TEST
1063 ; R5 FIRST DEVICE UNIBUS ADDRESS
1064 ; REQUIRES A CALL TO SOFINIT BE DONE PREVIOUSLY
1065 ;
1066 ; OUTPUT:
1067 ;
1068 ; R0 TSSR CONTENTS
1069 ; CARRY SET - WRITE CHARACTERISTICS COMMAND OK
1070 ; CLR - WRITE CHARACTERISTICS FAILED
1071 ;
1072 ; IMPLICIT OUTPUT:
1073 ;
1074 ; MESSAGE BUFFER AND OTHER BUFFERS ALL SET UP
1075 ; SOFTWARE SWITCHES SET AS FOLLOWS:
1076 ; EXTFEA * EXTENDED FEATURES PRESENT
1077 ; BENBSW * BUFFER ENABLE SWITCH ON OR OFF
1078 ;
1079 ;
1080 ; SIDE EFFECTS:
1081 ;
1082 ;
1083 ;-
1084 ;
1085 010742 WRTCHR: ;
1086 010742 SAVREG ; SAVE THE GENERAL REGISTERS
1087 010746 005037 002222 CLR BENBSW ; CLEAR BUFFER ENABLE SWITCH
1088 010752 005037 002220 CLR EXTFEA ; CLEAR EXTENDED FEATURES SW SWITCH
1089 010756 010465 000000 10$: MOV R4,TSDB(R5) ; SEND OUT COMMAND
1090 010762 004737 016416 JSR PC,CHKTSSR ; WAIT FOR SSR
1091 010766 103401 BCS 20$ ; BR, IF SSR IS SET AND OK
1092 010770 000435 BR 60$ ; BR IF TROUBLE CARRY * CLEAR
1093 010772 016501 000002 20$: MOV TSSR(R5),R1 ; READ TSSR
1094 010776 012702 000200 MOV #SSR,R2 ; SET UP EXPECTED

```

TSS3 - GLOBAL AREAS MACRO M1113 06-FEB-84 18:04
 WRTOHR - WRITE CHARACTERISTICS COMMAND

SEQ 047

```

1095 011002 032701 000100      BIT      00FL,R1      ;WAS OFF LINE SET IN TSSR
1096 011006 001402              BEQ      25$         ;BR, IF NO OFL SET
1097 011010 052702 000100      BIS      00FL,R2      ;MAKE THEM LOOK ALIKE
1098 011014 020201              25$:    CMP      R2,R1      ;ARE THEY OK
1099 011016 001401              BEQ      40$         ;BR, IF EQUAL = OK
1100 011020 000421              BR       60$         ;TROUBLE EXIT
1101 011022 062704 000010      40$:    ADD      08.,R4      ;POINT TO WRT CHARA DATA PACKET
1102 011026 011403              MOV      (R4),R3      ;GET ADDRESS OF MESSAGE BUFFER
1103 011030 032763 000200 000012  BIT      0X2.EXTF,XST2(R3) ;EXTENDED FEATURES BIT SET?
1104 011036 001402              BEQ      45$         ;BR IF NO
1105 011040 005237 002220      INC      EXTFEA      ;SET EXTENDED FEATURES SW SWITCH
1106 011044              45$:
1107 011044 032763 000100 000012  BIT      0X2.BUFE,XST2(R3) ;BUFFER ENABLE SWITCH SET
1108 011052 001402              BEQ      50$         ;BR, IF SWITCH NOT SET
1109 011054 005237 002222      INC      BENBSW      ;SET SOFTWARE SWITCH FOR ENABLED
1110 011060              50$:
1111 011060 000261              SEC
1112 011062 000401              BR       70$         ;SET CARRY NO TROUBLE
1113 011064 000241              60$:    CLC
1114 011066 016500 000002      70$:    MOV      TSSR(R5),R0 ;RETURN TSSR CONTENTS
1115 011072 000207      RTS      PC          ;RETURN
1116              .SBTTL  REWIND - POSITION TAPE (REWIND) COMMAND
1117
1118      ;+
1119      ;
1120      ; THIS ROUTINE WILL REWIND THE SELECTED TAPE.
1121      ;
1122      ; CAUTION: THE ROUTINE DOES NOT WAIT FOR BOT
1123      ; TO ARRIVE. ALSO THE CALLER MUST CHECK FOR
1124      ; SSR TO SET IN THE TSSR
1125
1126
1127      ; CALLING SEQUENCE:
1128      ;
1129      ; DO A SOFT INIT
1130      ; DO A WRITE CHARACTERISTICS
1131      ; JSR PC,REWIND
1132
1133      ; INPUT:
1134      ;
1135      ; R5 FIRST DEVICE UNIBUS ADDRESS
1136
1137      ; OUTPUT
1138      ;
1139      ; R0 THE CONTENTS OF R4 IS PASSED TO R0
1140
1141      ;
1142      ;
1143      ;
1144 011074      REWIND::
1145 011074              SAVREG
1146 011100 012704 011170      MOV      0RWPACK,R4      ;SAVE R1-R5 UNTIL NEXT RETURN
1147 011104 010465 000000      MOV      R4,TSSR(R5)     ;GET PACKET ADDRESS
1148 011110 012703 000550      MOV      0360.,R3      ;SEND PACKET ADDRESS TO EXECUTE
1149 011114 004737 016330      10$:    MOV      0360.,R3      ;ENOUGH TIME FOR 2400' REEL TO REWIND
1150 011120 103417              JSR      PC,WAITF      ;WAIT FOR SSR TO SET
1151 011122              BCS     20$           ;LEAVE WHEN SSR IS SET
                          DELAY 250.      ;WAIT FOR .25 SECONDS

```

```

011122 012727 000372      MOV      #250.,(PC)+
011123 000000      .WORD   0
011130 013727 002116      MOV      L#DLY,(PC)+
011134 000000      .WORD   0
011136 005367 177772      DEC      -6(PC)
011142 001375      BNE      .-4
011144 005367 177756      DEC      -22(PC)
011150 001367      BNE      .-20
1152 011152 005303      DEC      R3          ;BUMP COUNTER DOWN
1153 011154 001357      BNE      10$        ;KEEP GOING
1154 011156 000241      CLC          ;CLEAR CARRY TO SET ERROR
1155 011160 010400      20$: MOV      R4,R0    ;PASS THE PACKET ADDRESS
1156 011162 000207      RTS         PC      ;RETURN
1157
1159          011170
1161 011170      RWPACK: .=<.+10>&177770
1162 011170 102010      .WORD   102010      ;POSITION COMMAND (REWIND)
1163 011172 000000      .WORD   0           ;NOT USED
1164          .SBTTL  CKRAM - COMPARE RAM TO I/O PACKET
1165
1166      ;+
1167      ;
1168      ;ROUTINE TO READ THE FIRST 8 BYTES FROM RAM
1169      ;MEMORY AND COMPARE THIS DATA TO A COMMAND PACKET.
1170      ;
1171      ;INPUT:
1172      ;
1173      ;      R4      ADDRESS OF THE COMMAND PACKET
1174      ;      R5      FIRST DEVICE UNIBUS ADDRESS
1175      ;
1176      ;OUTPUT:
1177      ;
1178      ;      CARRY   SET - RAM MATCHES PACKET
1179      ;             CLR - RAM DOES NOT MATCH PACKET
1180      ;
1181      ;IMPLICIT OUTPUT:
1182      ;
1183      ;      THE TABLE RAMDATA IS FILLED WITH THE
1184      ;      DATA HELD IN RAM.
1185      ;      RAMSIZ IS SET TO 8. FOR PRAMPKT ROUTINE
1186      ;
1187      ;SIDE EFFECTS:
1188      ;
1189      ;      THE SUBSYSTEM IS LEFT IN MAINTENANCE MODE
1190      ;
1191      ;-
1192
1193 011174      CKRAM::
1194 011174      SAVREG          ;SAVE THE GENERAL REGISTERS
1195 011200 012701 002234      MOV      #RAMDATA,R1 ;ADDRESS TO SAVE THE RAM DATA
1196 011204 012702 000201      MOV      #RMPKTBEG,R2 ;BYTE ADDRESS OF FIRST RAM DATA
1197 011210 005003      CLR      R3         ;CLEAR THE ERROR FLAG
1198 011212 004737 016416      JSR      PC,CHKTSSR  ;WAIT FOR SSR
1199 011216 112765 000000 000000      MOV      #0,TSDB(R5) ;SET MAINTENANCE MODE
1200 011224 004737 016416      10$: JSR      PC,CHKTSSR  ;WAIT FOR SSR TO SET
1201 011230 010265 000000      MOV      R2,TSDB(R5) ;SELECT NEXT RAM ADDRESS
1202 011234 004737 016416      JSR      PC,CHKTSSR  ;WAIT FOR SSR TO SET
    
```


TSV3 - GLOBAL AREAS MACRO M1113 06-FEB-84 18:04
 CKRAM2 - COMPARE RAM TO I/O CHARACTERISTICS DATA

SEQ 050

```

1260 011364 012737 000010 002274      MOV      #8.,RAMSIZ      ;ASSUME EXTFEA NOT SET
1261 011372 005737 002220              TST      EXTFEA         ;IS THE SOFTWARE EXTENDED FEATURES SET
1262 011376 001407              BEQ      25$           ;BR, IF NOT SET
1263 011400 012737 000012 002274      MOV      #10.,RAMSIZ   ;SET RAMSIZ FOR EXTEND FEATURES
1264 011406 020227 000200              CMP      R2,#ARMCHEND  ;AT END OF EXTENDED BUFFER
1265 011412 003750              BLE     10$           ;BR, IF NOT AT END YET
1266 011414 000403              BR       27$         ;AT END BRANCH
1267 011416 020227 000176 25$:    CMP      R2,#ARMCHEND-2 ;REACHED END YET ?
1268 011422 003744              BLE     10$           ;BRANCH TILL ALL READ
1269 011424 005703 27$:    TST      R3           ;WAS AN ERROR FOUND ?
1270 011426 001402              BEQ     30$         ;BRANCH IF NOT
1271 011430 000241              CLC                     ;CLEAR CARRY TO SHOW ERROR
1272 011432 000401              BR       50$         ;AND EXIT
1273 011434 000261 30$:    SEC                     ;SHOW GOOD COMPARE
1274 011436 000207 50$:    RTS      PC          ;RETURN
1275                                .SBTTL  CKMSG  - COMPARE WRITE CHAR. MESSAGE BUFFERS
1276                                ;*
1277                                ;
1278                                ;ROUTINE TO COMPARE A WRITE CHARACTERISTICS EXPD AND RECV
1279                                ;BUFFER. THE EXPECTED AND RECEIVED BUFFERS ARE STORED FOR
1280                                ;ERROR PRINT ROUTINES.
1281                                ;
1282                                ;INPUT:
1283                                ;
1284                                ;      R0      RECV MESSAGE BUFFER HIGH ORDER ADDRESS
1285                                ;      R1      RECV MESSAGE BUFFER LOW ORDER ADDRESS
1286                                ;      R2      EXPD MESSAGE BUFFER ADDRESS
1287                                ;OUTPUT:
1288                                ;
1289                                ;      CARRY   SET - MESSAGE BUFFERS MATCH
1290                                ;              CLR -MESSAGE BUFFERS DON'T MATCH
1291                                ;
1292                                ;IMPLICIT OUTPUT.
1293                                ;
1294                                ;      EXPMSG   BUFFER IS SET TO EXPD DATA
1295                                ;      RECVMSG  BUFFER IS SET TO RECV DATA
1296                                ;      RCVHIADD  SET TO HIGH ORDER ADDRESS OF RECV
1297                                ;      RCVLOADD  SET TO LOW ORDER ADDRESS OF RECV
1298                                ;
1299                                ;-
1300 011440      CKMSG::
1301 011440      SAVREG                    ;SAVE R1-R5 UNTIL NEXT RETURN
1302 011444 010037 002276      MOV      R0,RCVHIADD  ;SAVE RECV HIGH ADDRESS
1303 011450 010137 002300      MOV      R1,RCVLOAD  ;SAVE RECV LOW ADDRESS
1304 011454 005737 003126      TST      KTENABLE    ;TESTING ABOVE 28K?
1305 011460 001403              BEQ     10$           ;BR IF NO
1306 011462 004737 017376      JSR     PC,SETMAP    ;RETURN ADDRESS BIASED TO PAR6 IN R0
1307 011466 010001              MOV     R0,R1        ;GET RETURNED ADDRESS BIASED TO PAR6
1308 011470 005004 10$:    CLR      R4           ;WORD IN BUFFER
1309 011472 005003              CLR     R3           ;CLEAR ERROR SEEN FLAG
1310 011474 010205              MOV     R2,R5        ;GET EXPD BUFFER ADDRESS
1311 011476 011264 002314 15$:    MOV     (R2),EXPMSG(R4) ;SAVE EXPD FOR ERROR REPORT
1312 011502 011164 002460      MOV     (R1),RECVMSG(R4) ;SAVE RECV FOR ERROR REPORT
1313 011506 022221              CMP     (R2)+,(R1)+  ;EXPD EQUAL RECV?
1314 011510 001401              BEQ     25$         ;BR IF YES
1315 011512 005203              INC     R3           ;SET ERROR SEEN FLAG
1316 011514 062704 000002 25$:    ADD     #2,R4        ;POINT TO NEXT WORD ADDRESS

```

TSV3 - GLOBAL AREAS MACRO M1113 06-FEB-84 18:04
 CKMSG - COMPARE WRITE CHAR. MESSAGE BUFFERS

SEQ 051

```

1317 011520 020427 000014      CMP      R4,#14      ;DONE FIRST 7 WORDS?
1318 011524 003764            BLE      15$        ;BR IF NO
1319 011526 032765 000200 000012  BIT      #X2.EXTF,XST2(R5);IS EXTENDED FEATURES SET IN EXPD?
1320 011534 001403            BEQ      50$        ;BR IF NO
1321 011536 020427 000016      CMP      R4,#16      ;DONE EXTENDED FEATURES WORD?
1322 011542 003755            BLE      15$        ;BR IF NO
1323 011544 005703          50$:     TST      R3      ;ANY ERRORS SEEN?
1324 011546 001402            BEQ      55$        ;BR IF NO
1325 011550 000241            CLC                    ;SET FAILURE
1326 011552 000401            BR       60$        ;
1327 011554 000261          55$:     SEC                    ;SET SUCCESS
1328 011556 000207          60$:     RTS      PC      ;RETURN
1329                                .SBTTL  CKMSG2 - COMPARE EXPD RECV MESSAGE BUFFERS
1330                                ;+
1331                                ;
1332                                ;ROUTINE TO COMPARE AN EXPECTED AND RECEIVED MESSAGE
1333                                ;BUFFER. THE EXPECTED AND RECEIVED BUFFERS ARE STORED FOR
1334                                ;ERROR PRINT ROUTINES.
1335                                ;
1336                                ;INPUT:
1337                                ;
1338                                ;      R0      RECV MESSAGE BUFFER HIGH ORDER ADDRESS
1339                                ;      R1      RECV MESSAGE BUFFER LOW ORDER ADDRESS
1340                                ;      R2      EXPD MESSAGE BUFFER ADDRESS
1341                                ;      R3      NUMBER OF BYTES TO COMPARE
1342                                ;
1343                                ;OUTPUT:
1344                                ;
1345                                ;      CARRY  SET - MESSAGE BUFFERS MATCH
1346                                ;      CLR    - MESSAGE BUFFERS DON'T MATCH
1347                                ;
1348                                ;IMPLICIT OUTPUT:
1349                                ;
1350                                ;      EXPMSG  BUFFER IS SET TO EXPD DATA
1351                                ;      RECVMSG  BUFFER IS SET TO RECV DATA
1352                                ;      RCVHIADD  SET TO HIGH ORDER ADDRESS OF RECV
1353                                ;      RCVLOADD  SET TO LOW ORDER ADDRESS OF RECV
1354                                ;
1355                                ;-
1356 011560      CKMSG2:;
1357 011560      SAVREG                    ;SAVE R1-R5 UNTIL NEXT RETURN
1358 011564 020327 000144      CMP      R3,#RECVMSG-EXPMSG;000 IS COUNT ABOVE MAX ALLOWED?
1359 011570 003412            BLE      5$        ;000 BR IF NO
1360 011572 012703 000144      MOV      #RECVMSG-EXPMSG,R3;000
1361 011576      PRINTF #DEBUGMSG ;000
1361 011576 012746 011712      MOV      #DEBUGMSG,-(SP)
1361 011602 012746 000001      MOV      #1,-(SP)
1361 011606 010600            MOV      SP,R0
1361 011610 104417            TRAP    C#PNTF
1361 011612 062706 000004      ADD      #4,SP
1362 011616 010037 002276          5$:     MOV      R0,RCVHIADD ;SAVE RECV HIGH ADDRESS
1363 011622 010137 002300      MOV      R1,RCVLOAD ;SAVE RECV LOW ADDRESS
1364 011626 005737 003126      IST      KTENABLE ;TESTING ABOVE 28K?
1365 011632 001403            BEQ      10$        ;BR IF NO
1366 011634 004737 017376      JSR      PC,SETMAP ;RETURN ADDRESS BIASED TO PAR6 IN R0
1367 011640 010001            MOV      R0,R1 ;GET RETURNED ADDRESS BIASED TO PAR6
1368 011642 005004          10$:     CLR      R4 ;WORD IN BUFFER

```

```

1369 011644 005005          CLR      R5          ;CLEAR ERROR SEEN FLAG
1370 011646 111264 002314 15$:  MOVB    (R2),EXPMSG(R4) ;SAVE EXPD FOR ERROR REPORT
1371 011652 111164 002460          MOVB    (R1),RECVMSG(R4) ;SAVE RECV FOR ERROR REPORT
1372 011656 122221          CMPB    (R2)+,(R1)+    ;EXPD EQUAL RECV?
1373 011660 001401          BEQ     25$          ;BR IF YES
1374 011662 005205          INC     R5          ;SET ERROR SEEN FLAG
1375 011664 062704 000001 25$:  ADD     #1,R4        ;POINT TO NEXT BYTE
1376 011670 020403          CMP     R4,R3        ;DONE ALL BYTES?
1377 011672 002001          BGE     50$          ;BR IF YES
1378 011674 000764          BR     15$          ;DO NEXT BYTE
1379 011676 005705          50$:  TST     R5          ;ANY ERRORS SEEN?
1380 011700 001402          BEQ     55$          ;BR IF NO
1381 011702 000241          CLC                    ;SET FAILURE
1382 011704 000401          BR     60$          ;
1383 011706 000261          55$:  SEC                    ;SET SUCCESS
1384 011710 000207          60$:  RTS     PC          ;RETURN
1385
1386 011712      120      122      117  DEBUGMSG: .ASCIZ 'PROGRAM INTERNAL ERROR -CKMSG2 MESSAGE BUFFER EXCEEDED-';@@D
1387 012002      045      116      045  FERCM  .ASCII /NNA ***/
1388 012013      040      040      124  ERCM:  .ASCIZ / TSSR ERROR CODE REC'D = /
1389 012046      056      056      056  SJMSG: .ASCIZ /... AFTER DOING SOFT INIT/
1390 012101      124      105      123  TINERR: .ASCIZ /TEST: .../
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407 012114          BGNMSG  SFMSG
      012114          SFMSG:  JSR     PC,PRITSSR    ;PRINT CONTENTS OF TSSR REGISTER
1408 012114 004737 006020          JSR     PC,CKDROP    ;DROP UNIT, IF ALLOWED
1409 012120 004737 017262          ENDMMSG
1410 012124          L10003: TRAP   C$MSG
      012124 104423
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422

```

TSV3 GLOBAL AREAS MACRO M1113 06-FEB-84 18:04
 CKMSG2 - COMPARE EXPD RECV MESSAGE BUFFERS

SEQ 053

```

1423 012126          BGNMSG  PKTSSR
      012126          PKTSSR::
1424 012126 004737 006020      JSR    PC,PRITSSR      ;PRINT THE CONTENTS OF TSSR REGISTER
1425 012132 012700 000004      MOV    #4,R0           ;NO. OF WORDS IN PACKET
1426 012136 004737 007446      JSR    PC,PRIPKT      ;PRINT THE CONTENTS OF COMMAND PACKET
1427 012142          ENDMSG
      012142          L10004:
      012142 104423      TRAP   C#MSG

1428
1429
1430      ;PRINT ROUTINE TO PRINT THE CONTENTS OF
1431      ;TSSR AND A GET STATUS COMMAND PACKET.
1432
1433      ;INPUTS:
1434
1435      ;      R1      TSSR CONTENTS
1436      ;      R#      ADDRESS OF COMMAND PACKET
1437
1438      ;-
1439
1440 012144          BGNMSG  PKTGETS
      012144          PKTGETS::
1441 012144 004737 006020      JSR    PC,PRITSSR      ;PRINT THE CONTENTS OF TSSR REGISTER
1442 012150 012700 000002      MOV    #2,R0           ;NO. OF WORDS IN GET STATUS PACKET
1443 012154 004737 007446      JSR    PC,PRIPKT      ;PRINT THE CONTENTS OF COMMAND PACKET
1444 012160          ENDMSG
      012160          L10005:
      012160 104423      TRAP   C#MSG

1445
1446
1447      ;PRINT TSSR ERRORS FOR INITIALIZATION TESTS
1448
1449      ;INPUTS:
1450
1451      ;      R1      TSSR CONTENTS
1452      ;      R#      ADDRESS OF COMMAND PACKET
1453
1454      ;-
1455 012162          BGNMSG  SFFMSG
      012162          SFFMSG::
1456 012162 004737 006020      JSR    PC,PRITSSR      ;PRINT CONTENTS OF TSSR REGISTER
1457 012166          ENDMSG
      012166          L10006:
      012166 104423      TRAP   C#MSG

1458
1459      .SBTTL  PKTME$ - PRINT TSSR AND MESSAGE BUFFER
1460
1461      ;PRINT ROUTINE TO PRINT THE CONTENTS OF TSSR AND MESSAGE
1462      ;BUFFER FOR ERROR REPORTS
1463
1464      ;INPUTS:
1465
1466      ;      R1      CONTENTS OF TSSR
1467      ;      R2      LOW ORDER MESSAGE BUFFER
1468      ;      R3      HIGH ORDER MESSAGE BUFFER ADDRESS
1469      ;      NOTE: R3 IS IGNORED IF KTENABLE FLAG IS CLEAR
1470

```

```

1471
1472 012170
1473 012170 004737 006020
1474 012174 010200
1475 012176 010301
1476 012200 004737 014322
1477 012204
    012204
    012204 104423
1478
1479
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490 012206
    012206
1491 012206 004737 010352
1492 012212 016501 000002
1493 012216 004737 006020
1494 012222
    012222
    012222 104423
1495
1496
1497
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507
1508 012224
    012224
1509 012224 012700 000007
1510 012230 005737 002220
1511 012234 001402
1512 012236 012700 000010
1513 012242 004737 014632
1514 012246
    012246
    012246 104423
1515
1516
1517
1518

```

```

;
; BGNMSG PKTMES
PKTMES::
; JSR PC,PRITSSR ;PRINT CONTENTS OF TSSR
; MOV R2,R0 ;LOW ORDER ADDRESS
; MOV R3,R1 ;HIGH ORDER ADDRESS
; JSR PC,PRMESS ;PRINT THE MESSAGE BUFFER
; ENDMMSG
L10007:
; TRAP C#MSG
; .SBTTL ADDSSR - PRINT TEST ADDRESS AND TSSR
;
; PRINT ROUTINE TO PRINT THE CONTENTS OF
; TSSR AND A MEMORY TEST ADDRESS
;
; INPUTS:
;
; R5 FIRST DEVICE UNIBUS ADDRESS
; ERRHI HIGH ORDER MEMORY TEST ADDRESS
; ERRLO LOW ORDER MEMORY TEST ADDRESS
;
;
; BGNMSG ADDSSR
ADDSSR::
; JSR PC,PRITADD ;PRINT MEMORY TEST ADDRESS
; MOV TSSR(R5),R1 ;GET CURRENT TSSR
; JSR PC,PRITSSR ;PRINT THE CONTENTS OF TSSR REGISTER
; ENDMMSG
L10010:
; TRAP C#MSG
; .SBTTL MSGEXP - PRINT WRITE CHAR. EXPD-RCV MESSAGE BUFFERS
;
; PRINT ROUTINE TO PRINT WRITE CHARACTERISTIC MESSAGE BUFFER
;
; IMPLICIT INPUTS:
;
; EXPMSG - EXPECTED MESSAGE BUFFER
; RECMMSG - RECEIVED MESSAGE BUFFER
; RCVHIADD - RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
; RCVLOADD - RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
;
;
; BGNMSG MSGEXP
MSGEXP::
; MOV #7,R0 ;ASSUME NO EXT FEATURES
; TST EXTFEA ;EXT FEATURES SET?
; BEQ 5; ;BR IF NO
; MOV #8,R0 ;EXT FEATURE BUFFER IS 8 WORDS
; JSR PC,PRMSGEXP ;PRINT EXPD/RCV MESSAGE BUFFERS
; ENDMMSG
L10011:
; TRAP C#MSG
; .SBTTL FIFEXP - PRINT FIFO EXP/RCV DATA
;
; PRINT ROUTINE TO PRINT FIFO EXP/RCV DATA

```

```

1519
1520          R1      - BYTE COUNT
1521
1522          ; IMPLICIT INPUTS:
1523
1524          ; EXPMSG - EXPECTED MESSAGE BUFFER (CONTAINS FIFO DATA ONLY)
1525          ; RECMMSG - RECEIVED MESSAGE BUFFER (CONTAINS FIFO DATA ONLY)
1526
1527          BGNMSG  FIFEXP
1528          FIFEXP:
1529          PRINTX  @FIF1MSG,R1      ;PRINT BYTES TRANSFERRED
1530          MOV     R1,-(SP)
1531          MOV     @FIF1MSG,-(SP)
1532          MOV     @2,-(SP)
1533          MOV     SP,RO
1534          TRAP   C:PNTX
1535          ADD     @6,SP
1536          PRINTX  @FIF2MSG      ;PRINT HEADER MSG
1537          MOV     @FIF2MSG,-(SP)
1538          MOV     @1,-(SP)
1539          MOV     SP,RO
1540          TRAP   C:PNTX
1541          ADD     @4,SP
1542          MOV     R1,RO          ;GET BYTE COUNT
1543          JSR    PC,PRBYTEXP     ;PRINT FIFO BYTES IN ERROR
1544          ENDMMSG
1545
1546          L10012:
1547          TRAP   C:MSG
1548          .ASCIZ 'NUMBER OF BYTES TRANSFERRED = #D2'
1549          .ASCIZ 'NUMBER FIFO DATA BYTES IN ERROR;'
1550          .EVEN
1551          .SBTTL MSGSTAT - PRINT STATUS HEADER AND MESSAGE BUFFERS
1552
1553          ; *
1554          ; PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RECV
1555          ;
1556          ; IMPLICIT INPUTS:
1557          ;
1558          ; EXPMSG - EXPECTED MESSAGE BUFFER
1559          ; RECMMSG - RECEIVED MESSAGE BUFFER
1560          ; RCVHIADD - RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
1561          ; RCVLOADD - RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
1562
1563          BGNMSG  MSGSTAT
1564          MSGSTAT:
1565          MOV     @STATCOD,R1     ;ASCII ADDRESS TABLE
1566          MOV     (R1)+,RO       ;DONE ALL MSG LINES?
1567          BEQ     20$,           ;BR IF YES
1568          PRINTX  RO             ;PRINT STATUS BIT NAMES
1569          MOV     RO,-(SP)
1570          MOV     @1,-(SP)
1571          MOV     SP,RO
1572          TRAP   C:PNTX
1573          ADD     @4,SP
1574          BR     10$            ;DO ANOTHER MSG LINE
1575          MOV     @10,,RO       ;NUMBER OF WORDS IN A READ STATUS BUFFER
  
```

TSV3 - GLOBAL AREAS MACRO M1113 06-FEB-84 18:04
MSGSTAT - PRINT STATUS HEADER AND MESSAGE BUFFERS

SEQ 056

```

1556 012464 004737 014632          JSR    PC,PRMSGEXP    ;PRINT EXPD/RCV MESSAGE BUFFERS
1557 012470          ENDMMSG
      012470          L10013:
      012470 104423          TRAP    C#MSG
1558
1559 012472 012510 012552 012643 STATCOD:      .WORD    1#,2#,3#,4#,5#,6#,0
1560 012510          045    116    045    1#:.ASCIZ  'N#A Tape Bus Signals in Word #8:'
1561 012552          045    116    045    2#:.ASCIZ  'N#A          PARERR<15> IEOT  <12> IFMK  <9> IRDY<6> IRWD<2>'
1562 012643          045    116    045    3#:.ASCIZ  'N#A          IRESV2<14> IIDENT<11> IHER  <8> IONL<5> IFBY<1>'
1563 012734          045    116    045    4#:.ASCIZ  'N#A          IRESV1<13> ICER  <10> ISPEED<7> ILDP<4> IFPT<0>'
1564 013025          045    116    045    5#:.ASCIZ  'N#A Tape Bus Signals in Word #9:'
1565 013067          045    116    045    6#:.ASCIZ  'N#A          DATMIS<7> ILW<6>  OUTRDY<5> INRDY<4>'
1566          .EVEN
1567
1568          .SBTTL  MSGLOOP - PRINT LOOPBACK HEADER AND MESSAGE BUFFERS
1569
1570
1571          ;
1572          ;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RCV
1573          ;
1574          ;IMPLICIT INPUTS:
1575          ;
1576          ;     EXPMSG  - EXPECTED MESSAGE BUFFER
1577          ;     RECMMSG - RECEIVED MESSAGE BUFFER
1578          ;     RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
1579          ;     RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
1580
1580 013144          BGNMSG  MSGLOOP
      013144
1581 013144 012701 013206          MSGLOOP:
1582 013150 012100          MOV     @LOOPCOD,R1      ;ASCII ADDRESS TABLE
1583 013152 001410          10#:   MOV     (R1)+,RO      ;DONE ALL MSG LINES?
1584 013154          BEQ     20#          ;BR IF YES
      013154 010046          PRINTX RO              ;PRINT STATUS BIT NAMES
      013156 012746 000001          MOV     RO,-(SP)
      013162 010600          MOV     @1,-(SP)
      013164 104415          MOV     SP,RO
      013166 062706 000004          TRAP   C#PNTX
1585 013172 000766          ADD     @4,SP
1586 013174 012700 000012          BR     10#              ;DO ANOTHER MSG LINE
1587 013200 004737 014632          20#:   MOV     @10,RO      ;NUMBER OF WORDS IN A READ STATUS BUFFER
1588 013204          JSR    PC,PRMSGEXP    ;PRINT EXPD/RCV MESSAGE BUFFERS
      013204          ENDMMSG
      013204 104423          L10014:
      013204          TRAP    C#MSG
1589
1590 013206 013226 013301 013400 LOOPCOD:      .WORD    1#,2#,3#,4#,5#,6#,7#,0
1591 013226          045    116    045    1#:.ASCIZ  'N#A Tape Bus Loopback Signals in Word #8:'
1592 013301          045    116    045    2#:.ASCIZ  'N#A          PARERR<15>          IRESV2<14>          IRESV1<13>'
1593 013400          045    116    045    3#:.ASCIZ  'N#A IHISP=>IEOT<12>          IWRT=>IIDENT<11>          IREV  =>ICER  <10>'
1594 013477          045    116    045    4#:.ASCIZ  'N#A IWFN =>IFMK<09>          IEDIT=>IHER <08>          IFAD  =>ISPEED<07>'
1595 013576          045    116    045    5#:.ASCIZ  'N#A ITADO=>IRDY<06>          ITAD1=>IONL <05>          IERASE=>ILDP <04>'
1596 013675          045    116    045    6#:.ASCIZ  'N#A IREW =>IDBY<03>          IRWU  =>IRWD <02>          IFEN  =>IFBY <01>'
1597 013774          045    116    045    7#:.ASCIZ  'N#A IGO  =>IFPT<00>'
1598          .EVEN
1599          .SBTTL  MSGSUB - PRINT WRITE SUBSYSTEM MESSAGE BUFFER
1600
1601          ;
1602          ;PRINT ROUTINE TO PRINT MESSAGE BUFFER EXPD/RCV

```



```

1603
1604
1605
1606
1607
1608
1609
1610
1611
1612 014022
      014022
1613 014022 012700 000012
1614 014026 004737 014632
1615 014032
      014032
      014032 104423
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628
1629 014034
      014034
1630 014034 004737 010236
1631 014040 013701 002224
1632 014044 013702 002226
1633 014050 004737 010020
1634 014054
      C14054
      014054 104423
1635
1636
1637
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1650
1651
1652
1653

```

```

;
;IMPLICIT INPUTS:
;
;   EXPMSG - EXPECTED MESSAGE BUFFER
;   RECMSG - RECEIVED MESSAGE BUFFER
;   RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
;   RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
;-
;   BGNMSG  MSGSUB
MSGSUB:
;   MOV     #10.,R0           ;SIZE OF WRITE SUBSYSTEM BUFFER
;   JSR     PC,PRMSGEXP      ;PRINT EXPD/RCV MESSAGE BUFFERS
;   ENDMSG
L10015:
;   TRAP    C#MSG
;
;   .SBTTL  MEMADD - PRINT MEMORY ADDRESS DATA ERROR
;+
;PRINT ROUTINE TO PRINT MEMORY ADDRESS DATA COMPARE ERROR
;
;IMPLICIT INPUTS:
;
;   ERRHI   - MEMORY ERROR HIGH ORDER ADDRESS
;   ERRLO   - MEMORY ERROR LOW ORDER ADDRESS
;   EXP     - EXPECTED DATA
;   RECV    - RECEIVED DATA
;-
;   BGNMSG  MEMADD
MEMADD:
;   JSR     PC,PRIADD        ;PRINT MEMORY ADDRESS IN ERROR
;   MOV     EXPD,R1          ;GET EXPD DATA
;   MOV     RECV,R2         ;GET RECEIVED DATA
;   JSR     PC,PRIXOR       ;PRINT EXPD/RCV
;   ENDMSG
L10016:
;   TRAP    C#MSG
;   .SBTTL  PRAMPKT - PRINT RAM AND PACKET DATA
;+
;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
;WHEN THE RAM DATA DOES NOT MATCH.
;
;INPUTS:
;
;   R4      POINTER TO COMMAND PACKET
;
;IMPLICIT INPUTS:
;
;   RAMDATA  DATA AS READ FROM THE RAM
;   RAMSIZ   NUMBER OF BYTES IN PACKET
;            IF RAMSIZ=0 THEN DEFAULT TO 8.
;
;IMPLICIT OUTPUTS:
;
;   RAMSIZ  SET TO 0

```

```

1654      ; -
1655
1656 014056      PRAMPKT:
1657 014056      SAVREG                ; SAVE R1-R5 UNTIL NEXT RETURN
1658 014062 012701 002234      MOV     #RAMDATA,R1          ; DATA FROM THE RAM
1659 014066 005002              CLR     R2                    ; INIT BYTE NUMBER
1660 014070 122124      5$:  CMPB   (R1)+,(R4)+      ; COMPARE EXPECTED, RECEIVED
1661 014072 001005              BNE    7$                    ; BR IF NO MATCH
1662 014074              FORCERROR      7$,NOTSSR
1663 014104 000436              BR     10$                   ; @@@
1664 014106 116105 177777      7$:  MOVB  -1(R1),R5          ; GET RECV RAM DATA
1665 014112 116403 177777      MOVB  -1(R4),R3          ; GET EXPD PACKET DATA
1666 014116              XOR    R5,R3                ; XOR EXPD/RECV
1667 014126 042703 177400      BIC   #177400,R3        ; LOW BYTE ONLY
1668 014132 116137 177777 002226      MCVB  -1(R1),RECV       ; GET RECEIVED RAM DATA
1669 014140 116437 177777 002224      MOVB  -1(R4),EXPD       ; GET EXPECTED RAM DATA
1670 014146      PRINTB #RAMASC,R2,RECV,EXPD,R3
      014146 010346      MOV   R3,-(SP)
      014150 013746 002224      MOV   EXPD,-(SP)
      014154 013746 002226      MOV   RECV,-(SP)
      014160 010246      MOV   R2,-(SP)
      014162 012746 014236      MOV   #RAMASC,-(SP)
      014166 012746 000C05      MOV   #5,-(SP)
      014172 010600      MOV   SP,R0
      014174 104414      TRAP  C#PNTB
      014176 062706 000014      ADD   #14,SP
1671 014202 005202      10$: INC    R2                ; UPDATE BYTE COUNT
1672 014204 005737 002274      TST   RAMSIZ            ; DEFAULT TO 8.?
1673 014210 001404              SEQ   15$                ; BR IF YES
1674 014212 020237 002274      CMP   R2,RAMSIZ        ; DONE ALL BYTES?
1675 014216 003724              BLE  5$                  ; BR IF NO
1676 014220 000403              BR   25$                 ;
1677 014222 020227 C00010      15$: CMP   R2,#8.        ; DONE DEFAULT NUMBER OF BYTES?
1678 014226 002720      20$: BLT   5$              ; BR IF NO
1679 014230 005037 002274      25$: CLR   RAMSIZ        ; SET DEFAULT RAMSIZ
1680 014234 000207              RTS    PC                ; RETURN
1681
1682 014236      045      116      045 RAMASC: .ASCIZ 'N#A BYTE: #D2#F RAM: #03#A Packet: #03#A XOR:#03#
1683      .EVEN
1684      .SBTTL PRMESS - PRINT .ONTENTS OF MESSAGE BUFFER
1685      ; +
1686      ;
1687      ; THIS ROUTINE PRINTS THE CONTENTS OF
1688      ; THE 7 OR 8 WORD MESSAGE BUFFER RETURNED BY THE
1689      ; TSV-05.
1690      ;
1691      ; INPUT:
1692      ;
1693      ; R0      LOW ORDER ADDRESS OF MESSAGE BUFFER
1694      ; R1      HIGH ORDER ADDRESS OF MESSAGE BUFFER
1695      ; NOTE: R1 IS IGNORED IF KENABLE FLAG IS CLEAR
1696      ;
1697      ; THIS ROUTINE IS NORMALLY CALLED FROM A PRINT ROUTINE
1698      ;
1699      ; -
1700
1701 014322      PRMESS:
    
```

```

1702 C14322 SAVREG ;SAVE THE REGISTERS
1703 014326 010005 MOV R0,R5 ;SAVE LOW ORDER ADDRESS
1704 014330 005737 003126 TST KTENABLE ;ADDRESS ABOVE 28K?
1705 014334 001001 BNE 10$ ;BR IF YES
1706 014336 005001 CLR R1 ;SET HIGH ORDER ADDRESS TO 0
1707 014340 010103 10$: MOV R1,R3 ;SAVE HIGH ORDER ADDRESS
1708 014342 006100 ROL R0 ;SHIFT BIT15 TO C BIT
1709 014344 006101 ROL R1 ;SHIFT TO HIGH ORDER FOR PRINTOUT
1710 C14346 PRINTX @PROASC,R1,R5 ;PRINT MESSAGE BUFFER ADDRESS
      014346 010546 MOV R5,-(SP)
      014350 010146 MOV R1,-(SP)
      014352 012746 014500 MOV @PROASC,-(SP)
      014356 012746 000003 MOV @3,-(SP)
      014362 010600 MOV SP,R0
      014364 104415 TRAP C$PNTX
      014366 062706 000010 ADD @10,SP
1711 014372 PRINTX @PRIASC ;PRINT HEADER FOR CONTENTS
      014372 012746 014545 MOV @PRIASC,-(SP)
      014376 012746 000001 MOV @1,-(SP)
      014402 010600 MOV SP,R0
      014404 104415 TRAP C$PNTX
      014406 062706 000004 ADD @4,SP
1712 014412 005004 CLR R4 ;NUMBER OF THE NEXT WORD
1713 014414 010501 MOV R5,R1 ;COPY LOW ORDER ADDRESS
1714 014416 010300 MOV R3,R0 ;COPY HIGH ORDER ADDRESS
1715 014420 001403 BEQ 20$ ;BR IF NOT ABOVE 28K
1716 014422 004737 017376 JSR PC,SETMAP ;SETUP PAR ADDRESS IN R0
1717 014426 010005 MOV R0,R5 ;GET PAR FORMAT ADDRESS ABOVE 28K
1718 014430 20$: PRINTX @PRASC,R4,(R5)+ ;PRINT THE CONTENTS OF MEMORY BUFFER
      014430 012546 MOV (R5)+,-(SP)
      014432 010446 MOV R4,-(SP)
      014434 012746 014603 MOV @PRASC,-(SP)
      014440 012746 000003 MOV @3,-(SP)
      014444 010600 MOV SP,R0
      014446 104415 TRAP C$PNTX
      014450 062706 000010 ADD @10,SP
1719 014454 005204 INC R4 ;NUMBER OF THE NEXT
1720 014456 020427 000007 CMP R4,@7 ;DONE ALL YET ?
1721 014462 003005 BGT 50$ ;BRANCH IF ALL DONE
1722 014464 002761 BLT 20$ ;PRINT FIRST 7 WORDS
1723 014466 032763 000200 000012 BI @X2.EXTF,XST2(R3);EXTENDED FEATUTES ON ?
1724 014474 001355 BNE 20$ ;PRINT EXTENDED STATUS WORD
1725 014476 000207 50$: RTS PC ;RETURN
1726
1727 014500 045 116 045 PROASC: .ASCIZ '##A Message Buffer Address - #01#05'
1728 014545 045 116 045 PRIASC: .ASCIZ '##A Message Buffer Contents:'
1729 014603 045 116 045 PRASC: .ASCIZ '##A Word#01#A: #0'
1730 .EVEN
1731 .SBTTL PRMSGEXP - PRINT EXPD/RCV MESSAGE BUFFERS
1732 ;*
1733 ;
1734 ;ROUTINE TO PRINT EXPECTED AND RECEIVED MESSAGE BUFFERS
1735 ;
1736 ; RO - NUMBER OF WORDS IN BUFFER
1737 ;
1738 ;IMPLICIT INPUTS:
1739 ;

```

```

1740      ; EXPMSG - EXPECTED MESSAGE BUFFER
1741      ; RECMMSG - RECEIVED MESSAGE BUFFER
1742      ; RCVHIADD- RECEIVED MESSAGE BUFFER HIGH ORDER ADDRESS
1743      ; RCVLOADD- RECEIVED MESSAGE BUFFER LOW ORDER ADDRESS
1744      ;
1745 014632 PRMSGEXP::
1746 014632 SAVREG ;SAVE R1-R5 UNTIL NEXT RETURN
1747 014636 010005 MOV R0,R5 ;SAVE NUMBER OF WORDS
1748 014640 013700 002300 MOV RCVLOADD,R0 ;GET RECV LOW ADDRESS
1749 014644 010004 MOV R0,R4 ;COPY LOW ADDRESS
1750 014646 013701 002276 MOV RCVHIADD,R1 ;GET RECV HIGH ADDRESS
1751 014652 006100 ROL R0 ;SHIFT BIT15 TO C BIT
1752 014654 006101 ROL R1 ;SHIFT TO HIGH ORDER FOR PRINTOUT
1753 014656 PRINTX #PRMSG0,R1,R4 ;PRINT MESSAGE BUFFER ADDRESS
      014656 010446 MOV R4,-(SP)
      014660 010146 MOV R1,-(SP)
      014662 012746 015012 MOV #PRMSG0,-(SP)
      014666 012746 000003 MOV #3,-(SP)
      014672 010600 MOV SP,R0
      014674 104415 TRAP C#PNTX
      014676 062706 000010 ADD #10,SP
1754 014702 PRINTX #PRMSG1 ;PRINT HEADER FOR CONTENTS
      014702 012746 015057 MOV #PRMSG1,-(SP)
      014706 012746 000001 MOV #1,-(SP)
      014712 010600 MOV SP,R0
      014714 104415 TRAP C#PNTX
      014716 062706 000004 ADD #4,SP
1755 014722 005004 CLR R4 ;NUMBER OF THE CURRENT WORD
1756 014724 012701 002314 MOV #EXPMSG,R1 ;GET EXPD BUFFER ADDRESS
1757 014730 012702 002460 MOV #RECMMSG,R2 ;GET RECV BUFFER ADDRESS
1758 014734 011100 20$: MOV (R1),R0 ;GET EXPD
1759 014736 011203 MOV (R2),R3 ;GET RECV
1760 014740 XOR R0,R3 ;XOR EXPD/RCV
1761 014750 PRINTX #PRMSG2,R4,(R1)+,(R2)+,R3
      014750 010346 MOV R3,-(SP)
      014752 012246 MOV (R2)+,-(SP)
      014754 012146 MOV (R1)+,-(SP)
      014756 010446 MOV R4,-(SP)
      014760 012746 015115 MOV #PRMSG2,-(SP)
      014764 012746 000005 MOV #5,-(SP)
      014770 010600 MOV SP,R0
      014772 104415 TRAP C#PNTX
      014774 062706 000014 ADD #14,SP
1762 015000 005204 INC R4 ;NUMBER OF THE NEXT
1763 015002 020405 CMP R4,R5 ;DONE ALL YET?
1764 015004 002001 BGE 50$ ;BR IF YES
1765 015006 000752 BR 20$ ;DO ANOTHER
1766 015010 000207 50$: RTS PC ;RETURN
1767
1768 015012 045 116 045 PRMSG0: .ASCIZ '##N##A Message Buffer Address = #01#05'
1769 015057 045 116 045 PRMSG1: .ASCIZ '##N##A Message Buffer Contents:'
1770 015115 045 116 045 PRMSG2: .ASCIZ '##N##A WORD #D2##A EXPD: #06##A RECV: .J6##A XOR: #06'
1771 .EVEN
1772 .SBTTL PRBYTEXP - PRINT ERROR BYTES IN EXP/REC MESSAGE BUFFER
1773 ;
1774 ;
1775 ;ROUTINE TO PRINT ERROR BYTES IN MESSAGE BUFFERS
    
```

```

1776          ONLY THE FIRST 8 ERRORS ENCOUNTERED ARE PRINTED DUE TO SCREEN SPACE
1777          :
1778          :      RO      - NUMBER OF BYTES IN BUFFER
1779          :
1780          :IMPLICIT INPUTS:
1781          :
1782          :      EXPMSG  - EXPECTED MESSAGE BUFFER
1783          :      RECMMSG - RECEIVED MESSAGE BUFFER
1784          :
1785 015202    PRBYTEXP::
1786 015202    SAVREG                                ;SAVE R1-R5 UNTIL NEXT RETURN
1787 015206    010005    MOV      R0,R5                ;SAVE NUMBER OF BYTES
1788 015210    005037    002312    CLR      PRMNO        ;INIT ERROR COUNT
1789 015214    005004    CLR      R4                    ;NUMBER OF THE CURRENT BYTE
1790 015216    012701    002314    MOV      #EXPMSG,R1    ;GET EXPD BUFFER ADDRESS
1791 015222    012702    002460    MOV      #RECMMSG,R2  ;GET RECV BUFFER ADDRESS
1792 015226    111100    20$:    MOVB     (R1),R0        ;GET EXPD BYTE
1793 015230    042700    177400    BIC     #C<377>,R0    ;CLEAR UPPER BYTE
1794 015234    110037    015550    MOVB     R0,PRBEXP    ;SAVE FOR ERROR REPORT
1795 015240    111203    MOVB     (R2),R3        ;GET RECV BYTE
1796 015242    042703    177400    BIC     #C<377>,R3    ;CLEAR UPPER BYTE
1797 015246    110337    015552    MOVB     R3,PRBREC    ;FOR ERROR REPORT
1798 015252    XOR      R0,R3                          ;XOR EXPD/RECV
1799 015262    122122    CMPB     (R1)+,(R2)+    ;EXPD = RECV?
1800 015264    001431    BEQ      30$                    ;BR IF YES
1801 015266    005237    002312    INC      PRMNO        ;UPDATE ERROR COUNT
1802 015272    023727    002312    000010    CMP      PRMNO,#8     ;PRINTED 8?
1803 015300    101023    BHI     30$                    ;BR IF YES
1804 015302    27$:    PRINTX   #PRBMSG,R4,PRBEXP,PRBREC,R3
1805 015302    010346    MOV      R3,-(SP)
1806 015304    013746    015552    MOV      PRBREC,-(SP)
1807 015310    013746    015550    MOV      PRBEXP,-(SP)
1808 015314    010446    MOV      R4,-(SP)
1809 015316    012746    015416    MOV      #PRBMSG,-(SP)
1810 015322    012746    000005    MOV      #5,-(SP)
1811 015326    010600    MOV      SP,R0
1812 015330    104415    TRAP    C#PNTX
1813 015332    062706    000014    ADD     #14,SP
1814 015336    50$:    FORL:    50$                    ;000
1815 015346    000404    BR      35$                    ;000
1816 015350    30$:    FORCERROR 27$,NOTSSR    ;000
1817 015350    35$:    INC      R4                    ;NUMBER OF THE NEXT
1818 015360    005204    CMP      R4,R5                ;DONE ALL YET?
1819 015362    020405    BGE     50$                    ;BR IF YES
1820 015364    002001    BR      20$                    ;DO ANOTHER
1821 015366    000717    50$:    PRINTX   #PRBTOT,PRMNO    ;PRINT TOTAL ERROR COUNT
1822 015370    013746    002312    MOV      PRMNO,-(SP)
1823 015374    012746    015503    MOV      #PRBTOT,-(SP)
1824 015400    012746    000002    MOV      #2,-(SP)
1825 015404    010600    MOV      SP,R0
1826 015406    104415    TRAP    C#PNTX
1827 015410    062706    000006    ADD     #6,SP
1828 015414    000207    RTS     PC                    ;RETURN
1829 015416    045      116      045  PRBMSG: .ASCIZ '###A  BYTE #D2#A  EXPD: #03#A  RECV: #03#A  XOR: #03#

```

TSV3 - GLOBAL AREAS MACRO M1113 06-FEB-84 18:04
 PRBYTEXP - PRINT ERROR BYTES IN EXP/REC MESSAGE BUFFER

SEQ 062

```

1818 015503    045    116    045 PRBTOT: .ASCIZ  'NWA NUMBER OF BYTES IN ERROR = #D2'
1819                                     .EVEN
1820 015550  000000 PRBEXP: .WORD  0          ;EXPD
1821 015552  000000 PRBREC: .WORD  0          ;RECV
1822                                     .SBTTL  EXPREC - PRINT EXPD/RECV WORD DATA
1823                                     ;+
1824                                     ;
1825                                     ;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
1826                                     ;
1827                                     ;INPUTS:
1828                                     ;
1829                                     ;    R1    RECEIVED DATA
1830                                     ;    R2    EXPECTED DATA
1831                                     ;
1832                                     ;-
1833
1834 015554          BGNMSG  EXPREC
1835 015554  004737  010020 EXPREC:  JSR    PC,PRIXOR          ;PRINT THE DATA
1836 015560          ENDMMSG
1837 015560  104423  L10017: TRAP   C$MSG
1838                                     .SBTTL  EXPBREC - PRINT EXPD/RECV BYTE DATA
1839                                     ;+
1840                                     ;
1841                                     ;PRINT ROUTINE TO DISPLAY BYTE EXPD/RECV DATA
1842                                     ;
1843                                     ;INPUTS:
1844                                     ;
1845                                     ;    R1    RECEIVED DATA BYTE
1846                                     ;    R2    EXPECTED DATA BYTE
1847                                     ;
1848                                     ;-
1849
1850 015562          BGNMSG  EXPBREC
1851 015562  004737  007670 EXPBREC: JSR    PC,PRIBXOR        ;PRINT THE DATA
1852 015566          ENDMMSG
1853 015566  104423  L10020: TRAP   C$MSG
1854                                     .SBTTL  RAMERR - PRINT RAM AND PACKET DATA
1855                                     ;+
1856                                     ;
1857                                     ;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
1858                                     ;
1859                                     ;INPUTS:
1860                                     ;
1861                                     ;    R4    POINTER TO COMMAND PACKET
1862                                     ;
1863                                     ;IMPLICIT INPUTS:
1864                                     ;
1865                                     ;    RAMDATA  DATA AS READ FROM THE RAM
1866                                     ;    RAMSIZ   NUMBER OF BYTES IN PACKET
1867                                     ;             IF RAMSIZ=0 THEN DEFAULT TO 8.
1868                                     ;

```

```

1869
1870 ;IMPLICIT OUTPUTS:
1871 ;
1872 ;       RAMSIZ  SET TO 0
1873 ;-
1874
1875 015570          BGNMSG  RAMERR
1876 015570 004737 014056 RAMERR::
1877 015574          JSR     PC,PRAMPKT      ;PRINT RAM/PACKET DATA
1878 015574          ENDMMSG
1879 015574 104423   L10021:
1880          TRAP    C$MSG
1881          .SBTTL  RAMTADD - PRINT TEST ADDRESS, RAM AND PACKET DATA
1882 ;*
1883 ;PRINT ROUTINE TO DISPLAY RAM/PACKET DATA
1884 ;
1885 ;INPUTS:
1886 ;       R4       POINTER TO COMMAND PACKET
1887 ;
1888 ;IMPLICIT INPUTS:
1889 ;
1890 ;       RAMDATA  DATA AS READ FROM THE RAM
1891 ;       RAMSIZ   NUMBER OF BYTES IN PACKET
1892 ;               IF RAMSIZ=0 THEN DEFAULT TO 8.
1893 ;       ERRHI    HIGH ORDER TEST ADDRESS
1894 ;       ERRLO    LOW ORDER TEST ADDRESS
1895 ;
1896 ;IMPLICIT OUTPUTS:
1897 ;
1898 ;       RAMSIZ  SET TO 0
1899 ;-
1900
1901 015576          BGNMSG  RAMTADD
1902 015576 004737 010352 RAMTADD::
1903 015606 004737 014056 JSR     PC,PRITADD      ;PRINT TEST ADDRESS
1904 015606          JSR     PC,PRAMPKT      ;PRINT RAM/PACKET DATA
1905 015606          ENDMMSG
1906 015606 104423   L10022:
1907          TRAP    C$MSG
1908          .SBTTL  RAMEXP - PRINT RAM EXPD/RECV DATA
1909 ;*
1910 ;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
1911 ;
1912 ;INPUTS:
1913 ;
1914 ;       R1       RECEIVED DATA
1915 ;       R2       EXPECTED DATA
1916 ;       R4       CONTROLLER RAM ADDRESS
1917 ;-
1918 015610          BGNMSG  RAMEXP
1919 015610          RAMEXP::

```

```

1919 015610 042701 177400      BIC    #C<377>,R1      ;SAVE EXPD RAM DATA BYTE
1920 015614 042702 177400      BIC    #C<377>,R2      ;SAVE EXPD RAM DATA BYTE
1921 015620 004737 010144      JSR    PC,PRIRAM       ;PRINT THE RAM ADDRESS
1922 015624 004737 010020      JSR    PC,PRIXOR       ;PRINT THE DATA
1923 015630
                                ENDMMSG
                                L10023:
                                TRAP    C$MSG
1924 015630 104423
                                .SBTTL  TIMEXP - PRINT TIMER A,B AND EXP/REC
1925
1926
1927
1928 ;PRINT ROUTINE TO DISPLAY EXPD/RECV DATA
1929 ;AND TIMER A,B HEADER MESSAGE
1930
1931 ;INPUTS:
1932
1933 ;      R1      RECEIVED DATA
1934 ;      R2      EXPECTED DATA
1935
1936
1937 015632      BGNMSG  TIMEXP
                                TIMEXP:
015632      PRINTX  #TIMSGO      ;PRINT HEADER
1938 015632      MOV    #TIMSGO, -(SP)
                                MOV    #1, -(SP)
                                MOV    SP, R0
                                TRAP  C$PNTX
                                ADD    #4, SP
1939 015652 004737 010020      JSR    PC,PRIXOR       ;PRINT THE DATA
1940 015656
                                ENDMMSG
                                L10024:
                                TRAP    C$MSG
1941
1942 015660      045      116      045  TIMSGO: .ASCIZ  'TIMER A STATUS IS IN BIT 3, TIMER B STATUS IS IN BIT 2'
1943 .EVEN
1944      .SBTTL  BADSSR - PRINT TSSR ERRORS ON DATA TRANSFERS
1945
1946
1947
1948 ;PRINT ROUTINE FOR TSSR ERRORS ON DATA TRANSFERS
1949
1950 ;INPUTS:
1951
1952 ;      R1      CONTENTS OF TSSR
1953 ;      R2      DATA WRITTEN (8 BITS)
1954
1955
1956
1957 015760      BGNMSG  BADSSR
                                BADSSR:
015760      MOV    R2, -(SP)      ;SAVE DATA TRANSFERRED
1958 015760 010246      BIC    #177400,R2      ;GET JUST ONE BYTE
1959 015762 042702 177400      PRINTB #XFERASC,R2
1960 015766      MOV    R2, -(SP)
                                MOV    #XFERASC, -(SP)
                                MOV    #2, -(SP)
                                MOV    SP, R0

```


1961	016010	012602				TRAP	C\$PNTB	
1962	016012	004737	006020			ADD	#6,SP	
1963	016016					MOV	(SP)+,R2	;RESTORE R2
	016016					JSR	PC,PRITSSR	;DECODE TSSR CONTENTS
	016016					ENDMSG		
1964	016020	104423	045	116	045	L10025: TRAP	C\$MSG	
1965							.ASCIZ	'#N#A Data Transferred = #03'
1966							.SBTTL	GLOBAL SUBROUTINES SECTION
1967								
1968								
1969								
1970								
1971								
1972								
1973								
1974								
1975								
1976								
1977								
1978								
1979								
1980								
1981								
1982								
1983								
1984								
1985								
1986								
1987								
1988								
1989								
1990								
1991								
1992								
1993								
1994								
1995								
1996								
1997								
1998								
1999	016054							
2000	016054							
2001	016060	012765	000000	000002				
2002	016066	004737	016330					
2003	016072	016500	000002					
2004	016076	010004						
2005	016100	042704	176277					
2006	016104	052704	002200					
2007	016110	020400						
2008	016112	001402						
2009	016114	000241						
2010	016116	000401						
2011	016120	000261						
2012	016122	000207						
2013								

```

; THE GLOBAL SUBROUTINES SECTION CONTAINS THE SUBROUTINES
; THAT ARE USED IN MORE THAN ONE TEST.
;--
.SBTTL SOFINIT - SOFT INITIALIZE OF CONTROLLER
;+
; ROUTINE TO DO A SOFT INITIALIZE OF THE CONTROLLER
; BY WRITING INTO THE TSSR REGISTER. AFTER THE INIT,
; THE TSSR REGISTER IS TESTED FOR ERRORS. ANY ERRORS
; DETECTED SHOULD BE TREATED AS DEVICE FATAL ERRORS.
; INPUTS:
; R5 ADDRESS OF FIRST REGISTER
; OUTPUTS:
; R0 CONTENTS OF TSSR, IF ERROR
; CARRY SET IF INIT WAS OKAY
; CLEAR IF FATAL ERROR
; CALLING SEQUENCE:
; MOV #ADDRESS,R5
; JSR PC,SOFINIT
; BCS CONTINUE
; ERRDF ;REPORT FATAL ERROR
;--
SOFINIT:
    SAVREG ; SAVE THE REGISTERS
    MOV #0,TSSR(R5) ; DO THE INIT.
    JSR PC,WAITF ; WAIT FOR SSR
    MOV TSSR(R5),R0 ; GET THE TSSR REGISTER
    MOV R0,R4 ; TSSR CONTENTS
    BIC #C<HIADDR!OFL>,R4
    BIS #SSR!NBA,R4 ; R4 HAS EXPECTED CONTENTS
    CMP R4,R0 ; ONLY EXPECTED BITS SET ?
    BEQ 5$ ; BRANCH IF OKAY
    CLC ; CLEAR THE CARRY FOR ERROR
    BR 10$ ; GO TO EXIT
5$: SEC ; SET THE CARRY BIT
10$: RTS PC ; RETURN TO CALLER
.SBTTL CHKAMB - CHECK TSSR FOR AMBIGUITY
    
```

```

2014
2015
2016
2017
2018
2019
2020
2021
2022
2023
2024
2025
2026
2027
2028
2029
2030
2031
2032
2033 016124
2034 016124
2035 016130 010004
2036 016132 032700 100000
2037 016136 001004
2038 016140 032700 174077
2039 016144 001023
2040 016146 000424
2041 016150 032700 000200
2042 016154 001011
2043 016156 032700 000040
2044 016162 001414
2045 016164 042700 177761
2046 016170 020400 000016
2047 016174 001000
2048 016176 000410
2049 016200 032700 000040
2050 016204 001405
2051 016206 032700 000006
2052 016212 001002
2053 016214 000241
2054 016216 000401
2055 016220 000261
2056 016222 000207
2057
2058
2059
2060
2061
2062
2063
2064
2065
2066
2067
2068
2069
2070 016224 000

;
; THIS ROUTINE TESTS THE CONTENTS OF THE TSSR REGISTER
; FOR AMBIGUITY
; INPUT:
;         RO      CONTENTS OF TSSR
; OUTPUT:
;         RO      CONTENTS OF TSSR
;         CARRY   SET - NO AMBIGUITY
;                CLR - AMBIGUOUS CONTENTS
;
CHKAMB:
  SAVREG          ;SAVE THE GENERAL REGISTERS
  MOV             RO,R4          ;CONTENTS OF TSSR
  BIT             #SC,RO         ;IS BIT 15 SET ?
  BNE             5#            ;BRANCH IF YES
  BIT             #C<NBA!UFL!SSR!HIADDR>,RO ;ANY OTHER BITS SET ?
  BNE             40#          ;MUST BE AN ERROR
  BR              45#          ;RETURN WITH SUCCESS
5#:  BIT          #SSR,RO        ;IS READY BIT SET ?
     BNE          10#          ;BRANCH IF READY BIT IS SET.
     BIT          #BIT5,RO     ;IS FATAL ERROR BIT SET ?
     BEQ          40#          ;ERROR IF NOT
     BIC          #C<TERCLS>,R4 ;CLEAR ALL BUT TERMINATION CODE
     CMP          R4,#16       ;ALL THREE BITS MUST BE SET
     BNE          40#          ;ERROR IF NOT SET
     BR           45#          ;OK IF ALL ARE SET
10#: BIT          #BIT5,RO     ;IS FATAL ERROR BIT SET ?
     BEQ          45#          ;ERROR IF BIT IS SET WITH SSR
     BIT          #BIT2!BIT1,RO ;IS THIS A FUNCTION REJECT
     BNE          45#          ;BR, IF TSSR IS OK
40#: CLC              ;AMBIGUOUS CONTENTS
     BR           50#
45#: SEC              ;SHOW SUCCESS - NO AMBIGUITY
50#: RTS             PC        ;RETURN TO CALLER
     .SBTTL ENAINT,DSBINT ; ENABLE/DISABLE INTERRUPTS
;
; DEFAULT DISPLAY INTERRUPT HANDLERS.
; IF DISPLAY TIME-OUT, REPORT DEV FATAL, AND ABORT PASS.
; OTHERWISE, SAVE DPU REGISTERS AND DISMISS.
;
; BIT DEFINITIONS FOR "INTMASK" AND "INTFLAG" BYTES:
;
;         IOKCKIN=BIT7 ; DON'T CHECK FOR BAD INTERRUPTS -- TEST WILL.
;         IOKSTP=BIT0  ; EXPECT "STOP" INTERRUPT.
;
; INTERRUPT MASK . SAYS EXPECTING INTERRUPTS
INTMASK: .BYTE 0
  
```

```

2071 ;INTERRUPT FLAG -- SAYS WE GOT ONE (IF POSITIVE)
2072 016225 000 INTFLAG: .BYTE 0
2073
2074 ;SAVED INTERRUPT VECTOR:
2075 016226 000000 INTVEC: .WORD 0
2076 ;SAVE CPU PC
2077 016230 000000 INTCPC: .WORD 0
2078
2079 ;SUBROUTINE TO ENABLE INTERRUPTS:
2080 016232 01004b ENAINT: MOV R0,-(SP) ;SAVE R0
2081 016234 013700 002202 MOV IVEC,R0 ;GET POINTER TO VECTORS
2082 016240 012720 016276 MOV @INTR,(R0); ;SET UP INTERRUPT VECTOR
2083 016244 012720 000340 MOV @PRIO7,(R0);
2084 016250 012600 MOV (SP),R0 ;RESTORE R0
2085 016252 011646 MOV (SP),-(SP)
2086 016254 012766 000000 000002 MOV @0,2(SP) ;SET CPU TO LEVEL 0
2087 016262 000002 RTI
2088
2089 ;SUBROUTINE TO DISABLE INTERRUPTS (RAISE PRIORITY TO LEVEL 7)
2090 016264 011646 DSBINT: MOV (SP),-(SP)
2091 016266 012766 000340 000002 MOV @PRIO7,2(SP)
2092 016274 000002 RTI
2093 .SBTTL INTR - INTERRUPT HANDLERS
2094
2095 016276 BGNSRV INTR ;DEFINE INTERRUPT ENTRY
016276
2096 016276 012737 000001 002216 INTR:: MOV @1,INTRECV ;SET FLAG TO SHOW INTERRUPT RECEIVED
2097 016304 105037 016225 CLRB INTFLAG ;CLEAR FLAG TO SAY WE GOT INTERRUPT
2098 016310 132737 000001 016224 BITB @IOKSTP,INTMASK ;EXPECTING STOP INTERRUPT?
2099 016316 001003 BNE 1; ;BR IF YES
2100 016320 152737 000001 016225 BISB @IOKSTP,INTFLAG ;NO. SET THE ERROR FLAG.
2101
2102 ;SAVE REGISTERS, MSG BUFFER, ETC.
2103 016326 1;:
2104 016326 ENDSRV
016326
L10026: RTI
016326 000002 .SBTTL WAITF - WAIT FOR SUBSYSTEM READY
2105
2106 ;
2107 ; SUBROUTINE TO WAIT FOR THE SUBSYSTEM READY FLAG
2108 ;
2109 ; INPUTS:
2110 ;
2111 ; R5 ADDRESS OF FIRST DEVICE REGISTER
2112 ;
2113 ; OUTPUTS:
2114 ;
2115 ; R0 CONTENTS OF LAST TSSR READ
2116 ; CARRY SET - READY BIT SET
2117 ; CLR - TIMEOUT WAITING FOR READY
2118 ;
2119 016330 000401 WAITF:: BR 1; ;NOP WHEN SUPER FIXED
2120 016332 BREAK ; DO A SUPVSR BREAK FIRST.
016332 104422 TRAP C#BRK
2121 016334 012746 011000 1;: MOV @11000,-(SP) ;25-APRIL-83 REV B - 1100 MSEC TIMER
2122 016340 016500 000002 2;: MOV TSSR(R5),R0 ;READ THE TSSR REGISTER
2123 016344 105700 TSTB R0 ;TEST FOR READY BIT SET
  
```

```

2124
2125 016346 100420          BMI      3$          ; EXIT ON STOP FLAG.
2126 016350          DELAY    1          ; WAIT 100 USEC
      016350 012727 000001    MOV      01,(PC)+
      016354 000000          .WORD    0
      016356 013727 002116    MOV      L$DLY,(PC)+
      016362 000000          .WORD    0
      016364 005367 177772    DEC      -6(PC)
      016370 001375          BNE      .-4
      016372 005367 177756    DEC      -22(PC)
      016376 001367          BNE      .-20
2127 016400 005316          DEC      (SP)          ;REDUCE DELAY COUNT
2128 016402 001356          BNE      2$          ;RETRY UNTIL TIMER EXPIRES
2129 016404 000241          CLC
2130 016406 000401          BR       4$          ; C = 0, CONTROLLER STILL RUNNING...
2131 016410 000261          3$: SEC          ;...OR HUNG-UP AFTER 300 MSEC.
2132 016412 005326          4$: DEC      (SP)+   ; C = 1, CONTROLLER IS STOPPED.
2133 016414 000207          RTS      PC          ;RESTORE STACK WITHOUT CHANGING CARRY BIT
2134          .SBTTL   CHKTSSR - CHECK TSSR FOR READY
2135
2136          ;*
2137          ;
2138          ;THIS ROUTINE WAITS FOR READY IN THE TSSR
2139          ;AND TESTS FOR AMBIGUOUS BIT SETTINGS IN TSSR.
2140          ;
2141          ;INPUT:
2142          ;
2143          ;      R5      ADDRESS OF CSR REGISTERS
2144          ;
2145          ;OUTPUT:
2146          ;
2147          ;      R0      CONTENTS OF TSSR
2148          ;      CARRY   SET - OKAY
2149          ;              CLR - NOT READY AMBIGUOUS, OR SC SET
2150          ;
2151          ;-
2152
2153 016416          CHKTSSR:
2154 016416 004737 016330          JSR      PC,WAITF    ;WAIT FOR READY
2155 016422 103014          BCC      20$        ;BRANCH IF TIME OUT
2156 016424 004737 016124          JSR      PC,CHKAMB   ;TSSR AMBIGUOUS?
2157 016430 103006          BCC      10$        ;BR IF YES
2158 016432 032700 100000          BIT      0$C,R0     ;SPECIAL CONDITION SET?
2159 016436 001405          BEQ      15$        ;BR IF NO
2160 016440 032700 074000          BIT      0$<SCE!BIE!RMR!NXM>,R0 ;ANY ERROR BITS SET?
2161 016444 001402          BEQ      15$        ;BR IF NO
2162 016446 000241          10$: CLC          ;SET FAILURE
2163 016450 000401          BR       20$
2164 016452 000261          15$: SEC          ;SET SUCCESS
2165 016454 000207          20$: RTS      PC    ;RETURN TO CALLER
2166          .SBTTL   XNXM - CHECK FOR NONEXISTENT MEMORY
2167
2168          ;*
2169          ; ROUTINE TO TEST FOR A NEXM IN THE RANGE (R1) THRU (R2).
2170          ; ON RETURN, IF "C" = 1, (R1) = NEXM ADDRESS,
2171          ;              "C" = 0, ALL ADDRESSES OK.
2172          ;
2173          ;CALL:  MOV ADR1,R1

```

```

2173      ;      MOV ADR2,R2
2174      ;      JSR PC,NXM
2175      ;      RETURN          ;TEST "C" AND PROCEED.
2176      ;
2177 016456 012737 016510 000004 XNXM:  MOV    02$,004      ; SET BUSERR VECTOR.
2178 016464 012737 000200 000006      MOV    0PRI04,006
2179 016472 005003      CLR    R3          ;FLAG.
2180 016474 005711 1$:  TST    (R1)        ;TEST THE ADDRESS(ES).
2181      ;
2182 016476 020102      CMP    R1,R2      ;IF ANY TRAP, CONTINUE AT 2$.
2183 016500 001407      BEQ    3$        ;OTHERWISE, CONTINUE HERE.
2184 016502 062701 000002      ADD    02,R1     ;BR IF FINISHED (NO NEXM'S).
2185 016506 000772      BR    1$        ;SET NEXT ADDRESS...
2186      ;
2187 016510 005103 2$:  COM    R3          ;GOT ONE, SET FLAG...
2188 016512 012716 016520      MOV    03$, (SP)
2189 016516 000002      RTI          ;...AND DISMISS INTERRUPT...
2190 016520 016520 012700 000004 3$:  CLRVEC 04        ;...AND GIVE BACK THE VECTOR.
      016524 104436      MOV    04,R0
2191 016526 005703      TRAP  C$CVEC
2192 016530 001401      TST    R3        ;DID WE CATCH ONE ??
2193 016532 000261      BEQ    .+4       ;NO, "C" = 0. SKIP NEXT.
2194 016534 000207      SEC          ;YES, "C" = 1. (R1) = NEXM ADDR.
2195      RTS    PC
2196
2197      .SBTTL  TSTLOOP - CHECK ITERATION COUNT
2198      ;
2199      ; SUBROUTINE TO EXECUTE TEST ITERATIONS.
2200      ; EXIT WITH "C" SET IF LOOPS ALLOWED AND LOOP COUNT NON-ZERO.
2201      ; LOOP COUNTER IS SET BY "BEGIN.TEST" MACRO.
2202      ;
2203      ; CALL: LOOPTO ARG
2204      ;
2205 016536      TSTLOOP:
2206 016536 005737 002162      TST    NOITS     ; ITERATIONS INHIBITED?
2207 016542 001006      BNE    1$        ; YES.
2208 016544 005737 002176      TST    QVP       ; NO.
2209 016550 100403      BMI    1$        ;LOOPS DISALLOWED IN QUICK PASS.
2210 016552 005337 002210      DEC    LOOPCNT   ; BUMP LOOP COUNTER.
2211 016556 001002      BNE    2$
2212 016560 000241 1$:  CLC          ;LOOP DISALLOWED, OR DONE.
2213 016562 000401      BR    3$
2214 016564 000261 2$:  SEC          ;LOOP ENABLED.
2215 016566 000207 3$:  RTS    PC
2216
2217      .SBTTL  TSTSETUP - PRINT TEST NAME AND INIT ERROR COUNTS
2218      ;
2219      ; PRINT THE NUMBER AND NAME OF EACH TEST AS WE GO ALONG.
2220      ; INCREMENT "TESTK" TO INDICATE THE NUMBER OF TESTS
2221      ; IN THE CURRENT RUN SEQUENCE.
2222      ; CLEAR THE ERROR COUNTER AND SIGNATURE EXTENSION FLAGS.
2223      ;
2224      ; INPUT:
2225      ;
2226      ; RO    POINTER TO TEST ID ASCIZ STRING
2227      ;

```

```

2228      ;OUTPUT:
2229      ;
2230      ;      R5      ADDRESS OF FIRST DEVICE REGISTER
2231      ;
2232      ;IMPLICIT OUTPUTS:
2233      ;
2234      ;      TSTCNT  UPDATED TO COUNT TESTS PERFORMED SINCE START OR RESTART
2235      ;
2236      ;SIDE EFFECTS:
2237      ;
2238      ;      INTERRUPT LEVEL IS RASIED TO LEVEL OF
2239      ;      THE DEVICE UNDER TEST
2240      ;
2241      ;-
2242
2243      TSTSETUP::
2244      016570      010046      MOV      R0,-(SP)      ;SAVE THE TEST ID MESSAGE
2245      016572      005037      003146      CLR      SIFLAG      ;CLEAR "SOFT INIT" FLAG
2246      016576      005037      017036      CLR      ERRK      ;CLEAR LOCAL ERROR COUNTER.
2247      016602      005037      005766      CLR      EXTA      ;CLEAR ERROR EXTENSION FLAG.
2248      016606      105037      016224      CLR      INTMASK    ;CLEAR INTERRUPT MASK (CHECK ERROR)
2249      016612      013700      002174      MOV      UNITN,R0    ;GET THE UNIT NUMBER,
2250      016616      006300      ASL      R0          ;... AND MAKE IT A WORD OFFSET.
2251      016620      005737      003106      TST      NDEV      ;DID STARTUP FIND THE DEVICE?
2252      016624      001430      BEQ      4$         ;BR IF YES
2253      016626      100010      BPL      3$         ;BR IF NOT IDLE
2254      016630      052760      160000      003170      BIS      @160000,ERTABL(R0) ; FLAG ERROR IN THE ERROR TABLE
2255      016636      104455      ERDF    1,NXR,NXRERR ; NO DEVICE HERE -- PRINT IT
2256      016640      000001      TRAP    C$ERDF
2257      016642      003734      .WORD  1
2258      016644      005732      .WORD  NXR
2259      016646      000407      .WORD  NXRERR
2260      016650      052760      160001      003170      3$:  BIS      @160001,ERTABL(R0) ; FLAG ERROR IN THE ERROR TABLE
2261      016656      104455      ERDF    2,NOINIT    ; DEVICE NOT IDLE
2262      016660      000002      TRAP    C$ERDF
2263      016662      004331      .WORD  2
2264      016664      000000      .WORD  NOINIT
2265      016666      012737      177777      003104      2$:  MOV      @-1,DUFLG    ; DROP THE UNIT
2266      016674      013700      002174      DODU    UNITN
2267      016700      104451      MOV      UNITN,R0
2268      016702      104444      TRAP    C$DODU
2269      016704      000423      DOCLN   ; ABORT THE PASS
2270      016706      104421      TRAP    C$DCLN
2271      016710      032700      001000      4$:  RFLAGS  R0          ; GET THE OPERATOR FLAGS.
2272      016714      001412      TRAP    C$RFLA
2273      016716      011600      BIT      @PNT,R0    ; PRINT THE TES' NUMBERS?
2274      016720      010046      BEQ      1$         ; BR IF NO
2275      016722      012746      016764      MOV      (SP),R0    ;GET THE ID MESSAGE
2276      016726      012746      000002      PRINTF  @TNAM,R0    ;DISPLAY THE TEST ID
2277      016732      010600      MOV      R0,-(SP)
2278      MOV      @TNAM,-(SP)
2279      MOV      @2,-(SP)
2280      MOV      SP,R0

```

```

016734 104417          TRAP  C$PNTF
016736 062706 000006    ADD   #6,SP
2269 016742 005237 002206    1$:  INC   TSTCNT          ; BUMP TEST COUNTER.
2270 016746          SETPRI IPRI             ; PRIORITY THAT OF DEVICE
      016746 013700 002204    MOV   IPRI,RO
      016752 104441          TRAP  C$SPRI
2271 016754 005726          TST   (SP)+          ; FIX UP THE STACK
2272 016756 013705 002200    MOV   CSRADDR,R5    ; ADDRESS OF TSV REGISTERS ON UNIBUS
2273 016762 000207          RTS   PC
2274 016764      045      123    045 TNAM:  .ASCIZ  'S*TA Test'
2275          .EVEN
2276          .SBTTL  TSTEND - PRINT ERRORS RECEIVED
2277
2278          ; AT END OF EACH TEST, PRINT THE NUMBER OF ERRORS RECEIVED
2279          ; IF NORMAL ERROR REPORTING IS DISABLED (FLA:IER).
2280
2281 017000          TSTEND: RFLAGS RO
      017000 104421          TRAP  C$RFLA
2282 017002 030027 020000    BIT   RO,#IER
2283 017006 001412          BEQ   1$            ; BR IF "IER" NOT SET.
2284 017010          PRINTF #ESUM,ERRK      ; PRINT ERROR COUNT.
      017010 013746 017036    MOV   ERRK,-(SP)
      017014 012746 017040    MOV   #ESUM,-(SP)
      017020 012746 000002    MOV   #2,-(SP)
      017024 010600          MOV   SP,RO
      017026 104417          TRAP  C$PNTF
      017030 062706 000006    ADD   #6,SP
2285 017034 000207          1$:  RTS   PC
2286
2287 017036 000000          ERRK:  0            ; LOCAL ERROR COUNT.
2288 017040      045      101    040 ESUM:  .ASCIZ  /#A #D#A ERRORS/
2289 017057      105      122    122 EMAXDU: .ASCIZ  /ERROR LIMIT REACHED -- DROPPING UNIT/
2290          .EVEN
2291
2292          .SBTTL  INCERK - INCREMENT LOCAL ERROR COUNT
2293
2294          ; *
2295          ; ROUTINES TO INCREMENT LOCAL ERROR COUNT AND CHECK FOR LIMIT:
2296
2296 017124 005237 017036    INCERK: INC  ERRK          ; INCREMENT LOCAL ERROR COUNT
2297 017130 010046          MOV   RO,-(SP)        ; SAVE RO
2298 017132 013700 002174    MOV   UNITN,RO        ; GET UNIT NUMBER.
2299 017136 006300          ASL   RO              ; ... AND MAKE IT A WORD OFFSET.
2300 017140 062700 003170    ADD   #ERTABL,RO      ; RO GETS ADDRESS OF ERROR TABLE ENTRY.
2301 017144 005210          INC   (RO)            ; INCREMENT THE DEVICE ERROR COUNT
2302 017146 032710 007777    BIT   #7777,(RO)     ; DID WE OVERFLOW THE FIELD?
2303 017152 001001          BNE   1$              ; BR IF NO.
2304 017154 005310          DEC   (RO)            ; YES -- BACK IT UP TO 7777.
2305 017156 012600          1$:  MOV   (SP)+,RO      ; RESTORE RO
2306 017160 000207          RTS   PC              ; RETURN TO CALLER.
2307
2308 017162 010046          CKEMAX: MOV  RO,-(SP)      ; SAVE RO
2309 017164 013700 002174    MOV   UNITN,RO        ; GET UNIT NUMBER
2310 017170 006300          ASL   RO              ; ... AND MAKE IT A WORD OFFSET
2311 017172 016000 003170    MOV   ERTABL,(RO),RO  ; GET ERROR TABLE ENTRY
2312 017176 042700 170000    BIC   #170000,RO      ; EXTRACT ERROR COUNT FIELD
2313 017202 020037 002166    CMP   RO,GERRMAX      ; IS GLOBAL LIMIT EXCEEDED FOR THIS UNIT?
2314 017206 103004          BHIS  1$              ; BR IF YES
    
```

```

2315 017210 023737 017036 002164      CMP      ERRK,LERRMAX      ; IS LOCAL LIMIT EXCEEDED FOR THIS TEST?
2316 017216 103417                    BLO      2$                ; BR IF NO
2317 017220                    1$:    RFLAGS  RO            ; GET OPERATOR FLAGS
      017220 104421                    TRAP    C$RFLA
2318 017222 032700 000040              BIT      @IDU,RO          ; IS DROPPING INHIBITED?
2319 017226 001013                    BNE      2$                ; BR IF YES.
2320 017230 012737 177777 003104      MOV      @-1,DUFLG       ; NO -- DROP THE UNIT
2321 017236                    ERDF    4,EMAXDU
      017236 104455                    TRAP    C$ERDF
      017240 000004                    .WORD  4
      017242 017057                    .WORD  EMAXDU
      017244 000000                    .WORD  0
2322 017246                    DODU    UNITN
      017246 013700 002174              MOV      UNITN,RO
      017252 104451                    TRAP    C$DODU
2323 017254                    DOCLN
      017254 104444                    TRAP    C$DCLN
2324 017256 012600                    2$:    MOV      (SP)+,RO      ; RESTORE RO
2325 017260 000207                    RTS      PC                ; RETURN TO CALLER
2326                    .SBTTL  CKDROP - CHECK IF UNIT SHOULD BE DROPPED
2327                    ;+
2328                    ; CHECK IF UNIT SHOULD BE DROPPED
2329                    ;-
2330 017262 010046                    CKDROP: MOV      RO,-(SP)
2331 017264                    FORCERROR 1$,NOTSSR
2332 017274                    RFLAGS  RO
      017274 104421                    TRAP    C$RFLA
2333 017276 032700 000040              BIT      @IDU,RO
2334 017302 001010                    BNE      1$
2335 017304 011600                    MOV      (SP),RO
2336 017306 012737 177777 003104      MOV      @-1,DUFLG
2337 017314                    DODU    UNITN
      017314 013700 002174              MOV      UNITN,RO
      017320 104451                    TRAP    C$DODU
2338 017322                    DOCLN                    ;ABORT THE PASS
      017322 104444                    TRAP    C$DCLN
2339 017324 012600                    1$:    MOV      (SP)+,RO
2340 017326 000207                    RTS      PC
2341
2342
2343                    .SBTTL  CONFIG - DETERMINE CONFIGURATION OF SYSTEM
2344                    ;
2345                    ; SUBROUTINE - DETERMINE CONFIGURATION OF TSV05 SYSTEM.
2346                    ;
2347 017330                    CONFIG:
2348 017330 004737 016054              JSR      PC,SOFINIT
2349 017334 000207                    RTS      PC
2350                    .SBTTL  KTON,KTOFF - ENABLE/DISABLE MEMORY MANAGEMENT
2351                    ;
2352                    ; SUBROUTINE - ENABLE MEM MGT.
2353                    ;
2354 017336 005737 003124              KTON:   TST      KFLG      ; GOT KT?
2355 017342 001403                    BEQ      1$                ; NO.
2356 017344 012737 000001 177572      MOV      @1,SRO          ; YES. ENABLE KT11.
2357 017352 000207                    1$:    RTS      PC
2358
2359                    ;

```



```

2360 ; SUBROUTINE - DISABLE MEM MGT.
2361 ;
2362 017354 005737 003124 KTOFF: TST KTF LG ; GOT KT11?
2363 017360 001405 BEQ 1$ ; NO.
2364 017362 000240 NOP
2365 017364 000240 NOP
2366 017366 012737 000000 177572 MOV #0,SRO ; DISABLE KT.
2367 017374 000207 1$: RTS PC
2368 .SBTTL SETMAP - SETUP PAR6 MAPPING
2369
2370 ;*
2371 ;
2372 ; THIS ROUTINE SETS UP KERNEL PAR6 TP HANDLE
2373 ; AN 18 BIT ADDRESS. THE OFFSET INTO THE PAGE
2374 ; IS RETURNED BIASED TO PAR6.
2375 ;
2376 ; INPUTS:
2377 ;
2378 ; R0 HIGH ORDER ADDRESS BITS
2379 ; R1 LOW ORDER ADDRESS BITS
2380 ;
2381 ; OUTPUTS:
2382 ;
2383 ; R0 OFFSET INTO BLOCK WITH PAR6 BIAS (I.E. THE ADDRESS)
2384 ; CARRY SET IF SUCCESS
2385 ; CLR IF ERROR
2386 ;
2387 017376 SETMAP:
2388 017376 SAVREG ; SAVE R1-R4 UNTIL NEXT RETURN
2389 017402 005737 003124 TST KTF LG ; SYSTEM HAVE ABOVE 28K?
2390 017406 001433 BEQ 10$ ; BR IF NO
2391 017410 010102 MOV R1,R2 ; SAVE LOW ORDER BITS
2392 000006 .REPT 6
2393 ASR R0 ; CONVERT WORD ADDRESS TO 32W BLOCKS
2394 ROR R1 ; MAKE IT DOUBLE PRECISION
2395 .ENDR
2396 017442 042701 000177 BIC #177,R1 ; ALINE FOR LOWER 4K BOUNDARY
2397 017446 020137 003124 CMP R1,KTF LG ; HIGHER THAN EXISTING MEMORY?
2398 017452 103011 BHIS 10$ ; BR IF YES
2399 017454 010137 172354 MOV R1,#KIPAR6 ; SETUP MAPPING REGISTER PAR6
2400 017460 042702 160000 BIC #160000,R2 ; SETUP DISPLACEMENT IN PAGE
2401 017464 062702 140000 ADD #140000,R2 ; ADD IN PAR6 BIAS
2402 017470 010200 MOV R2,R0 ; RETURN IN R0
2403 017472 000261 SEC ; SET SUCCESS
2404 017474 000401 BR 15$ ;
2405 017476 000241 10$: CLC ; SET FAILURE
2406 017500 000207 15$: RTS PC ; RETURN
2407 .SBTTL FILLMEM - FILL MEMORY WITH BACKGROUND PATTERN
2408 ;*
2409 ; FILL MEMORY WITH A BACKGROUND PATTERN
2410 ;
2411 ; INPUTS:
2412 ;
2413 ; R0 - BACKGROUND PATTERN
2414 ; FREE - FIRST LOCATION AVAILABLE TO DIAGNOSTIC
2415 ; KTF LG - SET TO HIGHEST MEMORY LOCATION IF > 28K.
2416 ;
    
```

```

2417 ; OUTPUTS:
2418 ;
2419 ;     NONE
2420 ;
2421 ;
2422 ; FILLMEM:
2423 ; SAVREG ; SAVE R1-R5 UNTIL NEXT RETURN
2424 017502 JSR PC,KTOFF ;DISABLE KT.
2425 017512 010003 MOV R0,R3 ;COPY TEST PATTERN
2426 017514 013701 003116 MOV FREE,R1 ;GET FIRST FREE LOCATION
2427 017520 013702 003120 MOV FRESIZ,R2 ;SIZE OF FREE SPACE BELOW 28K.
2428 017524 010321 10$: MOV R3,(R1)+ ;STORE A BACKGROUND WORD
2429 017526 005302 DEC R2 ;DONE ALL MEMORY IN FREE SPACE?
2430 017530 003375 BGT 10$ ;BR IF NO
2431 017532 005737 003124 TST KTFLG ; GOT KT?
2432 017536 001477 BEQ 55$ ; NO. GET OUT.
2433 017540 004737 017336 JSR PC,KTON ; YES. ENABLE KT.
2434 017544 005000 CLR R0 ;HIGH ORDER ADDRESS START
2435 017546 013701 003144 MOV PST32W,R1 ;GET >28K START ADDRESS (IN 32W BLOCKS)
2436 000006 .REPT 6
2437 CLC ;CLEAR C BIT
2438 ROL R1 ;CONVERT BLOCKS TO WORDS
2439 ROL R0 ;MAKE IT DOUBLE PRECISION
2440 .ENDR
2441 017616 004737 017376 JSR PC,SETMAP ;SETUP PAR6 MAPPING REGISTER
2442 017622 010320 30$: MOV R3,(R0)+ ;STORE TEST PATTERN IN >28K ADDRESS
2443 017624 020027 160000 CMP R0,#160000 ;END OF PAR6 MAPPING AREA?
2444 017630 103774 BLO 30$ ;BR IF NO
2445 017632 162700 020000 SUB #20000,R0 ;BACKUP INTO PAR6 MAPPING BEGIN
2446 017636 062737 000200 172354 ADD #200,#KIPAR6 ;POINT TO NEXT 4K BLOCK >28K.
2447 017644 023737 172354 003124 CMP #KIPAR6,KTFLG ;END OF MEMORY?
2448 017652 001427 BEQ 50$ ;BR IF YES
2449 017654 005737 003136 TST T23A ;11/23A?
2450 017660 001407 BEQ 35$ ;NO KEEP GOING
2451 017662 013704 177572 MOV SRO,R4 ;GET SRO CONTENTS
2452 017666 042704 177761 BIC #177761,R4 ;CLEAR ALL BUT PAGE NUMBER
2453 017672 022704 000016 CMP #16,R4 ;SEE IF PAGE 7
2454 017676 001415 BEQ 50$ ;EXIT IF THERE
2455 017700 005737 003140 35$: TST T23B ;11/23B?
2456 017704 001410 BEQ 45$ ;NO KEEP GOING
2457 017706 023727 172354 007600 CMP #KIPAR6,#7600 ;REACHED 18 BITS?
2458 017714 103001 BHIS 40$ ;YES
2459 017716 000403 BR 45$ ;NO KEEP GOING
2460 017720 012737 000020 172516 40$: MOV #20,SRO ;SET 22 BIT RELOCATION
2461 017726 000137 017622 45$: JMP 30$ ;KEEP GOING ON ETC.
2462 017732 004737 017354 50$: JSR PC,KTOFF ;DISABLE KT.
2463 017736 000207 55$: RTS PC
2464 ;.SBTTL CMPMEM - COMPARE MEMORY TO BACKGROUND PATTERN
2465 ;
2466 ; COMPARE MEMORY WITH A BACKGROUND PATTERN
2467 ;
2468 ; INPUTS:
2469 ;
2470 ; RO = BACKGROUND PATTERN
2471 ; FREE = FIRST LOCATION AVAILABLE TO DIAGNOSTIC
2472 ; KTFLG = SET TO HIGHEST MEMORY LOCATION IF > 28K.
2473 ;

```

```

2474      ; OUTPUTS:
2475      ;
2476      ;     CARRY  - SET IF NO ERROR
2477      ;     CARRY  - CLR IF ERROR
2478      ;
2479      ; IMPLICIT OUTPUTS:
2480      ;
2481      ;     ERRHI  - ERROR HIGH ADDRESS
2482      ;     ERRLO  - ERROR LOW ADDRESS
2483      ;     EXPD   - EXPECTED DATA
2484      ;     RECV   - RECEIVED DATA
2485      ;
2486 017740      ;
2487 017740      ; CMPMEM:
2488 017744 010003      SAVREG          ;SAVE R1-R5 UNTIL NEXT RETURN
2489 017746 004737 017354      MOV     R0,R3          ;COPY TEST PATTERN
2490 017752 013701 003116      JSR    PC,KTOFF       ;DISABLE KT.
2491 017756 013702 003120      MOV    FREE,R1       ;GET FIRST FREE LOCATION
2492 017762 020311          10$:      MOV    FRESIZ,R2      ;SIZE OF FREE SPACE BELOW 28K.
2493 017764 001411          BEQ    R3,(R1)       ;FREE SPACE LOCATION EQUAL TO EXPD?
2494 017766 010137 002232          BEQ    15$          ;BR IF YES
2495 017772 005037 002230          MOV    R1,ERRLO     ;SAVE ADDRESS IN ERROR
2496 017776 010337 002224          CLR    ERRHI        ;NO HIGH ADDRESS
2497 020002 011137 002226          MOV    R3,EXPD      ;SAVE EXPD FOR ERROR REPORT
2498 020006 000474          MOV    (R1),RECV    ;SAVE RECV FOR ERROR REPORT
2499 020010 005721          BR     50$          ;
2500 020012 005302          15$:      TST    (R1)+         ;POINT TO NEXT ADDRESS
2501 020014 003362          DEC    R2           ;DONE ALL MEMORY IN FREE SPACE?
2502 020016 005737 003124          BGT    10$         ;BR IF NO
2503 020022 001472          TST    KTFLG        ; GOT KT?
2504 020024 004737 017336          BEQ    55$         ; NO. GET OUT.
2505 020030 005000          JSR    PC,KTON      ; YES. ENABLE KT.
2506 020032 013701 003144          CLR    R0           ;HIGH ORDER ADDRESS START
2507          MOV    PST32W,R1 ;GET >28K START ADDRESS (IN 32W BLOCKS)
2508          .REPT 6
2509          ROL    R1
2510          ROL    R0
2511          .ENDR
2511 020066 042701 000177          BIC    #177,R1      ;ALINE 4K BOUNDARY
2512 020072 010046          MOV    R0,-(SP)     ;SAVE HIGH ORDER
2513 020074 010146          MOV    R1,-(SP)     ;SAVE LOW ORDER
2514 020076 004737 017376          JSR    PC,SETMAP    ;SETUP PAR6 MAPPING REGISTER
2515 020102 010004          MOV    R0,R4        ;COPY ADDRESS BIASED TO PAR6
2516 020104 012601          MOV    (SP)+,R1     ;RESTORE LOW ORDER IN NON PAR6 FORMAT
2517 020106 012600          MOV    (SP)+,R0     ;RESTORE HIGH ORDER IN NON PAR6 FORMAT
2518 020110 020314          30$:      CMP    R3,(R4)      ;ABOVE 28K LOCATION EQUAL EXPD?
2519 020112 001411          BEQ    32$         ;BR IF YES
2520 020114 010037 002230          MOV    R0,ERRHI    ;SAVE HIGH ORDER IN ERROR
2521 020120 010137 002232          MOV    R1,ERRLO    ;SAVE LOW ORDER IN ERROR
2522 020124 010337 002224          MOV    R3,EXPD     ;SAVE EXPD FOR ERROR REPORT
2523 020130 011437 002226          MOV    (R4),RECV   ;SAVE RECV FOR ERROR REPORT
2524 020134 000421          BR     50$         ;
2525 020136 062701 000002          32$:      ADD    #2,R1        ;UPDATE NON PAR6 ADDRESS
2526 020142 005500          ADC    R0           ;MAKE IT DOUBLE PRECISION ADD
2527 020144 062704 000002          ADD    #2,R4        ;UPDATE PAR FORMAT ADDRESS
2528 020150 020427 160000          CMP    R4,#160000  ;END OF PAR6 MAPPING AREA?
2529 020154 103755          BLO   30$         ;BR IF NO
2530 020156 162704 020000          SUB    #20000,R4   ;BACKUP INTO PAR6 MAPPING BEGIN

```

```

2531 020162 062737 000200 172354      ADD    #200,#KIPAR6 ;POINT TO NEXT 4K BLOCK >28K.
2532 020170 023737 172354 003124      CMP    #KIPAR6,KTFLG ;END OF MEMORY?
2533 020176 101744                      BLOS  30$           ;BR IF NO
2534 020200 004737 017354      50$:  JSR    PC,KTOFF ;TURN OFF MEMORY MAPPING
2535 020204 000241                      CLC                    ;SET FAILURE
2536 020206 000403                      BR     60$           ;
2537 020210 004737 017354      55$:  JSR    PC,KTOFF ;TURN OFF MEMORY MAPPING
2538 020214 000261                      SEC                    ;SET SUCCESS
2539 020216 000207      60$:  RTS    PC
2540                      .SBTTL  REGSAV - SAVE R1-R5 ON STACK
2541                      ;+
2542                      ;
2543                      ;ROUTINE TO
2544                      ;SAVE R1 THROUGH R5 ON THE STACK
2545                      ;
2546                      ;CALLING SEQUENCE:
2547                      ;
2548                      ;       JSR    R5,REGSAV
2549                      ;
2550                      ;THIS IS A COOROUTINE WHICH TRANSFER CONTROL BACK TO
2551                      ;THE CALLING ROUTINE. AT THE END OF THE CALLING ROUTINE,
2552                      ;THE RTS PC RETURNS CONTROL TO THIS ROUTINE TO RESTORE
2553                      ;REGISTERS.
2554                      ;
2555                      ;THIS ROUTINE SHOULD ONLY BE CALLED FROM ROUTINES WHICH ARE
2556                      ;CALLED VIA A JSR PC INSTRUCTION
2557                      ;
2558                      ;-
2559
2560 020220      REGSAV:
2561 020220 010446      MOV    R4,-(SP)
2562 020222 010346      MOV    R3,-(SP)
2563 020224 010246      MOV    R2,-(SP)
2564 020226 010146      MOV    R1,-(SP)
2565 020230 010546      MOV    R5,-(SP)
2566 020232 016605 000012      MOV    10.(SP),R5
2567 020236 004736      JSR    PC,8(SP)+
2568 020240 012601      MOV    (SP)+,R1
2569 020242 012602      MOV    (SP)+,R2
2570 020244 012603      MOV    (SP)+,R3
2571 020246 012604      MOV    (SP)+,R4
2572 020250 012605      MOV    (SP)+,R5
2573 020252 000207      RTS    PC
2574                      .SBTTL  GETPAT - GET 8 BIT PATTERN FROM OPERATOR
2575                      ;+
2576                      ;
2577                      ;ROUTINE TO REQUEST AN 8 BIT DATA PATTERN FROM THE OPERATOR
2578                      ;
2579                      ;INPUTS:
2580                      ;
2581                      ;       NONE.
2582                      ;
2583                      ;OUTPUTS:
2584                      ;
2585                      ;       R0      OCTAL NUMBER FROM THE OPERATOR
2586                      ;
2587                      ;CALLING SEQUENCE:

```

TSV3 : GLOBAL AREAS MACRO M1113 06-FEB-84 18:04
 GETPAT - GET 8 BIT PATTERN FROM OPERATOR

SEQ 077

```

2588      ;
2589      ;      JSR      PC,GETPAT
2590      ;
2591      ;-
2592
2593 020254  GETPAT::
2594 020254          SAVREG          ;SAVE THE GENERAL REGISTERS
2595 020260  1$:    GMANID  DATASC,PATDAT,0,377,0,377,NO
                TRAP    C$GMAN
                BR      10000$
                .WORD  PATDAT
                .WORD  T$CODE
                .WORD  DATASC
                .WORD  377
                .WORD  T$LOLIM
                .WORD  T$HILIM
                10000$:
2596 020300  BNCOMPLETE      1$      ;RETRY IF ERROR
                BCC      1$
2597 020302  013700  020310  MOV      PATDAT,R0      ;DATA PATTERN FROM OPERATOR
2598 020306  000207      RTS      PC      ;RETURN TO CALLER
2599
2600      ;+
2601      ;LOCAL DATA AREA
2602      ;-
2603
2604 020310  000000          PATDAT: .WORD  0      ;TEMPORARY STORAGE FOR DATA
2605 020312  105      116  124  DATASC: .ASCIZ  'ENTER DATA PATTERN'
2606          .EVEN
2607          .SBTTL  GETSEL - ISSUE MENU AND GET OPERATOR RESPONSE
2608
2609      ;+
2610      ;ROUTINE TO ISSUE A MENU AND GET
2611      ;THE OPERATOR'S RESPONSE.
2612      ;
2613      ;INPUTS:
2614      ;
2615      ;      R0      ADDRESS OF ASCIZ STRING OF MENU
2616      ;      R1      MAXIMUM ALLOWABLE OPERATOR RESPONSE
2617      ;
2618      ;OUTPUTS:
2619      ;
2620      ;      R0      NUMBER OF THE OPERATOR'S SELECTION
2621      ;
2622      ;-
2623
2624 020336  GETSEL::
2625 020336          SAVREG          ;SAVE GENERAL REGISTERS
2626 020342  010002  MOV      R0,R2      ;SAVE THE MENU ADDRESS
2627 020344  010203  MOV      R2,R3      ;START OF MENU STRING
2628 020346  005713  2$:    TST      (R3)      ;END OF ASCII ?
2629 020350  001412  BEQ      3$      ;BRANCH IF ALL LINES DISPLAYED
2630 020352          PRINTF  $SELASC,(R3)+  ;DISPLAY THE MENU
                MOV      (R3)+,-(SP)
                MOV      $SELASC,-(SP)
                MOV      $2,-(SP)
                MOV      SP,R0

```

```

020366 104417 TRAP C$PNTF
020370 062706 000006 ADD #6,SP
2631 020374 000764 BR 2$
2632 020376 3$: GMANID MENASC,MENRES,D,-1,0,-1,NO
020376 104443 TRAP C$GMAN
020400 000406 BR 10001$
020402 020556 .WORD MENRES
020404 000042 .WORD T$CODE
020406 020527 .WORD MENASC
020410 177777 .WORD -1
020412 000000 .WORD T$LOLIM
020414 177777 .WORD T$HILIM
020416 10001$:
2633 020416 BNCOMPLETE 1$ ;RETRY IF ERROR
020416 103352 BCC 1$
2634 020420 013700 020556 MOV MENRES,R0 ;GET THE OPERATOR'S REPLY
2635 020424 020001 CMP R0,R1 ;COMPARE TO MAXIMUM ALLOWED
2636 020426 101411 BLOS 5$ ;BRANCH IF OK
2637 020430 PRINTF #MENERR ;DISPLAY ERROR MESSAGE
020430 012746 020454 MOV #MENERR,-(SP)
020434 012746 000001 MOV #1,-(SP)
020440 010600 MOV SP,R0
020442 104417 TRAP C$PNTF
020444 062706 000004 ADD #4,SP
2638 020450 000735 BR 1$ ;RETRY
2639 020452 000207 5$: RTS PC ;RETURN TO CALLER
2640 020454 045 116 045 MENERR: .ASCIZ '#N#A *** Menu Selection Too Large ***'
2641 020522 045 116 045 SELASC: .ASCIZ '#N#T'
2642 020527 105 156 164 MENASC: .ASCIZ 'Enter Menu Selection: '
2643 .EVEN
2644 020556 000000 MENRES: .WORD 0
2645 .SBTTL CHKMAN - CHECK MANUAL INTERVENTION LEGALITY
2646 ;
2647 ;
2648 ;ROUTINE TO TEST FOR MANUAL INTERVENTION LEGALITY.
2649 ;
2650 ;INPUT:
2651 ;
2652 ; NONE.
2653 ;
2654 ;OUTPUT:
2655 ;
2656 ; CARRY 0 MANUAL INTERVENTION NOT ALLOWED
2657 ; 1 MANUAL INTERVENTION IS OK
2658 ;
2659 ;SIDE EFFECTS:
2660 ;
2661 ; A MESSAGE IS DISPLAYED WARNING THAT TEST IS
2662 ; NOT EXECUTED IF MANUAL INTERVENTION IS NOT
2663 ; ALLOWED.
2664 ;
2665 ;-
2666 ;
2667 020560 CHKMAN:: SAVREG ;SAVE THE REGISTERS
2668 020560 MANUAL ;SEE IF MANUAL INTERVENTION OK
2669 020564 TRAP C$MANI
020564 104450

```

```

2670 020566          BCOMPLETE 1$          ;BRANCH IF ALLOWED
      020566 103411          BCS 1$
2671 020570          PRINTF @NOMAN          ;PRINT THE WARNING MESSAGE
      020570 012746 020614          MOV @NOMAN, -(SP)
      020574 012746 000001          MOV @1, -(SP)
      020600 010600          MOV SP, R0
      020602 104417          TRAP C$PRINTF
      020604 062706 000004          ADD @4, SP
2672 020610 000241          CLC          ;CLEAR CARRY FOR ERROR
2673 020612 000207          1$: RTS PC          ;RETURN
2674
2675 020614 045 116 045 NOMAN: .ASCIZ 'NMA *** Manual Intervention not Allowed - Test Aborted ***'
2676 .even
2677 .SBTTL ENVIRN - SETUP FREE DIAGNOSTIC SPACE
2678
2679 ; SUBROUTINE TO SET-UP VARIOUS ENVIRONMENTAL PARAMETERS.
2680
2681 ENVIRN: MEMORY R0
      020710 104431          TRAP C$MEM
2682 020712 010037 003116          MOV R0, FREE          ; GET 1ST FREE ADDRESS...
2683 020716 062737 000002 003116          ADD @2, FREE
2684 020724 011037 003120          MOV (R0), FRESIZ          ;...AND WORD COUNT.
2685 020730 162737 000004 003120          SUB @4, FRESIZ
2686 020736 013702 002012          MOV L$UNIT, R2          ; GET NUMBER OF UNITS
2687 020742 162737 000007 003120 10$: SUB @7, FRESIZ          ; TAKE AWAY 7 WORDS PER UNIT
2688 020750 005302          DEC R2
2689 020752 001373          BNE 10$
2690 020754 013700 003116          MOV FREE, R0          ;GET FIRST FREE ADDRESS
2691 020760 063700 003120          ADD FRESIZ, R0          ;POINT TO LAST FREE ADDRESS
2692 020764 162700 000002          SUB @2, R0          ;BACKUP 1 WORD
2693 020770 010037 003122          MOV R0, FREEHI          ;STORE LAST FREE ADDRESS
2694 020774 000240          NOP
2695 020776 012701 177520          MOV @BDVPCR, R1          ;GET BDV11 PCR ADDRESS
2696 021002 010102          MOV R1, R2          ;COPY TO R2
2697 021004 062702 000002          ADD @2, R2          ;SET THE RANGE
2698 021010 004737 016456          JSR PC, XNXM          ;SEE IF WE HAVE ONE
2699 021014 103001          BCC 15$          ;OK TO SET FLAGS
2700 021016 000445          BR 40$          ;RETURN WITH FLAGS CLEAR
2701 021020 013701 177520          15$: MOV BDVPCR, R1          ;SAVE PCR CONTENTS
2702 021024 062701 000001          ADD @1, R1          ;ADD ONE TO IT
2703 021030 012702 177520          MOV @BDVPCR, R2          ;GET BDV11 PCR ADDRESS
2704 021034 005212          INC (R2)          ;TRY TO WRITE TO IT
2705 021036 013703 177520          MOV BDVPCR, R3          ;GET RESULTS
2706 021042 020103          CMP R1, R3          ;DID IT CHANGE?
2707 021044 001017          BNE 20$          ;NO, MUST BE 11/23B
2708 021046 005237 003136          INC T23A          ;SET THE FLAG
2709 021052 042737 170000 002120          BIC @170000, L$HIME          ;SUPERVISOR COULD BE WRONG
2710 021060 000240          NOP          ;BR 40$ FOR RELEASE
2711 021062          PRINTF @M8186          ;TELL THE SYSTEM TYPE
      021062 012746 005550          MOV @M8186, -(SP)
      021066 012746 000001          MOV @1, -(SP)
      021072 010600          MOV SP, R0
      021074 104417          TRAP C$PRINTF
      021076 062706 000004          ADD @4, SP
2712 021102 000413          BR 40$          ;RETURN
2713 021104 005237 003140          20$: INC T23B          ;SET THE FLAG
2714 021110 000240          NOP          ;BR 40$ FOR RELEASE

```

```

2715 021112          PRINTF 0M8189      ;TELL THE SYSTEM TYPE
      021112 012746 005641    MOV      0M8189,-(SP)
      021116 012746 000001    MOV      01,-(SP)
      021122 010600          MOV      SP,R0
      021124 104417          TRAP     C:PNTF
      021126 062706 000004    ADD      04,SP
2716 021132 000207          40$:   RTS      PC      ;RETURN
2717          .SBTTL  KTINIT - SETUP KT11 MEMORY MANAGEMENT REGISTERS
2718          ;
2719          ;
2720          ;ROUTINE TO INIT KT-11
2721          ;
2722          ;
2723          ;
2724 021134          KTINIT:
2725 021134 005037 003124    CLR      KTFLG      ; INIT >28K MEMORY FLAG
2726 021140 005037 003126    CLR      KTENABLE   ; INIT TEST >28K FLAG
2727 021144 023727 002120 001577  CMP      L:HIME,01577 ; GOT ENOUGH MEMORY (>28K)?
2728 021152 101444          BLOS    9$          ; NO.
2729 021154 013700 000004    MOV      00ERRVEC,R0 ; SAVE OLD ERR VEC PTR.
2730 021160 012737 021252 000004  MOV      020,00ERRVEC ; SET ERR VEC PTR.
2731 021166 005737 177572    TST     00SRO      ; GOT KT11?
2732 021172 000240          NOP           ; (TRAP IF NO).
2733 021174 013737 002120 003124  MOV      L:HIME,KTFLG ; YES. SET KT FLAG.
2734 021202 042737 000177 003124  BIC     0177,KTFLG
2735 021210 010037 000004    MOV      R0,00ERRVEC ; RESTORE OLD ERR VEC PTR.
2736 021214 005000          CLR      R0      ; R0 = AR DATA.
2737 021216 012701 172340    MOV      0KIPAR0,R1 ; R1 = KI REGS PTR.
2738 021222 012761 077406 177740 1$:   MOV      077406,-40(R1) ; SET DESCRIPTOR REG.
2739 021230 010021          MOV      R0,(R1)  ; SET KIPAR REG.
2740 021232 062700 000200    ADD     0200,R0   ; BUMP AR DATA BY "4K".
2741 021236 020027 002000    CMP     R0,02000 ; AT "I/O"?
2742 021242 001367          BNE     1$       ; NO.
2743 021244 012741 177600    MOV     0177600,-(R1) ; YES. SET KTPAR7 FOR I/O.
2744 021250 000405          BR      9$
2745          ;
2746 021252 012716 021200 2$:   MOV     060,(SP)   ; SET UP RETURN
2747 021256 000002          RTI           ; RTI TO NEXT LOCATION
2748          ;
2749 021260 010037 000004    6$:   MOV     R0,00ERRVEC ; RESTORE OLD ERR VEC PTR.
2750          ;
2751 021264 000207          9$:   RTS      PC
2752          ;
2753          ; SUBROUTINE TO SET EXTENDED FEATURES SWITCH
2754          ;
2755          ; Requires that SOFINIT and WRTPHR have been done previous to call.
2756          ;
2757          ;
2758          ; INPUTS:
2759          ; R5      CURRENT UNIT NUMBER
2760          ; OUTPUTS:
2761          ; The Extended Features Switch is set.
2762          ;
2763          ;
2764          ;
2765 021266          INVERT:;
2766          ;

```


TSV3 - GLOBAL AREAS MACRO M1113 06-FEB-84 18:04
 KTINIT - SETUP RT11 MEMORY MANAGEMENT REGISTERS

SEQ 081

```

2767 021266 005737 002220          TST    EXTFEA          ; IS SWITCH SET?
2768 021272 001020          BNE    1$             ; YES,EXIT STAGE RIGHT!(or the next one outa town!)
2769 021274 012737 100206 021340    MOV    #100206,CMDPKT ; WRT SUB-SYS MEM CMD
2770 021302 012737 021350 021342    MOV    #WSMBK,CMDPKT+2 ; MSG BUF ADDR
2771 021310 012737 000006 021346    MOV    #6,CMDPKT+6    ; BYTE COUNT
2772 021316 012737 100010 021350    MOV    #100010,WSMBK ; INVERT THE SWITCH
2773 021324 012704 021340          MCV    #CMDPKT,R4    ; SET CMDPKT INTO R4
2774 021330 004737 010742          JSR    PC,WRTCHR     ; DO IT
2775 021334 000207          1$:   RTS    PC      ; RETURN
2776
2777          ;          COMMAND PACKET.
2778
2779          021340          .          -          <,+3>&177774 ;MUST BE ON MOD 4 BOUNDRY.
2780
2781 021340 000000          CMDPKT:: 0          ;1ST WORD IS ISOS COMMAND.
2782 021342 000000          0          ;2ND WORD IS THE BUFFER LOW ADDRESS.
2783 021344 000000          0          ;3RD WORD IS THE BUFFER HIGH ADDRESS.
2784 021346 000000          0          ;4TH WORD IS THE BYTE/RECORD/FILE COUNT.
2785
2786          ;          WRITE SUB-SYSTEM MEMORY CHARACTERISTIC BLOCK.
2787
2788 021350 000000          WSMBK:: 0          ;1ST WORD:: SEL 0
2789 021352 000000          0          ;2ND WORD:: SEL 2
2790 021354 000000          0          ;3RD WORD:: SEL 4
2791          .EVEN
2792
2793          ;+          SUBROUTINE TO CHECK WETHER OR NOT WE'LL TEST NXM
2794          ;
2795          ;
2796          ;INPUTS:
2797          ;OUTPUTS:
2798          ;          The NXMFLG is set if we can test.
2799          ;          The NXMLO and NXMHI addresses are setup.
2800          ;-
2801
2802 021356          MEMCK::
2803
2804 021356          SAVREG          ;SAVE THE REGISTERS
2805 021362 005037 003130          CLR    NXMFLG        ;CLEAR THE FLAG
2806 021366 005037 003132          CLR    NXMLO         ;CLEAR THE TEST ADDRESS LO
2807 021372 005037 003134          CLR    NXMHI         ;CLEAR THE TEST ADDRESS HI
2808 021376 005737 003140          TST    T23B          ;IS IT A 11/23B?
2809 021402 001407          BEQ    1$            ;NO
2810 021404 023727 002120 007777    CMP    L#HIME,#7777  ; GREATER THAN 128K
2811 021412 103406          BLO    2$            ; NO
2812 021414 004737 021532          JSR    PC,NXMTST     ;SETUP THE ADDRESS
2813 021420 000427          BR     13$           ;SET THE FLAG AND EXIT
2814 021422 005737 003136          1$:   TST    T23A          ;IS IT A 11/23A?
2815 021426 001413          BEQ    4$            ;NO
2816 021430 023727 002120 005777    2$:   CMP    L#HIME,#5777 ;GREATER THAN 96K
2817 021436 101023          BHI    14$           ;YES,23A/23B WITH 128K MEMORY
2818 021440 023727 002120 003777    CMP    L#HIME,#3777  ;GREATER THAN 64K BUT LESS THAN 92K?
2819 021446 103403          BLO    4$            ;NO, CHECK 24K
2820 021450 004737 021532          JSR    PC,NXMTST     ;SETUP THE ADDRESS
2821 021454 000411          BR     13$           ;SET THE FLAG AND EXIT
2822 021456 023727 002120 001577    4$:   CMP    L#HIME,#1577  ;GREATER THAN 24K BUT LESS THAN 64K?
2823 021464 103410          BLO    14$           ;NO, TELL THEM AND FXIT WITH FLAG CLEAR

```

E7

TSV3 - GLOBAL AREAS MACRO M1113 06-FEB-84 18:04
KTINIT - SETUP KT11 MEMORY MANAGEMENT REGISTERS

SEQ 082

```
2824 021466 004737 021532      JSR    PC,NXMTST      ;SETUP THE ADDRESS
2825 021472 062737 000077 003134  ADD    #77,NXMHI     ;FOOL THE 11/02 & 11/03
2826 021500 005237 003130      13$:  INC    NXMFLG     ;SET THE FLAG
2827 021504 000411              BR     15$           ;EXIT
2828 021506 000410      14$:  BR     15$           ;NOP FOR PRINTOUT
2829 021510              PRINTF #NOMEM        ;TELL THEM & EXIT ***NO PRINT*****
      021510 012746 005454      MOV    #NOMEM,-(SP)
      021514 012746 000001      MOV    #1,-(SP)
      021520 010600              MOV    SP,R0
      021522 104417              TRAP  C#PNTF
      021524 062706 000004      ADD    #4,SP
2830 021530 000207      15$:  RTS    PC              ;RETURN
2831
2832      ;+
2833      ; SUBROUTINE TO SETUP THE NXM ADDRESS FOR TESTING
2834      ;
2835      ;OUTPUTS:NXMLO,NXMHI      ;SETUP WITH NXM ADDRESS
2836      ;
2837      ;-
2838
2839 021532 013701 002120  NXMTST: MOV    L#HIME,R1      ;GET TOP OF MEMORY
2840 021536 062701 000200      ADD    #200,R1         ;MAKE IT I/O BLOCK OR OTHER NYM
2841 021542 042701 000177      BIC    #177,R1
2842 021546 010102              MOV    R1,R2           ;RESAVE RESULTS
2843              000006      .REPT 6
2844              ASL    R1           ;PUT IN PLACE FOR XFER
2845              .ENDR
2846 021564 010137 003132      MOV    R1,NXMLO        ;SAVE TEST ADDRESS LOW
2847              000012      .REPT 10
2848              ASR    R2           ;PUT IN PLACE FOR XFER
2849              .ENDR
2850 021614 042702 177700      BIC    #177700,R2     ;DON'T WANT ILA!
2851 021620 010237 003134      MOV    R2,NXMHI        ;SAVE TEST ADDRESS HIGH
2852 021624 000207      RTS    PC              ;RETURN
2853
2854
2855
2856 021626      ENDMOD
```

F7

TSV4 - MISCELLANEOUS SECTIONS MACRO M1113 06-FEB-84 18:04
KTINIT - SETUP KT11 MEMORY MANAGEMENT REGISTERS

SEQ 083

7 .TITLE TSV4 - MISCELLANEOUS SECTIONS
8
9 021626 BGNMOD TSV4
021626 TSV4::
10

G7

TSV4 - MISCELLANEOUS SECTIONS MACRO M1113 06-FEB-84 18:04
PROTECTION TABLE

SEQ 084

```
17  
18 021626                            .SBTTL PROTECTION TABLE  
          021626                    BGNPROT  
19 021626 177777 177777 177777 L$PROT::  
20 021636                            .WORD -1, -1, -1, -1  
                                  ENDPROT
```

;NO DEVICE PROTECTION REQUIRED.

```

22          .SBTTL  INITIALIZE SECTION
23
24          ;++
25          ;THE INITIALIZE SECTION CONTAINS THE CODING THAT IS PERFORMED
26          ;AT THE BEGINNING OF EACH PASS.
27
28          ;IF "START" OR "RESTART", SET QUICK-PASS FLAG AND BUS-INIT.
29          ;IF "CONTINUE", NOTHING IS REQUIRED.
30
31          ;--
32          ;+
33          ;INSERT TEMPORARY JUMP TO ODT
34          ;-
35 021636          BGNINIT
021636          L$INIT::
36 021636 005037 002220          40$: CLR     EXTFEA
37 021642 005037 003130          CLR     NXMFLG
38 021646 012737 006354 002172  MOV     #EPRT1,EPRTSW          ;SET UP PRIMARY MESSAGE FOR REPLACEMENT
39 021654 005037 003146          CLR     SIFLAG          ;CLEAR "SOFT INIT" FLAG
40 021660 005037 003126          CLR     KTENABLE          ;CLEAR TEST ABOVE 28K FLAG
41 021664 005037 002274          CLR     RAMSIZ          ;CLEAR RAM SIZE FOR RAMERR ROUTINE
42 021670          READEF  #EF.CONTINUE
021670 012700 000036          MOV     #EF.CONTINUE,RO
021674 104447          TRAP   C$REFG
43 021676          BNCOMPLETE 1$
021676 103023          BCC     1$
44 021700 023737 002174 002012  CMP     UNITN,L$UNIT          ;UNIT IN RANGE?
45 021706 103070          BHIS   4$          ;BR IF NO.
46 021710 005737 003104          TST   DUFLG          ;DROPPED UNIT?
47 021714 100472          BMI   NXTU          ;BR IF YES
48 021716 013701 002174          MOV   UNITN,R1
49 021722 006301          ASL   R1
50 021724 005761 003170          TST   ERTABL(R1)
51 021730 001516          BEQ   SETU
52 021732 032761 040000 003170  BIT   #BIT14,ERTABL(R1)          ;DROPPED?
53 021740 001060          BNE   NXTU
54 021742          EXIT   INIT          ;DO NOTHING IF "CONTINUE".
021742 104432          TRAP   C$EXIT
021744 000416          .WORD  L10030-.
55 021746          1$: READEF  #EF.NEW
021746 012700 000035          MOV   #EF.NEW,RO
021752 104447          TRAP   C$REFG
56 021754          BNCOMPLETE NXTU          ;TAKE NEXT UNIT IF NOT NEW PASS.
021754 103052          BCC   NXTU
57 021756          READEF  #EF.START
021756 012700 000040          MOV   #EF.START,RO
021762 104447          TRAP   C$REFG
58 021764          BCOMPLETE 2$
021764 103404          BCS   2$
59 021766          READEF  #EF.RESTART
021766 012700 000037          MOV   #EF.RESTART,RO
021772 104447          TRAP   C$REFG
60 021774          BNCOMPLETE 31$
021774 103031          BCC   31$
61 021776          2$: BRESET
62 021776          TRAP   C$RESET          ;1ST PASS, BUS-INIT...
021776 104433          ;BUS RESET.

```

TSV4 - MISCELLANEOUS SECTIONS MACRO M1113 06-FEB-84 18:04
INITIALIZE SECTION

SEQ 086

```

63 022000 005037 002206          CLR    TSTCNT          ;NUMBER OF TESTS RUN IN PASS
64 022004 005037 002214          CLR    FATFLG         ;CLEAR FATAL ERROR COUNT
65 022010 005037 003136          CLR    T23A          ;CLEAR 11/23A FLAG
66 022014 005037 003140          CLR    T23B          ;CLEAR 11/23B FLAG
67                               ;    MOV    #340,-(SP)
68                               ;    MOV    #20,-(SP)          ;RETURN TO DEBUGGER
69                               ;    JMP    0,ODT          ;ENTER THE DEBUGGER
70 022020 005037 003372          CLR    SKIPT          ;CLEAR THE SUBTEST "SKIPPER"
71 022024                               20$:
72 022024 012737 177777 002176    MOV    #-1,QVP        ;...QUICK VERIFY...
73 022032 004737 020710          JSR    PC,ENVIRN     ;SET ENVIRONMENT.
74 022036 004737 021134          JSR    PC,KTINIT    ;INITIALIZE KT MEMORY MANAGEMENT
75 022042 012700 003170          MOV    #ERTABL,RO
76 022046 005020          30$:    CLR    (RO)+          ;CLEAR THE ERROR TABLE
77 022050 020027 003370          CMP    RO,#ERTABE
78 022054 103774          BLO   30$
79 022056 000404          BR    4$
80 022060 005037 002176          31$:    CLR    QVP
81 022064 000137 022134          JMP    PASRPT        ;GO REPORT THE STATUS
82
83 022070                               4$:
84 022070 012737 177777 002174    NEWPAS: MOV    #-1,UNITN ;INIT UNIT NUMBER...
85 022076 005037 002212          CLR    DEVCNT        ;CLEAR COUNT OF DEVICES RUNNING
86 022102                               NXTU:
87 022102 104422          TRAP  C#BRK
88 022104 005237 002174          INC    UNITN
89 022110 023737 002174 002012    CMP    UNITN,L#UNIT ;...AND SET NEXT UNIT NUMBER.
90 022116 103423          BLO   SETU
91 022120 012737 177777 003104    MOV    #-1,DUFLG
92 022126 000401          BR    11$
93 022130                               DOCLN
94 022130 104444          TRAP  C#DCLN        ;ABORT, NO MORE UNITS.
95 022132 000240          11$:    NOP
96 022134                               PASRPT:
97 022134 023727 002012 000001    CMP    L#UNIT,#1    ;HOW MANY UNITS SELECTED?
98 022142 101752          BLOS  NEWPAS        ;BR IF ONLY 1
99 022144 005737 002212          TST   DEVCNT        ;ARE ANY STILL RUNNING?
100 022150 001747          BEQ  NEWPAS        ;BR IF NO
101 022152 104421          TRAP  C#RFLA
102 022154 032700 000100          BIT   #ISR,RO      ;SHOULD WE PRINT STATISTICS
103 022160 001343          BNE  NEWPAS        ;BR IF NO
104 022162                               DORPT
105 022162 104424          TRAP  C#DRPT
106 022164 000741          BR    NEWPAS
107 022166                               10$:
108 022166 013700 002174          SETU:  GPHARD UNITN,RO ;GET UNIT N P-TABLE POINTER.
109 022172 104442          MOV   UNITN,RO
110 022174 103342          TRAP  C#GPHRD
111 022176 005037 003104          BNCOMPLETE NXTU    ;BR IF UNIT NOT AVAILABLE.
112 022202 005237 002212          BCC  NXTU
113 022206 012001          CLR  DUFLG          ;CLEAR "DROPPED" FLAG.
114 022210 010137 002200          INC  DEVCNT
115                               MOV   (RO)+,R1      ;GET 1ST REGISTER ADDRESS.
116                               MOV   R1,CSRADDR    ;ADDRESS OF REGISTERS OF UNIT UNDER TEST

```

```

113
114 022214 012001      MOV      (R0)+,R1      ;GET VECTOR ADDRESS.
115                    ;MOV      (R0),R2      ;GET INTERRUPT PRIORITY
116                    ;MOV      R2,IPRI    ;SET INTERRUPT PRIORITY.
117 022216 010137 002202 MOV      R1,IVEC      ;SET INTERRUPT VECTOR POINTER...
118 022222 012721 016276 MOV      @INTR,(R1)+  ;...VECTOR...
119 022226 013721 002204 MOV      IPRI,(R1)+  ;...AND PRIORITY.
120
121 022232             1$:
122                   ;      TST      QVP          ;1ST PASS ??
123                   ;      BEQ      5$          ;NO, SKIP THE PASS 1 STUFF.
124
125                   ;
126                   ;1ST PASS, CHECK THAT DEVICE ADDRESSES ARE VALID, AND
127                   ;THAT THE DISPLAY STATUS IS PROPERLY INITIALIZED.
128                   ;
129 022232 013701 002174      MOV      UNITN,R1
130 022236 006301            ASL      R1
131 022240 052761 100000 003170 BIS      @BIT15,ERTABL(R1) ;SAY DEVICE RUNNING
132 022246 005037 005766      CLR      EXTA          ;CLEAR ERROR EXTENSION FLAG.
133 022252 023727 002012 000001 CMP      L$UNIT,@1      ;ARE WE TESTING MULTIPLE UNITS?
134 022260 101416            BLOS    10$          ;BR IF NO.
135 022262            RFLACS  RO          ;YES -- GET OPERATOR FLAGS.
136 022264 032700 001000      TRAP    C$RFLA
137 022270 001412            BIT      @PNT,RO          ;SHOULD WE PRINT UNIT #?
138 022272            BEQ      10$          ;BR IF NOT.
139 022272            PRINTF  @PUNIT,UNITN ;PRINT THE UNIT #
140 022276 013746 002174      MOV      UNITN,-(SP)
141 022276 012746 022364      MOV      @PUNIT,-(SP)
142 022302 012746 000002      MOV      @2,-(SP)
143 022306 010600            MOV      SP,RO
144 022310 104417            TRAP    C$PNTF
145 022312 062706 000006      ADD      @6,SP
146 022316            10$:
147 022322 013701 002200      CLR      NODEV
148 022326 010102            MOV      CSRADDR,R1    ;ADDRESS OF FIRST REGISTER
149 022330 062702 000002      MOV      R1,R2        ;START OF REGISTERS
150 022334 004737 016456      ADD      @TSSR,R2     ;ADDRESS OF TSSR REGISTER
151 022340 103005            JSR      PC,XNXM       ;TEST BOTH CONTROLLER REGISTERS...
152 022342 010137 003106      BCC     2$            ;...AND BR IF ALL OK.
153 022346 012737 177777 003104 MOV      R1,NODEV     ;FLAG DEVICE AS NON-EXISTENT
154 022354            MOV      @-1,DUFLG    ;DROP THIS UNIT.
155 022354            2$:
156 022354            ;      ;FINALLY, SET CPU PRIORITY AND WE'RE DONE.
157 022354            ;
158 022354            5$:      SETPRI  @PRI00          ;ENABLE INTERRUPTS.
159 022354 012700 000000      MOV      @PRI00,RO
160 022360 104441            TRAP    C$SPRI
161 022362            ENDINIT
162 022362            L10030:
163 022362 104411            TRAP    C$INIT
164 022364 045 116 045 PUNIT: .ASCIZ  /NNNA***** TESTING UNIT #D2#A *****/
165 .EVEN

```


TSV4 - MISCELLANEOUS SECTIONS
ADD AND DROP UNITS SECTIONS

MACRO M1113 06-FEB-84 18:04

SEQ 089

```

195 022604    045    116    045 1$: .ASCIZ /#N#A UNIT #D#A DROPPED/
196          .EVEN
197 022634          .ENDDU
    022634          L10032:
    022634 104453      TRAP    C$DU
198
199          ;++
200          ; AUTO-DROP CODE SECTION.
201          ;--
    022636          BGNAUTO
    022636          L$AUTO:;
202 022636 013705 002200      MOV    CSRADDR,R5          ;POINT TO DEVICE REGISTER
203 022642 012703 000550      MOV    #360.,R3          ;ENOUGH TIME FOR 2400' REEL TO REWIND
204 022646 004737 016330      10$: JSR    PC,WAITF        ;WAIT FOR SSR TO SET
205 022652 103420          BCS    20$              ;LEAVE WHEN SSR IS SET
206 022654          DELAY  250.          ;WAIT FOR .25 SECONDS
    022654 012727 000372      MOV    #250.,(PC)+
    022660 000000          .WORD  0
    022662 013727 002116      MOV    L$DI',(PC)+
    022666 000000          .WORD  0
    022670 005367 177772      DEC    -6(PC)
    022674 001375          BNE    .-4
    022676 005367 177756      DEC    -22(PC)
    022702 001367          BNE    .-20
207 022704 005303          DEC    R3              ;BUMP COUNTER DOWN
208 022706 001357          BNE    10$            ;KEEP GOING
209 022710 004737 017262      JSR    PC,CKDROP        ;TRY AND DROP UNIT
210 022714
211 022714          20$: ENDAUTO          ; UNUSED.
    022714          L10033:
    022714 104461      TRAP    C$AUTO

```

```

213                                     .SBTTL  CLEAN-UP AND REPORT CODING SECTIONS
214
215                                     ;++
216                                     ; THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS
217                                     ; EXECUTED AT THE END OF EACH PASS (OR SUB-PASS).
218                                     ; USE TO RETURN DEVICE UNDER TEST TO A NEUTRAL STATE.
219                                     ;--
220 022716                               BGNCLN
220 022716                               L$CLEAN::
221 022716 013705 002200                 MOV     CSRADDR,R5           ;POINT TO DEVICE REGISTER
222 022722 005737 003104                 TST     DUFLG              ;"DROPPED" FLAG IS SET ON...
223 022726 100405                         BMI     1$                 ;...AND GROSS CONTROLLER FAULT...
224                                     ;...DON'T TRY TO XCT CLEANUP CODE.
225
226 022730 012765 000000 000002         MOV     #0,TSSR(R5)       ;DO SOFT INIT
227 022730 004737 016330                 JSR     PC,WAITF
228 022742                               1$:
229 022742                               2$:
229 022742                               L10034:
229 022742 104412                         TRAP   C$CLEAN
230
231                                     ;++
232                                     ; THE REPORT CODING SECTION CONTAINS THE
233                                     ; "PRINTS" CALLS THAT GENERATE STATISTICAL REPORTS.
234                                     ;--
234 022744                               BGNRPT
234 022744                               L$RPT::
235 022744                               PRINTS #DEVSUM
235 022744 012746 023206                 MOV     #DEVSUM,-(SP)
235 022750 012746 000001                 MOV     #1,-(SP)
235 022754 010600                         MOV     SP,RO
235 022756 104416                         TRAP   C$PNTS
235 022760 062706 000004                 ADD     #4,SP
236 022764 010246                         MOV     R2,-(SP)
237 022766 010346                         MOV     R3,-(SP)
238 022770 010446                         MOV     R4,-(SP)
239 022772 012704 003170                 MOV     #ERTAB1,R4       ; GET START OF ERROR TABLE.
240 022776 005003                         CLR     R3                ; CLEAR UNIT NUMBER
241 023000 011402                         1$: MOV     (R4),R2       ; GET ERROR TABLE ENTRY & TEST IT.
242 023002 001467                         BEQ     4$                ; ZERO IF UNIT NOT RUN
243 023004 100066                         BFL     4$
244 023006 032702 040000                 BIT     #BIT14,R2        ; WAS UNIT DROPPED?
245 023012 001015                         BNE     2$                ; BR IF YES
246 023014 042702 170000                 BIC     #C7777,R2       ; GET ERROR COUNT FIELD
247 023020                               PRINTS #DEVONL,R3,R2     ; PRINT
247 023020 010246                         MOV     R2,-(SP)
247 023022 010346                         MOV     R3,-(SP)
247 023024 012746 023243                 MOV     #DEVONL,-(SP)
247 023030 012746 000003                 MOV     #3,-(SP)
247 023034 010600                         MOV     SP,RO
247 023036 104416                         TRAP   C$PNTS
247 023040 062706 000010                 ADD     #10,SP
248 023044 000446                         BR      4$
249 023046 020227 160000                 2$: CMP     R2,#160000    ; WAS UNIT NON-EXISTENT?
250 023052 001012                         BNE     3$                ; BR IF NO
251 023054                               PRINTS #DEVNXR,R3
251 023054 010346                         MOV     R3,-(SP)
251 023056 012746 023313                 MOV     #DEVNXR,-(SP)

```

```

023062 012746 000002      MOV      #2,-(SP)
023066 010600      MOV      SP,R0
023070 104416      TRAP     C#PNTS
023072 062706 000006      ADD      #6,SP
252 023076 000431      BR       4$
253 023100 020227 160001      3$:     CMP      R2,#160001      ; WAS UNIT NOT READY AT STARTUP?
254 023104 001012      BNE      30$           ; BR IF NO.
255 023106      PRINTS  #DEVNRD,R3
      023106 010346      MOV      R3,-(SP)
      023110 012746 023375      MOV      #DEVNRD,-(SP)
      023114 012746 000002      MOV      #2,-(SP)
      023120 010600      MOV      SP,R0
      023122 104416      TRAP     C#PNTS
      023124 062706 000006      ADD      #6,SP
256 023130 000414      BR       4$
257 023132 042702 170000      30$:    BIC      #+C7777,R2
258 023136      PRINTS  #DEVDR0,R3,R2
      023136 010246      MOV      R2,-(SP)
      023140 010346      MOV      R3,-(SP)
      023142 012746 023456      MOV      #DEVDR0,-(SP)
      023146 012746 000003      MOV      #3,-(SP)
      023152 010600      MOV      SP,R0
      023154 104416      TRAP     C#PNTS
      023156 062706 000010      ADD      #10,SP
259 023162 062704 000002      4$:     ADD      #2,R4
260 023166 005203      INC      R3
261 023170 020427 003370      CMP      R4,#ERTABE
262 023174 103701      BLO     1$
263 023176 012604      MOV      (SP)+,R4
264 023200 012603      MOV      (SP)+,R3
265 023202 012602      MOV      (SP)+,R2
266 023204      ENDRPT      ; UNUSED.
      023204      L10035:
      023204 104425      TRAP     C#RPT
267
268 023206      045      116      045  DEVSUM: .ASCIZ  /#N#ADEVICE STATUS SUMMARY:#N/
269 023243      045      101      040  DEVONL: .ASCIZ  /#A UNIT #D3#A ONLINE, ERRORS = #D#N/
270 023313      045      101      040  DEVNXR: .ASCIZ  /#A UNIT #D3#A DROPPED, NON-EXISTENT REGISTER#N/
271 023375      045      101      040  DEVNRD: .ASCIZ  /#A UNIT #D3#A DROPPED, NOT READY AT STARTUP#N/
272 023456      045      101      040  DEVDR0: .ASCIZ  /#A UNIT #D3#A DROPPED, ERRORS = #D#N/
273      .EVEN
274
275 023526      ENDMOD
276
    
```

B8

TSV4 - MISCELLANEOUS SECTIONS MACRO M1113 06-FEB-84 18:04
CLEAN-UP AND REPORT CODING SECTIONS

SEQ 092

1
2
3
10
11
17

.TITLE TEST 1 - HARDWARE TEST 1-8 TESTS

023526
023526

BGNMUD TSV7B
TSV7B::


```

023662 012114
76 023664 013737 002174 026340 20$: MOV UNITN,T29DSW ;SET UP UNIT NUMBER .WORD SFIMSG
77
78 023672 012704 026320 MOV #T29PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
79 023676 004737 010742 JSR PC,WR1CHR ;ISSUE WRITE CHARACTERISTICS
80 023702 103407 BCS 25$ ;BR, IF COMMAND ISSUED OK
81 023704 005237 002214 INC FATFLG ;ERROR COUNT
85 023710 010001 MOV R0,R1 ;SAVE CONTENTS OF TSSR
86 023712 ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
023712 104456 TRAP C$ERHRD
023714 000146 .WORD 102
023716 005052 .WORD WRTMSG
023720 012114 .WORD SFIMSG
87 023722 25$: CKLOOP ;LOOP IF SELECTED
023722 104406 TRAP C$CLP1
88 023724 016501 000002 MOV TSSR(R5),R1 ;GET THE TSSR
89 023730 010102 MOV R1,R2 ;SET UP EXPECTED
90 023732 042702 000100 BIC #OFL,R2 ;OFF LINE SHOULD NOT BE SET
91 023736 020102 CMP R1,R2 ;THEY SHOULD BE EQUAL
92 023740 001406 BEQ 26$ ;BR, IF OFL IS NOT SET
96 023742 ERRDF ERRNO,T29OFL,EXPREC ;DRIVE IS OFF LINE
023742 104455 TRAP C$ERDF
023744 000147 .WORD 103
023746 026502 .WORD T29OFL
023750 015554 .WORD EXPREC
97 023752 004737 017262 JSR PC,CKDROP ;TRY AND DROP DRIVE
98 023756 004737 011074 26$: JSR PC,REWIND ;CALL TAPE REWIND COMMAND
99 023762 016501 000002 MOV TSSR(R5),R1 ;GET TSSR
100 023766 012702 000200 MOV #SSR,R2 ;SET UP EXPECTED TSSR
101 023772 103407 BCS 30$ ;BR, IF NO PROBLEM
102 023774 010004 MOV R0,R4 ;PACKET ADDRESS SET UP
103 023776 005237 002214 INC FATFLG ;ERROR COUNT
107 024002 ERRHRD ERRNO,T29RWN,PKTSSR ;REWIND NOT ACCEPTED
024002 104456 TRAP C$ERHRD
024004 000150 .WORD 104
024006 030305 .WORD T29RWN
024010 012126 .WORD PKTSSR
108 024012 30$: CKLOOP ;LOOP IF SELECTED
024012 104406 TRAP C$CLP1
109 024014 013701 026350 MOV T29BFR+6,R1 ;PICK UP XSTO
110 024020 010102 MOV R1,R2 ;SET UP EXPECTED
111 024022 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
112 024026 020102 CMP R1,R2 ;DOES EXP = REC'D
113 024030 001406 BEQ 40$ ;BR, IF EQUAL (OK)
114 024032 005237 002214 INC FATFLG ;ERROR COUNT
118 024036 ERRHRD ERRNO,T29BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
024036 104456 TRAP C$ERHRD
024040 000151 .WORD 105
024042 027776 .WORD T29BOT
024044 015554 .WORD EXPREC
119 024046 40$: CKLOOP ;LOOP IF SELECTED
024046 104406 TRAP C$CLP1
120 024050 013737 003116 026442 MOV FREE,T29RB ;ADDRESS OF READ BUFFER
121 024056 012737 141011 026440 MOV #141011,T29PK3 ;WRITE TAPE MARK RETRY,CVC-1,ACK COMMAND
122 024064 012704 026440 MOV #T29PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
123 024070 010465 000000 MOV R4,TSD8(R5) ;ISSUE COMMAND
124 024074 004737 016330 JSR PC,WAITF ;WAIT FOR SSR TO SET

```

125	024100	016501	000002	MOV	TSSR(R5),R1	;GET TSSR CONTENTS				
126	024104	012702	100206	MOV	#SSR!SC!BIT1!BIT2,R2	;SET UP EXPECTED				
127	024110	020102		CMP	R1,R2	;ARE THEY EQUAL				
128	024112	001406		BEQ	75\$;BR, IF OK				
129	024114	005237	002214	INC	FATFLG	;ERROR COUNT				
133	024120			ERRHRD	ERRNO,T29WDE,PKTSSR	;TSSR INCORRECT AFTER READ DATA				
	024120	104456					TRAP		C\$ERHRD	
	024122	000152					.WORD		106	
	024124	027562					.WORD		T29WDE	
	024126	012126					.WORD		PKTSSR	
134	024130			75\$:	CKLOOP	;LOOP IF SELECTED				
	024130	104406					TRAP		C\$CLP1	
135	024132	013701	026350	MOV	T29BFR+6,R1	;GET XSTO STATUS WORD				
136	024136	010102		MOV	R1,R2	;SET UP EXPECTED				
137	024140	052702	002000	BIS	#BIT10,R2	;SET THE NEF BIT				
138	024144	020102		CMP	R1,R2	;ARE THEY EQUAL				
139	024146	001406		BEQ	170\$;BR, IF EQUAL (GOOD)				
140	024150	005237	002214	INC	FATFLG	;ERROR COUNT				
144	024154			ERRHRD	ERRNO,T29NEF,EXPREC	;NEF SHOULD BE SET				
	024154	104456					TRAP		C\$ERHRD	
	024156	000153					.WORD		107	
	024160	026630					.WORD		T29NEF	
	024162	015554					.WORD		EXPREC	
145	024164			170\$:						
146	024164	005103		COM	R3	;RESET THE SWITCH				
147	024166	001273		BNE	26\$;BR, IF FIRST TIME THROUGH HERE				
148	024170			ENDSUB						
	024170									
	024170	104403								
149	024172	023727	002214 000017	CMP	FATFLG,#15.	;IS ERROR COUNT AT 25	TRAP		C\$ESUB	
150	024200	103402		BLO	999\$;BR, IF LESS THAN 25				
151	024202	004737	017262	JSR	PC,CKDROP	;TRY TO DROP THE UNIT				
152	024206			999\$:						
153				;						
154				;						
155				;TEST 1, SUBTEST 2						
156				;						
157				;VERIFIES THAT A WRITE TAPE MARK RETRY COMMAND ISSUED WHILE THE TAPE						
158				;IS POSITIONED BEFORE THE FIRST RECORD ON TAPE (BUT NOT AT BOT) RESULTS IN						
159				;TAPE STATUS ALERT TERMINATION, WITH THE REVERSE INTO BOT (RIB) STATUS BIT						
160				;SET.						
161				;						
162				;						
163				;						
164				;						
165	024206			;-						
	024206			BGNSUB						
	024206	104402								
166	024210	004737	032146	JSR	PC,T29REST	;SET COMMAND PACKET	TRAP		C\$BSUB	
167	024214	004737	032240	JSR	PC,T29RT2	;SET UP OTHER COMMAND PACKET				
168	024220	004737	032302	JSR	PC,T29RT3	;SET UP OTHER COMMAND PACKET				
169	024224	004737	016054	JSR	PC,SOFINIT	;DO INITIALIZE ON CONTROLLER				
170	024230	103407		BCS	20\$;BR IF INIT WAS OK				
171	024232	005237	002214	INC	FATFLG	;ERROR COUNT				
175	024236	010001		MOV	R0,R1	;CONTENTS OF TSSR REGISTER				
176	024240			ERRDF	ERRNO,SFIERR,SFIMSG	;FATAL ERROR TSSR WAS NOT OK				
	024240	104455					TRAP		C\$ERDF	

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 1: WRITE TAPE MARK RETRY

SEQ 097

	024470	027644							.WORD	T29WLK
	024472	012114							.WORD	SFIMSG
224	024474				DOCLN					;DROP IT
	024474	104444							TRAP	C\$DCLN
225	024476	005237	002214	41\$:	INC	FATFLG				;ERROR COUNT
229	024502				ERRHRD	ERRNO,T29WRT,PKTSSR				;TSSR INCORRECT AFTER WRITE DATA
	024502	104456							TRAP	C\$ERHRD
	024504	000160							.WORD	112
	024506	027731							.WORD	T29WRT
	024510	012126							.WORD	PKTSSR
230	024512			75\$:	CKLOOP					;LOOP IF SELECTED
	024512	104406							TRAP	C\$CLP1
231	024514	012737	000001		MOV	#1,T29RB				;NUMBER OF RECORDS TO SPACE OVER
232	024522	012737	140410		MOV	#140410,T29PK3				;SET UP COMMAND IN APCKET ;SET
UP	SPACE REVERSE									
233	024530	012704	026440		MOV	#T29PK3,R4				;SET UP R4 WITH PACKET ADDRESS
234	024534	010465	000000		MOV	R4,TSDB(R5)				;ISSUE COMMAND
235	024540	004737	016330		JSR	PC,WAITF				;WAIT FOR SSR TO SET
236	024544	016501	000002		MOV	TSSR(R5),R1				;GET TSSR CONTENTS
237	024550	012702	000200		MOV	#SSR,R2				;SET UP EXPECTED
238	024554	020102			CMP	R1,R2				;ARE THEY EQUAL
239	024556	001406			BEQ	175\$;BR. IF OK
240	024560	005237	002214		INC	FATFLG				;ERROR COUNT
244	024564				ERRHRD	ERRNO,T29WDE,PKTSSR				;TSSR INCORRECT AFTER READ DATA
	024564	104456							TRAP	C\$ERHRD
	024566	000161							.WORD	113
	024570	027562							.WORD	T29WDE
	024572	012126							.WORD	PKTSSR
245	024574			175\$:	CKLOOP					;LOOP IF SELECTED
	024574	104406							TRAP	C\$CLP1
246	024576	013737	003116		MOV	FREE,T29RB				;ADDRESS OF BUFFER
247	024604	012737	141011		MOV	#141011,T29PK3				;WRITE TAPE MARK RETRY,ACK,CVC=1 COMD.
248	024612	012704	026440		MOV	#T29PK3,R4				;SET UP R4 WITH PACKET ADDRESS
249	024616	010465	000000		MOV	R4,TSDB(R5)				;ISSUE COMMAND
250	024622	004737	016330		JSR	PC,WAITF				;WAIT FOR SSR TO SET
251	024626	016501	000002		MOV	TSSR(R5),R1				;GET TSSR CONTENTS
252	024632	012702	100204		MOV	#SSR,SC!BIT2,R2				;SET UP EXPECTED
253	024636	020102			CMP	R1,R2				;ARE THEY EQUAL
254	024640	001406			BEQ	180\$;BR. IF OK
255	024642	005237	002214		INC	FATFLG				;ERROR COUNT
259	024646				ERRHRD	ERRNO,T29WDE,PKTSSP				;TSSR INCORRECT AFTER READ DATA
	024646	104456							TRAP	C\$ERHRD
	024650	000162							.WORD	114
	024652	027562							.WORD	T29WDE
	024654	012126							.WORD	PKTSSR
260	024656			180\$:	CKLOOP					;LOOP IF SELECTED
	024656	104406							TRAP	C\$CLP1
261	024660	013701	026356		MOV	T29BFR+14,R1				;GET XST3 STATUS WORD
262	024664	010102			MOV	R1,R2				;SET UP EXPECTED
263	024666	052702	000001		BIS	#BIT0,R2				;SET THE RIB BIT
264	024672	020102			CMP	R1,R2				;ARE THEY EQUAL
265	024674	001406			BEQ	190\$;BR. IF EQUAL (GOOD)
266	024676	005237	002214		INC	FATFLG				;ERROR COUNT
270	024702				ERRHRD	ERRNO,T29RIB,EXPREC				;NEF SHOULD BE SET
	024702	104456							TRAP	C\$ERHRD
	024704	000163							.WORD	115
	024706	031724							.WORD	T29RIB
	024710	015554							.WORD	EXPREC

H8

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
TEST 1: WRITE TAPE MARK RETRY

SEQ 098

```

271 024712          190$:
272 024712          ENDSUB          ;>>>>>>>>>> END SUBTEST >>>>>>>>>>
      024712                    L10040:
      024712 104403                    TRAP          C$ESUB
273 024714 023727 002214 000017      CMP          FATFLG, #15.          ;IS ERROR COUNT AT 25
274 024722 103402                    BLO          999$                ;BR, IF LESS THAN 25
275 024724 004737 017262                    JSR          PC,CKDROP           ;TRY TO DROP THE UNIT
276 024730          999$:
277          ;*
278          ;
279          ;TEST 1, SUBTEST 3
280          ;
281          ;VERIFIES THAT A WRITE TAPE MARK RETRY COMMAND TERMINATES
282          ;PROPERLY AND WRITES THE TAPE MARK ONTO TAPE (BY ISSUING A READ REVERSE
283          ;COMMAND AND CHECKING FOR TAPE STATUS ALERT TERMINATION AND TMK=1).
284          ;
285          ;-
286 024730          BGNSUB          ;>>>>>>>>>> BEGIN SUBTEST >>>>>>>>>>
      024730                    T1.3:
      024730 104402                    TRAP          C$BSUB
287 024732 004737 032146                    JSR          PC,T29REST          ;SET COMMAND PACKET
288 024736 004737 032240                    JSR          PC,T29RT2          ;SET UP OTHER COMMAND PACKET
289 024742 004737 032302                    JSR          PC,T29RT3          ;SET UP OTHER COMMAND PACKET
290 024746 012737 023420 026500          MOV          #10000.,T29DLY      ;SET UP DELAY ROUTINE
291 024754 004737 016054          10$:          JSR          PC,SOFINIT          ;DO INITIALIZE ON CONTROLLER
292 024760 103426                    BCS          20$                ;BR IF INIT WAS OK
293 024762                    DELAY          250                ;DELAY ABOUT .25 SECONDS
      024762 012727 000250                    MOV          #250,(PC)+
      024766 000000                    .WORD          0
      024770 013727 002116                    MOV          L$DLY,(PC)+
      024774 000000                    .WORD          0
      024776 005367 177772                    DEC          -6(PC)
      025002 001375                    BNE          .-4
      025004 005367 177756                    DEC          -22(PC)
      025010 001367                    BNE          .-20
294 025012 005337 026500          DEC          T29DLY            ;BUMP DELAY ROUTINE DOWN
295 025016 001356                    BNE          10$                ;BR, IF MORE DELAY TIME LEFT
296 025020 005237 002214          INC          FATFLG            ;ERROR COUNT
300 025024 010001                    MCV          R0,R1              ;CONTENTS OF TSSR REGISTER
301 025026          ER/DF          ERRNO,SFIERR,SFIMSG          ;FATAL ERROR TSSR WAS NOT OK
      025026 104455                    TRAP          C$ERDF
      025030 000164                    .WORD          116
      025032 003646                    .WORD          SFIERR
      025034 012114                    .WORD          SFIMSG
302 025036 013737 002174 026340 20$:          MOV          UNITN,T29DSW        ;SET UP DRIVE NUMBER
303 025044 012704 026320                    MOV          #T29PACKET,R4      ;SUBROUTINE NEEDS PACKET ADDRESS
304 025050 004737 010742                    JSR          PC,WRTCHR          ;ISSUE WRITE CHARACTERISTICS
305 025054 103407                    BCS          23$                ;BR, IF COMMAND ISSUED OK
306 025056 005237 002214          INC          FATFLG            ;ERROR COUNT
310 025062 010001                    MOV          R0,R1              ;SAVE CONTENTS OF TSSR
311 025064          ERRHRD          ERRNO,WRTMSG,SFIMSG          ;WRITE CHARACTERISTICS FAILED
      025064 104456                    TRAP          C$ERHRD
      025066 000165                    .WORD          117
      025070 005052                    .WORD          WRTMSG
      025072 012114                    .WORD          SFIMSG
312 025074          23$:          CKLOOP          ;LOOP IF SELECTED
      025074 104406                    TRAP          C$CLP1

```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 1: WRITE TAPE MARK RETRY

SEQ 099

313	025076	004737	011074		JSR	PC,REWIND		;CALL TAPE REWIND COMMAND	
314	025102	103411			BCS	30\$;BR, IF NO PROBLEM	
315	025104	016501	000002		MOV	TSSR(R5),R1		;GET TSSR	
316	025110	010004			MOV	R0,R4		;SAVE PACKET ADDRESS	
317	025112	005237	002214		INC	FATFLG		;ERROR COUNT	
321	025116				ERRHRD	ERRNO,T29RWN,PKTSSR		;REWIND NOT ACCEPTED	
	025116	104456						TRAP	C\$ERHRD
	025120	000166						.WORD	118
	025122	030305						.WORD	T29RWN
	025124	012126						.WORD	PKTSSR
322	025126			30\$:	CKLOOP			;LOOP IF SELECTED	
	025126	104406						TRAP	C\$CLP1
323	025130	013701	026350		MOV	T29BFR+6,R1		;PICK UP XSTO	
324	025134	010102			MOV	R1,R2		;SET UP EXPECTED	
325	025136	052702	000002		BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED	
326	025142	020102			CMP	R1,R2		;DOES EXP = REC'D	
327	025144	001406			BEQ	40\$;BR, IF EQUAL (OK)	
328	025146	005237	002214		INC	FATFLG		;ERROR COUNT	
332	025152				ERRHRD	ERRNO,T29BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND	
	025152	104456						TRAP	C\$ERHRD
	025154	000167						.WORD	119
	025156	027776						.WORD	T29BOT
	025160	015554						.WORD	EXPREC
333	025162			40\$:	CKLOOP			;LOOP IF SELECTED	
	025162	104406						TRAP	C\$CLP1
334	025164	012737	140011	026440	MOV	#140011,T29PK3		;WRITE TAPE MARK,ACK,CVC=1 COMMAND	
335	025172	012704	026440		MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS	
336	025176	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND	
337	025202	004737	016330		JSR	PC,WAITF		;WAIT FOR SSR TO SET	
338	025206	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS	
339	025212	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED	
340	025216	020102			CMP	R1,R2		;ARE THEY EQUAL	
341	025220	001406			BEQ	70\$;BR, IF OK	
342	025222	005237	002214		INC	FATFLG		;ERROR COUNT	
346	025226				ERRHRD	ERRNO,T29WDC,PKTSSR		;TSSR INCORRECT AFTER WRITE TAPE MARK	
	025226	104456						TRAP	C\$ERHRD
	025230	000170						.WORD	120
	025232	030677						.WORD	T29WDC
	025234	012126						.WORD	PKTSSR
347	025236			70\$:	CKLOOP			;LOOP IF SELECTED	
	025236	104406						TRAP	C\$CLP1
348	025240	012703	000001		MOV	#1.,R3		;NUMBER OF RECORDS TO WRITE TM	
349	025244	012737	141011	026440	MOV	#141011,T29PK3		;WRITE TAPE MARK RETRY,ACK,CVC=1 COMMAND	
350	025252	012704	026440		MOV	#T29PK3,R4		;SET UP R4 WITH PACKET ADDRESS	
351	025256	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND	
352	025262	004737	016330		JSR	PC,WAITF		;WAIT FOR SSR TO SET	
353	025266	016501	000002		MOV	TSSR(R5),R1		;PICK UP TSSR	
354	025272	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED (SSR ONLY)	
355	025276	020102			CMP	R1,R2		;WAS STATUS GOOD	
356	025300	001406			BEQ	165\$;BR, IF TERMINATION WAS GOOD	
357	025302	005237	002214		INC	FATFLG		;ERROR COUNT	
361	025306				ERRHRD	ERRNO,T29WDC,PKTSSR		;TSSR NOT CORRECT AFTER WRT TAPE M.	
	025306	104456						TRAP	C\$ERHRD
	025310	000171						.WORD	121
	025312	030677						.WORD	T29WDC
	025314	012126						.WORD	PKTSSR
362	025316			165\$:	CKLOOP			;LOOP IF SELECTED	

K8

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 1: WRITE TAPE MARK RETRY

SEQ 101

411	025504	103426		BCS	20\$;BR IF INIT WAS OK		
412	025506			DELAY	250		;DELAY ABOUT .25 SECONDS		
	025506	012727	000250					MOV	#250,(PC)+
	025512	000000						.WORD	0
	025514	013727	002116					MOV	L\$DLY,(PC)+
	025520	000000						.WORD	0
	025522	005367	177772					DEC	-6(PC)
	025526	001375						BNE	.-4
	025530	005367	177756					DEC	-22(PC)
	025534	001367						BNE	.-20
413	025536	005337	026500	DEC	T29DLY		;BUMP DELAY ROUTINE DOWN		
414	025542	001356		BNE	10\$;BR, IF MORE DELAY TIME LEFT		
415	025544	005237	002214	INC	FATFLG		;ERROR COUNT		
419	025550	010001		MOV	RO,R1		;CONTENTS OF TSSR REGISTER		
420	025552			ERRDF	ERRNO,SFIERR,SFIMSG		;FATAL ERROR TSSR WAS NOT OK		
	025552	104455						TRAP	C\$ERDF
	025554	000174						.WORD	124
	025556	003646						.WORD	SFIERR
	025560	012114						.WORD	SFIMSG
421	025562	013737	002174	026340	20\$:	MOV	UNITN,T29DSW		;SET UP DRIVE NUMBER
422	025570	012704	026320			MOV	#T29PACKET,R4		;SUBROUTINE NEEDS PACKET ADDRESS
423	025574	004737	010742			JSR	PC,WRTCHR		;ISSUE WRITE CHARACTERISTICS
424	025600	103407				BCS	23\$;BR, IF COMMAND ISSUED OK
425	025602	005237	002214			INC	FATFLG		;ERROR COUNT
429	025606	010001				MOV	RO,R1		;SAVE CONTENTS OF TSSR
430	025610			ERRHRD	ERRNO,WRTMSG,SFIMSG		;WRITE CHARACTERISTIC FAILED		
	025610	104456						TRAP	C\$ERHRD
	025612	000175						.WORD	125
	025614	005052						.WORD	WRTMSG
	025616	012114						.WORD	SFIMSG
431	025620			23\$:	CKLOOP		;LOOP IF SELECTED		
	025620	104406						TRAP	C\$CLP1
432	025622	004737	011074			JSR	PC,REWIND		;CALL TAPE REWIND COMMAND
433	025626	103411				BCS	30\$;BR, IF NO PROBLEM
434	025630	016501	000002			MOV	TSSR(R5),R1		;GET TSSR
435	025634	010004				MOV	RO,R4		;SAVE PACKET ADDRESS
436	025636	005237	002214			INC	FATFLG		;ERROR COUNT
440	025642			ERRHRD	ERRNO,T29RWN,PKTSSR		;REWIND NOT ACCEPTED		
	025642	104456						TRAP	C\$ERHRD
	025644	000176						.WORD	126
	025646	030305						.WORD	T29RWN
	025650	012126						.WORD	PKTSSR
441	025652			30\$:	CKLOOP		;LOOP IF SELECTED		
	025652	104406						TRAP	C\$CLP1
442	025654	013701	026350			MOV	T298FR+6,R1		;PICK UP XSTO
443	025660	010102				MOV	R1,R2		;SET UP EXPECTED
444	025662	052702	000002			BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED
445	025666	020102				CMR	R1,R2		;DOES CAP = REC'D
446	025670	001406				BEQ	40\$;BR, IF EQUAL (OK)
447	025672	005237	002214			INC	FATFLG		;ERROR COUNT
451	025676			ERRHRD	ERRNO,T29BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND		
	025676	104456						TRAP	C\$ERHRD
	025700	000177						.WORD	127
	025702	027776						.WORD	T29BOT
	025704	015554						.WORD	EXPREC
452	025706			40\$:	CKLOOP		;LOOP IF SELECTED		
	025706	104406						TRAP	C\$CLP1

453	025710	012737	140011	026440	MOV	#140011,T29PK3	WRITE TAPE MARK,ACK,CVC=1 COMMAND
454	025716	012704	026440		MOV	#T29PK3,R4	SET UP R4 WITH PACKET ADDRESS
455	025722	010465	000000		MOV	R4,TSDB(R5)	ISSUE COMMAND
456	025726	004737	016330		JSR	PC,WAITF	WAIT FOR SSR TO SET
457	025732	016501	000002		MOV	TSSR(R5),R1	GET TSSR CONTENTS
458	025736	012702	000200		MOV	#SSR,R2	SET UP EXPECTED
459	025742	020102			CMP	R1,R2	ARE THEY EQUAL
460	025744	001406			BEQ	70\$	BR, IF OK
461	025746	005237	002214		INC	FATFLG	ERROR COUNT
465	025752				ERRHRD	ERRNO,T29WDC,PKTSSR	TSSR INCORRECT AFTER WRITE TAPE MARK
	025752	104456					TRAP C\$ERHRD
	025754	000200					.WORD 128
	025756	030677					.WORD T29WDC
	025760	012126					.WORD PKTSSR
466	025762			70\$:	CKLOOP		LOOP IF SELECTED
	025762	104406					TRAP C\$CLP1
467	025764	012703	000012		150\$:	MOV #10.,R3	NUMBER OF RECORDS TO WRITE TM
468	025770	012737	000001	026442	MOV	#1,T29RB	SET UP PACKET
469	025776	012737	141011	026440	MOV	#141011,T29PK3	WRITE TAPE MARK RETRY,ACK,CVC=1 COMMAND
470	026004	012704	026440		MOV	#T29PK3,R4	SET UP R4 WITH PACKET ADDRESS
471	026010	010465	000000		155\$:	MOV R4,TSDB(R5)	ISSUE COMMAND
472	026014	004737	016330		JSR	PC,WAITF	WAIT FOR SSR TO SET
473	026020	016501	000002		MOV	TSSR(R5),R1	PICK UP TSSR
474	026024	012702	000200		MOV	#SSR,R2	SET UP EXPECTED (SSR ONLY)
475	026030	020102			CMP	R1,R2	WAS STATUS GOOD
476	026032	001406			BEQ	165\$	BR, IF TERMINATION WAS GOOD
477	026034	005237	002214		INC	FATFLG	ERROR COUNT
481	026040				ERRHRD	ERRNO,T29WDC,PKTSSR	TSSR NOT CORRECT AFTER WRT TAPE M.
	026040	104456					TRAP C\$ERHRD
	026042	000201					.WORD 129
	026044	030677					.WORD T29WDC
	026046	012126					.WORD PKTSSR
482	026050			165\$:	CKLOOP		LOOP IF SELECTED
	026050	104406					TRAP C\$CLP1
483	026052	005303			DEC	R3	BUMP COUNTER DOWN
484	026054	001355			BNE	155\$	BR, IF LESS THAN 10 TAPE MARKS
485	026056	012737	140410	026440	MOV	#140410,T29PK3	SPACE REVERSE,ACK,CVC=1, COMMAND
486	026064	012737	000001	026442	MOV	#1,T29RB	NUMBER OF RECORDS TO SPACE BACK
487	026072	012704	026440		MOV	#T29PK3,R4	SET UP R4 WITH PACKET ADDRESS
488	026076	010465	000000		MOV	R4,TSDB(R5)	ISSUE COMMAND
489	026102	004737	016330		JSR	PC,WAITF	WAIT FOR SSR TO SET
490	026106	016501	000002		MOV	TSSR(R5),R1	GET TSSR CONTENTS
491	026112	012702	100204		MOV	#SSR!SC!BIT2,R2	SET UP EXPECTED
492	026116	020102			CMP	R1,R2	ARE THEY EQUAL
493	026120	001406			BEQ	222\$	BR, IF OK
494	026122	005237	002214		INC	FATFLG	ERROR COUNT
498	026126				ERRHRD	ERRNO,T29WDE,PKTSSR	TSSR INCORRECT AFTER SPACE CMD.
	026126	104456					TRAP C\$ERHRD
	026130	000202					.WORD 130
	026132	027562					.WORD T29WDE
	026134	012126					.WORD PKTSSR
499	026136			222\$:	CKLOOP		LOOP IF SELECTED
	026136	104406					TRAP C\$CLP1
500	026140	012737	100410	026440	MOV	#100410,T29PK3	SPACE REVERSE,ACK, COMMAND
501	026146	012737	000005	026442	MOV	#5,T29RB	NUMBER OF RECORDS TO SPACE BACK
502	026154	012704	026440		MOV	#T29PK3,R4	SET UP R4 WITH PACKET ADDRESS
503	026160	010465	000000		MOV	R4,TSDB(R5)	ISSUE COMMAND

```

504 026164 004737 016330 JSR PC,WAITF ;WAIT FOR SSR TO SET
505 026170 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
506 026174 012702 100204 MOV #SSR!SC!BIT2,R2 ;SET UP EXPECTED
507 026200 020102 CMP R1,R2 ;ARE THEY EQUAL
508 026202 001406 BEQ 260$ ;BR, IF OK
509 026204 005237 002214 INC FATFLG ;ERROR COUNT
513 026210 ERRHRD ERRNO,T29RDG,PKTSSR ;TSSR INCORRECT AFTER SPACE REV CMD
; TRAP C$ERHRD
; .WORD 131
; .WORD T29RDG
; .WORD PKTSSR
514 026220 260$: CKLOOP ;LOOP IF SELECTED
; TRAP C$CLP1
515 026222 013701 026356 MOV T29BFR+14,R1 ;PICK UP XST3
516 026226 010102 MOV R1,R2 ;SET UP EXPECTED
517 026230 052702 000001 BIS #BIT0,R2 ;RIB SHOULD BE SET
518 026234 020102 CMP R1,R2 ;IS RIB SET
519 026236 001406 BEQ 270$ ;BR, IF RIB WAS SET (GOOD)
520 026240 005237 002214 INC FATFLG ;ERROR COUNT
524 026244 ERRHRD ERRNO,T29RIB,EXPREC ;TMK NOT SET AFTER READ REV
; TRAP C$ERHRD
; .WORD 132
; .WORD T29RIB
; .WORD EXPREC
525 026254 270$: CKLOOP ;LOOP IF SELECTED
; TRAP C$CLP1
526 026256 330$: CKLOOP ;LOOP IF SELECTED
; TRAP C$CLP1
527 026260 ENDSUB ;<<<<<<<<<<<<< END SUBTEST >>>>>>>>>
; L10042:
; TRAP C$ESUB
528 026262 023727 002214 000017 CMP FATFLG,#15. ;IS ERROR COUNT AT 25
529 026270 103402 BLO 999$ ;BR, IF LESS THAN 25
530 026272 004737 017262 JSR PC,CKDROP ;TRY TO DROP THE UNIT
531 026276 999$:
532 ;
533 ;
534 ;
535 026276 004737 016536 JSR PC,TSTLOOP ;DO WE NEED TO ITERATE TEST
536 026302 103002 BCC 163$ ;BR, IF NO LOOP REQUIRED
537 026304 000137 023556 JMP T29LOOP ;EXECUTE AGAIN
538 026310 163$: EXIT TST ;ALL DONE THIS TEST
; TRAP C$EXIT
; .WORD L10036-.
539 ;+
540 ;LOCAL STORAGE FOR THIS TEST
541 ;-
543 026320 = < . + 10 > & 177770
545 026320 T29PACKET: ;COMMAND PACKET FOR TEST
; .WORD 14004 ;WRITE CHARACTERISTICS COMMAND, WITH CVC=1, ACK
; .WORD T29DATA ;ADDRESS OF CHARACTERISTICS BLOCK
; .WORD 0
; .WORD 10. ;STARTING VALUE OF BLOCK SIZE
546 026320 ;CHARACTERISTICS DATA BLOCK
547 026322 ;ADDRESS OF MESSAGE BUFFER
548 026324 000000
549 026326 000012
550 026330 T29DATA:
; .WORD T29BFR
551 026330 ; .WORD 0
552 026332 ; .WORD 20.
553 026334 ;LENGTH OF MESSAGE BUFFER

```

```

554 026336 000000          .WORD 0
555 026340 000000 T29DSW: .WORD 0          ;SELECT DRIVE 0
556 026342          T29BFR: .BLKW 25.      ;MESSAGE BUFFER
557
558          ;WRITE SUBSYSTEM MEMORY COMMAND PACKET
559
561          026430          .*=+.10>E177770
563 026430          T29PK2:
564 026430 100006          .WORD 100006      ;WRITE SUB SYS MEM COMMAND, AND ACK
565 026432 026450          .WORD T29BF2      ;ADDRESS OF SELECT BLOCK DATA
566 026434 000000          .WORD 0
567 026436 000006          .WORD 6.          ;SIZE OF DATA PACKET
568
572 026440          T29PK3:
573 026440 140005          .WORD 140005      ;WRITE TAPE MARK RETRY COMMAND, CVC=1 AND ACK
574 026442          T29RB:
575 026442 003116          T29WB: .WORD FREE      ;ADDRESS OF WRITE BUFFER
576 026444 000000          .WORD 0
577 026446 000000          T29SZ: .WORD 0          ;SIZE OF BUFFER (EXTENT)
578          .EVEN
579
580
581
582 026450          T29BF2:
583 026450 010          T29BS0: .BYTE 10      ;BSELO AREA
584 026451 200          T29BS1: .BYTE 200     ;BSEL1 AREA
585 026452 000000          T29S2: .WORD 0          ;SEL 2 AREA
586 026454 000000          T29S3: .WORD 0          ;DATA AREA
587
588
589          .EVEN
590          ;TAPE MOTION PACKET COMMAND VALUES
591
592 026456 140001          T29RN: .WORD 140001      ;READ DATA
593 026460 140401          T29WDR: .WORD 140401      ;READ DATA REVERSE
594 026462 141001          T29CON: .WORD 141001      ;READ PREVIOUS OPP=0
595 026464 161001          .WORD 161001      ;READ PREVIOUS OPP=1
596 026466 141401          .WORD 141401      ;WRITE TAPE MARK RETRY NEXT OPP=0
597 026470 161401          .WORD 161401      ;WRITE TAPE MARK RETRY NEXT OPP=1
598 026472 177777          .WORD 177777      ;END OF DATA
599
600
601 026474 000000          T29CNT: .WORD 0          ;TAPE RECORD COUNTER STORAGE AREA
602
603 026476 000000          T29RSZ: .WORD 0          ;RECORD STORAGE SIZE AREA
604 026500 000000          T29DLY: .WORD          ;DELAY COUNTER STORAGE AREA
605
606          ;LOCAL TEXT MESSAGES FOR TEST
607
608
609 026502 104 162 151 T290FL: .ASCIZ 'Drive is OFFLINE'
610 026523 124 141 160 T29WNG: .ASCIZ 'Tape Position Incorrect After WRITE TAPE MARK RETRY Previous (OPP=1)'
611 026630 127 122 111 T29NEF: .ASCIZ 'WRITE TAPE MARK RETRY At BOT, Failed To Set NEF (XST0)'
612 026720 124 123 123 T29RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
613 026767 127 122 111 T29RRF: .ASCIZ 'WRITE TAPE MARK RETRY Previous (Space Reverse, Read Forward) Command Failed'
614 027103 127 122 111 T29RRG: .ASCIZ 'WRITE TAPE MARK RETRY Previous (Read Forward, Space Reverse) Command Failed'
615 027217 120 117 123 T29SC: .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'

```


616	027301	122	111	102	T29LOR:	.ASCIZ	'RIB NOT SET AFTER READ REVERSE INTO BOT'
617	027351	124	123	123	T29WOF:	.ASCIZ	'TSSR Not Correct After Illegal Mode Bits Set'
618	027426	111	154	154	T29LOQ:	.ASCIZ	'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
619	027507	127	122	111	T29SSR:	.ASCIZ	'WRITE TAPE MARK RETRY COMMAND Not Accepted'
620	027562	124	123	123	T29WDE:	.ASCIZ	'TSSR Not Correct After SPACE REVERSE DATA Command'
621	027644	052	052	052	T29WLK:	.ASCIZ	'*****TAPE IS WRITE-LOCKED AND WILL CAUSE ERRORS*****'
622	027731	124	123	123	T29WRT:	.ASCIZ	'TSSR Not Correct After WRITE Command'
623	027776	124	141	160	T29BOT:	.ASCIZ	'Tape Not At BOT After REWIND Command'
624	030043	104	141	164	T29DTA:	.ASCIZ	'Data Written To Tape Not Equal To Data Read From Tape'
625	030131	127	122	111	T29EOT:	.ASCIZ	'WRITE TAPE MARK RETRY DATA OVER EOT GAVE NO TAPE STATUS ALERT'
626	030227	124	123	123	T29TM:	.ASCIZ	'TSSR Not Correct After SPACE REVERSE Into BOT'
627	030305	122	145	167	T29RWN:	.ASCIZ	'Rewind (POSITION) Command Not Accepted'
628	030354	122	101	115	T29RNC:	.ASCIZ	'RAM Error, Correct Data Pattern Not In Ram'
629	030427	124	123	123	T29AM3:	.ASCIZ	'TSSR Init, Failed After WRITE TAPE MARK RETRY COMMAND'
630	030515	104	162	151	T29OF7:	.ASCIZ	'Drive 7 Select Failed To Set "OFL" In TSSR'
631	030570	124	123	123	T29WDD:	.ASCIZ	'TSSR Not Correct After WRITE TAPE MARK RETRY DATA Command, SWB Bit Set'
632	030677	124	123	123	T29WDC:	.ASCIZ	'TSSR Not Correct After WRITE TAPE MARK RETRY DATA Command'
633	030771	103	126	103	T29VCK:	.ASCIZ	'CVC Set, Didn't Reset VCK In Message Buffer'
634	031044	124	123	102	T29BA:	.ASCIZ	'TSBA Not Correct After WRITE TAPE MARK RETRY DATA Command'
635	031136	127	122	111	T29WSS:	.ASCIZ	'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
636	031225	122	145	141	T29LON:	.ASCIZ	'Reading Long Record Failed To Set RLL Bit In XST0'
637	031307	122	145	141	T29LOP:	.ASCIZ	'Reading Long Record Failed To Set RLS Bit In XST0'
638	031371	122	145	163	T29PBP:	.ASCIZ	'Residual Byte Count Incorrect After Short Record Read'
639	031457	122	145	141	T29TRL:	.ASCIZ	'Reading Long Record Failed To Give Tape Status Alert'
640	031545	104	141	164	T29NEQ:	.ASCIZ	'Data WRITE TAPE MARK RETRY From Tape Not Correct, After SWB=1'
641	031643	124	123	123	T29RDG:	.ASCIZ	'TSSR Incorrect After READ REVERSE Into Tape Mark'
642	031724	127	122	111	T29RIB:	.ASCIZ	'WRITE TAPE MARK RETRY At First Record, Failed To Set RIB (XST3)'
643	032024	124	115	113	T29RRN:	.ASCIZ	'TRK (XST0) Failed To Set After READ REVERSE Into Tape Mark'
644	032117	127	162	151	T29ID:	.ASCIZ	'Write Tape Mark Retry'
645						.EVEN	
646							
647							
648							
649							
650							
651							
652							
653	032146				T29REST:		
654	032146				SAVREG		'SAVE THE REGISTERS
655	032152	012701	026320		MOV	@T29PACKET,R1	'START OF THE PACKET
656	032156	012721	140004		MOV	@140004,(R1),	'WRITE SUBSYSTEM MEM. WITH ACK, CVC=1
657	032162	012721	026330		MOV	@T29DATA,(R1),	'ADDRESS OF CHARACTERISTICS DATA BLOCK
658	032166	005021			CLR	(R1),	'EXTENDED ADDRESS
659	032170	012721	000012		MOV	@10,(R1),	'SIZE OF DATA BLOCK IN BYTES
660	032174	012721	026342		MOV	@T29BFR,(R1),	'ADDRESS OF MESSAGE BUFFER
661	032200	005021			CLR	(R1),	
662	032202	012721	000024		MOV	@20,(R1),	'LENGTH OF MESSAGE BUFFER
663	032206	005021			CLR	(R1),	
664	032210	012711	000000		MOV	@0,(R1)	'SELECT DRIVE ZERO (0)
665	032214	012702	000030		MOV	@24,R2	'NUMBER OF LOCATIONS TO BE CLEARED
666	032220	012762	177777	026342	MOV	@177777,T29BFR(R2)	'ALL ONES TO MESSAGE BUFFER
667	032226	005742			TST	(R2)	'NEXT LOCATION
668	032230	020227	000000		CMP	R2,@0	'CHECK FOR END OF LOOP
669	032234	001371			BNE	648	'KEEP GOING UNTIL DONE
670	032236	000207			RTS	PC	'RETURN
671							
672	032240				T29RT2:		

```

673 032240          SAVREG          ;SAVE THE REGISTERS
674 032244 012701 026430          MOV      @T29PK2,R1          ;START OF THE PACKET
675 032250 012721 140006          MOV      @140006,(R1)+        ;WRITE SUBSYSTEM MEM. WITH ACK,CVC=1,
676 032254 012721 026450          MOV      @T29BF2,(R1)+        ;ADDRESS OF DATA BLOCK
677 032260 005021          CLR      (R1)+          ;EXTENDED ADDRESS
678 032262 012721 000006          MOV      @6,(R1)+          ;SIZE OF DATA BLOCK IN BYTES
679 032266 005021          CLR      (R1)+
680 032270 012701 026450          MOV      @T29BF2,R1          ;POINT TO DATA SEL. AREA
681 032274 005021          CLR      (R1)+
682 032276 005011          CLR      (R1)
683 032300 000207          RTS      PC          ;RETURN
684 032302
685 032302          T29RT3:          SAVREG          ;SAVE THE REGISTERS
686 032306 012701 026440          MOV      @T29PK3,R1          ;START OF THE PACKET
687 032312 012721 000000          MOV      @0,(R1)+        ;WRITE SUBSYSTEM MEM. WITH ACK,
688 032316 012721 000000          MOV      @0,(R1)+        ;ADDRESS OF DATA BLOCK
689 032322 005021          CLR      (R1)+          ;EXTENDED ADDRESS
690 032324 012711 000000          MOV      @0,(R1)          ;SIZE OF DATA BLOCK IN BYTES
691 032330 000207          RTS      PC          ;RETURN
692 032332          ENDTST
        032332
        032332 104401          L10036:          TRAP      C$ETST
693
694          .SBTTL TEST 2: SKIP TAPE MARKS
695
696          ;
697          ; THIS TEST VERIFIES PROPER OPERATION OF THE SKIP TAPE MARKS
698          ; FORWARD AND SKIP TAPE MARKS REVERSE COMMANDS. PROPER OPERATION
699          ; UNDER CONTROL OF ALL COMBINATIONS OF THE ENABLE SKIP TAPE MARKS
700          ; STOP (ESS) AND ENABLE TAPE MARKS STOP OFF BOT (ENB) BITS SPECIFIED
701          ; BY THE WRITE CHARACTERISTICS COMMAND. THE TEST CONSISTS OF THE
702          ; FOLLOWING SUBTESTS (FOR EACH SUBTEST, THE TAPE IS FIRST WRITTEN
703          ; WITH AN APPROPRIATE SERIES OF DATA RECORDS AND/OR TAPE MARKS
704          ; AND/OR DOUBLE TAPE MARKS.
705          ;
706          ; THE TEST CONSISTS OF THE FOLLOWING 11 SUBTESTS
707          ;
708          ;
709          ;
710          ;
711          ;
712          ;
713          ;
714          ;
715          ;
716          ;
717          ;
718          ;
719          ;
720          ;
721          ;
722          ;
723          ;
724          ;
725          ;
726          ;
727          ;
728          ;
729          ;
730          ;

```


TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
TEST 2: SKIP TAPE MARKS

SEQ 108

```

777 032512 005237 002214          INC    FATFLG          ;ERROR COUNT
781 032516 010001                  MOV    R0,R1          ;SAVE CONTENTS OF TSSR
782 032520                  ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                104456          TRAP    C$ERHRD
                                032522 000312          .WORD  202
                                032524 005052          .WORD  WRTMSG
                                032526 012114          .WORD  SFIMSG
783 032530                  23$:   CKLOOP          ;LOOP IF SELECTED          TRAP    C$CLP1
                                032530 104406
784
785 ;*****
786 ;
787 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
788 ;
789 ;*****
790
791 032532 004737 011074          JSR    PC,REWIND      ;CALL TAPE REWIND COMMAND
792 032536 103411                  BCS   30$             ;BR, IF NO PROBLEM
793 032540 010004                  MOV    R0,R4          ;GET PACKET ADDRESS
794 032542 016501 000002          MOV    TSSR(R5),R1   ;GET STATUS REGISTER
795 032546 005237 002214          INC    FATFLG          ;ERROR COUNT
799 032552                  ERRHRD  ERRNO,T3ORWN,PKTSSR ;REWIND NOT ACCEPTED
                                104456          TRAP    C$ERHRD
                                032552 104456          .WORD  203
                                032554 000313          .WORD  T3ORWN
                                032556 040240          .WORD  PKTSSR
800 032562                  30$:   CKLOOP          ;LOOP IF SELECTED          TRAP    C$CLP1
                                032562 104406
801
802 ;*****
803 ;
804 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
805 ;
806 ;*****
807
808 032564 013701 036530          MOV    T30BFR+6,R1   ;PICK UP XSTO
809 032570 010102                  MOV    R1,R2          ;SET UP EXPECTED
810 032572 052702 000002          BIS   #BIT1,R2       ;SET BOT BIT IN EXPECTED
811 032576 020102                  CMP   R1,R2          ;DOES EXP = REC'D
812 032600 001406                  BEQ   40$             ;BR, IF EQUAL (OK)
813 032602 005237 002214          INC    FATFLG          ;ERROR COUNT
817 032606                  ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                104456          TRAP    C$ERHRD
                                032610 000314          .WORD  204
                                032612 040041          .WORD  T30BOT
                                032614 015554          .WORD  EXPREC
818 032616                  40$:   CKLOOP          ;LOOP IF SELECTED          TRAP    C$CLP1
                                032616 104406
819 032620 012737 000001 036654          MOV    #1.,T30FCN    ;SET "FILE" COUNTER AT 1 DECIMAL
820 032626 012703 000001          64$:  MOV    #1,R3    ;ONE RECORD PER "FILE"
821 032632 013737 003116 036622          65$:  MOV    FREE,T30WB ;SET UP PACKETS'S WRITE BUFFER
822 032640 012737 003720 036626          MOV    #2000.,T30SZ ;SET RECORD SIZE AT 2000 BYTES
823
824 ;*****
825 ;
826 ;WRITE DATA,ACK,CVC=1 COMMAND
827 ;

```

```

828 ;*****
829
830 032646 012737 140005 036620      MOV      140005,T30PK3      ;WRITE DATA,ACK,CVC=1 COMMAND
831 032654 012704 036620              MOV      T30FCN,R4        ;SET UP R4 WITH PACKET ADDRESS
832 032660 013702 036654              MOV      T30FCN,R2        ;GET FILE COUNTER
833 032664 000302                      SWAB     R2                ;MOVE TO UPPER BYTE
834 032666 010301                      MOV      R3,R1            ;GET RECORD COUNTER
835 032670 060201                      ADD      R2,R1            ;FILE COUNTER IN UPPER, RECORD # LOW
836 032672 010177 150220              MOV      R1,0FREE        ;MOV TO OUT PUT BUFFER
837 032676 010465 000000              MOV      R4,TSD8(R5)     ;ISSUE COMMAND
838 032702 004737 016330              JSR      PC,WAITF        ;WAIT FOR SSR TO SET
839 032706 016501 000002              MOV      TSSR(R5),R1     ;GET TSSR CONTENTS
840 032712 012702 000200              MOV      QSSR,R2        ;SET UP EXPECTED
841 032716 020102                      CMP      R1,R2            ;ARE THEY EQUAL
842 032720 001406                      BEQ      70$              ;BR, IF OK
843 032722 005237 002214              INC      FATFLG          ;ERROR COUNT
847 032726                      ERRHRD  ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP  C$ERRHRD
                                .WORD 205
                                .WORD T30WDD
                                .WORD PKTSSR
                                TRAP  C$CLP1
                                .WORD 206
                                .WORD T30WDC
                                .WORD PKTSSR
848 032736 104456                      70$:  CKLOOP              ;LOOP IF SELECTED
                                TRAP  C$CLP1
                                .WORD 206
                                .WORD T30WDC
                                .WORD PKTSSR
849 032740 005203                      INC      R3                ;COUNT THE RECORD COUNTER DOWN
850 032742 020327 000021              CMP      R3,#21          ;AT 20 YET
851 032746 001331                      BNE     65$              ;BR, IF NOT AT 20 RECORDS WRITTEN
852
853 ;*****
854 ;
855 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
856 ;
857 ;*****
858
859 032750 012737 141011 036620      MOV      #141011,T30PK3  ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
860 032756 012704 036620              MOV      #T30PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
861 032762 010465 000000              MOV      R4,TSD8(R5)    ;ISSUE COMMAND
862 032766 004737 016330              JSR      PC,WAITF        ;WAIT FOR SSR TO SET
863 032772 016501 000002              MOV      TSSR(R5),R1    ;PICK UP TSSR
864 032776 012702 000200              MOV      QSSR,R2        ;SET UP EXPECTED (SSR ONLY)
865 033002 020102                      CMP      R1,R2            ;WAS STATUS GOOD
866 033004 001406                      BEQ      160$            ;BR, IF TERMINATION WAS GOOD
867 033006 005237 002214              INC      FATFLG          ;ERROR COUNT
871 033012                      ERRHRD  ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP  C$ERRHRD
                                .WORD 206
                                .WORD T30WDC
                                .WORD PKTSSR
                                TRAP  C$CLP1
                                .WORD 206
                                .WORD T30WDC
                                .WORD PKTSSR
872 033022 104406                      160$: CKLOOP              ;LOOP IF SELECTED
                                TRAP  C$CLP1
                                .WORD 206
                                .WORD T30WDC
                                .WORD PKTSSR
873 033024 005237 036654              INC      T30FCN          ;COUNT THE "FILE" COUNTER DOWN
874 033030 023727 036654 000006      CMP      T30FCN,#6      ;WRITE 5 FILE TO TAPE
875 033036 001273                      BNE     64$              ;BR, IF NOT AT 5 FILES WRITTEN
876
877 ;*****
878 ;
879 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
880 ;
    
```

```

881 ;*****
882
883 033040 012737 141011 036620      MOV      #141011,T30PK3      ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
884 033046 012704 036620              MOV      #T30PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
885 033052 010465 000000              MOV      R4,TSD8(R5)      ;ISSUE COMMAND
886 033056 004737 016330              JSR      PC,WAITF        ;WAIT FOR SSR TO SET
887 033062 016501 000002              MOV      TSSR(R5),R1     ;PICK UP TSSR
888 033066 012702 000200              MOV      #SSR,R2        ;SET UP EXPECTED (SSR ONLY)
889 033072 020102                      CMP      R1,R2           ;WAS STATUS GOOD
890 033074 001406                      BEQ      165$           ;BR, IF TERMINATION WAS GOOD
891 033076 005237 002214              INC      FATFLG          ;ERROR COUNT
895 033102                      ERRHRD  ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP      C$ERHRD
                                .WORD    207
                                .WORD    T30WDC
                                .WORD    PKTSSR
                                TRAP      C$CLP1
033102 104456
033104 000317
033106 040362
033110 012126
896 033112                      165$:  CKLOOP          ;LOOP IF SELECTED
033112 104406                      TRAP      C$CLP1
897
898 ;*****
899 ;
900 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
901 ;
902 ;*****
903
904 033114 004737 011074              JSR      PC,REWIND      ;CALL TAPE REWIND COMMAND
905 033120 103411                      BCS     170$           ;BR, IF NO PROBLEM
906 033122 010004                      MOV      R0,R4          ;GET PACKET ADDRESS
907 033124 016501 000002              MOV      TSSR(R5),R1     ;GET STATUS REGISTER
908 033130 005237 002214              INC      FATFLG          ;ERROR COUNT
912 033134                      ERRHRD  ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP      C$ERHRD
                                .WORD    208
                                .WORD    T30RWN
                                .WORD    PKTSSR
                                TRAP      C$CLP1
033134 104456
033136 000320
033140 040240
033142 012126
913 033144                      170$:  CKLOOP          ;LOOP IF SELECTED
033144 104406                      TRAP      C$CLP1
914
915 ;*****
916 ;
917 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
918 ;
919 ;*****
920
921 033146 013701 036530              MOV      T30BFR+6,R1     ;PICK UP XSTO
922 033152 010102                      MOV      R1,R2          ;SET UP EXPECTED
923 033154 052702 000002              BIS     #BIT1,R2        ;SET BOT BIT IN EXPECTED
924 033160 020102                      CMP      R1,R2          ;DOES EXP = REC'D
925 033162 001406                      BEQ     180$           ;BR, IF EQUAL (OK)
926 033164 005237 002214              INC      FATFLG          ;ERROR COUNT
930 033170                      ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C$ERHRD
                                .WORD    209
                                .WORD    T30BOT
                                .WORD    EXPREC
                                TRAP      C$CLP1
033170 104456
033172 000321
033174 040041
033176 015554
931 033200                      180$:  CKLOOP          ;LOOP IF SELECTED
033200 104406                      TRAP      C$CLP1
    
```

```

932 033202 012703 036636          MOV      #T30IMV,R3          ;SET UP POINTER TO COMMAND TABLE
933 033206 013737 002174 036520  MOV      UNITN,T30DSW      ;SET UP UNIT NUMBER
934 033214 011337 036516          MOV      (R3),T30EIM      ;GET NEXT COMMAND
935 033220 012704 036500          MOV      #T30PACKET,R4    ;SUBROUTINE NEEDS PACKET ADDRESS
936
937                                ;*****
938                                ;
939                                ;ISSUE WRITE CHARACTERISTICS COMMAND
940                                ;
941                                ;*****
942
943 033224 004737 010742          JSR      PC,WRTCHR        ;ISSUE WRITE CHARACTERISTICS
944 033230 103407                BCS     188$             ;BR, IF COMMAND ISSUED OK
945 033232 005237 002214          INC     FATFLG          ;ERROR COUNT
949 033236 010001                MOV     R0,R1           ;SAVE CONTENTS OF TSSR
950 033240          ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP     C$ERHRD
                                .WORD   210
                                .WORD   WRTMSG
                                .WORD   SFIMSG
                                TRAP     C$CLP1
033240 104456
033242 000322
033244 005052
033246 012114
951 033250          188$:  CKLOOP          ;LOOP IF SELECTED
033250 104406
952
953                                ;*****
954                                ;
955                                ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
956                                ;
957                                ;*****
958
959 033252 012737 141010 036620  MOV     #141010,T30PK3    ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
960 033260 012737 000001 036622  MOV     #1,T30RB         ;SET UP NUMBER TO SKIP
961 033266 012704 036620          MOV     #T30PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
962 033272 010465 000000          189$:  MOV     R4,T30DB(R5) ;ISSUE COMMAND
963 033276 012737 176750 036656  MOV     #65000,T30DLY    ;SET UP DELAY COUNTER
964 033304 004737 016330          190$:  JSR     PC,WAITF     ;WAIT FOR SSR TO SET
965 033310 016501 000002          MOV     TSSR(R5),R1    ;PICK UP TSSR
966 033314 032701 000200          BIT     #SSR,R1        ;IS SSR SET YET
967 033320 001017                BNE    191$            ;BR, IF SSR IS SET
968 033322          DELAY  250      ;CALL DELAY ROUTINE
                                MOV     #250,(PC)+
                                .WORD   0
                                MOV     L$DLY,(PC)+
                                .WORD   0
                                DEC     -6(PC)
                                BNE    -4
                                DEC     -22(PC)
                                BNE    -20
033322 012727 000250
033326 000000
033330 013727 002116
033334 000000
033336 005367 177772
033342 001375
033344 005367 177756
033350 001367
969 033352 005337 036656          DEC     T30DLY          ;BUMP DELAY ROUTINE
970 033356 001352                BNE    190$            ;BR, IF MORE DELAY TO GO
971 033360 012702 000200          191$:  MOV     #SSR,R2    ;SET UP EXPECTED (SSR ONLY)
972 033364 020102                CMP    R1,R2          ;WAS STATUS GOOD
973 033366 001406                BEQ    192$            ;BR, IF TERMINATION WAS GOOD
974 033370 005237 002214          INC     FATFLG          ;ERROR COUNT
978 033374          ERRHRD  ERRNO,T30SKM,PKTSSR ;TSSR NOT CORRECT AFTER SKIP TAPE M.
                                TRAP     C$ERHRD
                                .WORD   211
                                .WORD   T30SKM
033374 104456
033376 000323
033400 037114

```

```

979 033402 012126          192$:  CKLOOP          ;LOOP IF SELECTED          .WORD  PKTSSR
      033404          ;*****
      033404 104406          ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
980                                     ;*****
981                                     ;*****
982                                     ;*****
983                                     ;*****
984                                     ;*****
985                                     ;*****
986                                     ;*****
987 033406 013701 036530      MOV      T30BFR+6,R1          ;PICK UP XSTO
988 033412 010102          MOV      R1,R2              ;SET UP EXPECTED
989 033414 052702 100000      BIS      #BIT15,R2          ;SET TMK BIT IN EXPECTED
990 033420 020102          CMP      R1,R2              ;DOES EXP = REC'D
991 033422 001406          BEQ      195$              ;BR, IF EQUAL (OK)
992 033424 005237 002214      INC      FATFLG            ;ERROR COUNT
996 033430          ERRHRD  ERRNO,T30TMK,EXPREC          ;TMK NOT SET AFTER WRT TAPE MARK
      033430 104456          TRAP      C$ERHRD
      033432 000324          .WORD   212
      033434 040514          .WORD   T30TMK
      033436 015554          .WORD   EXPREC
997 033440          195$:  CKLOOP          ;LOOP IF SELECTED          TRAP    C$CLP1
      033440 104406          ;VALUE TO WRITTEN TO MEMORY
998 033442 012700 177777      MOV      #177777,R0        ;FILL MEM WITH ALL ONES
999 033446 004737 017502      JSR      PC,FILLMEM        ;STARTING READ BUFFER ADDRESS
1000 033452 013737 003116 036622  MOV      FREE,T30RB
1001                                     ;*****
1002                                     ;*****
1003                                     ;*****
1004                                     ;*****
1005                                     ;*****
1006                                     ;*****
1007                                     ;*****
1008 033460 012737 140001 036620      MOV      #140001,T30PK3    ;READ FORWARD,ACK,CVC=1 COMMAND
1009 033466 012704 036620      MOV      #T30PK3,R4        ;SET UP R4 WITH PACKET ADDRESS
1010 033472 012737 003720 036626      MOV      #2000.,T30SZ      ;SET UP RECORD SIZE IN PACKET
1011 033500 010465 000000      MOV      R4,T30DB(R5)      ;ISSUE COMMAND
1012 033504 004737 016330      JSR      PC,WAITF          ;WAIT FOR SSR TO SET
1013 033510 016501 000002      MOV      TSSR(R5),R1       ;GET TSSR CONTENTS
1014 033514 012702 000200      MOV      #SSR,R2          ;SET UP EXPECTED
1015 033520 020102          CMP      R1,R2              ;ARE THEY EQUAL
1016 033522 001406          BEQ      200$              ;BR, IF OK
1017 033524 005237 002214      INC      FATFLG            ;ERROR COUNT
1021 033530          ERRHRD  ERRNO,T30RDF,PKTSSR          ;TSSR INCORRECT AFTER WRITE DATA
      033530 104456          TRAP      C$ERHRD
      033532 000325          .WORD   213
      033534 037413          .WORD   T30RDF
      033536 012126          .WORD   PKTSSR
1022 033540          200$:  CKLOOP          ;LOOP IF SELECTED          TRAP    C$CLP1
      033540 104406          ;FIRST LOC IN READ BUFFER
1023 033542 017701 147350      MOV      #FREE,R1          ;EXPECTED IF NO DATA TRANS.
1024 033546 012702 177777      MOV      #177777,R2        ;DID ANY DATA GET TRANSFERRED
1025 033552 020102          CMP      R1,R2              ;BR, IF NO DATA TRANS (GOOD)
1026 033554 001006          BNE     220$              ;ERROR COUNT
1027 033556 005237 002214      INC      FATFLG
1031 033562          ERRHRD  ERRNO,T30DTR,EXPREC          ;DATA TRANSFERRED ON READ TAPE MARK
      033562 104456          TRAP      C$ERHRD
    
```


TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
TEST 2: SKIP TAPE MARKS

SEQ 113

```

033564 000326 .WORD 214
033566 041070 .WORD T30DTR
033570 015554 .WORD EXPREC
1032 033572 220$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
033572 104406 ;SET UP RECORD NUMBER EXPECTED (FILE 2)
1033 033574 012702 001001 MOV #1001,R2 ;GET INFO FROM BUFFER
1034 033600 017701 147312 MOV #FREE,R1 ;ARE THEY EQUAL
1035 033604 020201 CMP R2,R1 ;BR, IF EQUAL (OK)
1036 033606 001406 BEQ 228$ ;ERROR COUNT
1037 033610 005237 002214 INC FATFLG ;RECORD POSITION WAS NOT CORRECT
1041 033614 ERRHRD ERRNO,T30PTB,EXPREC TRAP C$ERHRD
033614 104456 .WORD 215
033616 000327 .WORD T30PTB
033620 037242 .WORD EXPREC
033622 015554
1042 033624 228$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
033624 104406
1043
1044 ;*****
1045 ;
1046 ;ISSUE A FFWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
1047 ;
1048 ;*****
1049
1050 033626 004737 011074 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
1051 033632 103411 BCS 230$ ;BR, IF NO PROBLEM
1052 033634 010004 MOV R0,R4' ;SAVE PACKET ADDRESS
1053 033636 016501 000002 MOV TSSR(R5),R1 ;GET TSSR STATUS
1054 033642 005237 002214 INC FATFLG ;ERROR COUNT
1058 033646 ERRHRD ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED TRAP C$ERHRD
033646 104456 .WORD 216
033650 000330 .WORD T30RWN
033652 040240 .WORD PKTSSR
033654 012126
1059 033656 230$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
033656 104406
1060
1061 ;*****
1062 ;
1063 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
1064 ;
1065 ;*****
1066
1067 033660 013701 036530 MOV T30BFR+6,R1 ;PICK UP XSTO
1068 033664 010102 MOV R1,R2 ;SET UP EXPECTED
1069 033666 052702 000002 BIS #BIT1,R2 ;SET BOT BIT IN EXPECTED
1070 033672 020102 CMP R1,R2 ;DOES EXP = REC'D
1071 033674 001406 BEQ 240$ ;BR, IF EQUAL (OK)
1072 033676 005237 002214 INC FATFLG ;ERROR COUNT
1076 033702 ERRHRD ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND TRAP C$ERHRD
033702 104456 .WORD 217
033704 000331 .WORD T30BOT
033706 040041 .WORD EXPREC
033 015554
1077 033 240$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
033 104406
1078 033/14 005723 TST (R3)+ ;POINT TO NEXT POSITION

```

```

1079 033716 011301      MOV    (R3),R1      ;GET NEXT COMMAND ETC.
1080 033720 020127 177777 CMP    R1,#177777   ;END OF TABLE MARKER
1081 033724 001402      BEQ    330$         ;BR, IF AT END OF TABLE
1082 033726 000137 033214 JMP    182$         ;JUMP TO MORE COMMANDS TO DO
1083 033732          330$: CKLOOP        ;LOOP IF SELECTED
            033732 104406      TRAP    C$CLP1
1084 033734          ENDSUB        ;<<<<<<<<<<<<<<<< END SUBTEST >>>>>>>>>>
            033734          L10044:
            033734 104403      TRAP    C$ESUP
1085 033736 023727 002214 000017 CMP    FATFLG,#15.  ;IS ERROR COUNT AT 25
1086 033744 103402      BLO    999$         ;BR, IF LESS THAN 25
1087 033746 004737 017262 JSR    PC,CKDROP    ;TRY TO DROP THE UNIT
1088 033752          999$:
1089          ;*
1090          ;
1091          ;TEST 2, SUBTEST 2
1092          ;
1093          ;VERIFIES THAT SKIP TAPE MARKS COMMANDS WITH A TAPE
1094          ;MARK COUNT GREATER THAN 1 OPERATE PROPERLY. COUNTS
1095          ;OF 2,3,8,64,256, AND 512 ARE TESTED. THE
1096          ;TESTING SEQUENCE IS SIMILAR TO THAT USED IN SUBTEST 1.
1097          ;
1098          ;
1099          ;
1100          ;-
1101          ;-
1102 033752          BGNSUB        ;>>>>>>>>>>>>>>>> BEGIN SUBTEST >>>>>>>>>>
            033752          T2.2:
            033752 104402      TRAP    C$BSUB
1103 033754 004737 041252 JSR    PC,T30REST   ;SET COMMAND PACKET
1104 033760 005037 036654 CLR    T30FCN       ;CLEAR FILE COUNTER
1105 033764 004737 041344 JSR    PC,T30RT2    ;SET UP OTHER COMMAND PACKET
1106 033770 004737 041406 JSR    PC,T30RT3    ;SET UP OTHER COMMAND PACKET
1107 033774 012737 176750 036656 MOV    #65000.,T30DLY ;SET UP DELAY COUNTER
1108 034002 004737 016054 10$: JSR    PC,SOFINIT   ;DO INITIALIZE ON CONTROLLER
1109 034006 103426      BCS    20$         ;BR IF INIT WAS OK
1110 034010          DELAY    250      ;DELAY ROUTINE CALL
            034010 012727 000250      MOV    #250,(PC)+
            034014 000000      .WORD  0
            034016 013727 002116      MOV    L$DLY,(PC)+
            034022 000000      .WORD  0
            034024 005367 177772      DEC    -6(PC)
            034030 001375          BNE    .-4
            034032 005367 177756      DEC    -22(PC)
            034036 001367          BNE    .-20
1111 034040 005337 036656 DEC    T30DLY       ;BUMP COUNTER
1112 034044 001356          BNE    10$         ;BR, IF MORE COUNTING TO DO
1113 034046 005237 002214 INC    FATFLG       ;ERROR COUNT
1117 034052 010001      MOV    R0,R1
1118 034054          ERRDF    ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
            034054 104455      TRAP    C$ERDF
            034056 000332      .WORD  218
            034060 003646      .WORD  SFIERR
            034062 012114      .WORD  SFIMSG
1119 034064          20$:
1120 034064 013737 002174 036520 MOV    UNITN,T30DSW ;SET UP UNIT NUMBER
1121 034072 012704 036500 MOV    #T30PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS

```

```

1122
1123
1124
1125
1126
1127
1128
1129 034076 004737 010742          JSR    PC,WRTCHR          ;ISSUE WRITE CHARACTERISTICS
1130 034102 103407          BCS    23$                ;BR, IF COMMAND ISSUED OK
1131 034104 005237 002214          INC    FATFLG             ;ERROR COUNT
1135 034110 010001          MOV    RO,R1              ;SAVE CONTENTS OF TSSR
1136 034112          ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICSC FAILED
                                TRAP    C$ERHRD
                                .WORD   219
                                .WORD   WRTMSG
                                .WORD   SFIMSG
                                034112 104456
                                034114 000333
                                034116 005052
                                034120 012114
1137 034122          23$:  CKLOOP              ;LOOP IF SELECTED
                                TRAP    C$CLP1
                                034122 104406
1138
1139
1140
1141
1142
1143
1144
1145 034124 004737 011074          JSR    PC,REWIND          ;CALL TAPE REWIND COMMAND
1146 034130 103411          BCS    30$                ;BR, IF NO PROBLEM
1147 034132 010004          MOV    RO,R4              ;GET PACKET ADDRESS
1148 034134 016501 000002          MOV    TSSR(R5),R1        ;GET STATUS REGISTER
1149 034140 005237 002214          INC    FATFLG             ;ERROR COUNT
1153 034144          ERRHRD  ERRNO,T3ORWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP    C$ERHRD
                                .WORD   220
                                .WORD   T3ORWN
                                .WORD   PKTSSR
                                034144 104456
                                034146 000334
                                034150 040240
                                034152 012126
1154 034154          30$:  CKLOOP              ;LOOP IF SELECTED
                                TRAP    C$CLP1
                                034154 104406
1155
1156
1157
1158
1159
1160
1161
1162 034156 013701 036530          MOV    T3OBFR+6,R1        ;PICK UP XSTO
1163 034162 010102          MOV    R1,R2              ;SET UP EXPECTED
1164 034164 052702 000002          BIS    #BIT1,R2           ;SET BOT BIT IN EXPECTED
1165 034170 020102          CMP    R1,R2              ;DOES EXP = REC'D
1166 034172 001406          BEQ    40$                ;BR, IF EQUAL (OK)
1167 034174 005237 002214          INC    FATFLG             ;ERROR COUNT
1171 034200          ERRHRD  ERRNO,T3OBOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP    C$ERHRD
                                .WORD   221
                                .WORD   T3OBOT
                                .WORD   EXPREC
                                034200 104456
                                034202 000335
                                034204 040041
                                034206 015554
1172 034210          40$:  CKLOOP              ;LOOP IF SELECTED
                                TRAP    C$CLP1
                                034210 104406
    
```

```

1173 034212 012737 000001 036654      MOV      #1.,T30FCN      ;SET "FILE" COUNTER AT 1 DECIMAL
1174 034220 012703 000001      64$:    MOV      #1,R3      ;ONE RECORD PER "FILE"
1175 034224 013737 003116 036622 65$:    MOV      FREE,T30WB     ;SET UP PACKETS'S WRITE BUFFER
1176 034232 012737 000024 036626      MOV      #20.,T30SZ     ;SET RECORD SIZE AT 2000 BYTES
1177
1178      ;*****
1179      ;
1180      ;WRITE DATA,ACK,CVC=1 COMMAND
1181      ;
1182      ;*****
1183
1184 034240 012737 140005 036620      MOV      #140005,T30PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
1185 034246 012704 036620      MOV      #T30PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
1186 034252 013702 036654      MOV      T30FCN,R2     ;GET FILE COUNTER
1187 034256 000302      SWAB     R2             ;MOVE TO UPPER BYTE
1188 034260 010301      MOV      R3,R1         ;GET RECORD COUNTER
1189 034262 060201      ADD      R2,R1         ;FILE COUNTER IN UPPER, RECORD # LOW
1190 034264 010177 146626      MOV      R1,#FREE      ;MOV TO OUT PUT BUFFER
1191 034270 010465 000000      MOV      R4,TSDB(R5)   ;ISSUE COMMAND
1192 034274 004737 016330      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
1193 034300 016501 000002      MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
1194 034304 012702 000200      MOV      #SSR,R2      ;SET UP EXPECTED
1195 034310 020102      CMP      R1,R2        ;ARE THEY EQUAL
1196 034312 001406      BEQ      70$          ;BR. IF OK
1197 034314 005237 002214      INC      FATFLG        ;ERROR COUNT
1201 034320      ERRHRD  ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
      034320 104456      TRAP     C$ERHRD
      034322 000336      .WORD   222
      034324 037170      .WORD   T30WDD
      034326 012126      .WORD   PKTSSR
1202 034330      70$:    CKLOOP          ;LOOP IF SELECTED
      034330 104406      TRAP     C$CLP1
1203 034332 005203      INC      R3            ;COUNT THE RECORD COUNTER DOWN
1204 034334 020327 000021      CMP      R3,#21       ;AT 20 YET
1205 034340 001331      BNE     65$          ;BR. IF NOT AT 20 RECORDS WRITTEN
1206
1207      ;*****
1208      ;
1209      ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
1210      ;
1211      ;*****
1212
1213 034342 012737 141011 036620      MOV      #141011,T30PK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
1214 034350 012704 036620      MOV      #T30PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
1215 034354 010465 000000      MOV      R4,TSDB(R5)   ;ISSUE COMMAND
1216 034360 004737 016330      JSR      PC,WAITF      ;WAIT FOR SSR TO SET
1217 034364 016501 000002      MOV      TSSR(R5),R1   ;PICK UP TSSR
1218 034370 012702 000200      MOV      #SSR,R2      ;SET UP EXPECTED (SSR ONLY)
1219 034374 020102      CMP      R1,R2        ;WAS STATUS GOOD
1220 034376 001406      BEQ      160$         ;BR. IF TERMINATION WAS GOOD
1221 034400 005237 002214      INC      FATFLG        ;ERROR COUNT
1225 034404      ERRHRD  ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
      034404 104456      TRAP     C$ERHRD
      034406 000337      .WORD   223
      034410 040362      .WORD   T30WDC
      034412 012126      .WORD   PKTSSR
1226 034414      160$:  CKLOOP          ;LOOP IF SELECTED

```

```

1227 034414 104406                                TRAP C$CLP1
1227 034416 005237 036654 000031      INC      T30FCN      ;COUNT THE "FILE" COUNTER DOWN
1228 034422 023727 036654 000031      CMP      T30FCN, #25. ;WRITE 25 FILES TO TAPE
1229 034430 001273                                BNE      64$         ;BR. IF NOT AT 25 FILES WRITTEN
1230
1231 ;*****
1232 ;
1233 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
1234 ;
1235 ;*****
1236
1237 034432 012737 141011 036620      MOV      #141011,T30PK3 ;WRITE TAPE MARK,ACK,CVC=1 COMMAND
1238 034440 012704 036620                                MOV      #T30PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
1239 034444 010465 000000                                MOV      R4,TSD8(R5)  ;ISSUE COMMAND
1240 034450 004737 016330                                JSR      PC,WAITF     ;WAIT FOR SSR TO SET
1241 034454 016501 000002                                MOV      TSSR(R5),R1  ;PICK UP TSSR
1242 034460 012702 000200                                MOV      #SSR,R2     ;SET UP EXPECTED (SSR ONLY)
1243 034464 020102                                CMP      R1,R2        ;WAS STATUS GOOD
1244 034466 001406                                BEQ      165$         ;BR. IF TERMINATION WAS GOOD
1245 034470 005237 002214                                INC      FATFLG       ;ERROR COUNT
1249 034474                                ERRHRD  ERRNO,T30WDC,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
                                TRAP    C$ERHRD
                                .WORD   224
                                .WORD   T30WDC
                                .WORD   PKTSSR
                                TRAP    C$CLP1
                                034474 104456
                                034476 000340
                                034500 040362
                                034502 012126
1250 034504 165$: CKLOOP                                ;LOOP IF SELECTED
                                TRAP    C$CLP1
                                034504 104406
1251
1252 ;*****
1253 ;
1254 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
1255 ;
1256 ;*****
1257
1258 034506 004737 011074                                JSR      PC,REWIND   ;CALL TAPE REWIND COMMAND
1259 034512 103411                                BCS     170$         ;BR. IF NO PROBLEM
1260 034514 010004                                MOV      R0,R4       ;GET PACKET ADDRESS
1261 034516 016501 000002                                MOV      TSSR(R5),R1 ;GET STATUS REGISTER
1262 034522 005237 002214                                INC      FATFLG       ;ERROR COUNT
1266 034526                                ERRHRD  ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP    C$ERHRD
                                .WORD   225
                                .WORD   T30RWN
                                .WORD   PKTSSR
                                TRAP    C$CLP1
                                034526 104456
                                034530 000341
                                034532 040240
                                034534 012126
1267 034536 170$: CKLOOP                                ;LOOP IF SELECTED
                                TRAP    C$CLP1
                                034536 104406
1268
1269 ;*****
1270 ;
1271 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
1272 ;
1273 ;*****
1274
1275 034540 013701 036530                                MOV      T30BFR+6,R1 ;PICK UP XSTO
1276 034544 010102                                MOV      R1,R2       ;SET UP EXPECTED
1277 034546 052702 000002                                BIS      #BIT1,R2    ;SET BOT BIT IN EXPECTED
1278 034552 020102                                CMP      R1,R2       ;DOES EXP = REC'D
    
```

B10

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 2: SKIP TAPE MARKS

SEQ 118

```

1279 034554 001406          BEQ      180#          ;BR, IF EQUAL (OK)
1280 034556 005237 002214    INC      FATFLG      ;ERROR COUNT
1284 034562          ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C1ERHRD
                                .WORD    226
                                .WORD    T30BOT
                                .WORD    EXPREC
                                034562 104456
                                034564 000342
                                034566 040041
                                034570 015554
1285 034572          180# : CKLOOP          ;LOOP IF SELECTED
                                TRAP      C1CLP1
                                034572 104406
1286 034574 012737 000002 036654    MOV      #2,T30FCN   ;SET TO NUMBER OF SKIP "FILES"
1287 034602 012703 036636          MOV      #T30IMV,R3  ;SET UP POINTER TO COMMAND TABLE
1288 034606 013737 002174 036520    MOV      UNITN,T30DSW ;SET UP UNIT NUMBER
1289 034614 011337 036516    182# : MOV      (R5),T30ETM ;GET NEXT COMMAND
1290 034620 012704 036500          MOV      #T30PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
1291
1292
1293
1294
1295
1296
1297
                                ;*****
                                ;
                                ;ISSUE WRITE CHARACTERISTICS COMMAND
                                ;
                                ;*****
1298 034624 004737 010742          JSR      PC,WRTCHR   ;ISSUE WRITE CHARACTERISTICS
1299 034630 103407          BCS     188#          ;BR, IF COMMAND ISSUED OK
1300 034632 005237 002214    INC      FATFLG      ;ERROR COUNT
1304 034636 010001          MOV      R0,R1      ;SAVE CONTENTS OF TSSR
1305 034640          ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICSC FAILED
                                TRAP      C1ERHRD
                                .WORD    227
                                .WORD    WRTMSG
                                .WORD    SFIMSG
                                034640 104456
                                034642 000343
                                034644 005052
                                034646 012114
1306 034650          188# : CKLOOP          ;LOOP IF SELECTED
                                TRAP      C1CLP1
                                034650 104406
1307
1308
1309
1310
1311
1312
1313
                                ;*****
                                ;
                                ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
                                ;
                                ;*****
1314 034652 012737 141010 036620    MOV      #141010,T30PK3 ;SKIP TAPE MARK,ACK,CVC=1 COMMAND
1315 034660 013737 036634 036622    MOV      T30FCN,T30RB ;SET UP NUMBER TO SKIP
1316 034666 012704 036620          MOV      #T30PK3,R4  ;SET UP R4 WITH PACKET ADDRESS
1317 034672 010465 000000    189# : MOV      R4,TSDR(R5) ;ISSUE COMMAND
1318 034676 012737 176750 036656    MOV      #65000,,T30DLT ;SET UP DELAY COUNTER
1319 034704 004737 016330    190# : JSR      PC,WAITF   ;WAIT FOR SSR TO SET
1320 034710 016501 000002          MOV      TSSR(R5),R1 ;PICK UP TSSR
1321 034714 032701 000200          BIT      #SSR,R1     ;IS SSR SET YET
1322 034720 001017          BNE     191#          ;BR, IF SSR IS SET
1323 034722          DELAY   250         ;CALL DELAY ROUTINE
                                MOV      #250,(PC)+
                                .WORD    0
                                MOV      L1DLT,(PC)+
                                .WORD    0
                                DEC      -(PC)
                                BNE     ,4
                                DEC      -(PC)
                                BNE     ,20
    
```

C10

TEST 1: HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 2: SKIP TAPE MARKS

SEQ 119

```

1324 034752 005337 036656          DEC      T30DLY          ;BUMP DELAY ROUTINE
1325 034756 001352                   BNE      1901          ;BR, IF MORE DELAY TO GO
1326 034760 012702 000200          1911:  MOV      @SSR,R2    ;SET UP EXPECTED (SSR ONLY)
1327 034764 020102                   CMP      R1,R2        ;WAS STATUS GOOD
1328 034766 001406                   BEQ      1921          ;BR, IF TERMINATION WAS GOOD
1329 034770 005237 002214          INC      FATFLG        ;ERROR COUNT
1333 034774                   ERRHRD  ERRNO,T30SKM,PKTSSR ;TSSR NOT CORRECT AFTER SKIP TAPE M.
                                TRAP      C#ERHRD
                                .WORD    228
                                .WORD    T30SKM
                                .WORD    PKTSSR
      034774 104456
      034776 000344
      035000 037114
      035002 012126
1334 035004          1921:  CKLOOP          ;LOOP IF SELECTED
      035004 104406          TRAP      C#CLP1
1335
1336          ;*****
1337          ;
1338          ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
1339          ;
1340          ;*****
1341
1342 035006 013701 036530          MOV      T30BFR+6,R1   ;PICK UP XSTO
1343 035012 010102                   MOV      R1,R2        ;SET UP EXPECTED
1344 035014 052702 100000          BIS      @BIT15,R2    ;SET TMK BIT IN EXPECTED
1345 035020 020102                   CMP      R1,R2        ;DOES EXP = REC'D
1346 035022 001406                   BEQ      1951          ;BR, IF EQUAL (OK)
1347 035024 005237 002214          INC      FATFLG        ;ERROR COUNT
1351 035030          ERRHRD  ERRNO,T30TMK,EXPREC ;TMK NOT SET AFTER WRT TAPE MARK
                                TRAP      C#ERHRD
                                .WORD    229
                                .WORD    T30TMK
                                .WORD    EXPREC
      035030 104456
      035032 000345
      035034 040514
      035036 015554
1352 035040          1951:  CKLOOP          ;LOOP IF SELECTED
      035040 104406          TRAP      C#CLP1
1353 035042 012700 177777          MOV      @177777,R0    ;VALUE TO WRITTEN TO MEMORY
1354 035046 004737 017501          JSR      PC,FILLMEM    ;FILL MEM WITH ALL ONES
1355 035052 013737 003116 036622  MOV      FREE,T30RB    ;STARTING READ BUFFER ADDRESS
1356
1357          ;*****
1358          ;
1359          ;READ FORWARD,ACK,CVC=1 COMMAND
1360          ;
1361          ;*****
1362
1363 035060 012737 140001 036620  MOV      @140001,T30PK3 ;READ FORWARD,ACK,CVC=1 COMMAND
1364 035066 012704 036620          MOV      @T30PK3,R4   ;SET UP R4 WITH PACKET ADDRESS
1365 035072 012737 000024 036626  MOV      @20.,T30SZ    ;SET UP RECORD SIZE IN PACKET
1366 035100 010465 000000          MOV      R4,T30DB(R5) ;ISSUE COMMAND
1367 035104 004737 016330          JSR      PC,WAITF     ;WAIT FOR SSR TO SET
1368 035110 016501 000002          MOV      TSSR(R5),R1  ;GET TSSR CONTENTS
1369 035114 012702 000200          MOV      @SSR,R2      ;SET UP EXPECTED
1370 035120 020102                   CMP      R1,R2        ;ARE THEY EQUAL
1371 035122 001406                   BEQ      2001          ;BR, IF OK
1372 035124 005237 002214          INC      FATFLG        ;ERROR COUNT
1376 035130          ERRHRD  ERRNO,T30RDF,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP      C#ERHRD
                                .WORD    230
                                .WORD    T30RDF
      035130 104456
      035132 000346
      035134 037413

```


TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
TEST 2: SKIP TAPE MARKS

SEQ 121

1426	035274	010102				MOV	R1,R2		;SET UP EXPECTED	
1427	035276	052702	000002			BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED	
1428	035302	020102				CMP	R1,R2		;DOES EXP = REC'D	
1429	035304	001406				BEQ	240\$;BR, IF EQUAL (OK)	
1430	035306	005237	002214			INC	FATFLG		;ERROR COUNT	
1434	035312					ERRHRD	ERRNO,T30BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND	
	035312	104456							TRAP	C\$ERHRD
	035314	000352							.WORD	234
	035316	040041							.WORD	T30BOT
	035320	015554							.WORD	EXPREC
1435	035322				240\$:	CKLOOP			;LOOP IF SELECTED	
	035322	104406							TRAP	C\$CLP1
1436	035324	005723				TST	(R3)+		;POINT TO NEXT POSITION	
1437	035326	011301				MOV	(R3),R1		;GET NEXT COMMAND ETC.	
1438	035330	020127	177777			CMP	R1,#177777		;END OF TABLE MARKER	
1439	035334	001410				BEQ	330\$;BR, IF AT END OF TABLE	
1440	035336	013701	036654			MOV	T30FCN,R1		;GET NUMBER OF SKIPS	
1441	035342	000241				CLC			;CLEAR THE CARRY BIT	
1442	035344	006101				ROL	R1		;PUSH OVER ONE POSITION	
1443	035346	010137	036654			MOV	R1,T30FCN		;PUT BACK IN COUNTER	
1444	035352	000137	034614			JMP	182\$;JUMP TO MORE COMMANDS TO DO	
1445	035356				330\$:	CKLOOP			;LOOP IF SELECTED	
	035356	104406							TRAP	C\$CLP1
1446	035360					ENDSUB			; <<<<<<<<<<<<< END SUBTEST >>>>>>>>>>	
	035360								L10045:	
	035360	104403							TRAP	C\$ESUB
1447	035362	023727	002214	000017		CMP	FATFLG,#15.		;IS ERROR COUNT AT 25	
1448	035370	103402				BLO	999\$;BR, IF LESS THAN 25	
1449	035372	004737	017262			JSR	PC,CKDROP		;TRY TO DROP THE UNIT	
1450	035376				999\$:					
1451					;					
1452					;					
1453					;TEST 2, SUBTEST 3					
1454					;					
1455					;					
1456					;VERIFIES THAT A SKIP TAPE MARKS REVERSE COMMAND					
1457					;ISSUED WHILE THE TAPE IS POSITIONED AT BOT CAUSES					
1458					;FUNCTION REJECT TERMINATION, WITH THE NON-EXECUTABLE					
1459					;FUNCTION (NEF) ERROR BIT SET.					
1460					;					
1461					;					
1462					;					
1463					;					
1464					;					
1465					;					
1466	035376				;					
	035376				-	BGNSUB			; >>>	
	035376	104402							T2.3:	
	035376								TRAP	C\$BSUB
1467	035400	004737	041252			JSR	PC,T30REST		;SET COMMAND PACKET	
1468	035404	005037	036654			CLR	T30FCN		;CLEAR FILE COUNTER	
1469	035410	004737	041344			JSR	PC,T30RT2		;SET UP OTHER COMMAND PACKET	
1470	035414	004737	041406			JSR	PC,T30RT3		;SET UP OTHER COMMAND PACKET	
1471	035420	012737	176750	036656		MOV	#65000.,T30DLY		;SET UP DELAY COUNTER	
1472	035426	004737	016054		10\$:	JSR	PC,SOFINIT		;DO INITIALIZE ON CONTROLLER	
1473	035432	103426				BCS	20\$;BR IF INIT WAS OK	
1474	035434					DELAY	250		;DELAY ROUTINE CALL	
	035434	012727	000250						MOV	#250,(PC)+

```

035440 000000                                .WORD 0
035442 013727 002116                        MOV L$DLY,(PC)+
035446 000000                                .WORD 0
035450 005367 177772                        DEC -6(PC)
035454 001375                                BNE .-4
035456 005367 177756                        DEC -22(PC)
035462 001367                                BNE .-20
1475 035464 005337 036656                    DEC T30DLY ;BUMP COUNTER
1476 035470 001356                            BNE 10$ ;BR, IF MORE COUNTING TO DO
1477 035472 005237 002214                    INC FATFLG ;ERROR COUNT
1481 035476 010001                            MOV RO,R1 ;CONTENTS OF TSSR REGISTER
1482 035500 ERRDF ERRNO,SFIERR,SFIMSG        ;FATAL ERROR TSSR WAS NOT OK
035500 104455                                TRAP C$ERDF
035502 000353                                .WORD 235
035504 003646                                .WORD SFIERR
035506 012114                                .WORD SFIMSG
1483 035510
1484 035510 013737 002174 036520 20$:      MOV UNITN,T30DSW ;SET UP UNIT NUMBER
1485 035516 012704 036500                    MOV $T30PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
1486
1487 ;*****
1488 ;
1489 ;ISSUE WRITE CHARACTERISTICS COMMAND
1490 ;
1491 ;*****
1492
1493 035522 004737 010742                    JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
1494 035526 103407                            BCS 23$ ;BR, IF COMMAND ISSUED OK
1495 035530 005237 002214                    INC FATFLG ;ERROR COUNT
1499 035534 010001                            MOV RO,R1 ;SAVE CONTENTS OF TSSR
1500 035536 ERRHRD ERRNO,WRTMSG,SFIMSG        ;WRITE CHARACTERISTIC FAILED
035536 104456                                TRAP C$ERHRD
035540 000354                                .WORD 236
035542 005052                                .WORD WRTMSG
035544 012114                                .WORD SFIMSG
1501 035546 23$: CKLOOP ;LOOP IF SELECTED
035546 104406                                TRAP C$CLP1
1502
1503 ;*****
1504 ;
1505 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
1506 ;
1507 ;*****
1508
1509 035550 004737 011074                    JSR PC,REWIND ;CALL TAPE REWIND COMMAND
1510 035554 103411                            BCS 30$ ;BR, IF NO PROBLEM
1511 035556 010004                            MOV RO,R4 ;GET PACKET ADDRESS
1512 035560 016501 000002                    MOV TSSR(R5),R1 ;GET STATUS REGISTER
1513 035564 005237 002214                    INC FATFLG ;ERROR COUNT
1517 035570 ERRHRD ERRNO,T30RWN,PKTSSR        ;REWIND NOT ACCEPTED
035570 104456                                TRAP C$ERHRD
035572 000355                                .WORD 237
035574 040240                                .WORD T30RWN
035576 012126                                .WORD PKTSSR
1518 035600 30$: CKLOOP ;LOOP IF SELECTED
035600 104406                                TRAP C$CLP1
1519
    
```

G10

TEST 1 : HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 2: SKIP TAPE MARKS

SEQ 123

```

1520 ;*****
1521 ;
1522 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
1523 ;
1524 ;*****
1525
1526 035602 013701 036530      MOV      T30BFR+6,R1      ;PICK UP XSTO
1527 035606 010102          MOV      R1,R2           ;SET UP EXPECTED
1528 035610 052702 000002    BIS      #BIT1,R2        ;SET BOT BIT IN EXPECTED
1529 035614 020102          CMP      R1,R2           ;DOES EXP = REC'D
1530 035616 001406          BEQ     40$              ;BR, IF EQUAL (OK)
1531 035620 005237 002214    INC      FATFLG          ;ERROR COUNT
1535 035624          ERRHRD  ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C$ERHRD
                                .WORD    238
                                .WORD    T30BOT
                                .WORD    EXPREC
1536 035634          40$:   CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
1537 035636 012737 000001 036622  MOV      #1,T30WB        ;SET # OF TM TO SKIP
1538
1539 ;*****
1540 ;
1541 ;SKIP TAPE MARK REVERSE,ACK,CVC=1 COMMAND
1542 ;
1543 ;*****
1544
1545 035644 012737 141410 036620  MOV      #141410,T30PK3  ;SKIP TAPE MARK REVERSE,ACK,CVC=1 CMD
1546 035652 012704 036620      MOV      #T30PK3,R4      ;SET UP R4 WITH PACKET ADDRESS
1547 035656 010465 000000      MOV      R4,TSD8(R5)     ;ISSUE COMMAND
1548 035662 004737 016330      JSR     PC,WAITF         ;WAIT FOR SSR TO SET
1549 035666 016501 000002      MOV      TSSR(R5),R1     ;GET TSSR CONTENTS
1550 035672 012702 100206      MOV      #SSR!SC!BIT1!BIT2,R2 ;SET UP EXPECTED
1551 035676 020102          CMP      R1,R2           ;ARE THEY EQUAL
1552 035700 001406          BEQ     70$              ;BR, IF OK
1553 035702 005237 002214    INC      FATFLG          ;ERROR COUNT
1557 035706          ERRHRD  ERRNO,T30IBT,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP      C$ERHRD
                                .WORD    239
                                .WORD    T30IBT
                                .WORD    PKTSSR
1558 035716          70$:   CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
1559
1560 ;*****
1561 ;
1562 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
1563 ;
1564 ;*****
1565
1566 035720 013701 036530      MOV      T30BFR+6,R1     ;PICK UP XSTO
1567 035724 010102          MOV      R1,R2           ;SET UP EXPECTED
1568 035726 052702 002000    BIS      #BIT10,R2       ;SET NEF BIT IN EXPECTED
1569 035732 020102          CMP      R1,R2           ;DOES EXP = REC'D
1570 035734 001406          BEQ     180$             ;BR, IF EQUAL (OK)
1571 035736 005237 002214    INC      FATFLG          ;ERROR COUNT
1575 035742          ERRHRD  ERRNO,T30NEF,EXPREC ;TAPE NOT AT NEF
    
```

```

035742 104456                                TRAP   C$ERHRD
035744 000360                                .WORD  240
035746 040576                                .WORD  T3ONEF
035750 015554                                .WORD  EXPREC
1576 035752 180$:  CKLOOP                     ;LOOP IF SELECTED
035752 104406                                TRAP   C$CLP1
1577 035754                                ENDSUB                     ;<<<<<<<<<<< END SUBTEST >>>>>>>>>
035754                                L10046:
035754 104403                                TRAP   C$ESUB
1578 035756 023727 002214 000017             CMP     FATFLG,#15.        ;IS ERROR COUNT AT 25
1579 035764 103402                               BLO    999$               ;BR, IF LESS THAN 25
1580 035766 004737 017262                               JSR    PC,CKDROP         ;TRY TO DROP THE UNIT
1581 035772 999$:
1582      ;*
1583      ;
1584      ;TEST 2, SUBTEST 4
1585      ;
1586      ;
1587      ;VERIFIES THAT A SKIP TAPE MARKS REVERSE COMMAND
1588      ;ISSUED WHILE THE TAPE IS POSITIONED JUST BEFORE THE
1589      ;FIRST RECORD ON ON TAPE (BUT NOT AT BOT) CAUSES TAPE
1590      ;STATUS ALERT TERMINATION, WITH THE REVERSE INTO BOT
1591      ;(RIB) STATUS BIT SET.
1592      ;
1593      ;
1594      ;
1595      ;
1596      ;
1597      ;-
1598 035772                                BGNSUB                     ;>>>>>>>>>>> BEGIN SUBTEST >>>>>>>>>>>>
035772                                T2.4:
035772 104402                                TRAP   C$BSUB
1599 035774 004737 041252                               JSR    PC,T3OREST        ;SET COMMAND PACKET
1600 036000 005037 036654                               CLR    T3OFCN           ;CLEAR FILE COUNTER
1601 036004 004737 041344                               JSR    PC,T3ORT2        ;SET UP OTHER COMMAND PACKET
1602 036010 004737 041406                               JSR    PC,T3ORT3        ;SET UP OTHER COMMAND PACKET
1603 036014 012737 176750 036656                               MOV    #65000.,T3ODLY   ;SET UP DELAY COUNTER
1604 036022 004737 016054 10$:                               JSR    PC,SOFINIT       ;DO INITIALIZE ON CONTROLLER
1605 036026 103426                               BCS    20$              ;BR IF INIT WAS OK
1606 036030 012727 000250                               DELAY  250              ;DELAY ROUTINE CALL
036030                                MOV    #250,(PC)+
036034 000000                                .WORD  0
036036 013727 002116                               MOV    L$DLY,(PC)+
036042 000000                                .WORD  0
036044 005367 177772                               DEC    -6(PC)
036050 001375                               BNE    -.4
036052 005367 177756                               DEC    -22(PC)
036056 001367                               BNE    .-20
1607 036060 005337 036656                               DEC    T3ODLY           ;BUMP COUNTER
1608 036064 001356                               BNE    10$              ;BR, IF MORE COUNTING TO DO
1609 036066 005237 002214                               INC    FATFLG           ;ERROR COUNT
1613 036072 010001                               MOV    RO,R1            ;CONTENTS OF TSSR REGISTER
1614 036074                                ERRDF  ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
036074 104455                                TRAP   C$ERDF
036076 000361                                .WORD  241
036100 003646                                .WORD  SFIERR
036102 012114                                .WORD  SFIMSG

```

```

1615 036104
1616 036104 013737 002174 036520 20$: MOV UNITN,T30DSW ;SET UP UNIT NUMBER
1617 036112 012704 036500 MOV *T30PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
1618
1619 ;*****
1620 ;
1621 ;ISSUE WRITE CHARACTERISTICS COMMAND
1622 ;
1623 ;*****
1624
1625 036116 004737 010742 JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
1626 036122 103407 BCS 23$ ;BR, IF COMMAND ISSUED OK
1627 036124 005237 002214 INC FATFLG ;ERROR COUNT
1631 036130 010001 MOV RO,R1 ;SAVE CONTENTS OF TSSR
1632 036132 ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
036132 104456 TRAP C$ERHRD
036134 000362 .WORD 242
036136 005052 .WORD WRTMSG
036140 012114 .WORD SFIMSG
1633 036142 23$: CKLOOP ;LOOP IF SELECTED
036142 104406 TRAP C$CLP1
1634
1635 ;*****
1636 ;
1637 ;ISSUE A REWIND TO TAPE DRIVE AND WAIT FOR SSR TO SET
1638 ;
1639 ;*****
1640
1641 036144 004737 011074 JSR PC,REWIND ;CALL TAPE REWIND COMMAND
1642 036150 103411 BCS 30$ ;BR, IF NO PROBLEM
1643 036152 010004 MOV RO,R4 ;GET PACKET ADDRESS
1644 036154 016501 000002 MOV TSSR(R5),R1 ;GET STATUS REGISTER
1645 036160 005237 002214 INC FATFLG ;ERROR COUNT
1649 036164 ERRHRD ERRNO,T30RWN,PKTSSR ;REWIND NOT ACCEPTED
036164 104456 TRAP C$ERHRD
036166 000363 .WORD 243
036170 040240 .WORD T30RWN
036172 012126 .WORD PKTSSR
1650 036174 30$: CKLOOP ;LOOP IF SELECTED
036174 104406 TRAP C$CLP1
1651
1652 ;*****
1653 ;
1654 ;GET EXTENDED STATUS REGISTER ZERO (XSTO) FROM MESSAGE BUFFER
1655 ;
1656 ;*****
1657
1658 036176 013701 036530 MOV T30BFR+6,R1 ;PICK UP XSTO
1659 036202 010102 MOV R1,R2 ;SET UP EXPECTED
1660 036204 052702 000002 BIS *BIT1,R2 ;SET BOT BIT IN EXPECTED
1661 036210 020102 CMP R1,R2 ;DOES EXP = REC'D
1662 036212 001406 BEQ 40$ ;BR, IF EQUAL (OK)
1663 036214 005237 002214 INC FATFLG ;ERROR COUNT
1667 036220 ERRHRD ERRNO,T30BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
036220 104456 TRAP C$ERHRD
036222 000364 .WORD 244
036224 040041 .WORD T30BOT
    
```

```

036226 015554
1668 036230 104406 40$: CKLOOP ;LOOP IF SELECTED .WORD EXPREC
036230 104406 TRAP C$CLP1
1669 036232 013737 003116 036622 MOV FREE,T30WB ;SET UP GOOD WRITE BUFFER
1670 036240 012737 000400 036626 MOV $256.,T30SZ ;SET UP SIZE
1671
1672 ;*****
1673 ;
1674 ;WRITE DATA,ACK,CVC=1 COMMAND
1675 ;
1676 ;*****
1677
1678 036246 012737 140005 036620 MOV $140005,T30PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
1679 036254 012704 036620 MOV $T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
1680 036260 010465 000000 MOV R4,TSDB(R5) ;ISSUE COMMAND
1681 036264 004737 016330 JSR PC,WAITF ;WAIT FOR SSR TO SET
1682 036270 016501 000002 MOV TSSR(R5),R1 ;GET TSSR CONTENTS
1683 036274 012702 000200 MOV $SSR,R2 ;SET UP EXPECTED
1684 036300 020102 CMP R1,R2 ;ARE THEY EQUAL
1685 036302 001406 BEQ 70$ ;BR, IF OK
1686 036304 005237 002214 INC FATFLG ;ERROR COUNT
1690 036310 ERRHRD ERRNO,T30WDD,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
036310 104456 TRAP C$ERHRD
036312 000365 .WORD 245
036314 037170 .WORD T30WDD
036316 012126 .WORD PKTSSR
1691 036320 70$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
036320 104406
1692
1693 ;*****
1694 ;
1695 ;SKIP TAPE MARK REVERSE,ACK,CVC=1 COMMAND
1696 ;
1697 ;*****
1698
1699 036322 012737 000001 036622 MOV $1,T30WB ;# OF TM TO SKIP
1700 036330 012737 141410 036620 MOV $141410,T30PK3 ;SKIP TAPE MARK REVERSE,ACK,CVC=1 CMD
1701 036336 012704 036620 MOV $T30PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
1702 036342 010465 000000 MOV R4,TSDB(R5) ;ISSUE COMMAND
1703 036346 004737 016330 JSR PC,WAITF ;WAIT FOR SSR TO SET
1704 036352 016501 000002 MOV TSSR(R5),R1 ;PICK UP TSSR
1705 036356 012702 100204 MOV $SSR!BIT2!SC,R2 ;SET UP EXPECTED (SSR AND SC ONLY)
1706 036362 020102 CMP R1,R2 ;WAS STATUS GOOD
1707 036364 001406 BEQ 160$ ;BR, IF TERMINATION WAS GOOD
1708 036366 005237 002214 INC FATFLG ;ERROR COUNT
1712 036372 ERRHRD ERRNO,T30IBU,PKTSSR ;TSSR NOT CORRECT AFTER WRT TAPE M.
036372 104456 TRAP C$ERHRD
036374 000366 .WORD 246
036376 036660 .WORD T30IBU
036400 012126 .WORD PKTSSR
1713 036402 160$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
036402 104406
1714
1715 ;*****
1716 ;
1717 ;GET EXTENDED STATUS REGISTER ZERO (XST3) FROM MESSAGE BUFFER
1718 ;

```


1777 036620				T30PK3:			
1778 036620	100205			.WORD	100205		; REREAD COMMAND, IE AND ACK
1779 036622				T30RB:			
1780 036622	003116			T30WB:	.WORD	FREE	; ADDRESS OF WRITE BUFFER
1781 036624	000000				.WORD	0	
1782 036626	000000			T30SZ:	.WORD	0	; SIZE OF BUFFER (EXTENT)
1783					.EVEN		
1784				:			
1785				:			
1786				:			
1787 036630				T30BF2:			
1788 036630	010			T30BS0:	.BYTE	10	; BSELO AREA
1789 036631	200			T30BS1:	.BYTE	200	; BSEL1 AREA
1790 036632	000000			T30S2:	.WORD	0	; SEL 2 AREA
1791 036634	000000			T30S3:	.WORD	0	; DATA AREA
1792				:			
1793				:			
1794					.EVEN		
1795							; TAPE MOTION PACKET COMMAND VALUES
1796							
1797 036636				T30IMV:			
1798 036636				T30RN:			
1799 036636	000000			.WORD	000000		; NEITHER EWB NOR ESS
1800 036640	000100			.WORD	000100		; EWB SET
1801 036642	000200			.WORD	000200		; ESS SET
1802 036644	000300			.WORD	000300		; BOTH EWB AND ESS SET
1803 036646	177777			.WORD	177777		; END OF DATA
1804							
1805				:			
1806 036650	000000			T30CNT:	.WORD	0	; TAPE TIMER COUNTER STORAGE AREA
1807 036652	000000			T30CNU:	.WORD	0	; TAPE TIMER COUNTER STORAGE AREA
1808 036654	000000			T30FCN:	.WORD	0	; FILE NUMBER COUNTER
1809 036656	000000			T30DLY:	.WORD	0	; DELAY COUNTER STORAGE
1810				!+			
1811							; LOCAL TEXT MESSAGES FOR TEST
1812				!-			
1813							
1814 036660	124	123	123	T30IBU:	.ASCIZ	'TSSR Incorrect After SKIP TAPE MARK REVERSE Into BOT'	
1815 036745	122	111	102	T30RIB:	.ASCIZ	'RIB Bit (XST3) Failed To Set After Reverse Into BOT'	
1816 037031	124	123	123	T30IBT:	.ASCIZ	'TSSR Incorrect After SKIP TAPE MARK REVERSE At BOT'	
1817 037114	124	123	123	T30SKM:	.ASCIZ	'TSSR Incorrect After SKIP TAPE MARK Command'	
1818 037170	124	123	123	T30WDD:	.ASCIZ	'TSSR Not Correct After WRITE DATA Command'	
1819 037242	124	141	160	.3OPTB:	.ASCIZ	'Tape Not Positioned On Correct Record After READ REVERSE'	
1820 037333	124	141	160	T30TPB:	.ASCIZ	'Tape Not Positioned On Second File First Record'	
1821 037413	124	123	123	T30RDF:	.ASCIZ	'TSSR Incorrect After READ FORWARD Into "File"'	
1822 037471	124	123	123	T30RDG:	.ASCIZ	'TSSR Incorrect After SPACE Command Into TAPE MARK'	
1823 037553	124	123	123	T30WDF:	.ASCIZ	'TSSR Not Correct After Illegal Mode Bits Set'	
1824 037630	111	154	154	T30LOQ:	.ASCIZ	'Illegal Mode Bits, Failed To Set ILC Bit In XST0'	
1825 037711	127	122	111	T30SSR:	.ASCIZ	'WRITE MISCELLANEOUS Command Not Accepted'	
1826 037762	124	123	123	T30WDE:	.ASCIZ	'TSSR Not Correct After SKIP TAPE MARKS, At BOT'	
1827 040041	124	141	160	T30BOT:	.ASCIZ	'Tape Not At BOT After REWIND Command'	
1828 040106	124	123	123	T30TM:	.ASCIZ	'TSSR Not Correct After SPACE FORWARD Command'	
1829 040163	124	123	123	T30TM2:	.ASCIZ	'TSSR Not Correct After SPACE REVERSE Command'	
1830 040240	122	145	167	T30RWN:	.ASCIZ	'Rewind (POSITION) Command Not Accepted'	
1831 040307	104	162	151	T30OFL:	.ASCIZ	'Drive 7 Select Failed To Set "OFL" In TSSR'	
1832 040362	124	123	123	T30WDC:	.ASCIZ	'TSSR Not Correct After WRITE TAPE MARK Command'	
1833 040441	103	126	103	T30VCK:	.ASCIZ	'CVC Set, Didn't Reset VCK In Message Buffer'	


```

1834 040514      124      115      113  T30TMK: .ASCIZ 'TMK Not Set After WRITE TAPE MARK (RETRY) Command'
1835 040576      123      113      111  T3ONEF: .ASCIZ 'SKIP TAPE MARKS, At BCT, Failed To Set NEF Bit'
1836 040655      124      115      113  T3ORRM: .ASCIZ 'TMK Not Set After READ REVERSE Into TAPE MARK'
1837 040733      124      115      113  T3ORRN: .ASCIZ 'TMK Not Set After SPACE REVERSE Into TAPE MARK'
1838 041012      124      115      113  T3ORRP: .ASCIZ 'TMK Not Set After READ FORWARD Into TAPE MARK'
1839 041070      116      117      040  T3ODTR: .ASCIZ 'NO Data Transferred On READ FORWARD'
1840 041134      104      141      164  T3ODTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
1841 041231      123      153      151  TST30ID: .ASCIZ 'Skip Tape Marks'
1842                                     .EVEN
1843                                     ;+
1844                                     ;
1845                                     ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
1846                                     ;WRITE SUBSYSTEM MEMORY COMMAND
1847                                     ;
1848                                     ;-
1849
1850 041252      T3OREST:
1851 041252      SAVREG                                     ;SAVE THE REGISTERS
1852 041256      012701 036500      MOV          #T3OPACKET,R1                       ;START OF THE PACKET
1853 041262      012721 100004      MOV          #100004,(R1)+                         ;WRITE SUBSYSTEM MEM. WITH ACK,
1854 041266      012721 036510      MOV          #T3ODATA,(R1)+                       ;ADDRESS OF CHARAISTICS DATA BLOCK
1855 041272      005021      CLR          (R1)+                                 ;EXTENDED ADDRESS
1856 041274      012721 000012      MOV          #10.,(R1)+                            ;SIZE OF DATA BLOCK IN BYTES
1857 041300      012721 036522      MOV          #T3OBFR,(R1)+                         ;ADDRESS OF MESSAGE BUFFER
1858 041304      005021      CLR          (R1)+
1859 041306      012721 000024      MOV          #20.,(R1)+                            ;LENGTH OF MESSAGE BUFFER
1860 041312      005021      CLR          (R1)+
1861 041314      012711 000000      MOV          #0,(R1)                               ;SELECT DRIVE ZERO
1862 041320      012702 000030      MOV          #24.,R2                               ;NUMBER OF LOCATIONS TO BE CLEARED
1863 041324      012762 177777 036522 64$: MOV          #177777,T3OBFR(R2)                   ;ALL ONES TO MESSAGE BUFFER
1864 041332      005742      TST          -(R2)                                ;NEXT LOCATION
1865 041334      022702 000000      CMP          #0.,R2                               ;CHECK R2 FOR DONE
1866 041340      001371      BNE          64$                                  ;KEEP GOING UNTIL DONE
1867 041342      000207      RTS          PC                                  ;RETURN
1868
1869 041344      T3ORT2:
1870 041344      SAVREG                                     ;SAVE THE REGISTERS
1871 041350      012701 036610      MOV          #T3OPK2,R1                           ;START OF THE PACKET
1872 041354      012721 100006      MOV          #100006,(R1)+                         ;WRITE SUBSYSTEM MEM. WITH ACK,
1873 041360      012721 036630      MOV          #T3OBF2,(R1)+                       ;ADDRESS OF DATA BLOCK
1874 041364      005021      CLR          (R1)+                                 ;EXTENDED ADDRESS
1875 041366      012721 000006      MOV          #6.,(R1)+                             ;SIZE OF DATA BLOCK IN BYTES
1876 041372      005021      CLR          (R1)+
1877 041374      012701 036630      MOV          #T3OBF2,R1                           ;POINT TO DATA SEL AREA
1878 041400      005021      CLR          (R1)+
1879 041402      005011      CLR          (R1)
1880 041404      000207      RTS          PC                                  ;RETURN
1881 041406      T3ORT3:
1882 041406      SAVREG                                     ;SAVE REGISTERS
1883 041412      012701 036620      MOV          #T3OPK3,R1                           ;SET UP POINTER ADDRESS
1884 041416      005021      CLR          (R1)+                                 ;COMMAND SPACE
1885 041420      005021      CLR          (R1)+                                 ;ADDRESS OF DATA BLOCK
1886 041422      005021      CLR          (R1)+                                 ;EXTENDED ADDRESS
1887 041424      005011      CLR          (R1)                                ;SIZE OF DATA TRANSFER BLOCK
1888 041426      000207      RTS          PC                                  ;RETURN
1889 041430      ENDTST
1890 041430

```

L10043:

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

SEQ 131

041522	013727	002116				MOV	T31DLY,(PC)+		
041526	000000					.WORD	0		
041530	005367	177772				DEC	-6(PC)		
041534	001375					BNE	,-4		
041536	005367	177756				DEC	-22(PC)		
041542	001367					BNE	,-20		
1945	041544	005337	043342		DEC	T31DLY			;BUMP COUNTER
1946	041550	001356			BNE	101			;BR, IF COUNTER NOT DONE
1947	041552	005237	002214		INC	FATFLG			;ERROR COUNT
1951	041556	010001			MOV	R0,R1			;CONTENTS OF TSSR REGISTER
1952	041560				ERRDF	ERRNO,SFIERR,SFIMSG			;FATAL ERROR TSSR WAS NOT OK
	041560	104455					TRAP	C#ERDF	
	041562	000455					.WORD	301	
	041564	003646					.WORD	SFIERR	
	041566	012114					.WORD	SFIMSG	
1953	041570	013737	002174	043210	20#:	MOV	UNITN,T31DSW		;SET UP UNIT NUMBER IN PACKET
1954	041576	012704	043170			MOV	#T31PACKET,R4		;SUBROUTINE NEEDS PACKET ADDRESS
1955	041602	004737	010742			JSR	PC,WRTCHR		;ISSUE WRITE CHARACTERISTICS
1956	041606	103407				BCS	231		;BR, IF COMMAND ISSUED OK
1957	041610	005237	002214			INC	FATFLG		;ERROR COUNT
1961	041614	010001				MOV	R0,R1		;SAVE CONTENTS OF TSSR
1962	041616					ERRHRD	ERRNO,WRTMSG,SFIMSG		;WRITE CHARACTERISTIC FAILED
	041616	104456					TRAP	C#ERHRD	
	041620	000456					.WORD	302	
	041622	005052					.WORD	WRTMSG	
	041624	012114					.WORD	SFIMSG	
1963	041626				23#:	CKLOOP			;LOOP IF SELECTED
	041626	104406					TRAP	C#CLP1	
1964	041630	004737	011074			JSR	PC,REWIND		;CALL TAPE REWIND COMMAND
1965	041634	103407				BCS	301		;BR, IF NO PROBLEM
1966	041636	010004				MOV	R0,R4		;SET UP REWIND PACKET ADDRESS
1967	041640	005237	002214			INC	FATFLG		;ERROR COUNT
1971	041644					ERRHRD	ERRNO,T31RWN,PKTSSR		;REWIND NOT ACCEPTED
	041644	104456					TRAP	C#ERHRD	
	041646	000457					.WORD	303	
	041650	044674					.WORD	T31RWN	
	041652	012126					.WORD	PKTSSR	
1972	041654				30#:	CKLOOP			;LOOP IF SELECTED
	041654	104406					TRAP	C#CLP1	
1973	041656	013701	043220			MOV	T31BFR+6,R1		;PICK UP XSTO
1974	041662	010102				MOV	R1,R2		;SET UP EXPECTED
1975	041664	052702	000002			BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED
1976	041670	020102				CMP	R1,R2		;DOES EXP = REC'D
1977	041672	001406				BEQ	401		;BR, IF EQUAL (OK)
1978	041674	005237	002214			INC	FATFLG		;ERROR COUNT
1982	041700					ERRHRD	ERRNO,T31BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND
	041700	104456					TRAP	C#ERHRD	
	041702	000460					.WORD	304	
	041704	044345					.WORD	T31BOT	
	041706	015554					.WORD	EXPREC	
1983	041710				40#:	CKLOOP			;LOOP IF SELECTED
	041710	104406					TRAP	C#CLP1	
1984	041712	013737	003116	043312		MOV	FREE,T31WB		;STARTING WRITE BUFFER ADDRESS
1985	041720	012737	140005	043310	65#:	MOV	#140005,T31PK3		;WRITE DATA,CVC=1,ACK COMMAND
1986	041726	012704	043310			MOV	#T31PK3,R4		;SET UP R4 WITH PACKET ADDRESS
1987	041732	012700	000144			MOV	#100.,R0		;SET PATTERN IN CORRECT REGISTER
1988	041736	004737	017502			JSR	PC,FILLMEM		;FILL MEMORY WITH RECORD SIZE

1989	041742	012737	000144	043316	MOV	#100,,T31SZ	;SET UP RECORD SIZE IN PACKET		
1990	041750	010465	000000		MOV	R4,T50B(R5)	;ISSUE COMMAND		
1991	041754	004737	016330		JSR	PC,WAITF	;WAIT FOR SSR TO SET		
1992	041760	016501	000002		MOV	TSSR(R5),R1	;GET TSSR CONTENTS		
1993	041764	012702	000200		MOV	#SSR,R2	;SET UP EXPECTED		
1994	041770	020102			CMP	R1,R2	;ARE THEY EQUAL		
1995	041772	001406			BEQ	80#	;BR, IF OK		
1996	041774	005237	002214		INC	FATFLG	;ERROR COUNT		
2000	042000				ERRHRD	ERRNO,T31WDC,PKTSSR	;TSSR INCORRECT AFTER WRITE DATA		
	042000	104456						TRAP	C#ERHRD
	042002	000461						.WORD	305
	042004	045230						.WORD	T31WDC
	042006	012126						.WORD	PKTSSR
2001	042010			80#:	CKLOOP		;LOOP IF SELECTED		
	042010	104406						TRAP	C#CLP1
2002	042012	004737	011074		JSR	PC,REWIND	;CALL TAPE REWIND COMMAND		
2003	042016	103407			BCS	230#	;BR, IF NO PROBLEM		
2004	042020	010001			MOV	R0,R1	;SAVE TSSR		
2005	042022	005237	002214		INC	FATFLG	;ERROR COUNT		
2009	042026				ERRHRD	ERRNO,T31RWN,EXPREC	;REWIND NOT ACCEPTED		
	042026	104456						TRAP	C#ERHRD
	042030	000462						.WORD	306
	042032	044674						.WORD	T31RWN
	042034	015554						.WORD	EXPREC
2010	042036			230#:	CKLOOP		;LOOP IF SELECTED		
	042036	104406						TRAP	C#CLP1
2011	042040	013701	043220		MOV	T31BFR+6,R1	;PICK UP XSTO		
2012	042044	010102			MOV	R1,R2	;SET UP EXPECTED		
2013	042046	052702	000002		BIS	#BIT1,R2	;SET BOT BIT IN EXPECTED		
2014	042052	020102			CMP	R1,R2	;DOES EXP = REC'D		
2015	042054	001406			BEQ	240#	;BR, IF EQUAL (OK)		
2016	042056	005237	002214		INC	FATFLG	;ERROR COUNT		
2020	042062				ERRHRD	ERRNO,T31BOT,EXPREC	;TAPE NOT AT BOT AFTER REWIND		
	042062	104456						TRAP	C#ERHRD
	042064	000463						.WORD	307
	042066	044345						.WORD	T31BOT
	042070	015554						.WORD	EXPREC
2021	042072			240#:	CKLOOP		;LOOP IF SELECTED		
	042072	104406						TRAP	C#CLP1
2022	042074	012737	041012	043310	265#:	MOV	#041012,T31PK3	;NO-OP,CVC=1 COMMAND	
2023	042102	012704	043310		MOV	#T31PK3,R4	;SET UP R4 WITH PACKET ADDRESS		
2024	042106	010337	043316		MOV	R3,T31SZ	;SET UP RECORD SIZE IN PACKET		
2025	042112	010465	000000		MOV	R4,T50B(R5)	;ISSUE COMMAND		
2026	042116	004737	016330		JSR	PC,WAITF	;WAIT FOR SSR TO SET		
2027	042122	016501	000002		MOV	TSSR(R5),R1	;GET TSSR CONTENTS		
2028	042126	012702	000200		MOV	#SSR,R2	;SET UP EXPECTED		
2029	042132	020102			CMP	R1,R2	;ARE THEY EQUAL		
2030	042134	001406			BEQ	280#	;BR, IF OK		
2031	042136	005237	002214		INC	FATFLG	;ERROR COUNT		
2035	042142				ERRHRD	ERRNO,T31RDF,PKTSSR	;TSSR INCORRECT AFTER READ DATA		
	042142	104456						TRAP	C#ERHRD
	042144	000464						.WORD	308
	042146	043543						.WORD	T31RDF
	042150	012126						.WORD	PKTSSR
2036	042152			280#:	CKLOOP		;LOOP IF SELECTED		
	042152	104406						TRAP	C#CLP1
2037	042154	013701	043220		MOV	T31BFR+6,R1	;PICK UP XSTO		


```

2088      ;
2089      ;
2090      ;
2091 042340      ;
      042340      ;
      042340 104402      ;
2092 042342 004737 046610      JSR      PC,T31REST      ;SET COMMAND PACKET      TRAP      C$BSUB
2093 042346 004737 046702      JSR      PC,T31RT2      ;SET UP OTHER COMMAND PACKET
2094 042352 004737 046744      JSR      PC,T31RT3      ;SET UP OTHER COMMAND PACKET
2095 042356 004737 016054      JSR      PC,SOFINIT      ;DO INITIALIZE ON CONTROLLER
2096 042362 103407      BCS      20$      ;BR IF INIT WAS OK
2097 042364 005237 002214      INC      FATFLG      ;ERROR COUNT
2101 042370 010001      MOV      R0,R1      ;CONTENTS OF TSSR REGISTER
2102 042372      ERRDF      ERRNO,SFIERR,SFIMSG      ;FATAL ERROR TSSR WAS NOT OK
      042372 104455      TRAP      C$ERDF
      042374 000470      .WORD      312
      042376 003646      .WORD      SFIERR
      042400 012114      .WORD      SFIMSG
2103 042402 013737 002174 043210 20$:      MOV      UNITN,T31DSW      ;SET UP UNIT NUMBER IN PACKET
2104 042410 012704 043170      MOV      @T31PACKET,R4      ;SUBROUTINE NEEDS PACKET ADDRESS
2105 042414 004737 010742      JSR      PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
2106 042420 103407      BCS      23$      ;BR, IF COMMAND ISSUED OK
2107 042422 005237 002214      INC      FATFLG      ;ERROR COUNT
2111 042426 010001      MOV      R0,R1      ;SAVE CONTENTS OF TSSR
2112 042430      ERRHRD      ERRNO,WRTMSG,SFIMSG      ;WRITE CHARACTERISTICS FAILED
      042430 104456      TRAP      C$ERHRD
      042432 000471      .WORD      313
      042434 005052      .WORD      WRTMSG
      042436 012114      .WORD      SFIMSG
2113 042440      23$:      CKLOOP      ;LOOP IF SELECTED
      042440 104406      TRAP      C$CLP1
2114 042442 004737 011074      JSR      PC,REWIND      ;CALL TAPE REWIND COMMAND
2115 042446 103407      BCS      30$      ;BR, IF NO PROBLEM
2116 042450 010004      MOV      R0,R4      ;SET UP REWIND PACKET ADDRESS
2117 042452 005237 002214      INC      FATFLG      ;ERROR COUNT
2121 042456      ERRHRD      ERRNO,T31RWN,PKTSSR      ;REWIND NOT ACCEPTED
      042456 104456      TRAP      C$ERHRD
      042460 000472      .WORD      314
      042462 044674      .WORD      T31RWN
      042464 012126      .WORD      PKTSSR
2122 042466      30$:      CKLOOP      ;LOOP IF SELECTED
      042466 104406      TRAP      C$CLP1
2123 042470 013701 043220      MOV      T31BFR+6,R1      ;PICK UP XSTO
2124 042474 010102      MOV      R1,R2      ;SET UP EXPECTED
2125 042476 052702 000002      BIS      @BIT1,R2      ;SET BOT BIT IN EXPECTED
2126 042502 020102      CMP      R1,R2      ;DOES EXP = REC'D
2127 042504 001406      BEQ      40$      ;BR, IF EQUAL (OK)
2128 042506 005237 002214      INC      FATFLG      ;ERROR COUNT
2132 042512      ERRHRD      ERRNO,T31BOT,EXPREC      ;TAPE NOT AT BOT AFTER REWIND
      042512 104456      TRAP      C$ERHRD
      042514 000473      .WORD      315
      042516 044345      .WORD      T31BOT
      042520 015554      .WORD      EXPREC
2133 042522      40$:      CKLOOP      ;LOOP IF SELECTED
      042522 104406      TRAP      C$CLP1
2134 042524 013737 003116 043312      MOV      FREE,T31WB      ;STARTING WRITE BUFFER ADDRESS
2135 042532 012737 140005 043310 65$:      MOV      @140005,T31PKZ      ;WRITE DATA,CVC=1,ACK COMMAND

```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

SEQ 135

2136	042540	012704	043310		MOV	#T31PK3,R4		;SET UP R4 WITH PACKET ADDRESS
2137	042544	012700	000144		MOV	#100.,R0		;SET PATTERN IN CORRECT REGISTER
2138	042550	004737	017502		JSR	PC,FILLMEM		;FILL MEMORY WITH RECORD SIZE
2139	042554	012737	000144	043316	MOV	#100.,T31SZ		;SET UP RECORD SIZE IN PACKET
2140	042562	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND
2141	042566	004737	016330		JSR	PC,WAITF		;WAIT FOR SSR TO SET
2142	042572	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
2143	042576	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED
2144	042602	020102			CMP	R1,R2		;ARE THEY EQUAL
2145	042604	001406			BEQ	80\$;BR, IF OK
2146	042606	005237	002214		INC	FATFLG		;ERROR COUNT
2150	042612				ERRHRD	ERRNO,T31WDC,PKTSSR		;TSSR INCORRECT AFTER WRITE DATA
	042612	104456					TRAP	C\$ERHRD
	042614	000474					.WORD	316
	042616	045230					.WORD	T31WDC
	042620	012126					.WORD	PKTSSR
2151	042622			80\$:	CKLOOP			;LOOP IF SELECTED
	042622	104406					TRAP	C\$CLP1
2152	042624	004737	011074		JSR	PC,REWIND		;CALL TAPE REWIND COMMAND
2153	042630	103407			BCS	230\$;BR, IF NO PROBLEM
2154	042632	010001			MOV	R0,R1		;SAVE TSSR
2155	042634	005237	002214		INC	FATFLG		;ERROR COUNT
2159	042640				ERRHRD	ERRNO,T31RWN,EXPREC		;REWIND NOT ACCEPTED
	042640	104456					TRAP	C\$ERHRD
	042642	000475					.WORD	317
	042644	044674					.WORD	T31RWN
	042646	015554					.WORD	EXPREC
2160	042650			230\$:	CKLOOP			;LOOP IF SELECTED
	042650	104406					TRAP	C\$CLP1
2161	042652	013701	043220		MOV	T31BFR+6,R1		;PICK UP XST0
2162	042656	010102			MOV	R1,R2		;SET UP EXPECTED
2163	042660	052702	000002		BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED
2164	042664	020102			CMP	R1,R2		;DOES EXP = REC'D
2165	042666	001406			BEQ	240\$;BR, IF EQUAL (OK)
2166	042670	005237	002214		INC	FATFLG		;ERROR COUNT
2170	042674				ERRHRD	ERRNO,T31BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND
	042674	104456					TRAP	C\$ERHRD
	042676	000476					.WORD	318
	042700	044345					.WORD	T31BOT
	042702	015554					.WORD	EXPREC
2171	042704			240\$:	CKLOOP			;LOOP IF SELECTED
	042704	104406					TRAP	C\$CLP1
2172	042706	012737	041012	043310	265\$:	MOV	#041012,T31PK3	;INITIALIZE,CVC=1 COMMAND
2173	042714	012701	043310		MOV	#T31PK3,R4		;SET UP R4 WITH PACKET ADDRESS
2174	042720	010337	043316		MOV	R3,T31SZ		;SET UP RECORD SIZE IN PACKET
2175	042724	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND
2176	042730	004737	016330		JSR	PC,WAITF		;WAIT FOR SSR TO SET
2177	042734	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
2178	042740	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED
2179	042744	020102			CMP	R1,R2		;ARE THEY EQUAL
2180	042746	001406			BEQ	280\$;BR, IF OK
2181	042750	005237	002214		INC	FATFLG		;ERROR COUNT
2185	042754				ERRHRD	ERRNO,T31RDF,PKTSSR		;TSSR INCORRECT AFTER READ DATA
	042754	104456					TRAP	C\$ERHRD
	042756	000477					.WORD	319
	042760	043543					.WORD	T31RDF
	042762	012126					.WORD	PKTSSR

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

SEQ 137

TRAP C\$EXIT
 .WORD L10050-

```

043164 104432
043166 003600
2235
2236
2237
2241 043170
2242 043170 100004
2243 043172 043200
2244 043174 000000
2245 043176 000012
2246 043200
2247 043200 043212
2248 043202 000000
2249 043204 000024
2250 043206 000000
2251 043210 000000
2252 043212
2253
2254
2255
2257      043300
2259 043300
2260 043300 100006
2261 043302 043320
2262 043304 000000
2263 043306 000006
2264
2268 043310
2269 043310 100005
2270 043312
2271 043312 003116
2272 043314 000000
2273 043316 000000
2274
2275
2276
2277
2278 043320
2279 043320      010
2280 043321      200
2281 043322 000000
2282 043324 000000
2283
2284
2285
2286
2287
2288 043326 100205
2289 043330 100605
2290 043332 102205
2291 043334 177777
2292
2293
2294 043336 000000
2295 043340 000000
2296 043342 000000
2297

;+
;LOCAL STORAGE FOR THIS TEST
;-
T31PACKET:
      .WORD 100004
      .WORD T31DATA
      .WORD 0
      .WORD 10.
T31DATA:
      .WORD T31BFR
      .WORD 0
      .WORD 20.
      .WORD 0
T31DSW: .WORD 0
T31BFR: .BLKW 25.
;
;WRITE SUBSYSTEM MEMORY COMMAND PACKET
;
      .=<.*10>&177770
T31PK2:
      .WORD 100006
      .WORD T31BF2
      .WORD 0
      .WORD 6.
T31PK3:
      .WORD 100005
T31RB:
T31WB: .WORD FREE
      .WORD 0
T31SZ: .WORD 0
      .EVEN
;
;
;
T31BF2:
T31BS0: .BYTE 10
T31BS1: .BYTE 200
T31S2: .WORD 0
T31S3: .WORD 0
;
;
      .EVEN
;TAPE MOTION PACKET COMMAND VALUES
T31RN: .WORD 100205
T31WDR: .WORD 100605
T31CON: .WORD 102205
      .WORD 177777
;
;
T31CNT: .WORD 0
T31CNU: .WORD 0
T31DLY: .WORD 0
;+
;COMMAND PACKET FOR TEST
;WRITE CHARACTERISTICS COMMAND, WITH , ACK
;ADDRESS OF CHARACTERISTICS BLOCK
;STARTING VALUE OF BLOCK SIZE
;CHARACTERISTICS DATA BLOCK
;ADDRESS OF MESSAGE BUFFER
;LENGTH OF MESSAGE BUFFER
;SELECT DRIVE 0
;MESSAGE BUFFER
;WRITE SUB SYS MEM COMMAND, AND ACK
;ADDRESS OF SELECT BLOCK DATA
;SIZE OF DATA PACKET
;REREAD COMMAND, AND ACK
;ADDRESS OF WRITE BUFFER
;SIZE OF BUFFER (EXTENT)
;BSELO AREA
;BSEL1 AREA
;SEL 2 AREA
;DATA AREA
;REREAD DATA (NEXT)
;REREAD DATA RETRY
;WRITE CONTINUOUS
;END OF DATA
;TAPE TIMER COUNTER STORAGE AREA
;TAPE TIMER COUNTER STORAGE AREA
;DELAY COUNTER

```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

SEQ 138

```

2298 ;LOCAL TEXT MESSAGES FOR TEST
2299 ;-
2300
2301 043344 124 123 123 T31RDE: .ASCIZ 'TSSR Not Correct After PEAD Command'
2302 043410 124 141 160 T31WNH: .ASCIZ 'Tape Position Incorrect After INITIALIZE Command'
2303 043471 124 141 160 T31WNG: .ASCIZ 'Tape Position Incorrect After NOP Command'
2304 043543 124 123 123 T31RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
2305 043612 122 105 122 T31RRF: .ASCIZ 'REREAD Previous (Space Reverse, Read Forward) Command Failed'
2306 043707 120 117 123 T31SC: .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
2307 043771 122 111 102 T31LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'
2308 044041 124 123 123 T31WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
2309 044116 111 154 154 T31LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XSTO'
2310 044177 122 105 122 T31SSR: .ASCIZ 'REREAD COMMAND Not Accepted'
2311 044233 124 123 123 T31WDE: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE Command, At BOT'
2312 044345 124 141 160 T31BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XSTO)'
2313 044440 116 117 055 T31TIM: .ASCIZ 'NO-OP ("CLEAN TAPE") AND INITIALIZE'S Erase Tape Not Long Enough'
2314 044540 122 105 122 T31EOT: .ASCIZ 'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
2315 044617 124 123 123 T31TM: .ASCIZ 'TSSR Not Correct After REREAD COMMAND Reject'
2316 044674 122 145 167 T31RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
2317 044743 122 101 115 T31RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
2318 045016 124 123 123 T31AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
2319 045065 104 162 151 T31OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
2320 045140 124 123 123 T31WDD: .ASCIZ 'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
2321 045230 124 123 123 T31WDC: .ASCIZ 'TSSR Not Correct After REREAD DATA Command'
2322 045303 103 126 103 T31VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
2323 045356 124 123 102 T31BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
2324 045431 127 122 111 T31WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
2325 045520 122 145 141 T31LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XSTO'
2326 045602 122 145 141 T31LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XSTO'
2327 045664 122 145 163 T31PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
2328 045752 122 145 141 T31TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
2329 046040 116 117 055 T31NEF: .ASCIZ 'NO-OP ("CLEAN TAPE") AND INITIALIZE, At First Record, Failed To Set RIB Bit
X
2330 046161 124 123 123 T31SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
2331 046236 124 123 123 T31TSA: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE, Into BOT'
2332 046343 124 123 123 T31WRF: .ASCIZ 'TSSR Not Correct After NO-OP ("CLEAN TAPE") AND INITIALIZE Command'
2333 046446 104 141 164 T31DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
2334 046543 116 117 055 T31ID: .ASCIZ 'NO-OP ("Clean Tape") And INITIALIZE'
2335 ;
2336 ;*
2337 ;
2338 ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
2339 ;WRITE SUBSYSTEM MEMORY COMMAND
2340 ;
2341 ;-
2342
2343 T31REST:
2344 046610 SAVREG ;SAVE THE REGISTERS
2345 046614 MOV #T31PACKET,R1 ;START OF THE PACKET
2346 046620 MOV #100004,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK,
2347 046624 MOV #T31DATA,(R1)+ ;ADDRESS OF CHARAISTICS DATA BLOCK
2348 046630 CLR (R1)+ ;EXTENDED ADDRESS
2349 046632 MOV #10.,(R1)+ ;SIZE OF DATA BLOCK IN BYTES
2350 046636 MOV #T31BFR,(R1)+ ;ADDRESS OF MESSAGE BUFFER
2351 046642 CLR (R1)+
2352 046644 MOV #20.,(R1)+ ;LENGTH OF MESSAGE BUFFER
2353 046650 CLR (R1)+
2354 046652 MOV #0,(R1) ;SELECT DRIVE ZERO

```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 3: NO-OP ("CLEAN TAPE") AND INITIALIZE

SEQ 139

```

2355 046656 012702 000030      MOV     #24.,R2          ;NUMBER OF LOCATIONS TO BE CLEARED
2356 046662 012762 177777 043212 64$: MOV     #177777,T31BFR(R2) ;ALL ONES TO MESSAGE BUFFER
2357 046670 005742              TST     -(R2)           ;NEXT LOCATION
2358 046672 022702 000000      CMP     #0,R2           ;AT END OF LOOP YET
2359 046676 001371              BNE     64$             ;KEEP GOING UNTIL DONE
2360 046700 000207              RTS     PC              ;RETURN
2361
2362 046702                    T31RT2:
2363 046702                    SAVREG                ;SAVE THE REGISTERS
2364 046706 012701 043300      MOV     #T31PK2,R1     ;START OF THE PACKET
2365 046712 012721 100006      MOV     #100006,(R1)+  ;WRITE SUBSYSTEM MEM. WITH ACK,
2366 046716 012721 043320      MOV     #T31BF2,(R1)+ ;ADDRESS OF DATA BLOCK
2367 046722 005021              CLR     (R1)+          ;EXTENDED ADDRESS
2368 046724 012721 000006      MOV     #6.,(R1)+     ;SIZE OF DATA BLOCK IN BYTES
2369 046730 005021              CLR     (R1)+
2370 046732 012701 043320      MOV     #T31BF2,R1    ;POINT TO DATA SEL AREA
2371 046736 005021              CLR     (R1)+
2372 046740 005011              CLR     (R1)
2373 046742 000207              RTS     PC              ;RETURN
2374 046744                    T31RT3:
2375 046744                    SAVREG                ;SAVE REGISTERS
2376 046750 012701 043310      MOV     #T31PK3,R1    ;SET UP POINTER ADDRESS
2377 046754 005021              CLR     (R1)+         ;COMMAND SPACE
2378 046756 005021              CLR     (R1)+         ;ADDRESS OF DATA BLOCK
2379 046760 005021              CLR     (R1)+         ;EXTENDED ADDRESS
2380 046762 005011              CLR     (R1)         ;SIZE OF DATA TRANSFER BLOCK
2381 046764 000207              RTS     PC              ;RETURN
2382 046766                    ENDTST
2383 046766 104401              L10050: TRAP     C$ETST

```

.SBTTL TEST 4: Erase And Operation Incomplete

2383
 2384
 2385
 2386
 2387
 2388
 2389
 2390
 2391
 2392
 2393
 2394
 2395
 2396
 2397
 2398
 2399
 2400
 2401
 2402
 2403
 2404
 2405
 2406
 2407
 2408
 2409

VERIFIES THAT AN ERASE COMMAND ISSUED WHEN THE TAPE IS POSITIONED AT BOT OPERATES PROPERLY AND ACTUALLY ERASES TAPE. THE FOLLOWING TEST SEQUENCE IS PERFORMED:

1. THE TAPE IS FIRST REWOUND, SEVERAL TEST RECORDS ARE WRITTEN, AND THE TAPE IS REWOUND AGAIN.
2. AN ERASE COMMAND IS ISSUED, WHICH SHOULD ERASE A NUMBER OF THE TEST RECORDS.
3. NORMAL TERMINATION IS VERIFIED AND STATUS IS CHECKED (BOT SHOULD BE 0).
4. A READ REVERSE COMMAND IS ISSUED. IT IS VERIFIED THAT THE COMMAND TERMINATES WITH TAPE STATUS ALERT, THAT THE REVERSE INTO BOT (RIB) STATUS BIT IS SET, AND THAT NO DATA IS TRANSFERRED. THIS DEMONSTRATES THAT NO DATA WAS ENCOUNTERED IN THE AREA ERASED BY THE ERASE COMMAND.

```

2410 ;
2411 ;
2412 ;
2413 ;THE TEST CONSISTS OF THE FOLLOWING 3 SUBTESTS
2414 ;
2415 ;
2416 ;
2417 ;-
2418 046770            BGNTST
           046770
2419 046770 012737 006354 002172    MOV      #EPRT1,EPRTSW    ;PRIMARY ERROR MESSAGE
2424 046776 012700 052640           MOV      #TST32ID,RO     ;ASCII MESSAGE TO IDENTIFY TEST
2425 047002 004737 016570           JSR     PC,TSTSETUP     ;DO INITIAL TEST SETUP
2426 047006 012737 000005 002210    MOV      #5,LOOPCNT     ;PERFORM 5 ITERATIONS
2427 047014 005037 051510           CLR     T32CNT         ;CLEAR TAPE RECORD COUNTER
2428 ;+
2429 ;
2430 ;TEST 4, SUBTEST 1
2431 ;
2432 ;
2433 ;VERIFIES THAT A Erase And Operation Incomplete COMMAND ISSUED WHILE
2434 ;THE TAPE IS POSITIONED AT BOT CAUSES FUNCTION REJECT
2435 ;TERMINATION, WITH THE NON-EXECUTABLE FUNCTION (NEF)
2436 ;ERROR BIT SET.
2437 ;
2438 ;
2439 ;-
2440 ;
2441 047020            T32LOOP:
2442 ;
2443 ;
2444 ;-
2445 047020            BGNSUB            ;>>>>>>>>>>>>>>> BEGIN SUBTEST >>>>>>>>>>>>>>>
           047020            T4.1:
2446 047022 004737 052700           JSR     PC,T32REST     ;SET COMMAND PACKET
           104402           JSR     PC,T32RT2     ;SET UP OTHER COMMAND PACKET
2447 047026 004737 052772           JSR     PC,T32RT3     ;SET UP OTHER COMMAND PACKET
2448 047032 004737 053022           MOV      #65000.,T32DLY ;SET UP DELAY COUNTER
2449 047036 012737 176750 051514    10$:   JSR     PC,SOFINIT   ;DO INITIALIZE ON CONTROLLER
2450 047044 004737 016054           BCS     20$          ;BR IF INIT WAS OK
2451 047050 103426           DELAY    250         ;DELAY ABOUT .25 SEC
2452 047052           MOV      #250,(PC)+
           047056 000000           .WORD    0
           047060 013727 002116           MOV      L$DLY,(PC)+
           047064 000000           .WORD    0
           047066 005367 177772           DEC     -6(PC)
           047072 001375           BNE     -4
           047074 005367 177756           DEC     -22(PC)
           047100 001367           BNE     -20
2453 047102 005337 051514           DEC     T32DLY       ;BUMP COUNTER
2454 047106 001356           BNE     10$         ;BR. IF COUNTER NOT DONE
2455 047110 005237 002214           INC     FATFLG      ;ERROR COUNT
2459 047114 010001           MOV     R0,R1      ;CONTENTS OF TSSR REGISTER
2460 047116           ERRDF   ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
           047116 104455           TRAP    C$ERRDF
           047120 000621           .WORD   401

```


TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 4: ERASE AND OPERATION INCOMPLETE

SEQ 142

	047346	051700							.WORD	T32RWN
	047350	012126							.WORD	PKTSSR
2511	047352		30\$:	CKLOOP						;LOOP IF SELECTED
	047352	104406							TRAP	C\$CLP1
2512	047354	013701	051360	MOV	T32BFR+6,R1					;PICK UP XSTO
2513	047360	010102		MOV	R1,R2					;SET UP EXPECTED
2514	047362	052702	000002	BIS	#BIT1,R2					;SET BOT BIT IN EXPECTED
2515	047366	020102		CMP	R1,R2					;DOES EXP = REC'D
2516	047370	001406		BEQ	40\$;BR, IF EQUAL (OK)
2517	047372	005237	002214	INC	FATFLG					;ERROR COUNT
2521	047376			ERRHRD	ERRNO,T32BOE,EXPREC					;TAPE AT BOT AFTER ERASE
	047376	104456							TRAP	C\$ERHRD
	047400	000626							.WORD	406
	047402	052366							.WORD	T32BOE
	047404	015554							.WORD	EXPREC
2522	047406		40\$:	CKLOOP						;LOOP IF SELECTED
	047406	104406							TRAP	C\$CLP1
2523	047410	012737	140411	MOV	#140411,T32PK3					;ERASE TAPE,CVC=1,ACK COMMAND
2524	047416	012704	051450	MOV	#T32PK3,R4					;SET UP R4 WITH PACKET ADDRESS
2525	047422	010465	000000	MOV	R4,TSDB(R5)					;ISSUE COMMAND
2526	047426	004737	016330	JSR	PC,WAITF					;WAIT FOR SSR TO SET
2527	047432	016501	000002	MOV	TSSR(R5),R1					;GET TSSR CONTENTS
2528	047436	012702	000200	MOV	#SSR,R2					;SET UP EXPECTED
2529	047442	020102		CMP	R1,R2					;ARE THEY EQUAL
2530	047444	001406		BEQ	50\$;BR, IF OK
2531	047446	005237	002214	INC	FATFLG					;ERROR COUNT
2535	047452			ERRHRD	ERRNO,T32ERA,PKTSSR					;TSSR INCORRECT AFTER ERASE DATA
	047452	104456							TRAP	C\$ERHRD
	047454	000627							.WORD	407
	047456	052016							.WORD	T32ERA
	047460	012126							.WORD	PKTSSR
2536	047462		50\$:	CKLOOP						;LOOP IF SELECTED
	047462	104406							TRAP	C\$CLP1
2537	047464	013701	051360	MOV	T32BFR+6,R1					;PICK UP XSTO
2538	047470	010102		MOV	R1,R2					;SET UP EXPECTED
2539	047472	042702	000002	BIC	#BIT1,R2					;SET BOT BIT IN EXPECTED
2540	047476	020102		CMP	R1,R2					;DOES EXP = REC'D
2541	047500	001406		BEQ	55\$;BR, IF EQUAL (OK)
2542	047502	005237	002214	INC	FATFLG					;ERROR COUNT
2546	047506			ERRHRD	ERRNO,T32BOE,EXPREC					;TAPE NOT AT BOT AFTER REWIND
	047506	104456							TRAP	C\$ERHRD
	047510	000630							.WORD	408
	047512	052366							.WORD	T32BOE
	047514	015554							.WORD	EXPREC
2547	047516		55\$:	CKLOOP						;LOOP IF SELECTED
	047516	104406							TRAP	C\$CLP1
2548	047520	013737	003116	MOV	FREE,T32RB					;ADDRESS OF BUFFER
2549	047526	012737	140401	MOV	#140401,T32PK3					;READ REVERSE,ACK,CVC=1 COMMAND
2550	047534	012737	000400	MOV	#256.,T32SZ					;SET UP THE SIZE OF RECORD
2551	047542	012704	051450	MOV	#T32PK3,R4					;SET UP R4 WITH PACKET ADDRESS
2552	047546	010465	000000	MOV	R4,TSDB(R5)					;ISSUE COMMAND
2553	047552	004737	016330	JSR	PC,WAITF					;WAIT FOR SSR TO SET
2554	047556	016501	000002	MOV	TSSR(R5),R1					;GET TSSR CONTENTS
2555	047562	012702	100204	MOV	#SSR!SC!BIT2,R2					;SET UP EXPECTED TAPE STATUS ALERT
2556	047566	020102		CMP	R1,R2					;ARE THEY EQUAL
2557	047570	001406		BEQ	180\$;BR, IF OK
2558	047572	005237	002214	INC	FATFLG					;ERROR COUNT

```

2562 047576          ERRHRD  ERRNO,T32TSA,PKTSSR       ;TSSR INCORRECT AFTER READ DATA
      047576 104456                                 TRAP      C$ERHRD
      047600 000631                                 .WORD    409
      047602 052311                                 .WORD    T32TSA
      047604 012126                                 .WORD    PKTSSR
2563 047606          180$: CKLOOP                      ;LOOP IF SELECTED              TRAP      C$CLP1
      047606 104406
2564 047610 013701 051366  MOV      T32BFR+14,R1       ;GET XST3 STATUS WORD
2565 047614 010102  MOV      R1,R2            ;SET UP EXPECTED
2566 047616 052702 000001  BIS      #BIT0,R2         ;SET THE RIB BIT
2567 047622 020102  CMP      R1,R2            ;ARE THEY EQUAL
2568 047624 001406  BEQ      190$          ;BR, IF EQUAL (GOOD)
2569 047626 005237 002214  INC      FATFLG           ;ERROR COUNT
2573 047632          EORHRD  ERRNO,T32RIB,EXPREC       ;RIB SHOULD BE SET
      047632 104456                                 TRAP      C$ERHRD
      047634 000632                                 .WORD    410
      047636 052136                                 .WORD    T32RIB
      047640 015554                                 .WORD    EXPREC
2574 047642          190$:
2575 047642          ENDSUB                               ;>>>>>>>>>>>> END SUBTEST >>>>>>>>>>>>
      047642 104403                                       L10054:
2576 047644 023727 002214 000017  CMP      FATFLG,#15.      ;IS ERROR COUNT AT 25
2577 047652 103402  BLO      999$          ;BR, IF LESS THAN 25
2578 047654 004737 017262  JSR      PC,CKDROP       ;TRY TO DROP THE UNIT
2579 047660          999$:
2580          ;+
2581          ;
2582          ;TEST 4, SUBTEST 2
2583          ;
2584          ;   VERIFIES THAT AN ERASE COMMAND EXECUTED WHEN THE TAPE IS NOT
2585          ;   POSITIONED AT BOT OPERATES PROPERLY AND DOES NOT CORRUPT
2586          ;   PREVIOUS TAPE RECORDS.  THE TEST SEQUENCE IS:
2587          ;
2588          ;   1.  THE TAPE IS FIRST REWOUND, SEVERAL TEST RECORDS ARE
2589          ;   WRITTEN, AND THE TAPE IS REWOUND AGAIN.
2590          ;
2591          ;
2592          ;   2.  A SPACE RECORDS FORWARD COMMAND IS ISSUED TO MOVE THE
2593          ;   TAPE OFF OF BOT AND SKIP OVER THE FIRST SEVERAL
2594          ;   RECORDS.
2595          ;
2596          ;   3.  AN ERASE COMMAND IS ISSUED, WHICH SHOULD ERASE A NUMBER
2597          ;   OF THE TEST RECORDS.
2598          ;
2599          ;   4.  NORMAL TERMINATION IS VERIFIED AND STATUS IS CHECKED.
2600          ;
2601          ;   5.  A READ REVERSE COMMAND IS ISSUED.  IT IS VERIFIED THAT
2602          ;   NORMAL TERMINATION IS ACCOMPLISHED AND THAT THE DATA
2603          ;   TRANSFERRED CORRESPONDS TO THAT FOR THE EXPECTED
2604          ;   RECORD.  THIS DEMONSTRATES THAT NO DATA WAS ENCOUNTERED
2605          ;   IN THE AREA ERASED BY THE ERASE COMMAND, AND THAT THE
2606          ;   PREVIOUS RECORD WAS NOT CORRUPTED.
2607          ;
2608          ;
2609          ;
2610          ;

```

```

2611
2612
2613
2614 047660          |
      047660          |
      047660 104402   |
2615 047662 004737 052700   JSR    PC,T32REST      ;SET COMMAND PACKET
2616 047666 004737 052772   JSR    PC,T32RT2      ;SET UP OTHER COMMAND PACKET
2617 047672 004737 053022   JSR    PC,T32RT3      ;SET UP OTHER COMMAND PACKET
2618 047676 004737 016054   JSR    PC,SOFINIT     ;DO INITIALIZE ON CONTROLLER
2619 047702 103407          BCS    201             ;BR IF INIT WAS OK
2620 047704 005237 002214   INC    FATFLG         ;ERROR COUNT
2624 047710 010001          MOV    R0,R1          ;CONTENTS OF TSSR REGISTER
2625 047712          CRRDF  ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
      047712 104455          TRAP    C1ERDF
      047714 000633          .WORD  411
      047716 003646          .WORD  SFIERR
      047720 012114          .WORD  SFIMSG
2626 047722 013737 00217A 051350 201:  MOV    UNITN,T32DSW    ;SET UP UNIT NUMBER IN PACKET
2627 047730 012704 051330      MOV    #T32PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
2628 047734 004737 010742   JSR    PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
2629 047740 103407          BCS    231             ;BR, IF COMMAND ISSUED OK
2630 047742 005237 002214   INC    FATFLG         ;ERROR COUNT
2634 047746 010001          MOV    R0,R1          ;SAVE CONTENTS OF TSSR
2635 047750          ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
      047750 104456          TRAP    C1ERHRD
      047752 000634          .WORD  412
      047754 005052          .WORD  WRTMSG
      047756 012114          .WORD  SFIMSG
2636 047760          231:  CKLOOP    ;LOOP IF SELECTED
      047760 104406          TRAP    C1CLP1
2637 047762 004737 011074   JSR    PC,REWIND      ;CALL TAPE REWIND COMMAND
2638 047766 103407          BCS    301             ;BR, IF NO PROBLEM
2639 047770 010004          MOV    R0,R4          ;SET UP REWIND PACKET ADDRESS
2640 047772 005237 002214   INC    FATFLG         ;ERROR COUNT
2644 047776          ERRHRD  ERRNO,T32RWN,PKTSSR ;REWIND NOT ACCEPTED
      047776 104456          TRAP    C1ERHRD
      050000 000635          .WORD  413
      050002 051700          .WORD  T32RWN
      050004 012126          .WORD  PKTSSR
2645 050006          301:  CKLOOP    ;LOOP IF SELECTED
      050006 104406          TRAP    C1CLP1
2646 050010 013701 051360   MOV    T32BFR+6,R1    ;PICK UP XSTO
2647 050014 010102          MOV    R1,R2          ;SET UP EXPECTED
2648 050016 052702 000002   BIS    #BIT1,R2      ;SET BOT BIT IN EXPECTED
2649 050022 020102          CMP    R1,R2          ;DOES EXP = REC'D
2650 050024 001406          BEQ    401             ;BR, IF EQUAL (OK)
2651 050026 005237 002214   INC    FATFLG         ;ERROR COUNT
2655 050032          ERRHRD  ERRNO,T32BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
      050032 104456          TRAP    C1ERHRD
      050034 000636          .WORD  414
      050036 051516          .WORD  T32BOT
      050040 015554          .WORD  EXPREC
2656 050042          401:  CKLOOP    ;LOOP IF SELECTED
      050042 104406          TRAP    C1CLP1
2657 050044 012703 000144   MOV    #100,R3        ;STARTING RECORD SIZE
2658 050050 010300          MOV    R3,R0          ;SET UP MEMORY FILL

```


2659	050052	004737	017502		JSR	PC,FILLMEM		;CALL MEMORY FILLER
2660	050056	013737	003116	051452	MOV	FREE,T32WB		;STARTING WRITE BUFFER ADDRESS
2661	050064	012737	140005	051450 65:	MOV	0140005,T32PK3		;WRITE DATA,CVC*1,ACK COMMAND
2662	050072	012704	051450		MOV	0T32PK3,R4		;SET UP R4 WITH PACKET ADDRESS
2663	050076	010300			MOV	R3,R0		;SET PATTERN IN CORRECT REGISTER
2664	050100	004737	017502		JSR	PC,FILLMEM		;FILL MEMORY WITH RECORD SIZE
2665	050104	010337	051456		MOV	R3,T32SZ		;SET UP RECORD SIZE IN PACKET
2666	050110	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND
2667	050114	004737	016330		JSR	PC,WAITF		;WAIT FOR SSR TO SET
2668	050120	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
2669	050124	012702	000200		MOV	0SSR,R2		;SET UP EXPECTED
2670	050130	020102			CMP	R1,R2		;ARE THEY EQUAL
2671	050132	001406			BEQ	80:		;BR, IF OK
2672	050134	005237	002214		INC	FATFLG		;ERROR COUNT
2676	050140				ERRHRD	ERRNO,T32WDC,PKTSSR		;TSSR INCORRECT AFTER WRITE DATA
	050140	104456						TRAP C1ERHRD
	050142	000637						.WORD 415
	050144	052536						.WORD T32WDC
	050146	012126						.WORD PKTSSR
2677	050150			80:	CKLOOP			;LOOP IF SELECTED
	050150	104406						TRAP C1CLP1
2678	050152	005723			TST	(R3),		;BUMP RECORD SIZE COUNTER
2679	050154	020327	000156		CMP	R3,0110.		;AT 160 SIZE YET
2680	050160	001341			BNE	65:		;BR, IF MORE RECORDS TO WRITE
2681	050162	004737	011074		JSR	PC,REWIND		;CALL TAPE REWIND COMMAND
2682	050166	103407			BCS	230:		;BR, IF NO PROBLEM
2683	050170	010001			MOV	R0,R1		;SAVE TSSR
2684	050172	005237	002214		INC	FATFLG		;ERROR COUNT
2688	050176				ERRHRD	ERRNO,T32RWN,EXPREC		;REWIND NOT ACCEPTED
	050176	104456						TRAP C1ERHRD
	050200	000640						.WORD 416
	050202	051700						.WORD T32RWN
	050204	015554						.WORD EXPREC
2689	050206			230:	CKLOOP			;LOOP IF SELECTED
	050206	104406						TRAP C1CLP1
2690	050210	013701	051360		MOV	T32BFR+6,R1		;PICK UP XSTO
2691	050214	010102			MOV	R1,R2		;SET UP EXPECTED
2692	050216	052702	000002		BIS	0BIT1,R2		;SET BOT BIT IN EXPECTED
2693	050222	020102			CMP	R1,R2		;DOES EXP = REC'D
2694	050224	001406			BEQ	240:		;BR, IF EQUAL (OK)
2695	050226	005237	002214		INC	FATFLG		;ERROR COUNT
2699	050232				ERRHRD	ERRNO,T32BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND
	050232	104456						TRAP C1ERHRD
	050234	000641						.WORD 417
	050236	051516						.WORD T32BOT
	050240	015554						.WORD EXPREC
2700	050242			240:	CKLOOP			;LOOP IF SELECTED
	050242	104406						TRAP C1CLP1
2701	050244	012703	000001		MOV	01,R3		;SET UP FOR SPACE COMMAND
2702	050250	004737	010544		JSR	PC,SPACE		;ISSUE SPACE COMMAND 1 FORWARD
2703	050254	012737	140411	051450 265:	MOV	0140411,T32PK3		;ERASE DATA,ACK COMMAND
2704	050262	012704	051450		MOV	0T32PK3,R4		;SET UP R4 WITH PACKET ADDRESS
2705	050266	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND
2706	050272	004737	016330		JSR	PC,WAITF		;WAIT FOR SSR TO SET
2707	050276	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
2708	050302	012702	000200		MOV	0SSR,R2		;SET UP EXPECTED
2709	050306	020102			CMP	R1,R2		;ARE THEY EQUAL

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 4: ERASE AND OPERATION INCOMPLETE

SEQ 148

2805	050612	012704	051330		MOV	⊕T32PACKET,R4		;SUBROUTINE NEEDS PACKET ADDRESS	
2806	050616	004737	010742		JSR	PC,WRTCHR		;ISSUE WRITE CHARACTERISTICS	
2807	050622	103407			BCS	23⊕		;BR, IF COMMAND ISSUED OK	
2808	050624	005237	002214		INC	FATFLG		;ERROR COUNT	
2812	050630	010001			MOV	R0,R1		;SAVE CONTENTS OF TSSR	
2813	050632				ERRHRD	ERRNO,WRTMSG,SFIMSG		;WRITE CHARACTERISTIC FAILED	
	050632	104456						TRAP	C\$ERHRD
	050634	000646						.WORD	422
	050636	005052						.WORD	WRTMSG
	050640	012114						.WORD	SFIMSG
2814	050642			23⊕:	CKLOOP			;LOOP IF SELECTED	
	050642	104406						TRAP	C\$CLP1
2815	050644	004737	011074		JSR	PC,REWIND		;CALL TAPE REWIND COMMAND	
2816	050650	103411			BCS	30⊕		;BR, IF NO PROBLEM	
2817	050652	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS	
2818	050656	010004			MOV	R0,R4		;GET PACKET ADDRESS	
2819	050660	005237	002214		INC	FATFLG		;ERROR COUNT	
2823	050664				ERRHRD	ERRNO,T32RWN,PKTSSR		;REWIND NOT ACCEPTED	
	050664	104456						TRAP	C\$ERHRD
	050666	000647						.WORD	423
	050670	051700						.WORD	T32RWN
	050672	012126						.WORD	PKTSSR
2824	050674			30⊕:	CKLOOP			;LOOP IF SELECTED	
	050674	104406						TRAP	C\$CLP1
2825	050676	013701	051360		MOV	T32BFR+6,R1		;PICK UP XSTO	
2826	050702	010102			MOV	R1,R2		;SET UP EXPECTED	
2827	050704	052702	000002		BIS	⊕BIT1,R2		;SET BOT BIT IN EXPECTED	
2828	050710	020102			CMP	R1,R2		;DOES EXP = REC'D	
2829	050712	001406			BEQ	40⊕		;BR, IF EQUAL (OK)	
2830	050714	005237	002214		INC	FATFLG		;ERROR COUNT	
2834	050720				ERRHRD	ERRNO,T32BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND	
	050720	104456						TRAP	C\$ERHRD
	050722	000650						.WORD	424
	050724	051516						.WORD	T32BOT
	050726	015554						.WORD	EXPREC
2835	050730			40⊕:	CKLOOP			;LOOP IF SELECTED	
	050730	104406						TRAP	C\$CLP1
2836	050732	012737	140411	051450	65⊕:	MOV	⊕140411,T32PK3	;ERASE DATA,CVC=1,ACK COMMAND	
2837	050740	012704	051450		MOV	⊕T32PK3,R4		;SET UP R4 WITH PACKET ADDRESS	
2838	050744	010337	051456		MOV	R3,T32SZ		;SET UP RECORD SIZE IN PACKET	
2839	050750	010465	000000		MOV	R4,TSD8(R5)		;ISSUE COMMAND	
2840	050754	004737	016330		JSR	PC,WAITF		;WAIT FOR SSR TO SET	
2841	050760	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS	
2842	050764	012702	000200		MOV	⊕SSR,R2		;SET UP EXPECTED	
2843	050770	020102			CMP	R1,R2		;ARE THEY EQUAL	
2844	050772	001757			BEQ	65⊕		;BR, IF OK	
2845	050774	032701	000004		BIT	⊕BIT2,R1		;CHECK FOR TAPE STATUS ALERT	
2846	051000	001006			BNE	80⊕		;BR, IF TAPE STATUS ALERT SET	
2847	051002	005237	002214		INC	FATFLG		;ERROR COUNT	
2851	051006				ERRHRD	ERRNO,T32WDC,PKTSSR		;TSSR INCORRECT AFTER WRITE DATA	
	051006	104456						TRAP	C\$ERHRD
	051010	000651						.WORD	425
	051012	052536						.WORD	T32WDC
	051014	012126						.WORD	PKTSSR
2852	051016			80⊕:	CKLOOP			;LOOP IF SELECTED	
	051016	104406						TRAP	C\$CLP1
2853	051020	013701	051360		MOV	T32BFR+6,R1		;PICK UP XSTO	

TEST 1 HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 4: ERASE AND OPERATION INCOMPLETE

SEQ 149

```

2854 051024 010102      MOV      R1,R2      ;SET UP EXPECTED
2855 051026 052702 000001  BIS      #BIT0,R2   ;SET EOT BIT IN EXPECTED
2856 051032 020102      CMP      R1,R2      ;DOES EXP = REC'D
2857 051034 001406      BEQ      240$       ;BR, IF EQUAL (OK)
2858 051036 005237 002214  INC      FATFLG     ;ERROR COUNT
2862 051042      ERRHRD  ERRNO,T32EOT,EXPREC ;TAPE NOT AT EOT AFTER ERASE COMMANDS
      051042 104456      TRAP      C$ERHRD
      051044 000652      .WORD    426
      051046 051611      .WORD    T32EOT
      051050 015554      .WORD    EXPREC
2863      051052      240$:  CKLOOP      ;LOOP IF SELECTED
      051052 104406      TRAP      C$CLP1
2864 051054 012703 051460      MOV      #T32CMD,R3 ;STARTING RECORD SIZE
2865 051060 013737 003116 051452  MOV      FREE,T32RB ;STARTING READ BUFFER ADDRESS
2866 051066 011337 051450      265$:  MOV      (R3),T32PK3 ;READ DATA,ACK COMMAND
2867 051072 012704 051450      MOV      #T32PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
2868 051076 012700 177777      MOV      #177777,R0 ;SET PATTERN IN CORRECT REGISTER
2869 051102 004737 017502      JSR      PC,FILLMEM ;FILL MEMORY WITH ALL ONES
2870 051106 012737 000144 051456  MOV      #100.,T32SZ ;SET UP RECORD SIZE IN PACKET
2871 051114 010465 000000      MOV      R4,TSD8(R5) ;ISSUE COMMAND
2872 051120 012737 000062 051514  MOV      #50.,T32DLY ;SET UP DELAY COUNTER
2873 051126 004737 016330      270$:  JSR      PC,WAITF   ;WAIT FOR SSR TO SET
2874 051132 016501 000002      MOV      TSSR(R5),R1 ;GET TSSR CONTENTS
2875 051136 012702 100214      MOV      #SSR!SC!BIT2!BIT3,R2 ;SET UP EXPECTED
2876 051142 020102      CMP      R1,R2      ;ARE THEY EQUAL
2877 051144 001425      BEQ      280$       ;BR, IF OK
2878 051146      DELAY    250       ;DELAY FOR SSR TO BE SET
      051146 012727 000250      MOV      #250,(PC)+
      051152 000000      .WORD    0
      051154 013727 002116      MOV      L$DLY,(PC)+
      051160 000000      .WORD    0
      051162 005367 177772      DEC      -6(PC)
      051166 001375      BNE      .-4
      051170 005367 177756      DEC      -22(PC)
      051174 001367      BNE      .-20
2879 051176 005337 051514      DEC      T32DLY     ;COUNT DELAY ROUTINE DOWN
2880 051202 001351      BNE      270$       ;BR, IF DELAY HAS NOT ENDED
2881 051204 005237 002214  INC      FATFLG     ;ERROR COUNT
2885 051210      ERRHRD  ERRNO,T32ECF,PKTSSR ;TSSR INCORRECT AFTER READ DATA
      051210 104456      TRAP      C$ERHRD
      051212 000653      .WORD    427
      051214 052455      .WORD    T32ECF
      051216 012126      .WORD    PKTSSR
2886 051220      280$:  CKLOOP      ;LOOP IF SELECTED
      051220 104406      TRAP      C$CLP1
2887 051222 013701 051366      MOV      T32BFR+14,R1 ;PICK UP XST3
2888 051226 010102      MOV      R1,R2      ;SET UP EXPECTED
2889 051230 052702 000100      BIS      #BIT6,R2   ;SET OPI BIT IN EXPECTED
2890 051234 020102      CMP      R1,R2      ;IS OPI BIT SET
2891 051236 001406      BEQ      290$       ;BR, IF BIT IS SET
2892 051240 005237 002214  INC      FATFLG     ;ERROR COUNT
2896 051244      ERRHRD  ERRNO,T32OPI,EXPREC ;OPI BIT NOT SET
      051244 104456      TRAP      C$ERHRD
      051246 000654      .WORD    428
      051250 052603      .WORD    T32OPI
      051252 015554      .WORD    EXPREC
2897 051254      290$:  CKLOOP      ;LOOP IF SELECTED

```


TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 4: ERASE AND OPERATION INCOMPLETE

SEQ 151

```

2957
2958
2959
2960
2961 051460
2962 051460 140410
2963 051462 141410
2964 051464 140401
2965 051466 141001
2966 051470 161401
2967 051472 161001
2968 051474 141401
2969 051476 140001
2970 051500 141410
2971 051502 141010
2972 051504 141005
2973 051506 177777
2974
2975
2976 051510 000000
2977 051512 000000
2978 051514 000000
2979
2980
2981
2982
2983 051516 124 141 160 T32BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
2984 051611 124 141 160 T32EOT: .ASCIZ 'Tape Status Alert During Erase To EOT, But EOT Not Set'
2985 051700 122 145 167 T32RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
2986 051747 124 123 123 T32AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
2987 052016 124 123 123 T32ERA: .ASCIZ 'TSSR Not Correct After ERASE Command'
2988 052063 124 123 102 T32BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
2989 052136 122 105 101 T32RIB: .ASCIZ 'READ REVERSE, After ERASE From BOT, Failed To Set RIB In XST3'
2990 052234 124 123 123 T32SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
2991 052311 124 123 123 T32TSA: .ASCIZ 'TSSR Not Correct After READ REVERSE Into BOT'
2992 052366 102 117 124 T32BOE: .ASCIZ 'BOT (XST0) Still Set After Erase From Tape's BOT Marker'
2993 052455 105 122 101 T32ECF: .ASCIZ 'ERASE Failed To Clear Tape (Erase) Tape Properly'
2994 052536 124 123 123 T32WDC: .ASCIZ 'TSSR Not Correct After ERASE Command'
2995 052603 117 120 111 T32OPI: .ASCIZ 'OPI Bit (XST3) Failed To Set'
2996 052640 105 162 141 TST32ID: .ASCIZ 'Erase And Operation Incomplete'
2997
2998
2999
3000
3001
3002
3003
3004
3005 052700
3006 052700
3007 052704 012701 051330
3008 052710 012721 100004
3009 052714 012721 051340
3010 052720 005021
3011 052722 012721 000012
3012 052726 012721 051352
3013 052732 005021

```

```

;
; .EVEN
; TAPE MOTION PACKET COMMAND VALUES
T32CMD:
; .WORD 140410 ; SPACE RECORDS REVERSE
; .WORD 141410 ; SKIP TAPE MARKS REVERSE
; .WORD 140401 ; READ REVERSE
; .WORD 141001 ; REREAD PREVIOUS (OPP=0)
; .WORD 161401 ; REREAD NEXT (OPP=1)
; .WORD 161001 ; REREAD PREVIOUS (OPP=1)
; .WORD 141401 ; REREAD NEXT (OPP=0)
; .WORD 140001 ; READ NEXT
; .WORD 141410 ; SKIP TAPE MARKS REVERSE
; .WORD 141010 ; SKIP RECORDS FORWARD
; .WORD 141005 ; WRITE DATA RETRY
; .WORD 177777 ; END OF DATA

;
T32CNT: .WORD 0 ; TAPE TIMER COUNTER STORAGE AREA
T32CNU: .WORD 0 ; TAPE TIMER COUNTER STORAGE AREA
T32DLY: .WORD 0 ; DELAY COUNTER

;+
; LOCAL TEXT MESSAGES FOR TEST
;-

;+
; ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
; WRITE SUBSYSTEM MEMORY COMMAND
;
;-

T32REST:
; SAVREG ; SAVE THE REGISTERS
MOV #T32PACKET,R1 ; START OF THE PACKET
MOV #100004,(R1)+ ; WRITE SUBSYSTEM MEM. WITH ACK,
MOV #T32DATA,(R1)+ ; ADDRESS OF CHARACTERISTICS DATA BLOCK
CLR (R1)+ ; EXTENDED ADDRESS
MOV #10.,(R1)+ ; SIZE OF DATA BLOCK IN BYTES
MOV #T32BFR,(R1)+ ; ADDRESS OF MESSAGE BUFFER
CLR (R1)+

```

```

3014 052734 012721 000024      MOV      #20.,(R1)+      ;LENGTH OF MESSAGE BUFFER
3015 052740 005021              CLR      (R1)+
3016 052742 012711 000000      MOV      #0,(R1)        ;SELECT DRIVE ZERO
3017 052746 012702 000030      MOV      #24.,R2        ;NUMBER OF LOCATIONS TO BE CLEARED
3018 052752 012762 177777 031352 64$: MOV      #177777,T32BFR(R2) ;ALL ONES TO MESSAGE BUFFER
3019 052760 005742              TST      -(R2)          ;NEXT LOCATION
3020 052762 022702 000000      CMP      #0,R2          ;AT END OF LOOP YET
3021 052766 001371              BNE      64$            ;KEEP GOING UNTIL DONE
3022 052770 000207              RTS      PC              ;RETURN
3023
3024 052772              T32RT2:
3025 052772              SAVREG                  ;SAVE THE REGISTERS
3026 052776 012701 051440      MOV      #T32PK2,R1     ;START OF THE PACKET
3027 053002 012721 100006      MOV      #100006,(R1)+  ;WRITE SUBSYSTEM MEM. WITH ACK,
3028 053006 005021              CLR      (R1)+          ;ADDRESS OF DATA BLOCK
3029 053010 005021              CLR      (R1)+          ;EXTENDED ADDRESS
3030 053012 012721 000006      MOV      #6.,(R1)+     ;SIZE OF DATA BLOCK IN BYTES
3031 053016 005021              CLR      (R1)+
3032 053020 000207              RTS      PC              ;RETURN
3033
3034 053022              T32RT3:
3035 053026 012701 051450      SAVREG                  ;SAVE REGISTERS
3036 053032 005021              MOV      #T32PK3,R1     ;SET UP POINTER ADDRESS
3037 053034 005021              CLR      (R1)+          ;COMMAND SPACE
3038 053036 005021              CLR      (R1)+          ;ADDRESS OF DATA BLOCK
3039 053040 005011              CLR      (R1)+          ;EXTENDED ADDRESS
3040 053042 000207              RTS      PC              ;RETURN
3041 053044
3041 053044 104401              L10053: TRAP      C$ETST
    
```

3042 .SBTTL TEST 5: DATA PARITY TEST

```

3043 ;+
3044 ;
3045 ;
3046 ;
3047 ;
3048 ;
3049 ;TEST 5 -- Data Parity Test
3050 ;
3051 ;
3052 ;This test verifies that the data parity circuitry in both the controller and the
3053 ;transport is operating properly by forcing data records with wrong parity to be
3054 ;written onto tape and checking the results obtained when the data is read. The
3055 ;following test sequence is performed:
3056 ;
3057 ; 1. A Write Characteristics command is issued and the resulting status is
3058 ; examined to determine the states of the Extended Features and Buffering
3059 ; Enable switches on the controller module. If buffering is disabled, no
3060 ; further actions need be taken in this step and the program proceeds to
3061 ; the next step. If buffering is enabled, it is disabled via the Buffer
3062 ; Control field in the extended characteristics data word supplied by a
3063 ; Write Characteristics command. (The module must be in Extended mode,
3064 ; so if it is not already, a Write Subsystem Memory command is issued to
3065 ; change the logical sense of the Extended Features switch.)
3066 ;
3067 ; 2. The Write Subsystem Memory command is used to set the Force Wrong
3068 ; Parity control flip flop.
    
```


3127	053136	004737	016054	10\$:	JSR	PC,SOFINIT	;DO INITIALIZE ON CONTROLLER		
3128	053142	103426			BCS	20\$;BR IF INIT WAS OK		
3129	053144				DELAY	250	;DELAY ABOUT .25 SEC		
	053144	012727	000250					MOV	0250,(PC)+
	053150	000000						.WORD	0
	053152	013727	002116					MOV	L\$DLY,(PC)+
	053156	000000						.WORD	0
	053160	005367	177772					DEC	-6(PC)
	053164	001375						BNE	.4
	053166	005367	177756					DEC	-22(PC)
	053172	001367						BNE	.-20
3130	053174	005337	054722		DEC	T33DLY	;BUMP COUNTER		
3131	053200	001356			BNE	10\$;BR, IF COUNTER NOT DONE		
3132	053202	005237	002214		INC	FATFLG	;ERROR COUNT		
3136	053206	010001			MOV	R0,R1	;CONTENTS OF TSSR REGISTER		
3137	053210				ERRDF	ERRNO,SFIERR,SFIMSG	;FATAL ERROR TSSR WAS NOT OK		
	053210	104455						TRAP	C\$ERDF
	053212	000765						.WORD	501
	053214	003646						.WORD	SFIERR
	053216	012114						.WORD	SFIMSG
3138	053220	013737	002174	054570	20\$:	MOV	UNITN,T33DSW	;SET UP UNIT NUMBER	
3139									
3140	053226	012704	054550		MOV	0T33PACKET,R4	;SUBROUTINE NEEDS PACKET ADDRESS		
3141	053232	004737	010742		JSR	PC,WRTCHR	;ISSUE WRITE CHARACTERISTICS		
3142	053236	103407			BCS	23\$;BR, IF COMMAND ISSUED OK		
3143	053240	005237	002214		INC	FATFLG	;ERROR COUNT		
3147	053244	010001			MOV	R0,R1	;SAVE CONTENTS OF TSSR		
3148	053246				ERRHRD	ERRNO,WRTMSG,SFIMSG	;WRITE CHARACTERISTIC FAILED		
	053246	104456						TRAP	C\$ERHRD
	053250	000766						.WORD	502
	053252	005052						.WORD	WRTMSG
	053254	012114						.WORD	SFIMSG
3149	053256			23\$:	CKLOOP		;LOOP IF SELECTED		
	053256	104406						TRAP	C\$CLP1
3150	053260	004737	011074		JSR	PC,REWIND	;CALL TAPE REWIND COMMAND		
3151	053264	103411			BCS	30\$;BR, IF NO PROBLEM		
3152	053266	016501	000002		MOV	TSSR(R5),R1	;GET TSSR CONTENTS		
3153	053272	010004			MOV	R0,R4	;GET PACKET ADDRESS		
3154	053274	005237	002214		INC	FATFLG	;ERROR COUNT		
3158	053300				ERRHRD	ERRNO,T33RWN,PKTSSR	;REWIND NOT ACCEPTED		
	053300	104456						TRAP	C\$ERHRD
	053302	000767						.WORD	503
	053304	055420						.WORD	T33RWN
	053306	012126						.WORD	PKTSSR
3159	053310			30\$:	CKLOOP		;LOOP IF SELECTED		
	053310	104406						TRAP	C\$CLP1
3160	053312	013701	054600		MOV	T33BFR+6,R1	;PICK UP XSTO		
3161	053316	010102			MOV	R1,R2	;SET UP EXPECTED		
3162	053320	052702	000002		BIS	0BIT1,R2	;SET BOT BIT IN EXPECTED		
3163	053324	020102			CMP	R1,R2	;DOES EXP = REC'D		
3164	053326	001406			BEQ	40\$;BR, IF EQUAL (OK)		
3165	053330	005237	002214		INC	FATFLG	;ERROR COUNT		
3169	053334				ERRHRD	ERRNO,T33BOT,EXPREC	;TAPE NOT AT BOT AFTER REWIND		
	053334	104406						TRAP	C\$ERHRD
	053336	000100						.WORD	504
	053340	055325						.WORD	T33BOT
	053342	015554						.WORD	EXPREC

```

3170 053344          40$:  CKLOOP          ;LOOP IF SELECTED
      053344 104406
3171 053346 005737 002220 42$:  TST      EXTFEA          ;CHECK FOR EXTENDED FEATURES SW SWITCH
      053346 001025          BNE      55$          ;BR IF SWITCH IS ON
3172 053352 001025          MOV      #200,T33BS1 ;WRITE MISCELLANEOUS CONT/READ STATUS
3173 053354 112737 000200 054701  MOV      #10,T33BS0 ;FUNC. SEL. BIT (TURN ON EXTFEA SWITCH)
3174 053362 112737 000010 054700  MOV      #T33PK2,R4 ;WRITE SUBSYS MEM PACKET
3175 053370 012704 054660          MOV      R4,TSDB(R5) ;ISSUE COMMAND
3176 053374 010465 000000          JSR      PC,CHKTSSR  ;WAIT FOR SSR
3177 053400 004737 016416          BCS      50$          ;BR, IF NO ERROR
3178 053404 103407          MOV      R0,R1       ;ERROR, SAVE TSSR
3179 053406 010001          INC      FATFLG      ;ERROR COUNT
3180 053410 005237 002214          ERRHRD  ERRNO,T33SSR,PKTSSR ;TSSR NOT CORRECT AFTER WRT. MISCELLANEOUS
3184 053414          TRAP      C$CLP1
      053414 104456          .WORD    505
      053416 000771          .WORD    T33SSR
      053420 055241          .WORD    PKTSSR
      053422 012126
3185 053424          50$:  CKLOOP          ;LOOP IF SELECTED
      053424 104406          TRAP      C$CLP1
3186 053426 005737 002222 55$:  TST      BENBSW          ;CHECK FOR BUFFER ENABLED
      053426 001426          BEQ      70$          ;BR, IF BUFFERING NOT ENABLED
3187 053432 001426          MOV      UNITN,T33DSW ;SET UP UNIT NUMBER
3188 053434 013737 002174 054570  BIC      #8BIT4,T33DSW ;BUFFER DISABLE
3189 053442 042737 000020 054570  BIS      #8BIT3,T33DSW ;BUFFER DISABLE SEND 01 TO BITS 4 AND 3
3190 053450 052737 000010 054570  MOV      #T33PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
3191 053456 012704 054550          JSR      PC,WRTCHR   ;ISSUE WRITE CHARACTERISTICS
3192 053462 004737 010742          BCS      60$          ;BR, IF COMMAND ISSUED OK
3193 053466 103407          INC      FATFLG      ;ERROR COUNT
3194 053470 005237 002214          MOV      R0,R1       ;SAVE CONTENTS OF TSSR
3198 053474 010001          ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTICS FAILED
3199 053476          TRAP      C$ERHRD
      053476 104456          .WORD    506
      053500 000772          .WORD    WRTMSG
      053502 005052          .WORD    SFIMSG
      053504 012114
3200 053506          60$:  CKLOOP          ;LOOP IF SELECTED
      053506 104406          TRAP      C$CLP1
3201 053510          70$:
3202 053510 112737 000100 054701  MOV      #100,T33BS1 ;WRITE MISCELLANEOUS CONT/READ STATUS
3203 053516 112737 000011 054700  MOV      #11,T33BS0 ;FUNC. SEL. BIT (SET WRONG PARITY)
3204 053524 012704 054660          MOV      #T33PK2,R4 ;WRITE SUBSYS MEM PACKET
3205 053530 010465 000000          MOV      R4,TSDB(R5) ;ISSUE COMMAND
3206 053534 004737 016416          JSR      PC,CHKTSSR  ;WAIT FOR SSR
3207 053540 103407          BCS      80$          ;BR, IF NO ERROR
3208 053542 010001          MOV      R0,R1       ;ERROR, SAVE TSSR
3209 053544 005237 002214          INC      FATFLG      ;ERROR COUNT
3213 053550          ERRHRD  ERRNO,T33SSR,PKTSSR ;TSSR NOT CORRECT AFTER WRT. MISCELLANEOUS
3214 053550          TRAP      C$ERHRD
      053550 104456          .WORD    507
      053552 000773          .WORD    T33SSR
      053554 055241          .WORD    PKTSSR
      053556 012126
3214 053560          80$:  CKLOOP          ;LOOP IF SELECTED
      053560 104406          TRAP      C$CLP1
3215 053562 012703 000026          MOV      #22,R3      ;NUMBER OF RECORDS TO BE WRITTEN
3216 053566 013737 003116 054672  MOV      FREE,T33WB  ;STARTING WRITE BUFFER ADDRESS
3217 053574 005037 054720          CLR      T33CNU     ;MAKE SURE ITS CLEAR
3218 053600 012737 140005 054670 110$: MOV      #140005,T33PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
3219 053606 012704 054670          MOV      #T33PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
    
```

3220	053612	012737	000024	054676	MOV	#20.,T33SZ	;SET UP RECORD SIZE IN PACKET		
3221	053620	013777	054720	127270	MOV	T33CNU,@FREE	;MEMORY FILLED WITH DATA IN RECORD		
3222	053626	005237	054720		INC	T33CNU	;READY FOR NEXT RECORD		
3223	053632	010465	000000		MOV	R4,TSD8(R5)	;ISSUE COMMAND		
3224	053636	004737	016330		JSR	PC,WAITF	;WAIT FOR SSR TO SET		
3225	053642	016501	000002		MOV	TSSR(R5),R1	;GET TSSR CONTENTS		
3226	053646	012702	100210		MOV	#SSR!SC!BIT3,R2	;SET UP EXPECTED		
3227	053652	020102			CMP	R1,R2	;ARE THEY EQUAL		
3228	053654	001406			BEQ	120\$;BR, IF OK		
3229	053656	005237	002214		INC	FATFLG	;ERROR COUNT		
3233	053662				ERRHRD	ERRNO,T33WPW,PKTSSR	;TSSR INCORRECT AFTER WRITE DATA		
	053662	104456						TRAP	C\$ERHRD
	053664	000774						.WORD	508
	053666	055002						.WORD	T33WPW
	053670	012126						.WORD	PKTSSR
3234	053672			120\$:	CKLOOP		;LOOP IF SELECTED		
	053672	104406						TRAP	C\$CLP1
3235	053674	013701	054602		MOV	T33BFR+10,R1	;PICK UP XST1		
3236	053700	010102			MOV	R1,R2	;SET UP EXPECTED		
3237	053702	052702	000002		BIS	#BIT1,R2	;SET UNC BIT IN EXPECTED		
3238	053706	020102			CMP	R1,R2	;DOES EXP = REC'D		
3239	053710	001406			BEQ	130\$;BR, IF EQUAL (OK)		
3240	053712	005237	002214		INC	FATFLG	;ERROR COUNT		
3244	053716				ERRHRD	ERRNO,T33UNC,EXPREC	;TAPE NOT AT BOT AFTER REWIND		
	053716	104456						TRAP	C\$ERHRD
	053720	000775						.WORD	509
	053722	055062						.WORD	T33UNC
	053724	015554						.WORD	EXPREC
3245	053726			130\$:	CKLOOP		;LOOP IF SELECTED		
	053726	104406						TRAP	C\$CLP1
3246	053730	005303			DEC	R3	;DEC RECORD COUNTER		
3247	053732	001322			BNE	110\$;BR, IF MORE RECORDS TO WRITE		
3248	053734	004737	011074		JSR	PC,REWIND	;CALL TAPE REWIND COMMAND		
3249	053740	103411			DCS	140\$;BR, IF NO PROBLEM		
3250	053742	016501	000002		MOV	TSSR(R5),R1	;GET TSSR CONTENTS		
3251	053746	010004			MOV	R0,R4	;GET PACKET ADDRESS		
3252	053750	005237	002214		INC	FATFLG	;ERROR COUNT		
3256	053754				ERRHRD	ERRNO,T33RWN,PKTSSR	;REWIND NOT ACCEPTED		
	053754	104456						TRAP	C\$ERHRD
	053756	000776						.WORD	510
	053760	055420						.WORD	T33RWN
	053762	012126						.WORD	PKTSSR
3257	053764			140\$:	CKLOOP		;LOOP IF SELECTED		
	053764	104406						TRAP	C\$CLP1
3258	053766	013701	054600		MOV	T33BFR+6,R1	;PICK UP XST0		
3259	053772	010102			MOV	R1,R2	;SET UP EXPECTED		
3260	053774	052702	000002		BIS	#BIT1,R2	;SET BOT BIT IN EXPECTED		
3261	054000	020102			CMP	R1,R2	;DOES EXP = REC'D		
3262	054002	001406			BEQ	150\$;BR, IF EQUAL (OK)		
3263	054004	005237	002214		INC	FATFLG	;ERROR COUNT		
3267	054010				ERRHRD	ERRNO,T33BOT,EXPREC	;TAPE NOT AT BOT AFTER REWIND		
	054010	104456						TRAP	C\$ERHRD
	054012	000777						.WORD	511
	054014	055325						.WORD	T33BOT
	054016	015554						.WORD	EXPREC
3268	054020			150\$:	CKLOOP		;LOOP IF SELECTED		
	054020	104406						TRAP	C\$CLP1

Address	OpCode	Operand 1	Operand 2	Operand 3	Operand 4	Comment	Trap	Trap Word
3269	054022	005037	054720			CLR T33CNU		
3270	054026	012703	000024			MOV #20.,R3		
3271	054032	013737	003116	054672	1554:	MOV FREE,T33RB		
3272	054040	012737	140001	054670		MOV #140001,T33PK3		
3273	054046	012704	051670			MOV #T33PK3,R4		
3274	054052	012737	000024	054676		MOV #20.,T33SZ		
3275	054060	010465	000000			MOV R4,T33R5		
3276	054064	004737	010330			JSR PC,WAITF		
3277	054070	016501	000000			MOV T33R5,R1		
3278	054074	012702	100210			MOV #SSR!SC!BIT3,R2		
3279	054100	020102				CMP R1,R2		
3280	054102	001406				BEQ 1604		
3281	054104	005237	002214			INC FATFLG		
3285	054110					ERRHRD ERRNO,T33WDC,PKTSSR		
	054110	104456					TRAP	C1ERRHRD
	054112	001000					.WORD	512
	054114	055467					.WORD	T33WDC
	054116	012126					.WORD	PKTSSR
3286	054120			1604:	CKLOOP			
	054120	104406					TRAP	C1CLP1
3287	054122	013701	054602			MOV T33BFR+10,R1		
3288	054126	010102				MOV R1,R2		
3289	054130	052702	000002			BIS #BIT1,R2		
3290	054134	020102				CMP R1,R2		
3291	054136	001406				BEQ 1704		
3292	054140	005237	002214			INC FATFLG		
3296	054144					ERRHRD ERRNO,T33UND,EXPREC		
	054144	104456					TRAP	C1ERRHRD
	054146	001001					.WORD	513
	054150	055152					.WORD	T33UND
	054152	015554					.WORD	EXPREC
3297	054154			1704:	CKLOOP			
	054154	104406					TRAP	C1CLP1
3298	054156	013701	054602			MOV T33BFR+10,R1		
3299	054162	010102				MOV R1,R2		
3300	054164	052702	000400			BIS #BIT8,R2		
3301	054170	020102				CMP R1,R2		
3302	054172	001406				BEQ 1804		
3303	054174	005237	002214			INC FATFLG		
3307	054200					ERRHRD ERRNO,T33RBP,EXPREC		
	054200	104456					TRAP	C1ERRHRD
	054202	001002					.WORD	514
	054204	054724					.WORD	T33RBP
	054206	015554					.WORD	EXPREC
3308	054210			1804:	CKLOOP			
	054210	104406					TRAP	C1CLP1
3309	054212	017701	126700			MOV #FREE,R1		
3310	054216	013702	054720			MOV T33CNU,R2		
3311	054222	020102				CMP R1,R2		
3312	054224	001406				BEQ 1824		
3313	054226	005237	002214			INC FATFLG		
3317	054232					ERRHRD ERRNO,T33DIA,EXPREC		
	054232	104456					TRAP	C1ERRHRD
	054234	001003					.WORD	515
	054236	055550					.WORD	T33DIA
	054240	015554					.WORD	EXPREC
3318	054242			1824:	CKLOOP			

Line	Address	Offset	Value	Op	Opnd	Comment	Trap	Trap Code
3319	054242	104406		MOV	FREE, T33WB	STARTING WRITE BUFFER ADDRESS	TRAP	C1CLP1
3320	054244	013737	003116	MOV	0140401, T33PK3	READ REVERSE DATA RETRY, ACK COMMAND		
3321	054252	012737	140401	MOV	0T33PK3, R4	SET UP R4 WITH PACKET ADDRESS		
3322	054260	012704	054670	MOV	020., T33SZ	SET UP RECORD SIZE IN PACKET		
3323	054264	012737	000024	MOV	R4, TSD8(R5)	ISSUE COMMAND		
3324	054272	010465	000000	JSR	PC, WAITF	WAIT FOR SSR TO SET		
3325	054276	004737	016330	MOV	TSSR(R5), R1	GET TSSR CONTENTS		
3326	054302	012702	100210	MOV	0SC!SSR!BIT3, R2	SET UP EXPECTED		
3327	054306	012702	100210	CMP	R1, R2	ARE THEY EQUAL		
3328	054312	020102		BEQ	1901	BR, IF OK		
3329	054314	001406		INC	FATFLG	ERROR COUNT		
3333	054316	005237	002214	ERRHRD	ERRNO, T33WDC, PKTSSR	TSSR INCORRECT AFTER WRITE DATA		
	054322	104456					TRAP	C1ERHRD
	054324	001004					.WORD	516
	054326	055467					.WORD	T33WDC
	054330	012126					.WORD	PKTSSR
3334	054332	104406		1901:	CKLOOP	LOOP IF SELECTED		
	054332	104406					TRAP	C1CLP1
3335	054334	013701	054602	MOV	T33BFR+10, R1	PICK UP XST1		
3336	054334	010102		MOV	R1, R2	SET UP EXPECTED		
3337	054342	052702	000002	BIS	0BIT1, R2	SET UNC BIT IN EXPECTED		
3338	054346	020102		CMP	R1, R2	DOES EXP = REC'D		
3339	054350	001406		BEQ	2001	BR, IF EQUAL (OK)		
3340	054352	005237	002214	INC	FATFLG	ERROR COUNT		
3344	054356	104456		ERRHRD	ERRNO, T33UND, EXPREC	TAPE NOT AT BOT AFTER REWIND		
	054356	104456					TRAP	C1ERHRD
	054360	001005					.WORD	517
	054362	055152					.WORD	T33UND
	054364	015554					.WORD	EXPREC
3345	054366	104406		2001:	CKLOOP	LOOP IF SELECTED		
	054366	104406					TRAP	C1CLP1
3346	054370	013701	054602	MOV	T33BFR+10, R1	PICK UP XST0		
3347	054374	010102		MOV	R1, R2	SET UP EXPECTED		
3348	054376	052702	000400	BIS	0BIT8, R2	SET RBP BIT IN EXPECTED		
3349	054402	020102		CMP	R1, R2	DOES EXP = REC'D		
3350	054404	001406		BEQ	2101	BR, IF EQUAL (OK)		
3351	054406	005237	002214	INC	FATFLG	ERROR COUNT		
3355	054412	104456		ERRHRD	ERRNO, T33RBP, EXPREC	READ BUS PARITY ERROR BIT NOT SET		
	054412	104456					TRAP	C1ERHRD
	054414	001006					.WORD	518
	054416	054724					.WORD	T33RBP
	054420	015554					.WORD	EXPREC
3356	054422	104406		2101:	CKLOOP	LOOP IF SELECTED		
	054422	104406					TRAP	C1CLP1
3357	054424	017701	126466	MOV	0FREE, R1	GET DATA READ		
3358	054430	013702	054720	MOV	T33CNU, R2	GET PATTERN		
3359	054434	020102		CMP	R1, R2	ARE THEY EQUAL		
3360	054436	001406		BEQ	2151	BR, IF OK		
3361	054440	005237	002214	INC	FATFLG	ERROR COUNT		
3365	054444	104456		ERRHRD	ERRNO, T33DTA, EXPREC	DATA NOT CORRECT		
	054444	104456					TRAP	C1ERHRD
	054446	001007					.WORD	519
	054450	055550					.WORD	T33DTA
	054452	015554					.WORD	EXPREC
3366	054454	104406		2151:	CKLOOP	LOOP IF SELECTED		
	054454	104406					TRAP	C1CLP1

3367 054456 010302
 3368 054460 012703 000001
 3369 054464 004737 010544
 3370 054470 010203
 3371 054472 005237 054720
 3372 054476 005303
 3373 054500 001402
 3374 054502 000137 054032
 3375 054506
 3376 054506
 3377 054510 023727 002214 000017
 3378 054516 103402
 3379 054520 004737 017262
 3380 054524
 3381
 3382
 3383
 3384 054524 004737 016536
 3385 054530 103002
 3386 054532 000137 053076
 3387 054536
 3388 054536 104432
 3389 054540 001300
 3390
 3392 054550
 3394 054550
 3395 054550 100004
 3396 054552 054560
 3397 054554 000000
 3398 054556 000012
 3399 054560
 3400 054560 054572
 3401 054562 000000
 3402 054564 000024
 3403 054566 000000
 3404 054570 000000
 3405 054572
 3406
 3407
 3408
 3410 054660
 3412 054660
 3413 054660 100006
 3414 054662 054700
 3415 054664 000000
 3416 054666 000006
 3417
 3421 054670
 3422 054670 100005
 3423 054672
 3424 054672 003116
 3425 054674 000000
 3426 054676 000000

220\$:
 ENDSUB
 999\$:
 230\$:
 T33PACKET:
 T33DATA:
 T33DSW:
 T33BFR:
 T33PK2:
 T33PK3:
 T33RB:
 T33WB:
 T33SZ:
 LOCAL STORAGE FOR THIS TEST
 .<.10>E177770
 .WORD 100004
 .WORD T33DATA
 .WORD 0
 .WORD 10.
 .WORD T33BFR
 .WORD 0
 .WORD 20.
 .WORD 0
 .WORD 0
 .WORD 0
 .BLKW 25.
 .<.10>E177770
 .WORD 100006
 .WORD T33BFR2
 .WORD 0
 .WORD 6.
 .WORD 100005
 .WORD FREE
 .WORD 0
 .WORD 0

SAVE R3 FOR A MOMENT
 SPACE FORWARD ONE RECORD
 CALL ROUTINE
 RESTORE R3
 BUMP TO NEXT RECORD NUMBER
 BUMP COUNTER
 BR, IF DONE
 BR, IF NOT DONE YET
 <<<<<<<<<< END SUBTEST >>>>>>>>>>>>>>>>>>>>>>
 L10060:
 TRAP C#ESUB
 IS ERROR COUNT AT 25
 BR, IF LESS THAN 25
 TRY TO DROP THE UNIT
 DO WE NEED TO ITERATE TEST
 BR, IF NO LOOP REQUIRED
 EXECUTE AGAIN
 ALL DONE THIS TEST
 TRAP C#EXIT
 .WORD L10057-.
 COMMAND PACKET FOR TEST
 WRITE CHARACTERISTICS COMMAND, WITH . ACK
 ADDRESS OF CHARACTERISTICS BLOCK
 STARTING VALUE OF BLOCK SIZE
 CHARACTERISTICS DATA BLOCK
 ADDRESS OF MESSAGE BUFFER
 LENGTH OF MESSAGE BUFFER
 SELECT DRIVE 0
 MESSAGE BUFFER
 WRITE SUB SYS MEM COMMAND, AND ACK
 ADDRESS OF SELECT BLOCK DATA
 SIZE OF DATA PACKET
 REREAD COMMAND, AND ACK
 ADDRESS OF WRITE BUFFER
 SIZE OF BUFFER (EXTENT)

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 5: DATA PARITY TEST

SEQ 160

```

3427                                     ,EVEN
3428                                     ;
3429                                     ;
3430                                     ;
3431 054700 T33BF2:
3432 054700     010 T33BS0: .BYTE 10 ;BSELO AREA
3433 054701     200 T33BS1: .BYTE 200 ;BSEL1 AREA
3434 054702 000000 T33S2: .WORD 0 ;SEL 2 AREA
3435 054704 000000 T33S3: .WORD 0 ;DATA AREA
3436                                     ;
3437                                     ;
3438                                     ,EVEN
3439 ;TAPE MOTION PACKET COMMAND VALUES
3440
3441 054706 100205 T33RN: .WORD 100205 ;REREAD DATA (NEXT)
3442 054710 100605 T33WDR: .WORD 100605 ;REREAD DATA RETRY
3443 054712 102205 T33CON: .WORD 102205 ;WRITE CONTINUOUS
3444 054714 177777 .WORD 177777 ;END OF DATA
3445
3446                                     ;
3447 054716 000000 T33CNT: .WORD 0 ;TAPE TIMER COUNTER STORAGE AREA
3448 054720 000000 T33CNU: .WORD 0 ;TAPE TIMER COUNTER STORAGE AREA
3449 054722 000000 T33DLY: .WORD 0 ;DELAY COUNTER
3450                                     ;*
3451 ;LOCAL TEXT MESSAGES FOR TEST
3452 ;-
3453
3454 054724     122     145     141 T33RBP: .ASCIZ 'Read Bus Parity Bit Not Set (XST1), Should Be'
3455 055002     124     123     123 T33WPW: .ASCIZ 'TSSR Incorrect After Wrong Parity Write Command'
3456 055062     125     116     103 T33UNC: .ASCIZ 'UNC Bit (XST1) Not Set After Wrong Parity WRITE Command'
3457 055152     125     116     103 T33UND: .ASCIZ 'UNC Bit (XST1) Not Set After Wrong Parity READ Command'
3458 055241     127     122     111 T33SSR: .ASCIZ 'WRITE MISCELLANEOUS CONT/READ COMMAND Not Accepted'
3459 055325     124     141     160 T33BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
3460 055420     122     145     167 T33RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
3461 055467     124     123     123 T33WDC: .ASCIZ 'TSSR Not Correct After READ Wrong Parity Command'
3462 055550     104     141     164 T33DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
3463 055645     104     141     164 TST33ID: .ASCIZ 'Data Parity'
3464                                     ,EVEN
3465                                     ;*
3466                                     ;
3467 ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
3468 ;WRITE SUBSYSTEM MEMORY COMMAND
3469 ;
3470 ;-
3471
3472 055662 T33REST:
3473 055662 SAVREG
3474 055666 012701 054550 MOV #T33PACKET,(R1) ;SAVE THE REGISTERS
3475 055672 012721 100004 MOV #100004,(R1)+ ;START OF THE PACKET
3476 055676 012721 054560 MOV #T33DATA,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK.
3477 055702 005021 CLR (R1)+ ;ADDRESS OF CHARAISTICS DATA BLOCK
3478 055704 012721 000012 MOV #10.,(R1)+ ;EXTENDED ADDRESS
3479 055710 012721 054572 MOV #T33BFR,(R1)+ ;SIZE OF DATA BLOCK IN BYTES
3480 055714 005021 CLR (R1)+ ;ADDRESS OF MESSAGE BUFFER
3481 055716 012721 000024 MOV #20.,(R1)+ ;LENGTH OF MESSAGE BUFFER
3482 055722 005021 CLR (R1)+
3483 055724 012711 000000 MOV #0,(R1) ;SELECT DRIVE ZERO

```



```

3484 055730 012702 000030      MOV      #24.,R2      ;NUMBER OF LOCATIONS TO BE CLEARED
3485 055734 012762 177777 054572 64$:  MOV      #177777,T33BFR(R2) ;ALL ONES TO MESSAGE BUFFER
3486 055742 005742      TST      -(R2)      ;NEXT LOCATION
3487 055744 022702 000000      CMP      #0,R2      ;AT END OF LOOP YET
3488 055750 001371      BNE      64$        ;KEEP GOING UNTIL DONE
3489 055752 000207      RTS      PC         ;RETURN
3490
3491 055754      T33RT2:
3492 055754      SAVREG      ;SAVE THE REGISTERS
3493 055760 012701 054660      MOV      #T33PK2,R1 ;START OF THE PACKET
3494 055764 012721 100006      MOV      #100006,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK,
3495 055770 012721 054700      MOV      #T33BF2,(R1)+ ;ADDRESS OF DATA BLOCK
3496 055774 005021      CLR      (R1)+      ;EXTENDED ADDRESS
3497 055776 012721 000006      MOV      #6.,(R1)+  ;SIZE OF DATA BLOCK IN BYTES
3498 056002 005021      CLR      (R1)+
3499 056004 012701 054700      MOV      #T33BF2,R1 ;POINT TO DATA SEL AREA
3500 056010 005021      CLR      (R1)+
3501 056012 005011      CLR      (R1)
3502 056014 000207      RTS      PC         ;RETURN
3503 056016      T33RT3:
3504 056016      SAVREG      ;SAVE REGISTERS
3505 056022 012701 054670      MOV      #T33PK3,R1 ;SET UP POINTER ADDRESS
3506 056026 005021      CLR      (R1)+      ;COMMAND SPACE
3507 056030 005021      CLR      (R1)+      ;ADDRESS OF DATA BLOCK
3508 056032 005021      CLR      (R1)+      ;EXTENDED ADDRESS
3509 056034 005011      CLR      (R1)      ;SIZE OF DATA TRANSFER BLOCK
3510 056036 000207      RTS      PC         ;RETURN
3511 056040      ENDTST
3512 056040 104401      L10057: TRAP      C$ETST
3513      .SBTTL TEST 6: OPERATIONS AT EOT
3514      ;+
3515      ; THIS TEST VERIFIES PROPER OPERATION OF THE WRITE DATA RETRY
3516      ; COMMAND (SPACE REVERSE, ERASE, WRITE DATA)
3517      ;
3518      ;
3519      ; THE TEST CONSISTS OF THE FOLLOWING 1 SUBTEST
3520      ;
3521      ;
3522      ;
3523      ;-
3524 056042      BGNTST
3525 056042      T6:;
3530 056050 012737 006354 002172      MOV      #EPRT1,EPRTSW ;PRIMARY ERROR MESSAGE
3531 056054 004737 016570      MOV      #TST34ID,R0 ;ASCII MESSAGE TO IDENTIFY TEST
3532 056060 012737 000005 002210      JSR      PC,TSTSETUP ;DO INITIAL TEST SETUP
3533 056066 005037 060672      MOV      #5,LOOPCNT ;PERFORM 5 ITERATIONS
3534      CLR      T34CNT ;CLEAR TAPE RECORD COUNTER
3535      ;+
3536      ; TEST 6, SUBTEST 1
3537      ;
3538      ;
3539      ; THIS TEST VERIFIES THAT THE EOT STATUS IS HANDLED PROPERLY BY
3540      ; THE VARIOUS TAPE MOTION COMMANDS. THE FOLLOWING TEST SEQUENCE
3541      ; IS PERFORMED:

```


3644	056234	004737	010742		JSR	PC,WRTCHR		;ISSUE WRITE CHARACTERISTICS
3645	056240	103407			BCS	30\$;BR, IF COMMAND ISSUED OK
3646	056242	005237	002214		INC	FATFLG		;ERROR COUNT
3650	056246	010001			MOV	R0,R1		;SAVE CONTENTS OF TSSR
3651	056250				ERRHRD	ERRNO,WRTMSG,SFIMSG		;WRITE CHARACTERISTIC FAILED
	056250	104456						TRAP C\$ERHRD
	056252	001132						.WORD 602
	056254	005052						.WORD WRTMSG
	056256	012114						.WORD SFIMSG
3652	056260			30\$:	CKLOOP			;LOOP IF SELECTED
	056260	104406						TRAP C\$CLP1
3653	056262	004737	011074		JSR	PC,REWIND		;REWIND CALL
3654	056266	103411			BCS	35\$;BR, IF TSSR IS OK (GOOD)
3655	056270	016501	000002		MOV	TSSR(R5),R1		;GET TSSR
3656	056274	010004			MOV	R0,R4		;SET UP PACKET
3657	056276	005237	002214		INC	FATFLG		;ERROR COUNT
3661	056302				ERRHRD	ERRNO,T34RWN,PKTSSR		;TSSR IS INCORRECT AFTER REWIND
	056302	104456						TRAP C\$ERHRD
	056304	001133						.WORD 603
	056306	062337						.WORD T34RWN
	056310	012126						.WORD PKTSSR
3662	056312			35\$:	CKLOOP			;LOOP IF SELECTED
	056312	104406						TRAP C\$CLP1
3663	056314	012737	140005	060660	MOV	#140005,T34PK3		;WRITE DATA, ACK, CVC=1
3664	056322	012703	176750		MOV	#65000.,R3		;SET MAX NUMBER OF WRITES
3665	056326	013737	003116	060662	MOV	FREE,T34WB		;SET UP WRITE BUFFER ADDRESS
3666	056334	012737	006654	060666	MOV	#3500.,T34SZ		;SET UP BUFFER SIZE (4K BYTES)
3667	056342	012704	060660		MOV	#T34PK3,R4		;R4 = POINTER TO PACKET
3668	056346	010465	000000		MOV	R4,TSD8(R5)		;ISSUE COMMAND
3669	056352	004737	016330	40\$:	JSR	PC,WAITF		;WAIT FOR SSR TO SET
3670	056356	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
3671	056362	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED
3672	056366	020102			CMP	R1,R2		;ARE THEY EQUAL
3673	056370	001010			BNE	50\$;BR, IT MIGHT BE END OF TAPE
3674	056372	005303			DEC	R3		;DEC RECORD COUNTER
3675	056374	001364			BNE	40\$;BR, IF MORE TO GO
3676	056376	005237	002214		INC	FATFLG		;ERROR COUNT
3680	056402				ERRDF	ERRNO,T34ET,PKTSSR		;EOT NOT FOUND (USE SHORTER TAPE?)
	056402	104455						TRAP C\$ERDF
	056404	001134						.WORD 604
	056406	062116						.WORD T34ET
	056410	012126						.WORD PKTSSR
3681	056412	032701	000004	50\$:	BIT	#BIT2,R1		;CHECK FOR TAPE STATUS ALERT
3682	056416	001001			BNE	60\$;BR, IF SET
3683	056420	000752			BR	40\$;KEEP GOING
3684	056422	013701	060570	60\$:	MOV	T34BFR+6,R1		;PICK UP XSTO
3685	056426	010102			MOV	R1,R2		;SET UP EXPECTED
3686	056430	052702	000001		BIS	#BIT0,R2		;SET THE EOT BIT ON IN EXPECTED
3687	056434	020102			CMP	R1,R2		;WAS THE BIT ON
3688	056436	001402			BEQ	80\$;BR, IF EOT WAS FOUND
3689	056440	000137	056346		JMP	40\$;KEEP LOOKING
3690	056444			80\$:	CKLOOP			;LOOP IF SELECTED
	056444	104406						TRAP C\$CLP1
3691	056446	012737	140005	060660	MOV	#140005,T34PK3		;WRITE DATA, ACK, CVC=1
3692	056454	013737	003116	060662	MOV	FREE,T34WB		;SET UP WRITE BUFFER ADDRESS
3693	056462	012737	006654	060666	MOV	#3500.,T34SZ		;SET UP BUFFER SIZE (4K BYTES)
3694	056470	012704	060660		MOV	#T34PK3,R4		;R4 = POINTER TO PACKET

3695	056474	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND
3696	056500	004737	016330		JSR	PC,WAITF		;WAIT FOR SSR TO SET
3697	056504	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
3698	056510	012702	100204		MOV	*SC!SSR!BIT2,R2		;SET UP EXPECTED
3699	056514	020102			CMP	R1,R2		;ARE THEY EQUAL
3700	056516	001406			BEQ	90\$;BR. IF THEY ARE OK
3701	056520	005237	002214		INC	FATFLG		;ERROR COUNT
3705	056524				ERRHRD	ERRNO,T34ET2,PKTSSR		;WRITE TAPE AT EOT FAILED TO SET TSA
	056524	104456					TRAP	C\$ERHRD
	056526	001135					.WORD	605
	056530	061367					.WORD	T34ET2
	056532	012126					.WORD	PKTSSR
3706	056534			90\$:	CKLOOP			;LOOP IF SELECTED
	056534	104406					TRAP	C\$CLP1
3707	056536	013701	060570		MOV	T34BFR+6,R1		;PICK UP XSTO
3708	056542	010102			MOV	R1,R2		;SET UP EXPECTED
3709	056544	052702	000001		BIS	*BIT0,R2		;SET THE EOT BIT ON IN EXPECTED
3710	056550	020102			CMP	R1,R2		;WAS THE BIT ON
3711	056552	001406			BEQ	100\$;BR. IF EOT WAS FOUND
3712	056554	005237	002214		INC	FATFLG		;ERROR COUNT
3716	056560				ERRHRD	ERRNO,T34ETN,EXPREC		;EOT BIT (XSTO) NOT SET
	056560	104456					TRAP	C\$ERHRD
	056562	001136					.WORD	606
	056564	061451					.WORD	T34ETN
	056566	015554					.WORD	EXPREC
3717	056570			100\$:	CKLOOP			;LOOP IF SELECTED
	056570	104406					TRAP	C\$CLP1
3718	056572	012737	140011	060660	MOV	*140011,T34PK3		;WRITE TAPE MARK, ACK, CVC=1 COMMAND
3719	056600	012704	060660		MOV	*T34PK3,R4		;R4 = POINTER TO PACKET
3720	056604	010465	000000		MOV	R4,TSDB(R5)		;ISSUE COMMAND
3721	056610	004737	016330		JSR	PC,WAITF		;WAIT FOR SSR TO SET
3722	056614	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS
3723	056620	012702	100204		MOV	*SC!SSR!BIT2,R2		;SET UP EXPECTED
3724	056624	020102			CMP	R1,R2		;ARE THEY EQUAL
3725	056626	001406			BEQ	110\$;BR. IF STATUS IS GOOD (OK)
3726	056630	005237	002214		INC	FATFLG		;ERROR COUNT
3730	056634				ERRHRD	ERRNO,T34WTM,PKTSSR		;EOT NOT FOUND (USE SHORTER TAPE?)
	056634	104456					TRAP	C\$ERHRD
	056636	001137					.WORD	607
	056640	061300					.WORD	T34WTM
	056642	012126					.WORD	PKTSSR
3731	056644			110\$:	CKLOOP			;LOOP IF SELECTED
	056644	104406					TRAP	C\$CLP1
3732	056646	013701	060570		MOV	T34BFR+6,R1		;PICK UP XSTO
3733	056652	010102			MOV	R1,R2		;SET UP EXPECTED
3734	056654	052702	000001		BIS	*BIT0,R2		;SET THE EOT BIT ON IN EXPECTED
3735	056660	020102			CMP	R1,R2		;WAS THE BIT ON
3736	056662	001406			BEQ	120\$;BR. IF EOT WAS FOUND
3737	056664	005237	002214		INC	FATFLG		;ERROR COUNT
3741	056670				ERRHRD	ERRNO,T34ETO,EXPREC		;EOT BIT (XSTO) NOT SET
	056670	104456					TRAP	C\$ERHRD
	056672	001140					.WORD	608
	056674	061002					.WORD	T34ETO
	056676	015554					.WORD	EXPREC
3742	056700			120\$:	CKLOOP			;LOOP IF SELECTED
	056700	104406					TRAP	C\$CLP1
3743	056702	012737	141410	060660	MOV	*141410,T34PK3		;SKIP TAPE MARK REVERSE ACK,CVC=1 COMMAND

3744	056710	012737	000001	060662	MOV	#1,T34WB	;SET NUMBER (1) OF TMS TO SKIP		
3745	056716	012704	060660		MOV	#T34PK3,R4	;R4 = POINTER TO PACKET		
3746	056722	010465	000000		MOV	R4,TSDB(R5)	;ISSUE COMMAND		
3747	056726	004737	016330		JSR	PC,WAITF	;WAIT FOR SSR TO SET		
3748	056732	016501	000002		MOV	TSSR(R5),R1	;GET TSSR CONTENTS		
3749	056736	012702	000200		MOV	#SSR,R2	;SET UP EXPECTED		
3750	056742	020102			CMP	R1,R2	;ARE THEY EQUAL		
3751	056744	001406			BEQ	130\$;BR, IF STATUS IS GOOD (OK)		
3752	056746	005237	002214		INC	FATFLG	;ERROR COUNT		
3756	056752				ERRHRD	ERRNO,T34STM,PKTSSR	;SKIP TAPE MARK REV. DIDN'T SET TSA		
	056752	104456					TRAP	C\$ERHRD	
	056754	001141					.WORD	609	
	056756	061700					.WORD	T34STM	
	056760	012126					.WORD	PKTSSR	
3757	056762			130\$:	CKLOOP		;LOOP IF SELECTED		
	056762	104406					TRAP	C\$CLP1	
3758	056764	013701	060570		MOV	T34BFR+6,R1	;PICK UP XSTO		
3759	056770	010102			MOV	R1,R2	;SET UP EXPECTED		
3760	056772	052702	000001		BIS	#BIT0,R2	;SET THE EOT BIT ON IN EXPECTED		
3761	056776	020102			CMP	R1,R2	;WAS THE BIT ON		
3762	057000	001406			BEQ	140\$;BR, IF EOT WAS FOUND		
3763	057002	005237	002214		INC	FATFLG	;ERROR COUNT		
3767	057006				ERRHRD	ERRNO,T34ETN,EXPREC	;EOT BIT (XSTO) NOT SET		
	057006	104456					TRAP	C\$ERHRD	
	057010	001142					.WORD	610	
	057012	061451					.WORD	T34ETN	
	057014	015554					.WORD	EXPREC	
3768	057016			140\$:	CKLOOP		;LOOP IF SELECTED		
	057016	104406					TRAP	C\$CLP1	
3769	057020	013701	060570		MOV	T34BFR+6,R1	;PICK UP XSTO		
3770	057024	010102			MOV	R1,R2	;SET UP EXPECTED		
3771	057026	052702	100000		BIS	#BIT15,R2	;SET THE TMK BIT ON IN EXPECTED		
3772	057032	020102			CMP	R1,R2	;WAS THE BIT ON		
3773	057034	001406			BEQ	150\$;BR, IF TMK WAS FOUND		
3774	057036	005237	002214		INC	FATFLG	;ERROR COUNT		
3778	057042				ERRHRD	ERRNO,T34TMK,EXPREC	;EOT BIT (XSTO) NOT SET		
	057042	104456					TRAP	C\$ERHRD	
	057044	001143					.WORD	611	
	057046	061763					.WORD	T34TMK	
	057050	015554					.WORD	EXPREC	
3779	057052			150\$:	CKLOOP		;LOOP IF SELECTED		
	057052	104406					TRAP	C\$CLP1	
3780	057054	012737	140410	060660	MOV	#140410,T34PK3	;SPACE RECORDS REVERSE, ACK, CVC=1 CMD		
3781	057062	012737	000001	060662	MOV	#1,T34WB	;SPACE ONE RECORD REVERSE		
3782	057070	012704	060660		MOV	#T34PK3,R4	;R4 = POINTER TO PACKET		
3783	057074	010465	000000		MOV	R4,TSDB(R5)	;ISSUE COMMAND		
3784	057100	004737	016330		JSR	PC,WAITF	;WAIT FOR SSR TO SET		
3785	057104	016501	000002		MOV	TSSR(R5),R1	;GET TSSR CONTENTS		
3786	057110	012702	100204		MOV	#SC!SSR!BIT2,R2	;SET UP EXPECTED		
3787	057114	020102			CMP	R1,R2	;ARE THEY EQUAL		
3788	057116	001006			BNE	160\$;BR, IT MIGHT BE END OF TAPE		
3789	057120	005237	002214		INC	FATFLG	;ERROR COUNT		
3793	057124				ERRHRD	ERRNO,T34POS,PKTSSR	;EOT NOT FOUND (USE SHORTER TAPE?)		
	057124	104456					TRAP	C\$ERHRD	
	057126	001144					.WORD	612	
	057130	060714					.WORD	T34POS	
	057132	012126					.WORD	PKTSSR	

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
TEST 6: OPERATIONS AT EOT

SEQ 167

```

3794 057134           160$: CKLOOP             ;LOOP IF SELECTED
      057134  104406                                  TRAP C$CLP1
3795 057136  013701  060570      MOV    T34BFR+6,R1        ;PICK UP XSTO
3796 057142  010102                MOV    R1,R2            ;SET UP EXPECTED
3797 057144  052702  000001      BIS    @BIT0,R2         ;SET THE EOT BIT ON IN EXPECTED
3798 057150  020102                CMP    R1,R2            ;WAS THE BIT ON
3799 057152  001406                BEQ    163$            ;BR, IF EOT WAS FOUND
3800 057154  005237  002214      INC    FATFLG          ;ERROR COUNT
3804 057160                ERRHRD  ERRNO,T34ETN,EXPREC ;EOT BIT (XSTO) NOT SET
      057160  104456                                  TRAP C$ERHRD
      057162  001145                                  .WORD 613
      057164  061451                                  .WORD T34ETN
      057166  015554                                  .WORD EXPREC

3805 057170           163$: CKLOOP             ;LOOP IF SELECTED
      057170  104406                                  TRAP C$CLP1
3806 057172  013701  060570      MOV    T34BFR+6,R1        ;PICK UP XSTO
3807 057176  010102                MOV    R1,R2            ;SET UP EXPECTED
3808 057200  042702  100000      BIC    @BIT15,R2        ;CLEAR THE TMK BIT ON IN EXPECTED
3809 057204  020102                CMP    R1,R2            ;WAS THE BIT ON
3810 057206  001406                BEQ    165$            ;BR, IF TMK WAS FOUND
3811 057210  005237  002214      INC    FATFLG          ;ERROR COUNT
3815 057214                ERRHRD  ERRNO,T34TMK,EXPREC ;EOT BIT (XSTO) NOT SET
      057214  104456                                  TRAP C$ERHRD
      057216  001146                                  .WORD 614
      057220  061763                                  .WORD T34TMK
      057222  015554                                  .WORD EXPREC

3816 057224           165$: CKLOOP             ;LOOP IF SELECTED
      057224  104406                                  TRAP C$CLP1
3817 057226  012737  140410  060660      MOV    @140410,T34PK3    ;SPACE RECORDS REVERSE, ACK, CVC=1 CMD
3818 057234  012737  000001  060662      MOV    @1,T34WB         ;SPACE ONE RECORD REVERSE
3819 057242  012704  060660      MOV    @T34PK3,R4       ;R4 = POINTER TO PACKET
3820 057246  010465  000000      MOV    R4,TSDB(R5)      ;ISSUE COMMAND
3821 057252  004737  016330      JSR    PC,WAITF         ;WAIT FOR SSR TO SET
3822 057256  016501  000002      MOV    TSSR(R5),R1      ;GET TSSR CONTENTS
3823 057262  012702  000200      MOV    @SSR,R2         ;SET UP EXPECTED
3824 057266  020102                CMP    R1,R2            ;ARE THEY EQUAL
3825 057270  001406                BEQ    167$            ;BR, IT MIGHT BE END OF TAPE
3826 057272  005237  002214      INC    FATFLG          ;ERROR COUNT
3830 057276                ERRHRD  ERRNO,T34POS,PKTSSR ;EOT NOT FOUND (USE SHORTER TAPE?)
      057276  104456                                  TRAP C$ERHRD
      057300  001147                                  .WORD 615
      057302  060714                                  .WORD T34POS
      057304  012126                                  .WORD PKTSSR

3831 057306           167$: CKLOOP             ;LOOP IF SELECTED
      057306  104406                                  TRAP C$CLP1
3832 057310  013701  060570      MOV    T34BFR+6,R1        ;PICK UP XSTO
3833 057314  010102                MOV    R1,R2            ;SET UP EXPECTED
3834 057316  042702  000001      BIC    @BIT0,R2         ;CLEAR THE EOT BIT ON IN EXPECTED
3835 057322  020102                CMP    R1,R2            ;WAS THE BIT OFF
3836 057324  001406                BEQ    170$            ;BR, IF EOT WAS FOUND
3837 057326                CKLOOP             ;LOOP IF SELECTED
      057326  104406                                  TRAP C$CLP1
3838 057330  012737  100010  060660      MOV    @140010,T34PK3    ;SPACE RECORDS FORWARD, ACK, CVC=1
3839 057336  012737  000002  060662      MOV    @2,T34WB         ;SPACE TWO RECORDS
3840 057344  012704  060660      MOV    @T34PK3,R4       ;R4 = POINTER TO PACKET
3841 057350  010465  000000      MOV    R4,TSDB(R5)      ;ISSUE COMMAND
3842 057354  004737  016330      JSR    PC,WAITF         ;WAIT FOR SSR TO SET

```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 6: OPERATIONS AT EOT

SEQ 168

3843	057360	016501	000002		MOV	TSSR(R5),R1				;GET TSSR CONTENTS
3844	057364	012702	000200		MOV	*SSR,R2				;SET UP EXPECTED
3845	057370	020102			CMP	R1,R2				;ARE THEY EQUAL
3846	057372	001406			BEQ	190\$;BR, IT MIGHT BE END OF TAPE
3847	057374	005237	002214		INC	FATFLG				;ERROR COUNT
3851	057400				ERRHRD	ERRNO,T34POS,PKTSSR				;EOT NOT FOUND (USE SHORTER TAPE?)
	057400	104456							TRAP	C\$ERHRD
	057402	001150							.WORD	616
	057404	060714							.WORD	T34POS
	057406	012126							.WORD	PKTSSR
3852	057410			190\$:	CKLOOP					;LOOP IF SELECTED
	057410	104406							TRAP	C\$CLP1
3853	057412	013701	060570		MOV	T34BFR+6,R1				;PICK UP XSTO
3854	057416	010102			MOV	R1,R2				;SET UP EXPECTED
3855	057420	052702	000001		BIS	*BIT0,R2				;SET THE EOT BIT ON IN EXPECTED
3856	057424	020102			CMP	R1,R2				;WAS THE BIT ON
3857	057426	001406			BEQ	200\$;BR, IF EOT WAS FOUND
3858	057430	005237	002214		INC	FATFLG				;ERROR COUNT
3862	057434				ERRHRD	ERRNO,T34ETS,EXPREC				;EOT BIT (XSTO) NOT SET
	057434	104456							TRAP	C\$ERHRD
	057436	001151							.WORD	617
	057440	061530							.WORD	T34ETS
	057442	015554							.WORD	EXPREC
3863	057444			200\$:	CKLOOP					;LOOP IF SELECTED
	057444	104406							TRAP	C\$CLP1
3864	057446	012737	140401	060660	MOV	*140401,T34PK3				;READ REVERSE, ACK, CVC=1
3865	057454	013737	003116	060662	MOV	FREE,T34RB				;SET UP WRITE BUFFER ADDRESS
3866	057462	012704	060660		MOV	*T34PK3,R4				;R4 = POINTER TO PACKET
3867	057466	010465	000000		MOV	R4,T34DB(R5)				;ISSUE COMMAND
3868	057472	004737	016330		JSR	PC,WAITF				;WAIT FOR SSR TO SET
3869	057476	016501	000002		MOV	TSSR(R5),R1				;GET TSSR CONTENTS
3870	057502	012702	000200		MOV	*SSR,R2				;SET UP EXPECTED
3871	057506	020102			CMP	R1,R2				;ARE THEY EQUAL
3872	057510	001406			BEQ	205\$;BR, ONLY SSR IS SET
3873	057512	005237	002214		INC	FATFLG				;ERROR COUNT
3877	057516				ERRHRD	ERRNO,T34RRE,PKTSSR				;EOT NOT FOUND (USE SHORTER TAPE?)
	057516	104456							TRAP	C\$ERHRD
	057520	001152							.WORD	618
	057522	061066							.WORD	T34RRE
	057524	012126							.WORD	PKTSSR
3878	057526			205\$:	CKLOOP					;LOOP IF SELECTED
	057526	104406							TRAP	C\$CLP1
3879	057530	012737	140401	060660	MOV	*140401,T34PK3				;READ REVERSE, ACK, CVC=1
3880	057536	013737	003116	060662	MOV	FREE,T34RB				;SET UP WRITE BUFFER ADDRESS
3881	057544	012704	060660		MOV	*T34PK3,R4				;R4 = POINTER TO PACKET
3882	057550	010465	000000		MOV	R4,T34DB(R5)				;ISSUE COMMAND
3883	057554	004737	016330		JSR	PC,WAITF				;WAIT FOR SSR TO SET
3884	057560	016501	000002		MOV	TSSR(R5),R1				;GET TSSR CONTENTS
3885	057564	012702	000200		MOV	*SSR,R2				;SET UP EXPECTED
3886	057570	020102			CMP	R1,R2				;ARE THEY EQUAL
3887	057572	001406			BEQ	210\$;BR, IT MIGHT BE END OF TAPE
3888	057574	005237	002214		INC	FATFLG				;ERROR COUNT
3892	057600				ERRHRD	ERRNO,T34RRE,PKTSSR				;EOT NOT FOUND (USE SHORTER TAPE?)
	057600	104456							TRAP	C\$ERHRD
	057602	001153							.WORD	619
	057604	061066							.WORD	T34RRE
	057606	012126							.WORD	PKTSSR

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
TEST 6: OPERATIONS AT EOT

SEQ 169

```

3893 057610           210$: CKLOOP           ;LOOP IF SELECTED
      057610 104406                               TRAP      C$CLP1
3894 057612 012737 140001 060660  MOV     #140001,T34PK3   ;READ DATA, ACK, CVC=1
3895 057620 013737 003116 060662  MOV     FREE,T34RB      ;SET UP WRITE BUFFER ADDRESS
3896 057626 012737 006654 060666  MOV     #3500.,T34SZ    ;SET UP BUFFER SIZE (4K BYTES)
3897 057634 012704 060660           MOV     #T34PK3,R4      ;R4 = POINTER TO PACKET
3898 057640 010465 000000           MOV     R4,TSDB(R5)     ;ISSUE COMMAND
3899 057644 004737 016330           JSR     PC,WAITF        ;WAIT FOR SSR TO SET
3900 057650 016501 000002           MOV     TSSR(R5),R1     ;GET TSSR CONTENTS
3901 057654 012702 000200           MOV     #SSR,R2         ;SET UP EXPECTED
3902 057660 020102           CMP     R1,R2           ;ARE THEY EQUAL
3903 057662 001406           BEQ     230$           ;BR, IT MIGHT BE END OF TAPE
3904 057664 005237 002214           INC     FATFLG          ;ERROR COUNT
3908 057670           ERRHRD  ERRNO,T34RRE,PKTSSR ;EOT NOT FOUND (USE SHORTER TAPE?)
      057670 104456                               TRAP      C$ERHRD
      057672 001154                               .WORD    620
      057674 061066                               .WORD    T34RRE
      057676 012126                               .WORD    PKTSSR
3909 057700           230$: CKLOOP           ;LOOP IF SELECTED
      057700 104406                               TRAP      C$CLP1
3910 057702 012737 140001 060660  MOV     #140001,T34PK3   ;READ DATA, ACK, CVC=1
3911 057710 013737 003116 060662  MOV     FREE,T34RB      ;SET UP WRITE BUFFER ADDRESS
3912 057716 012737 006654 060666  MOV     #3500.,T34SZ    ;SET UP BUFFER SIZE (4K BYTES)
3913 057724 012704 060660           MOV     #T34PK3,R4      ;R4 = POINTER TO PACKET
3914 057730 010465 000000           MOV     R4,TSDB(R5)     ;ISSUE COMMAND
3915 057734 004737 016330           JSR     PC,WAITF        ;WAIT FOR SSR TO SET
3916 057740 016501 000002           MOV     TSSR(R5),R1     ;GET TSSR CONTENTS
3917 057744 012702 000200           MOV     #SSR,R2         ;SET UP EXPECTED
3918 057750 020102           CMP     R1,R2           ;ARE THEY EQUAL
3919 057752 001406           BEQ     235$           ;BR, IT MIGHT BE END OF TAPE
3920 057754 005237 002214           INC     FATFLG          ;ERROR COUNT
3924 057760           ERRHRD  ERRNO,T34RRE,PKTSSR ;EOT NOT FOUND (USE SHORTER TAPE?)
      057760 104456                               TRAP      C$ERHRD
      057762 001155                               .WORD    621
      057764 061066                               .WORD    T34RRE
      057766 012126                               .WORD    PKTSSR
3925 057770           235$: CKLOOP           ;LOOP IF SELECTED
      057770 104406                               TRAP      C$CLP1
3926 057772 013701 060570           MOV     T34BFR+6,R1     ;PICK UP XSTO
3927 057776 010102           MOV     R1,R2           ;SET UP EXPECTED
3928 060000 052702 000001           BIS     #BIT0,R2        ;SET THE EOT BIT ON IN EXPECTED
3929 060004 020102           CMP     R1,R2           ;WAS THE BIT ON
3930 060006 001406           BEQ     240$           ;BR, IF EOT WAS FOUND
3931 060010 005237 002214           INC     FATFLG          ;ERROR COUNT
3935 060014           ERRHRD  ERRNO,T34ETZ,EXPREC ;EOT BIT (XSTO) NOT SET
      060014 104456                               TRAP      C$ERHRD
      060016 001156                               .WORD    622
      060020 061622                               .WORD    T34ETZ
      060022 015554                               .WORD    EXPREC
3935 060024           240$: CKLOOP           ;LOOP IF SELECTED
      060024 104406                               TRAP      C$CLP1
3937 060026 012737 140410 060660  MOV     #140410,T34PK3   ;SPACE RECORDS REVERSE, ACK, CVC=1 CMD.
3938 060034 012737 000005 060662  MOV     #5,T34RB        ;NUMBER OF RECORDS TO SPACE
3939 060042 012704 060660           MOV     #T34PK3,R4      ;R4 = POINTER TO PACKET
3940 060046 010465 000000           MOV     R4,TSDB(R5)     ;ISSUE COMMAND
3941 060052 004737 016330           JSR     PC,WAITF        ;WAIT FOR SSR TO SET
3942 060056 016501 000002           MOV     TSSR(R5),R1     ;GET TSSR CONTENTS

```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 6: OPERATIONS AT EOT

SEQ 170

Address	Instruction	Comments	Labels	Other
3943	060062	012702	000200	
3944	060066	020102		
3945	060070	001406		
3946	060072	005237	002214	
3950	060076	104456		
	060100	001157		
	060102	060714		
	060104	012126		
3951	060106		2501:	CKLOOP
	060106	104406		
3952	060110	013701	060570	
3953	060114	010102		
3954	060116	042702	000001	
3955	060122	020102		
3956	060124	001406		
3957	060126	005237	002214	
3961	060132			
	060132	104456		
	060134	001160		
	060136	061157		
	060140	015554		
3962	060142		2601:	CKLOOP
	060142	104406		
3963	060144	012737	140010	060660
3964	060152	012737	000003	060662
3965	060160	012704	060660	
3966	060164	010465	000000	
3967	060170	004737	016330	
3968	060174	016501	000002	
3969	060200	012702	000200	
3970	060204	020102		
3971	060206	001406		
3972	060210	005237	002214	
3976	060214			
	060214	104456		
	060216	001161		
	060220	062116		
	060222	012126		
3977	060224		2701:	CKLOOP
	060224	104406		
3978	060226	013701	060570	
3979	060232	010102		
3980	060234	052702	000001	
3981	060240	020102		
3982	060242	001406		
3983	060244			
	060244	104406		
3984	060246	012737	141410	060660
3985	060254	012737	000003	060662
3986	060262	012704	060660	
3987	060266	010465	000000	
3988	060272	012737	176750	060674
3989	060300	004737	016330	
3990	060304	016501	000002	
3991	060310	032701	000200	
3992	060314	001017		

TEST 1: HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB 84 18:04
 TEST 6: OPERATIONS AT EOT

SEQ 171

3993	060316		DELAY	250			WAIT ABOUT .25 SECONDS
	060316	012727		000250			MOV #250,(PC)+
	060322	000000					.WORD 0
	060324	013727		002116			MOV L#DLY,(PC)+
	060330	000000					.WORD 0
	060332	005367		177772			DEC -6(PC)
	060336	001375					BNE .-4
	060340	005367		177756			DEC -22(PC)
	060344	001367					BNE .-20
3994	060346	005337		060674			BUMP COUNTER
3995	060352	001352					BR, IF MORE TO COUNT
3996	060354	012702	286:	000200			SET UP EXPECTED
3997	060360	020102					ARE THEY EQUAL
3998	060362	001007					BR, IT MIGHT BE END OF TAPE
3999	060364	005303					DEC RECORD COUNTER
4000	060366	005237		002214			ERROR COUNT
4004	060372						EOT NOT FOUND (USE SHORTER TAPE?)
	060372	104456					TRAP C#ERRRD
	060374	001162					.WORD 626
	060376	062116					.WORD T34ET
	060400	012126					.WORD PKTSSR
4005	060402	032701	290:	000004			CHECK FOR TAPE STATUS ALERT
4006	060406	013701		060570			PICK UP XSTO
4007	060412	010102					SET UP EXPECTED
4008	060414	042702		000001			CLEAR THE EOT BIT IN EXPECTED
4009	060420	020102					WAS THE BIT ON
4010	060422	001406					BR, IF EOT WAS FOUND
4011	060424	005237		002214			ERROR COUNT
4015	060430						EOT BIT (XSTO) NOT CLEAR
	060430	104456					TRAP C#ERRRD
	060432	001163					.WORD 627
	060434	061157					.WORD T34ETC
	060436	015554					.WORD EXPREC
4016	060440		300:				LOOP IF SELECTED
	060440	104406					TRAP C#CLP1
4017	060442	013701		060570			PICK UP XSTO
4018	060446	010102					SET UP EXPECTED
4019	060450	052702		000002			SET THE BOT BIT ON IN EXPECTED
4020	060454	020102					WAS THE BIT ON
4021	060456	001406					BR, IF BOT WAS FOUND
4022	060460	005237		002214			ERROR COUNT
4026	060464						EOT BIT (XSTO) NOT CLEAR
	060464	104456					TRAP C#ERRRD
	060466	001164					.WORD 628
	060470	061234					.WORD T34BOT
	060472	015554					.WORD EXPREC
4027	060474		320:				LOOP IF SELECTED
	060474	104406					TRAP C#CLP1
4028	060476		600:				
4029	060476						ENDSUB
	060476						***** END SUBTEST *****
	060476	104403					L10062:
4030	060500	023727		002214	000017		TRAP C#ESUB
4031	060506	103402					IS ERROR COUNT AT 25
4032	060510	004737		017262			BR, IF LESS THAN 25
4033	060514		999:				TRY TO DROP THE UNIT
4034	060514	004737		016536			DO WE NEED TO ITERATE TEST

4035	060520	103002		DCC	1634				
4036	060522	000137	056072	JMP	T34LOOP				
4037	060526			1634:	EXIT	TST			
	060526	104432							
	060530	002662							TRAP CEXIT .WORD L10061.
4038									
4039									
4040									
4041		060540							
4044	060540			T34PACKET:					
4045	060540	100004			.WORD	100004			
4046	060542	060550			.WORD	T34DATA			
4047	060544	000000			.WORD	0			
4048	060546	000010			.WORD	8.			
4049	060550			T34DATA:					
4050	060550	060562			.WORD	T34BFR			
4051	060552	000000			.WORD	0			
4052	060554	000012			.WORD	10.			
4053	060556	000000			.WORD	0			
4054	060560	000000		T34DSW:	.WORD	0			
4055	060562			T34BFR:	.BLKW	25.			
4056									
4057									
4058									
4060		060650							
4062	060650			T34PK2:					
4063	060650	100006			.WORD	100006			
4064	060652	060676			.WORD	T34BF2			
4065	060654	000000			.WORD	0			
4066	060656	000006			.WORD	6.			
4067									
4071	060660			T34PK3:					
4072	060660	100005			.WORD	100005			
4073	060662			T34RB:					
4074	060662	000000		T34WB:	.WORD	0			
4075	060664	000000			.WORD	0			
4076	060666	000000		T34SZ:	.WORD	0			
4077					.EVEN				
4078									
4079	060670	000000		T34RSZ:	.WORD	0			
4080	060672	000000		T34CNT:	.WORD	0			
4081	060674	000000		T34DLY:	.WORD	0			
4082									
4083									
4084	060676			T34BF2:					
4085	060676	010		T34BS0:	.BYTE	10			
4086	060677	200		T34BS1:	.BYTE	200			
4087	060700	000000		T34S2:	.WORD	0			
4088	060702	000000		T34S3:	.WORD	0			
4089									
4090									
4091									
4092									
4093									
4094	060704	100005		T34WD:	.WORD	100005			
4095	060706	100405		T34WR:	.WORD	100405			
4096	060710	102005		T34CUN:	.WORD	102005			

```

;BR, IF NO LOOP REQUIRED
;EXECUTE AGAIN
;ALL DONE THIS TEST

;COMMAND PACKET FOR TEST
;WRITE CHARACTERISTICS COMMAND, WITH ACK
;ADDRESS OF CHARACTERISTICS BLOCK

;STARTING VALUE OF BLOCK SIZE
;CHARACTERISTICS DATA BLOCK
;ADDRESS OF MESSAGE BUFFER

;LENGTH OF MESSAGE BUFFER

;SELECT DRIVE 0
;MESSAGE BUFFER

;WRITE SUBSYSTEM MEMORY COMMAND PACKET

;WRITE SUB SYS MEM COMMAND, AND ACK
;ADDRESS OF SELECT BLOCK DATA

;SIZE OF DATA PACKET

;WRITE COMMAND, AND ACK
;ADDRESS OF WRITE/READ BUFFER

;SIZE OF BUFFER (EXTENT)

;LARGEST TAPE RECORD IN BYTES
;TAPE RECORD COUNTER
;DELAY COUNTER

;BSELO AREA
;BSEL1 AREA
;SEL 2 AREA
;DATA AREA

;WRITE DATA (NEXT)
;WRITE DATA RETRY
;WRITE CONTINUOUS
    
```

TEST 1 : HARDWARE TEST 1.8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 6: OPERATIONS AT EOT

SEQ 173

```

4097 060712 177777          .WORD 177777          ;END OF DATA
4098
4099          ;LOCAL TEXT MESSAGES FOR TEST
4100
4101
4102 060714 124 123 123 T34POS: .ASCIZ 'TSSR Incorrect After Position (SPACE RECORDS) Command'
4103 061002 127 122 111 T34ETO: .ASCIZ 'WRITE TAPE MARK At EOT Failed To Set EOT Bit (XSTO)'
4104 061066 122 105 101 T34RRE: .ASCIZ 'READ Command At EOT Didn't Give Normal Termination (TSSR)'
4105 061157 125 156 141 T34ETC: .ASCIZ 'Unable To Clear EOT Indication, (XSTO) Bit 0'
4106 061234 122 105 127 T34BOT: .ASCIZ 'REWIND Failed To Set BOT (XSTO) Bit'
4107 061300 127 122 111 T34WTM: .ASCIZ 'WRITE TAPE MARK At EOT Failed To Set Tape Status Alert'
4108 061367 127 122 111 T34ET2: .ASCIZ 'WRITE DATA At EOT Failed To Set Tape Status Alert'
4109 061451 127 122 111 T34ETN: .ASCIZ 'WRITE DATA At EOT Failed To Set EOT Bit (XSTO)'
4110 061530 123 120 101 T34ETS: .ASCIZ 'SPACE RECORDS FORWARD At EOT Failed To Set EOT Bit (XSTO)'
4111 061622 122 105 101 T34ETZ: .ASCIZ 'READ DATA At EOT Failed To Set EOT Bit (XSTO)'
4112 061700 124 123 123 T34STM: .ASCIZ 'TSSR Incorrect After SKIP TAPE MARK REVERSE At EOT'
4113 061763 120 117 123 T34TMK: .ASCIZ 'POSITION Command At EOT Onto Tape Mark Failed To Set TMK (XSTO)'
4114 062063 127 122 111 T34SSR: .ASCIZ 'WRITE Command Not Accepted'
4115 062116 105 117 124 T34ET: .ASCIZ 'EOT Not Found In 65000 3.5K Writes, (Use Shorter Tape)'
4116 062205 127 122 111 T34EOT: .ASCIZ 'WRITE DATA OVER EOT GAVE NO TAPE STATUS ALERT'
4117 062263 124 123 123 T34TM: .ASCIZ 'TSSR Not Correct After WRITE Command Reject'
4118 062337 122 145 167 T34RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
4119 062406 122 101 115 T34RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
4120 062461 124 123 123 T34AM3: .ASCIZ 'TSSR Init. Failed After WRITE Command'
4121 062527 104 162 151 T34OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
4122 062602 124 123 123 T34WDD: .ASCIZ 'TSSR Not Correct After WRITE DATA Command, SWB Bit Set'
4123 062671 124 123 123 T34WDC: .ASCIZ 'TSSR Not Correct After WRITE DATA Command, Check For Tape Offline'
4124 062773 103 126 103 T34VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
4125 063046 124 123 102 T34BA: .ASCIZ 'TSBA Not Correct After WRITE DATA Command'
4126 063120 127 122 111 T34WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
4127 063207 117 160 145 TST34ID: .ASCIZ 'Operations At EOT'
4128          .EVEN
4129
4130          ;
4131          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
4132          ;WRITE SUBSYSTEM MEMORY COMMAND
4133          ;
4134          ;
4135
4136 063232          T34REST:
4137 063232          SAVREG          ;SAVE THE REGISTERS
4138 063236 012701 060540 MOV          #T34PACKET,R1          ;START OF THE PACKET
4139 063242 012721 100004 MOV          #100004,(R1)+          ;WRITE SUBSYSTEM MEM. WITH ACK
4140 063246 012721 060550 MOV          #T34DATA,(R1)+          ;ADDRESS OF CHARACTERISTICS DATA BLOCK
4141 063252 005021          CLR          (R1)+          ;EXTENDED ADDRESS
4142 063254 012721 000012 MOV          #10.,(R1)+          ;SIZE OF DATA BLOCK IN BYTES
4143 063260 012721 060562 MOV          #T34BFR,(R1)+          ;ADDRESS OF MESSAGE BUFFER
4144 063264 005021          CLR          (R1)+          ;
4145 063266 012721 000024 MOV          #20.,(R1)+          ;LENGTH OF MESSAGE BUFFER
4146 063272 005021          CLR          (R1)+          ;
4147 063274 012711 000000 MOV          #0,(R1)          ;SELECT DRIVE ZERO
4148 063300 012702 000030 MOV          #24.,R2          ;NUMBER OF LOCATIONS TO BE CLEARED
4149 063304 012762 177777 060562 64$ MOV          #177777,T34BFR(R2)          ;ALL ONES TO MESSAGE BUFFER
4150 063312 005742          TST          (R2)          ;BUMP DOWN TO NEXT LOCATION
4151 063314 020227 000000 CMP          R2,#0          ;R2 AT ZERO YET
4152 063320 001371          BNE          64$          ;KEEP GOING UNTIL DONE
4153 063322 000207          RTS          PC          ;RETURN

```


TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 7: EXTENDED MODE FEATURES

SEQ 175

```

4212 ; IMMEDIATE TERMINATION BUT NO INTERRUPT. STATUS IN THE MESSAGE
4213 ; BUFFER IS CHECKED TO VERIFY THAT THE MOTION (MOT) AND OPERATION
4214 ; IN PROGRESS (OPM) STATUS BITS ARE BOTH SET.
4215 ;
4216 ;
4217 ;
4218 ;
4219 ;
4220 ;
4221 ;
4222 063444 T35LOOP:
4223 063444 BGNSUB ;>>>>>>>>>> BEGIN SUBTEST >>>>>>>>>
    063444 ; T7.1:
4224 063444 104402 ; TRAP C$BSUB
4225 063446 004737 073164 JSR PC,T35REST ;SET COMMAND PACKET
4226 063452 005037 002216 CLR INTRECV ;CLEAR INTERRUPT RECEIVED FLAG
4227 063456 004737 073256 JSR PC,T35RT2 ;SET UP OTHER COMMAND PACKET
4228 063462 004737 073320 JSR PC,T35RT3 ;SET UP OTHER COMMAND PACKET
4229 063466 012737 176750 067542 MOV #65000.,T35DLY ;SET UP DELAY COUNTER
4230 063474 005037 067536 CLR T35CNT ;CLEAR COUNTER
4231 063500 004737 016054 10$: JSR PC,SOFINIT ;DO INITIALIZE ON CONTROLLER
4232 063506 103426 BCS 20$ ;BR IF INIT WAS OK
    063506 DELAY 250 ;DELAY ABOUT .25 SEC
    063506 012727 000250 MOV #250,(PC)+
    063512 000000 .WORD 0
    063514 013727 002116 MOV L$DLY,(PC)+
    063520 000000 .WORD 0
    063522 005367 177772 DEC -6(PC)
    063526 001375 BNE -.4
    063530 005367 177756 DEC -22(PC)
    063534 001367 BNE .-20
4233 063536 005337 067542 DEC T35DLY ;BUMP COUNTER
4234 063542 001356 BNE 10$ ;BR, IF COUNTER NOT DONE
4235 063544 005237 002214 INC FATFLG ;ERROR COUNT
4239 063550 010001 MOV RO,R1 ;CONTENTS OF TSSR REGISTER
4240 063552 ERRDF ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
    063552 104455 TRAP C$ERRDF
    063554 001275 .WORD 701
    063556 003646 .WORD SFIERR
    063560 012114 .WORD SFIMSG
4241 063562 013737 002174 067410 20$: MOV UNITN,T35DSW ;SET UP DRIVE NUMBER
4242 063570 012704 067370 MOV #T35PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
4243 063574 004737 010742 JSR PC,WRTCHR ;ISSUE WRITE CHARACTERISTICS
4244 063600 103407 BCS 25$ ;BR, IF COMMAND ISSUED OK
4245 063602 005237 002214 INC FATFLG ;ERROR COUNT
4249 063606 010001 MOV RO,R1 ;SAVE CONTENTS OF TSSR
4250 063610 ERRHRD ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
    063610 104456 TRAP C$ERRHRD
    063612 001276 .WORD 702
    063614 005052 .WORD WRTMSG
    063616 012114 .WORD SFIMSG
4251 063620 25$: CKLOOP ;LOOP IF SELECTED
    063620 104406 TRAP C$CLP1
4252 063622 004737 011074 JSR PC,R1 NO ;CALL TAPE REWIND COMMAND
4253 063626 103411 BCS 30$ ;BR, IF NO PROBLEM
4254 063630 010004 MOV RO,R4 ;SET UP REWIND PACKET ADDRESS
4255 063632 016501 000002 MOV TSSR(R5),

```

```

4256 063636 005237 002214          INC    FATFLG          ;ERROR COUNT
4260 063642          ERRHRD  ERRNO,T35RWN,PKTSSR ;REWIND NOT ACCEPTED
      063642 104456          TRAP   C$ERHRD
      063644 001277          .WORD  703
      063646 070644          .WORD  T35RWN
      063650 012126          .WORD  PKTSSR
4261 063652          30$:  CKLOOP          ;LOOP IF SELECTED          TRAP   C$CLP1
      063652 104406          MOV    T35BFR+6,R1      ;PICK UP XSTO
4262 063654 013701 067420          MOV    R1,R2           ;SET UP EXPECTED
4263 063660 010102          BIS    #BIT1,R2        ;SET BOT BIT IN EXPECTED
4264 063662 052702 000002          CMP    R1,R2           ;DOES EXP = REC'D
4265 063666 020102          BEQ    40$             ;BR, IF EQUAL (OK)
4266 063670 001406          INC    FATFLG          ;ERROR COUNT
4267 063672 005237 002214          ERRHRD  ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
4271 063676          104456          TRAP   C$ERHRD
      063700 001300          .WORD  704
      063702 070340          .WORD  T35BOT
      063704 015554          .WORD  EXPREC
4272 063706          40$:  CKLOOP          ;LOOP IF SELECTED          TRAP   C$CLP1
      063706 104406          MOV    #20.,R3         ;NUMBER OF RECORDS
4273 063710 012703 000024          MOV    #256.,T35SZ     ;SET UP RECORD SIZE
4274 063714 012737 000400 067516          MOV    FREE,T35WB      ;ADDRESS OF WRITE BUFFER
4275 063722 013737 003116 067512
4276
4277          ;*****
4278          ;
4279          ;WRITE DATA,ACK,CVC-1 COMMAND
4280          ;
4281          ;*****
4282
4283 063730 012737 140005 067510          MOV    #140005,T35PK3  ;WRITE DATA,ACK,CVC-1 COMMAND
4284 063736 012704 067510          MOV    #T35PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
4285 06374 010465 000000          50$:  MOV    R4,T35DB(R5) ;ISSUE COMMAND
4286 063746 004737 016330          JSR    PC,WAITF        ;WAIT FOR SSR TO SET
4287 063752 016501 000002          MOV    T35SR(R5),R1   ;GET T35SR CONTENTS
4288 063756 012702 000200          MOV    #SSR,R2        ;SET UP EXPECTED
4289 063762 020102          CMP    R1,R2          ;ARE THEY EQUAL
4290 063764 001406          BEQ    60$             ;BR, IF OK
4291 063766 005237 002214          INC    FATFLG          ;ERROR COUNT
4295 063772          ERRHRD  ERRNO,T35WDE,PKTSSR ;T35SR INCORRECT AFTER WRITE DATA
      063772 104456          TRAP   C$ERHRD
      063774 001301          .WORD  705
      063776 070266          .WORD  T35WDE
      064000 012126          .WORD  PKTSSR
4296 064002          60$:  CKLOOP          ;LOOP IF SELECTED          TRAP   C$CLP1
      064002 104406          DEC    R3              ;BUMP RECORD COUNTER
4297 064004 005303          BNE    50$            ;BR, IF MORE RRECORDS TO COUNT
4298 064006 001355
4299
4300          ;*****
4301          ;
4302          ;WAIT FOR TAPE TO STOP ALL MOTION
4303          ;
4304          ;*****
4305
4306 064010 012737 000012 067542          MOV    #10.,T35DLY    ;SET UP DELAY COUNTER
    
```



```

4307 064016          70$:  DELAY  250          ;WAIT ABOUT .25 SEC
      064016 012727 000250          MOV      #250,(PC)+
      064022 000000          .WORD   0
      064024 013727 002116          MOV      L#DLY,(PC)+
      064030 000000          .WORD   0
      064032 005367 177772          DEC      -6(PC)
      064036 001375          BNE     .-4
      064040 005367 177756          DEC      -22(PC)
      064044 001367          BNE     .-20
4308 064046 005337 067542          DEC      T35DLY          ;BUMP COUNTER DOWN
4309 064052 001361          BNE     70$             ;BR, IF MORE TO DELAY
4310 064054 005737 002220          TST     EXTFEA         ;CHECK FOR EXTENDED FEATURES SW SWITCH
4311 064060 001042          BNE     110$           ;BR IF SWITCH IS ON
4312 064062 112737 000200 067521  MOVB    #200,T35BS1     ;WRITE MISCELLANEOUS CONT/READ STATUS
4313 064070 112737 000010 067520  MOVB    #10,T35BS0     ;FUNCTION SELECTION BIT (TURN ON EXTFEA HW SWITCH)
4314 064076 012704 067500          MOV     #T35PK2,R4     ;WRITE SUBSYS MEM PACKET
4315 064102 010465 000000          MOV     R4,TSDB(R5)    ;ISSUE COMMAND
4316 064106 004737 016416          JSR    PC,CHKTSSR     ;WAIT FOR SSR
4317 064112 103407          BCS    90$             ;BR, IF NO ERROR
4318 064114 010001          MOV     R0,R1         ;ERROR, SAVE TSSR
4319 064116 005237 002214          INC     FATFLG        ;ERROR COUNT
4323 064122          ERRHRD  ERRNO,T35SSR,PKTSSR ;TSSR NOT CORRECT AFTER WRT. MISCELLANEOUS
      064122 104456          TRAP   C#ERRHRD
      064124 001302          .WORD  706
      064126 072422          .WORD  T35SSR
      064130 012126          .WORD  PKTSSR
4324 064132          90$:  CKLOOP          ;LOOP IF SELECTED
      064132 104406          TRAP   C#CLP1
4325 064134 012704 067370          MOV     #T35PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
4326 064140 004737 010742          JSR    PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
4327 064144 103407          BCS    100$           ;BR, IF COMMAND ISSUED OK
4328 064146 005237 002214          INC     FATFLG        ;ERROR COUNT
4332 064152 010001          MOV     R0,R1         ;SAVE CONTENTS OF TSSR
4333 064154          ERRHRD  ERRNO,WRTMSG,SFMSG ;WRITE CHARACTERISTICS FAILED
      064154 104456          TRAP   C#ERRHRD
      064156 001303          .WORD  707
      064160 005052          .WORD  WRTMSG
      064162 012114          .WORD  SFMSG
4334 064164          100$: CKLOOP          ;SCOPE LOOP
      064164 104406          TRAP   C#CLP1
4335 064166 012737 176750 067542 110$:  MOV     #65000.,T35DLY ;SET UP DELAY COUNTER
4336 064174 005037 067536          CLR     T35CNT        ;DELAY COUNTER
4337
4338          ;*****
4339          ;
4340          ;REWIND IMED. INTERRUPT,ACK,CVC=1,IE=0 COMMAND
4341          ;
4342          ;*****
4343
4344 064200 012737 142012 067510          MOV     #142012,T35PK3 ;REWIND IMED. INTERRUPT,ACK,CVC=1,IE=0 COMMAND
4345 064206 012704 067510          MOV     #T35PK3,R4    ;SET UP R4 WITH PACKET ADDRESS
4346 064212 010465 000000          MOV     R4,TSDB(R5)   ;ISSUE COMMAND
4347 064216 016501 000002          120$:  MOV     TSSR(R5),R1 ;GET TSSR CONTENTS
4348 064222 032701 000200          BII    #SSR,R1       ;CHECK FOR SSR SET
4349 064226 001021          BNE     130$         ;BR, WHEN SSR IS SET
4350 064230 005237 067536          INC     T35CNT        ;BUMP THE CYCLE COUNTER
4351 064234          DELAY  1             ;DELAY TO KEEP COUNTER DOWN

```

```

064234 012727 000001                                MOV    #1,(PC)+
064240 000000                                .WORD 0
064242 013727 002116                                MOV    L$DLY,(PC)+
064246 000000                                .WORD 0
064250 005367 177772                                DEC    -6(PC)
064254 001375                                BNE    -4
064256 005367 177756                                DEC    -22(PC)
064262 001367                                BNE    -20
4352 064264 005337 067542                DEC    T35DLY                ;DROP DEAD TIMER BUMP DOWN
4353 064270 001352                                BNE    120$                ;BR, IF MORE TIME TO GO
4354 064272 012702 000200                130$: MOV    #SSR,R2                ;SET UP EXPECTED
4355 064276 020102                                CMP    R1,R2                ;ARE THEY EQUAL
4356 064300 001406                                BEQ    140$                ;BR, IF OK
4357 064302 005237 002214                INC    FATFLG                ;ERROR COUNT
4361 064306                                ERRHRD ERRNO,T35RWE,PKTSSR    ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP    C$ERRHRD
                                .WORD 708
                                .WORD T35RWE
                                .WORD PKTSSR
                                TRAP    C$CLP1
4362 064316                                140$: CKLOOP                ;LOOP IF SELECTED
                                TRAP    C$CLP1
                                .WORD 709
                                .WORD T35INT
                                .WORD PKTSSR
4363 064320 005737 002216                TST    INTRECV                ;CHECK FOR INTERRUPTS
4364 064324 001410                                BEQ    150$                ;BR, IF NO INTERRUPTS DETECTED
4365 064326 016501 000002                MOV    TSSR(R5),R1            ;GET TSSR STATUS FOR PRINTOUT
4366 064332 005237 002214                INC    FATFLG                ;ERROR COUNT
4370 064336                                ERRHRD ERRNO,T35INT,PKTSSR    ;INTERRUPT RECEIVED (BAD)
                                TRAP    C$ERRHRD
                                .WORD 709
                                .WORD T35INT
                                .WORD PKTSSR
4371 064346                                150$: CKLOOP                ;LOOP IF SELECTED
                                TRAP    C$CLP1
064346 104406
4372
4373                ;*****
4374                ;
4375                ;NOW CHECK FOR THE MOTION BITS SET
4376                ;
4377                ;*****
4378
4379 064350 013701 067420                MOV    T35BFR+6,R1            ;PICK UP XST0
4380 064354 010102                MOV    R1,R2                ;SET UP EXPECTED
4381 064356 052702 000200                BIS    #BIT7,R2                ;SET MOT BIT IN EXPECTED
4382 064362 020102                CMP    R1,R2                ;DOES EXP = REC'D
4383 064364 001406                                BEQ    160$                ;BR, IF EQUAL (OK)
4384 064366 005237 002214                INC    FATFLG                ;ERROR COUNT
4388 064372                                ERRHRD ERRNO,T35MOT,EXPREC    ;TAPE NOT AT BOT AFTER REWIND
                                TRAP    C$ERRHRD
                                .WORD 710
                                .WORD T35MOT
                                .WORD EXPREC
064372 104456
064374 001306
064376 072503
064400 015554
4389 064402                                160$: CKLOOP                ;LOOP IF SELECTED
                                TRAP    C$CLP1
064402 104406
4390 064404 013701 067424                MOV    T35BFR+12,R1            ;PICK UP XST2
4391 064410 010102                MOV    R1,R2                ;SET UP EXPECTED
4392 064412 052702 100000                BIS    #BIT15,R2            ;SET OPM BIT IN EXPECTED
4393 064416 020102                CMP    R1,R2                ;DOES EXP = REC'D
4394 064420 001406                                BEQ    170$                ;BR, IF EQUAL (OK)
    
```

4395	064422	005237	002214		INC	FATFLG		;	ERROR COUNT			
4399	064426				ERRHRD	ERRNO,T35OPM,EXP		;	OPM BIT NOT SET			
	064426	104456								TRAP	C\$ERHRD	
	064430	001307								.WORD	711	
	064432	072672								.WORD	T35OPM	
	064434	015554								.WORD	EXP	
4400	064436			170\$:	CKLOOP			;	LOOP IF SELECTED			
	064436	104406								TRAP	C\$CLP1	
4401	064440	012737	000027	067542	MOV	#23.,T35DLY		;	SET UP DELAY COUNTER			
4402	064446			175\$:	DELAY	250		;	START DELAY			
	064446	012727	000250							MOV	#250,(PC)+	
	064452	000000								.WORD	0	
	064454	013727	002116							MOV	L\$DLY,(PC)+	
	064460	000000								.WORD	0	
	064462	005367	177772							DEC	-6(PC)	
	064466	001375								BNE	.4	
	064470	005367	177756							DEC	-22(PC)	
	064474	001367								BNE	.-20	
4403	064476	005337	067542		DEC	T35DLY		;	BUMP DELAY COUNTER			
4404	064502	001361			BNE	175\$;	BR, IF MORE DELAY			
4405	064504				ENDSUB							
	064504										L10064:	
	064504	104403								TRAP	C\$ESUB	
4406	064506	023727	002214	000017	CMP	FATFLG,#15.		;	IS ERROR COUNT AT 25			
4407	064514	103402			BLO	999\$;	BR, IF LESS THAN 25			
4408	064516	004737	C17262		JSR	PC,CKDROP		;	TRY TO DROP THE UNIT			
4409	064522			999\$:								
4410				:								
4411				:								
4412				:	TEST 7: SUBTEST 2							
4413				:								
4414				:								
4415				:								
4416				:								
4417				:								
4418				:								
4419				:								
4420				:								
4421				:								
4422				:								
4423				:								
4424				:								
4425				:								
4426	064522			:								
	064522			:	BGNSUB			;	BEGIN SUBTEST			
	064522	104402		:							T7.2:	
4427	064524				SETPRI	#PRI00		;	ENABLE INTERRUPTS.		TRAP	C\$BSUB
	064524	012700	000000									
	064530	104441								MOV	#PRI00,RO	
4428	064532	004737	073164		JSR	PC,T35REST		;	SET COMMAND PACKET		TRAP	C\$SPRI
4429	064536	005037	002216		CLR	INTRECV		;	CLEAR INTERRUPT RECEIVED FLAG			
4430	064542	004737	073256		JSR	PC,T35RT2		;	SET UP OTHER COMMAND PACKET			
4431	064546	004737	073320		JSR	PC,T35RT3		;	SET UP OTHER COMMAND PACKET			
4432	064552	012737	176750	067542	MOV	#65000.,T35DLY		;	SET UP DELAY COUNTER			
4433	064560	005037	067536		CLR	T35CNT		;	CLEAR COUNTER			
4434	064564	004737	016054	10\$:	JSR	PC,SOFINIT		;	DO INITIALIZE ON CONTROLLER			
4435	064570	103426			BCS	20\$;	BR IF INIT WAS OK			

4436	064572			DELAY	250		;DELAY ABOUT .25 SEC		
	064572	012727	000250					MOV	#250,(PC)+
	064576	000000						.WORD	0
	064600	013727	002116					MOV	L\$DLY,(PC)+
	064604	000000						.WORD	0
	064606	005367	177772					DEC	-6(PC)
	064612	001375						BNE	.-4
	064614	005367	177756					DEC	-22(PC)
	064620	001367						BNE	.-20
4437	064622	005337	067542	DEC	T35DLY		;BUMP COUNTER		
4438	064626	001356		BNE	10\$;BR, IF COUNTER NOT DONE		
4439	064630	005237	002214	INC	FATFLG		;ERROR COUNT		
4443	064634	010001		MOV	R0,R1		;CONTENTS OF TSSR REGISTER		
4444	064636			ERRDF	ERRNO,SFIERR,SFIMSG		;FATAL ERROR TSSR WAS NOT OK		
	064636	104455						TRAP	C\$ERDF
	064640	001310						.WORD	712
	064642	003646						.WORD	SFIERR
	064644	012114						.WORD	SFIMSG
4445	064646	013737	002174	MOV	UNITN,T35DSW	067410	20\$;		;SET UP DRIVE NUMBER
4446	064654	012704	067370	MOV	#T35PACKET,R4				;SUBROUTINE NEEDS PACKET ADDRESS
4447	064660	004737	010742	JSR	PC,WRTCHR				;ISSUE WRITE CHARACTERISTICS
4448	064664	103407		BCS	25\$;BR, IF COMMAND ISSUED OK
4449	064666	005237	002214	INC	FATFLG				;ERROR COUNT
4453	064672	010001		MOV	R0,R1				;SAVE CONTENTS OF TSSR
4454	064674			ERRHRD	ERRNO,WRTMSG,SFIMSG				;WRITE CHARACTERISTIC FAILED
	064674	104456						TRAP	C\$ERHRD
	064676	001311						.WORD	713
	064700	005052						.WORD	WRTMSG
	064702	012114						.WORD	SFIMSG
4455	064704			25\$:	CKLOOP		;LOOP IF SELECTED		
	064704	104406						TRAP	C\$CLP1
4456	064706	004737	011074	JSR	PC,REWIND				;CALL TAPE REWIND COMMAND
4457	064712	103411		BCS	30\$;BR, IF NO PROBLEM
4458	064714	010004		MOV	R0,R4				;SET UP REWIND PACKET ADDRESS
4459	064716	016501	000002	MOV	TSSR(R5),R1				;GET TSSR CONTENTS
4460	064722	005237	002214	INC	FATFLG				;ERROR COUNT
4464	064726			ERRHRD	ERRNO,T35RWN,PKTSSR				;REWIND NOT ACCEPTED
	064726	104456						TRAP	C\$ERHRD
	064730	001312						.WORD	714
	064732	070644						.WORD	T35RWN
	064734	012126						.WORD	PKTSSR
4465	064736			30\$:	CKLOOP		;LOOP IF SELECTED		
	064736	104406						TRAP	C\$CLP1
4466	064740	013701	067420	MOV	T35BFR+6,R1				;PICK UP XST0
4467	064744	010102		MOV	R1,R2				;SET UP EXPECTED
4468	064746	052702	000002	BIS	#BIT1,R2				;SET BOT BIT IN EXPECTED
4469	064752	020102		CMP	R1,R2				;DOES EXP = REC'D
4470	064754	001406		BEQ	40\$;BR, IF EQUAL (OK)
4471	064756	005237	002214	INC	FATFLG				;ERROR COUNT
4475	064762			ERRHRD	ERRNO,T35BOT,EXPREC				;TAPE NOT AT BOT AFTER REWIND
	064762	104456						TRAP	C\$ERHRD
	064764	001313						.WORD	715
	064766	070340						.WORD	T35BOT
	064770	015554						.WORD	EXPREC
4476	064772			40\$:	CKLOOP		;LOOP IF SELECTED		
	064772	104406						TRAP	C\$CLP1
4477	064774	012703	000024	MOV	#20.,R3				;NUMBER OF RECORDS

```

4478 065000 012737 000400 067516      MOV      #256.,T35SZ      ;SET UP RECORD SIZE
4479 065006 013737 003116 067512      MOV      FREE,T35WB     ;ADDRESS OF WRITE BUFFER
4480
4481      ;*****
4482      ;
4483      ;WRITE DATA,ACK,CVC=1 COMMAND
4484      ;
4485      ;*****
4486
4487 065014 012737 140005 067510      MOV      #140005,T35PK3 ;WRITE DATA,ACK,CVC=1 COMMAND
4488 065022 012704 067510      MOV      #T35PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
4489 065026 010465 000000      50$:    MOV      R4,TSDB(R5)   ;ISSUE COMMAND
4490 065032 004737 016330      JSR      PC,WAITF       ;WAIT FOR SSR TO SET
4491 065036 016501 000002      MOV      TSSR(R5),R1    ;GET TSSR CONTENTS
4492 065042 012702 000200      MOV      #SSR,R2       ;SET UP EXPECTED
4493 065046 020102      CMP      R1,R2         ;ARE THEY EQUAL
4494 065050 001406      BEQ      60$           ;BR, IF OK
4495 065052 005237 002214      INC      FATFLG        ;ERROR COUNT
4499 065056      ERRHRD  ERRNO,T35WDE,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA
                                TRAP      C$ERHRD
                                .WORD      716
                                .WORD      T35WDE
                                .WORD      PKTSSR
                                TRAP      C$CLP1
065056 104456
065060 001314
065062 070266
065064 012126
4500 065066      60$:    CKLOOP        ;LOOP IF SELECTED
065066 104406
4501
4502      ;*****
4503      ;
4504      ;WAIT FOR TAPE TO STOP ALL MOTION
4505      ;
4506      ;*****
4507
4508 065070 012737 000012 067542      70$:    MOV      #10.,T35DLY ;SET UP DELAY COUNTER
4509 065076      DELAY      250        ;WAIT ABOUT .25 SEC
                                MOV      #250,(PC)+
                                .WORD      0
                                MOV      L$DLY,(PC)+
                                .WORD      0
                                DEC      -6(PC)
                                BNE      -4
                                DEC      -22(PC)
                                BNE      -20
065076 012727 000250
065102 000000
065104 013727 002116
065110 000000
065112 005367 177772
065116 001375
065120 005367 177756
065124 001367
4510 065126 005337 067542      DEC      T35DLY        ;BUMP COUNTER DOWN
4511 065132 001361      BNE      70$          ;BR, IF MORE TO DELAY
4512 065134 005737 002220      TST      EXTFEA       ;CHECK FOR EXTENDED FEATURES SW SWITCH
4513 065140 001042      BNE      110$        ;BR IF SWITCH IS ON
4514 065142 112737 000200 067521      MOVB     #200,T35BS1   ;WRITE MISCELLANEOUS CONT/READ STATUS
4515 065150 112737 000010 067520      MOVB     #10,T35BS0   ;FUNCTION SELECTION BIT (TURN ON EXTFEA HW SWITCH)
4516 065156 012704 067500      MOV      #T35PK2,R4   ;WRITE SUBSYS MEM PACKET
4517 065162 010465 000000      MOV      R4,TSDB(R5)  ;ISSUE COMMAND
4518 065166 004737 016416      JSR      PC,CHKTSSR   ;WAIT FOR SSR
4519 065172 103407      BCS      90$          ;BR, IF NO ERROR
4520 065174 010001      MOV      R0,R1        ;ERROR, SAVE TSSR
4521 065176 005237 002214      INC      FATFLG        ;ERROR COUNT
4525 065202      ERRHRD  ERRNO,T35SSR,PKTSSR ;TSSR NOT CORRECT AFTER WRT. MISCELLANEOUS
                                TRAP      C$ERHRD
                                .WORD      717
065202 104456
065204 001315
    
```



```

4568 065412 005237 002214          INC      FATFLG          ;ERROR COUNT
4572 065416          ERRHRD   ERRNO,T35NIN,PKTSSR ;INTERRUPT NOT RECEIVED (BAD)
                                065416 104456          TRAP      C1ERHRD
                                065420 001320          .WORD    720
                                065422 073056          .WORD    T35NIN
                                065424 012126          .WORD    PKTSSR
4573 065426          1504:   CKLOOP          ;LOOP IF SELECTED
                                065426 104406          TRAP      C1CLP1
4574
4575          ;*****
4576          ;
4577          ;NOW CHECK FOR THE MOTION BITS SET
4578          ;
4579          ;*****
4580
4581 065430 013701 067420          MOV      T35BFR+6,R1      ;PICK UP XST0
4582 065434 010102          MOV      R1,R2           ;SET UP EXPECTED
4583 065436 052702 000200          BIS      @BIT7,R2        ;SET MOT BIT IN EXPECTED
4584 065442 020102          CMP      R1,R2           ;DOES EXP = REC'D
4585 065444 001406          BEQ      1604            ;BR, IF EQUAL (OK)
4586 065446 005237 002214          INC      FATFLG          ;ERROR COUNT
4590 065452          ERRHRD   ERRNO,T35MOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                065452 104456          TRAP      C1ERHRD
                                065454 001321          .WORD    721
                                065456 072503          .WORD    T35MOT
                                065460 015554          .WORD    EXPREC
4591 065462          1604:   CKLOOP          ;LOOP IF SELECTED
                                065462 104406          TRAP      C1CLP1
4592 065464 013701 067424          MOV      T35BFR+12,R1     ;PICK UP XST2
4593 065470 010102          MOV      R1,R2           ;SET UP EXPECTED
4594 065472 052702 100000          BIS      @BIT15,R2       ;SET OPM BIT IN EXPECTED
4595 065476 020102          CMP      R1,R2           ;DOES EXP = REC'D
4596 065500 001406          BEQ      1704            ;BR, IF EQUAL (OK)
4597 065502 005237 002214          INC      FATFLG          ;ERROR COUNT
4601 065506          ERRHRD   ERRNO,T35OPM,EXPREC ;OPM BIT NOT SET
                                065506 104456          TRAP      C1ERHRD
                                065510 001322          .WORD    722
                                065512 072672          .WORD    T35OPM
                                065514 015554          .WORD    EXPREC
4602 065516          1704:   CKLOOP          ;LOOP IF SELECTED
                                065516 104406          TRAP      C1CLP1
4603 065520 012737 000027 067542          MOV      @25,,T35DLT     ;SET UP DELAY COUNTER
4604 065526          1754:   DELAY      250      ;START DELAY
                                065526 012727 000250          MOV      @250,(PC),
                                065532 000000          .WORD    0
                                065534 013727 002116          MOV      T35DLT,(PC),
                                065540 000000          .WORD    0
                                065542 005367 177772          DEC      @6(PC)
                                065546 001375          BNE     .4
                                065550 005367 177756          DEC      @20(PC)
                                065554 001367          BNE     .20
4605 065556 005337 067542          DEC      T35DLT          ;BUMP DELAY COUNTER
4606 065562 001361          BNE     1754            ;BR, IF MORE DELAY
4607 065564          ENDSUB
                                065564          L10065:
                                065564 104403          TRAP      C1ESUB
4608 065566 023727 002214 000017          CMP      FATFLG,@15.     ;IS ERROR COUNT AT 25

```



```

065724 104456 TRAP C$ERRHRD
065726 001325 .WORD 725
065730 070644 .WORD T35RWN
065732 012126 .WORD PKT$SR
4664 065734 30$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
065734 104406
4665 065736 013701 067420 MOV T35BFR+6,R1 ;PICK UP XSTO
4666 065742 010102 MOV R1,R2 ;SET UP EXPECTED
4667 065744 052702 000002 BIS @BIT1,R2 ;SET BOT BIT IN EXPECTED
4668 065750 020102 CMP R1,R2 ;DOES EXP = REC'D
4669 065752 001406 BEQ 40$ ;BR, IF EQUAL (OK)
4670 065754 005237 002214 INC FATFLG ;ERROR COUNT
4674 065760 ERRHRD ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
065760 104456 TRAP C$ERRHRD
065762 001326 .WORD 726
065764 070340 .WORD T35BOT
065766 015554 .WORD EXPREC
4675 065770 40$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
065770 104406
4676 065772 012703 000024 MOV @20,R3 ;STARTING RECORD SIZE
4677 065776 013737 003116 067512 MOV FREE,T35WB ;STARTING WRITE BUFFER ADDRESS
4678 ;*****
4679 ;
4680 ;WRITE DATA,CVC-1,ACK COMMAND
4681 ;
4682 ;*****
4683 ;
4684 ;
4685 066004 012737 140005 067510 65$: MOV @140005,T35PK3 ;WRITE DATA,CVC-1,ACK COMMAND
4686 066012 012704 067510 MOV @T35PK3,R4 ;SET UP R4 WITH PACKET ADDRESS
4687 066016 010300 MOV R3,R0 ;SET PATTERN IN CORRECT REGISTER
4688 066020 004737 017502 JSR PC,FILLMEM ;FILL MEMORY WITH RECORD SIZE
4689 066024 010337 067516 MOV R3,T35SZ ;SET UP RECORD SIZE IN PACKET
4690 066030 010465 000000 MOV R4,T35DB(R5) ;ISSUE COMMAND
4691 066034 004737 016330 JSR PC,WAITF ;WAIT FOR SSR TO SET
4692 066040 016501 000002 MOV T35SR(R5),R1 ;GET T35SR CONTENTS
4693 066044 012702 000200 MOV @5SR,R2 ;SET UP EXPECTED
4694 066050 020102 CMP R1,R2 ;ARE THEY EQUAL
4695 066052 001406 BEQ 80$ ;BR, IF OK
4696 066054 005237 002214 INC FATFLG ;ERROR COUNT
4700 066060 ERRHRD ERRNO,T35WDC,PKT$SR ;T35SR INCORRECT AFTER WRITE DATA
066060 104456 TRAP C$ERRHRD
066062 001327 .WORD 727
066064 071200 .WORD T35WDC
066066 012126 .WORD PKT$SR
4701 066070 80$: CKLOOP ;LOOP IF SELECTED TRAP C$CLP1
066070 104406
4702 ;*****
4703 ;
4704 ;WRITE DATA RETRY,CVC-1,ACK COMMAND
4705 ;
4706 ;*****
4707 ;
4708 ;
4709 066072 012737 141005 067510 MOV @141005,T35PK3 ;WRITE DATA RETRY,CVC-1,ACK COMMAND
4710 066100 010465 000000 MOV R4,T35DB(R5) ;ISSUE COMMAND
4711 066104 004737 016330 JSR PC,WAITF ;WAIT FOR SSR TO SET

```

```

4712 066110 016501 000002      MOV      TSSR(R5),R1      ;GET TSSR CONTENTS
4713 066114 012702 000200      MOV      #SSR,R2        ;SET UP EXPECTED
4714 066120 020102              CMP      R1,R2          ;ARE THEY EQUAL
4715 066122 001406              BEQ     90$             ;BR, IF OK
4716 066124 005237 002214      INC     FATFLG          ;ERROR COUNT
4720 066130              ERRHRD  ERRNO,T35WRF,PKTSSR ;TSSR INCORRECT AFTER WRITE DATA RETRY
                                TRAP      C$ERRHRD
                                .WORD    728
                                .WORD    T35WRF
                                .WORD    PKTSSR
                                90$:  CKLOOP      ;LOOP IF SELECTED
                                TRAP      C$CLP1
4721 066140              TST     (R3),          ;BUMP RECORD SIZE COUNTER
                                .WORD    104406
                                .WORD    005723
4722 066142 005723 000052      CMP     R3,#42         ;AT 42 SIZE YET
4723 066144 020327 000052      BNE     65$             ;BR, IF MORE RECORDS TO WRITE
4724 066150 001315              JSR     PC,REWIND       ;CALL TAPE REWIND COMMAND
4725 066152 004737 011074      BCS     230$           ;BR, IF NO PROBLEM
4726 066156 103411              MOV     R0,R1          ;SAVE TSSR
4727 066160 010001              MOV     TSSR(R5),R1    ;GET TSSR CONTENTS
4728 066162 016501 000002      INC     FATFLG          ;ERROR COUNT
4729 066166 005237 002214      ERRHRD  ERRNO,T35RWN,EXPREC ;REWIND NOT ACCEPTED
                                TRAP      C$ERRHRD
                                .WORD    729
                                .WORD    T35RWN
                                .WORD    EXPREC
4733 066172 104456              230$: CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD    104406
                                .WORD    067420
4734 066202 104406              MOV     T35BFR+6,R1    ;PICK UP XSTO
4735 066204 013701 067420      MOV     R1,R2          ;SET UP EXPECTED
4736 066210 010102              BIS     #BIT1,R2       ;SET BOT BIT IN EXPECTED
4737 066212 052702 000002      CMP     R1,R2          ;DOES EXP = REC'D
4738 066216 020102              BEQ     240$           ;BR, IF EQUAL (OK)
4739 066220 001406              INC     FATFLG          ;ERROR COUNT
4740 066222 005237 002214      ERRHRD  ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP      C$ERRHRD
                                .WORD    730
                                .WORD    T35BOT
                                .WORD    EXPREC
4744 066226 104456              240$: CKLOOP          ;LOOP IF SELECTED
                                TRAP      C$CLP1
                                .WORD    001332
                                .WORD    070340
                                .WORD    015554
4745 066236 104406              MOV     #20.,R3        ;STARTING RECORD SIZE
4746 066240 012703 000024      MOV     FREE,T35RB     ;STARTING READ BUFFER ADDRESS
4747 066244 013737 003116 067512
4748
4749
4750
4751
4752
4753
4754
4755 066252 012737 100001 067510 265$: MOV     #100001,T35PK3 ;READ DATA,ACK COMMAND
4756 066260 012704 067510      MOV     #T35PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
4757 066264 012700 177777      MOV     #177777,R0     ;SET PATTERN IN CORRECT REGISTER
4758 066270 004737 017502      JSR     PC,FILLMEM     ;FILL MEMORY WITH RECORD SIZE
4759 066274 010337 067516      MOV     R3,T35S2       ;SET UP RECORD SIZE IN PACKET
4760 066300 010465 000000      MOV     R4,T35DB(R5)  ;ISSUE COMMAND
4761 066304 004737 016330      JSR     PC,WAITF       ;WAIT FOR SSR TO SET
4762 066310 016501 000002      MOV     TSSR(R5),R1    ;GET TSSR CONTENTS
    
```

4763	066314	012702	000200	MOV	QSSR,R2	;	SET UP EXPECTED		
4764	066320	020102		CMP	R1,R2	;	ARE THEY EQUAL		
4765	066322	001406		BEG	280\$;	BR, IF OK		
4766	066324	005237	002214	INC	FATFLG		;	ERROR COUNT	
4770	066330			ERRHRD	ERRNO,T35RDF,PKTSSR	;	TSSR INCORRECT AFTER READ DATA		
	066330	104456						TRAP	C\$ERHRD
	066332	001333						.WORD	731
	066334	067632						.WORD	T35RDF
	066336	012126						.WORD	PKTSSR
4771	066340			280\$:	CKLOOP	;	LOOP IF SELECTED		
	066340	104406						TRAP	C\$CLP1
4772	066342	013702	003116	MOV	FREE,R2	;	GET BUFFER ADDRESS		
4773	066346	010304		MOV	R3,R4	;	GET RECORD SIZE		
4774	066350	162704	000024	SUB	Q20.,R4	;	POINT BACK TO 1ST RECORD		
4775	066354	060204		285\$:	ADD R2,R4	;	POINT TO 1ST LOC IN BUFFER		
4776	066356	021403		CMP	(R4),R3	;	DATA WRITTEN - READ		
4777	066360	001410		BEG	290\$;	BR, IF DATA OK (GOOD)		
4778	066362	011401		MOV	(R4),R1	;	PICK UP BAD DATA		
4779	066364	010302		MOV	R3,R2	;	SET UP EXPECTED		
4780	066366	005237	002214	INC	FATFLG		;	ERROR COUNT	
4784	066372			ERRHRD	ERRNO,T35DTA,EXPREC	;	DATA IN BUFFER NOT CORRECT		
	066372	104456						TRAP	C\$ERHRD
	066374	001334						.WORD	732
	066376	072325						.WORD	T35DTA
	066400	015554						.WORD	EXPREC
4785	066402			290\$:	CKLOOP	;	LOOP IF SELECTED		
	066402	104406						TRAP	C\$CLP1
4786	066404	005724		TST	(R4),	;	BUMP TO NEXT ADDRESS		
4787	066406	160204		SUB	R2,R4	;	BACK TO RECORD SIZE		
4788	066410	020403		CMP	R4,R3	;	AT END OF RECORD YET		
4789	066412	001360		BNE	285\$;	BR, IF MORE DATA TO CHECK		
4790	066414	005723		TST	(R3),	;	BUMP RECORD SIZE		
4791	066416	020327	000050	CMP	R3,Q40.	;	DONE YET		
4792	066422	001313		BNE	265\$;	BR, IF NOT DONE YET (MORE READS)		
4793	066424			300\$:	CKLOOP	;	LOOP IF SELECTED		
	066424	104406						TRAP	C\$CLP1
4794	066426			330\$:					
4795	066426			ENDSUB		;	END SUBTEST		
	066426								
	066426	104403							
4796	066430	023727	002214 000017	CMP	FATFLG,Q15.	;	IS ERROR COUNT AT 25		
4797	066436	103402		BLO	999\$;	BR, IF LESS THAN 25		
4798	066440	004737	017262	JSR	PC,CKDROP	;	TRY TO DROP THE UNIT		
4799	066444			999\$:					
4800				;					
4801				;					
4802				;	TEST 7, SUBTEST 4				
4803				;					
4804				;	VERIFIES THAT A TAPE-MOTION COMMAND (READ, WRITE, POSITION),				
4805				;	ISSUED IMMEDIATELY AFTER TERMINATION OF A REWIND WITH				
4806				;	IMMEDIATE INTERRUPT COMMAND, IS "QUEUED" BY THE CONTROLLER AND				
4807				;	THEN EXECUTES PROPERLY.				
4808				;					
4809				;					
4810				;					
4811				;					
4812	066444			BGNSUB		;	BEGIN SUBTEST		

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 7: EXTENDED MODE FEATURES

SEQ 188

```

                                T7.4:
                                TRAP      C$BSUB
066444
066444 104402
4813 066446 004737 073164      JSR      PC,T35REST      ;SET COMMAND PACKET
4814 066452 004737 073256      JSR      PC,T35RT2      ;SET UP OTHER COMMAND PACKET
4815 066456 004737 073320      JSR      PC,T35RT3      ;SET UP OTHER COMMAND PACKET
4816 066462 012737 176750 067542  MOV      #65000.,T35DLY  ;SET UP DELAY COUNTER
4817 066470 004737 016054      JSR      PC,SOFINIT     ;DO INITIALIZE ON CONTROLLER
4818 066474 103426              BCS      20$           ;BR IF INIT WAS OK
4819 066476              DELAY     250         ;DELAY ABOUT .25 SEC
                                MOV      #250,(PC)+
                                .WORD    0
                                MOV      L$DLY,(PC)+
                                .WORD    0
                                DEC      -6(PC)
                                BNE     .-4
                                DEC      -22(PC)
                                BNE     .-20
                                TRAP      C$ERDF
                                .WORD    733
                                .WORD    SFIERR
                                .WORD    SFIMSG
066476 012727 000250
066502 000000
066504 013727 002116
066510 000000
066512 005367 177772
066516 001375
066520 005367 177756
066524 001367
4820 066526 005337 067542      DEC      T35DLY        ;BUMP COUNTER
4821 066532 001356              BNE     10$           ;BR, IF COUNTER NOT DONE
4822 066534 005237 002214      INC      FATFLG        ;ERROR COUNT
4826 066540 010001              MOV      R0,R1         ;CONTENTS OF TSSR REGISTER
4827 066542              ERRDF   ERRNO,SFIERR,SFIMSG ;FATAL ERROR TSSR WAS NOT OK
                                TRAP      C$ERDF
                                .WORD    733
                                .WORD    SFIERR
                                .WORD    SFIMSG
066542 104455
066544 001335
066546 003646
066550 012114
4828 066552 013737 002174 067410 20$:  MOV      UNITN,T35DSW   ;SET UP UNIT (DRIVE) NUMBER
4829 066560 012704 067370      MOV      #T35PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
4830 066564 004737 010742      JSR      PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
4831 066570 103407              BCS     23$           ;BR, IF COMMAND ISSUED OK
4832 066572 005237 002214      INC      FATFLG        ;ERROR COUNT
4836 066576 010001              MOV      R0,R1         ;SAVE CONTENTS OF TSSR
4837 066600              ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
                                TRAP      C$ERHRD
                                .WORD    734
                                .WORD    WRTMSG
                                .WORD    SFIMSG
066600 104456
066602 001336
066604 005052
066606 012114
4838 066610              CKLOOP              ;LOOP IF SELECTED
                                TRAP      C$CLP1
066610 104406
4839 066612 004737 011074      JSR      PC,REWIND     ;CALL TAPE REWIND COMMAND
4840 066616 103411              BCS     30$           ;BR, IF NO PROBLEM
4841 066620 016501 000002      MOV      TSSR(R5),R1   ;GET TSSR CONTENTS
4842 066624 010004              MOV      R0,R4         ;GET PACKET ADDRESS
4843 066626 005237 002214      INC      FATFLG        ;ERROR COUNT
4847 066632              ERRHRD  ERRNO,T35RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP      C$ERHRD
                                .WORD    735
                                .WORD    T35RWN
                                .WORD    PKTSSR
066632 104456
066634 001337
066636 070644
066640 012126
4848 066642              CKLOOP              ;LOOP IF SELECTED
                                TRAP      C$CLP1
066642 104406
4849 066644 013701 067420      MOV      T35BFR+6,R1   ;PICK UP XSTO
4850 066650 010102              MOV      R1,R2         ;SET UP EXPECTED
4851 066652 052702 000002      BIS      #BIT1,R2      ;SET BOT BIT IN EXPECTED
4852 066656 020102              CMP      R1,R2         ;DOES EXP = REC'D
4853 066660 001406              BEQ     40$           ;BR, IF EQUAL (OK)
4854 066662 005237 002214      INC      FATFLG        ;ERROR COUNT

```

```

4858 066666          ERRHRD  ERRNO,T35BOT,EXPREC      ;TAPE NOT AT BOT AFTER REWIND
      066666 104456          TRAP          C$ERHRD
      066670 001340          .WORD        736
      066672 070340          .WORD        T35BOT
      066674 015554          .WORD        EXPREC
4859 066676          40$:   CKLOOP                    ;LOOP IF SELECTED          TRAP          C$CLP1
      066676 104406
4860 066700 012703 000024      MOV          #20.,R3      ;STARTING RECORD SIZE
4861 066704 013737 003116 067512  MOV          FREE,T35WB   ;STARTING WRITE BUFFER ADDRESS
4862
4863 ;*****
4864 ;
4865 ;WRITE DATA,CVC-1,ACK COMMAND
4866 ;
4867 ;*****
4868
4869 066712 012737 140005 067510 65$:   MOV          #140005,T35PK3 ;WRITE DATA,CVC-1,ACK COMMAND
4870 066720 012704 067510      MOV          #T35PK3,R4  ;SET UP R4 WITH PACKET ADDRESS
4871 066724 010300      MOV          R3,R0       ;SET PATTERN IN CORRECT REGISTER
4872 066726 004737 017502      JSR          PC,FILLMEM  ;FILL MEMORY WITH RECORD SIZE
4873 066732 010337 067516      MOV          R3,T35SZ   ;SET UP RECORD SIZE IN PACKET
4874 066736 010465 000000      MOV          R4,TSD8(R5) ;ISSUE COMMAND
4875 066742 004737 016330      JSR          PC,WAITF   ;WAIT FOR SSR TO SET
4876 066746 016501 000002      MOV          TSSR(R5),R1 ;GET TSSR CONTENTS
4877 066752 012702 000200      MOV          #SSR,R2   ;SET UP EXPECTED
4878 066756 020102      CMP          R1,R2     ;ARE THEY EQUAL
4879 066760 001406      BEQ          80$      ;BR. IF OK
4880 066762 005237 002214      INC          FATFLG    ;ERROR COUNT
4884 066766          ERRHRD  ERRNO,T35WDC,PKTSSR     ;TSSR INCORRECT AFTER WRITE DATA
      066766 104456          TRAP          C$ERHRD
      066770 001341          .WORD        737
      066772 071200          .WORD        T35WDC
      066774 012126          .WORD        PKTSSR
4885 066776          80$:   CKLOOP                    ;LOOP IF SELECTED          TRAP          C$CLP1
      066776 104406
4886
4887 ;*****
4888 ;
4889 ;WRITE DATA RETRY,ACK,SWB-1 COMMAND
4890 ;
4891 ;*****
4892
4893 067000 012737 111005 067510      MOV          #111005,T35PK3 ;WRITE DATA RETRY,ACK,SWB-1 COMMAND
4894 067006 010465 000000      MOV          R4,TSD8(R5) ;ISSUE COMMAND
4895 067012 004737 016330      JSR          PC,WAITF   ;WAIT FOR SSR TO SET
4896 067016 016501 000002      MOV          TSSR(R5),R1 ;GET TSSR CONTENTS
4897 067022 012702 000200      MOV          #SSR,R2   ;SET UP EXPECTED
4898 067026 020102      CMP          R1,R2     ;ARE THEY EQUAL
4899 067030 001406      BEQ          90$      ;BR. IF OK
4900 067032 005237 002214      INC          FATFLG    ;ERROR COUNT
4904 067036          ERRHRD  ERRNO,T35WRF,EXPREC     ;TSSR INCORRECT AFTER WRITE DATA RETRY
      067036 104456          TRAP          C$ERHRD
      067040 001342          .WORD        738
      067042 072245          .WORD        T35WRF
      067044 015554          .WORD        EXPREC
4905 067046          90$:   CKLOOP                    ;LOOP IF SELECTED          TRAP          C$CLP1
      067046 104406
    
```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
TEST 7: EXTENDED MODE FEATURES

SEQ 190

```

4906 067050 005723          TST      (R3)+          ;BUMP RECORD SIZE COUNTER
4907 067052 020327 000052    CMP      R3,#42.       ;AT 42 SIZE YET
4908 067056 001315          BNE     65$           ;BR, IF MORE RECORDS TO WRITE
4909 067060 004737 011074    JSR     PC,REWIND     ;CALL TAPE REWIND COMMAND
4910 067064 103411          BCS     230$         ;BR, IF NO PROBLEM
4911 067066 016501 000002    MOV     TSSR(R5),R1   ;GET TSSR CONTENTS
4912 067072 010004          MOV     R0,R4         ;GET PACKET ADDRESS
4913 067074 005237 002214    INC     FATFLG        ;ERROR COUNT
4917 067100          ERRHRD  ERRNO,T35RWN,PKTSSR ;REWIND NOT ACCEPTED
                                TRAP     C$ERHRD
                                .WORD    739
                                .WORD    T35RWN
                                .WORD    PKTSSR
4918 067110          230$: CKLOOP        ;LOOP IF SELECTED
                                TRAP     C$CLP1
4919 067112 013701 067420    MOV     T35BFR+6,R1   ;PICK UP XSTO
4920 067116 010102          MOV     R1,R2         ;SET UP EXPECTED
4921 067120 052702 000002    RIS     #BIT1,R2      ;SET BOT BIT IN EXPECTED
4922 067124 020102          CMP     R1,R2         ;DOES EXP = REC'D
4923 067126 001406          BEQ     240$         ;BR, IF EQUAL (OK)
4924 067130 005237 002214    INC     FATFLG        ;ERROR COUNT
4928 067134          ERRHRD  ERRNO,T35BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
                                TRAP     C$ERHRD
                                .WORD    740
                                .WORD    T35BOT
                                .WORD    EXPREC
4929 067144          240$: CKLOOP        ;LOOP IF SELECTED
                                TRAP     C$CLP1
4930 067146 012703 000024    MOV     #20.,R3       ;STARTING RECORD SIZE
4931 067152 013737 003116 067512  MOV     FREE,T35RB    ;STARTING READ BUFFER ADDRESS
4932
4933          ;*****
4934          ;
4935          ;READ DATA,ACK COMMAND
4936          ;
4937          ;*****
4938
4939 067160 012737 100001 067510 265$: MOV     #100001,T35PK3 ;READ DATA,ACK COMMAND
4940 067166 012704 067510    MOV     #T35PK3,R4   ;SET UP R4 WITH PACKET ADDRESS
4941 067172 010337 067516    MOV     R3,T35SZ     ;SET UP RECORD SIZE IN PACKET
4942 067176 010465 000000    MOV     R4,TSDB(R5)  ;ISSUE COMMAND
4943 067202 004737 016330    JSR     PC,WAITF     ;WAIT FOR SSR TO SET
4944 067206 016501 000002    MOV     TSSR(R5),R1  ;GET TSSR CONTENTS
4945 067212 012702 000200    MOV     #SSR,R2      ;SET UP EXPECTED
4946 067216 020102          CMP     R1,R2         ;ARE THEY EQUAL
4947 067220 001406          BEQ     280$         ;BR, IF OK
4948 067222 005237 002214    INC     FATFLG        ;ERROR COUNT
4952 067226          ERRHRD  ERRNO,T35RDF,PKTSSR ;TSSR INCORRECT AFTER READ DATA
                                TRAP     C$ERHRD
                                .WORD    741
                                .WORD    T35RDF
                                .WORD    PKTSSR
4953 067236          280$: CKLOOP        ;LOOP IF SELECTED
                                TRAP     C$CLP1
4954 067240 013702 003116    MOV     FREE,R2      ;GET BUFFER ADDRESS
4955 067244 010304          MOV     R3,R4         ;GET RECORD SIZE
4956 067246 162704 000024    SUB     #20.,R4       ;POINT BACK TO 1ST RECORD

```

4957	067252	060204		285\$:	ADD	R2,R4				;POINT TO 1ST LOC IN BUFFER
4958	067254	000303			SWAB	R3				;SWAP BYTES SWB=1 ETC.
4959	067256	021403			CMP	(R4),R3				;DATA WRITTEN = READ
4960	067260	001410			BEQ	290\$;BR, IF DATA OK (GOOD)
4961	067262	011401			MOV	(R4),R1				;PICK UP BAD DATA
4962	067264	010302			MOV	R3,R2				;SET UP EXPECTED
4963	067266	005237	002214		INC	FATFLG				;ERROR COUNT
4967	067272				ERRHRD	ERRNO,T35DTA,EXPREC				;DATA IN BUFFER NOT CORRECT
	067272	104456								TRAP C\$ERHRD
	067274	001346								.WORD 742
	067276	072325								.WORD T35DTA
	067300	015554								.WORD EXPREC
4968	067302			290\$:	CKLOOP					;LOOP IF SELECTED
	067302	104406								TRAP C\$CLP1
4969	067304	005724			TST	(R4)+				;BUMP TO NEXT ADDRESS
4970	067306	160204			SUB	R2,R4				;BACK TO RECORD SIZE
4971	067310	000303			SWAB	R3				;PUT R3 BACK INTO SHAPE
4972	067312	020403			CMP	R4,R3				;AT END OF RECORD YET
4973	067314	001356			BNE	285\$;BR, IF MORE DATA TO CHECK
4974	067316	005723			TST	(R3)+				;BUMP RECORD SIZE
4975	067320	020327	000050		CMP	R3,#40.				;DONE YET
4976	067324	001315			BNE	265\$;BR, IF NOT DONE YET (MORE READS)
4977	067326			300\$:	CKLOOP					;LOOP IF SELECTED
	067326	104406								TRAP C\$CLP1
4978	067330				ENDSUB					; >>>>>>>>> END SUBTEST >>>>>>>>>
	067330									L10067:
4979	067332	023727	002214 000017		CMP	FATFLG,#15.				TRAP C\$ESUB
4980	067340	103402			BLO	999\$;IS ERROR COUNT AT 25
4981	067342	004737	017262		JSR	PC,CKDROP				;BR, IF LESS THAN 25
4982	067346			999\$:						;TRY TO DROP THE UNIT
4983				:						
4984				:						
4985				:						
4986	067346	004737	016536		JSR	PC,TSTLOOP				;DO WE NEED TO ITERATE TEST
4987	067352	103002			BCC	163				;BR, IF NO LOOP REQUIRED
4988	067354	000137	063444		JMP	T35LOOP				;EXECUTE AGAIN
4989	067360			163\$:	EXIT	TST				;ALL DONE THIS TEST
	067360	104432								TRAP C\$EXIT
	067362	003760								.WORD L10063-
4990				;						
4991				;						
4992				;						
4994		067370		;						
4996	067370			;						
4997	067370	100004		T35PACKET:						;COMMAND PACKET FOR TEST
4998	067372	067400			.WORD	100004				;WRITE CHARACTERISTICS COMMAND, WITH , ACK
4999	067374	000000			.WORD	T35DATA				;ADDRESS OF CHARACTERISTICS BLOCK
5000	067376	000012			.WORD	0				
5001	067400				.WORD	10.				;STARTING VALUE OF BLOCK SIZE
5002	067400	067412		T35DATA:						;CHARACTERISTICS DATA BLOCK
5003	067402	000000			.WORD	T35BFR				;ADDRESS OF MESSAGE BUFFER
5004	067404	000024			.WORD	0				
5005	067406	000000			.WORD	20.				;LENGTH OF MESSAGE BUFFER
5006	067410	000000			.WORD	0				
5007	067412			T35DSW:	.WORD	0				;SELECT DRIVE, 0
5008				T35BFR:	.BLKW	25.				;MESSAGE BUFFER
				;						

```

5009 ;WRITE SUBSYSTEM MEMORY COMMAND PACKET
5010 ;
5012 067500 ;*...+10>E177770
5014 067500 T35PK2: ;WRITE SUB SYS MEM COMMAND, AND ACK
5015 067500 100006 ;ADDRESS OF SELECT BLOCK DATA
5016 067502 067520 ;WORD 100006
5017 067504 000000 ;WORD T35BF2
5018 067506 000006 ;WORD 0
5019 ;WORD 6. ;SIZE OF DATA PACKET
5023 067510 T35PK3: ;REREAD COMMAND, AND ACK
5024 067510 100005 ;WORD 100005
5025 067512 T35RB: ;ADDRESS OF WRITE BUFFER
5026 067512 003116 T35WB: .WORD FREE
5027 067514 000000 ;WORD 0
5028 067516 000000 T35SZ: .WORD 0 ;SIZE OF BUFFER (EXTENT)
5029 ;EVEN
5030 ;
5031 ;
5032 ;
5033 067520 T35BF2:
5034 067520 010 T35BS0: .BYTE 10 ;BSEL0 AREA
5035 067521 200 T35BS1: .BYTE 200 ;BSEL1 AREA
5036 067522 000000 T35S2: .WORD 0 ;SEL 2 AREA
5037 067524 000000 T35S3: .WORD 0 ;DATA AREA
5038 ;
5039 ;
5040 ;EVEN
5041 ;TAPE MOTION PACKET COMMAND VALUES
5042 ;
5043 067526 100205 T35RN: .WORD 100205 ;REREAD DATA (NEXT)
5044 067530 100605 T35WDR: .WORD 100605 ;REREAD DATA RETRY
5045 067532 102205 T35CON: .WORD 102205 ;WRITE CONTINOUS
5046 067534 177777 ;WORD 177777 ;END OF DATA
5047 ;
5048 ;
5049 067536 000000 T35CNT: .WORD 0 ;TAPE TIMER COUNTER STORAGE AREA
5050 067540 000000 T35CNU: .WORD 0 ;TAPE TIMER COUNTER STORAGE AREA
5051 067542 000000 T35DLY: .WORD 0 ;DELAY COUNTER
5052 ;
5053 ;LOCAL TEXT MESSAGES FOR TEST
5054 ;-
5055 ;
5056 067544 124 141 160 T35WNG: .ASCIZ 'Tape Position Incorrect After REREAD Previous (OPP=1)'
5057 067632 124 123 123 T35RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
5058 067701 122 105 122 T35RRF: .ASCIZ 'REREAD Previous (Space Reverse, Read Forward) Command Failed'
5059 067776 120 117 123 T35SC: .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
5060 070060 122 111 102 T35LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'
5061 070130 124 123 123 T35WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
5062 070205 111 154 154 T35LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
5063 070266 124 123 123 T35WDE: .ASCIZ 'TSSR Not Correct After WRITE DATA Command'
5064 070340 124 141 160 T35BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
5065 070433 127 122 111 T35TIM: .ASCIZ 'WRITE DATA RETRY'S Erase Tape Not Long Enough'
5066 070510 122 105 122 T35EOT: .ASCIZ 'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
5067 070567 124 123 123 T35TM: .ASCIZ 'TSSR Not Correct After REREAD COMMAND Reject'
5068 070644 122 145 167 T35RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
5069 070713 122 101 115 T35RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
5070 070766 124 123 123 T35AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'

```


5071	071035	104	162	151	T35OFL: .ASCIZ	'Drive 7 Select Failed To Set "OFL" In TSSR'
5072	071110	124	123	123	T35WDD: .ASCIZ	'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
5073	071200	124	123	123	T35WDC: .ASCIZ	'TSSR Not Correct After REREAD DATA Command'
5074	071253	103	126	103	T35VCK: .ASCIZ	'CVC Set, Didn't Reset VCK In Message Buffer'
5075	071326	124	123	102	T35BA: .ASCIZ	'TSBA Not Correct After REREAD DATA Command'
5076	071401	127	122	111	T35WSS: .ASCIZ	'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
5077	071470	122	145	141	T35LON: .ASCIZ	'Reading Long Record Failed To Set RLL Bit In XST0'
5078	071552	122	145	141	T35LOP: .ASCIZ	'Reading Long Record Failed To Set RLS Bit In XST0'
5079	071634	122	145	163	T35PBP: .ASCIZ	'Residual Byte Count Incorrect After Short Record Read'
5080	071722	122	145	141	T35TRL: .ASCIZ	'Reading Long Record Failed To Give Tape Status Alert'
5081	072010	127	122	111	T35NEF: .ASCIZ	'WRITE DATA RETRY, At First Record, Failed To Set RIB Bit XST3'
5082	072106	124	123	123	T35SCF: .ASCIZ	'TSSR Not Correct After SPACE RECORDS Command'
5083	072163	124	123	123	T35TSA: .ASCIZ	'TSSR Not Correct After WRITE DATA RETRY, Into BOT'
5084	072245	124	123	123	T35WRF: .ASCIZ	'TSSR Not Correct After WRITE DATA RETRY Command'
5085	072325	104	141	164	T35DTA: .ASCIZ	'Data Compare Error, Data Read From Tape Not Equal To Written'
5086	072422	124	123	123	T35SSR: .ASCIZ	'TSSR Incorrect After WRITE MISCELLANEOUS Command'
5087	072503	115	117	124	T35MOT: .ASCIZ	'MOT Bit (XST0) Not Set During Rewind (Extended Features Mode)'
5088	072601	111	156	164	T35INT: .ASCIZ	'Interrupt Received After REWIND Command (IE Bit Not Set)'
5089	072672	117	120	115	T35OPM: .ASCIZ	'OPM Bit (XST2) Not Set During Rewind (Extended Features Mode)'
5090	072770	124	123	123	T35RWE: .ASCIZ	'TSSR Incorrect After Extended Features REWIND Command'
5091	073056	116	157	040	T35NIN: .ASCIZ	'No Interrupt Detected After REWIND IMMEDIATE'
5092	073133	105	170	164	TST35ID: .ASCIZ	'Extended Mode Functions'
5093					.EVEN	
5094					;	
5095					;	
5096					;	
5097					;	
5098					;	
5099					;	
5100					;	
5101	073164				T35REST:	
5102	073164				SAVREG	;SAVE THE REGISTERS
5103	073170	012701	067370		MOV	;START OF THE PACKET
5104	073174	012721	100004		MOV	;WRITE SUBSYSTEM MEM. WITH ACK,
5105	073200	012721	067400		MOV	;ADDRESS OF CHARAISTICS DATA BLOCK
5106	073204	005021			CLR	;EXTENDED ADDRESS
5107	073206	012721	000012		MOV	;SIZE OF DATA BLOCK IN BYTES
5108	073212	012721	067412		MOV	;ADDRESS OF MESSAGE BUFFER
5109	073216	005021			CLR	
5110	073220	012721	000024		MOV	;LENGTH OF MESSAGE BUFFER
5111	073224	005021			CLR	
5112	073226	012711	000000		MOV	;SELECT DRIVE ZERO
5113	073232	012702	000030		MOV	;NUMBER OF LOCATIONS TO BE CLEARED
5114	073236	012762	177777	067412	MOV	;ALL ONES TO MESSAGE BUFFER
5115	073244	005742			TST	;NEXT LOCATION
5116	073246	022702	000000		CMP	;AT END OF LOOP YET
5117	073252	001371			BNE	;KEEP GOING UNTIL DONE
5118	073254	000207			RTS	;RETURN
5119						
5120	073256				T35RT2:	
5121	073256				SAVREG	;SAVE THE REGISTERS
5122	073262	012701	067500		MOV	;START OF THE PACKET
5123	073266	012721	100006		MOV	;WRITE SUBSYSTEM MEM. WITH ACK,
5124	073272	012721	067520		MOV	;ADDRESS OF DATA BLOCK
5125	073276	005021			CLR	;EXTENDED ADDRESS
5126	073300	012721	000006		MOV	;SIZE OF DATA BLOCK IN BYTES
5127	073304	005021			CLR	

```

5128 073306 012701 067520      MOV      #T35BF2,R1      ;POINT TO DATA SEL AREA
5129 073312 005021              CLR      (R1)+
5130 073314 005011              CLR      (R1)
5131 073316 000207              RTS      PC              ;RETURN
5132 073320                      T35RT3:
5133 073320                      SAVREG      ;SAVE REGISTERS
5134 073324 012701 067510      MOV      #T35PK3,R1      ;SET UP POINTER ADDRESS
5135 073330 005021              CLR      (R1)+          ;COMMAND SPACE
5136 073332 005021              CLR      (R1)+          ;ADDRESS OF DATA BLOCK
5137 073334 005021              CLR      (R1)+          ;EXTENDED ADDRESS
5138 073336 005011              CLR      (R1)          ;SIZE OF DATA TRANSFER BLOCK
5139 073340 000207              RTS      PC              ;RETURN
5140 073342
      073342
      073342 104401
L10063: TRAP C:ETST

5141 .SBTTL TEST 8: RECORD BUFFERING
5142
5143
5144
5145
5146
5147
5148
5149
5150
5151
5152
5153
5154
5155
5156
5157
5158
5159
5160
5161
5162
5163
5164
5165
5166
5167
5168
5169
5170
5171
5172
5173
5174
5175
5176
5177
5178
5179
5180
5181
5182

```

THIS TEST VERIFIES THAT RECORD BUFFERING, USED FOR WRITE DATA AND READ NEXT COMMANDS, OPERATES PROPERLY AND IS PROPERLY CONTROLLED BY THE EXTENDED CHARACTERISTICS DATA WORD. IF THE M7196 CONTROLLER MODULE IS NOT ALREADY IN EXTENDED FEATURES MODE (AS CONTROLLED BY THE DIP SWITCH ON THE MODULE), IT IS PLACED INTO THAT MODE BY INVERTING THE SENSE OF THE SWITCH USING THE WRITE SUBSYSTEM MEMORY COMMAND. NOTE THAT RECORD BUFFERING HAS BEEN ENABLED IN PREVIOUS TESTS OF READ AND WRITE AND SO HAS BEEN PARTIALLY TESTED ALREADY. THIS TEST VERIFIES THAT BUFFERING IS ACTUALLY OPERATING. THE FOLLOWING SUBTESTS ARE PERFORMED:

VERIFIES THAT NORMAL BUFFERING ON WRITE DATA COMMANDS OPERATES PROPERLY AT LOW TAPE SPEED. THE FOLLOWING SEQUENCE IS PERFORMED:

1. THE TAPE IS REWOUND.
2. BUFFERING IS DISABLED AND LOW TAPE SPEED IS SELECTED (VIA WRITE CHARACTERISTICS COMMAND).
3. AN INITIAL RECORD IS WRITTEN ONTO THE TAPE IN ORDER TO MOVE THE TAPE OFF BOT.
4. THE PROGRAM DELAYS FOR A TIME SUFFICIENT TO ALLOW THE TAPE TO REPOSITION AND COME TO REST.
5. A WRITE DATA COMMAND, WITH A BYTE COUNT LESS THAN 3.5K, IS ISSUED, AND THE PROGRAM COUNTS, IN A WAIT LOOP, THE TIME IT TAKES TO RECEIVE COMMAND TERMINATION. THIS SHOULD BE A RELATIVELY LONG TIME SINCE BUFFERING IS DISABLED.
6. BUFFERING IS ENABLED.
7. THE WRITE DATA COMMAND IS AGAIN ISSUED, WITH THE SAME BYTE COUNT AS THAT USED PREVIOUSLY. THE TIME TO COMPLETION IS AGAIN MEASURED.

TEST 1 HARDWARE TEST 1 8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 8: RECORD BUFFERING

SEQ 196

5233	073472	001356		BNE	10:		;BR, IF COUNTER NOT DONE		
5234	073474	005237	002214	INC	FATFLG		;ERROR COUNT		
5238	073500	010001		MOV	R0,R1		;CONTENTS OF TSSR REGISTER		
5239	073502			ERRDF	ERRNO, SFIERR, SFIMSG		;FATAL ERROR TSSR WAS NOT OK		
	073502	104455					TRAP	C\$ERDF	
	073504	001441					.WORD	801	
	073506	003646					.WORD	SFIERR	
	073510	012114					.WORD	SFIMSG	
5240	073512	013737	002174	MOV	UNITN, T36DSW	075600 20:	;SET UP DRIVE NUMBER		
5241	073520	012704	075560	MOV	@T36PACKET, R4		;SUBROUTINE NEEDS PACKET ADDRESS		
5242	073524	004737	010742	JSR	PC, WRCHR		;ISSUE WRITE CHARACTERISTICS		
5243	073530	103407		BCS	25:		;BR, IF COMMAND ISSUED OK		
5244	073532	005237	002214	INC	FATFLG		;ERROR COUNT		
5248	073536	010001		MOV	R0,R1		;SAVE CONTENTS OF TSSR		
5249	073540			ERRHRD	ERRNO, WRTMSG, SFIMSG		;WRITE CHARACTERISTIC FAILED		
	073540	104456					TRAP	C\$ERHRD	
	073542	001442					.WORD	802	
	073544	005052					.WORD	WRTMSG	
	073546	012114					.WORD	SFIMSG	
5250	073550			25:	CKLOOP		;LOOP IF SELECTED		
	073550	104406					TRAP	C\$CLP1	
5251	073552	004737	011074	JSR	PC, REWIND		;CALL TAPE REWIND COMMAND		
5252	073556	103407		BCS	30:		;BR, IF NO PROBLEM		
5253	073560	010004		MOV	R0,R4		;SET UP REWIND PACKET ADDRESS		
5254	073562	005237	002214	INC	FATFLG		;ERROR COUNT		
5258	073566			ERRHRD	ERRNO, T36RWN, PKTSSR		;REWIND NOT ACCEPTED		
	073566	104456					TRAP	C\$ERHRD	
	073570	001443					.WORD	803	
	073572	077141					.WORD	T36HWN	
	073574	012126					.WORD	PKTSSR	
5259	073576			30:	CKLOOP		;LOOP IF SELECTED		
	073576	104406					TRAP	C\$CLP1	
5260	073600	013701	075610	MOV	T36BFR*6, R1		;PICK UP XSTO		
5261	073604	010102		MOV	R1, R2		;SET UP EXPECTED		
5262	073606	052702	000002	BIS	@BIT1, R2		;SET BOT BIT IN EXPECTED		
5263	073612	020102		CMP	R1, R2		;DOES EXP = REC'D		
5264	073614	001406		BEQ	40:		;BR, IF EQUAL (OK)		
5265	073616	005237	002214	INC	FATFLG		;ERROR COUNT		
5269	073622			ERRHRD	ERRNO, T36BOT, EXPREC		;TAPE NOT AT BOT AFTER REWIND		
	073622	104456					TRAP	C\$ERHRD	
	073624	001444					.WORD	804	
	073626	076635					.WORD	T36BOT	
	073630	015554					.WORD	EXPREC	
5270	073632			40:	CKLOOP		;LOOP IF SELECTED		
	073632	104406					TRAP	C\$CLP1	
5271	073634	013737	002174	MOV	UNITN, T36DSW	075600	;SET UP DRIVE NUMBER		
5272	073642	052737	000030	BIS	@BIT3!@BIT4, T36DSW	075600	;25-APR-83 REV B - TURN ON THE BUFFERING		
5273	073650	012704	075560	MOV	@T36PACKET, R4		;SUBROUTINE NEEDS PACKET ADDRESS		
5274	073654	004737	010742	JSR	PC, WRCHR		;ISSUE WRITE CHARACTERISTICS		
5275	073660	103407		BCS	50:		;BR, IF COMMAND ISSUED OK		
5276	073662	005237	002214	INC	FATFLG		;ERROR COUNT		
5280	073666	010001		MOV	R0,R1		;SAVE CONTENTS OF TSSR		
5281	073670			ERRHRD	ERRNO, WRTMSG, SFIMSG		;WRITE CHARACTERISTIC FAILED		
	073670	104456					TRAP	C\$ERHRD	
	073672	001445					.WORD	805	
	073674	005052					.WORD	WRTMSG	
	073676	012114					.WORD	SFIMSG	

5282	073700			50%:	CKLOOP			;LOOP IF SELECTED		
	073700	104406							TRAP	C%CLP1
5283	073702	012737	003720	075706	MOV	#2000.,T36SZ		;SET UP RECORD SIZE		
5284	073710	013737	003116	075702	MOV	FREE,T36WB		;ADDRESS OF WRITE BUFFER		
5285	073716	012737	140005	075700	MOV	#140005,T36PK3		;WRITE DATA,ACK,CVC=1 COMMAND		
5286	073724	012704	075700		MOV	#T36PK3,R4		;SET UP R4 WITH PACKET ADDRESS		
5287	073730	010465	000000		MOV	R4,TSD8(R5)		;ISSUE COMMAND		
5288	073734	004737	016330		JSR	PC,WAITF		;WAIT FOR SSR TO SET		
5289	073740	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS		
5290	073744	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED		
5291	073750	020102			CMP	R1,R2		;ARE THEY EQUAL		
5292	073752	001406			BEQ	60%		;BR, IF OK		
5293	073754	005237	002214		INC	FATFLG		;ERROR COUNT		
5297	073760				ERRHRD	ERRNO,WRTErr,PKTSSR		;TSSR INCORRECT AFTER READ DATA		
	073760	104456							TRAP	C%ERHRD
	073762	0C1446							.WORD	806
	073764	005107							.WORD	WRTErr
	073766	012126							.WORD	PKTSSR
5298	073770			60%:	CKLOOP			;LOOP IF SELECTED		
	073770	104406							TRAP	C%CLP1
5299	073772	012737	000005	075732	MOV	#05.,T36DLY		;25-APR-83 REV B - DELAY FOR TAPE TO STOP		
5300	074000			70%:	DELAY	1		;25-APR-83 REV B - DELAY ROUTINE CALL		
	074000	012727	000001						MOV	#1,(PC)+
	074004	000000							.WORD	0
	074006	013727	002116						MOV	L%DLY,(PC)+
	074012	000000							.WORD	0
	074014	005367	177772						DEC	-6(PC)
	074020	001375							BNE	.-4
	074022	005367	177756						DEC	-22(PC)
	074026	001367							BNE	.-20
5301	074030	005337	075732		DEC	T36DLY		;BUMP COUNTER DOWN		
5302	074034	001361			BNE	70%		;BR, IF MORE DELAY TO GO		
5303	074036	012737	006642	075706	MOV	#3490.,T36SZ		;SET SIZE OF TRANSFER		
5304	074044	012737	140005	075700	MOV	#140005,T36PK3		;WRITE DATA,ACK,CVC=1 COMMAND		
5305	074052	012704	075700		MOV	#T36PK3,R4		;SET UP R4 WITH PACKET ADDRESS		
5306	074056	005037	075726		CLR	T36CNT		;CLEAR COUNTER		
5307	074062	012737	001750	075732	MOV	#1000.,T36DLY		;SET DROP DEAD COUNTER VALUE		
5308	074070	010465	000000		MOV	R4,TSD8(R5)		;ISSUE COMMAND		
5309	074074	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS		
5310	074100	032701	000200	80%:	BIT	#SSR,R1		;CHECK FOR SSR SET		
5311	074104	001021			BNE	90%		;BR, IF SSR IS SET		
5312	074106	005237	075726		INC	T36CNT		;BUMP CYCLE COUNTER		
5313	074112				DELAY	1		;CUT NUMBER OF LOOPS DOWN		
	074112	012727	000001						MOV	#1,(PC)+
	074116	000000							.WORD	0
	074120	013727	002116						MOV	L%DLY,(PC)+
	074124	000000							.WORD	0
	074126	005367	177772						DEC	-6(PC)
	074132	001375							BNE	.-4
	074134	005367	177756						DEC	-22(PC)
	074140	001367							BNE	.-20
5314	074142	005337	075732		DEC	T36DLY		;BUMP DROP DEAD COUNTER		
5315	074146	001352			BNE	80%		;BR, IF THERE IS STILL TIME		
5316	074150	012702	000200	90%:	MOV	#SSR,R2		;SET UP EXPECTED		
5317	074154	020102			CMP	R1,R2		;ARE THEY EQUAL		
5318	074156	001406			BEQ	100%		;BR, IF OK		
5319	074160	005237	002214		INC	FATFLG		;ERROR COUNT		

5323	074164				ERRHRD	ERRNO,T36WDE,PKTSSR		;TSSR INCORRECT AFTER READ DATA		
	074164	104456						TRAP	C\$ERHRD	
	074166	001447						.WORD	807	
	074170	076563						.WORD	T36WDE	
	074172	012126						.WORD	PKTSSR	
5324	074174			100\$:	CKLOOP			;LOOP IF SELECTED		
	074174	104406						TRAP	C\$CLP1	
5325	074176	013737	002174	075600	MOV	UNITN,T36DSW		;SET UP DRIVE NUMBER		
5326	074204	052737	000010	075600	BIS	@BIT3,T36DSW		;25-APR-83 REV B - TURN OFF BUFFERING		
5327	074212	012704	075560		MOV	@T36PACKET,R4		;SUBROUTINE NEEDS PACKET ADDRESS		
5328	074216	004737	010742		JSR	PC,WRTCHR		;ISSUE WRITE CHARACTERISTICS		
5329	074222	103407			BCS	110\$;BR, IF COMMAND ISSUED OK		
5330	074224	005237	002214		INC	FATFLG		;ERROR COUNT		
5334	074230	010001			MOV	R0,R1		;SAVE CONTENTS OF TSSR		
5335	074232				ERRHRD	ERRNO,WRTMSG,SFIMSG		;WRITE CHARACTERISTIC FAILED		
	074232	104456						TRAP	C\$ERHRD	
	074234	001450						.WORD	808	
	074236	005052						.WORD	WRTMSG	
	074240	012114						.WORD	SFIMSG	
5336	074242			110\$:	CKLOOP			;LOOP IF SELECTED		
	074242	104406						TRAP	C\$CLP1	
5337	074244	012737	006642	075706	MOV	@3490.,T36SZ		;SET SIZE OF TRANSFER		
5338	074252	012737	140005	075700	MOV	@140005,T36PK3		;WRITE DATA,ACK,CVC-1 COMMAND		
5339	074260	012704	075700		MOV	@T36PK3,R4		;SET UP R4 WITH PACKET ADDRESS		
5340	074264	005037	075730		CLR	T36CNU		;CLEAR COUNTER		
5341	074270	012737	001750	075732	MOV	@1000.,T36DLY		;SET DROP DEAD COUNTER VALUE		
5342	074276	010465	000000		MOV	R4,T5DB(R5)		;ISSUE COMMAND		
5343	074302	016501	000002		MOV	TSSR(R5),R1		;GET TSSR CONTENTS		
5344	074306	032701	000200	120\$:	BIT	@SSR,R1		;CHECK FOR SSR SET		
5345	074312	001021			BNE	130\$;BR, IF SSR IS SET		
5346	074314	005237	075730		INC	T36CNU		;BUMP CYCLE COUNTER		
5347	074320				DELAY	1		;CUT NUMBER OF LOOPS DOWN		
	074320	012727	000001					MOV	@1,(PC)+	
	074324	000000						.WORD	0	
	074326	013727	002116					MOV	L\$DLY,(PC)+	
	074332	000000						.WORD	0	
	074334	005367	177772					DEC	-6(PC)	
	074340	001375						BNE	-.4	
	074342	005367	177756					DEC	-22(PC)	
	074346	001367						BNE	.-20	
5348	074350	005337	075732		DEC	T36DLY		;BUMP DROP DEAD COUNTER		
5349	074354	001352			BNE	120\$;BR, IF THERE IS STILL TIME		
5350	074356	012702	000200	130\$:	MOV	@SSR,R2		;SET UP EXPECTED		
5351	074362	020102			CMP	R1,R2		;ARE THEY EQUAL		
5352	074364	001406			BEQ	140\$;BR, IF OK		
5353	074366	005237	002214		INC	FATFLG		;ERROR COUNT		
5357	074372				ERRHRD	ERRNO,WRTERR,PKTSSR		;TSSR INCORRECT AFTER WRITE DATA		
	074372	104456						TRAP	C\$ERHRD	
	074374	001451						.WORD	809	
	074376	005107						.WORD	WRTERR	
	074400	012126						.WORD	PKTSSR	
5358	074402			140\$:	CKLOOP			;LOOP IF SELECTED		
	074402	104406						TRAP	C\$CLP1	
5359	074404	013701	075726		MOV	T36CNT,R1		;GET FIRST COUNTER		
5360	074410	013702	075730		MOV	T36CNU,R2		;GET SECOND COUNTER		
5361	074414	020102			CMP	R1,R2		;25 APR-83 REV B COMPARE EM		
5362	074416	003406			BLE	300\$;BR, IF VALUES ARE CORRECT (OK)		

TEST 1 - HARDWARE TEST 1 8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 8: RECORD BUFFERING

SEQ 199

```

5363 074420 005237 002214          INC      FATFLG          ;ERROR COUNT
5367 074424          ERRHRD  ERRNO,T36NAS,EXPREC ;TAPE NOT AT CORRECT SPEED
      074424 104456          TRAP      C$ERHRD
      074426 001452          .WORD    810
      074430 075734          .WORD    T36NAS
      074432 015554          .WORD    EXPREC
5368 074434          300$;  CKLOOP          ;LOOP IF SELECTED          TRAP      C$CLP1
      074434 104406          ENDSUB
5369 074436          L10071;
      074436 104403          TRAP      C$ESUB
5370 074440 023727 002214 000017  CMP      FATFLG,015,    ;IS ERROR COUNT AT 25
5371 074446 103402          BLO      999$          ;BR, IF LESS THAN 25
5372 074450 004737 017262          JSR      PC,CKDROP     ;TRY TO DROP THE UNIT
5373 074454          999$;
5374          ;*
5375          ;
5376          ;TEST 8, SUBTEST 2
5377          ;
5378          ;
5379          ;
5380          ;
5381          ;
5382          ;
5383          ;
5384          ;
5385          ;
5386          ;
5387          ;
5388          ;
5389          ;
5390          ;
5391          ;
5392          ;
5393          ;
5394          ;
5395          ;
5396          ;
5397          ;
5398          ;
5399          ;
5400          ;
5401          ;
5402          ;
5403          ;
5404          ;
5405          ;
5406          ;
5407          ;
5408          ;
5409          ;
5410          ;
5411          ;
5412          ;
5413          ;
5414          ;
5415          ;

```

THIS TEST VERIFIES THAT RECORD BUFFERING, USED FOR WRITE DATA AND READ NEXT COMMANDS, OPERATES PROPERLY AND IS PROPERLY CONTROLLED BY THE EXTENDED CHARACTERISTICS DATA WORD. IF THE M7196 CONTROLLER MODULE IS NOT ALREADY IN EXTENDED FEATURES MODE (AS CONTROLLED BY THE DIP SWITCH ON THE MODULE), IT IS PLACED INTO THAT MODE BY INVERTING THE SENSE OF THE SWITCH USING THE WRITE SUBSYSTEM MEMORY COMMAND. NOTE THAT RECORD BUFFERING HAS BEEN ENABLED IN PREVIOUS TESTS OF READ AND WRITE AND SO HAS BEEN PARTIALLY TESTED ALREADY. THIS TEST VERIFIES THAT BUFFERING IS ACTUALLY OPERATING. THE FOLLOWING SUBTESTS ARE PERFORMED:

VERIFIES THAT NORMAL BUFFERING ON WRITE DATA COMMANDS OPERATES PROPERLY AT LOW TAPE SPEED. THE FOLLOWING SEQUENCE IS PERFORMED:

1. THE TAPE IS REWOUND.
2. BUFFERING IS DISABLED AND LOW TAPE SPEED IS SELECTED (VIA WRITE CHARACTERISTICS COMMAND).
3. AN INITIAL RECORD IS WRITTEN ONTO THE TAPE IN ORDER TO MOVE THE TAPE OFF BOT.
4. THE PROGRAM DELAYS FOR A TIME SUFFICIENT TO ALLOW THE TAPE TO REPOSITION AND COME TO REST.
5. A WRITE DATA COMMAND, WITH A BYTE COUNT LESS THAN 3.5K, IS ISSUED, AND THE PROGRAM COUNTS, IN A WAIT LOOP, THE TIME IT TAKES TO RECEIVE COMMAND TERMINATION. THIS SHOULD BE A RELATIVELY LONG TIME SINCE BUFFERING IS DISABLED.
6. BUFFERING IS ENABLED.
7. THE WRITE DATA COMMAND IS AGAIN ISSUED, WITH THE SAME BYTE COUNT AS THAT USED PREVIOUSLY. THE TIME TO COMPLETION IS AGAIN MEASURED.

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 8: RECORD BUFFERING

SEQ 201

```

5460 074642 010004          MOV      R0,R4          ;SET UP REWIND PACKET ADDRESS
5461 074644 005237 002214    INC      FATFLG          ;ERROR COUNT
5465 074650          ERRHRD  ERRNO,T36RWN,PKTSSR ;REWIND NOT ACCEPTED
           074650 104456          TRAP      C$ERHRD
           074652 001455          .WORD     813
           074654 077141          .WORD     T36RWN
           074656 012126          .WORD     PKTSSR

5466          30$: CKLOOP      ;LOOP IF SELECTED
           074660 104406          TRAP      C$CLP1
5467 074662 013701 075610    MOV      T36BFR+6,R1    ;PICK UP XSTO
5468 074666 010102          MOV      R1,R2          ;SET UP EXPECTED
5469 074670 052702 000002    BIS      @BIT1,R2       ;SET BOT BIT IN EXPECTED
5470 074674 020102          CMP      R1,R2          ;DOES EXP = REC'D
5471 074676 001406          BEQ      40$            ;BR, IF EQUAL (OK)
5472 074700 005237 002214    INC      FATFLG          ;ERROR COUNT
5476 074704          ERRHRD  ERRNO,T36BOT,EXPREC ;TAPE NOT AT BOT AFTER REWIND
           074704 104456          TRAP      C$ERHRD
           074706 001456          .WORD     814
           074710 076635          .WORD     T36BOT
           074712 015554          .WORD     EXPREC

5477          40$: CKLOOP      ;LOOP IF SELECTED
           074714 104406          TRAP      C$CLP1
5478 074716 013737 002174 075600    MOV      UNITN,T36DSW   ;SET UP DRIVE NUMBER
5479 074724 052737 000030 075600    BIS      @BIT3!BIT4,T36DSW ;25-APR-83 REV B - TURN ON THE BUFFERING
5480 074732 012704 075560    MOV      @T36PACKET,R4 ;SUBROUTINE NEEDS PACKET ADDRESS
5481 074736 004737 010742    JSR      PC,WRTCHR      ;ISSUE WRITE CHARACTERISTICS
5482 074742 103407          BCS      50$            ;BR, IF COMMAND ISSUED OK
5483 074744 005237 002214    INC      FATFLG          ;ERROR COUNT
5487 074750 010001          MOV      R0,R1          ;SAVE CONTENTS OF TSSR
5488 074752          ERRHRD  ERRNO,WRTMSG,SFIMSG ;WRITE CHARACTERISTIC FAILED
           074752 104456          TRAP      C$ERHRD
           074754 001457          .WORD     815
           074756 005052          .WORD     WRTMSG
           074760 012114          .WORD     SFIMSG

5489          50$: CKLOOP      ;LOOP IF SELECTED
           074762 104406          TRAP      C$CLP1
5490 074764 012737 003720 075706    MOV      @2000.,T36SZ   ;SET UP RECORD SIZE
5491 074772 013737 003116 075702    MOV      FREE,T36WB     ;ADDRESS OF WRITE BUFFER
5492 075000 012737 140005 075700    MOV      @140005,T36PK3 ;WRITE DATA,ACK,CVC-1 COMMAND
5493 075006 012704 075700    MOV      @T36PK3,R4     ;SET UP R4 WITH PACKET ADDRESS
5494 075012 010465 000000    MOV      R4,TSD8(R5)    ;ISSUE COMMAND
5495 075016 004737 016330    JSR      PC,WAITF       ;WAIT FOR SSR TO SET
5496 075022 016501 000002    MOV      TSSR(R5),R1    ;GET TSSR CONTENTS
5497 075026 012702 000200    MOV      @SSR,R2        ;SET UP EXPECTED
5498 075032 020102          CMP      R1,R2          ;ARE THEY EQUAL
5499 075034 001406          BEQ      60$            ;BR, IF OK
5500 075036 005237 002214    INC      FATFLG          ;ERROR COUNT
5504 075042          ERRHRD  ERRNO,WRTERR,PKTSSR ;TSSR INCORRECT AFTER READ DATA
           075042 104456          TRAP      C$ERHRD
           075044 001460          .WORD     816
           075046 005107          .WORD     WRTERR
           075050 012126          .WORD     PKTSSR

5505          60$: CKLOOP      ;LOOP IF SELECTED
           075052 104406          TRAP      C$CLP1
5506 075054 012737 000005 075732    MOV      @05.,T36DLY    ;25-APR-83 REV B - DELAY FOR TAPE TO STOP
5507 075062          70$: DELAY 1          ;25-APR-83 REV B - DELAY ROUTINE CALL
           075062 012727 000001    MOV      @1,(PC)+

```

075066	000000						.WORD	0
075070	013727	002116					MOV	L\$DLY,(PC)+
075074	000000						.WORD	0
075076	005367	177772					DEC	-6(PC)
075102	001375						BNE	.-4
075104	005367	177756					DEC	-22(PC)
075110	001367						BNE	.-20
5508	075112	005337	075732			DEC	T36DLY	;BUMP COUNTER DOWN
5509	075116	001361				BNE	70\$;BR, IF MORE DELAY TO GO
5510	075120	012737	006642	075706		MOV	#3490.,T36SZ	;SET SIZE OF TRANSFER
5511	075126	012737	140005	075700		MOV	#140005,T36PK3	;WRITE DATA,ACK,CVC=1 COMMAND
5512	075134	012704	075700			MOV	#T36PK3,R4	;SET UP R4 WITH PACKET ADDRESS
5513	075140	005037	075726			CLR	T36CNT	;CLEAR COUNTER
5514	075144	012737	001750	075732		MOV	#1000.,T36DLY	;SET DROP DEAD COUNTER VALUE
5515	075152	010465	000000			MOV	R4,TSD8(R5)	;ISSUE COMMAND
5516	075156	016501	000002	80\$:		MOV	TSSR(R5),R1	;GET TSSR CONTENTS
5517	075162	032701	000200			BIT	#SSR,R1	;CHECK FOR SSR SET
5518	075166	001021				BNE	90\$;BR, IF SSR IS SET
5519	075170	005237	075726			INC	T36CNT	;BUMP CYCLE COUNTER
5520	075174					DELAY	1	;CUT NUMBER OF LOOPS DOWN
	075174	012727	000001				MOV	#1,(PC)+
	075200	000000					.WORD	0
	075202	013727	002116				MOV	L\$DLY,(PC)+
	075206	000000					.WORD	0
	075210	005367	177772				DEC	-6(PC)
	075214	001375					BNE	.-4
	075216	005367	177756				DEC	-22(PC)
	075222	001367					BNE	.-20
5521	075224	005337	075732			DEC	T36DLY	;BUMP DROP DEAD COUNTER
5522	075230	001352				BNE	80\$;BR, IF THERE IS STILL TIME
5523	075232	012702	000200	90\$:		MOV	#SSR,R2	;SET UP EXPECTED
5524	075236	020102				COMP	R1,R2	;ARE THEY EQUAL
5525	075240	001406				BEQ	100\$;BR, IF OK
5526	075242	005237	002214			INC	FATFLG	;ERROR COUNT
5530	075246					ERRHRD	ERRNO,T36WDE,PKTSSR	;TSSR INCORRECT AFTER READ DATA
	075246	104456					TRAP	C\$ERHRD
	075250	001461					.WORD	817
	075252	076563					.WORD	T36WDE
	075254	012126					.WORD	PKTSSR
5531	075256			100\$:		CKLOOP		;LOOP IF SELECTED
	075256	104406					TRAP	C\$CLP1
5532	075260	013737	002174	075600		MOV	UNITN,T36DSW	;SET UP DRIVE NUMBER
5533	075266	052737	000010	075600		BIS	#BIT3,T36DSW	;25-APR-83 REV B - TURN OFF BUFFERING
5534	075274	012704	075560			MOV	#T36PACKET,R4	;SUBROUTINE NEEDS PACKET ADDRESS
5535	075300	004737	010742			JSR	PC,WRTCHR	;ISSUE WRITE CHARACTERISTICS
5536	075304	103407				BCS	110\$;BR, IF COMMAND ISSUED OK
5537	075306	005237	002214			INC	FATFLG	;ERROR COUNT
5541	075312	010001				MOV	RO,R1	;SAVE CONTENTS OF TSSR
5542	075314					ERRHRD	ERRNO,WRTMSG,SFIMSG	;WRITE CHARACTERISTIC FAILED
	075314	104456					TRAP	C\$ERHRD
	075316	001462					.WORD	818
	075320	005052					.WORD	WRTMSG
	075322	012114					.WORD	SFIMSG
5543	075324			110\$:		CKLOOP		;LOOP IF SELECTED
	075324	104406					TRAP	C\$CLP1
5544	075326	012737	006642	075706		MOV	#3490.,T36SZ	;SET SIZE OF TRANSFER
5545	075334	012737	140005	075700		MOV	#140005,T36PK3	;WRITE DATA,ACK,CVC=1 COMMAND

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 8: RECORD BUFFERING

SEQ 203

5546	075342	012704	075700		MOV	#T36PK3,R4		;SET UP R4 WITH PACKET ADDRESS
5547	075346	005037	075730		CLR	T36CNU		;CLEAR COUNTER
5548	075352	012737	001750	075732	MOV	#1000.,T36DLY		;SET DROP DEAD COUNTER VALUE
5549	075360	010465	000000		MOV	R4,TSD8(R5)		;ISSUE COMMAND
5550	075364	016501	000002	120\$:	MOV	TSSR(R5),R1		;GE; TSSR CONTENTS
5551	075370	032701	000200		BIT	#SSR,R1		;CHECK FOR SSR SET
5552	075374	001021			BNE	130\$;BR, IF SSR IS SET
5553	075376	005237	075730		INC	T36CNU		;BUMP CYCLE COUNTER
5554	075402				DELAY	1		;CUT NUMBER OF LOOPS DOWN
	075402	012727	000001					MOV #1,(PC)+
	075406	000000						.WORD 0
	075410	013727	002116					MOV L\$DLY,(PC)+
	075414	000000						.WORD 0
	075416	005367	177772					DEC -6(PC)
	075422	001375						BNE .-4
	075424	005367	177756					DEC -22(PC)
	075430	001367						BNE .-20
5555	075432	005337	075732		DEC	T36DLY		;BUMP DROP DEAD COUNTER
5556	075436	001352			BNE	120\$;BR, IF THERE IS STILL TIME
5557	075440	012702	000200	130\$:	MOV	#SSR,R2		;SET UP EXPECTED
5558	075444	020102			CMP	R1,R2		;ARE THEY EQUAL
5559	075446	001406			BEQ	140\$;BP, IF OK
5560	075450	005237	002214		INC	FATFLG		;ERROR COUNT
5564	075454				ERRHRD	ERRNO,WRERR,PKTSSR		;TSSR INCORRECT AFTER WRITE DATA
	075454	104456						TRAP C\$ERHRD
	075456	001463						.WORD 819
	075460	005107						.WORD WRERR
	075462	012126						.WORD PKTSSR
5565	075464			140\$:	CKLOOP			;LOOP IF SELECTED
	075464	104406						TRAP C\$CLP1
5566	075466	013701	075726		MOV	T36CNT,R1		;GET FIRST COUNTER
5567	075472	013702	075730		MOV	T36CNU,R2		;GET SECOND COUNTER
5568	075476	020102			CMP	R1,R2		;25-APR-83 REV B - COMPARE EM
5569	075500	003406			BLE	300\$;BR, IF VALUES ARE CORRECT (OK)
5570	075502	005237	002214		INC	FATFLG		;ERROR COUNT
5574	075506				ERRHRD	ERRNO,T36NAS,EXPREC		;TAPE NOT AT CORRECT SPEED
	075506	104456						TRAP C\$ERHRD
	075510	001464						.WORD 820
	075512	075734						.WORD T36NAS
	075514	015554						.WORD EXPREC
5575	075516			300\$:	CKLOOP			;LOOP IF SELECTED
	075516	104406						TRAP C\$CLP1
5576	075520				ENDSUB			
	075520							L10072:
	075520	104403						TRAP C\$ESUB
5577	075522	023727	002214	000017	CMP	FATFLG,#15.		;IS ERROR COUNT AT 25
5578	075530	103402			BLO	999\$;BR, IF LESS THAN 25
5579	075532	004737	017262		JSR	PC,CKDROP		;TRY TO DROP THE UNIT
5580	075536			999\$:				
5581								
5582								
5583								
5584	075536	004737	016536		JSR	PC,TSTLOOP		;DO WE NEED TO ITERATE TEST
5585	075542	103002			BCC	163\$;BR, IF NO LOOP REQUIRED
5586	075544	000137	073400		JMP	T36LOOP		;EXECUTE AGAIN
5587	075550			163\$:				
5588	075550				EXIT	TST		;ALL DONE THIS TEST

TRAP C\$EXIT
 .WORD L10070-

075550 104432
 075552 003344
 5589
 5590
 5591
 5593 075560
 5595 075560
 5596 075560 100004
 5597 075562 075570
 5598 075564 000000
 5599 075566 000012
 5600 075570
 5601 075570 075602
 5602 075572 000000
 5603 075574 000024
 5604 075576 000000
 5605 075600 000000
 5606 075602
 5607
 5608
 5609
 5611 075670
 5613 075670
 5614 075670 100006
 5615 075672 075710
 5616 075674 000000
 5617 075676 000006
 5618
 5622 075700
 5623 075700 100005
 5624 075702
 5625 075702 003116
 5626 075704 000000
 5627 075706 000000
 5628
 5629
 5630
 5631
 5632 075710
 5633 075710 010
 5634 075711 200
 5635 075712 000000
 5636 075714 000000
 5637
 5638
 5639
 5640
 5641
 5642 075716 100205
 5643 075720 100605
 5644 075722 102205
 5645 075724 177777
 5646
 5647
 5648 075726 000000
 5649 075730 000000
 5650 075732 000000

```

;+
;LOCAL STORAGE FOR THIS TEST
;-
        .=<.+10>E177770
T36PACKET:
        .WORD 100004
        .WORD T36DATA
        .WORD 0
        .WORD 10.
T36DATA:
        .WORD T36BFR
        .WORD 0
        .WORD 20.
        .WORD 0
T36DSW: .WORD 0
T36BFR: .BLKW 25.
;
;WRITE SUBSYSTEM MEMORY COMMAND PACKET
;
        .=<.+10>E177770
T36PK2:
        .WORD 100006
        .WORD T36BF2
        .WORD 0
        .WORD 6.
T36PK3:
        .WORD 100005
T36RB:
T36WB: .WORD FREE
        .WORD 0
T36SZ: .WORD 0
        .EVEN
;
;
T36BF2:
T36BS0: .BYTE 10
T36BS1: .BYTE 200
T36S2: .WORD 0
T36S3: .WORD 0
;
;
        .EVEN
;TAPE MOTION PACKET COMMAND VALUES
T36RN: .WORD 100205
T36WR: .WORD 100605
T36CON: .WORD 102205
        .WORD 177777
;
T36CNT: .WORD 0
T36CNU: .WORD 0
T36DLY: .WORD 0
    
```

```

;COMMAND PACKET FOR TEST
;WRITE CHARACTERISTICS COMMAND, WITH , ACK
;ADDRESS OF CHARACTERISTICS BLOCK

;STARTING VALUE OF BLOCK SIZE
;CHARACTERISTICS DATA BLOCK
;ADDRESS OF MESSAGE BUFFER

;LENGTH OF MESSAGE BUFFER

;SELECT DRIVE 0
;MESSAGE BUFFER

;WRITE SUB SYS MEM COMMAND, AND ACK
;ADDRESS OF SELECT BLOCK DATA

;SIZE OF DATA PACKET

;REREAD COMMAND, AND ACK

;ADDRESS OF WRITE BUFFER

;SIZE OF BUFFER (EXTENT)

;BSEL0 AREA
;BSEL1 AREA
;SEL 2 AREA
;DATA AREA

;REREAD DATA (NEXT)
;REREAD DATA RETRY
;WRITE CONTINUOUS
;END OF DATA

;TAPE TIMER COUNTER STORAGE AREA
;TAPE TIMER COUNTER STORAGE AREA
;DELAY COUNTER
    
```

```

5651
5652          ;*
5653          ;LOCAL TEXT MESSAGES FOR TEST
5654          ;-
5655 075734    111    155    160 T36NAS: .ASCIZ 'Improper Tape Controller Buffering Speed'
5656 076005    124    141    160 T36WNG: .ASCIZ 'Tape Position Incorrect After REREAD Previous (OPP=1)'
5657 076073    124    123    123 T36RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
5658 076142    122    105    122 T36RRF: .ASCIZ 'REREAD Previous (Space Reverse, Read Forward) Command Failed'
5659 076237    120    117    123 T36SC: .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
5660 076321    122    111    102 T36LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'
5661 076371    124    123    123 T36WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
5662 076446    111    154    154 T36LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
5663 076527    122    105    122 T36SSR: .ASCIZ 'REREAD COMMAND Not Accepted'
5664 076563    124    123    123 T36WDE: .ASCIZ 'TSSR Not Correct After WRITE DATA Command'
5665 076635    124    141    160 T36BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
5666 076730    127    122    111 T36TIM: .ASCIZ 'WRITE DATA RETRY''S Erase Tape Not Long Enough'
5667 077005    122    105    122 T36EOT: .ASCIZ 'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
5668 077064    124    123    123 T36TM: .ASCIZ 'TSSR Not Correct After REREAD COMMAND Reject'
5669 077141    122    145    167 T36RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
5670 077210    122    101    115 T36RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
5671 077263    124    123    123 T36AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
5672 077332    104    162    151 T36OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
5673 077405    124    123    123 T36WDD: .ASCIZ 'TSSR Not Correct After REREAD DATA Command, SWB Bit Set'
5674 077475    124    123    123 T36WDC: .ASCIZ 'TSSR Not Correct After REREAD DATA Command'
5675 077550    103    126    103 T36VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
5676 077623    124    123    102 T36BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
5677 077676    127    122    111 T36WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
5678 077765    122    145    141 T36LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XST0'
5679 100047    122    145    141 T36LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XST0'
5680 100131    122    145    163 T36PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
5681 100217    122    145    141 T36TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
5682 100305    127    122    111 T36NEF: .ASCIZ 'WRITE DATA RETRY, At First Record, Failed To Set RIB Bit XST3'
5683 100403    124    123    123 T36SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
5684 100460    124    123    123 T36TSA: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY, Into BOT'
5685 100542    124    123    123 T36WRF: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY Command'
5686 100622    104    141    164 T36DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
5687 100717    122    145    143 T36ID: .ASCIZ 'Record Buffering'
5688          .EVEN
5689          ;*
5690          ;
5691          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
5692          ;WRITE SUBSYSTEM MEMORY COMMAND
5693          ;
5694          ;-
5695
5696 100740
5697 100740          T36REST:          SAVREG
5698 100744 012701 075560          MOV          #T36PACKET,R1          ;SAVE THE REGISTERS
5699 100750 012721 100004          MOV          #100004,(R1)+         ;START OF THE PACKET
5700 100754 012721 075570          MOV          #T36DATA,(R1)+       ;WRITE SUBSYSTEM MEM. WITH ACK,
5701 100760 005021          CLR          (R1)+                 ;ADDRESS OF CHARAISTICS DATA BLOCK
5702 100762 012721 000012          MOV          #10.,(R1)+           ;EXTENDED ADDRESS
5703 100766 012721 075602          MOV          #T36BFR,(R1)+       ;SIZE OF DATA BLOCK IN BYTES
5704 100772 005021          CLR          (R1)+                 ;ADDRESS OF MESSAGE BUFFER
5705 100774 012721 000024          MOV          #20.,(R1)+           ;LENGTH OF MESSAGE BUFFER
5706 101000 005021          CLR          (R1)+
5707 101002 012711 000000          MOV          #0,(R1)              ;SELECT DRIVE ZERO

```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 8: RECORD BUFFERING

SEQ 206

```

5708 101006 012702 000030      MOV      #24.,R2      ;NUMBER OF LOCATIONS TO BE CLEARED
5709 101012 012762 177777 075602 64$:  MOV      #177777,T36BFR(R2) ;ALL ONES TO MESSAGE BUFFER
5710 101020 005742              TST      -(R2)        ;NEXT LOCATION
5711 101022 022702 000000      CMP      #0,R2       ;AT END OF LOOP YET
5712 101026 001371              BNE      64$         ;KEEP GOING UNTIL DONE
5713 101030 000207              RTS      PC          ;RETURN
5714
5715 101032              T36RT2:
5716 101032              SAVREG              ;SAVE THE REGISTERS
5717 101036 012701 075670      MOV      #T36PK2,R1  ;START OF THE PACKET
5718 101042 012721 100006      MOV      #100006,(R1)+ ;WRITE SUBSYSTEM MEM. WITH ACK,
5719 101046 012721 075710      MOV      #T36BF2,(R1)+ ;ADDRESS OF DATA BLOCK
5720 101052 005021              CLR      (R1)+       ;EXTENDED ADDRESS
5721 101054 012721 000006      MOV      #6.,(R1)+   ;SIZE OF DATA BLOCK IN BYTES
5722 101060 005021              CLR      (R1)+
5723 101062 012701 075710      MOV      #T36BF2,R1  ;POINT TO DATA SEL AREA
5724 101066 005021              CLR      (R1)+
5725 101070 005011              CLR      (R1)
5726 101072 000207              RTS      PC          ;RETURN
5727 101074              T36RT3:
5728 101074              SAVREG              ;SAVE REGISTERS
5729 101100 012701 075700      MOV      #T36PK3,R1  ;SET UP POINTER ADDRESS
5730 101104 005021              CLR      (R1)+       ;COMMAND SPACE
5731 101106 005021              CLR      (R1)+       ;ADDRESS OF DATA BLOCK
5732 101110 005021              CLR      (R1)+       ;EXTENDED ADDRESS
5733 101112 005011              CLR      (R1)        ;SIZE OF DATA TRANSFER BLOCK
5734 101114 000207              RTS      PC          ;RETURN
5735 101116              ENDTST
101116              L10070:
101116 104401              TRAP      C$ETST
    
```

5736 .SBTTL TEST 9: FUNCTION TIMING

```

5737 ;+
5738 ;
5739 ; THIS TEST VERIFIES THAT THE TAPE TRANSPORT SEEMS TO BE WRITING
5740 ; RECORDS, GAPS, AND EXTENDED GAPS OF THE PROPER LENGTH. BOTH LOW
5741 ; AND HIGH SPEED MODES ARE TESTED. IT IS ALSO VERIFIED THAT A
5742 ; SPACE RECORDS COMMAND WITH A RECORD COUNT OF 80 OR MORE, AND A
5743 ; SKIP TAPE MARKS COMMAND WITH A COUNT OF 2 OF MORE, OPERATE THE
5744 ; TAPE IN HIGH-SPEED MODE. THIS TEST CAN ONLY BE RUN IF A
5745 ; REAL-TIME CLOCK IS AVAILIABLE ON THE SYSTEM. THE TEST OPERATES BY
5746 ; TIMING VARIOUS TAPE-MOTION OPERATIONS. USING A NUMBER OF
5747 ; DIFFERENT TEST RECORD LENGTHS.
5748 ;
5749 ;
5750 ;-
    
```

```

5751 101120              BGNTST
101120
5752 101120 012737 006354 002172      MOV      #EPRT1,EPRTSW ;PRIMARY ERROR MESSAGE
5753 101126 004737 017354              JSR      PC,KTOFF    ;TURN KT OFF
5758 101132 012700 105343              MOV      #TST37ID,R0 ;ASCII MESSAGE TO IDENTIFY TEST
5759 101136 004737 016570              JSR      PC,TSTSETUP ;DO INITIAL TEST SETUP
5760 101142 012737 000005 002210      MOV      #5,LOOPCNT  ;PERFORM 5 ITERATIONS
5761 101150 005037 102406              CLR      T37CNT     ;CLEAR TAPE RECORD COUNTER
    
```

```

5762 ;+
5763 ;
5764 ; TEST 9, SUBTEST 1
5765 ;
    
```


....B1	CKMSG2 - COMPARE EX....B5	TEST 1: WRITE TAPEB9	TEST 5: DATA PARITY....B13
....C1	PKTMES - PRINT TSSR....C5	TEST 1: WRITE TAPEC9	TEST 5: DATA PARITY....C13
....D1	FIFEXP - PRINT FIFO....D5	TEST 2: SKIP TAPE M....D9	TEST 5: DATA PARITY....D13
....E1	MSGSTAT - PRINT STAT....E5	TEST 2: SKIP TAPE M....E9	TEST 5: DATA PARITY....E13
....F1	MSGSUB - PRINT WRITE....F5	TEST 2: SKIP TAPE M....F9	TEST 5: DATA PARITY....F13
....G1	PRAMPKT - PRINT RAMG5	TEST 2: SKIP TAPE M....G9	TEST 6: OPERATIONSG13
....H1	PRMESS - PRINT CONT....H5	TEST 2: SKIP TAPE M....H9	TEST 6: OPERATIONSH13
....I1	PRMSGEXP - PRINT EXP....I5	TEST 2: SKIP TAPE M....I9	TEST 6: OPERATIONSI13
....J1	PRBYTEXP - PRINT ERR....J5	TEST 2: SKIP TAPE M....J9	TEST 6: OPERATIONSJ13
....K1	PRBYTEXP - PRINT ERR....K5	TEST 2: SKIP TAPE M....K9	TEST 6: OPERATIONSK13
....L1	RAMERR - PRINT RAML5	TEST 2: SKIP TAPE M....L9	TEST 6: OPERATIONSL13
....M1	RAMEXP - PRINT RAMM5	TEST 2: SKIP TAPE M....M9	TEST 6: OPERATIONSM13
....N1	BADSSR - PRINT TSSRN5	TEST 2: SKIP TAPE M....N9	TEST 6: OPERATIONSN13
....B2	CHKAMB - CHECK TSSR....B6	TEST 2: SKIP TAPE M....B10	TEST 6: OPERATIONSB14
....C2	ENAIN,DSBINT - ENAB....C6	TEST 2: SKIP TAPE M....C10	TEST 6: OPERATIONSC14
....D2	WAITF - WAIT FOR S....D6	TEST 2: SKIP TAPE M....D10	TEST 6: OPERATIONSD14
PROGRAM HEADER	XNXM - CHECK FORE6	TEST 2: SKIP TAPE M....E10	TEST 6: OPERATIONSE14
DISPATCH TABLE	TSTSETUP - PRINT TES....F6	TEST 2: SKIP TAPE M....F10	TEST 6: OPERATIONSF14
DEFAULT HARDWARE P-T....G2	TSTSETUP - PRINT TES....G6	TEST 2: SKIP TAPE M....G10	TEST 7: EXTENDED MO....G14
SOFTWARE P-TABLE	INCERK - INCREMENTH6	TEST 2: SKIP TAPE M....H10	TEST 7: EXTENDED MO....H14
SOFTWARE P-TABLE	KTON,KTOFF - EN....I6	TEST 2: SKIP TAPE M....I10	TEST 7: EXTENDED MO....I14
GLOBAL EQUATES SECTI....J2	FILLMEM - FILL MEMOR....J6	TEST 2: SKIP TAPE M....J10	TEST 7: EXTENDED MO....J14
MEMORY MANAGEMENT DE....K2	CMPMEM - COMPARE ME....K6	TEST 2: SKIP TAPE M....K10	TEST 7: EXTENDED MO....K14
MEMORY MANAGEMENT DE....L2	CMPMEM - COMPARE ME....L6	TEST 2: SKIP TAPE M....L10	TEST 7: EXTENDED MO....L14
TSV05 REGISTER AND P....M2	GETPAT - GET 8 BITM6	TEST 2: SKIP TAPE M....M10	TEST 7: EXTENDED MO....M14
TSV05 REGISTER AND P....N2	GETSEL - ISSUE MENU....N6	TEST 2: SKIP TAPE M....N10	TEST 7: EXTENDED MO....N14
TSV05 REGISTER AND P....B3	CHKMAN - CHECK MANU....B7	TEST 3: NO-OP ("CLE....B11	TEST 7: EXTENDED MO....B15
TSV05 REGISTER AND P....C3	ENVIRN - SETUP FREE....C7	TEST 3: NO-OP ("CLE....C11	TEST 7: EXTENDED MO....C15
TSV05 REGISTER AND P....D3	KTINIT - SETUP KT11....D7	TEST 3: NO-OP ("CLE....D11	TEST 7: EXTENDED MO....D15
TSV05 REGISTER AND P....E3	KTINIT - SETUP KT11....E7	TEST 3: NO-OP ("CLE....E11	TEST 7: EXTENDED MO....E15
SPECIAL MACROS AND O....F3	KTINIT - SETUP KT11....F7	TEST 3: NO-OP ("CLE....F11	TEST 7: EXTENDED MO....F15
GLOBAL DATA SECTIONG3	PROTECTION TABLEG7	TEST 3: NO-OP ("CLE....G11	TEST 7: EXTENDED MO....G15
TSTBLK - TEST DATAH3	INITIALIZE SECTIONH7	TEST 3: NO-OP ("CLE....H11	TEST 7: EXTENDED MO....H15
GLOBAL ENVIRONMENT S....I3	INITIALIZE SECTIONI7	TEST 3: NO-OP ("CLE....I11	TEST 7: EXTENDED MO....I15
GLOBAL TEXT MESSAGES....J3	INITIALIZE SECTIONJ7	TEST 3: NO-OP ("CLE....J11	TEST 7: EXTENDED MO....J15
GLOBAL TEXT MESSAGES....K3	ADD AND DROP UNITS S....K7	TEST 4: ERASE AND O....K11	TEST 7: EXTENDED MO....K15
GLOBAL ERROR REPORTL3	ADD AND DROP UNITS S....L7	TEST 4: ERASE AND O....L11	TEST 7: EXTENDED MO....L15
PRITSSR - PRINT TSSR....M3	CLEAN-UP AND REPORTM7	TEST 4: ERASE AND O....M11	TEST 7: EXTENDED MO....M15
PRITSSR - PRINT TSSR....N3	CLEAN-UP AND REPORTN7	TEST 4: ERASE AND O....N11	TEST 8: RECORD BUFF....N15
PRITSSR - PRINT TSSR....B4	CLEAN-UP AND REPORTB8	TEST 4: ERASE AND O....B12	TEST 8: RECORD BUFF....B16
PRIPKT - PRINT THEC4	TEST 1: WRITE TAPEC8	TEST 4: ERASE AND O....C12	TEST 8: RECORD BUFF....C16
PRIXOR - PRINT EXPD....D4	TEST 1: WRITE TAPED8	TEST 4: ERASE AND O....D12	TEST 8: RECORD BUFF....D16
PRIRAM - PRINT RAME4	TEST 1: WRITE TAPEE8	TEST 4: ERASE AND O....E12	TEST 8: RECORD BUFF....E16
PRITADD - PRINT MEMO....F4	TEST 1: WRITE TAPEF8	TEST 4: ERASE AND O....F12	TEST 8: RECORD BUFF....F16
SPACE - SPACE RECO....G4	TEST 1: WRITE TAPEG8	TEST 4: ERASE AND O....G12	TEST 8: RECORD BUFF....G16
SPACE - SPACE RECO....H4	TEST 1: WRITE TAPEH8	TEST 4: ERASE AND O....H12	TEST 8: RECORD BUFF....H16
WRCHR - WRITE CHAR....I4	TEST 1: WRITE TAPEI8	TEST 4: ERASE AND O....I12	TEST 8: RECORD BUFF....I16
REWIND - POSITION T....J4	TEST 1: WRITE TAPEJ8	TEST 4: ERASE AND O....J12	TEST 8: RECORD BUFF....J16
CKRAM - COMPARE RA....K4	TEST 1: WRITE TAPEK8	TEST 5: DATA PARITY....K12	TEST 8: RECORD BUFF....K16
CKRAM2 - COMPARE RA....L4	TEST 1: WRITE TAPEL8	TEST 5: DATA PARITY....L12	TEST 8: RECORD BUFF....L16
CKMSG - COMPARE WR....M4	TEST 1: WRITE TAPEM8	TEST 5: DATA PARITY....M12	TEST 9: FUNCTION TI....M16
CKMSG2 - COMPARE EX....N4	TEST 1: WRITE TAPEN8	TEST 5: DATA PARITY....N12	

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 9: FUNCTION TIMING

SEQ 208

	101360	001607							.WORD	903
	101362	103565							.WORD	T37RWN
	101364	012126							.WORD	PKTSSR
5812	101365			30:	CKLOOP					
	101366	104406							TRAP	C\$CLP1
5813	101370	013701	102270		MOV	T37BFR+6,R1				
5814	101374	010102			MOV	R1,R2				
5815	101376	052702	000002		BIS	#BIT1,R2				
5816	101402	020102			CMP	R1,R2				
5817	101404	001406			BEQ	40:				
5818	101406	005237	002214		INC	FATFLG				
5822	101412				ERRHRD	ERRNO,T37BOT,EXPREC				
	101412	104456							TRAP	C\$ERHRD
	101414	001610							.WORD	904
	101416	103261							.WORD	T37BOT
	101420	015554							.WORD	EXPREC
5823	101422			40:	CKLOOP					
	101422	104406							TRAP	C\$CLP1
5824	101424	012703	000144		MOV	#100.,R3				
5825	101430	013737	003116	102362	MOV	FREE,T37WB				
5826	101436	012737	140005	102360	65:	MOV	#140005,T37PK3			
5827	101444	012704	102360		MOV	#T37PK3,R4				
5828	101450	012737	001130	102366	MOV	#600.,T37S2				
5829	101456	010465	000000		MOV	R4,T37S2				
5830	101462	004737	016330		JSR	PC,WAITF				
5831	101466	016501	000002		MOV	TSSR(R5),R1				
5832	101472	012702	000200		MOV	#SSR,R2				
5833	101476	020102			CMP	R1,R2				
5834	101500	001406			BEQ	70:				
5835	101502	005237	002214		INC	FATFLG				
5839	101506				ERRHRD	ERRNO,T37WDC,PKTSSR				
	101506	104456							TRAP	C\$ERHRD
	101510	001611							.WORD	905
	101512	104121							.WORD	T37WDC
	101514	012126							.WORD	PKTSSR
5840	101516			70:	CKLOOP					
	101516	104406							TRAP	C\$CLP1
5841	101520	005303			DEC	R3				
5842	101522	001345			BNE	65:				
5843	101524	004737	011074		JSR	PC,REWIND				
5844	101530	103411			BCS	130:				
5845	101532	016501	000002		MOV	TSSR(R5),R1				
5846	101536	010004			MOV	R0,R4				
5847	101540	005237	002214		INC	FATFLG				
5851	101544				ERRHRD	ERRNO,T37RWN,PKTSSR				
	101544	104456							TRAP	C\$ERHRD
	101546	001612							.WORD	906
	101550	103565							.WORD	T37RWN
	101552	012126							.WORD	PKTSSR
5852	101554			130:	CKLOOP					
	101554	104406							TRAP	C\$CLP1
5853	101556	013701	102270		MOV	T37BFR+6,R1				
5854	101562	010102			MOV	R1,R2				
5855	101564	052702	000002		BIS	#BIT1,R2				
5856	101570	020102			CMP	R1,R2				
5857	101572	001406			BEQ	140:				
5858	101574	005237	002214		INC	FATFLG				

5862	101600				ERRHRD	ERRNO,T37BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND		
	101600	104456						TRAP	C#ERHRD	
	101602	001613						.WORD	907	
	101604	103261						.WORD	T37BOT	
	101606	015554						.WORD	EXPREC	
5863	101610			140#:	CKLOOP			;LOOP IF SELECTED		
	101610	104406						TRAP	C#CLP1	
5864	101612	012704	102360		MOV	#T37PK3,R4		;SET UP PACKET ADDRESS		
5865	101616	012737	000037	102362	MOV	#31.,T37RB		;SET UP RECORDS TO SPACE OVER		
5866	101624	012737	140010	102360	MOV	#140010,T37PK3		;ACK,CVC=1,SPACE FORWARD COMMAND		
5867	101632	010465	000000		150#:	MOV	R4,T37DB(R5)	;ISSUE COMMAND		
5868	101636	005237	102406		152#:	INC	T37CNT	;BUMP TIMER		
5869	101642				DELAY	1		;DELAY ABOUT 100US		
	101642	012727	000001					MOV	#1,(PC)+	
	101646	000000						.WORD	0	
	101650	013727	002116					MOV	L#DLY,(PC)+	
	101654	000000						.WORD	0	
	101656	005367	177772					DEC	-6(PC)	
	101662	001375						BNE	.-4	
	101664	005367	177756					DEC	-22(PC)	
	101670	001367						BNE	.-20	
5870	101672	016501	000002		MOV	TSSR(R5),R1		;GET TSSR		
5871	101676	032701	000200		BIT	#SSR,R1		;CHECK FOR TSSR'S SSR SET		
5872	101702	001755			BEQ	152#		;KEEP COUNTING UNTIL SET		
5873	101704	012702	000200		MOV	#SSR,R2		;SET UP EXPECTED		
5874	101710	020201			CMP	R2,R1		;WAS EVERYTHING OK		
5875	101712	001406			BEQ	160#		;BR, IF ALL IS WELL		
5876	101714	005237	002214		INC	FATFLG		;ERROR COUNT		
5880	101720				ERRHRD	ERRNO,T37SCF,PKTSSR		;SPACE FORWARD DIDN'T WORK OUT		
	101720	104456						TRAP	C#ERHRD	
	101722	001614						.WORD	908	
	101724	105027						.WORD	T37SCF	
	101726	012126						.WORD	PKTSSR	
5881	101730			160#:	CKLOOP			;LOOP IF SELECTED		
	101730	104406						TRAP	C#CLP1	
5882	101732	004737	011074		JSR	PC,REWIND		;CALL TAPE REWIND COMMAND		
5883	101736	103411			BCS	170#		;BR, IF NO PROBLEM		
5884	101740	010004			MOV	R0,R4		;GET PACKET ADDRESS		
5885	101742	016501	000002		MOV	TSSR(R5),R1		;GET STATUS FROM TSSR		
5886	101746	005237	002214		INC	FATFLG		;ERROR COUNT		
5890	101752				ERRHRD	ERRNO,T37RWN,PKTSSR		;REWIND NOT ACCEPTED		
	101752	104456						TRAP	C#ERHRD	
	101754	001615						.WORD	909	
	101756	103565						.WORD	T37RWN	
	101760	012126						.WORD	PKTSSR	
5891	101762			170#:	CKLOOP			;LOOP IF SELECTED		
	101762	104406						TRAP	C#CLP1	
5892	101764	013701	102270		MOV	T37BFR+6,R1		;PICK UP XSTO		
5893	101770	010102			MOV	R1,R2		;SET UP EXPECTED		
5894	101772	052702	000002		BIS	#BIT1,R2		;SET BOT BIT IN EXPECTED		
5895	101776	020102			CMP	R1,R2		;DOES EXP = REC'D		
5896	102000	001406			BEQ	175#		;BR, IF EQUAL (OK)		
5897	102002	005237	002214		INC	FATFLG		;ERROR COUNT		
5901	102006				ERRHRD	ERRNO,T37BOT,EXPREC		;TAPE NOT AT BOT AFTER REWIND		
	102006	104456						TRAP	C#ERHRD	
	102010	001616						.WORD	910	
	102012	103261						.WORD	T37BOT	

D1

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 9: FUNCTION TIMING

SEQ 210

5902	102014	015554									.WORD	EXPREC
	102016		175:	CKLOOP								
	102016	104406									TRAP	C\$CLP1
5903	102020	012704	102360		MOV	#T37PK3,R4						
5904	102024	012737	000121	102362	MOV	#81,,T37RB						
5905	102032	012737	140010	102360	MOV	#140010,T37PK3						
5906	102040	010465	000000		MOV	R4,T37CNU	250:					
5907	102044	005237	102410		INC	T37CNU	252:					
5908	102050				DELAY	1						
	102050	012727	000001								MOV	#1,(PC)+
	102054	000000									.WORD	0
	102056	013727	002116								MOV	L\$DLY,(PC)+
	102062	000000									.WORD	0
	102064	005367	177772								DEC	-6(PC)
	102070	001375									BNE	.-4
	102072	005367	177756								DEC	-22(PC)
	102076	001367									BNE	.-20
5909	102100	016501	000002		MOV	T37CNU,R1						
5910	102104	032701	000200		BIT	T37CNU,R1						
5911	102110	001755			BEG	252:						
5912	102112	012702	000200		MOV	#SSR,R2						
5913	102116	020201			CMP	R2,R1						
5914	102120	001406			BEG	260:						
5915	102122	005237	002214		INC	FATFLG						
5919	102126				ERRHRD	ERRNO,T37SCF,PKTSSR						
	102126	104456									TRAP	C\$ERHRD
	102130	001617									.WORD	911
	102132	105027									.WORD	T37SCF
	102134	012126									.WORD	PKTSSR
5920	102136			260:	CKLOOP							
	102136	104406									TRAP	C\$CLP1
5921	102140	013701	102406		MOV	T37CNU,R1						
5922	102144	013702	102410		MOV	T37CNU,R2						
5923	102150	042701	000077		BIC	#000077,R1						
5924	102154	042702	000077		BIC	#000077,R2						
5925	102160	020102			CMP	R1,R2						
5926	102162	003406			BLE	300:						
5927	102164	005237	002214		INC	FATFLG						
5931	102170				ERRHRD	ERRNO,T37TIM,EXPREC						
	102170	104456									TRAP	C\$ERHRD
	102172	001620									.WORD	912
	102174	103354									.WORD	T37TIM
	102176	015554									.WORD	EXPREC
5932	102200			300:	CKLOOP							
	102200	104406									TRAP	C\$CLP1
5933	102202				ENDSUB							
	102202											
	102202	104403										
5934	102204	023727	002214	000017	CMP	FATFLG,#15,						
5935	102212	103402			BLO	999:						
5936	102214	004737	017262		JSR	PC,CKDROP						
5937	102220											
5938												
5939												
5940												
5941	102220	004737	017262		JSR	PC,TSTLOOP						
5942	102224	103002			BCC	163:						

```

;LOOP IF SELECTED
;SET UP PACKET ADDRESS
;SET UP RECORDS TO SPACE OVER
;ACK,CVC=1,SPACE FORWARD COMMAND
;ISSUE COMMAND
;BUMP TIMER
;DELAY ABOUT 100US
MOV #1,(PC)+
.WORD 0
MOV L$DLY,(PC)+
.WORD 0
DEC -6(PC)
BNE .-4
DEC -22(PC)
BNE .-20

;GET TSSR
;CHECK FOR TSSR'S SSR SET
;KEEP COUNTING UNTIL SET
;SET UP EXPECTED
;WAS EVERYTHING OK
;BR, IF ALL IS WELL
;ERROR COUNT
;SPACE FORWARD DIDN'T WORK OUT
TRAP C$ERHRD
.WORD 911
.WORD T37SCF
.WORD PKTSSR

;LOOP IF SELECTED
;TIME FOR WRITE SPACING
;TIME FOR WRITE RETRY SPACING
;SETTING UP CONSTANTS
;SETTING UP CONSTANTS
;CHECK FOR DIFFERENCE
;BR, IF GOOD CHECK
;ERROR COUNT
;TIME WAS NOT DIFFERENT ENOUGH
TRAP C$ERHRD
.WORD 912
.WORD T37TIM
.WORD EXPREC

;LOOP IF SELECTED
TRAP C$CLP1
;<<<<<<<<<<<<<<<< END SUBTEST >>>>>>>>>
L10074:
TRAP C$ESUB
;IS ERROR COUNT AT 25
;BR, IF LESS THAN 25
;TRY TO DROP THE UNIT

;DO WE NEED TO ITERATE TEST
;BR, IF NO LOOP REQUIRED

```



```

6005 102406 000000          T37CNT: .WORD 0          ;TAPE TIMER COUNTER STORAGE AREA
6006 102410 000000          T37CNU: .WORD 0          ;TAPE TIMER COUNTER STORAGE AREA
6007 102412 000000          T37DLY: .WORD 0          ;DELAY COUNTER
6008
6009                          ;*
6010                          ;LOCAL TEXT MESSAGES FOR TEST
6011                          ;-
6012 102414      124      141      160  T37WNG: .ASCIZ 'Tape Position Incorrect After REREAD Previous (OPP=1)'
6013 102502      124      123      123  T37RDF: .ASCIZ 'TSSR Incorrect After READ DATA Command'
6014 102551      122      105      122  T37RRF: .ASCIZ 'REREAD Previous (Space Reverse, Read Forward) Command Failed'
6015 102646      120      117      123  T37SC: .ASCIZ 'POSITION (Space Command) Failed, TSSR Not Correct'
6016 102730      122      111      102  T37LOR: .ASCIZ 'RIB NOT SET AFTER READ REVERSE INTO BOT'
6017 103000      124      123      123  T37WDF: .ASCIZ 'TSSR Not Correct After Illegal Mode Bits Set'
6018 103055      111      154      154  T37LOQ: .ASCIZ 'Illegal Mode Bits, Failed To Set ILC Bit In XST0'
6019 103136      122      105      122  T37SSR: .ASCIZ 'REREAD COMMAND Not Accepted'
6020 103172      124      123      123  T37WDE: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY Command, At BOT'
6021 103261      124      141      160  T37BOT: .ASCIZ 'Tape Not At BOT After REWIND Command (BOT Not Set In XST0)'
6022 103354      127      122      111  T37TIM: .ASCIZ 'WRITE DATA RETRY'S Erase Tape Not Long Enough'
6023 103431      122      105      122  T37EOT: .ASCIZ 'REREAD DATA OVER EOT GAVE NO TAPE STATUS ALERT'
6024 103510      124      123      123  T37TM: .ASCIZ 'TSSR Not Correct After REREAD COMMAND Reject'
6025 103565      122      145      167  T37RWN: .ASCIZ 'Rewind (POSITION) Command Not Accepted'
6026 103634      122      101      115  T37RNC: .ASCIZ 'RAM Error, Correct Data Pattern Not In Ram'
6027 103707      124      123      123  T37AM3: .ASCIZ 'TSSR Init. Failed After REREAD COMMAND'
6028 103756      104      162      151  T37OFL: .ASCIZ 'Drive 7 Select Failed To Set "OFL" In TSSR'
6029 104031      124      123      123  T37WDD: .ASCIZ 'TSSR Not Correct After REREAD DATA Command, SW9 Bit Set'
6030 104121      124      123      123  T37WDC: .ASCIZ 'TSSR Not Correct After REREAD DATA Command'
6031 104174      103      126      103  T37VCK: .ASCIZ 'CVC Set, Didn't Reset VCK In Message Buffer'
6032 104247      124      123      102  T37BA: .ASCIZ 'TSBA Not Correct After REREAD DATA Command'
6033 104322      127      122      111  T37WSS: .ASCIZ 'WRITE SUBSYSTEM MEMORY Command Not Accepted (RAM Read)'
6034 104411      122      145      141  T37LON: .ASCIZ 'Reading Long Record Failed To Set RLL Bit In XST0'
6035 104473      122      145      141  T37LOP: .ASCIZ 'Reading Long Record Failed To Set RLS Bit In XST0'
6036 104555      122      145      163  T37PBP: .ASCIZ 'Residual Byte Count Incorrect After Short Record Read'
6037 104643      122      145      141  T37TRL: .ASCIZ 'Reading Long Record Failed To Give Tape Status Alert'
6038 104731      127      122      111  T37NEF: .ASCIZ 'WRITE DATA RETRY, At First Record, Failed To Set RIB Bit XST3'
6039 105027      124      123      123  T37SCF: .ASCIZ 'TSSR Not Correct After SPACE RECORDS Command'
6040 105104      124      123      123  T37TSA: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY, Into BOT'
6041 105166      124      123      123  T37WRF: .ASCIZ 'TSSR Not Correct After WRITE DATA RETRY Command'
6042 105246      104      141      164  T37DTA: .ASCIZ 'Data Compare Error, Data Read From Tape Not Equal To Written'
6043 105343      106      165      156  T37ID: .ASCIZ 'Function Timing'
6044
6045                          ;*
6046                          ;
6047                          ;ROUTINE TO RESTORE COMMAND PACKET TO START-UP (DEFAULT) VALUES
6048                          ;WRITE SUBSYSTEM MEMORY COMMAND
6049                          ;
6050                          ;-
6051
6052 105364          T37REST:
6053 105364          SAVREG
6054 105370      012701  102240      MOV      #T37PACKET,R1          ;SAVE THE REGISTERS
6055 105374      012721  100004      MOV      #100004,(R1)          ;START OF THE PACKET
6056 105400      012721  102250      MOV      #T37DATA,(R1)        ;WRITE SUBSYSTEM MEM. WITH ACK.
6057 105404      005021          CLR      (R1)                  ;ADDRESS OF CHARAISTICS DATA BLOCK
6058 105406      012721  000012      MOV      #10.,(R1)            ;EXTENDED ADDRESS
6059 105412      012721  102267      MOV      #T37BFR,(R1)        ;SIZE OF DATA BLOCK IN BYTES
6060 105416      005021          CLR      (R1)                  ;ADDRESS OF MESSAGE BUFFER
6061 105420      012721  000024      MOV      #20.,(R1)            ;LENGTH OF MESSAGE BUFFER
    
```

TEST 1 - HARDWARE TEST 1-8 TEST MACRO M1113 06-FEB-84 18:04
 TEST 9: FUNCTION TIMING

SEQ 213

6062	105424	005021		CLR	(R1)+	
6063	105426	012711	000000	MOV	#0,(R1)	;SELECT DRIVE ZERO
6064	105432	012702	000030	MOV	#24,,R2	;NUMBER OF LOCATIONS TO BE CLEARED
6065	105436	012762	177777	MOV	#177777,T37BFR(R2)	;ALL ONES TO MESSAGE BUFFER
6066	105444	005742		TST	-(R2)	;NEXT LOCATION
6067	105446	022702	000000	CMP	#0,R2	;AT END OF LOG? YET
6068	105452	001371		BNE	64\$;KEEP GOING UNTIL DONE
6069	105454	000207		RTS	PC	;RETURN
6070						
6071	105456			T37RT2:		
6072	105456			SAVREG		;SAVE THE REGISTERS
6073	105462	012701	102350	MOV	#T37PK2,R1	;START OF THE PACKET
6074	105466	012721	100006	MOV	#100006,(R1)+	;WRITE SUBSYSTEM MEM. WITH ACK,
6075	105472	012721	102370	MOV	#T37BF2,(R1)+	;ADDRESS OF DATA BLOCK
6076	105476	005021		CLR	(R1)+	;EXTENDED ADDRESS
6077	105500	012721	000006	MOV	#6,,(R1)+	;SIZE OF DATA BLOCK IN BYTES
6078	105504	005021		CLR	(R1)+	
6079	105506	012701	102370	MOV	#T37BF2,R1	;POINT TO DATA SEL AREA
6080	105512	005021		CLR	(R1)+	
6081	105514	005011		CLR	(R1)	
6082	105516	000207		RTS	PC	;RETURN
6083	105520			T37RT3:		
6084	105520			SAVREG		;SAVE REGISTERS
6085	105524	012701	102360	MOV	#T37PK3,R1	;SET UP POINTER ADDRESS
6086	105530	005021		CLR	(R1)+	;COMMAND SPACE
6087	105532	005021		CLR	(R1)+	;ADDRESS OF DATA BLOCK
6088	105534	005021		CLR	(R1)+	;EXTENDED ADDRESS
6089	105536	005011		CLR	(R1)	;SIZE OF DATA TRANSFER BLOCK
6090	105540	000207		RTS	PC	;RETURN
6091	105542			ENDTST		
	105542					
	105542	104401				L10073: TRAP C\$ETST
6092	105544			ENDMOD		

```

1          .TITLE  TSV6 - PARAMETER CODING
7
12
18
19 105544  BGNMOD  TSV6
105544  TSV6::
20
21          .SBTTL  HARDWARE PARAMETER CODING SECTION
22
23          ;**
24          ; THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
25          ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
26          ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
27          ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
28          ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
29          ; WITH THE OPERATOR.
30          ;--
31 105544  BGNHRD
105544 000010  .WORD  L10075-L$HARD/2
105546  L$HARD::
32
33 105545  GPRMA  HPM1,0,0,160010,177776,YES      ;GET TSBA/TSDB REGISTER ADDRESS.
105546 000031  .WORD  T$CODE
105550 105566  .WORD  HPM1
105552 160010  .WORD  T$L$LOLIM
105554 177776  .WORD  T$HILIM
34 105556  GPRMA  HPM2,2,0,0,776,YES      ;GET VECTOR ADDRESS.
105556 001031  .WORD  T$CODE
105560 105622  .WORD  HPM2
105562 000000  .WORD  T$L$LOLIM
105564 000776  .WORD  T$HILIM
35          ;GPRMD  HPM3,4,0,340,0,7,YES      ;GET INTERRUPT PRIORITY.
36 105566  ENDRD
          .EVEN
          105566          L10075:
37 105566          104          105          126  HPM1:  .ASCIZ  'DEVICE ADDRESS (TSBA/TSDB) '
38 105622          111          116          124  HPM2:  .ASCIZ  'INTERRUPT VECTOR '
39 105646          111          116          124  HPM3:  .ASCIZ  'INTERRUPT PRIORITY '
40          .EVEN
    
```

```

42          .SBTTL  SOFTWARE PARAMETER CODING SECTION
43
44          ;**
45          ; THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
46          ; THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
47          ; MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
48          ; INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
49          ; MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
50          ; WITH THE OPERATOR.
51          ;--
52 105676      BGNSFT
105676      .WORD L10076-L$SOFT/2
105700
53          L$SOFT::
54          ;      GPRML   SPM1,0,-1,YES          ; GET TRANSPORT TEST FLAG.
          ;      GPRML   SPM4,2,-1,YES          ; GET ITERATION CONTROL.
          ;      .WORD   T$CODE
          ;      .WORD   SPM4
          ;      .WORD   -1
55          ;      GPRMD   SPM6,4,D,7777,0,7777,YES      ; GET LOCAL EPROR LIMIT
56          ;      GPRMD   SPM7,6,D,7777,0,7777,YES      ; GET GLOBAL ERROR LIMIT
57 105706      ENDSFT
          .EVEN
          L10076:
58
59 105706      105      116      101  SPM1:  .ASCIZ  'ENABLE TRANSPORT TESTS '
60 105736      111      116      110  SPM4:  .ASCIZ  'INHIBIT ITERATIONS '
61 105766      120      105      122  SPM6:  .ASCIZ  'PER TEST ERROR LIMIT '
62 106016      120      105      122  SPM7:  .ASCIZ  'PER UNIT ERROR LIM, '
63          .SBTTL  PATCH AREA
64
65          ;
66          ; FINALLY A GENEROUS PATCH AREA.
67          ;
68          ; AND AN ADJUSTMENT TO ACCOUNT FOR THE "LASTAD BIT7" HACK
69          ; DESCRIBED IN "SUPPRG.MEM" (FOR REV C).
70          ;
71          ;
72 106046      PATCH::
73
74 106046      .BLKW   32,
75
76          .-.!37/+1
77          LASTAD      ;SET LAST USED ADDRESS.
106400      .EVEN
106402      .WORD   0
106404      .WORD   0
80 106404      L$LAST::
81 106404      ENDMOD
          .END

```


ADDSSR	012206	G	C#AU	000052	DEVDR0	023456	FRESIZ	003120	G	INTFLA	016225	
ADR	000020	G	C#AUTO	000061	DEVNRD	023375	FUSI	004113		INTMAS	016224	
AMBTSS	006713		C#BRK	000022	DEVNXR	023313	F#AU	000015		INTR	016276	G
ASSEMB	000010		C#BSEG	000004	DEVONL	023243	F#AUTO	000020		INTREC	002216	G
A1716	000003		C#BSUB	000002	DEVSUM	023206	F#BGN	000040		INTVEC	016226	
BADDAT	003150	G	C#CEFG	000045	DFPTBL	002150	F#CLEA	000007		INTX	004274	
BADSSR	015760	G	L#CLCK	000062	DIAGMC	000000	F#DU	000016		INVERT	021266	G
BDVPCR	177520	G	C#CLEA	000012	DICED	000001	F#END	000041		IOKCKI	000200	
BENBSW	002222	G	C#CLOS	000035	DSBINT	016264	F#HARD	000004		IOKSTP	000001	
BIF	040000		C#CLP1	000006	DIAD12	004637	F#HW	000013		IPRI	002204	G
BIT0	000001	G	C#CVEC	000036	DUFLG	003104	F#INIT	000006		ISR	000100	G
BIT03	000001	G	C#DCLN	000044	DUMMY	003054	F#JMP	000050		IVEC	002202	G
BIT01	000002	G	C#DDDU	000051	EF.CON	000036	F#MOD	000000		IXE	004000	G
BIT02	000004	G	C#DRPT	000024	EF.NEW	000035	F#MSG	000011		I#AU	000041	
BIT03	000010	G	C#DU	000053	EF.PWR	000034	F#PROT	000021		I#AUTO	000041	
BIT04	000020	G	C#EDIT	000003	EF.RES	000037	F#PWR	000017		I#CLN	000041	
BIT05	000040	G	C#ERDF	000055	EF.STA	000040	F#RPT	000012		I#DU	000041	
BIT06	000100	G	C#ERRR	000056	EMAXDU	017057	F#SEG	000003		I#HRD	000041	
BIT07	000200	G	C#ERRG	000060	EN	000000	F#SOFT	000005		I#INIT	000041	
BIT08	000400	G	C#ERSF	000054	ENAIN	016232	F#SRV	000010		I#MOD	000041	
BIT09	001000	G	C#ERSJ	000057	ENVIRN	020710	F#SUB	000002		I#MSG	000041	
BIT1	000002	G	C#ESCA	000010	EPRTSW	002172	F#SW	000014		I#PROT	000040	
BIT10	002000	G	C#ESEG	000005	EPRT1	006354	F#TEST	000001		I#PTAB	000041	
BIT11	004000	G	C#ESUB	000003	EPRT2	006413	GDDAT	003152	G	I#PWR	000041	
BIT12	010000	G	C#ETST	000001	ERCM	012013	GERRMA	002166	G	I#RPT	000041	
BIT13	020000	G	C#EXIT	000032	ERRHI	002230	GETPAT	020254	G	I#SEG	000041	
BIT14	040000	G	C#GETB	000026	ERRK	017036	GETSEL	020336	G	I#SETU	000041	
BIT15	100000	G	C#GETW	000027	ERRLO	002232	G#CNT0	000200		I#SFT	000041	
BIT2	000004	G	C#GMAN	000043	ERRNC	001620	G#DELM	000372		I#SRV	000041	
BIT3	000010	G	C#GPHR	000042	ERRVEC	000004	G#DISP	000003		I#SUB	000041	
BIT4	000020	G	C#GPL0	000030	ERTABE	003370	G#EXCP	000400		I#TST	000041	
BIT5	000040	G	C#GPRI	000040	ERTABL	003170	G#HILI	000002		J#JMP	000167	
BIT6	000100	G	C#INIT	000011	ESUM	017040	G#LOLI	000001		KIPAR0	172340	
BIT7	000200	G	C#INLP	000020	EVL	000004	G#NO	000000		KIPAR1	172342	
BIT8	000400	G	C#MANI	000050	EXBCNT	000010	G#OFFS	000400		KIPAR2	172344	
BIT9	001000	G	C#MEM	000031	EXPBRE	015562	G#OF SI	000376		KIPAR3	172346	
BOE	000400	G	C#MSG	000023	EXPD	002224	G#PRMA	000001		KIPAR4	172350	
BRINIT	004453		C#OPEN	000034	EXPGOT	004527	G#PRMD	000002		KIPAR5	172352	
BSELO	000000		C#PNTB	000014	EXPGT2	004563	G#PRML	000000		KIPAR6	172354	
BSEL1	000001		C#PNTF	000017	EXPMSC	002314	G#RADA	000140		KIPAR7	172356	
CHKAMB	016124		C#PNIS	000016	EXPREC	015554	G#RADB	000000		KIPDR0	172300	
CHKMAN	020560	G	C#PNTX	000015	EXTA	005766	G#RADD	000040		KIPDR1	172302	
CHKTSS	016416		C#QIO	000377	EXTEND	005764	G#RADL	000120		KIPDR2	172304	
CKDROP	017262		C#RDBU	000007	EXTFEA	002220	G#RADO	000020		KIPDR3	172306	
CKEMAX	017162		C#REFG	000047	E#END	002100	G#XFER	000004		KIPDR4	172310	
CKMSG	011440	G	C#RESE	000033	E#LOAD	000035	G#ES	000010		KIPDR5	172312	
CKMSG2	011560	G	C#REVI	000003	FATERR	000050	HIADDR	001400		KIPDR6	172314	
CKRAM	011174	G	C#RFLA	000021	FATFLG	002214	HOE	100000	G	KIPDR7	172316	
CKRAM2	011304	G	C#RPT	000025	FERCM	012002	HPM1	105566		KTENAB	003126	G
CMOPKT	021340	G	C#SEFG	000046	FIFEXP	012250	HPM2	105622		KTFLG	003124	G
CMEMEM	017740		C#SPRI	000041	FIF1MS	012322	HPM3	105646		KTINIT	021134	
CONFIG	017330		C#SVEC	000037	FIF2MS	012371	YBE	010000	G	KTOFF	017354	
COUNT	002302	G	C#YPRI	000013	FILLME	017502	IDU	000040	G	KTON	017336	
CSRADD	002200	G	DATA	002304	FNOINT	004211	IER	020000	G	LERRMA	002164	G
CTAB	003156	G	DATAS	020312	FORCER	002170	IFAU	004252		LISTAL	000001	
CTABE	003170	G	DEBUG	011712	FREE	003115	INCERK	017124		LOE	040000	G
CTABM	003156	G	DEVcnt	002212	FREEHI	003122	INTCPC	016230		LOOPCN	002210	G

LOOPCO	013206	L10001	002170	L10073	105542	O\$ERRT	000000	PST32W	003144 G
LOOPFL	003154 G	L10002	005762	L10074	102202	O\$GNSW	000001	PUNIT	022364
LOT	000010 G	L10003	012124	L10075	105566	O\$FOIN	000001	PW.D11	000021
L\$ACP	002110 G	L10004	012142	L10076	105706	O\$SETU	000000	PW.D13	000022
L\$APT	002036 G	L10005	012160	MEMADD	014034 G	PASRPT	022134	PW.D22	000020
L\$AL	022432 G	L10006	012166	MEMCK	021356 G	PATCH	106046 G	PW.NOP	000000
L\$AUT	002070 G	L10007	012204	MENASC	020527	PATDAT	020310	PW.NO1	000023
L\$AUTO	022636 G	L10010	012222	MENERR	020454	PC.ERA	002400	PW.RDE	000024
L\$CCP	002106 G	L10011	012246	MENRES	020556	PC.IER	002000	PW.RDR	000001
L\$CLEA	022716 G	L10012	012320	MMVEC	000250	PC.NOD	001000	PW.RDS	000005
L\$CO	002032 G	L10013	012470	MSA.FR	000006	PC.REL	000000	PW.RFI	000003
L\$DEPO	002011 G	L10014	013204	MSA.NO	000000	PC.REW	000400	PW.WCT	000006
L\$DESC	003402 G	L10015	014032	MSA.NR	000004	PKBCNT	000006	PW.WFI	000004
L\$DESP	002076 G	L10016	014054	MSA.VO	000002	PKHI	000004	PW.WFM	000007
L\$DEVP	002060 G	L10017	015560	MSGEXP	012224 G	PKLOW	000002	PW.WMI	000010
L\$DISP	002124 G	L10020	015566	MSGLOO	013144 G	PKTARD	007632	PW.WNP	000011
L\$DLY	002116 G	L10021	015574	MSGSTA	012430 G	PKTFRM	007574	PW.WTR	000002
L\$DTP	002040 G	L10022	015606	MSGSUB	014022 G	PKTGET	012144 G	P.ACK	100000
L\$DTYP	002034 G	L10023	015630	MS.ATI	000006	PKTMES	012170 G	P.CMD	000037
L\$DU	022530 G	L10024	015656	MS.EXT	000200	PKTRAM	004741 G	P.CONT	000012
L\$DUT	002072 G	L10025	016016	MS.RSD	000001	PKTSSR	012126 G	P.CVC	040000
L\$DVTY	003374 G	L10026	016326	MS.RSF	000020	PNT	001000 G	P.FMT	000140
L\$EF	002052 G	L10030	022362	MS.RST	000010	PRAMPK	014056	P.FORM	000011
L\$ENVI	002044 G	L10031	022526	M8186	005550	PRASC	014603	GETS	000017
L\$LTP	002102 G	L10032	022634	M8189	005641	PRBEXP	015550	IE	000200
L\$EXP1	002046 G	L10033	022714	M8A	002000	PRBMSG	015416	P.INIT	000013
L\$EXP4	002064 G	L10034	022742	NEWPAS	022070	PRBREC	015552	P.MODE	007400
L\$EXP5	002066 G	L10035	023204	NODEV	003106 G	PRBTOT	015503	P.OPP	020000
L\$HARD	105546 G	L10036	032332	NOINIT	004331	PRBYTE	015202 G	P.POSI	000010
L\$HIME	002120 G	L10037	024170	NOINTR	004215	PRI	002000 G	P.READ	000001
L\$MPCP	002016 G	L10040	024712	NOITS	002162 G	PRIADD	010236	P.SWB	010000
L\$HPTP	002022 G	L10041	025436	NOMAN	020614	PRIAO	010306	P.WRIT	000005
L\$HW	002150 G	L10042	026260	NOMEM	005454	PRI BXO	007670 G	P.WRTC	000004
L\$ICP	002104 G	L10043	041430	NP.IR	000200	PRIEQU	010136	P.WRTS	000006
L\$INIT	021636 G	L10044	033734	NP.LOO	000040	PRIPKT	007446 G	QVP	002176 G
L\$LADP	002026 G	L10045	035360	NP.OUT	000100	PRIRAM	010144	RAMASC	014236
L\$LAST	106404 G	L10046	035754	NP.WRP	000020	PRITAD	010352	RAMDAT	002234 G
L\$LOAD	002100 G	L10047	036440	NSI	001146	PRITSS	006020	RAMERR	015570 G
L\$LUN	002074 G	L10050	046766	NSINIT	004403	PRITO	010434	RAMEXP	015610 G
L\$MREV	002050 G	L10051	042322	NUL	004523	PRIT1	010477	RAMFOR	010174
L\$NAME	002000 G	L10052	043134	NULCR	004524	PRIXOR	000020 G	RAMSIZ	002274 G
L\$PRIO	002042 G	L10053	053044	NXM	004000	PRI00	000000 G	RAMTAD	015576 G
L\$PROT	021626 G	L10054	047642	NXMFLG	003130 G	PRI01	000040 G	RCVMA	002276 G
L\$PRT	002112 G	L10055	050452	NXMHI	003134 G	PRI02	000100 G	RCVLOA	002300 G
L\$REPP	002062 G	L10056	051266	NXMLD	003132 G	PRI03	000140 G	RDERR	005202
L\$REV	002010 G	L10057	056040	NXMTST	021532	PRI04	000200 G	RECMG	002460 G
L\$RPT	022744 G	L10060	054506	NXR	003734	PRI05	000240 G	RECV	002226 G
L\$SOFT	105700 G	L10061	063412	NXRERR	005732 G	PRI06	000300 G	REGSAV	020220
L\$SPC	002056 G	L10062	060476	NXRX	003773	PRI07	000340 G	RETFRR	005366
L\$SPCP	002020 G	L10063	073342	NXTU	022102	PRMESS	014322	REWIND	011074 G
L\$SPTP	002024 G	L10064	064504	OFL	000100	PRMNO	002312 G	RMCHBE	000167
L\$STA	002030 G	L10065	065564	ONEFIL	000000	PRMSGE	014632 G	RMCHEN	000200
L\$SW	002160 G	L10066	066426	O\$APTS	000000	PRMSG0	015012	RMMSGB	000215
L\$TEST	002114 G	L10067	067330	O\$AU	000001	PRMSG1	015057	RMMSGE	000234
L\$TIHL	002014 G	L10070	101116	O\$BGNR	000001	PRMSG2	015115	RMPKTB	000201
L\$UNIT	002012 G	L10071	074436	O\$BGNS	000001	PROASC	014500	RMPKTE	000210
L10000	002156	L10072	075520	O\$DU	000001	PRIASC	014545	RMR	010000

RWPACK	011170	S2.INR	000020	T\$EXCP	000000	T29CON	026462	T30BOT	040041
SC	100000	S2.OUT	000040	T\$FLAG	000040	T29DAT	026330	T30BS0	036630
SCE	020000	S2.UND	000003	T\$GMAN	000000	T29DLY	026500	T30BS1	036631
SCHERR	005274	TBLEND	003054 G	T\$ILI	000776	T29DSW	026340	T30CNT	036650
SCME	005007	TCOASC	006554	T\$LAST	000001	T29DTA	030043	T30CNU	036652
SDELAY	010740	TCJCOD	006754	T\$LOLI	000000	T29EOT	030131	T30DAT	036510
SELASC	020522	TEMP1	003110 G	T\$LSYM	010000	T29LON	031225	T30DLY	036656
SELDAT	000004	TEMP2	003112 G	T\$LTND	000011	T29LOO	023556	T30DLY	036520
SEL2	000002	TERCLS	000016	T\$NEST	177777	T29LOP	031307	T30DLY	041134
SETMAP	017376	TESTNO	000011	T\$NSO	000000	T29LOQ	027426	T30DTR	041070
SETU	022166	TEXASC	006513	T\$NS1	000005	T29LOR	027301	T30ETM	036516
SFFMSG	012162 G	TFCASC	006615	T\$NS2	000002	T29NEF	026630	T30FCN	036654
SFHERR	003701	TIMEXP	015630 G	T\$PTNU	000000	T29NEQ	031545	T30IBT	037031
SFIERR	003646	TIMSGO	015660	T\$SAVL	177777	T29OFL	026502	T30IBU	036660
SFIMSG	012114 G	TINERR	012101	T\$SEGL	177777	T29OF7	030515	T30IMV	036636
SFPTBL	002160 G	TMPBFR	002624 G	T\$SUBN	000001	T29PAC	026320	T30LOO	032360
SIFLAG	003146 G	TNAM	016764	T\$TAGL	177777	T29PBP	031371	T30LOQ	037630
SIMSG	012046	TRANST	002160 G	T\$TAGN	010077	T29PK2	026430	T30NEF	040576
SKIPT	003372	TSBA	000000 G	T\$TEMP	000000	T29PK3	026440	T30OFL	040307
SOFINI	016054 G	TSBAH	000001 G	T\$TEST	000011	T29RB	026442	T30PAC	036500
SPACE	010544 G	TSDB	000000 G	T\$TSTM	177777	T29RDF	026720	T30PK2	036610
SPM1	105706	TSDBH	000001 G	T\$TSTS	000001	T29RDG	031643	T30PK3	036620
SPM4	105736	TSFCOD	007314	T\$TAU	010031	T29RES	032146	T30PTB	037242
SPM6	105766	TSREJ	000006	T\$TAUT	010033	T29RIB	031724	T30RB	036622
SPM7	106016	TSSDEF	006664	T\$CLE	010034	T29RN	026456	T30RDF	037413
SRO	177572	TSSR	000002 G	T\$DU	010032	T29RNC	030354	T30RDG	037471
SR1	177574	TSSRBI	003476 G	T\$HAR	010075	T29RRF	026767	T30RES	041252
SR2	177576	TSSRFO	006473	T\$HW	010000	T29RRG	027103	T30RIB	036745
SR3	172516	TSSRH	000003 G	T\$INI	010030	T29RRN	032024	T30RN	036636
SSR	000200	TSSX	004014	T\$MSG	010025	T29RSZ	026476	T30RRM	040655
STATCO	012472	TSTBLK	002744 G	T\$PRO	010027	T29RT2	032240	T30RRN	040733
SVCGBL	000000	TSTCNT	002206 G	T\$RPT	010035	T29RT3	032302	T30RRP	041012
SVCINS	000000	TSTEND	017000	T\$SOF	010076	T29RWN	030305	T30RT2	041344
SVCSUB	000001	TSTFLA	002306 G	T\$SRV	010026	T29SC	027217	T30RT3	041406
SVCTAG	000000	TSTLOO	016536 G	T\$SRT	010074	T29SSR	027507	T30RWN	040240
SVCTST	000001	TSTPTR	002310 G	T\$SRT	010001	T29SZ	026446	T30SKM	037114
S\$LSYM	010000	TSTSET	016570 G	T\$TLS	010073	T29S2	026452	T30SSR	037711
S0.IDB	000010	TST29I	032117	T1	023526 G	T29S3	026454	T30SZ	036626
S0.IFB	000002	TST30I	041231	T1.1	023556	T29TM	030227	T30S2	036632
S0.IFP	000001	TST31I	046543	T1.2	024206	T29TRL	031457	T30S3	036634
S0.ILD	000020	TST32I	052640	T1.3	024730	T29VCK	030771	T30TM	040106
S0.ION	000040	TST33I	055645	T1.4	025454	T29WB	026442	T30TMK	040514
S0.IRD	000100	TST34I	063207	T2	032334 G	T29WDC	030677	T30TM2	040163
S0.IRW	000004	TST35I	073133	T2.1	032360	T29WDD	030570	T30TPB	037333
S0.ISP	000200	TST36I	100717	T2.2	033752	T29WDE	027562	T30VCK	040441
S1.ICE	002000	TST37I	105343	T2.3	035376	T29WDF	027351	T30WB	036622
S1.IED	003000	TSV2	002000 G	T2.4	035772	T29WDR	026460	T30WDC	040362
S1.IFM	001000	TSV3	002170 G	T23A	003136 G	T29WLK	027644	T30WDC	037170
S1.IHE	000400	TSV4	021626 G	T23B	003140 G	T29WNG	026523	T30WDC	037762
S1.IID	004000	TSV6	105544 G	T29AM3	030427	T29WRT	027731	T30WDF	037553
S1.IIR	020000	TSV7B	023526 G	T29BA	031044	T29WSS	031136	T31AM3	045016
S1.I2R	040000	TTIBFR	177562 G	T29BF1	026342	T3	041432 G	T31BA	045356
S1.PAR	100000	TTICSR	177560 G	T29BF2	026450	T3FLG	003142 G	T31BFR	043212
S2.ATI	000010	TTIVFC	000060 G	T29BOT	027776	T3.1	041462	T31BF2	043320
S2.BTI	000004	T\$ARGC	000003	T29BS0	026450	T3.2	042340	T31BOT	044345
S2.DIM	000200	T\$CODE	001130	T29BS1	026451	T30BFR	036522	T31BS0	043320
S2.ILW	000100	T\$ERRN	001620	T29CNT	026474	T30BF2	036630	T31BS1	043321

T31CNT	043336	T32CNU	051512	T34BA	063046	T35CON	07532	T36BS1	075711
T31CNU	043340	T32DAT	051340	T34BFR	060562	T35DAT	067400	T36CNT	075726
T31CON	043332	T32DLY	051514	T34BF2	060676	T35DLY	067542	T36CNU	075730
T31DAT	043200	T32DSW	051350	T34BOT	061234	T35DSW	067410	T36CON	075722
T31DLY	043342	T32ECF	052455	T34BS0	060676	T35DTA	072325	T36DAT	075570
T31DSW	043210	T32EOT	051611	T34BS1	060677	T35EOT	070510	T36DLY	075732
T31DTA	046446	T32ERA	052016	T34CNT	060672	T35INT	072601	T36DSW	075600
T31EOT	044540	T32L00	047020	T34CON	060710	T35LON	071470	T36DTA	100622
T31LON	045520	T32OPI	052603	T34DAT	060550	T35L00	063444	T36EOT	077005
T31L00	041462	T32PAC	051330	T34DLY	060674	T35L0P	071552	T36LON	077765
T31L0P	045602	T32PK2	051440	T34DSW	060560	T35L0Q	070205	T36L00	073400
T31L0Q	044116	T32PK3	051450	T34EOT	062205	T35L0R	070060	T36L0P	100047
T31LOR	043771	T32RB	051452	T34ET	062116	T35MOT	072503	T36L0Q	076446
T31NEF	046040	T32RES	052700	T34ETC	061157	T35NEF	072010	T36LOR	076321
T31OFL	045065	T32RIB	052136	T34ETN	061451	T35NIN	073056	T36NAS	075734
T31PAC	043170	T32RT2	052772	T34ETO	061002	T35OFL	071035	T36NEF	100305
T31PBP	045664	T32RT3	053022	T34ETS	061530	T35OPM	072672	T36OFL	077332
T31PK2	043300	T32RWN	051700	T34ETZ	061622	T35PAC	067370	T36PAC	075560
T31PK3	043310	T32SCF	052234	T34ET2	061367	T35PBP	071634	T36PBP	100131
T31RB	043312	T32SZ	051456	T34L00	056072	T35PK2	067500	T36PK2	075670
T31RDE	043344	T32TSA	052311	T34OFL	062527	T35PK3	067510	T36PK3	075700
T31RDF	043543	T32WB	051452	T34PAC	060540	T35RB	067512	T36RB	075702
T31RES	046610	T32WDC	052536	T34PK2	060650	T35RDF	067632	T36RDF	076073
T31RN	043326	T33BFR	054572	T34PK3	060660	T35RES	073164	T36RES	100740
T31RNC	044743	T33BF2	054700	T34POS	060714	T35RN	067526	T36RN	075716
T31RRF	043612	T33BOT	055325	T34RB	060662	T35RNC	070713	T36RNC	077210
T31RT2	046702	T33BS0	054700	T34RES	063232	T35RRF	067701	T36RRF	076142
T31RT3	046744	T33BS1	054701	T34RNC	062406	T35RT2	073256	T36RT2	101032
T31RWN	044674	T33CNT	054716	T34RRE	061066	T35RT3	073320	T36RT3	101074
T31SC	043707	T33CNU	054720	T34RSZ	060670	T35RWE	072770	T36RWN	077141
T31SCF	046161	T33CON	054712	T34RT2	063324	T35RWN	070644	T36SC	076237
T31SSR	044177	T33DAT	054560	T34RT3	063366	T35SC	067776	T36SCF	100403
T31SZ	043316	T33DLY	054722	T34RWN	062337	T35SCF	072106	T36SSR	076527
T31S2	043322	T33DSW	054570	T34SSR	062063	T35SSR	072422	T36SZ	075705
T31S3	043324	T33DTA	055550	T34STM	061700	T35SZ	067516	T36S2	075712
T31TIM	043440	T33L00	053076	T34SZ	060666	T35S2	067522	T36S3	075714
T31TM	044617	T33PAC	054550	T34S2	060700	T35S3	067524	T36TIM	076730
T31TRL	043752	T33PK2	054660	T34S3	060702	T35TIM	070433	T36TM	077064
T31TSA	046236	T33PK3	054670	T34TM	062263	T35TM	070567	T36TRL	100217
T31VCK	04303	T33RC	054672	T34TMK	061763	T35TSA	071722	T36TSA	100460
T31WB	043312	T33RBP	054724	T34VCK	062773	T35VCK	071263	T36VCK	077550
T31WDC	045230	T33RES	055662	T34WB	060662	T35V0C	071253	T36WB	075702
T31WDD	045140	T33RN	054706	T34WD	060704	T35WB	067512	T36WDC	077475
T31WDE	044233	T33RT2	055754	T34WDC	062671	T35WDC	071200	T36WDD	077405
T31WDF	044041	T33RT3	056016	T34WDD	062602	T35WDD	071110	T36WDE	076563
T31WDR	043330	T33RWN	055420	T34WDR	060706	T35WDE	070266	T36WDF	076371
T31WNG	043471	T33SSR	055241	T34WSS	063120	T35WDF	070130	T36WDR	075720
T31WNH	043410	T33SZ	054676	T34WTH	061300	T35WDR	067530	T36WNG	076005
T31WRF	046343	T33S2	054702	T35AM3	070766	T35WNG	067544	T36WRF	100542
T31WSS	045431	T33S3	054704	T35BA	071326	T35WRF	072245	T36WSS	077676
T32AM3	051747	T33UNC	055062	T35BFR	067412	T35WSS	071401	T37AM3	103707
T32BA	052063	T33UND	055152	T35BF2	067520	T36AM3	077263	T37BA	104247
T32BFR	051352	T33WB	054672	T35BOT	070340	T36BFR	075602	T37BFR	102262
T32BOE	052366	T33WDC	055467	T35BS0	067520	T36BF2	075710	T37BF2	102370
T32BOT	051516	T33WDR	054710	T35BS1	067521	T36BOT	076635	T37BOT	103261
T32CMD	051460	T33WPW	055002	T35CNT	067536	T36BS0	075710	T37BS0	102370
T32CNT	051510	T34AM3	062461	T35CNU	067540			T37BS1	102371

N1

TSV6 - PARAMETER CODING MACRO M1113 06-FEB-84 18:04
SYMBOL. TABL.

SEQ 2:

T37CNT	102406	T37SSR	103136	T7.4	066444	WSMBK	021350 G	X\$OFFS	= 000400
T37CNU	102410	T37SZ	102366	T8	073344 G	XFERAS	016020	X\$TRUE	= 000020
T37CON	102402	T37S2	102372	T8.1	073400	XNXM	016456	X1.COR	= 020000
T37DAT	102250	T37S3	102374	T8.2	074454	XOPBFO	007752	X1.DLT	= 100000
T37DLY	102412	T37TIM	103354	T9	101120 G	XORFOR	010070	X1.MBZ	= 017375
T37DSW	102260	T37TM	103510	T9.1	101154	XST0	= 000006 G	X1.RBP	= 000400
T37DTA	105246	T37TRL	104643	UAM	= 000200 G	XST1	= 000010 G	X1.SPA	= 040000
T37EOT	103431	T37TSA	105104	UNITN	002174 G	XST2	= 000012 G	X1.UNC	= 000002
T37LON	104411	T37VCK	104174	UNREC	= 000006	XST3	= 000014 G	X2.UF	= 000100
T37LOO	101154	T37WB	102362	USI	004117	XST4	= 000016 G	X2.EXT	= 000200
T37LOP	104473	T37WDC	104121	WAITF	016330 G	XSOBOT	= 000002	X2.OPM	= 100000
T37LOQ	103055	T37WDD	104031	WC.IFA	= 000200	XSOEOT	= 000001	X2.RCE	= 040000
T37LOR	102730	T37WDE	103172	WC.IFE	= 000002	XSOIE	= 000040	X2.REV	= 000077
T37NEF	104731	T37WDF	103000	WC.IGO	= 000001	XSOILA	= 000400	X2.SPA	= 035400
T37OFL	103756	T37WDR	102400	WC.IRE	= 000010	XSOILC	= 001000	X2.UNI	= 000007
T37PAC	102240	T37WNG	102414	WC.IRW	= 000004	XSOLET	= 020000	X2.WCF	= 002000
T37PBP	104555	T37WRF	105166	WC.IOT	= 000100	XSOMOT	= 000200	X3.DCK	= 000010
T37PK2	102350	T37WSS	104322	WC.I1T	= 000040	XSONEF	= 002000	X3.MBZ	= 000006
T37PK3	102360	T4	046770 G	WC.ISR	= 000020	XSOONL	= 000100	X3.MOE	= 177400
T37RB	102362	T4.1	047020	WF.IED	= 000010	XSOPED	= 000010	X3.OPI	= 000100
T37RDF	102502	T4.2	047660	WF.IER	= 000004	XSORLL	= 010000	X3.REV	= 000040
T37RES	105364	T4.3	050470	WF.IHI	= 000200	XSORLS	= 040000	X3.RIB	= 000001
T37RN	102376	T5	053046 G	WF.IRE	= 000040	XSOTMK	= 100000	X3.SPA	= 000200
T37RNC	103634	T5.1	053076	WF.IWF	= 000020	XSOVCK	= 000020	X3.TRF	= 000020
T37RRF	102551	T6	056042 G	WF.IWR	= 000100	XSOWLE	= 004000	X4.HSP	= 100000
T37RT2	105456	T6.1	056072	WF.I3R	= 000002	XSOWLK	= 000004	X4.MBZ	= 017400
T37RT3	105520	T7	063414 G	WF.I4R	= 000001	XXCOM1	003114 G	X4.RCE	= 040000
T37RWN	103565	T7.1	063444	WRCHR	010742 G	X\$ALWA	= 000000	X4.TSM	= 020000
T37SC	102646	T7.2	064522	WRTERR	005107	X\$FALS	= 000040	X4.WRC	= 000377
T37SCF	105027	T7.3	065602	WRTMSG	005052				

. ABS. 106404 000
000000 001

ERRORS DETECTED: 0

VIRTUAL MEMORY USE): 30328 WORDS (119 PAGES)
DYNAMIC MEMORY: 20614 WORDS (79 PAGES)
ELAPSED TIME. 00:43:58
CVTSDB, CVTSDB, SEQ/-SP=SVC/ML, TSV1D, TSV22D, TSV3B, TSV4, TSV7B, TSV6

TEST 9: FUNCTION TI....B1
TEST 9: FUNCTION TI....C1
TEST 9: FUNCTION TI....D1
TEST 9: FUNCTION TI....E1
TEST 9: FUNCTION TI....F1
TEST 9: FUNCTION TI....G1
TEST 9: FUNCTION TI....H1
SOFTWARE PARAMETER C....I1
SYMBOL TABLEJ1
SYMBOL TABLEK1
SYMBOL TABLEL1
SYMBOL TABLEM1
SYMBOL TABLEN1